

OPERATOR'S MANUAL

Original instructions

TB260

Serial No. 126000002~

TB260

Serial No. 126100003~

Book No. AQ0E007

OETB260_A-XH

MINI EXCAVATOR

TAKEUCHI



WARNING Read and understand these instructions.
Failure to do so can cause injury or death.

SAFETY ALERT SYMBOL




This symbol represents the safety alert. The message that follows the symbol contains important information about safety.

Read and understand the message to avoid personal injury or death.

It is the owner or employer's responsibility to fully instruct each operator in the proper and safe operation of all equipment. All persons using this machine should thoroughly familiarize themselves with the contents of this manual.

All operators must be instructed on the proper functions of the excavator before running the machine.

Learn and practice correct use of the machine controls in a safe, clear area before operating this machine on a job site.



Improper operation, inspection and maintenance of this machine can cause injury or death.

Read and understand this manual before performing any operation, inspection or maintenance on this machine.

Always store this manual near at hand preferably on the machine itself. If it should be lost or damaged, immediately order a new one from your Takeuchi dealer. When transferring ownership of this machine, be sure to hand this manual to the next owner.

Takeuchi supplies machines complying with the local regulations and standards of the country of export. If your machine has been purchased in another country or from a person or company of another country, it may not have the safety devices or safety standards required for use in your country. Should you have any question about whether your machine complies with the regulations and standards of your country, contact a Takeuchi dealer.

SIGNAL WORDS

Safety messages appearing in this manual and on machine decals are identified by the words “DANGER”, “WARNING” and “CAUTION”. These signal words mean the following:



DANGER

DANGER indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.



WARNING

WARNING indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.



CAUTION

CAUTION indicates a hazard with a low level of risk which, if not avoided, could result in minor moderate injury.

IMPORTANT: The word **IMPORTANT** is used to alert operators and maintenance personnel about situations which could result in damage to the machine and its components.

It is impossible to foresee every possible circumstance that might involve a potential hazard. The warnings in this manual or on the machine can not cover all possible contingencies. You must exercise all due care and follow normal safety procedures when operating the machine so as to ensure that no damage occurs to the machine, its operators or other persons.

INTRODUCTION

FOREWORD


This manual describes operation, inspection and maintenance of the machine, as well as safety instructions to be heeded during these operations.

If you have any questions about the machine, please contact a Takeuchi sales or service outlet.


MANUAL STORAGE COMPARTMENT

A compartment for storing this manual is provided at the position shown on the diagram below.

Cabine



Canopy




1. Insert the ignition key and turn it counterclockwise to open the cover (1).
2. After using the manual, place it in the plastic pouch and store it back in the manual storage compartment.

SERIAL NUMBERS


IMPORTANT: Do not remove the machine name plate with the serial number. Check the serial numbers of the machine and engine and write them down in the spaces below.

Machine number:




Engine number:

<Applicable machine models 126000002 or later>




<Applicable machine models 126100003 or later>



MACHINE DESCRIPTION

FRONT, REAR, LEFT AND RIGHT



This manual refers the front, rear, left and right of the machine as seen when sitting in the operator's seat with the dozer blade visible to the front.

DESIGNATED OPERATIONS

Use this machine primarily for the following operations:

- Excavation
- Digging ditches
- Digging side ditches
- Leveling
- Loading

FEATURES

- Adopting the auto-idle enables less fuel consumption
- Equipping the auxiliary 1st and 2nd lines with a flow rate control mechanism
- Configuring the auxiliaries of 2nd, 3rd (high-pressure type) and 4th.
- Legible instrument cluster with a 5-inch color LCD
- Smaller rear slew radius, smaller turns (stability is retained)
- Installing the ROPS certified large cab (with front sash assist)
- Adopting the larger engine hood and right side cover allows easier maintenance
- Optional angle dozer blade with a float

BREAK-IN PERIOD

When the machine is new, operate the machine for the first 100 hours (as indicated on the hour meter) by following the instructions below.

Using a new machine without a break-in period will lead to quicker deterioration of machine performance and may shorten the machine's service life.

- Sufficiently warm up the engine and hydraulic oil.
- Avoid heavy loads and rapid operations. Operate with a load of about 80% the maximum load.
- Do not abruptly start up, accelerate, change directions, or stop unless necessary.

NOTES ON READING THIS MANUAL

Please note that the descriptions and diagrams included in this manual may not be applicable to your machine.

The numbers used in the illustration are with circles around them. The same numbers appear between the parentheses in the text.
(Example: ① → (1))

Symbols used in this manual

The symbols used in this manual have the following meanings.

 ,  Prohibition

 Lock

 Unlock

CONTENTS

Introduction	0-2
---------------------------	------------

Machine description	0-3
----------------------------------	------------

Safety	1-1
---------------------	------------

General precautions	1-2
Precautions when preparing	1-8
Precautions when starting	1-12
Precautions when operating	1-14
Precautions when stopping	1-23
Precautions when transporting	1-24
Precautions on maintenance	1-26
Safety signs (decals)	1-35

Controls	2-1
-----------------------	------------

Names of components (Canopy)	2-2
Names of components (Cab)	2-4
Covers	2-6
Starter key	2-6
Right side cover	2-6
Engine hood	2-7
Left side cover	2-7
Fuel lid	2-8
Fuel filler port	2-8
Fuse box cover	2-9
Cab	2-10
Cab door	2-10
Emergency exit	2-10
Front window	2-11
Lower front window	2-12
Side window	2-12
Emergency hammer (optional)	2-13
Sun shade	2-13
Seat and seat belt	2-14
Seat	2-14
Seat belt	2-15
Multi-information display	2-16
Main Menu screen	2-16
Warning lamps	2-17
Indicators	2-18
Screen control key	2-21
Screen navigation	2-22
Switching images	2-27
Instrument cluster	2-28
Warning lamps	2-28
Indicators	2-29
Meters	2-29
Multi-data display	2-30
Switches	2-48

Starter switch	2-48
Engine shutdown switch	
<Applicable machine models 126100003	
or later>	2-48
Throttle controller	2-48
Horn button	2-49
Deceleration button	2-49
Travel speed button	2-49
Auxiliary 1st switches	2-50
Auxiliary 2nd/4th switch (If equipped)	2-50
Third auxiliary hydraulic switch and	
button (If equipped)	2-51
Auxiliary 2/4 select button	
(If equipped)	2-51
DPF manual regeneration/inhibit select	
switch	
<Applicable machine models 126100003	
or later>	2-52
Light switch	2-54
Wiper switch	2-54
Washer switch	2-54
Automatic deceleration switch	2-55
Power/Highland mode switch	2-55
Detent mode switch	
(Auxiliary 1st) (If equipped)	2-56
Auxiliary 1st auto tank switch	
(If equipped)	2-56
Lift overload warning switch	
(If equipped)	2-57
Beacon lamp switch (If equipped)	2-57
Levers and Pedals	2-58
Safety lock lever	2-58
Operating levers	2-58
Blade lever	2-59
Travel levers/pedals	2-60
Boom swing pedal	2-60
Accessories	2-62
Air conditioner (If equipped)	2-62
Cup holder	2-67
Ashtray	2-68
Power supply socket	2-68
Interior light	2-69
Mirrors	2-69
External power sockets	2-70
Radio (for cab)	2-72
Auxiliary hydraulic lines (If equipped) ..	2-76
Operating the machine with an	
accumulator	2-81
Load safety device (If equipped)	2-82
Fuel supply pump (If equipped)	2-84

Operation 3-1

Before starting operation	3-2
Getting on or off the machine.....	3-2
Walk-around inspection	3-2
Daily inspection.....	3-2
Starting and stopping the engine	3-3
Before starting the engine	3-3
Starting the Engine	3-4
Warming up the engine.....	3-5
Stopping the engine	3-5
Operating the machine	3-6
Lever pattern (ISO pattern).....	3-6
Lever pattern (G pattern) (If equipped) ..	3-7
Warming up the machine (hydraulic oil) ..	3-8
Inspection after warm-up	3-9
Operating the travel levers/pedals	3-10
Stopping travel	3-13
Operating the working equipment	3-14
Operating procedures.....	3-16
Prohibited operations.....	3-16
Cautions on operating	3-19
Cautions on traveling on slopes	3-20
Getting out of mud	3-22
Operations possible with this machine.....	3-22
Parking the machine.....	3-24
Parking.....	3-24
Inspection and checks after stopping the engine.....	3-24
Handling in cold climates.....	3-25
Preparing for cold climates	3-25
Cautions after operations.....	3-25
After the cold climate	3-25
Handling rubber crawlers.....	3-26
Prohibitions.....	3-26
Cautions.....	3-27
Preventing the rubber crawlers from coming off	3-27

Transport 4-1

Loading and unloading	4-2
Hoisting the machine	4-4
Securing the machine	4-6

Maintenance 5-1

General.....	5-2
Maintenance overview	5-2
Cautions on maintenance	5-2
Service data	5-4

Fuel and lubricant table.....	5-4
Regularly replace the hydraulic oil	5-8
List of consumables.....	5-9
List of tools (If equipped).....	5-10
List of tightening torques	5-11
Safety-critical parts	5-12
Maintenance list.....	5-14
Walk-around inspection	5-16
Inspecting by opening the engine hood and covers.....	5-16
Inspecting by walking around the machine.....	5-17
Inspecting while sitting in the operator's seat	5-17
Daily inspection (every 10 hours).....	5-18
Inspecting and replenishing the coolant	5-18
Inspecting and replenishing the engine oil	5-19
Inspecting the water separator	5-20
Inspecting the fuel level.....	5-21
Inspecting the hydraulic oil tank level and replenishing	5-22
Lubricating the working equipment	5-23
After the initial 50 hours (only for new machines)	5-24
Replacing the engine oil and the oil filter	5-24
Inspecting and adjusting the fan belt..	5-26
Inspecting and adjusting the compressor belt (AC)	5-27
Every 50 hours	5-28
Inspecting and adjusting the crawler tension	5-28
Lubricating the slew bearing	5-30
Draining the water from the fuel tank..	5-30
Inspecting the battery fluid level and replenishing	5-31
Every 100 hours	5-33
Cleaning the water separator <Applicable machine models 126000002 or later>	5-33
After the initial 250 hours (only for new machines)	5-34
Replacing the hydraulic oil return filter ..	5-34
Replacing the pilot line filter.....	5-35
Replacing the travel motor gear oil.....	5-36
Every 250 hours	5-37
Replacing the engine oil and the oil filter	5-37

Inspecting and adjusting the fan belt..	5-37
Inspecting and adjusting the compressor belt (AC)	5-37
Cleaning the air cleaner	5-38
Cleaning the radiator fins and the oil cooler fins	5-39
Cleaning the air filters (AC)	5-40
Cleaning the condenser (AC)	5-41
Inspecting the refrigerant (gas) level (AC)	5-42
Every 500 hours	5-44
Replacing the fuel filter.....	5-44
Replacing the water separator filter	5-45
Every 1000 hours	5-46
Replacing the hydraulic oil return filter	5-46
Replacing the pilot line filter.....	5-46
Replacing the travel motor gear oil.....	5-46
Cleaning the engine cooling system...	5-46
Replacing the air cleaner element	5-48
Replacing the air breather filter	5-49
Inspecting and adjusting the engine valve clearance	5-49
Inspecting the engine compression pressure	5-49
Inspecting and cleaning the engine starter and the alternator	5-49
Every 1500 hours	5-50
Inspecting, cleaning and checking operation of the engine fuel injectors <Applicable machine models: 126000002 or later>	5-50
Inspecting the crankcase breather system.....	5-50
Cleaning the EGR cooler (cleaning the water side and exhaust air passage blower) <Applicable machine models: 126100003 or later>	5-50
Every 2000 hours	5-51
Lapping the engine valve seats	5-51
Every 3000 hours	5-52
Inspecting the turbocharger (blow wash as necessary)	5-52
Inspecting, cleaning and checking operation of the EGR valve <Applicable machine models: 126100003 or later>	5-52
Cleaning the EGR lead valve <Applicable machine models: 126100003 or later>	5-52

Inspecting and cleaning the DPF soot filter <Applicable machine models: 126100003 or later>	5-52
Inspecting the operation of the air intake throttle valve	5-52
Inspecting and cleaning the injector <Applicable machine models: 126100003 or later>	5-52
Every 4000 hours	5-53
Replacing the hydraulic oil and cleaning the suction strainer	5-53
When required	5-56
Replacing the bucket teeth and the side cutters	5-56
Replacing the bucket	5-58
Adjusting the gap between the bucket and arm (If equipped).....	5-60
Inspecting and replenishing the windshield washer fluid	5-61
Draining the water from the water separator	5-61
Lubricating the levers and pedals.....	5-62
Inspecting the rubber crawlers.....	5-63
Replacing the rubber crawlers	5-64
Every 2 years.....	5-66
Replacing the receiver dryer.....	5-66
Maintenance during extended storage period.....	5-67

Troubleshooting 6-1

Symptoms that are not malfunctions	6-2
If the engine overheats.....	6-3
If the battery goes dead	6-4
If a fuse blows	6-6
Inspecting and replacing the fuse.....	6-6
Inspecting the fusible link	6-7
Restarting after adding fuel	6-8
Bleeding air from the fuel system	6-8
If a warning lamp flashes	6-10
Vehicle error code list.....	6-12
Engine error code list.....	6-14
Other symptoms.....	6-22
Lowering the boom to the ground	6-25
Towing.....	6-26
If the cab or canopy is damaged	6-27

Specifications 7-1

Basic Specifications.....	7-2
Machine dimensions.....	7-4
Operating ranges.....	7-6

Lifting Capacities	7-9
--------------------------	-----

Options 8-1

General precautions	8-2
Safety precautions	8-2
Cautions when installing attachments ..	8-2
Cautions when operating attachments ..	8-3
Attachment combination table	8-4
Selecting a lever pattern	8-5
Switching the lever pattern	8-5
Hydraulic breaker	8-6
Cautions on operating	8-6
Replacing the hydraulic oil regularly	8-7
Travel alarm	8-8
Optional equipment mass	8-9
Biodegradable oil.....	8-10
Replacing the hydraulic oil with biodegradable oil	8-10
Cab options.....	8-11
Angle dozer blade <Applicable machine models 126100003 or later>	8-12
Specifications	8-13
Operating lever switch kit 1.....	8-14
Horn button.....	8-14
Deceleration button	8-14
Travel speed button	8-14
Auxiliary 1st switches.....	8-15
Auxiliary 2nd/4th switch.....	8-15
Auxiliary 2/4 select button.....	8-16





GENERAL PRECAUTIONS

It is your responsibility to observe all pertinent laws and regulations and to follow the manufacture's instructions on machine operation, inspection and maintenance.

Virtually all accidents occur as the result of a failure to observe basic safety rules and precautions.

Most accidents can be prevented by identifying the potentially hazardous situations beforehand.

Read and understand all safety messages which describe how to prevent accidents.

Do not operate the machine until you are sure that you have gained a proper understanding of its operation, inspection and maintenance.

Observe all safety rules

- Operation, inspection and maintenance of this machine must be performed only by a trained and qualified person.
- All rules, regulations, precautions and safety procedures must be understood and followed when performing operation, inspection and maintenance of this machine.
- Do not perform any operation, inspection and maintenance of this machine when under the adverse influence of alcohol, drugs, medication, fatigue, or insufficient sleep.

When a problem is found on the machine

If any problem (noise, vibration, smell, disorder of instrument, smoke, oil leak, wrong indication of alarm or unusual indication in the instrument cluster, etc.) is detected during the operation or inspection and maintenance of the machine, immediately inform your sales or service dealer and take proper actions. Do not operate the machine until the trouble is cleared.


Operating temperature range

To maintain the performance of machine and to prevent it from early wear, observe the following operating conditions.


- Do not operate the machine if the ambient temperature is higher than +45°C (+113°F) or lower than -15°C (+5°F).
 - If operated at an ambient temperature of higher than +45°C (+113°F), the engine may overheat and cause the engine oil to degrade. Also, the hydraulic oil may become very hot, causing damage to the hydraulic equipment.
 - If operated at an ambient temperature of lower than -15°C (+5°F), the parts made of rubber such as gaskets may get hardened to cause an early wear or damage to the machine.
 - If the machine is to be used outside the ambient temperature range described above, consult your sales or a service dealer.

**GENERAL PRECAUTIONS****Wear appropriate clothing and protective equipment**


- Do not wear loose clothing or any accessory that can catch on controls or in moving parts.
- Do not wear oily or fuel stained clothing that can easily catch fire.
- Wear a hard hat, safety shoes, safety glasses, filter mask, heavy gloves, ear protection and other protective equipment as required by job conditions. Wear required appropriate equipment such as safety glasses and filter mask when using grinders, hammers or compressed air, as metal fragments or other objects can fly and cause serious injury.
- Use hearing protection when operating the machine. Loud prolonged noise can cause hearing impairments, even the total loss of hearing.

Install a fire extinguisher and first aid kit**Be prepared for fire and accidents**

- Install an extinguisher and a first aid kit, and learn how to use them.
- Learn how to fight a fire and how to deal with accidents.
- Know how to contact emergency assistance and make a list of emergency contacts.


Never remove safety equipment

- Make sure all protective guards, covers and doors are in place and secured. Repair or replace damaged parts before operating the machine.
- Know how to use the safety lock lever, seat belt and other safety equipment and use them properly.
- Never remove any safety equipment except for servicing. Keep all safety equipment in good operating condition.

**GENERAL PRECAUTIONS****Use a signal person and a flag person**

Learn how to use the hand signals required for particular jobs and make sure who has the responsibility for signaling.

- All personnel must fully understand all the signals.
- The operator must respond to signals only from the appointed signal person, but must obey a stop signal at any time from anyone.
- The signal person must stand in a clearly visible location when giving signals.


Cautions when standing up from or leaving the operator's seat

- Before standing up from the operator's seat to open/close the window or remove/install the lower window, lower the working equipment to the ground, raise the safety lock levers to engage the lock and stop the engine. If any controls should be accidentally touched when the safety lock levers is lowered (unlocked), the machine will suddenly move and cause serious injury or death.
- Be careful not to touch the operating levers when raising or lowering the safety lock levers.
- Before leaving the operator's seat, lower the working equipment to the ground, raise the safety lock levers to engage the lock and stop the engine. Also, be sure to remove the key, lock the door and covers, take it with you and store it in a specified place.

**GENERAL PRECAUTIONS****Avoid fire and explosion hazards**

Keep flames away from fuel, oil, grease and antifreeze. Fuel is particularly flammable and dangerous.

- When handling these combustible materials, keep lit cigarettes, matches, lighters and other flames or sources of flames away.
- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Do not leave the location while refilling with fuel or oil.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Also, do not spill the fuel on the hot surface of the machine or the component of the electric system.
- Clean up spilled fuel or oil immediately.
- Check for fuel, oil leak. Stop all leaks and clean the machine before operating.
- When operating with grinder or welding, move inflammables to a safe place.
- Do not cut or weld on pipes or tubes that contain flammable fluids. Clean thoroughly with nonflammable solvent before cutting or welding.
- Remove all trash or debris from the machine. Make sure that oily rags or other flammable material are not stored on the machine.
- Handle all solvents and dry chemicals (foam type fire extinguisher) according to procedures identified on manufacturer's containers. Work in a well-ventilated area.
- Never use fuel for cleaning purposes. Always use a nonflammable solvent.
- When handling the fuel, washing oil or paint, open the door and windows to ventilate thoroughly.
- Store all flammable fluids and materials in a safe and well-ventilated place.
- The short circuit of the electric system may cause the fire. Check for any loosened connections or damage to the wires every day. Retighten the loosened connector and wire clamp. Fix or change the damaged wire.
- Fire from the pipes:
Make sure that the clamps, guards and cushions of the hoses and tubes are securely fixed. If not, hoses or tubes may be damaged due to vibration or contact with other parts during operation. This can cause the high-pressure oil to spurt out, resulting in the fire or injury.
- Do not perform the DPF regeneration if the machine is surrounded by flammable items such as plants, trees, dry grass, wastepaper, oil and waste tires. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF.
DPF: Diesel Particulate Filter
<Applicable machine models 126100003 or later>

**GENERAL PRECAUTIONS****Exhaust fumes from the engine is poisonous**

- Do not operate the engine in an enclosed area without adequate ventilation.
- If natural ventilation is not possible, install ventilators, fans, exhaust extension pipes or other venting devices.
- Do not perform the DPF regeneration in poorly-ventilated indoor spaces, as smoke may be generated during the regeneration.

Be careful not to get crushed or cut

Never put your hands, feet or other parts of your body between the upperstructure and the undercarriage or tracks, between the machine body and working equipment, or between a cylinder and moving part. The sizes of these gaps change when the machine moves, and a person can suffer severe injury or death.

Handling asbestos dust

Inhaling asbestos dust can cause lung cancer. When handling the materials which may contain asbestos, take the following precautions:

- Never use compressed air for cleaning.
- Avoid brushing or grinding parts containing asbestos.
- For clean up, use a vacuum equipped with a high efficiency particulate air filter (HEPA).
- Wear the stipulated respirator if there is no other way to control the dust. When working indoors, install a ventilation system with a macromolecular filter.
- Do not allow unauthorized personnel in the work area while working.
- Follow the rules and environmental standard applicable to the work area.

**GENERAL PRECAUTIONS**

Using optional products

- Consult with Takeuchi before installing optional attachments. Depending on the type of attachments or the combination of them, the attachment may come into contact with the operator's compartment or the other parts of the machine. Make sure that the optional attachment installed is not contacted with other parts before use.
- Do not use attachments that have not been approved by Takeuchi. Doing so may compromise safety or adversely affect the machine's operation or service life.
- Takeuchi will not be held responsible for any injuries, accidents or damage to its products caused by the use by a non-approved attachment.

Never modify the machine

Unauthorized modifications to this machine can cause injury or death. Never make unauthorized modifications to any part of this machine.




PRECAUTIONS WHEN PREPARING

Know the work area

Before starting operation, know the working area condition to ensure a safety operation.

- Inspect the topography and ground condition of the working area, or the structure of the building when working indoors, and take the safety precautions as necessary.
- Be sure to avoid all hazards and obstructions such as ditches, underground lines, trees, cliffs, overhead electrical wires, or places where there is a danger of falling rocks or slides.



- Check with the administrator for the locations of buried gas pipes, water pipes and power cables. If necessary, determine what specific precautions must be taken to insure safety by consulting with the administrator.
- When working on roads, be sure to consider the safety of pedestrians and vehicles.
 - Use a flag person and/or a signal.
 - Fence off the working area and keep off unauthorized persons.
- When working in water or crossing shallow streams or creeks, check the depth of the water, the solidity of the ground and the water flow speed beforehand. Refer to "Cautions on operating" for further instructions.

<Applicable machine models 126100003 or later>




- Do not perform the DPF regeneration if the machine is surrounded by flammable items such as plants, trees, dry grass, wastepaper, oil and waste tires. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF. DPF: Diesel Particulate Filter
- The DPF may automatically perform the regeneration while the engine is left running. Make sure that there are no flammable items around the DPF and the exhaust line, and also that the engine hood is closed to prevent fire. Be careful not to burn yourself on the high-temperature exhaust gas.
- Do not perform the DPF regeneration in poorly-ventilated indoor spaces, as smoke may be generated during the regeneration.




Check the strength of the bridge


When traveling over a bridge or a structure, check the permissible load. If the strength is insufficient, reinforce the bridge or the structure.



Always keep the machine clean



- Clean windows, mirrors and lights to ensure good visibility.
Adjust the mirror to the best position for the operator to see the rear view (blind spot) from the operator's seat.
- Wipe off any oil, grease, mud, snow or ice, to prevent accidents due to slipping.
- Remove all loose objects and unnecessary devices from the machine.
- Remove any dirt, oil or grease from the engine area to prevent fires.
- Clean around the operator's seat and remove any unnecessary object from the machine.

**PRECAUTIONS WHEN PREPARING****Perform inspection and maintenance every day**

Failure to identify or repair the irregularities or damage on machine can lead to accidents.

- Before operating, perform the specified inspection and make prompt repairs where necessary.
- If a failure occurs and the operation becomes impossible or the engine fails, immediately stop the machine by following the shutdown procedure, and keep machine securely parked until the malfunction is corrected.


Cautions in the operator's compartment

- Remove mud and grease from shoe soles before entering the operator's compartment. Pedaling the machine with the shoes with mud and grease will cause a slip accident.
- Do not leave the parts or tools around the operator's seat.
- Do not leave any plastic bottles in the operator's compartment or attach any suction cups on the window glass. The plastic bottle or suction cup act as a lens and can cause fire.
- Do not use the mobile phone during traveling or working.
- Do not bring combustibles or explosives into the operator's compartment.
- After smoking, be sure to tightly close the lid of the ashtray to put out the match or cigarette.
- Do not leave the cigarette lighter in the operator's compartment. When the room temperature rises, the lighter may explore.




Emergency exit

Front window (excluding machines with a front guard)



If you should become trapped inside the cab, open the front window to get out.

Emergency hammer (optional)



An emergency hammer is installed to be used to escape from the cab in an emergency. When escaping, break the windows with the hammer.

- When breaking the window pane with a hammer, take great care not to injure yourself with the broken glass pieces.
- Remove the glass pieces from the window sill so as not to cut yourself when evacuating. Broken glass will fall from the window, so be careful of your footing and do not slip on the glass.



PRECAUTIONS WHEN STARTING

Support your weight in a three point secure stance when getting on/off the machine

- Do not jump on or down from the machine. Never attempt to get on or off the moving machine.
- When getting on or off the cab, first fully open the door to the locked position and check that it does not move (for machines with cab).



- Climb up/down the steps facing the machine and holding the handrail to support your weight in a three point secure stance (hand and feet).
- Never use the safety lock lever or control levers as hand holds.

Before starting the machine, ask any unauthorized personnel to leave the area

Do not start the engine until you are sure it is safe to start the machine by checking the following items.

- Walk around the machine and warn the person who is servicing the machine or is walking near the machine. Do not start the machine until you are certain that no one is around the machine.




- Check if there is a “DO NOT OPERATE” alert sign or similar sign is on the cab door, controls or starter switch. If there is one, do not start the engine or touch any levers.
- Sound the horn to warn people around the machine.

Sit in the operator's seat and start the engine

- Adjust the seat to securely latch it.



- Fasten the seat belt.
- Check if the parking brake is on and all control levers and pedals are in the neutral position.
- Check if the safety lock lever is in the lock position.
- Make sure that no one is near the machine.
- Start and operate the machine only from the operator's seat.
- Never attempt to start the engine by shorting across the starter terminals.

**PRECAUTIONS WHEN STARTING****Starting with jumper cables**

Use jumper cables only in the recommended manner. Improper use of jumper cables can result in battery explosion or unexpected machine motion.

Refer to “If the battery goes dead” for further instructions.

After starting the engine

After starting the engine, perform the operations and checks described below in a safe place with no persons or obstacles in the area. If any malfunction is found, follow the shutdown procedure and report the malfunction.

- Warm up the engine and hydraulic oil.
- Check if all gauges and warning devices are properly working.
- Check for any noises.
- Test the engine speed control.
- Operate each control to ensure they are properly working.

In cold climates

- Be careful of slippery conditions on freezing ground, steps and hand holds.
- In severe cold climates, do not touch any metal parts of the machine with bare hands. The skin will freeze to the metal, resulting in severe injury.
- Do not use ether or starting fluid on this engine. The starting fluids can cause explosion and serious injury or death.
- Warm up the engine and hydraulic oil. If the levers are operated without warming, the machine will not react or move promptly or properly, resulting in accident.



PRECAUTIONS WHEN OPERATING

Ensure good visibility


- When working in dark places, turn on the machine's working lights and headlights and additional lighting equipment installed, as necessary.
- When visibility is poor due to bad weather (fog, snow, rain or a cloud of dust), stop operating the machine and wait until visibility improves.

Do not permit riders on the machine



Do not allow anyone to ride on any part of the machine at any time while traveling or operating.

Check if the work area is safe and secure before operation




- Confirm the performance limits of the machine.
- Use a signal person at road shoulders, narrow places or where your vision is obstructed.
- Never allow anyone to enter the machine's slewing radius and path.
- Signal your intention to move by sounding the horn.
- There is a blind spot in the rear of the machine. Before traveling in reverse, check that the area is safe and clear.

Safety precautions when performing the DPF regeneration


The DPF may automatically perform the regeneration while the engine is left running. Make sure that there are no flammable items around the DPF and the exhaust line, and also that the engine hood is closed to prevent fire. Be careful not to burn yourself on the high-temperature exhaust gas.

DPF: Diesel Particulate Filter

<Applicable machine models 126100003 or later>

**PRECAUTIONS WHEN OPERATING****Check the position of the undercarriage (tracks) before traveling**


Before operating the travel levers/pedals, make sure that the dozer blade is to the front of the operator's seat. Remember that when the dozer blade is to the rear of the operator's seat, the travel levers/pedals must be operated in the reverse direction from when it is to the front.

Travel safely

- Travel with the dozer blade raised, the hoe attachment folded as shown on the figure above, and the bucket raised 30 to 40 cm (12 to 16 in.) above the ground.
- Do not slew while traveling. If you must operate the hoe attachment while traveling, operate at speeds slow enough so you have complete control at all times.
- When a load greater than a set value is applied during traveling in 2nd (high) speed, the speed will automatically slow down to 1st (low) speed. When the load becomes lighter, the speed will increase and return to 2nd (high) speed. It should be

noted that the travel speed changes depending on the load condition (for machines with the automatic travel shift-down system).

- When traveling on the uneven road or sharp slope, turn off the deceleration switch and the auto-deceleration switch. If the machine is operated on such roads with these switches turned on, the engine speed may increase, causing the machine to travel unexpectedly rapidly (for machines with the deceleration and auto-deceleration switches).





- Avoid crossing over obstacles whenever possible. If you must do so, keep the hoe attachment close to the ground level and travel slowly. Never cross obstacles which will tilt the machine to an angle of 10° or greater.
- On uneven ground, maintain the low speed and avoid starting, stopping or changing directions abruptly. Otherwise, the working equipment may come in contact with the ground, causing the machine to lose its balance and get damaged or to damage the structures in the surrounding area.

**PRECAUTIONS WHEN OPERATING****Cautions on traveling on slopes**


When traveling on slopes or grades, be careful that the machine does not tip (roll) over or slide.

- Never travel on slopes that are too steep for the machine to maintain its stability (maximum gradeability: 30°, lateral tipping angle: 15°). Note that in reality, the machine's stability becomes lower than the above values depending on the working condition.



- When climbing a hill, keep the operator's seat facing the hillside. When descending a hill, keep the operator's seat facing the downhill direction. In either case, travel must be done while paying attention to the ground in front of the machine.
- When traveling on slopes, lower the bucket to a height of 20 to 30 cm (8 to 12 in.) above the ground. When climbing a steep slope, extend the hoe attachment to the front. In emergencies, lower the bucket to the ground and stop the machine.


- When traveling on slopes or grades, drive slowly in 1st (low) speed. When descending a slope, slow down the engine speed.
- Do not descend slopes in reverse.



- Do not change directions on slopes or traverse slopes. First return to a flat surface, and then take an alternative path.
- The machine may slip sideways even on a slight slope if the ground is covered with grass or dead leaves, or when traveling on a wet metal plate or frozen surfaces. Make sure the machine is never positioned sideways on slopes.
- If the machine is stalled on the slope, return each operating lever to the neutral position before restarting the engine.


**PRECAUTIONS WHEN OPERATING****Operate the machine on snow or ice with extra care**

- When traveling on snow or on frozen surfaces, drive at a low speed and avoid starting, stopping or changing directions abruptly.
- In the snowy area, the road shoulder and objects placed beside the road are buried in the snow and cannot be seen. There is a hazard of the machine tipping over or hitting covered objects, so always carry out operations carefully.
- If the machine enters deep snow, there is a hazard that it may tip over or become buried in the snow.
Be careful not to drive beyond the road shoulder or to get trapped in a snow drift.
- With frozen ground surfaces, the ground becomes soft when the temperature rises, and this may cause the machine to tip over, resulting in an operator trapped inside the machine.
- When parking the machine on an unstable ground, lower the dozer blade.

Ensure driver's safety when loading

Do not load a truck unless the truck driver is in a safe place.

- Never swing or position the bucket over a person or the cab room.
- Load the truck from the rear.


Do not move the bucket over the heads of people

Moving the bucket over the heads of people entails the danger of the load spilling or the sudden dropping of the bucket.


**PRECAUTIONS WHEN OPERATING****Keep a safe distance from the overhead high-voltage cables**

Never bring any part of the machine or loaded material to near to the high voltage cables unless all safety precautions required by the local and national authorities have been installed. If a person comes near to the machine that is discharging sparks or located near to or in contact with the power source, there is a hazard of electric shock and death.


- Always maintain a safe distance between the machine and the high-voltage electric cable.
- Check with the local power company about safe operating procedure before starting operations.
- Consider all cables to be high-voltage cables and treat all cables as energized even though it is known or believed that the power is shut off and the cables are visibly grounded.
- Use a signal person to give warning if the machine approaches too close to the high-voltage electric cables.
- Caution all personnel in the work area not to come close to the machine or the loaded material.




- Pay also careful attention to the high-voltage electric cables buried underground.

**PRECAUTIONS WHEN OPERATING****Watch out for hazardous working conditions**


- Never undercut a high bank. Doing so is dangerous as it may cause ground collapse.
- Do not operate in places where there is a danger of falling rocks.




- Maintain a safe distance between the machine and the edge of the digging site. Do not dig the ground under the front of the machine.
- When working close to the cliffs or road shoulders, to make it easier to escape if there is any problem, set the crawlers at right angles to the cliff or road shoulder and the dozer blade to the front when carrying out operations.




- Do not enter areas where there is soft ground. Doing so could cause the machine to tilt under its own weight, resulting in a machine tipping over or sinking into the ground.




- Do not come close to unstable grounds (cliffs, road shoulders, deep ditches). If the ground should collapse under the weight or vibration of the machine, there is a hazard that the machine may fall or tip over.
 - Remember that the soil after heavy rain or blasting is weak.
 - The ground of top of the embankment and of the circumferences of the excavated ditches are also weak.

**PRECAUTIONS WHEN OPERATING**

- Do not perform demolition work under the machine. There is a hazard that the machine may fall down, because the ground becomes unstable.
- When working on or from the top of buildings or other structures, check the strength and the structure before starting operations. If a building or structure collapses, serious injury or damage will result.



- When doing demolition work, do not perform demolition above your head. There is a hazard of broken parts falling or of the building collapsing and causing serious injury or damage.




- Do not use the impact force of the hoe attachment for breaking work. There is a hazard of serious injury being caused by flying pieces of broken materials and by the damaged hoe attachment.

Be careful with flying objects


This machine is not equipped with protective equipment to protect the operator from flying objects. Do not use this machine in places where there are risks of the operator being hit by flying objects.

**PRECAUTIONS WHEN OPERATING****Operating on slopes is dangerous**


When operating on slopes or grades, slewing or operation of working equipment may cause the machine to lose stability and tip over. Avoid operating on slopes whenever possible.



- Level off the work area.




- Avoid slewing to the downhill direction with the bucket full of loaded material. This will reduce the stability of the machine and may result in tipping over.

Never slew (swing) sideways with a heavy load

The machine can tip over more easily in the lateral direction than in the longitudinal direction.

- Do not slew (swing) sideways with a heavy load at the tip of the hoe attachment. In particular, do not slew (swing) sideways on slopes.
- The tip of the attachment is heavier for machines equipped with breakers, crushers or long arms than for machines equipped with the standard bucket. For such machines with heavier tips, do not perform excavation with the digging arm (boom) facing the downhill direction or operate toward sideways.

Be careful with the overhead objects


When operating under bridges, in tunnels, near electric cables or indoors, be careful not to let the boom or arm hit overhead objects.

**PRECAUTIONS WHEN OPERATING****Excavators are not designed for lifting loads**

AG7A054

This machine is specifically designed for excavation work. Therefore, it has no safety equipment for crane operation. Extreme caution should be paid if the excavator is used for lifting.

- Never lift loads in excess of capacity. Overload will cause the machine to roll and can result in serious injury or death.
- All rated lift capacities are determined by using a machine placed on a stable and flat ground. For a safe lifting work, the user is expected to make due allowance for the particular job conditions. They include, soft or uneven ground, non-level condition, side loads, dynamic or jerked loads, hazardous conditions, and experience of personnel. The operator and other personnel should fully acquaint themselves with the operator's manual before operating this machine, and rules for safe operation of equipment shall be adhered to at all times.
- The bucket linkage or lifting device may fail if chains or lifting device are incorrectly attached, resulting in serious injury or death.
- Do not attempt to pull stumps out of the ground when using the machine as a crane. The loads imposed on the machine under this use are completely unknown.
- Do not allow anyone to stand on or under the lifted loads or come close to the work area.

Cautions when towing


When towing, serious injury or death could result, if performed incorrectly or the wire rope being used is inappropriate or not properly inspected.

- Do not tow using only a towing hole on one side.
 - It becomes dangerous if the wire rope breaks or becomes disengaged. Use a wire rope appropriate for the required tractive force.
 - Do not use a wire rope that is kinked, twisted or otherwise damaged.
 - Do not apply heavy loads abruptly to the wire rope.
 - Wear safety gloves when handling the wire rope.
 - Make sure there is an operator on the machine being towed as well as on the machine that is towing.
 - Never tow on slopes.
 - Do not let anyone come near to the wire rope while towing.
- Refer to "Towing" for further instructions.




PRECAUTIONS WHEN STOPPING

Park safely



AG7A058


- Park the machine on a flat, rigid and safe ground. Set the parking brake.



AG7A059PE

If you must park on a slope or incline, park the machine securely and block the movement of the machine.

- When parking on a street, use barriers, caution signs, lights, etc., so that the machine can easily be seen even at night to avoid collision with other vehicles.



AG7A060


- Before leaving the machine, do the followings:
 1. Lower the bucket and the dozer blade to the ground.
 2. Raise the safety lock lever to the locked position.
 3. Stop the engine and remove the starter key.
 4. Lock the cab and covers and take the key with you.



PRECAUTIONS WHEN TRANSPORTING

Load/unload the machine safely

- Lock the cab door after being loaded, if applicable. Otherwise, the door may open during transport.
- Chock the tracks and secure the machine to the truck bed with wire rope or chain.



The machine may roll or tip over or fall while being loaded or unloaded. Take the following precautions:

- Select a firm, level surface and keep sufficient distance from road shoulders.
- Secure the ramps of adequate strength and size to the truck bed. The slope of the ramps must not exceed 15°. If the ramps are bowed down too low, support them with poles or blocks.
- Never use the working equipment to load or unload the machine. Doing so may result in tipping over or falling down of the machine.
- Keep the truck bed and loading ramps clean of oil, soil, ice, snow, and other materials to prevent the machine from sliding sideways. Clean the crawlers.
- Chock the transporter wheels to prevent movement.
- Turn off the deceleration switch and auto-deceleration switch. Otherwise, the engine speed may suddenly increase to cause troubles.
- When being loaded or unloaded, travel slowly in 1st (low) gear by following the signal from the signal person.
- Never change courses on the ramps.
- Do not slew/swing on the ramps. The machine may tip over.
- When slewing/swinging on the truck bed, do it slowly as the footing should be unstable.

**PRECAUTIONS WHEN TRANSPORTING**

Hoist the machine safely

- Know and use correct crane signals.
- Check the hoisting equipment for damaged or missing parts on a daily basis and replace as necessary.
- When hoisting, use a wire rope capable of lifting the machine mass.
- Hoist the machine in such a manner described in the procedure below. Do not do it in any other manner, as it may result in the machine losing its balance. Refer to “Hoisting the machine” for further instructions.
- Do not hoist the machine with an operator on it.
- When hoisting, hoist slowly so that the machine does not tip.
- Keep everyone out of the area when hoisting. Do not move the machine over the heads of the persons.

Transport the machine safely

- Know and follow the applicable safety rules, vehicle code and traffic laws when transporting the machine.
- Select the best transport route by considering the length, width, height and weight of the truck with the machine loaded on it.
- Never abruptly start or stop or run at a high speed at the sharp curves during transport. Doing so will move or lose the balance of the loaded machine.



PRECAUTIONS ON MAINTENANCE

Display a “DO NOT OPERATE” alert sign

Severe injury could result if an unauthorized person should start the engine or touch controls during inspection or maintenance.


- Before performing maintenance, stop the engine, remove the key and take it with you.



AG7A023PE

- Display a “DO NOT OPERATE” alert sign on easy-to-see locations such as on the starter switch or on control levers.

Use the correct tools



AG7A065

Do not use damaged or weakened tools or tools designed for other purposes. Use tools appropriate for the work involved.

Replace safety-critical parts periodically


- Replace fuel hoses periodically. Fuel hoses wear out over time, even if they do not show any symptom of wear.
 - Regardless of the replacement schedule, replace immediately if a symptom of wear is found.
- Refer to “List of safety-critical parts” for further details.

Explosionproof lighting



AG7A067


To prevent an ignition or explosion, use explosion-proof lights when inspecting fuel, oil, coolant or battery fluid. Otherwise, explosion could result causing serious injury or death.

**PRECAUTIONS ON MAINTENANCE****Prohibit access by unauthorized persons**

Do not allow unauthorized personnel in the work area while working. Be careful when grinding, welding or using a hammer. You could be injured by flying debris from the machine.

Prepare work area


- Select a firm, level work area. Make sure there is adequate light and, if indoors, ventilation.
- Clear obstacles and dangerous objects. Eliminate slippery areas.

Always keep the machine clean

- Clean the machine before performing maintenance.
- Stop the engine before washing the machine. Cover the electrical parts so that water cannot enter. Water on electrical parts could cause short-circuits or malfunctions. Do not use water or steam to wash the battery, electronic control components, sensors, connectors or the operator's compartment.

Stop the engine before performing maintenance

- Avoid lubrication or mechanical adjustments while the machine is moving or while the engine is running when the machine is not moving.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
 - One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
 - The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.

**Stay clear of the moving parts**

- Stay clear of all rotating and moving parts. If a hand or tool becomes trapped in the rotating or moving part, serious injury or death could result.
- If a tool or other objects is dropped or inserted in the fan or fan belt, it will be flown or cut in pieces. Do not drop or insert anything in the fan or fan belt.

Firmly secure the machine or any component that may fall

- Before performing maintenance or repairs under the machine, lower all moveable working equipment to the ground or in the lowermost position.
- Chock the tracks.
- If you must work beneath the raised machine or equipment, always use wood blocks, jack-stands or other rigid and stable supports. Never get under the machine or working equipment if they are not sufficiently supported. This procedure is especially important when working on hydraulic cylinders.

Secure the working equipment

To prevent unexpected movement, firmly secure the working equipment when repairing or replacing the bucket teeth or side cutter.

Secure the engine hood or cover when opened

Be sure to secure the engine hood or cover before working the inside. Do not keep the hood or cover open on a windy day or if the machine is parked on a slope.

Place heavy objects in a stable position

When it is necessary to temporarily place a heavy object or an attachment on the ground during removal or installation, be sure to place it in a stable position. Keep off unauthorized persons from the storage place for such object.



Cautions when refueling



- Do not smoke or permit open flames while fueling or near fueling operations.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Do not spill fuel on the hot surface of the machine.
- Fill the fuel tank in a well ventilated place.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Clean up spilled fuel immediately.
- Securely tighten the fuel filler cap. If the fuel cap is lost, replace it only with the genuine cap. Use of a non-approved cap without proper venting may result in pressurization of the tank.
- Never use fuel for cleaning.
- Use the correct grade of fuel for the operating season.

Handling of hoses

Oil leak or fuel leak can cause a fire.

- Do not twist, bend or hit the hoses.
- Never use twisted, bent or cracked pipes, tubes or hoses; otherwise, they may burst.
- Retighten loose connection.

Be careful with hot and pressurized components



Stop the engine and allow the machine to cool down before performing maintenance.

- The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
- The engine coolant, hydraulic oil and other oils are also hot and under high pressure. Be careful not to touch the hydraulic oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- The DPF and the exhaust gas emitted from the exhaust line can be very hot while the engine is running or the regeneration is under way, as well as immediately after the engine is stopped. Be careful not to accidentally touch them; doing so could cause burns.


**Be careful with hot cooling systems**

Do not remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine and wait until the engine and the cooling water cool. Then, slowly loosen the radiator cap to release the internal pressure and remove it.

Be careful with oil internal pressure

Pressure is maintained in the hydraulic circuit long after the engine has been shut down.

- Completely relieve the internal pressure before performing maintenance work.



- The hydraulic oil is high enough pressure to penetrate the skin or eyes and cause serious injury, blindness or death. Remember that the hydraulic oil escaping from a small hole is almost invisible. When checking for leaks, wear protective goggle and thick gloves, and use a paperboard or plywood to keep your skin from oil spurting. If oil penetrates the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury.

Release pressure before working on the hydraulic system

Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.

- Immediately after the engine is stopped, and while the safety lock lever is still in the unlock position, turn the starter switch to ON and move all the control levers and pedals several times all the way in each direction to release the pressure from the working equipment circuitry.
- Press the air breather button to relieve the internal pressure from the tank.
- When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.
- Oil or plug may spurt out according to the pressure in the travel motor case. Loosen the plug slowly and release the internal pressure.

Be careful with debris when the hammer is being used

When using a hammer, pins may fly out or metal particles may be scattered. This may lead to serious injury.

- If hard metal parts such as pins, bucket teeth, side cutter or bearings are hit with a hammer, wear protective gear such as safety goggles and gloves.
- When hitting pins or bucket teeth, always check that there is no one in the surrounding area.


Be careful with the high-pressure grease



In the track adjuster, the grease has been injected under high pressure. If the tension is adjusted without following the prescribed procedure, the grease discharge valve may fly off, resulting in injury.

- Never loosen the grease fitting.
- Loosen the grease discharge valve slowly. Do not turn it more than one turn.
- Do not put your face, arms, legs or body in front of the grease discharge valve.
- If grease does not come out when the grease discharge valve is loosened, the valve is faulty. Ask a Takeuchi service agent for repair.

Never disassemble the track adjuster



There is a very strong spring contained in the track adjuster. If the track adjuster is accidentally disassembled, the spring can pop out, resulting in serious injury. Never disassemble the track adjuster.

Cautions when servicing the air conditioner

If the refrigerant comes in contact with eyes, it damages your eyesight. If the refrigerant comes in contact with skin, it may cause frostbite. Never touch the refrigerant.

Handling of the accumulator



Be sure to handle the high-pressure nitrogen gas enclosed in the accumulator with care. If handled incorrectly, it could explode and cause serious injury. Strictly observe the following precautions:

- Do not disassemble.
- Do not allow flame near or throw it into a fire.
- Do not drill, weld or fuse.
- Do not subject it to physical shock such as hitting, rolling or dropping.
- Before disposing of the unit, the sealed gas must be drained. Contact a Takeuchi service agent for help.



Disconnect the battery wiring



Disconnect the battery wiring before working on the electrical system or doing electric welding. Disconnect the negative (-) battery cable first. When reconnecting, connect the negative (-) battery cable last.

Use caution when handling batteries

- Batteries contain sulfuric acid which will damage the eyes or skin in case of contact.
 - If eye contact occurs, flush immediately with clean water and get prompt medical attention.
 - If accidentally swallowed, drink large quantities of water or milk and call a physician immediately.
 - If acid contacts skin or clothing, wash off immediately with a lot of water.
- Wear protective goggle and gloves when working with batteries.
- Batteries generate flammable hydrogen gas which may explode. Keep away from flame, sparks, fire or lighted cigarettes.
- When checking the level of the battery fluid, use a flashlight.
- Be sure to stop the engine by turning off the starter switch before inspecting or handling the battery.
- Be careful not to let metal tools or any metal objects come into contact with the battery terminals and cause a short circuit.
- Loose battery terminals may result in sparks. Be sure to fasten terminals tightly.
- Make sure the battery caps are tightened securely.
- Do not charge a battery or jump-start the engine if the battery is frozen; otherwise it may explode. Warm the frozen battery to 15°C (60°F) before use.
- Do not use the battery when the fluid level is below the lower level limit. Doing so will hasten the deterioration of the internal portions of the battery and shorten the battery life. It also can cause rupturing (explosion).
- Do not add the distilled water above the upper level limit. Doing so could cause the fluid to leak. This fluid can cause skin damage if contacted, or can cause the machine components to corrode.
- Use a dampened cloth to clean around the fluid level line and check the fluid level. Do not clean with a dry cloth; otherwise it could cause static electricity to build up, resulting in ignition or explosion.

**Periodically replace the safety-critical parts**

- To use the machine safely for a longer period, periodically add oil and perform inspection and maintenance. To improve the safety, replace the safety-critical parts like hoses and seat belts periodically. Refer to “Safety-critical parts to be replaced periodically” for further details.
- The “Safety-critical parts to be replaced periodically” are the parts which deteriorate, wear and fatigue after repeated use and whose properties change over time. While these characters of these parts could cause serious physical or personal damage, judging the remaining life of these parts are difficult from external inspection or the feeling when operating.
- Replace the “Safety-critical parts to be replaced periodically” if any defect is found from external inspection, even when they have not reached the time specified interval.

Jump starting with booster cables

- When starting the engine using the booster cables, be sure to connect the cables in the proper order described below. Wrongly connected cables can result in sparking and battery explosion.
 - Do not allow the “machine in trouble” and “rescue machine” to touch each other.
 - Do not allow the positive (+) and negative (–) clips of the booster cables to touch each other or to come in contact with the machine.
 - When connecting, attach the positive booster cable to the positive (+) terminals first. When disconnecting, remove the negative cable from the negative (–) terminal (ground) first.
 - Be sure to connect the clips securely.
 - Connect the last clip of the booster cable to a point as far away from the battery as possible.
- Always wear the protective goggles and gloves when starting the engine by using the booster cables.
- Use the booster cables and clips of a size suited to the capacity of battery. Do not use damaged or corroded booster cables and clips.
- Be sure that the battery of the “rescue machine” has the same capacity as the battery of the “machine in trouble”.



Have a Takeuchi service agent repair welding

If welding must be performed, make sure that it is done by a qualified person in a properly equipped workplace. To prevent any part from breaking down or being damaged due to overcurrent or sparks, observe the following.

- Disconnect the wiring from the battery before doing electric welding.
- Do not continuously apply 200 V or more.
- The earth ground must be connected within one meter from the welding section. Do not connect the earth ground near to an electronically controlled device/instrument or connectors.
- Make sure that there are no seals or bearings between the welding section and the earth ground.
- Do not connect the earth ground around the pins for the working equipment or hydraulic cylinders.
- When welding is to be done on the machine body, disconnect the connectors for the electronically controlled devices before working.

Vibrations operators are subject to

According to the results of the tests conducted to determine the vibrations transmitted to the operator by the machine, the upper limbs are subjected to vibrations lower than 2.5 m/s^2 (8.2 ft/s^2) while the seated part of the body is subjected to vibrations lower than 0.5 m/s^2 (1.64 ft/s^2).

Checks after maintenance

- Gradually increase the engine speed from a low idle to maximum speed and check that there is no oil or water leaking from the serviced parts.
- Operate each control lever and check that the machine is operating properly.

Disposing of wastes



- Always collect oil that is drained from the machine in containers. Improperly disposed waste oil can cause environmental harm.
- Follow appropriate laws and regulations when disposing of harmful objects such as oil, fuel, coolant, solvent, filters and batteries.

Handling of poisonous chemicals

Poisonous chemicals will cause serious injury if directly contacted.

Poisonous chemistry used in this machine includes grease, battery solution, coolant, paint and adhesive agent.


Handle the poisonous chemicals properly with care.



SAFETY SIGNS (DECALS)

For the safety of the operator and the personnel working around the site, safety signs (decals) are placed at certain locations on the machine as shown below. Walk around the machine with this manual, and check the content and location of these safety signs. Review these signs and the operating instructions in this manual with your machine operators.

- Keep the signs clean and legible. If any of the safety labels is peeling or damaged and becomes difficult to read, replenish it with a new one. Please include your product serial number when ordering a new sign from the Takeuchi service agent.
- When a part/unit to which a safety sign is attached is replenished, a new sign must be attached to the new part/unit.



AQQA0025E

*: Applicable machine models 126100003 or later

**1. No.08810-31556**

Warning
Read and understand this manual before performing any operation, inspection or maintenance on this machine.

4. No.03793-66006

Hazard of rotating parts
Turn off before inspection and maintenance.

**5. No.08810-31557**

Hazard from falling window
After raising window, be sure to lock it in place with lock pins.

**2. No.05793-00049**

Safety Distance
Hazard of being hit by the working device of the machine.
Keep away from machine during operation.

**6. No.05793-00045**

Hazard at lifting or lowering window
When the front window is opened or closed, it will come close to the head. Be careful that the window does not strike the head.

**3. No.05793-00011**

Safety Distance
Do not get near or stand within the machine working area.

**7. No.05793-03630**

Sign indicates a burn hazard from touching heated parts, such as engine, pump, or muffler during or right after operation.
Never touch when hot.






8. No.03393-75040



12. No.08710-86051

Position of Emergency Exit



13. No.03593-06600

Diesel fuel



9. No.03593-47010 (If equipped)



14. No.03593-06700

Hydraulic oil



15. No.08810-31549

Tie down point



10. No.03593-47020



16. No.03993-00500

Position of hoisting




17. No.03993-00400

For EU

Position of Fire extinguisher



11. No.03593-13700






18. No.03993-47101

Noise Outside the Cab (If equipped)

This value indicates the noise level outside the machine and refers to the noise perceived by the persons who are in the vicinity of the work area.




19. No.05793-00052

Hazard of a flying plug from track adjuster

Read manual before adjusting track for safe and proper handling.



20. No.05693-00090



21. No.05693-68009

Before starting lifting operation, be sure to turn on the lift overload warning switch. An alarm sounds if an excessive weight is lifted.



22. No.05793-03643



Be careful about the hoe attachment interference. When lowering the hoe attachment, be careful not to let it hit the undercarriage or dozer blade. Also, make sure that the boom cylinder hose does not contact the chassis.

23. No.03793-69110 (Option)

**WARNING!**

Do not press the float switch while the machine is raised by the dozer blade.

Doing so may cause the machine to fall.

24. No.03593-32300(Option)



25. No.05593-00067(Cab)
No.05593-00068(Canopy)
For USA

! WARNING

EXCAVATOR MODEL TB260

Long arm Length - 1780mm(70.1in.)
Machine with Cab and Rubber counter, without bucket

- Do not attempt to lift or hold any load that is greater than these rated values at their specified load radii and heights.
- The rated lift capacities are based on the machine being level and situated on a firm supporting surface.
- For safe lifting the operator is expected to make due allowance for the particular job conditions, such as soft or uneven ground, uneven load conditions, lead to the machine sides, hazardous conditions, experience of personnel, etc.
- The load safety device shall be equipped for lifting load.
- The overload warning switch shall be turned on when the machine is used for lifting load.
- The loads in the charts do not exceed 87% of hydraulic lift capacity or 75 % of tipping load.
- The load point is the bucket hinge pin.

UNITS: lbs.

LIFTING CAPACITIES Over Front - Sides DOWN				LIFTING CAPACITIES Over Front - Sides UP				LIFTING CAPACITIES Over Side			
LIFT POINT RADIUS (ft)				LIFT POINT RADIUS (ft)				LIFT POINT RADIUS (ft)			
MAX	15	12	9	MAX	15	12	9	MAX	15	12	9
2082	2275	2571	2185	2052	2243	2537	2155	1787	1825	2011	2185
1919	2110	2384	2000	1833	2048	2324	1968	1682	1724	1904	2082
1574	1665	1925	1615	1508	1577	1825	1475	1373	1426	1585	1665
1134	1192	1418	1167	1045	1104	1330	1081	1004	1058	1208	1134
1039	1098	1328	1060	1000	1059	1285	1000	923	978	1104	1039
887	914	1071	892	808	837	1000	808	757	785	904	887
788	812	938	788	720	745	870	720	669	694	808	788
500	500	500	500	460	460	460	460	420	420	420	420

! WARNING

EXCAVATOR MODEL TB260

Long arm Length - 1780mm(70.1in.)
Machine with Cab and Rubber counter, without bucket

Do not attempt to lift or hold any load that is greater than these rated values at their specified load radii and heights.

The rated lift capacities are based on the machine being level and situated on a firm supporting surface.

For safe lifting the operator is expected to make due allowance for the particular job conditions, such as soft or uneven ground, uneven load conditions, lead to the machine sides, hazardous conditions, experience of personnel, etc.

The load safety device shall be equipped for lifting load.

The overload warning switch shall be turned on when the machine is used for lifting load.

The loads in the charts do not exceed 87% of hydraulic lift capacity or 75 % of tipping load.

The load point is the bucket hinge pin.

UNITS: lbs.

LIFTING CAPACITIES Over Front - Sides DOWN				LIFTING CAPACITIES Over Front - Sides UP				LIFTING CAPACITIES Over Side			
LIFT POINT RADIUS (ft)				LIFT POINT RADIUS (ft)				LIFT POINT RADIUS (ft)			
MAX	15	12	9	MAX	15	12	9	MAX	15	12	9
2082	2275	2571	2185	2052	2243	2537	2155	1787	1825	2011	2185
1919	2110	2384	2000	1833	2048	2324	1968	1682	1724	1904	2082
1574	1665	1925	1615	1508	1577	1825	1475	1373	1426	1585	1665
1134	1192	1418	1167	1045	1104	1330	1081	1004	1058	1208	1134
1039	1098	1328	1060	1000	1059	1285	1000	923	978	1104	1039
887	914	1071	892	808	837	1000	808	757	785	904	887
788	812	938	788	720	745	870	720	669	694	808	788
500	500	500	500	460	460	460	460	420	420	420	420

! WARNING

EXCAVATOR MODEL TB260

Long arm Length - 1780mm(70.1in.)
Machine with Cab and Rubber counter, without bucket

Do not attempt to lift or hold any load that is greater than these rated values at their specified load radii and heights.

The rated lift capacities are based on the machine being level and situated on a firm supporting surface.

For safe lifting the operator is expected to make due allowance for the particular job conditions, such as soft or uneven ground, uneven load conditions, lead to the machine sides, hazardous conditions, experience of personnel, etc.

The load safety device shall be equipped for lifting load.

The overload warning switch shall be turned on when the machine is used for lifting load.

The loads in the charts do not exceed 87% of hydraulic lift capacity or 75 % of tipping load.

The load point is the bucket hinge pin.

UNITS: lbs.

LIFTING CAPACITIES Over Front - Sides DOWN				LIFTING CAPACITIES Over Front - Sides UP				LIFTING CAPACITIES Over Side			
LIFT POINT RADIUS (ft)				LIFT POINT RADIUS (ft)				LIFT POINT RADIUS (ft)			
MAX	15	12	9	MAX	15	12	9	MAX	15	12	9
2082	2275	2571	2185	2052	2243	2537	2155	1787	1825	2011	2185
1919	2110	2384	2000	1833	2048	2324	1968	1682	1724	1904	2082
1574	1665	1925	1615	1508	1577	1825	1475	1373	1426	1585	1665
1134	1192	1418	1167	1045	1104	1330	1081	1004	1058	1208	1134
1039	1098	1328	1060	1000	1059	1285	1000	923	978	1104	1039
887	914	1071	892	808	837	1000	808	757	785	904	887
788	812	938	788	720	745	870	720	669	694	808	788
500	500	500	500	460	460	460	460	420	420	420	420

! WARNING

EXCAVATOR MODEL TB260

Long arm Length - 1780mm(70.1in.)
Machine with Cab and Rubber counter, without bucket

Do not attempt to lift or hold any load that is greater than these rated values at their specified load radii and heights.

The rated lift capacities are based on the machine being level and situated on a firm supporting surface.

For safe lifting the operator is expected to make due allowance for the particular job conditions, such as soft or uneven ground, uneven load conditions, lead to the machine sides, hazardous conditions, experience of personnel, etc.

The load safety device shall be equipped for lifting load.

The overload warning switch shall be turned on when the machine is used for lifting load.

The loads in the charts do not exceed 87% of hydraulic lift capacity or 75 % of tipping load.

The load point is the bucket hinge pin.

UNITS: lbs.


LIFTING CAPACITIES Over Front - Sides DOWN				LIFTING CAPACITIES Over Front - Sides UP				LIFTING CAPACITIES Over Side			
LIFT POINT RADIUS (ft)				LIFT POINT RADIUS (ft)				LIFT POINT RADIUS (ft)			
MAX	15	12	9	MAX	15	12	9	MAX	15	12	9
2082	2275	2571	2185	2052	2243	2537	2155	1787	1825	2011	2185
1919	2110	2384	2000	1833	2048	2324	1968	1682	1724	1904	2082
1574	1665	1925	1615	1508	1577	1825	1475	1373	1426	1585	1665
1134	1192	1418	1167	1045	1104	1330	1081	1004	1058	1208	1134
1039	1098	1328	1060	1000	1059	1285	1000	923	978	1104	1039
887	914	1071	892	808	837	1000	808	757	785	904	887
788	812	938	788	720	745	870	720	669	694	808	788
500	500	500	500	460	460	460	460	420	420	420	420

CONTROLS





NAMES OF COMPONENTS (CANOPY)



AQ0B0441

Upperstructure


1. Canopy
2. Seat
3. Engine hood
4. Fuel tank
5. Hydraulic oil tank

Undercarriage

6. Crawler belt
7. Idler
8. Track roller
9. Carrier roller
10. Travel motor

Working equipment

11. Bucket
12. Bucket cylinder
13. Arm
14. Arm cylinder
15. Boom
16. Boom cylinder
17. Boom bracket
18. Swing cylinder
19. Auxiliary hydraulic lines
20. Dozer blade
21. Blade cylinder




AQ0B0453

- | | |
|----------------------------|--|
| 1. Instrument cluster | 14. Light switch |
| 2. Starter switch | 15. Automatic deceleration switch |
| 3. Blade lever | 16. Power/Highland mode switch |
| 4. Throttle controller | 17. Detent mode switch |
| 5. Right operating lever* | 18. Lift overload warning switch* |
| 6. Horn button | 19. Beacon lamp switch* |
| 7. Deceleration button | 20. Engine shutdown switch* |
| 8. Boom swing pedal | 21. Auxiliary 2nd/4th switch* |
| 9. Travel levers/pedals | 22. Auxiliary 2/4 select button* |
| 10. Travel speed button | 23. Third auxiliary hydraulic button* |
| 11. Left operating lever | 24. Third auxiliary hydraulic switch* |
| 12. Auxiliary 1st switches | 25. DPF manual regeneration/inhibit select switch <Applicable machine models 126100003 or later> |
| 13. Safety lock lever | |

*: Subject to the specifications or optional products selected



NAMES OF COMPONENTS (CAB)



AQ0B001

Upperstructure


- 1. Cab
- 2. Seat
- 3. Engine hood
- 4. Fuel tank
- 5. Hydraulic oil tank

Undercarriage

- 6. Crawler belt
- 7. Idler
- 8. Track roller
- 9. Carrier roller
- 10. Travel motor

Working equipment

- 11. Bucket
- 12. Bucket cylinder
- 13. Arm
- 14. Arm cylinder
- 15. Boom
- 16. Boom cylinder
- 17. Boom bracket
- 18. Swing cylinder
- 19. Auxiliary hydraulic lines
- 20. Dozer blade
- 21. Blade cylinder



AQ0B0021


- | | |
|------------------------------|--|
| 1. Multi-information display | 18. Automatic deceleration switch |
| 2. Starter switch | 19. Power/Highland mode switch |
| 3. Blade lever | 20. Detent mode switch |
| 4. Throttle controller | 21. Auxiliary 1st auto tank switch* |
| 5. Right operating lever* | 22. Lift overload warning switch* |
| 6. Horn button | 23. Beacon lamp switch* |
| 7. Deceleration button | 24. Engine shutdown switch* |
| 8. Boom swing pedal | 25. Auxiliary 2nd/4th switch* |
| 9. Ashtray | 26. Auxiliary 2/4 select button* |
| 10. Travel levers/pedals | 27. Third auxiliary hydraulic button* |
| 11. Travel speed button | 28. Third auxiliary hydraulic switch* |
| 12. Left operating lever | 29. Power supply socket* |
| 13. Auxiliary 1st switches | 30. Radio* |
| 14. Safety lock lever | 31. AC Control panel* |
| 15. Light switch | 32. DPF manual regeneration/inhibit select switch <Applicable machine models 126100003 or later> |
| 16. Wiper switch | |
| 17. Washer switch | |

*: Subject to the specifications or optional products selected



COVERS

STARTER KEY



The starter key is used to start and stop the engine, as well as to lock and unlock the following components:

- Cab door
- Engine hood
- Covers

RIGHT SIDE COVER




WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
- Do not keep the right side cover open on a windy day or if the machine is parked on a slope.
- When opening and closing the right side cover, be careful not to get your hands or other parts of your body caught by the cover.

For inspection and maintenance of the hydraulic oil system, electrical system or window washer, open this cover. The selector valve switching in the auxiliary 1st and the lever pattern (optional) switching are also performed.

The grease gun and the tools are stored under the cover.

Opening



1. Insert the starter key and turn it counterclockwise to unlock the right side cover (1).
2. Push in the key hole with your thumb and open the right side cover (1) all the way.

Closing

1. Close the right side cover (1) and press it down until a click is heard.
2. Insert the starter key and turn it clockwise to lock the right side cover (1).




ENGINE HOOD

WARNING

- Before opening the engine hood, be sure to stop the engine. If a hand or tool becomes trapped in the rotating or moving part, serious injury could result.
- When opening or closing the engine hood, be careful not to get your hands or other parts of your body caught by it.

Opening



1. Insert the starter key and turn it counterclockwise to unlock the engine hood (1).
2. Push in the key hole with your thumb and open the engine hood (1).

Closing

1. Close the engine hood (1) and press down the edge of it until a click is heard.
2. Insert the starter key and turn it clockwise to lock the engine hood (1).


LEFT SIDE COVER

CAUTION

Be sure to close the cab door before opening the left side cover and work inside. If not, the wind-blown door could cause injury by striking you in the head or body.

The fuel supply pump (if equipped) is placed under the cover. After use, store it inside.

Opening



1. Insert the starter key and turn it counterclockwise to unlock the left side cover (1).
2. Open the left side cover (1).

Closing

1. Close the left side cover (1) and turn the key clockwise to lock it.
Refer to "Fuel supply pump (If equipped)" on page 2-84.




FUEL LID

CAUTION

Be sure to close the cab door before opening the fuel lid for fueling. If not, the wind-blown door could cause injury by striking you in the head or body.

For adding fuel or checking its level, open this cover.

Opening



1. Insert the starter key and turn it counterclockwise to unlock the fuel lid (1).
2. Open the fuel lid (1).

Closing


1. Close the fuel lid (1).
2. Insert the starter key and turn it clockwise to lock the fuel lid (1).

FUEL FILLER PORT

WARNING

- Do not smoke and keep away from heat or flame while filling the fuel tank.
- Fill the fuel tank in a well ventilated place, with the engine turned off.
- Clean up spilled fuel immediately.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Securely tighten the fuel filler cap.

Opening



1. Open the fuel lid.
2. Turn the fuel cap (1) counterclockwise and remove it.

Closing


1. Turn the fuel cap (1) clockwise and close it.
2. Close the fuel lid and lock it.



FUSE BOX COVER

For inspection and maintenance of the fuse, open this cover.

Opening



1. Insert the starter key and turn it counterclockwise to unlock the fuse box cover (1).
2. Tilt the fuse box cover (1) forward.

Closing

1. Close the fuse box cover (1) and turn the key clockwise to lock it.



CAB

CAB DOOR


WARNING

When getting on or off the cab, first open the door all the way until it is secured in the catch and check that it does not move.

Open the door fully and press it against the catch at the back of the door to secure it in place.

The door must be locked when getting on or off the machine and while in operation.


Locking and unlocking



Insert the starter key and turn it.

Opening


1. Pull the knob (1) towards you and open the door.



To open the door from inside the cab, push the lever (2) to the lower.

2. Open the door fully and press it against the cab to secure it in place.


Closing



1. Push the release lever (3) to the lower.
2. Close the released door.

EMERGENCY EXIT

Front window (excluding machines with a front guard)



If you should become trapped inside the cab, open the front window to get out.




FRONT WINDOW


WARNING

- Grasp the handles firmly with both hands when opening and closing the front window. Your head or hands may get caught if it slips from your hands.
- When the front window is opened or closed, it will come close to the head. Be careful that the window does not strike the head.
- When you open the front window, be sure to lock it in place with the lock pins on the left and right sides. The window may fall if it is not locked in place.

Opening



1. Park on a level surface and stop the engine.
2. Set the safety lock lever to the locked position.
3. Grasp the left and right handles (1) and press the knobs (2) with your thumb to release the lock.
4. Pull the front window (3) toward you and lift while doing so.




5. Release your thumb from the knobs (2) and then lift the front window (3) fully and lock the front window with lock pin (4).


Closing

WARNING

When closing the front window slowly so as not to hit your head. Lowering the window abruptly may result injury or damage the front window.



1. Grasp the left and right handles (1) and press the knobs (2) with your thumb to release the lock.
2. Pull down the front window (3) and while doing so, slide it to the front and slowly lower it.




3. Release your thumb from the knobs (2) and then press the front window toward front and lock the front window with lock pin (4).




LOWER FRONT WINDOW

Removing




1. Open the front window and stow it in the ceiling.
2. Slowly lift the lower front window (4).



3. Hold the window in a vertical position (the bottom of the window should be in front of you), place it through the guide (5) on the left side of the cab, and then secure it with the support (6).


SIDE WINDOW



1. Grasp the catch (7), unlock it and open the side window.
2. To close the side window, close it until a click is heard.




EMERGENCY HAMMER (OPTIONAL)



An emergency hammer is installed to be used to escape from the cab in an emergency. When escaping, break the windows with the hammer.

- When breaking the window pane with a hammer, take great care not to injure yourself with the broken glass pieces.
- Remove the glass pieces from the window sill so as not to cut yourself when evacuating. Broken glass will fall from the window, so be careful of your footing and do not slip on the glass.

SUN SHADE



1. Pull out the sun shade forward.
2. Hook the sun shade to the two catches (1).




SEAT AND SEAT BELT

SEAT

WARNING

- Adjust and secure the seat.
- Do not make any adjustments while operating the machine.
- Do not set the backrest to its maximum reclining position and slide the seat backwards at the same time. Doing so may damage the rear window or cause injury.
- Remember that the backrest returns to the forward position abruptly due to the spring force.




(A) Adjusting the backrest angle

1. Sit up and sit back in the chair.
2. Pull up the lever (1), recline the backrest by using the spring force. Release the lever (1) at the desired angle to secure the backrest.

(B) Fore-and-aft adjustment

1. Pull up the lever (2) and slide the seat backward or forward to the desired position for operation of machine.
2. Release the lever (2) at the desired position to secure the seat.
Adjustment range: 15 positions, in 150 mm (5.9 in.)



(C) Adjusting according to operator's weight

1. Turn the handle (3) until the scale (4) indicates the weight of operator.
Adjustment range: 50 to 130 kg (110 to 287 lbs)

(D) Adjusting the height of the seat

Upward

1. Lift the seat to first or second position click-stop.
Adjustment ranges: 2 positions, in 60mm (2.36 in.)

Downward

1. First lift the seat to highest position, then the seat can be lowered to lowest position.

**(E) Adjusting the headrest (Option)**

The headrest (E) can be moved upward or downward.


1. Grab the headrest (E) with both hands, and move upward or downward to the desired position.

SEAT BELT**WARNING**


Be sure to fasten the seat belt securely before starting the engine.

Fastening the seat belt

1. Adjust the seat to the desired position for operation, sit up and sit back in the chair.
2. Pull the seat belt to the desired length.



3. Make sure that the belt is not twisted and then insert the tongue plate (A) into the buckle (B) of the seat belt until you hear a clicking sound as it locks in place.
4. Check if the belt is securely locked by pulling it, and arrange the belt around your waist.


Releasing the seat belt

1. Grasp the tongue plate (A) and press the button (C) on the buckle (B). The seat belt retracts back into its original position.



MULTI-INFORMATION DISPLAY

MAIN MENU SCREEN



AQ0B0061

For explanation purposes, all lamps on this page are in the lit condition. This screen image is quite different from that of the real operation. In the actual operation, if a warning is given or any function is selected, the corresponding symbol appears enlarged at the center of the display for approx. one second.

When the starter switch is set to ON, the battery charge warning lamp and the engine oil pressure warning lamp first appear enlarged, and then turn on with an alarm at their original locations. The machine system is normal if the lamps turn off after the engine is started.



WARNING LAMPS

IMPORTANT: If a warning lamp flashes and an alarm is sounded, immediately stop all operations and check the corresponding component. Refer to “If a warning lamp flashes” on pages 6-10 and 6-11.

1. ECM error warning lamp <Applicable machine models 126100003 or later>

This warning lamp flashes if the Electronic Control Module (ECM) detects an engine problem while the starter switch is in the ON position. The problem detected is recorded as an ECM error.

Refer to “Engine error code list” on pages 6-14 to 6-21.

1-1. Vehicle and engine emergency lamp

This lamp is displayed enlarged for one second, and then flashes and an alarm sounds if there is a problem with the machine. Go to the (7) error code display from the Menu screen, get the vehicle or engine error code number, and consult your sales or service dealer referring to the “Vehicle error code list” or “Engine error code list” in this manual.

Refer to “Menu screen” on page 2-22.

Refer to “(7) Error code display” on page 2-25.

Refer to “Vehicle error code list” on pages 6-12 to 6-13.

Refer to “Engine error code list” on pages 6-14 to 6-21.

2. Battery charge warning lamp

This lamp flashes and an alarm is sounded if a problem rises in the charging system while the engine is running.

3. Engine oil pressure warning lamp

This lamp flashes and an alarm is sounded if the lubricant oil pressure abnormally low while the engine is running.

4. Water separator warning lamp

This lamp flashes if the water is detected within the water separator while the starter switch is in the ON position.

5. Coolant temperature warning lamp

This lamp flashes and an alarm is sounded if the engine coolant temperature becomes abnormally high while the engine is running.

6. Air cleaner warning lamp

This lamp flashes and an alarm is sounded if the air cleaner filter is clogged while the engine is running.

7. Fuel filter warning lamp

This lamp flashes and an alarm is sounded if the fuel filter is clogged while the engine is running.

8. Fuel level warning lamp

This lamp flashes when the fuel level is low while the starter switch is in the ON position.


9. Third auxiliary hydraulic warning lamp

This lamp starts flashing and an alarm sounds if the fixed side (left “e”) pressure of the auxiliary 3rd drops abnormally while the engine is running, or while the quick-hitch is being removed or installed.



INDICATORS

10. Deceleration indicator lamp



..... Automatic deceleration indicator

..... Deceleration indicator

AQ0B007

Automatic deceleration indicator

It flashes when the automatic deceleration switch is pressed and remains lit while in the deceleration mode.

Refer to “Deceleration button” on page 2-49.

Refer to “Automatic deceleration switch” on page 2-55.

Deceleration indicator lamp

This lamp turns on when the deceleration button is pressed. The lamp lights up to indicate that the engine is in the deceleration mode at low idling speed (1150 rpm).

11. Exhaust temperature warning indicator

<Applicable machine models 126100003 or later>


This indicator lights up to warn if the exhaust temperature is abnormally increased. Check for any flammable items around the exhaust piping.

12. Glow indicator lamp

This indicator lamp turns off when the engine preheating is completed.

13. DPF auto regeneration/inhibit indicator lamp

<Applicable machine models 126100003 or later>



..... DPF auto regeneration under way

..... DPF auto regeneration inhibit

AQ0B008

DPF auto regeneration under way

The DPF regeneration is automatically performed by the engine, when certain criteria are met. The operator only has to check the display.

DPF auto regeneration inhibit

The DPF manual regeneration inhibit symbol appears on the display when the DPF manual regeneration under way or the DPF auto regeneration under way is cancelled.

Refer to “DPF manual regeneration/inhibit select switch” on page 2-52.

14. DPF manual regeneration under way/regeneration promoting indicator

<Applicable machine models 126100003 or later>


The indicator starts flashing and an alarm starts sounding, if the accumulated PM exceeds the limited amount on the DPF. Immediately perform the manual DPF regeneration.

Refer to “DPF manual regeneration/inhibit select switch” on page 2-52.

15. Highland mode indicator lamp

Highland mode is selected.

Refer to “Power/Highland mode switch” on page 2-55.

**16. Travel speed indicator lamp**

..... High-speed travel

..... Low-speed travel


This lamp turns on when the travel speed button is set to the 2nd (high) speed.

17. Power mode indicator lamp

This lamp lights up when the power mode side of the Power/Highland mode select switch is pressed. The maximum engine output is maintained for as long as this lamp is lit.

18. Lift overload warning indicator lamp

This lamp turns on when the lift overload warning switch is turned on.

19. Auxiliary 2nd/4th select indicator lamp

..... Auxiliary 2nd is selected.

..... Auxiliary 4th is selected.

20. Auxiliary 1st one-way (one-way circuit) indicator lamp

..... Auxiliary 1st auto tank is selected.

..... Auxiliary 1st one-way is selected.

No display: Two-way (two-way circuit) is selected.

21. High-flow indicator lamp

This lamp flashes and then stays lit when the auxiliary 1st flow rate is set to high-flow. It also flashes when the high-flow setting is changed.

22. Dozer blade float indicator lamp (If equipped)


..... This lamp lights up when the float switch on the blade lever is pressed.

23. Water temperature gauge

Indicates the temperature of the engine coolant water. The indicator level must be within the green range during machine operation. The red range indicates overheating.

24. Fuel gauge

Indicates the amount of fuel in the tank. Be sure to fill up the tank before running out of fuel.

25. Throttle opening position indicator




The red range increases as the engine load increases, indicating higher fuel consumption. When the button (C) (Bar meter key) is pressed in a normal screen, the display is changed from the throttle opening position to the lift load factor and the PM accumulation amount (only for machine models of 126100003 or later), in this order.

- The lift load factor is displayed if there is no change in the throttle opening position for five seconds after the lift alarm switch is turned on.
- The throttle opening position is displayed if the highland mode switch is turned on or there is a change in the throttle opening position.

26. Auxiliary 1st flow rate indicator lamp

This lamp lights up to indicate which flow rate setting is selected in the auxiliary 1st.



Refer to “Auxiliary 1st flow rate setting” on page 2-23.

27. Air conditioner indicator lamp

Lights up while the air conditioner is operating.

28. Working light indicator

Lights up when the working light is turned on.


29. Date and time indicator



Displays the date and time set.
Refer to “Date and time setting” on page 2-25.

30. Hour meter/Trip meter

• Hour meter



Displays the total engine running time in hours.
The rightmost digit indicates tenths of


hours (6 minutes).

Set the inspection and maintenance intervals according to the time displayed on the hour meter.

• Trip meter

Three patterns of desired operating hours can be displayed.

Refer to “Trip meter setting” on page 2-23.

**SCREEN CONTROL KEY**

Note: Do not press the symbol keys on the display. The LCD could be damaged if the symbol keys are pressed hard. For actual operation, press the push button keys located at the bottom of the screen.

A. Menu key

Use this key to switch between the Home screen and the Menu screen. This key is also used to cancel changes made in each setting. The screen returns to the Home screen if this key is pressed in the information screen.

B. Hour meter key

This hour meter symbol is displayed in the initial screen. Pressing this key changes the meter display in the following order. Trip meter 1, Trip meter 2, Trip meter 3, Hour meter.

Down (↓) key

Use this key to move the cursor ► downward and to decrease the value in each setting. Press and hold this key for one second to rapidly decrease the value.

C. Bar meter key

This hour meter symbol is displayed in the initial screen. Pressing this key changes the meter display in the following order. Throttle opening position, Lift load factor, PM accumulation amount

Up (↑) key

Use this key to move the cursor ► upward and to increase the value in each setting.

Press and hold this key for one second to rapidly increase the value.

D. Auxiliary 1st key

The auxiliary 1st symbol is displayed in the initial screen. Pressing this key changes the symbol display in the following order. Auxiliary 1st setting 1, Auxiliary 1st setting 2, Auxiliary 1st setting 3.

Enter key

Use this key to confirm or execute the setting made by each key.


To clear the trip meter being displayed, press and hold this key for three seconds.

E. Camera image key (If equipped)

<Applicable machine models 126001208 or later>

**WARNING**

Do not look at the images produced by the camera when traveling in reverse. Move in reverse while visually looking at the direction of travel.




AW6C0211

1. Press the Camera key in the Main screen to display the images taken by the rear camera.
2. Press the Camera key again or other key to return to the Main screen.



SCREEN NAVIGATION

• Menu screen



AQ0B018


Press the Menu key to go the Menu screen while in the Home screen.

- (1) Trip meter setting
- (2) Auxiliary line flow rate display
- (3) Auxiliary 1st flow rate setting
- (4) Auxiliary 2nd/4th flow rate setting
- (5) Date and time setting
- (6) Data display
- (7) Error code display
- (8) LCD setting

Move the cursor ► with the Up (↑) or Down (↓) key to go to the desired item to be set, and then press the Enter key to confirm. To return to the Menu screen, press the Menu key. The wrench symbol indicates the “setting is possible state” and the (i) mark indicates information only.



(1) TRIP METER SETTING



Six patterns of desired operating hours can be set.

To start setting, press the Enter key. The value flashes while being set.

Up (↑) key: Increases the value or moves the cursor ► upward. Rapidly increases the value when pressed and held for one second.


Down (↓) key: Decreases the value or moves the cursor ► downward. Rapidly decreases the value when pressed and held for one second.

Enter key: Confirms setting

Menu key: Cancels setting or returns to the Menu screen.

Pressing and holding the Enter key for three seconds clears the trip meter pointed by the cursor.


(2) AUXILIARY LINE FLOW RATE DISPLAY



Displays the flow rate of the Auxiliary 1st, 2nd and 4th.

The flow rate cannot be changed.

(3) AUXILIARY 1ST FLOW RATE SETTING




Three flow rate patterns can be set in the auxiliary 1st.

Refer to the trip meter setting for the key operation. To move the cursor ► in the direction of the arrow, use the Down (↓) key. To move the cursor ► in the opposite direction of the arrow, use the Up (↑) key.

Initial condition	A/B common, standard flow	Variable range
Auxiliary 1st-1	100%=57L/min (15.1 US gpm)	10 to 100%
Auxiliary 1st-2	75%=43L/min (11.4 US gpm)	10 to 100%
Auxiliary 1st-3	50%=28L/min (7.4 US gpm)	10 to 100%

Maximum flow rate	A/B common, high-flow	Variable range
Auxiliary 1st-1, 2, 3	180%=102L/min (26.9 US gpm)	101 to 180%

The table shows the 1-way flow rate when there is no load.



Pressing the Enter key while the cursor ● is at "Select ATT" goes to the attachment select screen.


Pressing the Down (↓) key will move the blue flashing light in the direction of the arrow.

Pressing the UP (↑) key will move the blue flashing light in the opposite direction of the arrow.

Move the blue flashing light to the desired symbol or the number, and then press the Enter key to confirm.

The selected symbol will appear at the lower left of the Home screen.

(4) AUXILIARY 2ND/4TH FLOW RATE SETTING




One pattern of the auxiliary 2nd/4th flow rate can be set.

Initial condition	Standard flow	Variable range
Auxiliary 2nd	C/D 100%=44L/min (11.6 US gpm)	10 to 100%
Auxiliary 4th	G/H 100%=44L/min (11.6 US gpm)	10 to 100%

The table shows the 1-way flow rate when there is no load.

Refer to the trip meter setting for the key operation. To move the cursor ► in the direction of the arrow, use the Down (↓) key. To move the cursor ► in the opposite direction of the arrow, use the Up (↑) key.

**(5) DATE AND TIME SETTING**


The year, month, date, hour and minute can be set. (Effective year range: 2010 to 2099)

- Move the cursor ► to the clock symbol, and then press the Enter key. The cursor ▼ will be shifted to the place for setting the year.

Press the Enter key again, and then enter the year. (The year display keeps flashing during editing.)

Press the Enter key to confirm. The month, date, hour and minute can be set using the same procedure for the year.


- Move the cursor ► to the calendar symbol, and then press the Enter key to change the format of “Year-Month-Date” to “Date-Month-Year” or “Month-Date-Year”. Refer to the trip meter setting for the key operation.

(6) DATA DISPLAY

Displays various data. The setting cannot be changed.

Display items

- Engine RPM
- Coolant temperature
- —
- Battery voltage
- PM accumulation amount <Applicable machine models 126100003 or later>

(7) ERROR CODE DISPLAY**! Vehicle error code**

Displays four error codes, with the latest code in the upper left.

Refer to “Vehicle error code list” on pages 6-12 to 6-13.

! ECM error code

<Applicable machine models 126100003 or later>

Engine ECM (Engine Control Module) error code

Displays three error codes, with the latest code at the top.


Refer to “Engine error code list” on pages 6-14 to 6-21.

IMPORTANT: If an error code appears, immediately stop the operation and contact a Takeuchi sales or service outlet for help.



(8) LCD SETTING

• Background color setting



Move the cursor ► to the background color symbol, and then press the Enter key. The blue flashing light moves from blue gray to gray, blue and black, in this order. Move the blue flashing light to the desired color position, and then press the Enter key to confirm.

The background color can be changed in this screen, regardless of mode (day or night).


• Unit setting

Switch between SI unit and US units.

Move the blue flashing light to the desired unit position, and then press the Enter key to confirm.

Menu key: returns to the Menu screen.

Pressing the Menu key again returns to the Home screen.



• The brightness of the LCD is set to between 0 and 100%.

The brightness changes each time the adjustment is made.

Day mode: initial setting value is 50%


Night mode: initial setting value is 50%

While in the day (night) mode, adjustment is possible only for the brightness set to the night (day) mode.


Refer to the trip meter setting for the key operation.



SWITCHING IMAGES




- Changing the background color (day/night)



Turn on the light switch on any screen to decrease the display brightness and to enter the “evening mode”.



INSTRUMENT CLUSTER



AH1B0051

For explanation purposes, all lamps on this page are in the lit condition. This screen image is quite different from that of the real operation.

Once the starter switch is turned to ON, all lamps on the instrument cluster light up and the alarm sounds.

Then, the battery charge warning lamp (3) and the engine oil pressure warning lamp (2) start flashing and an alarm sounds. The machine system is normal if the lamps turn off after the engine is started.

If any lamp is not lit when the starter switch is turned to ON, there is something wrong in the machine. Consult your sales or service dealer.

WARNING LAMPS

IMPORTANT: If a warning lamp flashes and an alarm is sounded, immediately stop all operations and check the corresponding component.

Refer to “If a warning lamp flashes” on pages 6-10 to 6-11.

**1. Vehicle and engine emergency lamp**

This lamp flashes and an alarm sounds if there is a problem with the machine. Go to the “Failure Record (FAILURE RECORD)” from the side menu screen, get the vehicle or engine error code number, and then consult your sales or service dealer referring to the “Vehicle error code list” or “Engine error code list” in this manual. Refer to “Side menu screen” on page 2-39.

Refer to “Failure Record (FAILURE RECORD)” on page 2-46.

Refer to “Vehicle error code list” on pages 6-12 and 6-13.

Refer to “Engine error code list” on pages 6-14 to 6-21.

2. Engine oil pressure warning lamp

This lamp flashes and an alarm is sounded if the lubricant oil pressure abnormally low while the engine is running.

3. Battery charge warning lamp

This lamp flashes and an alarm is sounded if a problem rises in the charging system while the engine is running.

4. Coolant temperature warning lamp

This lamp flashes and an alarm is sounded if the engine coolant temperature becomes abnormally high while the engine is running.

5. Fuel level warning lamp

This lamp turns on if the fuel level becomes low while the starter switch is in the ON position.

6. Air cleaner warning lamp

This lamp flashes and an alarm is sounded if the air cleaner filter is clogged while the engine is running.

INDICATORS**7. Glow lamp**

This lamp goes out when the engine preheating is completed.

8. Travel speed lamp

This lamp turns on when the travel speed button is set to the 2nd (high) speed.

9. Deceleration lamp

This lamp turns on when the deceleration button is pressed. The lamp lights up to indicate that the engine is in the deceleration mode at low idling speed (1150 rpm).

It flashes When the automatic deceleration switch is pressed to indicate that the machine is in the automatic deceleration mode.

Refer to “Deceleration button” on page 2-49.

Refer to “Automatic deceleration switch” on page 2-55.

METERS**10. Water temperature gauge**

Indicates the temperature of the engine coolant water.

The LED should be within the green range during machine operation.

The red range indicates overheating.

11. Fuel gauge

Indicates the amount of fuel in the tank.

Be sure to top off the tank before running out of fuel.




MULTI-DATA DISPLAY

12. LCD (Liquid Crystal Display)

It displays various functions and data on hour meter, trip meter, clock, tachometer and the machine.

Home screen



1. Key function display

The key function display changes depending on the screens (Home, Menu and each setting)

For actual operation, use the buttons, "A", "B" and "C", located beneath each symbol.

Refer to "Function of each key" on pages 2-34 to 2-47.

2. Hour meter/Trip meter


- Hour meter
Displays the total engine running time in hours.
The rightmost digit indicates tenths of hours (6 minutes).
Set the inspection and maintenance intervals according to the time displayed on the hour meter.
- Trip meter
Three patterns of desired operating hours can be displayed.
Refer to "Trip meter display" on page 2-34.

3. Time display

Displays the time set.

Refer to "Time setting" on page 2-37.

4. Tachometer





Displays the engine RPM in 10 levels.

Pressing the (B) key while the tachometer is displayed changes to the display of the PM accumulation rate and lift load factor, in this order.

- The throttle opening position is displayed if the lift alarm switch is turned on and there is no change in the throttle opening position.
- The tachometer is displayed if the highland mode switch is turned on or there is a change in the throttle opening position.

5. Functions (Page 1)



**A. Auxiliary 2nd/4th selection**

..... Auxiliary 2nd is selected.

..... Auxiliary 4th is selected.

B. —**C. Auxiliary 1st One-way (one-way circuit)**

..... Auxiliary 1st auto tank is selected.

..... Auxiliary 1st one-way is selected.

No display: Two-way (two-way circuit) is selected.

D. Lift overload warning/power mode

..... This lamp lights up when the power mode side of the Power/Highland mode select switch is pressed. The maximum engine output is maintained for as long as this lamp is lit.

..... Display the symbol when the lift overload warning switch is turned on.

Refer to “Power/Highland mode switch” on page 2-55.

Refer to “Lift overload warning switch (If equipped)” on page 2-57.

E. DPF Auto Regeneration/Inhibit

..... DPF auto regeneration under way

..... DPF auto regeneration inhibit

DPF auto regeneration under way

The DPF regeneration is automatically performed by the engine, when certain criteria are met. The operator only has to check the display.

DPF auto regeneration inhibit

The DPF manual regeneration inhibit symbol appears on the display when the DPF manual regeneration under way or the DPF auto regeneration under way is cancelled.

Refer to “DPF manual regeneration/inhibit select switch” on page 2-52.

F. Highland Mode (If equipped)

This mode is used to reduce the engine load due to the hydraulic pump. When the machine is operated at a high-altitude site, the engine output is decreased due to thin air. In such cases, the hydraulic horse power is automatically adjusted to prevent the engine from stalling.


Refer to “Power/Highland mode switch” on page 2-55.

**G. Alarm**

Displays the clock symbol when the alarm function is turned on. Refer to "Alarm setting" on page 2-37.

6. Function indicators (Page 2)

When the (A) key is pressed, the display changes as the following.

**H. Auxiliary 1st indicator****I. Auxiliary 1st flow rate selection indicator**

Press the (B) key to move the ■ and select the desired flow rate.

Refer to "Auxiliary 1st Flow Rate Setting" on page 2-40.

J. Attachment symbol indicators

Displays the symbol of the attachment selected in the "Auxiliary 1st Flow Rate Setting" section.

K. High-flow indicator


Displays the symbol of high-flow when the auxiliary 1st flow rate is set to high-flow.

L. Dozer blade float indicator

Displays the symbol of the dozer blade float when the float button is pressed.

7. Warning indicators (Page 3)

When the (A) key is pressed, the display changes as the following. If there is no warning, the screen returns to the "Functions" on Page 1.



Warning display is first flashed and enlarged for three seconds and then stays displayed, if there is a problem with the machine. If multiple warnings are to be displayed, the highest priority warning is displayed. Priority from the highest to the lowest: ECM error warning, DPF regeneration prompting, Auxiliary 3rd hydraulic pressure warning, water separator warning and fuel filter warning.

No enlarged display for the exhaust temperature warning and the maintenance warning.

Go to the "MAINTENANCE/ FAILURE RECORD/Error code display" from the Side menu screen, get the vehicle or engine error code number, and consult your sales or service dealer referring to the "Vehicle error code list" or "Engine error code list" in this manual.

**M.ECM error warning indicator**

This warning lamp flashes if the Electronic Control Module (ECM) detects an engine problem while the starter switch is in the ON position. The problem detected is recorded as an ECM error.

Refer to “Engine error code list” on pages 6-14 to 6-21.

N.Water separator warning indicator

This lamp flashes if the water is detected within the water separator while the starter switch is in the ON position.

Refer to “If a warning lamp flashes” on page 6-10.

O.DPF manual regeneration under way/regeneration promoting indicator

This indicator starts flashing and an alarm starts sounding, if the accumulated PM exceeds the limited amount on the DPF. Immediately perform the manual DPF regeneration.

Refer to “DPF manual regeneration/inhibit select switch” on page 2-52.

P. Exhaust temperature warning indicator

This indicator lights up to warn if the exhaust temperature is abnormally increased. Check for any flammable items around the exhaust piping.

Q.Fuel filter warning indicator


This lamp flashes and an alarm is sounded if the fuel filter is clogged while the engine is running.

R.Auxiliary 3rd hydraulic pressure warning indicator (If equipped)

This warning lamp starts flashing and an alarm sounds if the pressure in the fixed side (left “e”) of the Auxiliary 3rd drops abnormally while the engine is running, or while the quick-hitch is being used for changing the bucket.

S. Maintenance warning indicator

When the time for maintenance set by the trip meter is reached, this warning lamp flashes and an alarm sounds.




When the time for maintenance set by the trip meter is reached, the screen is changed from the Main to the Trip Meter for Maintenance on the DATA screen. Each value remains flashing until its corresponding key is pressed. At this stage, the trip meter values cannot be reset. Pressing any key returns to the Warning (Page 3) of Main screen in which the maintenance warning lamp is flashing and the alarm is sounding. Promptly inspect and service the relevant item. Refer to “Menu/Trip meter reset” on page 2-35.

Refer to “Maintenance” on page 5-1.



FUNCTION OF EACH KEY



The functions are as below in the Home screen. The different functions appear in the other screens.

A. Stopping the alarm or switching the display between Functions and Warnings

- Pressing the (A) key while the alarm is sounding stops the alarm.
- Pressing the (A) key to switch the display; Functions (Page 1), Functions (Page 2), and Warnings (Page 3).

B. Meter switching

Pressing and holding the (B) key for two seconds or more each time the display changes as follows:

1. Hour meter



AC8B010

2. Trip meter 1



AC8B011

3. Trip meter 2



AC8B012

4. Trip meter 3



AC8B013

5. Returns to the hour meter

- When the (B) key is pressed, the display changes in the following order.



1. Tachometer



2. PM accumulation rate



3. Lift load factor




4. Return to the engine RPM.

C. Menu/trip meter reset

- Pressing the (C) key switches to the Menu screen.
- Pressing and holding the (C) key for three seconds or more while the trip meter is displayed returns the trip meter to "0".

MENU SCREEN



Press the (A) key to proceed to the screen selected by the bar.

Press the (B) key to move the selection bar.

Press the (C) key to return to the Home screen.

• DATA


The trip meter for maintenance, battery and auxiliary circuits can be checked. Unlike the trip meter displayed on the Main screen, data items on the engine oil filter, hydraulic oil filter and fuel filter are included so that you can use them as a guideline for replacement.

• SETTING

Time, alarm and contrast can be set.




DATA SCREEN (DATA)



Press the (A) key to proceed to the screen selected by the bar.
Press the (B) key to move the selection bar.
Press the (C) key to return to the Menu screen.

- **Trip meter (TRIP METER) for maintenance**

The trip meters for the engine oil filter, hydraulic oil filter or fuel filter are displayed.




Press and hold the (A) key for at least five seconds resets the selected trip meter to "0".

Press the (B) key to move the selection bar.
Press the (C) key to return to the DATA screen.

- **Battery (BATTERY)**


Displays the battery voltage.



Press the (C) key to return to the DATA screen.

- **Auxiliary circuit (AUXILIARY)**

Displays the flow rate in the auxiliary circuits of the 1st, 2nd or 3rd.




Each time the (B) key is pressed, the auxiliary circuit is displayed in this order: Auxiliary 1st, Auxiliary 2nd and Auxiliary 4th.

Press the (C) key to return to the Data screen.



SETTING SELECTION SCREEN (SETTING)




Press the (A) key to proceed to the screen selected by the bar.

Press the (B) key to move the selection bar.

Press the (C) key to return to the Menu screen.

• Time setting (CLOCK)

The time to be displayed on the Home screen can be set here.




- When the selection bar is at CLOCK, press the (A) key to proceed to the time setting screen (CLOCK SET).
- Pressing the (A) key in this screen moves the selection bar and flashes the figures on the bar.
Setting range: hours, 1 to 24; minutes, 00 to 59
- Press the (B) key to increase the number value selected.
Press and hold the (B) key to rapidly increase the number value selected.
- Press and hold the (A) key for at least two seconds to complete the setting and to return to the Setting Selection screen.

- Press the (C) key cancels editing and to return to the Setting Selection screen.

• Alarm setting (ALARM)

Five patterns of alarm setting are available.

Alarm function can be set to on or off within the five patterns.




- When the selection bar is at ALARM, press the (A) key to proceed to the alarm setting screen (ALARM SET).
- Press the (A) key in this screen to place a checkmark in the box at the left of the setting bar. Press the (A) key again to remove the checkmark.
The alarm setting cannot be changed only by placing or removing a checkmark.
- Press and hold the (A) key for at least two seconds to complete the setting and to return to the Setting Selection screen.
Be sure to perform the above operation when you wish to set the alarm.
A clock symbol is displayed on the Home screen.
- Press the (B) key to move the selection bar.
- Press and hold the (B) key for at least three seconds to enter the alarm time setting mode.
- Press the (C) key to cancel editing and to return to the Setting Selection screen.
Checked On
Unchecked Off



- **Alarm time setting mode**


Sets the time for alarm.



- Select the item to be set in the alarm setting screen (ALARM SET).
- Press and hold the (B) key for at least three seconds to enter the alarm time setting mode.
- Press the (A) key in this screen to move the selection bar and to flash the figures on the bar.
Setting range: hours, 1 to 24; minutes, 00 to 59
- Press the (B) key to increase the number value selected.
Press and hold the (B) key to rapidly increase the number value selected.
- Press and hold the (A) key for at least two seconds to complete the setting and to return to the Setting Selection screen.
- Press the (C) key to cancel editing and to return to the Setting Selection screen.

- **Contrast setting (CONTRAST)**


Adjust the LCD contrast.



- When the selection bar is at CONTRAST, press the (A) key to proceed to the contrast setting screen (CONTRAST).
- To increase contrast, press the (B) key. The bar advances to the right.
Press and hold the (B) key to rapidly advance the bar.
Once the bar reaches the right end (highest contrast), it returns to the left end (lowest contrast).
- Press and hold the (A) key for at least three seconds to complete the setting and to return to the Setting Selection screen.
- Press the (C) key to cancel editing and to return to the Setting Selection screen. The changes made to the setting are reflected, but they will be removed when the starter switch is turned off.



SIDE MENU SCREEN



To display the side menu, turn the starter switch from the OFF to the ON position while pressing the (C) key.

Press the (A) key to proceed to the screen selected by the bar.

Press the (B) key to move the selection bar.

- **SETTING**


The flow rate ratio of the auxiliary circuits (Auxiliary 1st, Auxiliary 2nd and Auxiliary 4th) can be set.

- **MAINTENANCE**

Diagnosis and failure record can be checked.




SETTING SELECTION SCREEN (SETTING)



Press the (A) key to proceed to the screen selected by the bar.
Press the (B) key to move the selection bar.
Press the (C) key to return to the side menu screen.

• Auxiliary 1st flow rate setting (1st AUX SET)

Set the flow rate ratio for the No. 1, No. 2 and No. 3rd in the Auxiliary 1 circuit.




- Pressing the (A) key in this screen moves the selection bar and flashes the figures on the bar.
- Press the (B) key to increase the number value selected.
Press and hold the (B) key for at least one second to rapidly increase the number value selected.

Initial condition	A/B common, standard flow	Variable range
Auxiliary 1st No. 1	100%=57L/min (15.1 US gpm)	10 to 100%
Auxiliary 1st No. 2	75%=43L/min (11.4 US gpm)	10 to 100%
Auxiliary 1st No. 3	50%=28L/min (7.4 US gpm)	10 to 100%

Maximum flow rate	A/B common, high-flow	Variable range
Auxiliary 1st Nos. 1, 2 and 3	180%=102L/min (26.9 US gpm)	101 to 180%

The table shows the 1-way flow rate when there is no load.




- When the selection bar is at a symbol of attachment, press the (B) key to change it to the desired symbol.
Select the symbol representing the attachment to be used.
- The setting for Auxiliary 1 No. 2 and Auxiliary 1 No. 3 can be done using the same procedure as above.
- Press and hold the (A) key for three seconds or more to complete the setting and return to the setting selection screen.
- Press the (C) key to cancel editing and to return to the setting selection screen.



- **Auxiliary 2nd flow rate setting
(2nd AUX SET)**

Set the flow rate ratio for the Auxiliary 2nd circuit.




a. For the key operation, refer to the Auxiliary 1st flow rate setting section.

Initial condition	Standard flow	Variable range
Auxiliary 2nd	C/D 100%=44 L/min (11.6 US gpm)	10 to 100%

- **Auxiliary 4th flow rate setting
(4th AUX SET)**

Set the flow rate ratio for the Auxiliary 4th circuit.




a. For the key operation, refer to the Auxiliary 1st flow rate setting section.

Initial condition	Standard flow	Variable range
Auxiliary 4th	G/H 100%=44 L/min (11.6 US gpm)	10 to 100%



MAINTENANCE


• Inputs/outputs (INPUTS/OUTPUTS)



AH1B033


Diagnosis and failure record can be checked.
Press the (A) key to proceed to the screen selected by the bar.
Press the (B) key to move the selection bar.
Press the (C) key to return to the side menu screen.

- Diagnosis (DIAGNOSIS)
Input/Output, Analog Input, PWM Output, Engine Control Module (ECM) can be checked.



AH1B035

The 9-page diagnosis data can be displayed.
Press the (B) key to display a different page.
Press the (C) key to return to the Diagnosis screen.



AH1B034

Press the (A) key to proceed to the screen selected by the bar.
Press the (B) key to move the selection bar.
Press the (C) key to return to the Maintenance screen.



IN	1 page	OUT
OFF/ON	Load dump relay	OFF/ON
OFF/I	Wiper relay	OFF/ON
OFF/C		
OFF/ON	Overload warning relay	OFF/ON

IN	2 page	OUT
OFF/ON	Blade float relay	OFF/ON
OFF/ON	Safety lock SOL.	OFF/ON
OFF/ON	Buzzer	OFF/ON
OFF/ON	AUX auto depress SOL.	OFF/ON

IN	3 page	OUT
OFF/G	Travel speed SOL.	OFF/ON
OFF/L		
OFF/G	AUX3 SOL.	OFF/ON
OFF/F		
OFF/2	AUX2/4 SOL.	OFF/ON
OFF/S	Swing/Adjust SOL.	OFF/ON

IN	4 page	OUT
OFF/ON	Blade right angle SOL.	OFF/ON
OFF/ON	Blade left angle SOL.	OFF/ON
OFF/ON	1 Way SOL.	OFF/ON



IN	5 page	OUT
OFF/ON	Option AUX4	OFF/ON
OFF/ON	Deceleration button	OFF/ON
OFF/ON	AUX2/4 SW	OFF/ON
OFF/ON	PWR mode SW	OFF/ON
OFF/ON	Highland mode SW	OFF/ON

IN	6 page	OUT
OFF/ON	Engine discriminate (Yanmar)	OFF/ON
OFF/ON	Automatic deceleration SW	OFF/ON


IN	7 page	OUT
OFF/ON	AUX1 flow rate select SW	OFF/ON
OFF/ON	Option 2 piece boom	OFF/ON
OFF/ON	Selector button (2 piece boom)	OFF/ON

IN	8 page	OUT
OFF/ON	AUX3 pressure SW	OFF/ON
OFF/ON	Pressure SW(auto decel)	OFF/ON
OFF/ON	Air cleaner filter clogging	OFF/ON

IN	9 page	OUT
OFF/ON	Water separator warning SW	OFF/ON
OFF/ON	Glow	OFF/ON
OFF/ON	AC compressor	OFF/ON
OFF/ON	BAT charge	OFF/ON




· Analog inputs (ANALOG INPUTS)



Displays the analog input information in one page.

Accel	0.00 V
Fuel	0.0 Ohm
Lift pressure	0.00 V
	0.0 Mpa

· PWM outputs (PWM OUTPUTS)



Displays the output information on the pump and the auxiliary circuits in two pages.


Page 1

Hydraulic pump	00000 mA
1st AUX Hydraulic A	00000 mA
1st AUX Hydraulic B	00000 mA

Page 2

2/4 AUX	
Hydraulic C/G	00000 mA
2/4 AUX	
Hydraulic D/H	00000 mA

· Engine Control Module (ECM)



Displays the engine output information in three pages.

Page 1

Pedal Position	000 %
Torque	0000 %
Engine Speed	0000 rpm
Operating Speed	0000 rpm
Glow	0

Page 2


Coolant Temp.	000 °C
Fuel Temp.	000 °C
Oil Pressure	0000 kPa
Fuel Rate	0000 L/h
Barometric Pressure	000 kPa

Page 3

Air Inlet Temp.	000 °C
Boost Pressure	000 kPa
Boost Temp.	000 °C
Battery Voltage	0000 V




- **Failure Record (FAILURE RECORD)**
The Active Failure Record data and the Past Failure Record data can be checked.



AH1B039

Press the (A) key to proceed to the screen selected by the bar.
Press the (B) key to move the selection bar.
Press the (C) key to return to the Maintenance screen.


- **Active Failure Record (ACTIVE)**



AH1B040

- **Vehicle error code list**
Pressing the (A) key while the Engine Error Code List is displayed changes the screen to the Vehicle Error Code List. Four latest codes are displayed.


- **Engine error code**



AH1B041

Pressing the (A) key while the Vehicle Error Code List is displayed changes the screen to the Engine Error Code List. The three latest code SPNs and the FMIs are displayed.
Press the (B) key to display a different page.
Pressing the (C) key returns to the Failure Record screen.

- **Past Fault History (PAST)**




AH1B042

- **Vehicle Error Code 1 to 12**
When the (A) key is pressed while the past engine error codes are displayed, the display changes to the past vehicle error code screen. The fault history data is displayed with the latest one at the top, as well as with the serial numbers (1 to 12) attached. The most recent time of fault occurrence recorded by the hour meter is also displayed.



 Engine error code 1 to 12



Pressing the (A) key while the past vehicle error codes are displayed changes to the past engine error code screen. The fault history data is displayed with the latest code SPNs and FMIs as well as the serial numbers of 1 to 12.


Press the (B) key to display a different page.

Pressing the (C) key returns to the Failure Record screen.



SWITCHES

STARTER SWITCH




IMPORTANT: Do not repeatedly switch the key from OFF to ON and ON to OFF over a short period. Doing so will cause engine breakdown.

OFF Position for stopping the engine and inserting or removing the key.

ON Position in which the engine is running. At this position, all the electrical equipment is functional. When the coolant temperature is too low, the engine is automatically preheated.

START Position for starting the engine. When the key is released, the switch automatically returns to the ON position.


ENGINE SHUTDOWN SWITCH <APPLICABLE MACHINE MODELS 126100003 OR LATER>



This switch is used to shutdown the engine if it fails to stop, due to machine failure or breakage, when the starter switch is set to the OFF position.

1. Press the switch (1).
2. After use, reset the switch (1).

THROTTLE CONTROLLER




This controls the engine speed.

- (A) Low idling
(B) Medium speed
(C) Maximum speed



HORN BUTTON




Press the button situated on the right operating lever to blow the horn.

DECELERATION BUTTON

WARNING

Before operating the deceleration button, set the operating lever to the neutral position and take your foot off the pedals. If the deceleration button is pressed while driving, the machine's operating speed will abruptly change to result in a dangerous situation.




Press this button on the right operating lever to lower the engine speed to low idling. Press the button again to return to the engine speed set with the throttle controller. For safety reasons, it is designed that the deceleration function is activated to set the engine revolutions to low idling whenever the engine is started. Cancel the deceleration mode by pressing the deceleration button as necessary.

Note: This deceleration button is capable of decreasing the engine speed and reducing the fuel consumption, with a simple operation, in a situation such as when little engine output is required and thus the operating or the travel levers are in neutral.

TRAVEL SPEED BUTTON

WARNING

When a load greater than a set value is applied during traveling in 2nd (high) speed, the speed will automatically slow down to 1st (low) speed. When the load becomes lighter, the speed will increase and return to 2nd (high) speed. It should be noted that the travel speed changes depending on the load condition (for machines with the automatic travel shift-down system).




Press this switch to set the travel speed to 2nd (high) speed. Press it again to return to 1st (low) speed.



AUXILIARY 1ST SWITCHES

Auxiliary hydraulic buttons




Press those buttons to control the flow of the oil in the first auxiliary hydraulic lines.

- Proportional control of the auxiliary hydraulic circuit is not possible.
- (A).....Hydraulic oil flows to the left auxiliary line (a).
(B) Hydraulic oil flows to the right auxiliary line (b).

Slider switch (Proportional control)

Proportional control allows for slow-to-fast/ fast-to-slow movement of attachment.

Example: If you move the slider switch half way, the attachment will move at approximately one-half the speed.



Move this switch to control the flow of the oil in the first auxiliary hydraulic lines.

- (A).....Hydraulic oil flows to the left auxiliary line (a).
(B) Hydraulic oil flows to the right auxiliary line (b).


Refer to “Auxiliary hydraulic lines (If equipped)” on pages 2-76 to 2-80.

AUXILIARY 2ND/4TH SWITCH (IF EQUIPPED)

Slider switch (Proportional control)


Proportional control allows for slow-to-fast/ fast-to-slow movement of attachment.

Example: If you move the slider switch half way, the attachment will move at approximately one-half the speed.



Move this switch to control the flow of the oil in the second auxiliary hydraulic lines.

- (C): Hydraulic oil flows to the left auxiliary line (c).
(D): Hydraulic oil flows to the right auxiliary line (d).



To use the auxiliary 4th hydraulic line, press the auxiliary 2/4 select button to change to the operation of the auxiliary 4th.

Refer to “Auxiliary hydraulic lines (If equipped)” on pages 2-76 to 2-80.



THIRD AUXILIARY HYDRAULIC SWITCH AND BUTTON (IF EQUIPPED)

Refer to “Third auxiliary hydraulic switch and button (If equipped)” on page 2-79.

AUXILIARY 2/4 SELECT BUTTON (IF EQUIPPED)

Refer to “Auxiliary 2/4 select button (If equipped)” on page 2-80.




DPF MANUAL REGENERATION/INHIBIT SELECT SWITCH <APPLICABLE MACHINE MODELS 126100003 OR LATER>

WARNING



- The DPF and the exhaust gas emitted from the exhaust line can be very hot while the engine is running or the regeneration is under way, as well as immediately after the engine is stopped. Be careful not to accidentally touch them; doing so could cause burns.
- Do not perform the DPF regeneration if the machine is surrounded by flammable items such as plants, trees, dry grass, wastepaper, oil and waste tires. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF.
- Do not perform the DPF regeneration in poorly-ventilated indoor spaces, as smoke may be generated during the regeneration.
- Do not perform regeneration when the engine hood is open. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF.




IMPORTANT: Press the manual regeneration side on the DPF manual regeneration/inhibit select switch to burn the particulate matter (PM), when the DPF manual regeneration lamp flashes and an alarm sounds. If the machine continues to be operated without performing the manual regeneration, the engine power will decrease and eventually the engine will stop running. The ECM warning display will also flash if the DPF needs to be repaired. A number appears on the engine error code screen. Refer to the “Engine error code list” and contact a Takeuchi sales or service dealer for repair.

• DPF manual regeneration

When the DPF manual regeneration symbol on the display starts flashing and an alarm starts sounding, perform the DPF manual regeneration by following the procedure below.

1. Park the machine in a safe place where there is no fire hazard.
2. Raise the safety lock lever to the lock position.
 - Do not lower the safety lock lever and move the control levers during regeneration. Doing so interrupts the regeneration.
3. Decrease the engine speed to low idling.
4. Press and hold the manual regeneration side on the DPF manual regeneration/inhibit select switch.



5. The manual regeneration symbol stops flashing and remains lit to indicate that the engine RPM is automatically increased and the DPF (1) regeneration (PM burning) has started.
6. Release the switch. Do not leave the machine during regeneration. It takes approximately 25 to 30 minutes, depending on the ambient temperature, to complete the regeneration operation.
7. The manual regeneration symbol goes off to indicate the end of manual regeneration.

Note:

- Since the exhaust gas is cleaned through the catalyst fitted inside the DPF, it has a smell different from that of the conventional diesel engine.
- In some cases smoke may be emitted from the tail pipe while the DPF regeneration is being performed. This is not a failure; it is due to burning of the particulate matter (PM).
- It is normal that a sound is produced when the DPF regeneration is started or completed; This is to adjust the air-intake throttle and EGR opening position.
- In some cases the noise associated with the DPF regeneration operation or cancel operation may change; this is not a failure.
- The DPF manual regeneration can be completed faster while the machine engine is warm rather than cold. Note that the manual regeneration does not start unless the coolant temperature is higher than a set value. The coolant temperature may increase while manual regeneration is being performed.

- Since the DPF regeneration is designed to work only when the accumulated particulate matter (PM) in the filter exceeds a certain amount, it will not start otherwise, even if you attempt to perform manual regeneration.

• **DPF regeneration inhibit (cancel)**

To cancel the DPF regeneration currently being processed (manual or auto), press the regeneration inhibit symbol side.

The DPF regeneration inhibit symbol appears on the display, and the regeneration operation must be performed again. Start the manual regeneration procedure from Step (1) above, as soon as possible. Do not press the DPF regeneration inhibit switch unless there is a risk of fire.

To cancel, press the switch again. Turning the starter switch to OFF will also cancel the operation.

<Cab>


Refer to “DPF auto regeneration/inhibit indicator lamp” and “DPF manual regeneration under way/regeneration promoting indicator” on page 2-18.

<Canopy>

Refer to “DPF Auto Regeneration/Inhibit” on page 2-31 and “DPF manual regeneration under way/regeneration promoting indicator” on page 2-33.



LIGHT SWITCH




When this switch is turned while the starter switch is at ON, the lights turn on as follows:

OFF Off

ON Switch lamps, front light, boom light, side lights and tail lamps will be lit. (switch lamp is lit)

WIPER SWITCH

IMPORTANT: If no washer fluid is discharged, do not operate the washer. Doing so may damage the pump.
IMPORTANT: Operating the wiper with no moisture on the windshield will scratch the glass. Use water or washer fluid when operating the wiper.
IMPORTANT: In cold climates, the wiper blade may freeze to the glass. Operating the wiper forcibly may damage the wiper motor.




OFF Off

INT Intermittence operation

ON Continuous operation


WASHER SWITCH



ON Pressing the ON side of the switch causes the washer to spray washer fluid. To stop spraying, release the switch.




AUTOMATIC DECELERATION SWITCH



When the ON side of the switch is pressed, the deceleration lamp in the instrument cluster flashes. This flashing stops when the deceleration function starts working, and the lamp remains lit while in the deceleration mode. The engine speed automatically drops to low idle (deceleration mode) four seconds after the control levers are set to neutral, to reduce fuel consumption. Moving the control levers will cause the speed to return to the original engine speed.

Switching from the deceleration button to the auto-deceleration switch will first return to the engine speed set with the throttle controller. Then, the engine will automatically enter the deceleration mode (low idling) if the control levers are not operated within four seconds.

POWER/HIGHLAND MODE SWITCH



• Power mode

- Pressing the PWR symbol side of the switch turns on the Power mode indicator lamp on the instrument cluster. The maximum engine output is obtained.
- STD mode: Pressing the PWR symbol side of the switch again turns off the power mode indicator lamp.

• Highland mode


This switch is used to reduce the engine load due to the hydraulic pump. When the machine is operated at a high-altitude site, the engine output is decreased due to thin air. In such cases, the hydraulic horse power is automatically adjusted to prevent the engine from stalling. Use this switch when the machine is operated at a high-altitude site.

- Pressing the PWR symbol side of the switch turns on the Power mode indicator lamp on the instrument cluster.
- To cancel the highland mode, press the PWR symbol side halfway to set to the neutral position. The highland mode indicator lamp goes out and enters the lowland mode.
Refer to “Multi-information display” on page 2-16.
Refer to “Instrument cluster” on page 2-28.




DETENT MODE SWITCH (AUXILIARY 1ST) (IF EQUIPPED)

IMPORTANT: Do not operate the machine in the detent mode for a long time. Doing so will increase the hydraulic oil temperature and shorten the service life of the hydraulic units.



This switch is used to change the operation mode of the auxiliary 1st button (A). Pressing the ON side of the switch causes the auxiliary button (A) to enter the detent mode. Pressing the OFF side changes to the momentary mode.

AUXILIARY 1ST AUTO TANK SWITCH (IF EQUIPPED)



Use this switch to change the direction of hydraulic oil flow in the Aux. 1st line.

- (1) When using a hydraulic breaker (1-way flow)
- (2) When using a reversible attachment (2-way flow)
- (3) The one-way flow can be set only when the button "A" of the Aux. 1 is pressed. (The tank circuit is automatically opened.)




LIFT OVERLOAD WARNING SWITCH (IF EQUIPPED)



WARNING

If the overload is not removed after the overload warning horn is sounded, the machine may tip over. If the horn starts sounding, stop operating the machine and lighten the load.




If a weight greater than the lifting capacity is applied or lifted, the overload warning device is activated and the horn sounds. (When the lift overload warning switch is turned on.)

OFF Off

ON On

BEACON LAMP SWITCH (IF EQUIPPED)



When this switch is turned on while the starter switch is at ON, the lamp turns on as follows:

OFF Off

ON Beacon lamp is lit




LEVERS AND PEDALS

SAFETY LOCK LEVER

WARNING

- Before standing up from the operator's seat to open/close the window or remove/install the lower window, lower the working equipment to the ground, raise the safety lock levers to engage the lock and stop the engine. If any controls should be accidentally touched when the safety lock levers is lowered (unlocked), the machine will suddenly move and cause serious injury or death.
- Be careful not to touch the operating levers when raising or lowering the safety lock lever.
- Before leaving the operator's seat, lower the working equipment to the ground, raise the safety lock levers to engage the lock and stop the engine. Also, be sure to remove the key, lock the door and covers, take it with you and store it in a specified place.




This device is for locking the operations of hoe attachment, slewing, auxiliary, dozer blade and traveling. When the lever is raised, the lever stand springs up to lock the lever.

OPERATING LEVERS

WARNING

- Before starting operation, carefully check which lever pattern you are going to use.
- It is described using the ISO pattern in this manual.




Use these levers to operate the boom, arm, bucket and upperstructure. Refer to "Lever pattern" on pages 3-6 and 3-7.

Refer to "Operating the working equipment" on pages 3-14 and 3-15.



BLADE LEVER



Use this lever to operate the dozer blade.

(A).....Blade up

(B) Blade down

Refer to “Operating the dozer blade” on page 3-15.


Float button (if equipped)



WARNING

- Do not press the float button while the machine is raised by the blade. Doing so will cause the machine to fall. If you must work beneath the raised machine, always use a secure support to keep the machine raised.
- Do not press the float button while the blade is raised. Doing so will cause the blade to fall. Lower the blade to the ground before pressing the float button.
- Do not travel forward while the blade is in the float mode.

Float operation



Button (C).....Float mode

Press the float button (C) to set the dozer blade to the float mode.


To cancel the float mode, press the float button (C) again. The float mode is temporally cancelled when the blade lever is tilted backward. To return to the float mode, tilt the blade lever back to the neutral position. Take caution when returning to the float mode.



TRAVEL LEVERS/PEDALS

WARNING

- Before operating the travel levers/pedals, make sure that the dozer blade is to the front of the operator's seat. Remember that when the dozer blade is to the rear of the operator's seat, the travel levers/pedals must be operated in the reverse direction from when it is to the front.
- Do not rest your foot on the pedal unless operating it for traveling. If the pedal is accidentally stepped while working, the machine may suddenly move and cause serious injury or death.




Use these levers/pedals to move forward or backward and to change directions. Refer to "Operating the travel levers/pedals" on page 3-10.

BOOM SWING PEDAL


WARNING

Keep the pedal cover to the locked position when not using the pedal. Stepping on a pedal accidentally when it is not locked may cause accidents.



Use this pedal to operate the boom swing.
(A).....Boom swing right
(B) Boom swing left
Refer to "Operating the boom swing" on page 3-15.

Pedal lock



Set the pedal cover over the pedal to lock it. Open the pedal cover from the pedal to unlock it.

MEMO



ACCESSORIES

AIR CONDITIONER (IF EQUIPPED)

CAUTIONS ON USE

Ventilate periodically

- When using the air conditioner over an extended period of time, open the windows about once each hour to let in fresh air.
- Your eyes may become irritated if you smoke while using the air conditioner. If this happens, open the windows to let in fresh air. Smoking particularly irritates the eyes when the air conditioner is being used. Since the humidity in the cab drops, the cornea becomes dry.
- If the outside air is dirty, set the air conditioner to the circulation mode.

Always maintain good visibility

Working with the dirty windows or fogged windows restricts visibility and is dangerous. Always clean dirt and moisture off the windows before working.

- The windows tend to get foggy when the humidity is high. If this happens, turn on the air conditioner to use outside air and the defroster to get rid of the fog.
- If the air conditioner is set to high when using the defroster, the difference between the external and internal temperatures increases, resulting in frost on the outside of the windows. If this happens, either turn the air conditioner off or turn the temperature control dial clockwise to increase the internal temperature.
- Mist may blow out of the air outlets. This is not a malfunction. When moist air passes through the evaporator on the air conditioner unit, water particles in the air freeze and are emitted as mist.

Do not overcool

For health reasons, the air inside the cab should be kept at a temperature at which you feel a little cool when entering the cab from outside (a difference of 5 to 6°C (41 to 43°F)). Remember to adjust the temperature properly.

Do not turn on the air conditioner until the engine is started

To avoid placing an excessive load on the compressor, wait until the engine is started and is running smoothly before turning on the air conditioner.

Let hot air out first

If the machine has been parked in the sun, open the windows and door to let the hot air out of the cab before using the air conditioner.

Caution on refrigerant (gas)


If the refrigerant comes in contact with skin or eyes, it may cause frostbite or eye damage. Never touch the refrigerant or loosen the parts on the cooling circuit. If the refrigerant gas leaks, keep flames away.

Off-season inspection

Even off season, run the air conditioner for 3 to 5 minutes at least once a week to maintain oil in the various parts of the compressor.




NAMES OF COMPONENTS



AQ0C001

1. Defroster
2. Condenser
3. Receiver dryer
4. Outlets
5. Compressor
6. Air conditioner unit
7. Circulation filter
8. Ventilation filter
9. Ventilation/Circulation select lever



AQ0C002


Control panel

10. Air conditioner switch
11. Temperature control knob
12. Fan dial



Air conditioner switch

IMPORTANT: To avoid placing an excessive load on the compressor, wait until the engine is started and is running smoothly before turning on the air conditioner.



Use this switch to turn on or off the cooling/dehumidifying function. When this switch is pressed while the engine is running with the fan dial set to ON, the lamp lights up and the cooling/dehumidifying function is turned on. Press this switch again or turn the fan dial to OFF to turn off the cooling/dehumidifying function.


Lamp is off OFF

Lamp is on ON

Note: To prevent leakage of refrigerant gas from the compressor's seal, operate the air conditioner at least once a week, regardless of the season.

Note: The air conditioner will not function if the temperature in the cab is low (3°C (38°F) or lower).

Fan dial



Use this dial to select the fan speed from the three levels. Turning this dial to the OFF position turns off the air conditioner.


OFF Turning off the fan and the air conditioner.

LO Low

ME Medium

HI High

Temperature control knob



Use this knob to adjust the air temperature.


COOL..... Decreases the temperature

WARM..... Increases the temperature

Note: No warm air is emitted if the temperature of the engine coolant is low.




Outlets



Move the louvers up and down or left and right to adjust the air flow direction and amount.

Ventilation/Circulation select lever



Use this lever to select between Ventilation and Circulation.

(C) Circulation



- Cool or heat the cab quickly
- When external air is dirty

(D) Ventilation

- Lets in fresh air
- Removes frosting from the windows
- Ventilates while cooling or heating

Operation

Dehumidifying and Heating (in cold climates or when the humidity is high)



Arrange the foot outlets and the defroster so that they are directed to the front window. Let the dehumidified warm air blow on the front window, to prevent frosting.

1. Set the desired temperature by turning the temperature control knob to between the center and the right end.
2. Set the fan dial to the desired position.




Cooling

CAUTION


- When the air conditioner is set to the circulation mode, the air in the cab gradually becomes dirty. Switch to the “ventilation” to ventilate once a comfortable temperature is obtained.
- Excessive cooling can be harmful to your health. It is best to keep the air inside the cab only about 5 to 6°C (41 to 43°F) cooler than the outside air.

Note: If the machine has been parked in the sun, open the windows and door to let the hot air out of the cab before using the air conditioner.




1. Set the fan outlet to the desired position.
2. Set the temperature by moving the temperature control knob to between the center and the left end.
3. Set the fan dial to the desired position.

Quick cooling



1. Set the fan outlet to the desired position.
2. Move the temperature control knob to the left end.
3. Set the fan dial to “HI”.
4. Tilt the Ventilation/Circulation select lever backward to select Circulation.

Heating




1. Arrange the outlet louvers so that air can be directed to the feet.
2. Set the fan dial to the desired position.
3. Set the temperature by moving the temperature control knob to between the center and the right end.
For the highest temperature, move the knob all the way to the right.
4. Turn the fan dial to the OFF position to turn off heating.



Defrosting or defogging the windows

Note: If the air conditioner fan is set to High when using the defroster, the difference between the external and internal temperatures increases, resulting in frost on the outside of the windows. If this happens, either turn off the air conditioner or move the temperature control knob to the right end to increase the internal temperature.




1. Set the temperature by moving the temperature control knob to between the center and the right end.
2. Set the fan dial to the desired position.
3. Tilt the Ventilation/Circulation select lever forward to select Ventilation.
4. Arrange the foot and defroster outlets so that they are directed to the front window.

CUP HOLDER

CAUTION

- Drinks may be spilled due to vibration when the machine is operating or traveling. Be particularly careful not to burn yourself with hot drinks.
- Note that the power supply socket or other electric parts may be damaged if drinks are spilled on them. Be careful not to spill fluid on them.




Use to hold cups or bottles.



ASHTRAY

WARNING

- Be sure to extinguish cigarettes and matches completely before putting them in the ashtray, and close the ashtray after each use.
- Do not overfill the ashtray with cigarette butts or put in paper or other easily burnable objects. Doing so could cause fire.




Pull the ashtray out towards you to use it. To clean, press the ash discharge button (1) and pull out the ashtray.

POWER SUPPLY SOCKET


WARNING

Use only those electric products which comply with the specifications of these sockets.

<Canopy>



<Cab>




This socket is used to supply power to the interior electrical components. When using, be careful not to exceed 12 V/5 A. To use, open the cap (1).



INTERIOR LIGHT



IMPORTANT: The battery capacity decreases if the interior light is left on for a long time when the engine is stopped.



OFF Remains off all the time.

ON Lights up all the time.

MIRRORS



Adjust the rear view mirrors and side view mirrors so that you have a better view.

1. Check the right side rear view
2. Check the left side rear view
3. Check the rear view.




EXTERNAL POWER SOCKETS




WARNING

Use only those electric products which comply with the specifications of these sockets.



For beacon



Use these sockets to connect the external power supply. When using, be careful not to exceed 12V/5A.

To use, open the cap (1).

MEMO




RADIO (FOR CAB)

CAUTIONS ON USE

- To ensure safe operation of the machine, always be sure to keep the volume of the radio down to a level where you can easily hear sounds from outside the machine.
- Do not use the radio for a long time when the engine is stopped. Doing so will drain the battery and make it difficult or impossible to restart the engine.
- Be careful not to allow water or other liquids to come into contact with the radio. Otherwise, it may result in malfunction.

NAMES OF COMPONENTS



(1) POWER button

Use this button to turn on or off the radio.

(2) LCD

Displays the time/the receiving frequency and the operation mode.

(3) Display button (DISP)

Pressing this button while the frequency is displayed on the LCD changes the display to the clock. Pressing the button again returns to the frequency. If the button is not pressed for five seconds, the display returns to the frequency.

(4) Auto store/Auto seek station (AST)

Press this button to automatically assign receivable radio stations to preset buttons (1 to 6).

(5) Tuning button (TUNE)

Press and hold this button ( or ) for one second or more to start seeking the receivable stations. The seeking stops when a station is found. To cancel tuning halfway, press the button again. Pressing the TUNE button () starts seeking stations with higher frequency. Pressing the TUNE button () starts seeking stations with lower frequency. The frequency changes as either button is pressed in one second intervals.



(6) Preset buttons (1 to 6) (PRESET STATION)

Each button can store three FM stations (FM1, FM2, FM3) and one MW (AM) station. For how to set these buttons, refer to "Presetting stations".

(7) Band button (BAND)

Pressing this button changes the band from FM1 to FM2, FM3 and MW (AM) in this order. The received band and its frequency appear on the display.

(8) VOL buttons

Use these buttons to control the sound volume. Press the button  to increase the volume and the button  to decrease the sound volume. Press and hold each button to continuously increase/decrease the volume.

(9) Clock zero set button (ZERO)

Use this button to set the minute to "00" when it is between "55" to "59" or "01" to "05".

The LCD returns to the frequency display if no more operation is performed for five seconds.

(10) Auxiliary input select button (AUX)

Pressing this button changes the input source to the external device connected to the AUX-IN (11) jack. The display of "AUX" appears on the LCD. Pressing the button again returns to the radio.

(11) Auxiliary input jack (AUX-IN)

Use this jack to connect an external audio source such as a portable music player. Pull off the rubber cap and connect the output terminal (headphone jack) of the portable player to the AUX-IN with the stereo mini-plug (3.5 mm) cord.

Be sure that jack is closed with the rubber cap when not in use.

Playing the radio

1. Turn the ignition key to the ACC or ON position, and then press the power button (1) to turn on the radio.
2. Select the band, FM or MW (AM) by pressing the BAND button.
3. Select the station with the preset button or the tuning button, and adjust the volume with the volume button.
4. To turn off the radio, press the power button.

Selecting a station-auto select

Press and hold the TUNE button  for one second or more to start seeking stations in the higher frequencies direction. Press and hold the TUNE button  for one second or more to start seeking stations in the lower frequencies direction. The radio will stop seeking when it finds an receivable station and start playing.

Selecting a station-manual select

The selection can be done manually. Press the tune  button to seek stations with higher frequencies. Press the tune  button to seek stations with lower frequencies.



Presetting stations

1. Press the BAND button to select a band (MW (AM) or FM), and then select the station by pressing the TUNE button for seeking.
2. To assign the selected station to a preset button, press and hold the button to be assigned for one second or more. The number of the preset button appears on the LCD.
3. For more stations to preset, repeat the steps 1 and 2 above.
 - If the preset button on which a station has been assigned is pressed and held for one second or more, the preset information will be modified.
 - If the stored information is erased during battery replacement on the vehicle, assign the stations again to the preset buttons.
 - Each preset button (1 to 6) can store three FM stations (one from each FM1, FM2, FM3) and one AM station.

Auto storing (AST)


Press the AST button while playing the radio. The radio automatically starts seeking the receivable stations within the band currently selected and assign each preset button (1 to 6) a station.

Note: The previous stations stored will be cleared (cancelled) by the auto storing. If the station stored in the preset button is not desirable, try to preset the station manually.

Auxiliary input (AUX)

- Connect a portable audio player and listen to your favorite music.
- Plug a patch cord (without resistor) into the headphone jack of the audio player.
- Plug a stereo mini plug (3.5 mm) into the AUX-IN jack on the radio.
- To listen to an external portable audio player, press the AUX button. (The “AUX” display appears on the LCD and the frequency display is changed to the clock display.)
- To return to the radio, press the AUX button again.
- When connecting, adjust the sound volume level of the audio player so that it is same as that of the radio.
- Adjust the sound volume of the audio player by using the volume control buttons on the radio.
- Do not connect a device with a larger output compared with a portable audio player.

Setting the clock



- If a frequency is displayed on the LCD, press the AUX button (auxiliary input) to display the clock.
- Use the tune (M) button to set the minute. Use the tune (H) button to set the hour.
- To set the minute digits to “00” when they are from “55” to “59” or from “01” to “05”, press the ZERO button.



Resetting

If there are any problems, such as the abnormal display of frequency or failure of selection, reset the radio by pressing the “4” button while pressing the AST button and the AUX button together. Then, “JP” and the clock display appear on the LCD, indicating that the radio is turned off. Note that the memory stored in the preset button is cleared.

Switching the volume mode when the radio is on

Switch the modes between SU and FI by pressing the (1) button while pressing the AST and AUX buttons together, when the radio is on.

The SU or FI display appears on the LCD, followed by the radio turning off by itself.

SU mode: The volume at power-off is retained.

FI mode: The volume at power-off is reset.

SPECIFICATIONS

Power source: 12/24 VDC (negative ground)

Maximum power consumption:
..... 3A or less (at max. volume, 24 V)

Maximum output power:
..... 16 W + 16 W (4Ω) (at 28.8 VDC input)
..... 5W+5W (4Ω) (at 14.4 VDC input)

Rated output power:
..... 12 W + 12 W (10% distortion, 4Ω) (at 28.8 VDC input)
..... 3.5 W + 3.5 W (10% distortion, 4Ω) (at 14.4 VDC input)

Dimensions:..... 178 (W) x 50 (H) x 65 (D) mm (excluding protrusions)

Receiving frequency:
..... MW (AM) 531 to 1602 kHz (Europe, Asia), 530 to 1710 kHz (North, Central and South America)
..... FM 87.5 to 108 MHz (Europe, Asia), 87.9 to 108 MHz (North, Central and South America)

Practical sensitivity:
..... MW (AM) 32 dB or less (S/N 20 dB)
..... FM 12 dB or less (S/N 30 dB)


S/N ratio:..... MW (AM) 40 dB or more
..... FM 50 dB or more

AUX-IN: Stereo mini jack (3.5 mm); rated input, 90 mV; 20 kΩ impedance

Note: Specifications and dimensions may be changed without notice.



AUXILIARY HYDRAULIC LINES (IF EQUIPPED)



AM1C026



WARNING

Oil may spurt out if pipes disconnected before releasing the pressure in the hydraulic system.

- Immediately after the engine is stopped and while the safety lock lever is still in the unlock position, turn the starter switch to ON and press each auxiliary hydraulic switch several times to release the pressure from the auxiliary hydraulic circuit.
- Press the air breather button to relieve the tank pressure.
- When disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.

These lines deliver the hydraulic oil necessary for operating a hydraulic breaker, crusher or other attachments.

- (1).....First auxiliary hydraulic lines
- (2).....Second auxiliary hydraulic lines
- (3).....Third auxiliary hydraulic lines
- (4).....Fourth auxiliary hydraulic lines

Stop valve

(S) : Closed

(O) : Open



Connecting the hydraulic circuits

To connect the attachment hydraulic lines, observe the following procedures:


1. Release the pressure remaining in the lines, and then close the stop valve.
Refer to “Releasing the residual pressure” on page 2-78.
2. Remove the plugs.
3. Connect the attachment hydraulic lines to ports (a/c) and (b/d). When installing a hydraulic breaker, connect the supply circuit to the port (a) and the return circuit to port (b).
4. Open the stop valves. When installing a hydraulic breaker, open the selector valve (1). Refer to “Selector valve” on page 2-79.
5. When connecting is complete, purge air from the hydraulic lines.
 - a. Start the engine and run it at a low idle speed with no load for 10 minutes.
 - b. With the engine running in low idle, operate the auxiliary hydraulic switches repeatedly (approx. 10 times) to purge air from the hydraulic lines.
 - c. Stop the engine and wait for at least 5 minutes until bubbles escape from the hydraulic oil in the tank.

IMPORTANT: Follow the procedures for purging air as instructed by the attachment manufacturer, if applicable.

6. Check for oil leaks.

Disconnecting the hydraulic circuits

1. Release the pressure remaining in the lines, and then close the stop valve.
Refer to “Releasing the residual pressure” on page 2-78.
2. Disconnect the lines from the ports (a/c) and (b/d).
3. Install the plugs.



Operating

Press those buttons to control the flow of the oil in the first/second auxiliary hydraulic lines.

- (A).....Hydraulic oil flows to left auxiliary line (a).
- (B) Hydraulic oil flows to right auxiliary line (b).
- (C) Hydraulic oil flows to left auxiliary line (c).
- (D) Hydraulic oil flows to right auxiliary line (d).

Releasing the residual pressure


After the auxiliary hydraulic circuits have been used, pressure remains in the circuits. This is called the residual pressure. Release this residual pressure before disconnecting the lines.

Perform the residual pressure releasing within 10 minutes after the engine stopping.

1. Park the machine on a flat, rigid and safe ground.
2. Stop the engine.
3. Lower the safety lock lever to the unlocked position.
4. Turn the starter switch to the ON position.
5. Press the auxiliary hydraulic switches several times to release the residual pressure in the auxiliary hydraulic circuitry.



Selector valve



Open..... When using a hydraulic breaker
(1-way flow)


Closed..... When using a reversible
attachment (2-way flow)

Change the direction of the hydraulic oil flow
by opening or closing the selector valve (1)
inside the right side cover.

For the machine with the auxiliary 1st auto
tank switch, use the switch to select the
flow.

Refer to “Auxiliary 1st auto tank switch (If
equipped)” on page 2-56.

Third auxiliary hydraulic switch and button (If equipped)



The auxiliary 3rd is mainly used for the
attachment that can quickly connect/
disconnect the bucket. After the engine is
started, hydraulic oil constantly flows into the
pipe (e). This allows the pressure in the (e)
side to increase, preventing the pin inserted
on the bucket from coming out. If the
pressure in the (e) side drops, the warning
lamp starts flashing to warn that the bucket
may come out. For a safety reason, the
bucket can be disconnected only when the
button (1) and the switch (2) are pressed at
the same time. When they are pressed, the
hydraulic oil flows into the line (f) to increase
the pressure there. As the result, the pin on
the bucket comes out and the bucket is
removed from the machine.


- **Bleeder unit for simultaneous use with
the auxiliary 1st and 2nd (if equipped)**

Pressing both the auxiliary 3rd button (1)
and the switch (2) makes it possible to
release internal pressure from the auxiliary
3rd (e side), auxiliary 1st and auxiliary 2nd
at the same time. (The pressure is kept
drawn for six seconds after the button and
the switch are released.) This enables
faster attachment change.




Third auxiliary hydraulic warning lamp

<Canopy>




<Cab>



This lamp illuminates and an alarm sounds if the auxiliary 3rd hydraulic pressure drops abnormally while the engine is running.

Auxiliary 2/4 select button (If equipped)



This button is used to change from the second auxiliary operation to the fourth auxiliary operation.

Pressing this button displays the second auxiliary on the LCD to indicate that the second auxiliary operation is enabled. Pressing this button again displays the auxiliary 4th on the LCD to indicate that the auxiliary 4th operation is enabled. The actual operation is performed with the auxiliary 2nd/4th switch (slider switch). Refer to "Auxiliary 2nd/4th switch (If equipped)" on page 2-50.



OPERATING THE MACHINE WITH AN ACCUMULATOR

WARNING

Be sure to handle the high-pressure nitrogen gas enclosed in the accumulator with care. If handled incorrectly, it could explode and cause serious injury. Strictly observe the following precautions:


- Do not disassemble.
- Do not allow flame near or throw it into a fire.
- Do not drill, weld or fuse.
- Do not subject it to physical shock such as hitting, rolling or dropping.
- Before disposing of the unit, the sealed gas must be drained. Contact a Takeuchi service agent for help.

For a machine with an accumulator, the residual pressure in the auxiliary hydraulic circuit or the working equipment circuit can be released even after the engine is stopped.

Releasing residual pressure

Residual pressure refers to the pressure that remains in the hydraulic circuit after the operation. Release the residual pressure as necessary by using the following steps. Perform the residual pressure releasing within 10 minutes after the engine stopping.

1. Return the throttle controller to idle the engine at low speed.
2. Lower the bucket and dozer blade to the ground.
3. Check that the safety lock lever is in the released position.
4. Stop the engine.
5. Turn the starter switch to the ON position.



6. Move or press the auxiliary hydraulic switches several times to release the residual pressure in the circuitry.
7. Move all the control levers and pedals several times in all directions to release the pressure from the working equipment circuitry.
8. Raise the safety lock lever to engage the lock.

Lowering the boom when the engine has stopped

Perform this operation within 10 minutes after the engine stopping.

1. Sit at the operator's seat.
2. Turn the starter switch to the ON position.
3. Lower the safety lock lever to the unlock position
4. Slowly push the operating lever forward to lower the boom.



LOAD SAFETY DEVICE (IF EQUIPPED)

The load safety devices include an emergency shut-off valve and an overload warning device.

Emergency shut-off valve




WARNING


If the boom or arm stops due to the breakage of hose, immediately move away from the load being lifted and go to a safe location.

The emergency shut-off valve (1) prevents the boom or arm from falling rapidly in case the hydraulic hose is broken.

Boom



Arm (option)



If the hose breaks and the emergency shut-off valve (1) is activated to stop the operation of boom or arm, lower the boom or arm by slowly operating the lever while ensuring safety. Ask your sales or service dealer for repair.




Overload warning device



WARNING

If the overload is not removed after the overload warning horn is sounded, the machine may tip over. If the horn starts sounding, stop operating the machine and lighten the load.

If a weight greater than the lifting capacity is applied or lifted, the overload warning device is activated and the horn sounds. (When the lift overload warning switch is turned on.)



AM1B057

Lift overload warning switch

OFF Off

ON On



FUEL SUPPLY PUMP (IF EQUIPPED)



DANGER

Do not use the fuel supply pump for gasoline or hydraulic oil. Doing so could result in explosion or damage.


Only use the fuel supply pump for diesel fuel.



CAUTION

Be sure to close the cab door before opening the left side cover and work inside. If not, the wind-blown door could cause injury by striking you in the head or body.

This device automatically supplies fuel to the fuel tank and stops automatically when the fuel tank is full.



1. Open the left side cover.
2. Insert the pump's nozzle (1) in the fuel supply tank.
3. Press the switch (2).
The pump stops automatically once the fuel tank is full.
4. Turn off the switch.
5. Store the nozzle.

OPERATION





BEFORE STARTING



OPERATION

GETTING ON OR OFF THE MACHINE



WARNING

- Do not jump on or down from the machine. Never attempt to get on or off the moving machine.
- When getting on or off the cab, first fully open the door to the locked position and check that it does not move.



- Climb up/down the steps holding the handrail to support your weight in a three point secure stance (hand and feet).
- Never use the safety lock lever or control levers as hand holds.

WALK-AROUND INSPECTION

Perform the walk-around inspections once a day before starting the engine for the first time that day.

Refer to "MAINTENANCE, Walk-around inspection", on pages 5-16 and 5-17.

DAILY INSPECTION


Perform the daily inspections once a day before starting the engine for the first time. Refer to "MAINTENANCE, Daily inspection", on pages 5-18 to 5-23.




STARTING AND STOPPING THE ENGINE

BEFORE STARTING THE ENGINE


1. Adjust the seat for a comfortable operating position.
2. Fasten the seat belt.



3. Check that the safety lock lever is in the locked position.




4. Check that all levers and pedals are in the neutral position.




5. Insert the key into the starter switch, turn it to the ON position, then perform the following inspections:

<Canopy>



<Cab>



- All warning lamps flash and an alarm is sounded for two seconds. The meters also start functioning. After two seconds, the deceleration lamp (3) stops flashing and remains lit, while the battery charge warning lamp (1) and engine oil pressure warning lamp (2) remain flashing. (If the auxiliary 3rd is selected, it is also flashing.) The other lamps go out.
- Turn on the light switch to check that the boom light, front light, side lights and tail lamps turn on.
- Check the fuel level.

If a lamp does not light or the alarm is not sounded, the display or a wire may be damaged. Ask your sales or service dealer for repair.



STARTING THE ENGINE


WARNING

- Clear all personnel from the work area.
- Sound the horn to warn people around the machine.

IMPORTANT: Do not run the starter motor for more than 15 consecutive seconds. If the engine fails to start, wait for 30 seconds, and then try again to start the engine.

IMPORTANT: If the engine stalls due to fuel shortage, add fuel, turn the key to the ON position for 60 seconds, and then turn it to the START position. Running the starter for a long time before there is enough fuel is going through can cause the starter to fail.

Normal starting




1. Turn the starter key to the START position and start the engine.
2. Once the engine starts, release the key. The key automatically returns to the ON position.
3. Check that the warning lamps are off. For safety reasons, it is designed that the deceleration function is activated to set the engine revolutions to low idling whenever the engine is started. Cancel the deceleration mode by pressing the deceleration button as necessary.
4. Warm up the engine. Refer to "Warming up the engine" on page 3-5.
5. After the completion of the warming up,

press the deceleration button to cancel the deceleration mode.


Starting in cold climates

WARNING

Never use starting fluid on this engine, as the starting fluid could cause an explosion.



1. Turn the throttle controller to the middle position.



2. Turn the starter key to the ON position, and confirm that the glow lamp is on. (The glow lamp stays lit for 15 seconds when the coolant temperature is -10°C (14°F).)
3. After the glow lamp goes out, press the deceleration button (to cancel the deceleration mode), and then turn the key to the START position to start the engine.
4. Once the engine starts, release the key. The key automatically returns to the ON position.
5. Check that the warning lamps are off.
6. Return the throttle controller to the original position and warm up the engine. Refer to "Warming up the engine" on page 3-5.




Note: The glow lamp turns on if the coolant temperature is low after the engine is started.

WARMING UP THE ENGINE

IMPORTANT: Avoid racing the engine until it has warmed up.


Do not warm up the engine for a long time (20 minutes or more). When idling is required, occasionally place a load or run the engine at medium speed.




1. Return the throttle controller, and then run at a low idle with no load for 5 minutes.

STOPPING THE ENGINE

IMPORTANT: Do not stop the engine suddenly when operating with heavy loads or at the maximum speed. Doing so may cause the engine to overheat or seize. Never stop running the engine suddenly except in emergency.



1. Return the throttle controller.
2. Idle the engine for about 5 minutes to gradually let it cool.



3. Turn the starter key to the OFF position to stop the engine.




OPERATING THE MACHINE

LEVER PATTERN (ISO PATTERN)

WARNING


- Before starting operation, carefully check which lever pattern you are going to use.
- It is described using the ISO pattern in this manual.



	Left crawler forward		Right crawler forward
	Left crawler reverse		Right crawler reverse
	Arm out		Boom lower
	Arm in		Boom raise
	Upperstructure slew left		Bucket load
	Upperstructure slew right		Bucket dump
	Boom swing left		Dozer blade lower
	Boom swing right		Dozer blade raise

**LEVER PATTERN (G PATTERN) (IF EQUIPPED)****⚠ WARNING**

- Before starting operation, carefully check which lever pattern you are going to use.
- It is described using the ISO pattern in this manual.



	Left crawler forward		Right crawler forward
	Left crawler reverse		Right crawler reverse
	Boom lower		Arm out
	Boom raise		Arm in
	Upperstructure slew left		Bucket load
	Upperstructure slew right		Bucket dump
	Boom swing left		Dozer blade lower
	Boom swing right		Dozer blade raise

Refer to "Selecting a lever pattern" on page 8-5.




WARMING UP THE MACHINE (HYDRAULIC OIL)

WARNING

Operating the working equipment without warming up the machine (hydraulic oil) is dangerous, as the working equipment cannot response to controls quickly or may move in unexpected ways, and the safety devices may not operate properly. Be sure to sufficiently warm up the machine.


IMPORTANT: Do not operate the levers too quickly when the hydraulic oil temperature is below 20°C (68°F). The proper hydraulic oil temperature during operation is 50 to 80°C (122 to 176°F). If operations must be performed at lower temperatures, heat up the hydraulic oil to at least 20°C (68°F).

Normal warm-up




AG8D001

1. Turn the throttle controller to the middle position, and then run the engine at medium speed for about five minutes with no load.




AM1D009

2. Fully lower the safety lock lever to disengage the lock and lift the bucket from the ground.




AG7D017

3. Extend and retract each of the cylinders slowly several times with no load.



AG7D018

4. Slew slowly to the left and the right several times.




AG7D019

5. Travel slowly forward and in reverse several times.

**Warm-up in cold climates**



1. Perform the normal warm-up procedure.




2. Set the bucket cylinder at the stroke end and keep it there.
Do not keep this condition for more than 30 seconds.
3. Repeat Step 2 until the bucket operating speed becomes normal.

INSPECTION AFTER WARM-UP

After warming up the engine and machine (hydraulic oil), perform the checks and inspections described below, and repair if necessary.

<Canopy>**<Cab>**

1. Check that the warning lamps and meters are as follows:
 - Are all warning lamps off?
 - Is the water temperature level within the green range?
2. Check that there are no irregularities in the exhaust color, sound and vibrations.




3. Raise the safety lock lever to the locked position, and then check that the operating and travel levers are locked.



OPERATING THE TRAVEL LEVERS/ PEDALS


WARNING

- Never allow anyone to enter the machine's slewing radius and path.
- Signal your intention to move by sounding the horn.
- There is a blind spot in the rear of the machine. Before traveling in reverse, as necessary, swing the cab around in reverse to check that the area is safe and clear.




- Before operating the travel levers/pedals, make sure that the dozer blade is to the front of the operator's seat. Remember that when the dozer blade is to the rear of the operator's seat, the travel levers/pedals must be operated in the reverse direction from when it is to the front.
- Clear all obstacles from the path of the machine.


Moving the machine forward and backward




1. Turn the throttle controller and increase the engine speed.



2. Fully lower the safety lock lever to disengage the lock.




3. Fold the hoe attachment and lower it 30 to 40 cm (12 to 16 in.) above the ground.
4. Lift the dozer blade.
5. Operate the left and right travel levers as below.



When the dozer blade is in front of the operator's seat:

- ➔ To move forward:
Tilt the levers forward.
- ⇨ To move backward:
Tilt the levers backward.



When the dozer blade is behind the operator's seat:


- ➔ To move forward:
Tilt the levers backward.
- ⇨ To move backward:
Tilt the levers forward.

Traveling in 2nd (High) speed




WARNING

When a load greater than a set value is applied during traveling in 2nd (high) speed, the speed will automatically slow down to 1st (low) speed. When the load becomes lighter, the speed will increase and return to 2nd (high) speed. It should be noted that the travel speed changes depending on the load condition (for machines with the automatic travel shift-down system).



Press the travel speed switch to set to the 2nd (high) speed, and press it again to return to the 1st (low) speed.


**Pivot turn**

AG7D027

Turning to the left when stopped:

- ➔ To turn forward to the left:
Tilt the right lever forward.
- ⇒ To turn backward to the left:
Tilt the right lever backward.

To turn to the right, operate the left lever in the same way as for the right lever.




AG7D028

Turning to the left while traveling:

- ➔ To turn left while traveling forward:
Set the left lever to neutral.
- ⇒ To turn left while traveling backward:
Set the left lever to neutral.

To turn to the right while traveling, operate the right lever in the same way as for the left lever.

Spin turn

AG7D029

- ➔ To spin left:
Tilt the left lever backward and the right lever forward.
- ⇒ To spin right:
Tilt the right lever backward and the left lever forward.



STOPPING TRAVEL




WARNING

- Park the machine on a flat, rigid and safe ground. Set the parking brake. If you must park on a slope, chock the tracks to block the machine.
- If any control is accidentally touched when the safety lock lever is not locked, the machine may suddenly move and cause serious injury or death.



CAUTION

Never stop running the machine suddenly except in emergency. Stop in good time, if possible.



AG7D030


1. Set the left and right travel levers slowly to the neutral position. The machine stops.



OPERATING THE WORKING EQUIPMENT

WARNING

- Before starting operation, carefully check which lever pattern you are going to use.
- It is described using the ISO pattern in this manual.



Use the right operating lever to operate the boom and bucket.

Use the left operating lever to operate the arm and slewing.


Return the operating levers to the neutral position to stop the hoe attachments.

1. Lower the safety lock lever to the unlocked position.
2. Set the pedal cover to the unlocked position.

Slewing


WARNING

Check the surrounding area for safety before slewing.



- ➔ Upperstructure slew left:
Tilt the left operating lever to the left.
- ➔ Upperstructure slew right:
Tilt the left operating lever to the right.


Operating the boom



- ➔ Boom lower:
Tilt the right operating lever forward.
- ➔ Boom raise:
Tilt the right operating lever backward.




Operating the arm



AG7D034

- ➔ Arm in:
Tilt the left operating lever backward.
- ⇒ Arm out:
Tilt the left operating lever forward.


Operating the boom swing



AM1D012

- ➔ Boom swing left:
Step on the left side of the pedal.
- ⇒ Boom swing right:
Step on the right side of the pedal.


Operating the bucket



AG7D035

- ➔ Bucket load:
Tilt the right operating lever to the left.
- ⇒ Bucket dump:
Tilt the right operating lever to the right.

Operating the dozer blade



AG7D037

- ➔ Dozer blade lower:
Tilt the lever forward.
- ⇒ Dozer blade raise:
Tilt the lever backward.




OPERATING PROCEDURES

PROHIBITED OPERATIONS

WARNING


- Do not operate on bedrock (hard or soft).
- Do not slew /swing while traveling. If you must operate the hoe attachment while traveling, operate at speeds slow enough so you have complete control at all times.

Do not perform demolition or leveling using slew force




Do not demolish walls or level ground using slew force. Also, do not dig the bucket teeth into the ground during slewing. Doing so will damage the hoe attachment.

Do not dig while traveling




Do not dig the bucket into the ground and use the traveling force to dig.

Be gentle when using the hydraulic cylinder



Do not extend the hydraulic cylinders to the stroke ends. Operate them with leeway.



Do not support the machine body with the hoe attachment when the body is lowering with the arm cylinder fully extended. Doing so concentrates the load on the arm cylinder and could damage the arm cylinder.




Do not drive piles with the bucket or dig by banging the bucket




Doing so will shorten the service life of the hoe attachment. Use the hydraulic force to dig.

Do not perform operations using the machine's dropping force




Putting excessive strain on the machine will shorten its service life. When digging, use the hydraulic force of the cylinders and the shallow and long strokes.

Digging bedrock




For hard base rock, break the rock up into small pieces with a breaker, etc., before digging. This prevents damage to the machine and is thus more economical in the end.



Caution on exposing the dozer blade to shocks



Hitting the dozer blade against rocks, etc., could damage the dozer blade or the blade cylinder.


**Caution on folding the hoe attachment**

Be careful not to let the bucket hit the dozer blade when the hoe attachment is being folded.

Do not use the dozer blade as an outrigger**Pay attention to the dozer blade when digging**

When digging deeply with the dozer blade positioned at the front, be careful that the boom cylinder and bucket do not hit the dozer blade.

Operate with the dozer blade at the rear whenever possible.


Caution on digging down with the dozer blade

This dozer blade is designed for simple earth pushing. Do not dig down deeply with the dozer blade. Doing so could damage the dozer blade and undercarriage.




CAUTIONS ON OPERATING

Cautions on traveling



Traveling over obstacles (rocks, stumps, etc.) may put a great load on the machine body and may cause damage to it. Avoid crossing over obstacles whenever possible. If you must do so, keep the hoe attachment near the ground, travel at a low speed, and go over the obstacle at the center of the crawler.


Cautions on traveling in 2nd (High) speed




- On uneven ground, maintain the low speed and avoid starting, stopping or changing directions abruptly.
- When a load greater than a set value is applied during traveling in 2nd (high) speed, the speed will automatically slow down to 1st (low) speed. When the load becomes lighter, the speed will increase and return to 2nd (high) speed. It should be noted that the travel speed changes depending on the load condition (for machines with the automatic travel shift-down system).

- When traveling in 2nd speed, do so with the dozer blade at the front.

Cautions on using machine in water



If the rear of the machine is submerged in water as shown in the figure above, it causes the radiator fan to turn in water, resulting in damage to the fan. The rear of the machine must not be submerged.



- **Allowable water depth**
Use the machine in water only when the water is up to the bottom of the carrier roller (1).
- For those parts used in water for a long time, apply enough grease until the old grease is expelled.
- Never submerge the slew bearing or main body in water or sand. If submerged, contact a Takeuchi service agent for inspection.




CAUTIONS ON TRAVELING ON SLOPES



WARNING


- Never travel on slopes that are too steep for the machine to maintain its stability. (maximum gradeability: 30°, lateral tipping angle: 15°) Note that in reality, the machine's stability becomes lower than the above values depending on the working condition.
- When traveling on slopes, lower the bucket to a height of 20 to 30 cm (8 to 12 in.) above the ground. When climbing a steep slope, extend the hoe attachment to the front. In emergencies, lower the bucket to the ground and stop the machine.
- When traveling on slopes or grades, drive slowly in 1st (low) speed.
- When climbing a hill, keep the operator's seat facing the hillside. When descending a hill, keep the operator's seat facing the downhill direction. In either case, travel must be done while paying attention to the ground in front of the machine.
- Do not descend slopes in reverse.



- Do not change directions on slopes or traverse slopes. First return to a flat surface, and then take an alternative path.


- The machine may slip sideways even on a slight slope if they are covered with grass or dead leaves, or when traveling on a wet metal plate or frozen surfaces. Do not allow the machine to position sideways to slopes.

Traveling posture on slopes Climbing slopes




When climbing slopes of 15° or more, maintain the machine posture as shown in the figure above.


Descending slopes




When descending slopes of 15° or more, slow down the engine speed and maintain the machine posture as shown in the figure above.

**Braking when descending slopes**

When descending slopes, the brakes are applied automatically once the travel levers are returned to the neutral position.

If the crawler slips

If the crawler slips while climbing a slope and impossible to travel, use the pulling force of the arm to climb the slope.

If the engine stops

If the engine stops when descending a slope, set the travel levers to the neutral position, stop the machine, then start the engine.

Do not open the door while traveling on slopes


Opening the door while traveling on slopes is dangerous, as the force required to open and close the door changes abruptly. Always keep the door closed when traveling on slopes.



GETTING OUT OF MUD


If the machine gets stuck in mud, use the procedure below to get it out.

If one crawler is stuck



1. Swing the bucket to the side of the crawler being stuck.
2. Set the arm and boom to an angle of 90 to 110°.
3. Press the bottom of the bucket (not the teeth) against the ground.
4. Place a plank or the like under the lifted crawler.
5. Lift the bucket and slowly move the machine out of the mud.


If both crawlers are stuck



1. Perform the steps 1 to 4 above for both crawlers.
2. Dig the bucket into the ground in front of the machine.
3. Pull with the arm while traveling forward to slowly move the machine out.


OPERATIONS POSSIBLE WITH THIS MACHINE

Excavating



1. Set the dozer blade on the side opposite to the side you want to dig on.
2. Use the arm and bucket and dig with shallow, long strokes. The maximum digging force can be obtained when the boom and arm angle is 80 to 120°. Use this angle for effective digging.


Digging ditches



Install a bucket suited for digging ditches and set the crawlers parallel to the ditch to be dug for greater efficiency. When digging wide ditches, dig the sides first, and then dig the center.




Digging side drains



Use the boom swing function to dig side ditches as shown in the figure.


Loading



When loading dirt onto a truck bed, load from the back of the truck, as it is easier and able to load more load than doing it from the front.

Also, use a small slewing angle for greater efficiency.

Leveling



1. Bring the hoe attachment close to the body.
2. Gradually remove the dirt from the side of the mound.
3. Once the mound is low, remove the dirt from the top. If the load becomes too heavy for the machine body, adjust by raising or lowering the dozer blade.




PARKING THE MACHINE

PARKING




WARNING



AG7A058

- Park the machine on a flat, rigid and safe ground. Set the parking brake.



AG7A059PE

If you must park on a slope or incline, park the machine securely and block the movement of the machine.

- When parking on a street, use barriers, caution signs, lights, etc., so that the machine can easily be seen even at night to avoid collision with other vehicles.
- Before leaving the operator's seat, raise the safety lock lever to engage the lock and stop the engine. Also, be sure to remove the key, lock the door and covers, take it with you and store it in a specified place.

3. Lower the bucket and the dozer blade to the ground.
4. Raise the safety lock lever to the locked position.
5. Stop the engine and remove the key. Refer to "Stopping the engine" on page 3-5.


For machines equipped with accumulator: Refer to "Operating the machine with an accumulator" on page 2-81.

INSPECTION AND CHECKS AFTER STOPPING THE ENGINE

1. Check for oil or water leak and inspect the working equipment, covers and undercarriage. If any irregularities are found, repair.
2. Fill up the fuel tank.
Refer to "Inspecting the fuel level" on page 5-21.
3. Remove any paper scraps or dirt from the engine room.
4. Remove any mud from the undercarriage.

Locking

Be sure to lock the following places:



AG7A009

- Cab door
- Engine hood
- Covers

1. Set the left and right travel levers to the neutral position.
2. Return the throttle controller to set the engine to low idling.



HANDLING IN COLD

CLIMATES

PREPARING FOR COLD CLIMATES

Starting engine in cold climates is not easy, and it becomes more difficult if the coolant freezes. Prepare for cold-climate problems as follows.

Replacing the fuel and lubricant

Replace the hydraulic oil, engine oil and fuel with those intended for cold climates. Refer to “Fuel and lubricant table” on page 5-4.

Engine coolant



WARNING

The engine coolant is combustible. Keep away from flame.

Use long-life coolant (antifreeze) and tap water for the engine coolant.

Note: New machines are delivered with JIS Type 2 long-life coolant (antifreeze) at a concentration of 50%.

Refer to “Fuel and lubricant table” on page 5-4.

Battery

As the temperature drops, the battery performance decreases.

Inspect the battery. If it is discharging, contact a Takeuchi service agent to have the battery recharged.

Refer to “Inspecting the battery fluid level and replenishing” on page 5-31.

CAUTIONS AFTER OPERATIONS

Observe the following cautions to prevent mud, water, or the undercarriage from freezing and making it impossible for the machine to move.

- Remove all mud and water from the machine body. In particular, wipe the hydraulic cylinder rod clean to prevent damage to the seal caused by mud or dirt on the rod surface getting inside the seal together with drops of water.
- Park the machine on hard and dry ground. If this is impossible, park the machine on a wooden board placed on ground.
- Drain any water in the fuel tank to prevent it from freezing.

Refer to “Draining the water from the fuel tank” on page 5-30.

- As the battery capacity drops markedly in low temperatures, cover the battery or remove it from the machine and keep it in a warm place.

If the electrolyte level is low, add distilled water in the morning before beginning work. To prevent the battery electrolyte from freezing in the night, do not add water after the day's work.

AFTER THE COLD CLIMATE

When the climate becomes warmer, do as follows:

- Replace the fuel and oil for all parts with those specified in the “Fuel and lubricant table”. Refer to “Fuel and lubricant table” on page 5-4.
- If a coolant of “one season type” is used, drain the cooling system completely, clean out the inside of the cooling system thoroughly, and fill with tap water. Refer to “Cleaning the engine cooling system” on page 5-46.



HANDLING RUBBER CRAWLERS

Rubber crawlers have an inherent weakness, lack of strength, due to their use of rubber. Be sure to observe the prohibitions and cautions below to prevent the crawlers from being damaged or coming off.


PROHIBITIONS

Do not travel or operate the machine in the following places:




AG7E031

- Traveling and slewing on crushed rock, extremely rough hard rock, steel beams, scrap iron, or near the edges of steel plates will cause damage to the rubber crawlers.



AG7E032

- Traveling on riverbeds or places where there are large numbers of boulders may cause the stones to get caught and damage the crawler or make the crawler come off.
- Do not use the machine on the seashore. The salt may corrode the steel core.



AG7E033

- Do not let fuel, oil, salt or chemical solvents get on the crawlers. These substances may corrode the bonding of the steel cores on the crawlers, resulting in rust or peeling. If any of these substances gets on the crawler, immediately clean it off with water.




AG7E034

- It will cause an irregular wear or damage to the lugs, if the machine travels on irregular surfaces such as recently paved with asphalt, exposed to a bonfire or of hot iron sheets under the blazing sun.
- Do not move earth in places where the rubber crawlers may slip. Doing so may speed up lug wear.




CAUTIONS

Observe the following cautions when operating the machine:



- Do not turn the undercarriage with the front of the machine body lifted using the hoe attachment (the upperstructure is not turned). Doing so will twist the crawlers with the load concentrated on a single point on the crawler belt, causing rapid damage to the crawlers.
- Avoid changing course abruptly or spin-turning on concrete surfaces whenever possible. Doing so may wear or damage the rubber crawlers.
- Avoid drops that may expose the rubber crawlers to strong shocks.
- Salt, potassium chloride, ammonium sulfate, potassium sulfate, and triple superphosphate of lime can damage the crawler belts. If any of these substances gets on the crawler belts, wash it off thoroughly with water.
- Do not let the sides of the rubber crawlers rub against concrete or walls.
- Do not damage the rubber crawlers by hitting the bucket against them.
- Be especially careful on snowy or frozen surfaces in winter, as the crawler belts tend to slip in such conditions.
- Use rubber crawler belts at temperatures between -25°C to $+55^{\circ}\text{C}$ (-14°F to 131°F).
- When storing the rubber crawlers for long periods of time (three months or more), do so indoors in a place not exposed to direct sunlight or rain.




- Rubber crawler belts are not as stable as steel crawler belts since the entire lugs are made of rubber. Be very careful when slewing and swinging sideways.

PREVENTING THE RUBBER CRAWLERS FROM COMING OFF

Observe the following cautions to prevent the crawler from coming off:

- Always keep the crawlers at the proper tension.



- When traveling over a large step such as a cobblestone or rock (20 cm (8 in.) or deeper), climb up the step at the right angle and do not change courses on top of the step.




- When climbing in reverse, do not change directions at the point where the slope starts.





- Do not change directions when the crawler belts are slack as shown in the figure.



- Avoid traveling by setting one crawler on a slope or projecting portion and the other crawler on a flat surface (with the machine at a tilt of 10° or more). Travel with both crawlers set on flat surfaces.



- The rubber crawler belts will come off if the machine travels backward in this condition.



- The rubber crawler belts will come off if the machine turns in this condition.





LOADING AND UNLOADING




WARNING



The machine may roll or tip over or fall while being loaded or unloaded. Take the following precautions:

- Select a firm, level surface and keep sufficient distance from road shoulders.
- Secure the ramps of adequate strength and size to the truck bed. The slope of the ramps must not exceed 15°. If the ramps are bowed down too low, support them with poles or blocks.
- Never use the working equipment to load or unload the machine. Doing so may result in tipping over or falling down of the machine.
- Keep the truck bed and loading ramps clean of oil, soil, ice, snow, and other materials to prevent the machine from sliding sideways. Clean the crawlers.
- Chock the transporter wheels to prevent movement.
- Turn off the deceleration switch and auto-deceleration switch. Otherwise, the engine speed may suddenly increase to cause troubles.
- When being loaded or unloaded, travel slowly in 1st (low) gear by following the signal from the signal person.
- Never change courses on the ramps.
- Do not slew/swing on the ramps. The machine may tip over.
- When slewing/swinging on the truck bed, do it slowly as the footing should be unstable.
- Lock the cab door after being loaded, if applicable. Otherwise, the door may open during transport.
- Chock the tracks and secure the machine to the truck bed with wire rope or chain.

When loading or unloading the machine, be sure to use ramps or a platform and follow the procedure below.



1. Set the parking brake on the transporter and chock the wheels.
2. Fix the ramps securely to the truck bed. The slope of the ramps must not exceed 15°.
3. Align the center of the truck bed with the center of the machine, and of the ramp with the center of the crawler.
4. Make sure the dozer blade does not hit the ramps.
5. Lower the hoe attachment as far as possible without letting it touch the transporter.
6. Decrease the engine speed.



**LOADING AND UNLOADING**

7. Drive the machine straight toward the ramps and travel up or down the ramps at 1st (low) speed, by following the signal from the signal person.
8. Load the machine at the specified position on the transporter.
Refer to "Transporting posture" on page 4-6.



HOISTING THE MACHINE



WARNING

- Know and use the correct crane signals.
- Check the hoisting equipment for damaged or missing parts on a daily basis and replace as necessary.
- When hoisting, use a wire rope capable of lifting the machine mass.
- Hoist the machine in such a manner described in the procedure below. Do not do it in any other manner. Doing so is dangerous as it may result in the machine losing its balance.
- Do not hoist the machine with an operator on it.
- When hoisting, hoist slowly so that the machine does not tip.
- Keep everyone out of the area when hoisting. Do not move the machine over the heads of the persons.


IMPORTANT: This hoisting method applies to machines with standard specifications. The center of gravity differs according to the attachments and optional equipment installed. Contact your Takeuchi service agent for details.

Hoisting

1. Slew the upperstructure so that the dozer blade is at the rear of the machine (set the upperstructure parallel to the track frame).
2. Raise the dozer blade fully.
3. Extend the bucket cylinder and arm cylinder fully to raise the boom to its uppermost position.
4. If the boom is swung to either the left or right side, set it in the neutral position.
5. Raise the safety lock lever to the locked position.
6. Stop the engine, remove the starter key and get off the machine.
7. Install the wire ropes as shown on the figure below. Install the wire ropes and hoisting attachment without letting them touch the machine body.
8. Hoist the machine slowly until it leaves the ground.
9. Stop hoisting until the machine becomes stable, and then start hoisting the machine slowly again.



HOISTING THE MACHINE






SECURING THE MACHINE

After loading the machine at the specified position, secure it as described below.

Transporting posture



AQ0F002E

1. Lower the dozer blade.
2. Extend the bucket cylinder and arm cylinder fully, and then lower the boom.
3. Raise the safety lock lever to the locked position.
4. Stop the engine, remove the starter key and lock all locks.
5. Place the stoppers (chocks) in front and behind the crawlers.
6. Install a chain or wire rope over the lower frame of the machine and fasten it securely to prevent the machine from slipping sideways.
7. Secure the bucket with a chain or wire rope.

Precautions to be taken during transportation



WARNING

- Know and follow the applicable safety rules, vehicle code and traffic laws when transporting the machine.
- Select the best transport route by considering the length, width, height and weight of the truck with the machine loaded on it.
- Never abruptly start or stop or run at a high speed at the sharp curves during transport. Doing so will move or lose the balance of the loaded machine.

IMPORTANT: Place a wooden block under the bucket to protect the floor from damage caused by the bucket.

MAINTENANCE





GENERAL

MAINTENANCE OVERVIEW

To keep the machine in good condition and use it for a long period, perform the inspection and maintenance properly and safely following the procedures recommended by this manual.

The inspection and maintenance items are divided into groups according to the machine's total operating time: every 10 hours (walk-around and daily inspection), every 50 hours, every 250 hours, etc. Refer to the hour meter readings to determine when to schedule an inspection and maintenance. Items for which it is not possible to determine the inspection and maintenance interval are included under "When Required".

When operating the machine in extremely harsh environments (with high dust levels or high temperatures), inspection and maintenance should be performed earlier than the times specified on the Maintenance List.

CAUTIONS ON MAINTENANCE

Do not perform any other inspection and maintenance works than those listed in this manual.

For works not listed in this manual, ask your sales or a service dealer for help.

Keep the machine clean

- Clean the machine before performing inspection and maintenance and try to keep it clean.
- Stop the engine before washing the machine. Cover the electrical parts so that water cannot enter. Water on electrical parts could cause short-circuits or malfunctions. Do not use water or steam to wash the battery, electronic control components, sensors, connectors or the operator's compartment.

Fuel, lubricant and grease

- Choose fuel, lubricant and grease by following to the "Fuel and lubricant table".
- Use fuels, lubricants and greases which do not contain water, and be careful to keep dirt out when changing or replenishing fuel, lubricant or grease.
- Store fuels, lubricants and greases in the prescribed places and in such a way that no water or dirt can get in them.

Cautions on refueling

- If the port includes a strainer, do not remove the strainer when fueling.
- After fueling, be sure to securely tighten the fuel filler cap.
- Do not add more than the specified amount of fuel.

Do not use fuel to clean parts

Do not use fuel to clean parts. Use a non-combustible cleaning agent.

Keep dirt out

When mounting and removing parts, do so in a place where there is no dust, clean the working area and the part, and keep dirt out.




Clean the installation surfaces

When installing and removing parts, be sure that the surfaces of contact of the parts are clean. If the sealing grooves of the surface of contact are damaged, consult your sales or service dealer for repair or release.

Seals and split pins

- Be sure to replace all seals and cotter pins with new ones.
- When installing, be careful not to damage or twist the seal.

Sealing tape



- When wrapping the plug with sealing tape, remove any old sealing tape from the threads and clean the threads.
- Wrap the thread tight with seal tape starting 1 or 2 threads away from the thread end.

Disposing of wastes

- Always collect oil that is drained from the machine in containers. Improperly disposed waste oil can cause environmental harm.
- Follow appropriate laws and regulations when disposing of harmful objects such as oil, fuel, cooling water, coolant, filters and batteries.

Check after maintenance

- Gradually increase the engine speed from a low idle to maximum speed and check that there is no oil or water leaking from serviced parts.
- Operate each control lever and check that the machine is operating properly.

Cautions on handling of battery wiring

- Disconnect the wiring from the both terminals (+ and -) on the battery before working on the electrical system or doing electric welding.
Always disconnect it from the earth side (-). When connecting, connect the earth side last.
- Do not disconnect the battery wiring while the engine is moving. Otherwise, the electric circuits of the rotary converter or others may be damaged.



SERVICE DATA

FUEL AND LUBRICANT TABLE

Select the appropriate fuel, lubricant and grease according to the temperature by referring to the table below.

- Regardless of the specified time, change the oil if it becomes too dirty or degraded.
- When refilling, never mix oils of different brands. If a brand is to be changed, replace the whole fuel/oil.

Fuel

Diesel fuel specifications

Diesel fuel should comply with the following specifications. The table lists several worldwide specifications for diesel fuels.

Diesel fuel specification	Location	Diesel fuel specification	Location
ASTM D975 No.1-D S15 No.2-D S15	USA Canada	ISO 8217DMX	International
Bio-diesel fuel Biodiesel blends up to B5 ASTM D6751, D7467			
EN590: 2009	European union	BS2869-A1 or A2	United kingdom
Bio-diesel fuel Biodiesel blends up to B5 EN14214, EN590			



Fuel tank	Diesel fuel	To maintain the performance and service life of the engine, always use clean and high-quality fuel. • To avoid freezing in cold climates, use a diesel fuel that still functions when the temperature is at least 12°C (53.6°F) below the lowest expected ambient temperature. • Use a diesel fuel that has a cetane number of 45 or higher. When operating at a very low temperature or at a high altitude, a higher cetane number fuel will be required. • Use fuel with sulfur content of less than 15 ppm by volume. Especially in the U.S.A. and Canada, ultra-low sulfur fuel should be used. A higher sulfur content fuel may cause sulfuric acid corrosion in the cylinders of the engines. • Never mix kerosene, used engine oil, or residual fuel with the diesel fuel. Use of kerosene is prohibited. • Poor quality fuel can reduce engine performance and / or cause engine damage. • Fuel additives are not recommended. Some fuel additives may cause poor engine performance. • The content of metal, such as zinc, sodium, magnesium, silicon and aluminum, must be 1 mass ppm or less. (JPI-5S-44-95 test analysis method) Precautions when using bio-diesel fuel The warranty of the engine manufacturer may be voided by using a bio-diesel fuel that does not meet the standard or that is deteriorated.
------------------	--------------------	---



Lubricant

Location	Type	Type by air temperature								When to replace
		-4	14	32	50	68	86	104°F		
		-20	-10	0	10	20	30	40°C		
Engine oil pan	Diesel engine oil <Applicable machine models 126000002 or later> API: CD class ACEA: E3/E4/E5 class JASO: DH1 class									Every 250 hrs after the initial 50 hrs.
	<Applicable machine models 126100003 or later> API: CJ-4 class ACEA: E6 class JASO: DH2 class									
Hydraulic oil tank	Takeuchi genuine hydraulic oil 46									Every 4000 hrs.***
	Anti-wear hydraulic oil									Every 2000 hrs.***
Engine cooling system	Cooling water (water + coolant)** SAE: J814C or J1034									Every 1000 hrs.
Travel reduction gear	Gear oil API: GL-4									Every 1000 hrs after the initial 250 hrs*.
Slew bearing	Lithium based grease									Every 50 hrs.
Working equipment	EP-2 NLGI No.2									Daily or every 10 hrs.



- * : If the ratio of traveling time to total operating time is high, replace the gear oil earlier than the specified time.
- ** : For water, use tap water (soft). Do not use well or river water. When the ambient temperature drops below 0°C (32°F), add coolant (antifreeze). Follow the coolant manufacturer's instructions to determine the mixture ratio.
- *** : The hydraulic oil replacement interval depends on the type of hydraulic oil being used. New machine are delivered with Takeuchi genuine hydraulic oil 46, and the hydraulic oil replacement intervals indicated in this manual assume that Takeuchi genuine hydraulic oil 46 is being used. When using conventional antiwear hydraulic oil, the hydraulic oil should be replaced every 2000 hours.

API standard: American Petroleum Institute

ACEA standard: Association des Constructeurs Européens d'Automobiles

JASO standard: Japanese Automobile Standards Organization

SAE standard: Society of Automotive Engineers

Volume

Engine oil pan	Engine cooling system	Hydraulic oil tank	Fuel tank	Travel reduction gear
Upper limit 7.4 L (7.8 US qt.) Lower limit 4.0 L (4.2 US qt.)	11 L (11.6 US qt.)	System 90 L (23.8 US gal.) Tank 49 L (12.9 US gal.)	Level capacity 81 L (21.3 US gal.) 76 L (20.1 US gal.)*	0.8L X 2 (0.85 US qt.) X 2

*: When the auto fuel supply pump is stopped



REGULARLY REPLACE THE HYDRAULIC OIL


When a hydraulic breaker is used, the oil deteriorates more quickly than that used for a usual excavation operation. Be sure to replace the hydraulic oil and the return filter elements.

- Failure to replace these in time can lead to damage to the machine and the breaker hydraulic system. To prolong the service life of the hydraulic devices, properly replace the hydraulic oil and the return filter elements according to the table below.
- When replacing the hydraulic oil, clean the suction strainer.

Replacement interval (hours)

Item	Hydraulic oil	Filter element
1st time	—	25
2nd time	—	100
Periodically	1200 (600)	200

When the breaker operating ratio is 100%.
Refer to “Hydraulic breaker” on page 8-6.



(): When a conventional antiwear hydraulic oil is used.



LIST OF CONSUMABLES

Periodically replace consumables such as filters and elements according to the table below.

System	Item	Part name	Part No.	When to replace
Hydraulic system	Hydraulic oil return filter	Element	15511-03900	Every 1000 hrs after the initial 250 hrs.
	Pilot line filter		15512-00601	
	Air breather filter		15520-02715	Every 1000 hrs.
Engine lubrication system	Engine oil filter	Cartridge	Y129150-35153	Every 250 hrs after the initial 50 hrs.
Fuel system	Fuel filter	Cartridge	<Applicable machine models 126000002 or later> Y129907-55801	Every 500 hrs.
			<Applicable machine models 126100003 or later> Y129A00-55800	
	Water separator filter	Element	<Applicable machine models 126000002 or later> If equipped with filter for high sulfur fuel Y41650-550800	
			<Applicable machine models 126100003 or later> Y129A00-55730	
Air cleaner system	Air cleaner	Primary (Outer) element	19111-12001	Every 1000 hrs. or after 6 cleanings (whichever comes first)
		Secondary (Inner) element	19111-12002	When the primary elements are replaced.
AC system	Receiver dryer		19115-14513	Every 2 years
	Ventilation filter	Element	05546-00025	Every year
	Circulation filter	Element	05546-03101	Every year



LIST OF TOOLS (IF EQUIPPED)

Code	Part name	Part No.	Remarks
1	Spanner	Y28110-100120	10 - 12
2	Spanner	Y28110-140170	14 - 17
3	Screwdriver	Y104200-92350	(+) (-) replaceable shank
4	Filter wrench	Y119640-92750	ø80
5	Filter wrench	Y129A00-92750	for water separator filter <Applicable machine models 126100003 or later>
6	Hammer	16903-00330	3/4
7	Monkey wrench	16904-00250	250 mm
8	Pliers	16905-00200	200 mm
9	Spanner	16900-01922	19-22
10	Spanner	16900-02427	24-27
11	Single-ended wrench	16901-00013	13
12	Single-ended wrench	16901-00041	41
13	Combination wrench	16909-00026	26
14	Hex. wrench	16906-00400	4 mm
15	Hex. wrench	16906-00500	5 mm
16	Hex. wrench	16906-00600	6 mm
17	Hex. wrench	16906-00800	8 mm
18	Hex. wrench	16906-01000	10 mm
19	Hex. wrench	16906-01400	14 mm
20	Tool case	16914-00005	
21	Case	16919-00001	
22	Grease gun	16910-60610	600 cc
23	Drain connector	15545-12601	





LIST OF TIGHTENING TORQUES

Nuts and Bolts (for ISO strength category 10.9)

Tighten nuts and bolts at the torques shown on the table below, unless otherwise specified.

- The tightening torques used for the mounted plastic covers are not listed in the table below. Consult your sales or service dealer for details. They will be damaged if over tightened.
- When replacing nuts and bolts, replace them with nuts and bolts of the same size and standards.
- Tighten nuts and bolts alternately (top, bottom, left then right) or in 2 or 3 times so that they are evenly tightened.



Classification	Head width (b)	Size (a) x pitch	Tightening torque	
			General connection points	
	mm	mm	N·m	ft·lb.
Coarse	10	M6 x 1.0	9.8±0.5	7.2±0.4
	12, 13	M8 x 1.25	22.6±1.1	16.6±0.8
	14, 17	M10 x 1.5	47.1±2.4	34.7±1.7
	17, 19	M12 x 1.75	83.4±4.1	61.5±3.0
	19, 22	M14 x 2.0	134.4±6.7	99.1±4.9
	22, 24	M16 x 2.0	207.9±10.4	153.3±7.7
	27, 30	M20 x 2.5	410.9±20.5	303.1±15.1
Fine	12, 13	M8 x 1.0	24.5±1.2	18.1±0.9
	14, 17	M10 x 1.25	50±2.5	36.9±1.8
	17, 19	M12 x 1.5	87.3±4.3	64.4±3.2
	19, 22	M14 x 1.5	135.3±6.8	99.8±5.0
	22, 24	M16 x 1.5	220.6±11	162.7±8.1
	27, 30	M20 x 1.5	452.1±22.6	333.4±16.6



SAFETY-CRITICAL PARTS

To use the machine safely, periodically perform inspection and maintenance. The safety-critical parts listed below must be periodically replaced for an increased safety. Serious injury or a fire could result if they are worn or damaged.

List of safety-critical parts

Unit		Safety-critical parts to be replaced periodically	When to replace
Fuel system		Fuel hoses	Every 2 years
		Packing on fuel filler cap	
Heater & AC systems		Heater hoses	
		Air conditioner hoses	
Hydraulic system	Main body	Hydraulic hoses (pump - delivery)	
		Hydraulic hoses (pump - suction)	
		Hydraulic hoses (slew motor)	
		Hydraulic hoses (travel motor)	
	Working equipment	Hydraulic hoses (boom cylinder piping)	
		Hydraulic hoses (arm cylinder piping)	
		Hydraulic hoses (bucket cylinder piping)	
		Hydraulic hoses (swing cylinder)	
		Hydraulic hoses (blade cylinder)	
		Hydraulic hoses (angle blade cylinder)	
		Hydraulic hoses (pilot valve)	
		Hydraulic hoses (auxiliary piping)	
		Seat belt	Every 3 years



The material of the safety-critical part listed above tends to change over time and cause wear or deterioration. It is difficult to determine the degree of deterioration at the periodic inspection, and thus they need to be replaced with new ones after a certain time to maintain their proper performance even if they appear in good condition. Note that regardless of the replacement schedule, replacement must be performed immediately if a symptom of wear is found. If a hose clamp is deformed or cracked, replace it together with the hose immediately. When replacing the safety-critical parts, ask your sales or service dealer.

In addition to the safety-critical parts, inspect the hydraulic hoses and retighten or replace as necessary. When replacing the hydraulic hoses, replace the O-rings and seals at the same time.

Check the fuel and hydraulic hoses according to the periodic schedule described below.

Refer to "Maintenance".

Type of inspection	Inspection item
Daily inspection	Leakage from the connecting parts of hydraulic or fuel hoses Damage to cab or canopy - replace*
Monthly inspection	Leakage from the connecting parts of hydraulic or fuel hoses Damaged hydraulic or fuel hoses (cracks, wear and tear)
Annual inspection	Leakage from the connecting parts of hydraulic or fuel hoses Deteriorated, twisted, damaged hydraulic or fuel hoses (cracks, wear and tear) or hoses in contact with other parts of the machine

*: Canopy parts No. 05584-00085

*: Cab parts No. 05586-03100



MAINTENANCE LIST

Inspection and maintenance item	Page
Walk-around inspection	
Inspecting by opening the engine hood and covers	5-16
Inspecting by walking around the machine	5-17
Inspecting while sitting in the operator's seat	5-17
Daily inspection (every 10 hours)	
Inspecting and replenishing the coolant	5-18
Inspecting and replenishing the engine oil	5-19
Inspecting the water separator	5-20
Inspecting the fuel level	5-21
Inspecting the hydraulic oil tank level and replenishing	5-22
Lubricating the working equipment	5-23
After the initial 50 hours (only for new machines)	
Replacing the engine oil and the oil filter	5-24
Inspecting and adjusting the fan belt	5-26
Inspecting and adjusting the compressor belt (AC)	5-27
Every 50 hours	
Inspecting and adjusting the crawler tension	5-28
Lubricating the slew bearing	5-30
Draining the water from the fuel tank	5-30
Inspecting the battery fluid level and replenishing	5-31
Every 100 hours	
Cleaning the water separator <Applicable machine models 126000002 or later>	5-33
After the initial 250 hours (only for new machines)	
Replacing the hydraulic oil return filter	5-34
Replacing the pilot line filter	5-35
Replacing the travel motor gear oil*	5-36
Every 250 hours	
Replacing the engine oil and the oil filter	5-37
Inspecting and adjusting the fan belt	5-37
Inspecting and adjusting the compressor belt (AC)	5-37
Cleaning the air cleaner	5-38
Cleaning the radiator fins and the oil cooler fins	5-39
Cleaning the air filters (AC)	5-40
Cleaning the condenser (AC)	5-41
Inspecting the refrigerant (gas) level (AC)	5-42
Every 500 hours	
Replacing the fuel filter	5-44
Replacing the water separator filter	5-45

*: If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.

(AC): Air conditioner



Inspection and maintenance item	Page
Every 1000 hours	
Replacing the hydraulic oil return filter	5-46
Replacing the pilot line filter	5-46
Replacing the travel motor gear oil *	5-46
Cleaning the engine cooling system	5-46
Replacing the air cleaner element	5-48
Replacing the air breather filter	5-49
Inspecting and adjusting the engine valve clearance	5-49
Inspecting the engine compression pressure	5-49
Inspecting and cleaning the engine starter and the alternator	5-49
Every 1500 hours	
Inspecting, cleaning and checking operation of the engine fuel injectors <Applicable machine models 126000002 or later>	5-50
Inspecting the crankcase breather system	5-50
Cleaning the EGR cooler (cleaning the water side and exhaust air passage blower) <Applicable machine models: 126100003 or later>	5-50
Every 2000 hours	
Lapping the engine valve seats	5-51
Every 3000 hours	
Inspecting the turbocharger (blow wash as necessary)	5-52
Inspecting, cleaning and checking operation of the EGR valve <Applicable machine models: 126100003 or later>	5-52
Cleaning the EGR lead valve <Applicable machine models: 126100003 or later>	5-52
Inspecting and cleaning the DPF soot filter <Applicable machine models: 126100003 or later>	5-52
Inspecting the operation of the air intake throttle valve	5-52
Inspecting and cleaning the injector <Applicable machine models: 126100003 or later>	5-52
Every 4000 hours	
Replacing the hydraulic oil and cleaning the suction strainer	5-53
When required	
Replacing the bucket teeth and the side cutters	5-56
Replacing the bucket	5-58
Adjusting the gap between the bucket and arm (If equipped)	5-60
Inspecting and replenishing the windshield washer fluid	5-61
Draining the water from the water separator	5-61
Lubricating the levers and pedals	5-62
Inspecting the rubber crawlers	5-63
Replacing the rubber crawlers	5-64
Every 2 years	
Replacing the receiver dryer	5-66

*: If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.




WALK-AROUND INSPECTION

Perform the following inspections every day before starting the engine for the first time.

WARNING

- Before operating, perform the walk-around inspections and make repairs immediately where necessary.
- Be sure to secure the engine hood or cover before working the inside. Do not keep the hood or cover open on a windy day or if the machine is parked on a slope.

Before starting the engine, look around the machine and clean any combustibles from the surroundings of the engine. Also, inspect if oil or water is leaking and any nuts or bolts are loosened.



AQ0G001

INSPECTING BY OPENING THE ENGINE HOOD AND COVERS

1. Check for any twigs, leaves, oil or other combustible materials around the engine and battery.
2. Check for oil or engine coolant water leakage around the engine.
3. Check for oil leakage from the hydraulic oil tank, hydraulic devices, hoses or connections.

**INSPECTING BY WALKING AROUND THE MACHINE**

4. Check lights for dirt, damage and burnt out bulbs.
5. Check attachments and hoses for damage.
6. Check the bucket, bucket teeth and side cutter for wear, damage and looseness.
7. Check the hook, slip stopper and hook mount of buckets with hooks for damage. (Option)
8. Check the handrail, the steps and the slip-resistant surfaces for damage and loose bolts.
9. Check the crawlers, carrier rollers, track rollers, idlers and sprockets for damage, wear and loose bolts.
10. Check for oil leakage from the travel motor, carrier rollers, track rollers and idlers.
11. Check the cab and guard for damage and loose nuts and bolts.
12. Check the mirrors for dirt or damage, and adjust them.
13. Check the labels for dirt and damage.

INSPECTING WHILE SITTING IN THE OPERATOR'S SEAT

14. Check the windshield for dirt or damage.
15. Check the seat and seat belt for dirt or damage.
Check the operator's seat for dirt, oil or other combustible materials.
16. Check the monitor, instruments and switches for dirt or damage.



DAILY INSPECTION (EVERY 10 HOURS)

Perform the following inspections every day before starting the engine for the first time.



WARNING

- Before operating, perform the daily inspections and make repairs immediately where necessary.
- Be sure to secure the engine hood or cover before working the inside. Do not keep the hood or cover open on a windy day or if the machine is parked on a slope.


INSPECTING AND REPLENISHING THE COOLANT



WARNING

- Do not remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine and wait until the engine and the radiator cool before slowly loosening the radiator cap and the drain plug to remove them.
- Always wear the protective goggle and gloves when handling coolant (antifreeze). If any coolant (antifreeze) comes in contact with eyes or skin, wash it off with clean water. Otherwise, it could result in injuries.

Inspection



1. Open the engine hood.
2. Inspect the cooling water level in the reserve tank (1).
The level should be between the upper limit (H) and the lower limit (L).
If it is below the lower limit (L), replenish.

Replenishing

1. Remove the cap (2) of the reserve tank (1).
2. Add cooling water up to the upper limit (H) of the reserve tank (1).
If the reserve tank (1) is found empty at the inspection, check for water leakage and then the water level in the radiator (3). Add water to the radiator (3) as required, and then to the reserve tank (1).
3. Install the cap (2).

Note: Use only clean water (soft water), such as tap water, to replenish the coolant loss due to evaporation. If the coolant loss is due to leakage, replenish the mixture of antifreeze and clean water (soft water) prepared using the same mixing ratio used for the current coolant.


INSPECTING AND REPLENISHING THE ENGINE OIL



WARNING

Stop the engine and allow the machine to cool down before performing maintenance.

Inspection



1. Open the engine hood.
2. Take out the dipstick (1) and wipe the oil off with a rag.
3. Fully reinsert the dipstick (1), and then pull it back out.
4. Check the oil on the dipstick (1).
The level should be between the upper limit (H) and the lower limit (L).
If it is below the lower limit (L), replenish.

Replenishing

1. Remove the oil filler cap (2).
2. Add oil up to between the upper limit (H) and the lower limit (L) of the dipstick (1). Problems could arise if the oil level is either too low or too high.
3. Tighten the oil filler cap (2).
4. Start the engine, run it at low idle for about 5 minutes, then stop it.
5. After about 10 to 20 minutes, inspect the oil level.




INSPECTING THE WATER SEPARATOR

WARNING


- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.

<Applicable machine models 126000002 or later>



1. Open the engine hood.
2. Check if there is water in the water separator (1).
If water collects in the separator, the float (red ring) (6) goes up. Be sure to drain water before the float goes up to the element (5),
3. Loosen the vent plug (8) and then the drain plug (7) to discharge water collected inside.
4. After drainage of water, tighten each plug and bleed air from the fuel system.
Refer to "Bleeding air from the fuel system" on page 6-8.

<Applicable machine models 126100003 or later>



1. Turn the starter switch to the ON position.
2. Inspect the water separator warning lamp.
3. If the warning lamp is flashing, drain the water.
Refer to "Draining the water from the water separator" on page 5-61.




INSPECTING THE FUEL LEVEL



WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Do not spill fuel on the hot surface of the machine.
- Fill the fuel tank in a well ventilated place.
- Clean up spilled fuel immediately.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Securely tighten the fuel filler cap.
- Use the correct grade of fuel for the operating season.



1. Check the fuel level using the fuel gauge (1).
F: Tank is full.
E: Tank is empty.
2. If the fuel level is low, open the fuel lid.
3. Add fuel from the fuel filler port (2) while watching the sight gauge (3).
Refer to "Fuel filler port" on page 2-8.



INSPECTING THE HYDRAULIC OIL TANK LEVEL AND REPLENISHING

WARNING


Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.

- Press the air breather button to relieve the internal pressure from the tank.

Inspection


The oil level changes with the oil temperature. Inspect the oil by maintaining the machine at posture shown in the figure at the next.

- Machine posture for inspecting the hydraulic oil level



1. Start the engine and run it at low speed.
2. Fully retract the cylinders (arm and bucket), and lower the bucket to the ground.
3. Lower the dozer blade, and then stop the engine.
4. Open the right side cover.
5. Inspect the oil level using the sight gauge (1).
 - When the oil temperature is about 20°C (68°F):
The level should be between the upper limit (H) and the lower limit (L).
If it is below the lower limit (L), replenish.
 - When the oil temperature is about 50 to 80°C (122 to 176°F):
The level should be slightly below the upper limit (H).

Replenishing




IMPORTANT: Do not fill up to the level higher than the upper limit (H). It will damage the hydraulic circuits or result in oil spurting. If accidentally done, stop the engine and wait the hydraulic oil to cool, and then let the excessive oil to drain from the drain plug.

1. Open the right side cover.
2. Press the air breather button (2) to relieve the internal pressure from the tank.
3. Remove the plug (3).
4. Add the hydraulic oil up to the middle point of the sight gauge (1).
5. Tighten the plug (3).



LUBRICATING THE WORKING EQUIPMENT



1. Keep the machine configuration as shown in the diagram above, lower the working equipment to the ground, and then stop the engine.
2. Use the grease gun to lubricate the grease fittings.
3. Wipe off the excess grease.



AFTER THE INITIAL 50 HOURS (ONLY FOR NEW MACHINES)

REPLACING THE ENGINE OIL AND THE OIL FILTER




WARNING

Stop the engine and allow the machine to cool down before performing maintenance.

- The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
- The engine oil is also hot.

Be careful not to touch the hydraulic oil when loosening the cap or plug.


Working on the machine under these conditions could result in burns or injuries.



2. Loosen the bolts and remove the under cover (3).
3. Place a pan for catching the waste oil under the drain plug (4).
4. Remove the cap (A), install connector (B) and drain the oil. (The oil comes out when the screw is tightened.)
5. Remove the connector (B) and install the cap (A).
6. Install the under cover (3).

IMPORTANT: Check the waste oil for metal powder. If it contains large amounts of metal powder, consult your sales or service dealer.

Engine oil



1. Open the engine hood and remove the oil filler cap (2).

**Engine oil filter**

7. Turn the filter (5) counterclockwise with the filter wrench and remove it.
8. Clean the surface of installation of the filter stand.
9. Apply a thin layer of oil on the packing of the new filter.
10. Install the new filter by hand.
11. Tighten one more turn (with the filter wrench) after the filter packing comes in contact with the surface of installation.
(Torque when tightening with filter wrench: 19.6 to 23.5 N·m or 14 to 17 ft-lb.)
12. Add oil up to between the upper limit (H) and the lower limit (L) of the dipstick (1).
Problems could arise if the oil level is either too low or too high. It takes around 10 to 20 minutes for all of the added oil to go down to the oil pan.
13. Tighten the oil filler cap (2).
14. Start the engine, run it at low idle for about 5 minutes, then stop it.
15. After about 10 minutes, inspect the oil level.



INSPECTING AND ADJUSTING THE FAN BELT

WARNING

Stop the engine and allow the machine to cool down before performing maintenance.


- The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.

IMPORTANT: The loose belts could result in bad battery charge, overheat of engine or early wear of belt. Too tight belts could damage the water pump or bearing and belt used to drive the alternator.

IMPORTANT: Do not let any oil or grease get on the belt.

Inspection

1. Open the engine hood.




2. Press the fan belt (1) at the midpoint between the fan pulley (2) and alternator pulley (3) to check the tension (approx. 98 N or 22 lbf).

The slack (A) should be 7 to 10 mm (0.28 to 0.4 in).

3. Inspect the fan belt (1) and replace it if it is as follows.
 - There are cuts or cracks.
 - The belt is worn and touches the bottom of the V groove in the pulley.
 - The belt stretched too loose to be adjusted.

Adjustment



1. Loosen the bolt (5) and locking nut (4).
2. Turn the adjustment bolt (6) to move the alternator (7) and to adjust the tension of the fan belt (1).
 - Tighten: Clockwise
 - Loosen: Counterclockwise
3. Tighten the bolt (5) and locking nut (4).

Note: When replacing with a new belt, run the engine at low idle speed for about 3 to 5 minutes to break in the new belt, before adjusting the tension.



INSPECTING AND ADJUSTING THE COMPRESSOR BELT (AC)




WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
 - The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
- The high-pressure pipes of the air conditioner can be very hot (80 to 120°C or 176 to 248°F). Be careful not to burn yourself.

IMPORTANT: Do not let any oil or grease get on the belt. It will cause the belt to slip, decrease the cooling capacity or shorten the service life of the air conditioner.

If the belt is too slack, it will slip and vibrate, resulting in decreased cooling capacity. The service life of the air conditioner also will be shortened. Adjust the belt tension to the standard value.

Inspection



1. Open the engine hood.
2. Measure the belt (1) tension using the belt tension gauge. The belt tension is normal if the belt tension gauge indicates the following values.
294 to 392 N or 66 to 88 lbf.

Adjustment

If the belt tension is not normal, adjust it with the adjuster bolt (2).

1. Loosen the locking nut (3).
2. Turn the adjuster bolt (2) as follows.
 - Tighten: Clockwise
 - Loosen: Counterclockwise
3. Tighten the locking nut (3) after adjustment.
Tightening torque:
 - Locking nut (3) 31.4 to 45.1 N·m (23.2 to 33.3 ft·lb.)

Note: When replacing with a new belt, run the engine at low idle speed for about 3 to 5 minutes to break in the new belt, before adjusting the tension again.

Replacing

Replace the belt in the following cases:

- There are cuts or cracks.
- The belt is worn and touches the bottom of the V groove in the pulley.
- The belt stretched too loose to be adjusted.



EVERY 50 HOURS


INSPECTING AND ADJUSTING THE CRAWLER TENSION




WARNING

- If you must work beneath the raised machine or working equipment, always use wood blocks, jack-stands or other rigid and stable supports. Never get under the machine or working equipment if they are not sufficiently supported. This procedure is especially important when working on hydraulic cylinders.
- Be careful with the high-pressure grease. In the track adjuster, the grease has been injected under high pressure. If the tension is adjusted without following the prescribed procedure, the grease discharge valve may fly off, resulting in injury.
 - Never loosen the grease fitting.
 - Loosen the grease discharge valve slowly. Do not turn it more than one turn.
 - Do not put your face, arms, legs or body in front of the grease discharge valve.
 - If grease does not come out when the grease discharge valve is loosened, the valve is faulty. Ask a Takeuchi service agent for repair.


Inspection



1. For rubber crawlers, move the machine so that the "M", "J" or "∞" mark at the joint is at the top center of the crawler frame.



2. Use the working equipment to lift the machine body. Operate the levers slowly.




3. Inspect the gap (A or B) between the bottom surface of the frame at the center of the crawler frame and the top surface of the crawler.
The gap (A or B) must be within the following range:

- (A) Rubber crawler
83 to 93mm (3.3 to 3.7 in.)
- (B) Steel crawler
150 to 170mm (5.9 to 6.7 in.)
- (B) Segmental rubber crawler
150 to 170 mm (5.9 to 6.7 in.)




Adjustment

Increasing the tension



1. Remove the cover (1).
2. Using the grease gun, insert grease through the grease fitting (3) in the grease discharge valve (2).
3. Inspect the crawler tension.

Decreasing the tension




1. Remove the cover (1).
2. Using the spanner, slowly loosen the grease discharge valve (2) (one turn) and drain the grease.
If the grease does not drain easily, move the machine forward or backward.
3. Tighten the grease discharge valve (2).
 - Tightening torque: 60 to 80 N·m (44.3 to 59 ft·lb.)



LUBRICATING THE SLEW BEARING


WARNING

Do not slew while lubricating. Doing so is dangerous, as you may get caught in the machine.




AQ0G032

1. Stop the engine with the machine in the posture shown on the figure above.



AQ0G009

2. Use the grease gun to grease the grease fitting (1).



AG7G042

3. Start the engine, lift the bucket and slew clockwise 90°.


4. Lower the bucket to the ground, and then stop the engine.
5. Repeat the steps 2 to 4 above three times.
6. Wipe off the grease expelled from the slew bearing and grease fitting.

DRAINING THE WATER FROM THE FUEL TANK


WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Do not spill fuel on the hot surface of the machine.
- Fill the fuel tank in a well ventilated place.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Clean up spilled fuel immediately.
- Securely tighten the fuel filler cap.
- Use the correct grade of fuel for the operating season.

Do the draining operation before starting the machine.



AQ0G010



1. Open the fuel lid.
2. Remove the fuel filler cap (2).
3. Loosen the bolts and remove the under cover (3).
4. Place a pan under the drain valve (4).
5. Remove the cap (A), install the connector (B), and then drain the water and sediment buildup in the bottom of the tank (the water comes out when the screw is tightened).
6. Remove the connector (B) and install the cap (A).
7. Install the under cover (3).
8. Add fuel while watching the sight gauge (1).
9. Tighten the fuel filler cap (2).
10. Close the fuel lid and lock it with the key.
11. Bleed air.

Bleeding air from the fuel system

Refer to "Bleeding air from the fuel system" on page 6-8.

Note: Air in the fuel system causes the engine to fail to start or to have problems. Bleed air when the fuel tank is emptied, using the same procedure above.

INSPECTING THE BATTERY FLUID LEVEL AND REPLENISHING



DANGER

- Do not use the battery when the fluid level is below the lower level limit. Doing so will hasten the deterioration of the internal portions of the battery and shorten the battery life. It also can cause rupturing (explosion).
- Batteries generate flammable hydrogen gas which may explode. Keep away from flame, sparks, fire or lighted cigarettes.
- Use a dampened cloth to clean above the fluid level line and check the fluid level. Do not clean with a dry cloth; otherwise it can cause static electricity to build up, resulting in ignition or explosion.



WARNING


- Wear protective goggle and clothing when working with batteries.
- Do not add the distilled water above the upper level limit. Doing so could cause the fluid to leak. This fluid can cause skin damage if contacted, or can cause the machine components to corrode.
- Batteries contain sulfuric acid which will damage eyes or skin if contacted.
 - If eye contact occurs, flush immediately with clean water and get prompt medical attention.
 - If accidentally swallowed, drink large quantities of water or milk and call a physician immediately.
 - If acid contacts skin or clothing, wash off immediately with a lot of water.



Inspection

IMPORTANT: Check the fluid level of all cells following the steps below, even when the fluid level can be checked using the indicator.

1. Open the right side cover.




2. Inspect the indicator (1).

- Blue: Good
- White: Charging needed
- Red: Insufficient battery fluid

3. Inspect the fluid level.

The fluid level must be between the upper level line (H) and lower level line (L). If not, add distilled water up to the line (H).

- If the fluid level cannot be checked by fluid level lines:



Remove the caps (2) and look into the fluid filler holes to check the fluid level. If the fluid is below the sleeve (3), be sure to add distilled water up to the bottom edge of the sleeve (3).

Proper level (A)

If the fluid reaches up to the bottom edge of the sleeve (3), the surface tension causes the fluid to swell and the plate appears as if it is distorted.

Level too low (B)

If fluid does not reach up to the bottom edge of the sleeve (3), the plate looks laminar, not distorted.

4. Check the terminals for looseness and dirt.

Replenishing

When adding distilled water, do so before starting operations in order to prevent freezing.

1. Remove the caps (2), and add distilled water until the upper level (H).
2. Check that the indicator (1) turns blue.
3. Clean the exhaust hole on the cap, then tighten the caps (2) securely.




EVERY 100 HOURS

CLEANING THE WATER SEPARATOR <APPLICABLE MACHINE MODELS 126000002 OR LATER>



WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.



(S): Close

1. Open the engine hood.
2. Close the valve (2).
3. Loosen the ring (3), then remove the case (4), element (5) and indicator ring (6) and clean them.
4. Inspect the O-ring and the element (5). If there are any scratches or other irregularities, replace them.
5. Assemble the indicator ring (6), case (4) and element (5) and tighten the ring (3).
6. Open the valve (2).
7. Loosen the vent plug (7) and bleed the air.
8. Tighten the vent plug (8).
Refer to "Bleeding air from the fuel system" on page 6-8.




AFTER THE INITIAL 250 HOURS (ONLY FOR NEW MACHINES)

REPLACING THE HYDRAULIC OIL RETURN FILTER



WARNING

- Stop the engine and allow each part of the machine to cool down before performing maintenance.
 - The engine, the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
 - The hydraulic oil is also hot and under high pressure immediately after the engine is stopped. Be careful not to touch the oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.
 - Press the air breather button to relieve the internal pressure from the tank.
 - When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.



AQ0G012

1. Open the right side cover.
2. Press the air breather button (2) to relieve the internal pressure from the tank.
3. Loosen the bolts and remove the flange (4).
4. Remove the return filter (5).
5. Install a new return filter.
6. Install the flange (4) on its original position.
7. Inspect the level with the sight gauge (1), and replenish if the level is too low. Refer to "Inspecting the hydraulic oil tank level and replenishing" on page 5-22.




REPLACING THE PILOT LINE FILTER




WARNING

- Stop the engine and allow each part of the machine to cool down before performing maintenance.
 - The engine, the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
 - The hydraulic oil is also hot and under high pressure immediately after the engine is stopped. Be careful not to touch the oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.
 - Press the air breather button to relieve the internal pressure from the tank.
 - When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.



1. Open the right side cover.
2. Press the air breather button (2) to relieve the internal pressure from the tank.



3. Open the engine hood.
4. Turn the case (4) counterclockwise and remove it.
5. Remove the element (5) and O-ring (6).
6. Clean the inside of the case (4).
7. Apply a thin layer of oil on the O-ring of the new filter.
8. Install the new element on the filter stand (7).
9. Apply a thin layer of oil on the new O-ring (6).
10. Install the new O-ring (6) and the case (4) on the filter stand (7).
11. Inspect the level with the sight gauge (1) and replenish if the level is too low. Refer to "Inspecting the hydraulic oil tank level and replenishing" on page 5-22.




REPLACING THE TRAVEL MOTOR GEAR OIL

WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
 - The travel motor is hot immediately after the engine is stopped. Touching it will cause burns.
 - The gear oil is also hot and under high pressure immediately after the engine is stopped.
Be careful when loosening the plugs. Working on the machine under these conditions could result in burns or injuries.
- The pressure in the reduction gear case of travel motor may cause oil or the plug to fly out. Loosen the plug slowly to release the pressure.

6. Add oil through the hole of the plug (3) until oil flows out of the hole of the plug (2).
7. Tighten the plugs (2) and (3).
 - Plug (2) tightening torque: 12 to 18 N·m (8.8 to 13.3 ft-lb)
 - Plug (3) tightening torque: 46 to 51 N·m (34 to 37.6 ft-lb)

IMPORTANT: If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.



1. Set the travel motor so that plug (1) is at the very bottom.
2. Place a pan under the plug (1).
3. Remove the plugs (1), (2) and (3) and drain the oil.
4. Rewrap the plugs with new sealing tape.
5. Tighten the plug (1).
 - Plug (1) tightening torque: 46 to 51 N·m (34 to 37.6 ft-lb)



EVERY 250 HOURS

REPLACING THE ENGINE OIL AND THE OIL FILTER

Refer to “Replacing the engine oil and the oil filter” on page 5-24.

INSPECTING AND ADJUSTING THE FAN BELT

Refer to “Inspecting and adjusting the fan belt” on page 5-26.

INSPECTING AND ADJUSTING THE COMPRESSOR BELT (AC)

Refer to “Inspecting and adjusting the compressor belt (AC)” on page 5-27.



CLEANING THE AIR CLEANER


WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
 - The engine, muffler, radiator and many other parts of the machine are hot immediately after the engine is stopped. Touching it will cause burns.
- Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.


IMPORTANT: Be careful not to scratch the element. Do not use an element if it is damaged.

IMPORTANT: When operating the machine in very dusty places, perform inspection and maintenance operations every day.


IMPORTANT: Be sure to install the element and dust cap securely. If not, dust could be drawn into the cylinder, damaging the engine.



1. Open the engine hood.



2. Loosen the clamps (1) and remove the dust cup (2).
3. Clean the inside of the dust cup (2).
4. Remove the primary element (3).
To prevent dirt from getting inside the engine, do not remove the secondary element (5).
5. Clean the inside of the body (4).



6. Clean the primary element (3) with dried compressed air (294 to 490 kPa or 43 to 71 psi).
First blow the air from the inside of the element along the pleats. Then blow the air from the outside and finally from the inside again.
7. Light up the inside of the primary element (3) with a light bulb, inspect it, and replace it if there are small holes or thin spots.
8. Install the primary element (3).
9. Install the dust cup (2) with its "▲▲▲▲ OBEN/TOP" mark facing up, and then fasten it with the clamps (1).



CLEANING THE RADIATOR FINS AND THE OIL COOLER FINS

WARNING

Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.


IMPORTANT: Be careful not to damage the fins when cleaning.

- When using compressed air or pressurized water, make sure the pressure is no higher than 200 kPa (28 psi) and hold the nozzle sufficiently away from the fins.


IMPORTANT: When using water, cover the electrical system to prevent water from getting in.

IMPORTANT: When operating the machine in very dusty places, perform inspection and maintenance operations every day.

2. Remove the screws (1) and open the condenser.
3. Blow compressed air on the fins to remove mud and dirt stuck on them.



1. Open the engine hood.





CLEANING THE AIR FILTERS (AC)


WARNING

Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.

Clean the filters immediately after operating in dusty places.


If the filters are clogged, the air flow is reduced and a booming sound is heard from the air conditioner unit.

Removing the filters



1. Open the cab door.
2. Loosen the screw and remove the switch box (1).
3. Remove the ventilation filter (3) from the filter case (2).

Ventilation filter (3):
parts No. 05546-00025



4. Loosen the screw and remove the cover (4).
 5. Remove the circulation filter (5).
 6. Use compressed air or water to clean the filters, depending on how dirty they are.
- Circulation filter (5) Part No. 05546-03101

Cleaning

1. Blow dry, compressed air (138 kPa or 20 psi or less) directly on the filters from the inside, moving up and down along the pleats.
Be sure to keep the nozzle at an adequate distance from the filters.
2. Wash the filter with neutral detergent if it is very dirty. Dry the filter completely after washing it.

Replacing

Replace the filter with a new one once a year or if it is still clogged after blow-drying with compressed air and washing.



CLEANING THE CONDENSER (AC)




WARNING

Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.

IMPORTANT: Be careful not to damage the fins when cleaning.

- When using compressed air or pressurized water, make sure the pressure is no higher than 200kPa (28 psi) and hold the nozzle sufficiently away from the fins.



1. Open the engine hood.
2. Clean the condenser (1).




INSPECTING THE REFRIGERANT (GAS) LEVEL (AC)

WARNING

- Exposure of the eyes or hands to the cooler's refrigerant could result in blindness or frostbite.
Never touch the refrigerant or loosen the parts of the cooling circuit.
- Keep flames away if the refrigerant gas is leaking.
- The high-pressure pipes of the air conditioner can be very hot (80 to 120°C or 176 to 248°F). Be careful not to burn yourself.

The cooling capacity decreases if the amount of refrigerant is insufficient.
Inspect the refrigerant level using the sight glass (2) on the top of the receiver dryer (1).







1. Open the engine hood.
2. Inspect the places for the conditions below.

Places for inspection	Conditions
Cab door	Fully open
Temperature control dial	Set fully to the COOL side
Fan speed	High
Ventilation/ Circulation select lever	Circulation
Engine speed	Maximum speed
Air conditioner switch	ON

3. Inspect the refrigerant by watching the flow of air bubbles through the sight glass (2).
Refer to "Check list for refrigerant volume" on page 5-43.
4. Check the temperature of the compressor's high pressure pipe (3) and low pressure pipe (4).
Refer to "Check list for refrigerant volume" on page 5-43.



Check list for refrigerant volume

Air conditioner	Normal	Abnormal		
High/low pressure pipe temperature	High pressure pipe is hot (80 to 120°C or 176 to 248°F), low pressure pipe is cold (8 to 15°C or 46 to 59°F). Clear difference in temperature between the pipes.	High pressure pipe is warm, low pressure pipe is slightly cool. No significant difference in temperature between the pipes.	Little difference in temperature between the high-pressure pipe and the low-pressure pipe.	High pressure pipe is hot, low pressure pipe is slightly cool. A significant difference in temperature between the pipes.
Pipe connection	Normal	Some places are dirty with oil.	Some places are extremely dirty with oil.	Normal
Sight glass	 AG7G064 Almost transparent with some bubbles. Fully transparent when the engine speed is increased or decreased.	 AG7G065 Flow of bubbles can be seen constantly. Sometimes transparent or white with bubbles.	 AG7G066 Mist-like flow is faintly visible.	 AG7G067 No bubbles is visible, even when the fan is set to High and the engine is idling.
Refrigerant level	Proper level	Refrigerant may be leaking.	Refrigerant has leaked; little is left.	Refrigerant level too high

If the air conditioner is not working

If the air conditioner does not work well, set the fan switch to OFF and contact your sales or service dealer for inspection and/or repairs.

IMPORTANT: Continued use of the air conditioner when it is not working properly will damage its various parts.

IMPORTANT: Using the air conditioner when there is no refrigerant will damage the compressor.

IMPORTANT: Always consult your sales or service dealer for replacing the refrigerant. Be sure to use R134a refrigerant (660 to 740 g or 1.45 to 1.63 lb.).




EVERY 500 HOURS

REPLACING THE FUEL FILTER


WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.

<Applicable machine models 126000002 or later>



<Applicable machine models 126100003 or later>



5. Install the new filter by hand.
6. Tighten one more turn after the filter packing comes in contact with the surface of installation. (Torque when tightening with filter wrench: 19.6 to 23.5 N·m or 14 to 17ft-lb.)
7. Bleed the air.
Refer to “Bleeding air from the fuel system” on page 6-8.

1. Open the engine hood.
2. Turn the filter (1) counterclockwise with the filter wrench and remove it.
3. Clean the surface of installation of the filter stand.
4. Apply a thin layer of oil on the packing of the new filter.




REPLACING THE WATER SEPARATOR FILTER

WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.


<Applicable machine models 126000002 or later>

If equipped with filter for high sulfur fuel



1. Open the engine hood.
2. Place a pan under the filter (1).
3. Remove the plug (2) and drain the fuel from the filter case (3).
4. Loosen the bolt (4) right under the filter (1) and remove the filter case (3).
5. Replace the element (5) in the filter case (3) with a new one.
6. Install the filter case (3) and tighten the bolt (4).
7. Tighten the plug (2) and bleed air. Refer to "Bleeding air from the fuel system" on page 6-8.

<Applicable machine models 126100003 or later>



(S): Close

1. Open the engine hood.
2. Close the valve (2) of the water separator (1).
3. Place a pan for catching fuel under the drain hose.
4. Loosen the air-bleeding plug (8) and the drain plug (7) to discharge fuel from inside.
5. Remove the sensor wiring coupler (3).
6. Remove the case (4) with the filter wrench.
7. Remove the element (5), and then clean the case. When doing the above, be careful not to damage the sensor.
8. Replace the packing with a new one and lubricate it with diesel fuel.
9. Install the new element (5) on the filter stand.
10. Tighten the case (4) by hand. Be sure to do it by hand.
Tightening torque: 27 to 33 N·m (20 to 24.6 ft·lb)
11. Install the sensor wiring coupler (3).
12. Tighten the drain plug (7).
13. Bleed air.
Refer to "Bleeding air from the fuel system" on page 6-8.



EVERY 1000 HOURS

REPLACING THE HYDRAULIC OIL RETURN FILTER

Refer to “Replacing the hydraulic oil return filter” on page 5-34.

REPLACING THE PILOT LINE FILTER

Refer to “Replacing the pilot line filter” on page 5-35.

REPLACING THE TRAVEL MOTOR GEAR OIL

Refer to “Replacing the travel motor gear oil” on page 5-36.

CLEANING THE ENGINE COOLING SYSTEM




WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
 - The engine, muffler, radiator and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
 - The engine coolant is also hot and under high pressure immediately after the engine is stopped. Be careful when loosening the caps or plugs. Working on the machine under these conditions could result in burns or injuries due to the hot coolant spurting out.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
 - One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
 - The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.
- Standing at the back of the machine while the engine is running is extremely dangerous, as the machine could move suddenly. Never stand at the back of the machine while the engine is running.
- Do not remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine and wait until the engine and the cooling water cool. Then, slowly loosen the radiator cap and the drain plug to remove them.


When cleaning, if the temperature of the coolant is low, the thermostat will be closed and the coolant will not circulate in the radiator. Heat the coolant water to at least 90°C (194°F) before cleaning.



1. Open the engine hood and the side cover.



2. Gradually loosen the radiator cap (3) to release the internal pressure, and then remove the cap.



3. Place a pan for catching the waste coolant under the drain plug (4), and then loosen the drain plug (4) to drain the coolant.
4. Tighten the drain plug (4).
5. Add tap water to the radiator through the coolant fill port up to the top of the port. Take time and slowly add water, so that no air enters the radiator.
6. Close the radiator cap (3).
7. Start the engine and run it at a speed slightly above low idling. Raise the water temperature to at least 90°C (194°F), and then run the engine for about 10 minutes with the thermostat open.
8. Stop the engine, wait until the cooling water temperature becomes lower, and then remove the drain plug (4) to drain the water.
9. After draining, clean the cooling system using a cleaning agent. When using the cleaning agent, follow the instructions included with the agent.

10. Repeat the steps 4 to 8 to rinse the cooling system.
11. Tighten the drain plug (4).
12. Take time and slowly add the new coolant (mixture of antifreeze and tap water) to the radiator through the fill port until it is full.
13. Close the radiator cap (3).
14. Warm up the engine. Use the meters to check that there are no irregularities in the cooling system at this time.
15. Increase the water temperature to at least 90°C (194°F). Then, run the engine for about 10 minutes with the thermostat kept open.
16. Stop the engine, wait until the cooling water temperature becomes lower, and then check the level of coolant in the radiator.
If necessary, add cooling water until the radiator is full.
17. Close the radiator cap (3).
18. Clean the interior of the reserve tank (1), and then add coolant to the upper limit (H).
19. When the coolant has been replaced, inspect the coolant level once again after operating the machine.
Once the machine is operated, the coolant is distributed throughout the entire system, resulting in the lower coolant level.
Replenish the cooling water that has been used.



REPLACING THE AIR CLEANER ELEMENT

WARNING

Stop the engine and allow the machine to cool down before performing maintenance.


- The engine, muffler, radiator and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.

IMPORTANT: Do not use an element if its pleats, gaskets or seals are damaged.


IMPORTANT: Be sure to install the element and dust cap securely. If not, dust could be drain into the cylinder, damaging the engine.

7. Install the new elements. Press them firmly into the body (4).

8. Install the dust cup (2) with its "▲▲▲ OBEN/TOP" mark facing up, and then fasten it with the clamps (1).



1. Open the engine hood.



2. Loosen the clamps (1) and remove the dust cup (2).
3. Clean the inside of the dust cup (2).
4. Remove the primary element (3).
Do not remove the secondary element yet.
5. Clean the inside of the body (4).
6. Remove the secondary element (5).




REPLACING THE AIR BREATHER FILTER

WARNING

Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.

- Press the air breather button to relieve the tank pressure.



1. Open the right side cover.
2. Press the button (K) to relieve the internal pressure from the tank.
3. Remove the nut (N) on the air breather.
4. Remove the cover (H).
5. Replace the filter (A).
6. Install the cover (H) on the body (B).
7. Install the nut (N).

INSPECTING AND ADJUSTING THE ENGINE VALVE CLEARANCE

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING THE ENGINE COMPRESSION PRESSURE

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING AND CLEANING THE ENGINE STARTER AND THE ALTERNATOR

This operation requires experience. Ask your sales or service dealer for it.



EVERY 1500 HOURS

INSPECTING, CLEANING AND CHECKING OPERATION OF THE ENGINE FUEL INJECTORS <APPLICABLE MACHINE MODELS: 126000002 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING THE CRANKCASE BREATHING SYSTEM

This operation requires experience. Ask your sales or service dealer for it.

CLEANING THE EGR COOLER (CLEANING THE WATER SIDE AND EXHAUST AIR PASSAGE BLOWER) <APPLICABLE MACHINE MODELS: 126100003 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.



EVERY 2000 HOURS

LAPPING THE ENGINE VALVE SEATS

This operation requires experience. Ask your sales or service dealer for it.



EVERY 3000 HOURS

INSPECTING THE TURBOCHARGER (BLOW WASH AS NECESSARY)

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING, CLEANING AND CHECKING OPERATION OF THE EGR VALVE <APPLICABLE MACHINE MODELS: 126100003 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

CLEANING THE EGR LEAD VALVE <APPLICABLE MACHINE MODELS: 126100003 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING AND CLEANING THE DPF SOOT FILTER <APPLICABLE MACHINE MODELS: 126100003 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

- Do not modify the DPF without permission. If modified, it may be damaged or malfunction may occur. As a result, an expensive repair work may be required.
- Do not reuse the DPF that has been dropped to the ground. There is catalyst fitted inside the DPF. It can be damaged if strong shocks are applied to it.

INSPECTING THE OPERATION OF THE AIR INTAKE THROTTLE VALVE

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING AND CLEANING THE INJECTOR <APPLICABLE MACHINE MODELS: 126100003 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.



EVERY 4000 HOURS


REPLACING THE HYDRAULIC OIL AND CLEANING THE SUCTION STRAINER



WARNING

- Stop the engine and allow each part of the machine to cool down before performing maintenance.
 - The engine, the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
 - The hydraulic oil is also hot and under high pressure immediately after the engine is stopped. Be careful not to touch the oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.
 - Press the air breather button to relieve the internal pressure from the tank.
 - When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.

1. Slew 60° clockwise and set the machine to the hydraulic oil level inspection posture. Refer to "Inspecting the hydraulic oil tank level and replenishing" on page 5-22.
2. Open the right side cover.



AQ0G024

3. Press the button (2) to relieve the internal pressure from the tank.
4. Replace the air breather filter (A). Refer to "Replacing the air breather filter" on page 5-49.
5. Remove the plug (3).
6. Loosen the bolts and remove the flange (4).
7. Remove the return filter (5).
8. Place a pan under the plug (6) to catch the waste oil.
9. Remove the cap (B), install the connector (C), and then drain the hydraulic oil. (The oil comes out once the screw is tightened.)
10. Loosen the bolts and remove the flange (7).
11. Remove the suction strainer (8) and clean it.
12. Clean the inside of the hydraulic oil tank.
13. Remove the connector (C) and install the cap (B).
14. Install the suction strainer (8) on the tank and then install the flange (7).



15. Install the new return filter (5) and the flange (4) on the tank.
16. Add hydraulic oil from the hole of plug (3) up to the level between the upper limit (H) and the lower limit (L) in the sight gauge (1).
17. Tighten the plug (3).
18. Bleed air from the hydraulic oil circuit following "Bleeding air" below.
19. Set the machine to the hydraulic oil level inspection posture and inspect the oil level after the oil cools.
Refer to "Inspecting the hydraulic oil tank level and replenishing" on page 5-22.


• Cylinders

1. Start the engine, let it run at a low-idling speed for 10 minutes.
2. Maintain the engine at low idle, and then slowly extend and retract each cylinder 4 or 5 times, without letting them reach the stroke end.
3. While running the engine at high speed, slowly extend and retract each cylinder 4 or 5 times, without letting them reach the stroke end.
4. Return the engine speed to low idle, and then slowly extend and retract each cylinder 4 or 5 times to the stroke end.

Bleeding air

IMPORTANT: After replacing the hydraulic oil or hydraulic devices, or after performing maintenance of the hydraulic devices, bleed air from the hydraulic circuits and hydraulic devices. Failure to do so may damage the hydraulic devices.

• Hydraulic pump



1. Open the engine hood.
2. Loosen the vent plug (1) on the hydraulic pump.
3. Once hydraulic oil overflows from the vent plug hole (1), tighten the vent plug (1).



- **Emergency shut-off valve**

This operation is dangerous and requires experience. Ask your sales or service dealer for help.

If air is not released, the working equipment could become slow in reacting to the operation of the operator and show unexpected behavior.




WARNING

When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.


1. Place a pan under the hose (A) or (B) to catch the waste oil.
2. Start the engine and run it at low idle.
3. Fully lower the safety lock lever to the unlock position.

Boom



4. Hold the hose fitting (A) in place with a wrench and slowly loosen the hose nut (1).
5. Slowly move the boom in the "Boom lower" direction a little until there are no more air bubbles coming from the hose nut (1) joint.
6. Hold the hose fitting (A) in place with a wrench and tighten the hose nut (1).

Arm



4. Loosen the hose (B) slowly.
5. Slowly move the arm in the "Arm in" direction a little until there are no more air bubbles coming from the hose (B) joint.
6. Tighten the hose (B).



WHEN REQUIRED

REPLACING THE BUCKET TEETH AND THE SIDE CUTTERS

Replace the bucket teeth if the tooth points are worn. Do not wait until the bucket is damaged.




WARNING

- Before performing maintenance or repairs under the machine, lower all moveable working equipment to the ground or in the lowermost position.
- To prevent unexpected movement, firmly secure the working equipment when repairing or replacing the bucket teeth or side cutter.
- When using a hammer, pins may fly out or metal particles may be scattered. This may lead to serious injury.
 - If hard metal parts such as pins, bucket teeth, side cutter or bearings are hit with a hammer, wear protective gear such as safety goggles and gloves.
 - When hitting pins or bucket teeth, always check that there is no one in the surrounding area.
- Do not allow unauthorized personnel in the work area while working.


Removing

1. Clean the bucket and park the machine on a flat and rigid ground.



2. Place the bucket with its bottom flat on the blocks so that the locking pin can be knocked out.


3. Remove the key, and then check that the bucket is stable.



4. Knock out the locking pin (1) and remove the point (2).

Note: If the drift is set against rubber pin lock (3) when it is hit, the rubber pin lock may break. Set it against the back of the locking pin.

5. Remove the rubber pin lock (3). Check if the rubber pin lock is still usable. Replace it if it is as follows.




A There are cracks in the rubber and the roller is coming off.


B The roller is dented when pressed with a finger.




Installation



1. Remove the dirt on the surface of adaptor and the inner part of tooth, make the better contact on the mating part.
2. Push rubber pin lock (3) into the welding adaptor (4).
Do not let the rubber pin lock stick out from the welding adaptor surface.




3. Install the point (2) onto the welding adaptor (4).
Insert the point so that the surface behind the point's pin hole is aligned with the surface behind the welding adapter's pin hole.



4. Knock out the locking pin (1).
Check that the end surfaces of the locking pin just knocked out are aligned with the upper and lower surface of the point. Do not use the worn locking pin.
The life of the teeth can be lengthened and the frequency of its replacement can be reduced by turning it upside down so that it will wear evenly.
Replace the rubber pin lock and locking pin at the same time as replacing the teeth. This makes it possible to prevent the teeth from falling out

• Side cutter Installation



1. Insert the bolts from the inner of the bucket and tighten the side cutter with nuts.
Tightening torque: 475 N·m (350 ft-lb.)
2. Caulk the bolts with a punch at three spots along the periphery of the screw to prevent the nuts from coming loose.




REPLACING THE BUCKET

WARNING

- Before performing maintenance or repairs under the machine, lower all working equipment to the ground or in the lowermost position.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
 - One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
 - The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.
- When using a hammer, pins may fly out or metal particles may be scattered. This may lead to serious injury.
 - If hard metal parts such as pins, bucket teeth, side cutter or bearings are hit with a hammer, wear protective gear such as safety goggles and gloves.
 - When hitting pins or bucket teeth, always check that there is no one in the surrounding area.
- When aligning the pin holes, always do so by checking them visually. Do not insert your finger in the pin hole, or you could lose your finger.


Removing



1. Lower the bucket to the ground as shown on the figure above in a stable position.

Note: When removing pins, set the bucket so that it is barely touching the ground. If the bucket is firmly touching the ground, the resistance will be great and it will be difficult to remove the pin.

2. Set the safety lock lever to the locked position and stop the engine.




3. Remove the bolt (1).
4. Hammer the pin (2) out of the bucket.
5. Remove the bucket.


Inspect the pin seal (3) and replace it if it is deformed or damaged. (See next page.)




Installation




1. Set the O-ring (4) on the bucket as shown on the figure above.



2. Align the pin hole (A) on the bucket with the pin hole on the arm (5), and install the pin (2).
3. Operate the cylinder, align the pin hole (B) on the bucket with the pin hole on the link arm (6), and install the pin (2).



4. Align the turn prevention holes, and then install the bolt (1) and the nut. Be sure to leave a gap of about 0.5 to 1 mm (0.02 to 0.04 in.) between the nut and bucket bush, or the nut will come loose.




5. Adjust the gap between the bucket and the arm.

Refer to "Adjusting the gap between the bucket and arm (If equipped)" on page 5-60.

6. Slide the O-ring (4).

Replacing the pin seal




1. Set the pin seal (3) in the direction shown on the figure above.
2. Use a mallet to slowly press the pin seal in. Be careful not to damage the seal.




ADJUSTING THE GAP BETWEEN THE BUCKET AND ARM (IF EQUIPPED)

WARNING


- Before performing maintenance or repairs under the machine, lower all working equipment to the ground or in the lowermost position.
- To prevent unexpected movement, securely block the working equipment when adjusting the gap.




1. Lower the bucket to the ground as shown on the figure above in a stable position.
2. Check that the bucket does not move, and then set the safety lock lever to the locked position and stop the engine.



3. Move the O-ring (1) to bring the gap (A) into view and measure the width of the gap (A).
The gap (A) should be 0.5 mm (0.02 in.). Swing the upperstructure slightly to the left and lightly press the arm point to the left side of the bucket (the side without an adjuster).



4. Remove the three bolts (2), the end plate (3) and flange (4).



5. Pull out the adjustment shim(s) (5) corresponding to the gap (A) from between the flange (4) and the bucket body.
Adjustment shim thickness : 0.5 mm (0.02 in.)
Be careful that the gap is no less than 0.5 mm (0.02 in.) after adjustment.

Note:

Example (for a gap of 2 mm or 0.08 in.):
2 mm - 0.5 mm (standard value) = 1.5 mm (0.06 in.)

In the above example, three shims (5) should be removed.

6. Insert the adjustment shim(s) (5) removed in step 5 above between the end plate (3) and the flange (4), and then fasten it in place with the three bolts (2).
 - Tightening torque for bolts (2): 83 N·m (61.5 ft·lb.)
7. Return the O-ring (1) to the original position.




INSPECTING AND REPLENISHING THE WINDSHIELD WASHER FLUID

WARNING

Choose ethyl alcohol as washer solution. Do not use methyl alcohol as washer solution. It could damage the eyes.

Use a windshield washer fluid designed specifically for motor vehicles. Follow the instructions included with the washer fluid.



Inspection

1. Open the right side cover.
2. Inspect the washer tank (1) and add washer fluid if the level is low.

Replenishing


1. Mix the washer fluid to the prescribed concentration.
2. Remove the cap (2) and add washer fluid. Keep the dust away while replenishing the washer fluid.
3. Install the cap (2).

DRAINING THE WATER FROM THE WATER SEPARATOR


WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.

<Applicable machine models 126000002 or later>



<Applicable machine models 126100003 or later>



1. Open the engine hood.
2. Place a pan under the drain valve (7) to catch fuel.
3. Open the drain valve (7) and drain the water.
If the water does not drain easily, loosen the plug (8).



4. Close the drain valve (7) and tighten the plug (8).
Refer to "Bleeding air from the fuel system" on page 6-8.


LUBRICATING THE LEVERS AND PEDALS

WARNING


Set the machine to the parking posture, stop the engine, remove the starter key and store it. Failure to do so may result in the machine moving abruptly, leading to serious injury or death.

If the levers or pedals no longer move smoothly, grease them.


Operating levers




Travel levers



Boom swing pedal



Dozer blade lever



1. Remove the lower mount section of the boot (1) and turn it upward.
2. Wipe off the old grease.
3. Apply grease to points (A) and (B).
4. Set the boot (1) back as it was.




INSPECTING THE RUBBER CRAWLERS

Repair or replace the rubber crawlers if their condition becomes as described below. Consult your sales or service dealer for repair or replacement.

Rubber crawler


Replace the crawler if the entire crawler is stretched and cannot be adjusted.

(1) Lug



Replace if the height of (A) is 5 mm (0.2 in.) or below.


(2) Steel cord



Replace if the steel cord is exposed for two links or more.


Replace if the half or more of the steel cords on one side are cut.

(3) Metal core



Replace if even one metal core is off.

(4) Rubber



Repair if there are cracks of 60 mm (2.4 in.) or greater in length.

If the steel cord is visible, repair as soon as possible, regardless of the length of the crack.




REPLACING THE RUBBER CRAWLERS



WARNING


- If you must work beneath the raised machine or working equipment, always use wood blocks, jack-stands or other rigid and stable supports. Never get under the machine or working equipment if they are not sufficiently supported.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
 - One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
 - The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.



3. Set an iron pipe (1) in the rubber crawler and turn the sprocket slowly in the reverse direction.
4. Turn until the iron pipe (1) is directly next to the idler and the rubber crawler lifts away from the idler, then stop turning the sprocket.
5. Slide the rubber crawler sideways and remove it from the crawler frame. Remove the other rubber crawler using the same procedure.

Removal

1. Fully release the tension of the rubber crawler.
Refer to "Inspecting and adjusting the crawler tension" on page 5-28.




2. Use the working equipment to lift the body.



Installation

1. Use the working equipment to lift the body.



2. Set the rubber crawler on the sprocket.
3. Set an iron pipe (1) in the rubber crawler and turn the sprocket slowly in the reverse direction.
4. Turn until the iron pipe (1) is directly next to the idler and the rubber crawler lifts away from the idler, then stop turning the sprocket.
5. Slide the rubber crawler inward, engage it on the idler, then pull out the iron pipe.
6. Check that the rubber crawler is securely engaged on the sprocket and idler.
7. Tighten the rubber crawler to the standard tension.
Refer to "Inspecting and adjusting the crawler tension" on page 5-28.
8. Install the other rubber crawler using the same procedure.



EVERY 2 YEARS

REPLACING THE RECEIVER DRYER

This operation requires experience. Ask your sales or service dealer for it.



MAINTENANCE DURING EXTENDED STORAGE PERIOD

Storage procedures

If the machine is to be stored for 30 days or more, store it indoors. If it must be stored outdoors, park the machine on a surface laid with lumber on a flat ground, and place a waterproof cover over it so that it stays dry.

1. Clean the machine.
2. Inspect for oil leakage, water leakage, cracks and loose nuts and bolts.
3. Add fuel and replace the hydraulic oil and oil.
4. To prevent rusting and freezing, replace the engine coolant with long-life coolant (LLC).
Refer to "Cleaning the engine cooling system" on page 5-46.
5. Use the grease gun to lubricate the grease fittings.
6. Fully retract the bucket and arm cylinders and lower the bucket and dozer blade to the ground.
7. Apply rust-inhibiting oil to the hydraulic cylinder rods.
8. Disconnect the negative cable from the battery and cover the battery to prevent freezing.

During storage



WARNING

- **Do not operate the machine in an enclosed area without adequate ventilation.**
- **If natural ventilation is not possible, install ventilators, fans, exhaust extension pipes or other venting devices.**

1. To prevent rusting, operate the machine once a month so that the oil can be circulated throughout the system.
2. Inspect the battery and recharge it as necessary.
Ask your sales or service dealer for recharging.

Starting the machine after storage

IMPORTANT: If the above "Storage procedures" have not been followed during the extended storage periods, consult your sales or service dealer before starting the machine again.

1. Wipe off the rust-inhibiting oil that was applied on the piston rods of the hydraulic oil cylinders.
2. Add oil or grease as necessary.

Returning the engine to service

1. Perform the daily checks.
2. The engine should be pre-oiled before startup.
 - a. Crank the engine, leaving the fuel system shut off so the engine will not start, for 15 seconds.
 - b. Then pause for 30 seconds.
 - c. Repeat the procedure until you have cranked the engine for a total of one minute. This will circulate the oil in the engine's lubrication system.
3. Prime the fuel system.
4. Start the engine. Allow the engine to idle for approximately 15 minutes while you check for:
 - Proper oil pressure
 - Fuel, engine oil or coolant leaks
 - Proper operation of the indicators and/or gauges
5. Avoid prolonged operation at minimum or maximum engine speeds and loads for the remainder of the first hour of operation.

TROUBLESHOOTING






SYMPTOMS THAT ARE NOT MALFUNCTIONS


The symptoms listed below are not malfunctions.

- It becomes less easy to operate the machine when an attachment weighing more than a standard arm or bucket is installed.



AG7J002

- The arm retracting speed momentarily slows down when it reaches an almost vertical position while the engine is running at low speed.



AG7J003

- The bucket teeth moving speed momentarily slows down when it reaches an almost horizontal position while the engine is running at low speed.
- The slew motor produces noise at the beginning and end of the slewing.
- The travel motor produces noise when stopped suddenly from its high speed traveling.
- The control valve produces noise if excessive force is applied to the working equipment or when it moved to the stroke end.




IF THE ENGINE OVERHEATS

WARNING


- Do not open the engine hood when steam is coming from it. The steam or hot water may spurt out and cause burns.
- Do not try to remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine, wait until the engine and the radiator cool, and then slowly loosen the radiator cap to release the internal pressure.
- Before performing maintenance, stop the engine and allow the machine to cool down.

The symptoms listed below indicate overheating.

< Canopy >



< Cab >



- An alarm is sounded and the engine emergency lamp and the coolant temperature warning lamp start flashing.

- The water temperature gauge level is in the red zone.
- The engine slows down and the engine power decreases.
- Steam comes from the engine room.

Remedy procedure

1. Park the machine in a safe place.
2. Check if steam is coming out of the closed engine hood.
3. If there is steam, stop the engine immediately and contact your sales or service dealer for repair. If steam is not coming out run the engine at low idle and let the water temperature cool down.
4. When the water temperature gauge level drops in the green zone, stop the engine.
5. Perform the inspections and the remedies listed below once the engine cools down.
 - Fan belt slack..... Adjust
Refer to page 5-26.
 - Coolant level Add
Refer to page 5-18.
 - Water leakage Repair
 - Radiator fins..... Clean
Refer to page 5-39.
 - Sediment in cooling system
..... Clean
Refer to page 5-46.

If the problem persists after the above remedies, contact your sales or service dealer for repair.



IF THE BATTERY GOES DEAD

The symptoms below indicate that the battery is dead.

- The starter motor does not turn or fails to start the engine.
- The horn is too weak.

Remedy procedure

Start the engine using the booster battery on the other vehicle (booster vehicle) and the jumper cables.



WARNING

- When starting the engine using the jumper cables, be sure to connect the cables by following the proper steps. Improper use of jumper cables can result in battery explosion or unexpected machine motion.
 - Do not allow the booster vehicle and the machine with a dead battery (dead machine) to touch each other.
 - Do not allow the positive (+) and the negative (-) clips of the jumper cables to touch each other.
 - When connecting, attach the jumper cable to the positive (+) terminals first. When disconnecting, remove the cable from the negative (-) terminal (ground) first.
 - Connect the last clip of the jumper cable to a point as far away from the battery as possible.
- Always wear the protective goggle when jump starting the engine by using the jumper cables.


IMPORTANT: Use the jumper cables and clips of a size suited to the capacity of battery. Do not use damaged or corroded jumper cables and clips.

IMPORTANT: Be sure that the battery of the booster vehicle has the same capacity as the battery of the dead machine.

IMPORTANT: Be sure to connect the clips securely.

Connecting the jumper cables

IMPORTANT: Set the starter keys of the booster vehicle and the dead machine to the OFF position.




1. Connect the clip of jumper cable (R) to the positive (+) battery terminal of the dead machine.
2. Connect the other clip of jumper cable (R) to the positive (+) battery terminal of the booster vehicle.
3. Connect the clip of jumper cable (B) to the negative (-) battery terminal of the booster vehicle.
4. Connect the other clip of jumper cable (B) to the engine block of the dead machine. Connect the clip to a place as far from the battery as possible.

Starting the engine

1. Check that the clips are securely connected to the terminals.
2. Start the engine of the booster vehicle and run it at high speed.
3. Start the engine of the dead machine.

**IF THE BATTERY GOES DEAD****Disconnecting the jumper cables**

Once the dead machine is successfully running, remove the jumper cables by following the same steps as for connection in the reverse order.



1. Disconnect the clip of jumper cable (B) from the engine block of the dead machine.
2. Disconnect the other clip of jumper cable (B) from the negative (-) battery terminal of the booster vehicle.
3. Disconnect the clip of jumper cable (R) from the positive (+) battery terminal of the booster vehicle.
4. Disconnect the clip of jumper cable (R) from the positive (+) battery terminal of the dead machine.

Recharging

Ask your sales or service dealer for recharging the dead battery.



IF A FUSE BLOWS

If a light does not come on or the electrical system does not work, a fuse may be blown. Inspect the fuses.


INSPECTING AND REPLACING THE FUSE




WARNING

If the fuse blows again soon after replacement, then the electric system is likely faulty. It may pose a fire hazard if not properly repaired. Contact your sales or service dealer for advice.

1. Turn the starter key to the OFF position to stop the engine.



2. Open the fuse box cover (1).
3. Check for any blown fuses (2).



4. If a fuse is blown, replace it with a spare fuse of the same capacity.


Fuse layout and circuits protected

Capacity	Symbol	Protected circuit
5A		Switch lighting
10A		Horn
5A		Starter switch
10A		Immobilizer
25A		Light
10A*		Wiper
20A*/15A		Lever lock
15A	CTL	Controller power supply
20A	CTL (OX)	OX controller power supply
25A*	CAB	Cab interior power supply
25A	OPT(1)	Option (1)
10A*		Air conditioner
30A*		Engine ACC <Applicable machine models 126000002 or later>
10A		Feed pump
30A*		Air conditioner blower motor
25A	CAB	Cab light

*: Cab



INSPECTING THE FUSIBLE LINK



If the machine is not turned on after turning the starter switch to the ON position, there is likely a break in the cartridge type fusible link (1).

1. Open the right side cover.
2. Loosen the bolts and remove the cover (2).
3. Inspect the fusible link (1).
4. If there is a break, please contact your sales or service dealer.

Note: Fusible links are large type fuses used in high current applications. Like a regular fuse, they act as fuses by protecting the electric components and wirings from damage caused by excessive current draw.




RESTARTING AFTER ADDING FUEL

BLEEDING AIR FROM THE FUEL SYSTEM


IMPORTANT: NEVER use the starter motor to crank the engine in order to prime the fuel system. This may cause the starter motor to overheat and damage the coils, pinion gear and/or ring gear.

IMPORTANT: If the engine stalls due to fuel shortage, add fuel, turn the key to the ON position for 60 seconds, and then turn it to the START position. Running the starter for a long time before there is enough fuel is going through can cause the starter to fail.

problems. Always bleed air when the fuel tank is emptied or when there is air in the fuel system.



1. Add fuel.



2. Turn the starter key to the ON position and hold it for about 60 seconds.

The automatic air bleeder bleeds air from the fuel system.

Note: Air in the fuel system causes the engine to fail to start or to have other

MEMO



IF A WARNING LAMP FLASHES

If an alarm is sounded or a warning lamp starts flashing during operation, park the machine in a safe place and perform the remedy procedures described below.

Warning lamp	Lamp name	Causes and remedies
 AW4J007	Vehicle and engine emergency lamp	There is a problem in the machine. Refer to the respective warning lamp below. Get the vehicle or engine error code number from the multi-information display or the instrument cluster, and then consult your sales or service dealer referring to the "Vehicle error code list" or "Engine error code list". Refer to "Multi-information display" on page 2-16 or "Instrument cluster" on page 2-28. Refer to "Vehicle error code list" on pages 6-12 and 6-13. Refer to "Engine error code list" on pages 6-14 to 6-21. <Applicable machine models 126100003 or later>
 AW4J0041	ECM error warning lamp <Applicable machine models 126100003 or later>	An engine problem is detected. If an error code is displayed on the multi-information display or the instrument cluster, inform your sales or service dealer of the code and ask for help. Refer to "Multi-information display" on page 2-16 or "Instrument cluster" on page 2-28. Refer to "Engine error code list" on pages 6-14 to 6-21.
 AG7J019	Battery charge warning lamp	There is a problem with the fan belt or charger. Check the fan belt for slack or breakage and adjust as necessary. If the lamp continues flashing after maintenance, there is likely a problem with the charger. Consult your sales or service dealer for help. Refer to "Inspecting and adjusting the fan belt" on page 5-26.
 AG7J017	Engine oil pressure warning lamp	There is a problem in the engine lubrication system. Check the engine oil level. If the lamp is flashing when the level is normal or even after replenishment of oil or coolant, consult your sales or service dealer. Refer to "Inspecting and replenishing the engine oil" on page 5-19.
 AW4J009	Water separator warning lamp	Water is in the water separator. Drain water. Refer to "Draining the water from the water separator" on page 5-61.

**IF A WARNING LAMP FLASHES**

Warning lamp	Lamp name	Causes and remedies
 AG7J018	Coolant temperature warning lamp	The coolant temperature is too high and the engine is overheating. Refer to “If the engine overheats” on page 6-3.
 AG7J020	Air cleaner warning lamp	The air cleaner is clogged. Clean it. Refer to “Cleaning the air cleaner” on page 5-38.
 AQ0J008	Fuel filter warning lamp	The fuel filter is clogged. Replace the fuel filter. Refer to “Replacing the fuel filter” on page 5-44.
 AW4J010	Fuel level warning lamp	The fuel level is too low. Add fuel. Refer to “Inspecting the fuel level” on page 5-21.
 AQ0J004	Third auxiliary hydraulic warning lamp	Pressure in the third auxiliary hydraulic line is too low Consult your sales or service dealer for help.
 AM1J005	Lift overload warning indicator lamp	This lamp starts flashing if the overload warning device is activated. If it occurs, reduce the load to be lifted. Refer to “Lift overload warning switch (If equipped)” on page 2-57.



VEHICLE ERROR CODE LIST

If an error code appears on the display, consult your sales or service dealer.

Error code	Error details
9	Impossible to sense ACC key
19	Parameter version mismatching
402	CAN 0 communication error
602	CAN communication error (cluster gauge)
612	CAN communication error (OX024)
1703	Main power supply voltage error (too high)
1704	Main power supply voltage error (too low)
1713	OX024 power supply voltage error (too high)
1714	OX024 power supply voltage error (too low)
2503	Sensor voltage error (too high) MMC
2504	Sensor voltage error (too low) MMC
3300	Alternator charge faulty
3401	Engine oil pressure error
3500	Overheat
3503	Water temperature (high pressure) <Applicable machine models: 126000002 or later>
3504	Water temperature (low pressure) <Applicable machine models: 126000002 or later>
3600	Air cleaner clogged
3700	Water separator alarm
5303	Accelerator sensor error (too high)
5304	Accelerator sensor error (too low)
5353	Governor position sensor error (high pressure) <Applicable machine models: 126000002 or later>
5354	Governor position sensor error (low pressure) <Applicable machine models: 126000002 or later>
5505	Fuel gauge resistance value error (cable break)



Error code	Error details
5603	Lift alarm sensor error (too high)
5604	Lift alarm sensor error (too low)
6503	AUX1 slide switch voltage value error (too high)
6504	AUX1 slide switch voltage value error (too low)
6509	AUX1 slide switch neutral error
6519	AUX1 (L) switch error
6529	AUX1 (R) switch error
6603	AUX2 slide switch voltage value error (too high)
6604	AUX2 slide switch voltage value error (too low)
6609	AUX2 slide switch neutral error
6709	AUX3 button error (Grip)
6719	AUX3 switch error (Foot)
8005	Pump PWM output voltage error (too low)
8006	Pump PWM output voltage error (too high)
8015	AUX1 (L) PWM output voltage error (too low)
8016	AUX1 (L) PWM output voltage error (too high)
8025	AUX1 (R) PWM output voltage error (too low)
8026	AUX1 (R) PWM output voltage error (too high)
8035	AUX2 (L) PWM output voltage error (too low)
8036	AUX2 (L) PWM output voltage error (too high)
8045	AUX2 (R) PWM output voltage error (too low)
8046	AUX2 (R) PWM output voltage error (too high)
8054	Throttle motor A (low pressure) <Applicable machine model: 126000002 or later>
8064	Throttle motor B (low pressure) <Applicable machine model: 126000002 or later>

PWM = Pulse width modulation



ENGINE ERROR CODE LIST

If an error code appears on the display, consult your sales or service dealer.

<Applicable machine models 126000002 or later>

No engine error code

<Applicable machine models 126100003 or later>

Error code		Error details	DTC
SPN	FMI		
522400	2	Crank speed sensor (Crank signal malfunction)	P0336
	5	Crank speed sensor (No crank signal)	P0337
522401	2	Cam speed sensor (Cam signal malfunction)	P0341
	5	Cam speed sensor (No cam signal)	P0342
	7	Cam speed sensor (Angle offset failure)	P1341
523249	5	No signal on both crank and cam speed sensor	P0008
91	3	Accelerator sensor 1 (Excessive sensor output)	P0123
	4	Accelerator sensor 1 (Insufficient sensor output)	P0122
28	3	Accelerator sensor 2 (Excessive sensor output)	P0223
	4	Accelerator sensor 2 (Insufficient sensor output)	P0222
522624	7	Dual accelerator sensor (closed position) failure	P1646
522623	7	Dual accelerator sensor (open position) failure	P1647
29	3	Accelerator sensor 3 (Excessive sensor output)	P0228
	4	Accelerator sensor 3 (Insufficient sensor output)	P0227
	8	Pulse sensor failure (Pulse communication)	P1227
28	0	Accelerator sensor 3 failure (Foot pedal in open positon)	P1126
	1	Accelerator sensor 3 failure (Foot pedal in closed positon)	P1125
51	3	Intake throttle opening sensor fault (High voltage)	P02E9
	4	Intake throttle opening sensor fault (Low voltage)	P02E8

**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
102	3	EGR low pressure side sensor fault (High voltage)	P0238
	4	EGR low pressure side sensor fault (Low voltage)	P0237
	13	EGR low pressure side sensor fault (Abnormal learning value)	P0236
1209	3	EGR high pressure side sensor fault (High voltage)	P0473
	4	EGR high pressure side sensor fault (Low voltage)	P0472
	13	EGR high pressure side sensor (Abnormal learning value)	P0471
110	3	Cooling water temperature sensor fault (High voltage)	P0118
	4	Cooling water temperature sensor fault (Low voltage)	P0117
	0	Cooling water temperature sensor temperature abnormal high (Overheat)	P0217
172	3	New air temperature sensor fault (High voltage)	P0113
	4	New air temperature sensor fault (Low voltage)	P0112
174	3	Fuel temperature sensor fault (High voltage)	P0183
	4	Fuel temperature sensor fault (Low voltage)	P0182
	0	Fuel temperature sensor temperature abnormal high	P0168
157	3	Rail pressure sensor fault (High voltage)	P0193
	4	Rail pressure sensor fault (Low voltage)	P0192
3251	3	DPF differential pressure sensor fault (High voltage)	P2455
	4	DPF differential pressure sensor fault (Low voltage)	P2454
	0	DPF differential pressure sensor differential pressure abnormal high	P2452
	13	DPF differential pressure sensor (Abnormal learning value)	P2453
3609	3	DPF high pressure side sensor fault (High voltage)	P1455
	4	DPF high pressure side sensor fault (Low voltage)	P1454
3242	3	DPF inlet temperature sensor fault (High voltage)	P1428
	4	DPF inlet temperature sensor fault (Low voltage)	P1427
	0	DPF inlet temperature sensor temperature abnormal high	P1436

**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
3250	3	DPF intermediate temperature sensor fault (High voltage)	P1434
	4	DPF intermediate temperature sensor fault (Low voltage)	P1435
	1	DPF intermediate temperature sensor temperature abnormal low temperature	P0420
	0	DPF intermediate temperature sensor temperature abnormal high (Post-injection failure)	P1426
108	3	Atmospheric pressure sensor fault (High voltage)	P2229
	4	Atmospheric pressure sensor fault (Low voltage)	P2228
	10	Atmospheric pressure sensor characteristic fault	P1231
412	3	EGR gas temperature sensor fault (High voltage)	P041D
	4	EGR gas temperature sensor fault (Low voltage)	P041C
105	3	Intake manifold temperature sensor fault (High voltage)	P040D
	4	Intake manifold temperature sensor fault (Low voltage)	P040C
173	3	Exhaust manifold temperature sensor fault (High voltage)	P0546
	4	Exhaust manifold temperature sensor fault (Low voltage)	P0545
1485	7	Main relay contact stuck	P068B
	2	Main relay early opening	P068A
522243	5	Startup assist relay interrupted	P0543
	6	Startup assist relay GND interrupted	P0541
651 (4TNV), 652 (3TNV)	5	Injector 1 open circuit (Inherent location of the injector)	P0204 (4TNV), P0203 (3TNV)
	6	Injector 1 coil short circuit	P0271 (4TNV), P0268 (3TNV)
	3	Injector 1 short circuit	P1271 (4TNV), P1262 (3TNV)

**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
653	5	Injector 2 open circuit (Inherent location of the injector)	P0202
	6	Injector 2 coil short circuit	P0265
	3	Injector 2 short circuit	P1265
654	5	Injector 3 open circuit (Inherent location of the injector)	P0201
	6	Injector 3 coil short circuit	P0262
	3	Injector 3 short circuit	P1262
652	5	Injector 4 open circuit (Inherent location of the injector)	P0203
	6	Injector 4 coil short circuit	P0268
	3	Injector 4 short circuit	P1268
4257	12	Injector drive IC error	P0611
2797	6	Injector drive circuit (Bank 1) short circuit (4TN: Common circuit for No.1, No.4 and all 3TN cylinders)	P1146
2798	6	Injector drive circuit (Bank 2) short circuit (4TN: Circuit for No.2 and No.3 cylinders)	P1149
523462	13	IQA corrected injection amount for injector 1 error	P1648
523463	13	IQA corrected injection amount for injector 2 error	P1649
523464	13	IQA corrected injection amount for injector 3 error	P1650
523465	13	IQA corrected injection amount for injector 4 error	P1651
522571	3	High-pressure pump drive circuit (Low side VB short-circuit)	P1641
	6	High-pressure pump drive circuit (Low side GND short-circuit)	P1643
633	3	High-pressure pump drive circuit (High side VB short-circuit)	P0629
	6	High-pressure pump drive circuit (High side GND short-circuit)	P1642
	5	High-pressure pump drive circuit (Open circuit)	P0627
522572	6	High-pressure pump drive circuit (Drive current (high level))	P062A
	11	High-pressure pump drive circuit (Pump overload error)	P1645

**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
157	0	Actual rail pressure rise error	P0088
	18	Rail pressure deviation error during the actual rail pressure drop	P0094
	15	Rail pressure deviation error during the actual rail pressure rise	P0093
	16	PLV open valve	P000F
523469	0	Rail pressure fault (The times of PLV valve opening error)	P1666
523470	0	Rail pressure fault (The time of PLV valve opening error)	P1667
523489	0	Rail pressure fault (The actual rail pressure is too high during PRV limp home)	P1668
523468	9	Rail pressure fault (Controlled rail pressure error after PLV valve opening)	P1665
523491	0	Rail pressure fault (Injector B/F temperature error during PLV4 limp home)	P1669
523460	7	Rail pressure fault (Operation time error during RPS limp home)	P1670
190	16	Overspeed	P0219
2950	5	No-load of throttle valve drive H bridge circuit	P0660
	3	Power short circuit of throttle valve drive H bridge output 1	P1658
	4	GND short circuit of throttle valve drive H bridge output 1	P1659
	6	Overload on the drive H bridge circuit of throttle valve	P1660
2951	3	VB Power short circuit of throttle valve drive H bridge output 2	P1661
	4	GND short circuit of throttle valve drive H bridge output 2	P1662
522596	9	TSC1 (CAN message) reception time out (SA1)	U0292
522597	9	TSC1 (CAN message) reception time out (SA2)	U1301
522599	9	Y_ECR1 (CAN message) reception time out	U1292
522600	9	Y_EC (CAN message) reception time out	U1293
522601	9	Y_RSS (CAN message) reception time out	U1294
522603	9	VH (CAN message) reception time out	U1296
522605	9	Y_ECM3 (CAN message) reception time out	U1298

**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
237	31	VI (CAN message) reception time out	U0168
	13	VI (CAN message) reception data fault	U3002
522609	9	Y_ETCP1 (CAN message) reception time out	U1300
522618	9	EBC1 (CAN message) reception time out	U1302
522619	9	Y_DPFIF (CAN message) reception time out	U1303
522610	9	CAN1 (for EGR): Reception time out	U010B
522611	9	Exhaust throttle (CAN message from the exhaust throttle time out)	U1107
2791	0	EGR over-voltage fault	P0404
	1	EGR under-voltage fault	P1404
	7	EGR feedback malfunction	P1409
	9	EGR ECM data fault	U0401
	12	Open circuit between the EGR motor coils	P0403
522579	12	Short circuit between the EGR motor coils	P1405
522580	12	EGR position sensor malfunction	P0488
522581	7	EGR stuck open valve malfunction	P148A
522582	7	EGR initialization malfunction	P049D
522183	1	EGR high temperature thermistor malfunction	P1410
522184	1	EGR low temperature thermistor malfunction	P1411
522617	12	EGR target value out of range	U1401
522746	12	Exhaust throttle (Voltage fault)	P1438
522747	12	Exhaust throttle (Motor fault)	P1439
522748	12	Exhaust throttle (Sensor system fault)	P1440
522749	12	Exhaust throttle (MPU fault)	P1441
522750	12	Exhaust throttle (PCB fault)	P1442
522751	19	Exhaust throttle (CAN fault)	P1443
630	12	EEPROM memory deletion error	P0601
522576	12	EEPROM memory read error	P160E

**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
522578	12	EEPROM memory writing error	P160F
522585	12	ECU internal fault (CY146 SPI communication fault)	P1613
522588	12	ECU internal fault (Excessive voltage of supply 1)	P1608
522589	12	ECU internal fault (Insufficient voltage of supply 1)	P1617
522590	12	ECU internal fault (Sensor supply voltage error 1)	P1609
522591	12	ECU internal fault (Sensor supply voltage error 2)	P1618
522592	12	ECU internal fault (Sensor supply voltage error 3)	P1619
522744	4	ECU internal fault (Actuator drive circuit 1 short to ground)	P1626
522994	4	ECU internal fault (Actuator drive circuit 2 short to ground)	P1633
523471	6	ECU internal fault (Actuator drive circuit 3 short to ground)	P1467
523473	12	ECU internal fault (AD converter fault 1)	P1469
523474	12	ECU internal fault (AD converter fault 2)	P1470
523475	12	ECU internal fault (External monitoring IC and CPU fault 1)	P1471
523476	12	ECU internal fault (External monitoring IC and CPU fault 2)	P1472
523477	12	ECU internal fault (ROM fault)	P1473
523478	12	ECU internal fault (Shutoff path fault 1)	P1474
523479	12	ECU internal fault (Shutoff path fault 2)	P1475
523480	12	ECU internal fault (Shutoff path fault 3)	P1476
523481	12	ECU internal fault (Shutoff path fault 4)	P1477
523482	12	ECU internal fault (Shutoff path fault 5)	P1478
523483	12	ECU internal fault (Shutoff path fault 6)	P1479
523484	12	ECU internal fault (Shutoff path fault 7)	P1480
523485	12	ECU internal fault (Shutoff path fault 8)	P1481
523486	12	ECU internal fault (Shutoff path fault 9)	P1482
523487	12	ECU internal fault (Shutoff path fault 10)	P1483
523488	0	ECU internal fault (Recognition error of engine speed)	P1484
522323	0	Air cleaner clogged alarm	P1101



Error code		Error details	DTC
SPN	FMI		
522329	0	Oil/water separator alarm	P1151
167	5	Charge switch (Charge switch open circuit)	P1562
	1	Charge switch (Charge alarm)	P1568
100	4	Oil pressure switch (Oil pressure switch open circuit)	P1192
	1	Oil pressure switch (Low oil pressure fault alarm)	P1198
522573	0	DPF overaccumulation (Method C)	P2463
522574	0	DPF overaccumulation (Method P)	P1463
522575	7	DPF regeneration defect (Stationary regeneration failure)	P2458
522577	11	DPF regeneration defect (Stationary regeneration not-performed)	P2459
3720	16	DPF OP interface (Ash cleaning request 1)	P242F
	0	DPF OP interface (Ash cleaning request 2)	P1420
3719	16	DPF OP interface (Stationary regeneration standby)	P1421
	0	DPF OP interface (Backup mode)	P1424
3695	14	DPF OP interface (Reset regeneration prohibited)	P1425
3719	9	DPF OP interface (Recovery regeneration failure)	P1445
	7	DPF OP interface (Recovery regeneration prohibition)	P1446



OTHER SYMPTOMS

For symptoms not included in the table below or if the problem persists after the proper remedies have been taken, consult your sales or service dealer.

Symptoms	Major causes	Remedies
Left and right operating levers do not move smoothly	• Insufficient grease on the left and right operating levers	• Grease the levers. Refer to page 5-62.
Travel levers, blade lever and pedals do not move smoothly	• Insufficient grease on travel levers, blade lever and pedals	• Grease the levers and pedals. Refer to page 5-62.
Operation of hoe attachment, dozer blade, auxiliary hydraulics, slewing or traveling is not possible.	• Safety lock lever is raised (locked) • Fuse is blown	• Lower (release) the safety lock lever. Refer to page 2-58. • Replace the fuse. Refer to page 6-6.
Digging force is insufficient	• Hydraulic oil level too low • Hydraulic oil is not warm enough • Air cleaner is clogged • Hydraulic oil is not of suitable type	• Add to the specified level. Refer to page 5-22. • Perform the warm-up. Refer to pages 3-8 to 3-9. • Clean the air cleaner. Refer to page 5-38. • Replace the hydraulic oil. Refer to page 5-53.
Traveling is not possible or not smooth	• Stones or foreign objects are stuck	• Remove the foreign object.
Machine veers to the right/left	• Stones or foreign objects are stuck • Crawler belt tension is faulty.	• Remove the foreign object. • Check and adjust (ask your sales or service dealer). Refer to pages 5-28 to 5-29.
Travel speed cannot be changed	• Fuse is blown	• Replace the fuse. Refer to page 6-6.
Slewing is not possible or not smooth	• Insufficient grease on slew bearing	• Grease the bearing. Refer to page 5-30.
Hydraulic oil temperature is too high	• Hydraulic oil level too low	• Add up to the specified level. Refer to page 5-22.



Symptoms	Major causes	Remedies
Starter motor turns but engine does not start	• Insufficient fuel • Air in fuel system • Water in fuel system • Fuel is frozen. • Engine control system is faulty. • Fuel line is faulty. • Preheating device is faulty.	• Add fuel. Refer to page 5-21. • Bleed air. Refer to page 6-8. • Drain water. Refer to page 5-30. • Warm the fuel pipe with hot water or wait until the ambient temperature becomes high. • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer).
Crawlers come off	• Crawlers too loose	• Check and adjust (ask your sales or service dealer). Refer to pages 5-28 to 5-29.
Engine exhaust is white or bluish	• Excessive engine oil • Insufficient engine warm-up. • Engine control system is faulty. • Fuel line is faulty. • Prolonged idling (approx. two hours or more) • Poor fuel	• Adjust to the specified level. Refer to page 5-19. • Perform the warm-up operation. Refer to page 3-5. • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer). • Increase the engine RPM and check for smoke. • Replace the fuel.



Symptoms	Major causes	Remedies
Engine exhaust is occasionally black	• Air cleaner is clogged • Engine control system is faulty. • Fuel line is faulty. • Clogging in the exhaust line. • DPF is faulty.	• Clean the air cleaner. Refer to page 5-38. • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer).
Irregular noise is produced from the engine (combustion or mechanical noise)	• Low quality fuel is being used • Engine is overheating • Damage inside the muffler	• Replace the fuel. • Refer to “If the engine overheats” on page 6-3. • Replace the muffler. For replacement, ask your sales or service dealer.



LOWERING THE BOOM TO THE GROUND

If the hoe attachment must be lowered to the ground while the engine is stopped, use the following procedure.

Procedure 1 (machines with an accumulator)

Perform this operation within 10 minutes after the engine stopping.

1. Sit at the operator's seat.
2. Turn the starter switch to the ON position.
3. Lower the safety lock lever to the unlock position
4. Slowly push the operating lever forward to lower the boom.

Procedure 2 (machines without an accumulator)

This operation is dangerous and requires experience. Ask your sales or service dealer for it.




WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
 - The engine and the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
 - The hydraulic oil is also hot and under high pressure immediately after the engine is stopped. Be careful when loosening the caps or plugs. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Keep away from the working area when the hoe attachment is lowered. You may be hit by dirt falling out of the bucket or the hoe attachment as it drops.
- Slowly turn the hose nut and lower the boom at a slow pace.
- Do not loosen or remove the hoses not located in the specified places. Oil may

spurt out if wrongly handled.

Emergency shut-off valve



1. Place a pan under the hose to catch the waste oil.
2. Hold the hose fitting (1) with a wrench and slowly loosen the hose nut (2) with another wrench.
3. The oil in the boom cylinder is drained and the hoe attachment is lowered.
4. After the hoe attachment is lowered to the ground, check the safety and stability of the machine.
5. Hold the hose fitting (1) with a wrench and tighten the hose nut (2) with another wrench.
 - Tightening torque: 31.4 N·m (23.1 ft-lb.)



TOWING



WARNING

When towing, serious injury or death could result, if performed incorrectly or the wire rope being used is inappropriate or not properly inspected.


- It becomes dangerous if the wire rope breaks or becomes disengaged. Use a wire rope appropriate for the required tractive force.
- Do not use a wire rope that is kinked, twisted or otherwise damaged.
- Do not apply heavy loads abruptly to the wire rope.
- Wear safety gloves when handling the wire rope.
- Make sure there is an operator on the machine being towed as well as on the machine that is towing.
- Never tow on slopes.
- Do not let anyone come near to the wire rope while towing.

IMPORTANT: Do not tow a machine if its engine does not start or if the machine does not run. Doing so could damage the machine being towed.

IMPORTANT: Be sure to follow the steps below closely when using the towing hole to tow. Failure to heed even one of the steps may cause damage to the towing hole or other parts of the frame.

Towing the machine

Use the procedure described below to tow heavy objects or the machine itself if it should get stuck in the mud and not be able to get out on its own.



- Permissible forces: 83.2 kN (18700 lbf)
Do not tow using only a towing hole on one side.

1. Attach the wire rope to the shackle (1).
2. Fasten the shackle (1) to the towing holes (2).
3. Make sure that the wire rope is at a cone angle of 20° or less to the travel frame.
4. Move the machine to tension the wire rope.
5. Operate the machine slowly and tow.



IF THE CAB OR CANOPY IS DAMAGED



WARNING

Immediately replace the damaged cab or canopy. Serious injury or death may occur if the machine is operated with damaged cab/canopy.

Do not operate the machine until the replacement is complete. Do not try to repair the damaged cab or canopy by welding. Doing so could endanger the safety of the cab/canopy.

Canopy part number: 05584-00085

Cab part number: 05586-03100

SPECIFICATIONS





BASIC SPECIFICATIONS

<Applicable machine models 126000002 or later>


Type			Cab	
MASS				
Operating mass	kg (lb)	Rubber crawlers	5735 (12645)	
		Steel crawlers	5920 (13050)	
PERFORMANCE				
Bucket capacity (Standard bucket)	m³ (cu. ft.)	Heaped	0.168 (5.93)	
		Struck	0.127 (4.48)	
Slew speed	min ⁻¹ (rpm)		9.4 (9.4)	
Travel speed	km/h (mph)	Rubber crawlers	1st	2.8 (1.74)
			2nd	4.9 (3.04)
		Steel crawlers	1st	2.6 (1.62)
			2nd	4.6 (2.86)
Gradeability	(degrees)		30	
Ground pressure	kPa (psi)	Rubber crawlers	31.5 (4.57)	
		Steel crawlers	32.7 (4.74)	
Noise level	dB (A)	Sound power level	L _{WA} 97	
		Sound pressure level	L _{pA} 80	
ENGINE				
Manufacturer and model			Yanmar 4TNV84T-BPTB	
Rated output	Net (ISO 14396)	kW/min ⁻¹ (hp/rpm)	34.3/2400 (46/2400)	
	Net (ISO 9249/ SAEJ1349)	kW/min ⁻¹ (hp/rpm)	32.4/2400 (43.4/2400)	
Displacement		ml (cu.in.)	1995 (121.7)	
Starter		V-kW	12-2.3	
Alternator		V-kW	12-0.66	
Battery (IEC 60095-1)		V-A·h	12-90	



<Applicable machine models 126100003 or later>

Type			Canopy	Cab
MASS				
Operating mass	kg (lb)	Rubber crawlers	5500 (12125)	5735 (12645)
		Steel crawlers	5685 (12535)	5920 (13050)
PERFORMANCE				
Bucket capacity (Standard bucket)	m³ (cu. ft.)	Heaped	0.168 (5.93)	
		Struck	0.127 (4.48)	
Slew speed	min ⁻¹ (rpm)	9.4 (9.4)		
Travel speed	km/h (mph)	Rubber crawlers	1st	2.8 (1.74)
			2nd	4.9 (3.04)
		Steel crawlers	1st	2.6 (1.62)
			2nd	4.6 (2.86)
Gradeability	(degrees)	30		
Ground pressure	kPa (psi)	Rubber crawlers	30.2 (4.38)	31.5 (4.57)
		Steel crawlers	31.4 (4.55)	32.7 (4.74)
Noise level	dB (A)	Sound power level	L _{WA} 97	
		Sound pressure level	L _{pA} 75	
ENGINE				
Manufacturer and model			Yanmar 4TNV86CT-PTB I	Yanmar 4TNV86CT-PTB
Rated output	Net (ISO 14396)	kW/min ⁻¹ (hp/rpm)	35.5/2400 (47.6/2400)	
	Net (ISO 9249/SAEJ1349)	kW/min ⁻¹ (hp/rpm)	33.6/2400 (45.1/2400)	
Displacement		ml (cu.in.)	2091 (127.6)	
Starter		V-kW	12-2.3	
Alternator		V-kW	12-0.66	
Battery (IEC 60095-1)		V-A·h	12-90	

MACHINE DIMENSIONS



AQ0K001

<Applicable machine models 126000002 or later /126100003 or later>


Unit: mm (inch)

	Item	Middle arm		Long arm	
		Rubber crawlers	Steel crawlers	Rubber crawlers	Steel crawlers
A	Overall length	5540 (218.0)	←	5550 (218.5)	←
B	Upperstructure overall width	1870 (73.6)	←	←	←
C	Overall height	2560 (100.8) 2575 (101.4)**	2550 (100.4) 2565 (101.0)**	2560 (100.8) 2575 (101.4) **	2550 (100.4) 2565 (101.0) **
D	Slew radius	1300 (51.2)	←	←	←
E	Clearance height under upperstructure	635 (25.0)	625 (24.6)	635 (25.0)	625 (24.6)
F	Crawler base	2050 (80.7)	2035 (80.2)	2050 (80.7)	2035 (80.2)
G	Crawler overall length	2575 (101.3)	2560 (100.8)	2575 (101.3)	2560 (100.8)
H	Crawler overall width	2000 (78.7)	←	←	←
J	Crawler shoe width	400 (15.7)	←	←	←
K	Ground clearance of undercarriage	330 (13.1)	325 (12.7)	330 (13.1)	325 (12.7)
L	Minimum radius of equipment and attachment	2390 (94.0)	←	2420 (95.4)	←
M	Minimum radius of equipment at maximum front offset	1945 (76.6)	←	1975 (77.8)	←
P	Offset distance of bucket (right swing)	655 (25.8)	←	←	←
Q	Offset distance of bucket (left swing)	785 (31.0)	←	←	←
R	Dozer blade width	2000 (78.7)	←	←	←
S	Dozer blade height	430 (16.9)	←	←	←
T	Front distance to axis of rotation	4240 (166.9)	←	4255 (167.5)	←
U	Dozer blade distance to axis of rotation	1870 (73.6) 1930 (76.0)*	←	←	←
V	Boom swing angle (Left)	78°	←	←	←
W	Boom swing angle (Right)	55°	←	←	←
X	Overall length (dozer blade at rear)	6110 (240.5) 6170 (242.9)*	←	6125 (241.2) 6185 (243.5)*	←

* : With an angle dozer blade

** : Canopy

OPERATING RANGES



AQ0K002



<Applicable machine models 126000002 or later /126100003 or later>

Unit: mm (inch)

	Item	Middle arm		Long arm	
		Rubber crawlers	Steel crawlers	Rubber crawlers	Steel crawlers
A	Maximum reach	6120 (240.9)	←	6270 (246.9)	←
B	Maximum reach at ground reference plane	5975 (235.3)	←	6130 (241.4)	←
C	Maximum digging depth	3735 (147.1)	3745 (147.4)	3895 (153.4)	3905 (153.7)
D	Maximum vertical digging depth	2830 (111.3)	2835 (111.7)	2980 (117.4)	2990 (117.7)
E	Reach at maximum vertical digging depth	4175 (164.3)	←	4220 (166.1)	←
F	Maximum height of cutting edge	5835 (229.7)	5825 (229.4)	5940 (233.9)	5930 (233.5)
G	Maximum dumping height	4115 (162.0)	4105 (161.6)	4220 (166.1)	4210 (165.8)
H	Minimum dumping height	1465 (57.6)	1455 (57.3)	1305 (51.5)	1300 (51.1)
J	Dozer blade maximum lifting	430 (16.9) 445 (17.5)*	420 (16.5) 435 (17.2)*	430 (16.9) 445 (17.5)*	420 (16.5) 435 (17.2)*
K	Dozer blade maximum lowering	430 (16.9) 450 (17.7)*	440 (17.2) 455 (18.0)*	430 (16.9) 450 (17.7)*	440 (17.2) 455 (18.0)*

*: With an angle dozer blade

MEMO



LIFTING CAPACITIES

Rated lift capacity chart

- The loads in the charts do not exceed 87% of hydraulic lift capacity or 75% of tipping load.
- Figures marked with an asterisk (*) are hydraulically-limited capacities.
- The mass of slings and any other lifting devices shall be deducted from the rated load to determine the net load that may be lifted.
- The load point is the bucket hinge pin, and the bucket posture is with the standard bucket completely retracted under the arm.
- Unit: daN (lbs)

Load hooking system

A load hooking system must be provided with the following capabilities.

1. A system which can withstand twice the rated lift capacity no matter at what position the load is applied.
2. A system that poses no risk of the lifted load falling from the hooking device. For example, equipped with a hook slippage prevention device.
3. A system that poses no risk of the hooking system slipping from the hoe attachment.




WARNING

- Do not attempt to lift or hold any load that is greater than these rated values at their specified load radii and height.
 - The rated lift capacities are based on the machine being level and situated on a firm supporting surface. For safe lifting, the operator is expected to make due allowance for the particular job conditions such as soft or uneven ground, non-level condition, load to the machine sides, hazardous conditions, experience of personnel, etc. The operator and other personnel should fully acquaint themselves with the operator's manual furnished by the manufacturer before operating this machine. When operating the machine, the safety rules of the equipment must also be followed.
 - Do not travel while lifting a load; It is very dangerous.
-



<Cab> Middle arm (Applicable machine models 126000002 or later)

Over Front ; Dozer Blade Up




Units: daN(lbs.)




<Cab> Middle arm (Applicable machine models 126000002 or later)

Over Side



Over Rear




Units: daN(lbs.)




<Cab> Long arm (Applicable machine models 126000002 or later)

Over Front ; Dozer Blade Up






<Cab> Long arm (Applicable machine models 126000002 or later)





<Cab> Middle arm (Applicable machine models 126100003 or later)

Over Front ; Dozer Blade Up




Units: daN(lbs.)




<Cab> Middle arm (Applicable machine models 126100003 or later)

Over Side



Over Rear




Units: daN(lbs.)




<Cab> Long arm (Applicable machine models 126100003 or later)

Over Front ; Dozer Blade Up






<Cab> Long arm (Applicable machine models 126100003 or later)





<Canopy> Middle arm (Applicable machine models 126100003 or later)

Over Front ; Dozer Blade Up




Units: daN(lbs.)




<Canopy> Middle arm (Applicable machine models 126100003 or later)

Over Side



Units: daN(lbs.)


Over Rear





<Canopy> Long arm (Applicable machine models 126100003 or later)

Over Front ; Dozer Blade Up




Units: daN(lbs.)




<Canopy> Long arm (Applicable machine models 126100003 or later)

Over Side



Over Rear



Units: daN(lbs.)

OPTIONS



GENERAL PRECAUTIONS

SAFETY PRECAUTIONS



WARNING

When removing or installing an attachment or optional part, take the following precautions.

- Consult with Takeuchi before installing an optional attachment.
- Do not use any attachments not approved by Takeuchi. Doing so may cause safety problems. Or, it may adversely affect the machine's operation or service life.
- We will not be held responsible for any injuries, accidents or damage to its products caused by the use by a non-approved attachment.
- Select a firm, level work area. Also, be sure to park in a well ventilated place.
- Clear obstacles and dangerous objects, and clean up spilled fuel immediately.
- When hoisting, be sure to designate a person to act as a signalman. Follow the instructions of the signalman regarding the procedure and measures.
- When it is necessary to temporarily place a heavy object or an attachment on the ground during removal or installation, be sure to place it in a stable position.
- Keep everyone out of the area when hoisting. There is a hazard of objects falling or contacting with people in the area.
- Use a crane to move heavy objects (25 kg (55 lb.) or greater).
- Before removing a heavy object, be sure to put a support to it. When lifting with a crane, pay attention to the center of gravity of the load to keep the machine in balance.
- Do not operate the machine while the load is lifted by a crane stand.

- Use the proper procedure when mounting a boom or arm; otherwise serious damage could result. Consult your sales or service dealer for help.

CAUTIONS WHEN INSTALLING ATTACHMENTS

Be sure to perform a test operation after an optional or other special attachment has been replaced. Inspect the hydraulic oil level and recharge it as necessary. Consult your sales or service dealer for detailed procedures on installing/removing attachments.




CAUTIONS WHEN OPERATING ATTACHMENTS



WARNING

Long attachments reduce stability of the machine. The machine may tip over if it loses the balance when traveling or slewing on slopes.


Never perform the operations listed below as they are extremely dangerous.



- Traveling down the slopes with the attachment raised



- Traveling across slopes



- Slewing on slopes
- If there is a heavy attachment is installed, the machine takes longer distance than usual to come to a complete stop when the stopping operation is performed. Carefully judge the distance so as not to bump into an object around the machine. Keep a safe distance from surrounding obstacles. When a heavy attachment is installed, natural drop (the gradual dropping of the attachment under its own weight when it is stopped in midair) increases.
- The machine can tip over more easily in the lateral direction than in the longitudinal direction.
 - Do not slew sideways with a heavy load at the how attachment. In particular, do not slew sideways on slopes.
 - The attachment is heavier for machines equipped with breakers or crushers than for machines equipped with the standard bucket. Do not operate such machines sideways, especially digging downhill.
- When a long arm is installed, the operating range increases. Carefully judge the distance so as not to bump into an object around the machine. Keep a safe distance from surrounding obstacles.



ATTACHMENT COMBINATION TABLE

The table below shows which bucket should be installed when the machine is using a standard arm, middle arm or long arm. Select a proper bucket by following the table.

WARNING

- Consult with Takeuchi before installing an optional attachment.
- Do not use any attachments not approved by Takeuchi. Doing so may cause safety problems. Or, it may adversely affect the machine's operation or service life.
- We will not be held responsible for any injuries, accidents or damage to its products caused by the use by a non-approved attachment.
- The swing stopper must be installed when a bucket wider than a 640W (standard) bucket is installed. Failure to do so may result in the bucket hitting the machine body.

√ :Can be used.

Δ :Can be used only for light operations (digging and loading of dry and loose soil or mud)

— :Cannot be used.

Total bucket mass = Bucket mass + Heaped bucket load (specific gravity: 1.8)

Bucket	Rated capacity m ³ (cu.yd.)	Bucket cutting width mm (inch)	Middle arm 1620 mm (63.8 in.)	Long arm 1780 mm (70.1 in.)
640 W (S.T.D.)	0.168 (0.2)	640 (25.2)	√	√
Total bucket weight= Within 440 kg (970 lb.)		Within 640 (25.2)	√	√




SELECTING A LEVER PATTERN

The operating pattern of the left and right operating levers can be changed.




WARNING

Before starting the engine, check the selector to see which operating pattern the left and right operating levers are set.



AG7L0331

SWITCHING THE LEVER PATTERN



(A) : ISO pattern

(G) : G pattern

1. Park the machine on a flat and rigid ground, and stop the engine.
2. Open the right side cover.
3. Loosen the wing bolt (1).
4. Turn the selector valve lever (2) to change the pattern.
5. Tighten the wing bolt (1) and fasten the lever (2) in place.
6. Close the right side cover.
7. Confirm the lever pattern.




HYDRAULIC BREAKER


For handling of the breaker, read the hydraulic breaker's manual, provided separately.

IMPORTANT: When installing an attachment, make sure that it is appropriate for the machine being used. Contact your sales or service dealer for advice on selecting attachments.


CAUTIONS ON OPERATING




- Start the engine and run it at 75% of the maximum speed.




- Pound with the chisel pressed perpendicular to the surface to be pounded.
- When pounding, press the chisel properly against the object to be broken so as to avoid pounding the air.




- Do not pry with the chisel or do not pry while pounding.
- Do not move the chisel while pounding.
- Do not pound continuously for over 30 seconds on the same surface.



- Do not pound with the cylinder fully extended or retracted (at the stroke end). Leave a margin of at least 50mm(2 in).



- Do not pound with the arm placed perpendicular to the ground surface.



- Do not drop the breaker itself on the object to be broken in order to break it.
- Do not move objects to be broken or rocks with the breaker itself.
- Slew the machine occasionally to cool the engine.
- If a hydraulic hose is vibrating abnormally, nitrogen gas may be leaking from the accumulator. Ask for an inspection early.

REPLACING THE HYDRAULIC OIL REGULARLY


When a hydraulic breaker is used, the oil deteriorates more quickly than that used for a usual operation. Be sure to replace the hydraulic oil and the return filter elements.

- Failure to replace these in time can lead to damage to the machine and the breaker hydraulic system. To improve the service life of the hydraulic systems, be sure to replace the hydraulic oil and return filter element after the number of hours shown on the diagram below.
- When replacing the hydraulic oil, clean the suction strainer.

Replacement interval (hours)

Item	Hydraulic oil	Filter element
1st time	—	25
2nd time	—	100
Periodically	1200 (600)	200

When the breaker operating ratio is 100%.



(): When using conventional antiwear hydraulic oil.



TRAVEL ALARM

The alarm sounds while the machine is traveling and stops when the machine stops traveling.


If the alarm does not sound when the machine travels, the fuse may be blown. Inspect the fuses.




WARNING

If the fuse blows again soon after replacement, then the electric system is likely faulty. It may pose a fire hazard if not properly repaired. Contact your sales or service dealer for advice.

1. Turn the starter key to the OFF position to stop the engine.



2. Open the fuse box cover (1).
3. Check for any blown fuses (2).



4. If a fuse is blown, replace it with a spare fuse of the same capacity.

Fuse layout and circuits protected

Capacity	Symbol	Protected circuit
5A		Switch lighting
10A		Horn
5A		Starter switch
10A		Immobilizer
25A		Light
10A*		Wiper
20A*/15A		Lever lock
15A	CTL	Controller power supply, Travel alarm
20A	CTL (OX)	OX controller power supply
25A*	CAB	Cab interior power supply
25A	OPT(1)	Option (1)
10A*		Air conditioner
30A*		Engine ACC <Applicable machine models 126000002 or later>
10A		Feed pump
30A*		Air conditioner blower motor
25A	CAB	Cab light

*: Cab



OPTIONAL EQUIPMENT MASS

Standard machine mass kg (lb.) (Not including operator)		Applicable machine models 126000002 or later	Applicable machine models 126100003 or later
		Cab/Rubber crawlers	
		5660 (12480)	
OPTION			
Steel crawler		175 (385)	
Segmental rubber crawler		176 (388)	
Center guide		10 (20)	
Angle blade		—	130 (285)
Long arm		13 (30)	
Auxiliary hydraulic lines	Auxiliary 3rd + Auxiliary 4th.	13 (30)	
Roof guard (Level II: ISO 10262)		47 (104)	
Front guard (Level II: ISO 10262)		42 (91)	

Units: kg (lb)

*: Mass of optional equipment is added to the standard machine mass.

*: This table only contains the optional equipment of 10kg (20lb) or more in mass.



BIODEGRADABLE OIL

Biodegradable oil is a new type of hydraulic oil that is decomposed into carbon dioxide and water by microorganisms in the soil and water. It is highly safe for living organisms and offers advantages in term of environmental protection.

- Recommended biodegradable oil: Mobile EAL EnviroSyn 46H (an ester synthetic oil). When replacing the hydraulic oil with biodegradable oil, use the above or an equivalent oil.
Note that other oils, even other brands of ester synthetic oils, may damage O-rings, packings and seals. Takeuchi products shipped with the optional biodegradable oil are shipped with the above brand of oil.
- When switching from a mineral oil to a biodegradable oil, the parking brake torque decreases by about 30%.

REPLACING THE HYDRAULIC OIL WITH BIODEGRADABLE OIL

Mixing mineral oil with biodegradable oil will result in a decrease of the hydraulic oil's performance as well as a decrease in biodegradability and safety. The hydraulic oil system must be flushed as described below before supplying the biodegradable oil. This operation is dangerous and requires experience. Have it performed by a Takeuchi sales or service outlet.

Flushing

To be performed by a Takeuchi sales or service outlet


1. Drain the hydraulic oil (mineral oil) from the hydraulic oil tank and clean the inside of the tank and suction strainer.
Refer to "Replacing the hydraulic oil and cleaning the suction strainer".
2. Remove the cylinder hoses and drain the hydraulic oil (mineral oil) from inside the cylinders.
3. Supply new biodegradable oil to the hydraulic oil tank.

4. Bleed the air from the hydraulic oil system.
5. Operate the hydraulic devices for 30 minutes.
6. Drain the biodegradable oil from the tank and cylinders.
7. Replace the hydraulic oil return filter with a new filter.
8. Repeat steps 3 and 4.
9. Operate the hydraulic devices for 30 minutes.
10. Drain the biodegradable oil from the tank and cylinders.
11. Repeat steps 3 and 4.
12. Operate the hydraulic devices for 1 hour.
13. Drain the biodegradable oil from the tank and cylinders.
14. Replace the return filter with a new filter.
15. Repeat steps 3 and 4.
16. Operate the hydraulic devices, then check for oil leakage.

There is no need to flush the hydraulic oil system when switching from biodegradable to mineral hydraulic oil.



CAB OPTIONS



AM1L0031

1. Rain guard
2. Front light
3. Roof guard (Level II: ISO 10262)
4. Front guard (Level II: ISO 10262)
5. Rear light



ANGLE DOZER BLADE <APPLICABLE MACHINE MODELS 126100003 OR LATER>



WARNING

- Do not press the float button while the machine is raised by the dozer blade. Doing so will cause the machine to fall. If you must work beneath the raised machine, always use a secure support to keep the machine raised.
- Do not press the float button while the dozer blade is raised. Doing so will cause the dozer blade to fall. Lower the dozer blade to the ground before pressing the float button.
- Do not travel forward while the dozer blade is in the float mode.

IMPORTANT: Do not raise the machine by using the angled dozer blade. Or, the dozer blade may be damaged due to the load concentrated onto a point on the dozer blade.

This dozer blade can be angled (to 25° right or left). Also, it can be used in the float mode.

Angle operation



Button (A) Left angle (0 to 25°)

Button (B) Right angle (0 to 25°)

The dozer blade angle is increased/decreased between 0 and 25° as long as the button is pressed.


To position the dozer blade at a right angle, align the matching marks (D) as shown in the figure.

Float operation


Button (C) Float mode

To cancel the float mode, press the button again.

Daily inspection (every 10 hours) Lubricating



1. Lower the working equipment to the ground and stop the engine.
2. Use the grease gun to lubricate the grease fitting.
3. Wipe off the excess grease.

**SPECIFICATIONS**

AQOL004

	Item	Rubber crawlers
A	Dozer blade width	2000 (78.7)
B	Dozer blade height	430 (17)
C	Dozer blade distance to axis of rotation	1930 (76)
D	Dozer blade maximum lifting	445 (17.5)
E	Dozer blade maximum lowering	450 (17.6)
F	Angle degree (Left/Right)	25°


Unit: mm (inch)



OPERATING LEVER SWITCH

KIT 1

HORN BUTTON




Press the button situated on the left operating lever to blow the horn.

DECELERATION BUTTON

WARNING

Before operating the deceleration button, set the operating lever to the neutral position and take your foot off the pedals. If the deceleration button is pressed while driving, the machine's operating speed will abruptly change to result in a dangerous situation.



Press this button on the left operating lever to lower the engine speed to low idling. Press the button again to return to the engine speed set with the throttle controller. For safety reasons, it is designed that the deceleration function is activated to set the

engine revolutions to low idling whenever the engine is started.


Cancel the deceleration mode by pressing the deceleration button as necessary.

Note: This deceleration button is capable of decreasing the engine speed and reducing the fuel consumption, with a simple operation, in a situation such as when little engine output is required and thus the operating or the travel levers are in neutral.

TRAVEL SPEED BUTTON

WARNING

When a load greater than a set value is applied during traveling in 2nd (high) speed, the speed will automatically slow down to 1st (low) speed. When the load becomes lighter, the speed will increase and return to 2nd (high) speed. It should be noted that the travel speed changes depending on the load condition (for machines with the automatic travel shift-down system).




Press this switch to set the travel speed to 2nd (high) speed. Press it again to return to 1st (low) speed.



AUXILIARY 1ST SWITCHES

Auxiliary hydraulic buttons



Press those buttons to control the flow of the oil in the first auxiliary hydraulic lines.

- Proportional control of the auxiliary hydraulic circuit is not possible.

(A).....Hydraulic oil flows to the left auxiliary line (a).


(B) Hydraulic oil flows to the right auxiliary line (b).

Slider switch

(Proportional control)

Proportional control allows for slow-to-fast/ fast-to-slow movement of attachment.

Example: If you move the slider switch half way, the attachment will move at approximately one-half the speed.



Move this switch to control the flow of the oil in the first auxiliary hydraulic lines.

(A).....Hydraulic oil flows to the left auxiliary line (a).

(B) Hydraulic oil flows to the right auxiliary line (b).

Refer to “Auxiliary hydraulic lines” on pages 2-76 to 2-80.


AUXILIARY 2ND/4TH SWITCH

Slider switch

(Proportional control)

Proportional control allows for slow-to-fast/ fast-to-slow movement of attachment.


Example: If you move the slider switch half way, the attachment will move at approximately one-half the speed.



Move this switch to control the flow of the oil in the second auxiliary hydraulic lines.

(C): Hydraulic oil flows to the left auxiliary line (c).

(D): Hydraulic oil flows to the right auxiliary line (d).




To use the auxiliary 4th hydraulic line, press the auxiliary 2/4 select button to change to the operation of the auxiliary 4th.

Refer to “Auxiliary hydraulic lines” on pages 2-76 to 2-80.



AUXILIARY 2/4 SELECT BUTTON




This button is used to change from the second auxiliary operation to the fourth auxiliary operation.

Pressing this button displays the second auxiliary on the display to indicate that the second auxiliary operation is enabled.

Pressing this button one more time displays the fourth auxiliary on the display to indicate that the fourth auxiliary operation is enabled.

The actual operation is performed with the auxiliary 2nd/4th switch (slider switch).



Operating

Press those buttons to control the flow of the oil in the first/second auxiliary hydraulic lines.

- (A).....Hydraulic oil flows to left auxiliary line (a).
- (B) Hydraulic oil flows to right auxiliary line (b).
- (C) Hydraulic oil flows to left auxiliary line (c).
- (D) Hydraulic oil flows to right auxiliary line (d).

Refer to "Auxiliary hydraulic lines" on pages 2-76 to 2-80.

Releasing the residual pressure

After the auxiliary hydraulic circuits have been used, pressure remains in the circuits. This is called the residual pressure. Release this residual pressure before disconnecting the lines.

Perform the residual pressure releasing within 10 minutes after the engine stopping.

1. Park the machine on a flat, rigid and safe ground.
2. Stop the engine.
3. Lower the safety lock lever to the unlocked position.
4. Turn the starter switch to the ON position.
5. Press the auxiliary hydraulic switches several times to release the residual pressure in the auxiliary hydraulic circuitry.

First Published March 2013
Eighth Published February 2015

No.43754

OPERATOR'S MANUAL

TB260 Mini excavator

Edited and issued by TAKEUCHI MFG. CO., LTD.

Printed in Japan by STATION M Co., Ltd.

CALIFORNIA

PROPOSITION 65 WARNING

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling battery.

EC-CONFORMITY CERTIFICATE

We herewith declare that following named machine, based on its conception and design and in the form brought into service is in accordance with the relevant, basic safety and health requirements of the following EC directives. In case of any alteration of the machine not coordinated with us, this certificate loses its validity.

Designation of the machine	Compact Excavator
Manufacturer	TAKEUCHI MFG. CO., LTD 205 Uwadaira, Sakaki-machi, Hanishina-gun, Nagano 389-0605, Japan

Model	TB260 <S/N 126000002~>	TB260 <S/N 126100003~>
Engine type	4TNV84T-BPTB	4TNV86CT-PTB
Engine power	34.3 kW @ 2400 rpm	35.5 kW @ 2400 rpm

The machine is in accordance with the requirements of EC regulations:

- 1) Machine directive 2006/42/EC and appendix
- 2) Electromagnetic compatibility-regulation 2004/108/EC and appendix
- 3) Noise directive 2000/14/EC (Evaluation procedure according to appendix VI), 2005/88/EC and appendices.
- 4) Regulations on engine emissions: 2004/26/EC and appendices.

Harmonized norms: EN474-1:2006+A1:2009, EN474-5:2006+A2:2012.

Complier of the technical files:

Hans Friedrich
Oliver Scharschmidt
Wilhelm Schafer GmbH
68307 Mannheim-Sandhofen GERMANY

Issued in Sakaki, Japan
Akio Takeuchi, President