



SERVICE MANUAL

B SERIES TRACTORS

B-1	B-10
BIG TEN	B-12
B-110	B-112
HB-112	HB-212
B-206	B-206-E
B-207	B-207-E
B-208	B-208-S

SPECIFICATIONS	A	
ENGINE	B	
TRACTOR	C	
HYDROSTATIC DRIVE UNIT	D	
POWER TRAIN	E	
WIRING DIAGRAM	F	
B-SERIES ATTACHMENTS	G	

NOTE: When repairing any "B" Series Tractor, refer to the proper component in the Service Manual which is found in the unit being worked on. Many of the components are similar in design and care should be used in picking the proper procedure and picture.



SAFETY PRECAUTIONS

ATTENTION! BECOME ALERT!
YOUR SAFETY IS INVOLVED!

This symbol is used to call your attention to safety precautions that should be followed by the operator to avoid accidents. When you see this symbol - Heed Its Warning.

Many hours of lost time and much suffering is caused by the failure to practice simple safety rules.

IT IS TOO LATE TO REMEMBER WHAT SHOULD HAVE BEEN DONE AFTER THE ACCIDENT HAS HAPPENED.

OPERATION

- * **KNOW THE CONTROLS** and how to stop quickly - **READ THE OPERATOR'S MANUAL.**
- * **DO NOT** allow children to operate vehicle. **DO NOT** allow adults to operate it without proper instruction.
- **DO NOT** carry passengers. **KEEP CHILDREN AND PETS A SAFE DISTANCE AWAY.**
- **CLEAR** work area of objects which might be picked up and thrown.
- **TAKE ALL** possible precautions when leaving vehicle unattended; such as disengaging power take off, lowering attachments, shifting into neutral, setting parking brake, stopping engine and removing key.
- **DO NOT** stop or start suddenly when going uphill or downhill. Mow up and down the face of steep slopes; never across the face.
- * **REDUCE** speed on slopes and in sharp turns to prevent tipping or loss of control. Exercise extreme caution when changing direction on slopes.
- **STAY ALERT** for holes in terrain and other hidden hazards.
- * **USE CARE** when pulling loads or using heavy equipment:
 - A. Use only approved drawbar hitch points.
 - B. Limit loads to those you can safely control.
 - C. Do not turn sharply. Use care when backing.
 - D. Use counterweight(s) or wheel weights when suggested in operator's manual.
- **WATCH** for traffic when crossing or near roadways.
- **KEEP** all nuts, bolts and screws tight to be sure equipment is in safe working condition.
- **DO NOT** change engine governor settings or overspeed engine.

- **DO NOT** operate equipment when barefoot or wearing open sandals. Always wear substantial footwear.
- **CAUTION:** This tractor does not have warning devices for operation on public roads or highways.
- **OPERATE TRACTOR ONLY** in daylight or good artificial light.

FUEL AND FIRE HAZARDS

- **HANDLE** gasoline with **care** -- it is highly flammable. Always carry and store it in an approved gasoline container.
- * **DO NOT** remove the **fuel cap** or fill fuel tanks:
 - A. When the engine is running.
 - B. When engine is hot.
 - C. While using a **lantern**.
 - D. While smoking.
 - E. When tractor is in a **closed** building.
- **DO NOT** overfill the **fuel tank** or spill the fuel.
- **DO NOT** run the engine in a closed area -- exhaust fumes are very **dangerous**.
- **NEVER** store equipment with gasoline in the tank inside a building where **fumes** may reach an open flame or spark.
- **ALLOW** engine to cool **before** storing in any enclosure.
- **TO REDUCE** fire hazard keep engine free of grass, leaves or excessive grease.

IMPLEMENTS

- **DISENGAGE** all implement clutches and shift into neutral before attempting to start engine.
- * **DISENGAGE** power to implements and stop engine before leaving operator position.
- * **DISENGAGE** power to implement(s), stop engine and remove ignition key before making any inspections, adjustments or repairs to tractor or implements.
- **DISENGAGE** power to implements when transporting or not in use.
- When using any implements **NEVER** direct discharge of material toward bystanders or allow anyone near vehicle while in operation.

- **KEEP** vehicle and implements in good operating condition and keep safety devices in place. Use guards as instructed in operator's manual. Replace lost or damaged safety decals immediately.

- * **VEHICLE** and implements should be stopped and inspected for damage after striking a foreign object and the damage should be repaired before restarting and operating the equipment.

- **REMEMBER** that safe operation is no accident.

- When using vehicle with **MOWER**:

- A. Check blade mounting bolts for proper tightness at frequent intervals.
- B. Never operate mower unless deflector assembly or vacuum collector adapter assembly is firmly attached to the mower discharge.
- C. When cleaning material out of the hoses or blower of the vacuum collector be sure to stop both tractor and blower engines and wait until all moving parts have stopped before removing hoses. **ALSO, ALWAYS REMOVE SPARK PLUG WIRE ON BLOWER engine and fasten it so that it cannot touch spark plug before placing hands inside blower housing. Moving the fan blades could possibly start engine and blower running if plug wire is not removed.**

- D. When using the roving vacuum nozzle **ALWAYS** stop tractor engine and engage parking brakes before leaving tractor seat. **ALSO NEVER** remove hose from blower entrance or discharge openings unless blower engine is stopped and all moving parts have come to a stop.

SAFETY DECALS

The safety warning signs reproduced on this page are placed at strategic locations on the top of the mower housing and tractor frame (as shown in Figure 10 in Tractor Section and 15 in Mower Section) as a constant reminder to the operator of the most important safety precautions in the operation of the mower.

If any of these signs are lost or damaged replace them at once for the operators safety. They can be purchased from your Allis-Chalmers Lawn and Garden Equipment Dealer.

AVOID ACCIDENTS

BUILT IN SAFETY FEATURES CAN BE EFFECTIVE ONLY IF PROPERLY MAINTAINED AND UTILIZED.

SAFETY AND OPERATIONAL DECALS

WARNING
DO NOT OPERATE MOWER
WITHOUT DEFLECTOR OR
VACUUM COLLECTOR IN PLACE.

DANGER
STAND CLEAR OF
DISCHARGE OPENING

CAUTION
KEEP HANDS & FEET
FROM UNDER MOWER



ALLIS-CHALMERS
Lawn and Garden Equipment
P.O. Box 997
Port Washington, WI 53074

Part No. 9003453
February, 1976
Printed in U.S.A.


INDEX

SPECIFICATIONS

B-1	A-1
B-10 S/N 15001-31227	A-2
Big TEN	A-3
B-10 S/N 50001 and Up	A-4
B-12	A-5
B-110	A-6
B-112	A-7
HB-112	A-8
B-206 and B-206-E	A-9
B-207 and B-207-E	A-10
B208 and B-208-S	A-11
B-210, B-212, and HB-212	A-12

A





SPECIFICATIONS MODEL B-1 TRACTOR

ENGINE

Make	Briggs & Stratton
Type	4 cycle - air cooled
Horse Power	7-1/4
Bore and Stroke	3" x 2-5/8"
Displacement	18.55 cu. in.
R. P. M.	3600 max. full load
Air Cleaner	Oil bath
Starter	Electric & manual
Governor	Mechanical (flyweight)
Electrical System	12 volt - combination starter-generator
Ignition System	Magneto

TRANSMISSION

Sliding spur gear and spiral bevel gear.
Three speeds forward and one reverse.

DIFFERENTIAL

Engine, Trans. Drive Spur gear with
controlled traction direct shaft with flexible
couplings.

The Allis-Chalmers Manufacturing Company reserves the right to make changes in the above specifications or to add improvements at any time without notice or obligation.

Tractors

CAPACITY

Engine Case	3 pts.
Fuel Tank	6 qts.
Transmission	1-1/2 qts.

SPEEDS

First	2 MPH
Second	3-3/4 MPH
Third	6 MPH

DIMENSIONS

Height (at steering wheel)	37-1/4"
Height (at hood line)	33-3/8"
Width	34-1/4"
Length	68"
Wheel Tread	26"
Wheel Base	44"
Clearance (front axle)	9"
Clearance (differential)	6"
Clearance (drawbar)	7"
Clearance (center housing)	15-1/4"

SHIPPING WEIGHT - Approx. 600 lbs.

SPECIFICATIONS
Model B-10 Wheel Tractor
Ser. No. 15001-31227

ENGINE

Make	Briggs & Stratton
Type	4 cycle - air cooled
Horse Power	9
Bore and Stroke	3" x 3-1/4"
Displacement	22.97 cu. in.
R. P. M.	3600 max. full load
Air Cleaner	Oil foam
Starter	Electric & manual
Governor	Mechanical (flyweight)
Electrical System	12 volt - combination starter-generator
Ignition System	Magneto

TRANSMISSION

Sliding spur gear and spiral bevel gear.
Three speeds forward and one reverse.

DIFFERENTIAL

Planetary gear with controlled traction.

CAPACITY

Engine Case	4 pts.
Fuel Tank	6 qts.
Transmission	1-1/2 qts.

SPEEDS

First	2 MPH
Second	3-3/4 MPH
Third	6 MPH


DIMENSIONS

Height (at steering wheel)	37-1/4"
Height (at hood line)	33-3/8"
Width	34-1/4"
Length	68"
Wheel Tread	26"
Wheel Base	44"
Clearance (front axle)	9"
Clearance (differential)	6"
Clearance (drawbar)	7"
Clearance (center housing)	15-1/4"

SHIPPING WEIGHT - Approx. 685 lbs.

TIRE PRESSURES

Rear	8 PSI.
Front	12 PSI.



The Allis-Chalmers Manufacturing Company reserves the right to make changes in the above specifications or to add improvements at any time without notice or obligation.

SPECIFICATIONS Model Big Ten Wheel Tractor

ENGINE

Make Briggs & Stratton
 Type 4 cycle - air cooled
 Horse Power 10
 Bore and Stroke 3-1/16" x 3-1/4"
 Displacement 23.94 cu. in.
 R. P. M. 3600 RPM full throttle full load
 Air Cleaner Oil foam
 Starter Electric & manual
 Governor Mechanical (flyweight)
 Electrical System 12 volt-combination starter-generator
 Ignition System Magneto

BATTERY

Make Allis-Chalmers-40 ampere hour-12 volt

TRANSMISSION

Sliding spur gear and spiral bevel gear. Three speeds forward and one reverse, with standard drive, six speeds forward and two reverse with optional Hi-Lo range pulley.

DIFFERENTIAL

Planetary gear with controlled traction.

SPEEDS - Standard Drive

First 2 MPH
 Second 3-3/4 MPH
 Third 6 MPH

SPEEDS - Hi-Lo Drive (Optional)

First Hi 1.5 MPH - Lo .8
 Second Hi 3.5 - Lo 1.3
 Third Hi 6.0 - Lo 2.2
 Reverse Hi 3.0 - Lo 1.1

DIMENSIONS

Height (at steering wheel) 37-1/4"
 Height (at hood line) 33-3/8"
 Width 34-1/4"
 Length 68"
 Wheel Tread 26"
 Wheel Base 44"
 Clearance (Front Axle) 9"
 Clearance (Differential) 6"
 Clearance (Drawbar) 7"
 Clearance (Center housing) 15-1/4"

SHIPPING WEIGHT - Approx. 680 lbs.

TIRE PRESSURE

	Standard Tractor	With Loader	With Fork Lift
Rear	8 PSI	20 PSI	20 PSI
Front	12 PSI	14 PSI	20 PSI

CAPACITY

Engine Crankcase 4 pts.
 Fuel Tank 6 qts. "regular" gas
 Transmission 1-1/2 qts. SAE 90 oil
 Bevel gear housing 1 pt. SAE 90 oil

The Allis-Chalmers Manufacturing Company reserves the right to make changes in the above specifications or to add improvements at any time without notice or obligation.

SPECIFICATIONS
Model B-10 Wheel Tractor
S/N 50001 and up

ENGINE

Make Briggs & Stratton
Type 4 cycle - air cooled
Horse Power 10
Bore and Stroke 3-1/16" x 3-1/4"
Displacement 23.94 cu. in.
R.P.M. 3600 RPM full throttle full load
Air Cleaner Oil foam
Starter Electric & manual
Governor Mechanical (flyweight)
Electrical System 12 volt-combination starter-generator
Ignition System Magneto

BATTERY

Make Allis-Chalmers-40 ampere hour-12 volt

TRANSMISSION

Sliding spur gear and spiral bevel gear. Three speeds forward and one reverse, with standard drive, six speeds forward and two reverse with optional Hi-Lo range pulley.

DIFFERENTIAL

Planetary gear with controlled traction.

SPEEDS - Standard Drive

First 2 MPH
Second 3-3/4 MPH
Third 6 MPH

SPEEDS - Hi-Lo Drive (Optional)

First Hi 1.5 MPH - Lo .8
Second Hi 3.5 Lo 1.3
Third Hi 6.0 Lo 2.2
Reverse Hi 3.0 Lo 1.1

DIMENSIONS

Height (at steering wheel) 37-1/4"
Height (at hood line) 33-3/8"
Width 34-1/4"
Length 68"
Wheel Tread 26"
Wheel Base 44"
Clearance (Front Axle) 9"
Clearance (Differential) 6"
Clearance (Drawbar) 7"
Clearance (Center housing) 15-1/4"

SHIPPING WEIGHT - Approx. 680 lbs.

TIRE PRESSURE

	Standard Tractor	With Loader	With Fork Lift
Rear	8 PSI	20 PSI	20 PSI
Front	12 PSI	14 PSI	20 PSI

CAPACITY

Engine Crankcase 4 pts.
Fuel Tank 6 qts. "regular" gas
Transmission 1-1/2 qts. SAE 90 oil
Bevel gear housing 1 pt.-SAE 90 oil

The Allis-Chalmers Manufacturing Company reserves the right to make changes in the above specifications or to add improvements at any time without notice or obligation.

Tractors

SPECIFICATIONS Model B-12 Wheel Tractor

ENGINE

Make Briggs & Stratton
 Type 4 cycle - air cooled
 Horse Power 12
 Bore and Stroke 3-1/4" x 3-7/16"
 Displacement 30.16 cu. in.
 R.P.M. 3600 RPM full throttle full load
 Air Cleaner Oil foam
 Starter Electric & manual
 Governor Mechanical (flyweight)
 Electrical System 12 volt-combination starter-generator
 Ignition System Magneto

BATTERY

Make Allis-Chalmers-40 ampere hour-12 volt

TRANSMISSION

Sliding spur gear and spiral bevel gear. Three speeds forward and one reverse, with standard drive, six speeds forward and two reverse with optional Hi-Lo range pulley.

DIFFERENTIAL

Planetary gear with controlled traction.

SPEEDS - Standard Drive

First 2 MPH
 Second 3-3/4 MPH
 Third 6 MPH

SPEEDS - Hi-Lo Drive (Optional)

First Hi 1.5 MPH - Lo .8
 Second Hi 3.5 Lo 1.3
 Third Hi 6.0 Lo 2.2
 Reverse Hi 3.0 Lo 1.1

DIMENSIONS

Height (at steering wheel). 37-1/4"
 Height (at hood line) 33-3/8"
 Width. 34-1/4"
 Length 68"
 Wheel Tread 26"
 Wheel Base 44"
 Clearance (front axle) 9"
 Clearance (differential). 6"
 Clearance (drawbar) 7"
 Clearance (center housing) 15-1/4"

SHIPPING WEIGHT - Approx. 680 lbs.

TIRE PRESSURE

	Standard Tractor	With Loader	With Fork Lift
Rear	.8 PSI	20 PSI	20 PSI
Front	10 PSI	14 PSI	20 PSI

CAPACITY

Engine Crankcase 4 pts.
 Fuel Tank. 6 qts. "regular" gas
 Transmission 1-1/2 qts. SAE 90 oil
 Bevel gear housing. 1 pt. SAE 90 oil

The Allis-Chalmers Manufacturing Company reserves the right to make changes in the above specifications or to add improvements at any time without notice or obligation.

SPECIFICATIONS

ENGINE

Make	Briggs & Stratton
Type	4 cycle - air cooled
Horse Power	10
Bore & Stroke	3-1/16" x 3-1/4"
Displacement	23.94 cu. in.
R.P.M.	3600 RPM full throttle full load
Air Cleaner	Oil Foam
Starter	Electric & Manual
Governor	Mechanical (flyweight)
Electrical System	12 volt -combination starter - generator
Ignition System	Magneto

BATTERY

Make Allis-Chalmers - 40 ampere hour - 12 volt

TRANSMISSION

Sliding spur gear and spiral bevel gear. Three speeds forward and one reverse, with standard drive. Six speeds forward and two reverse with optional Hi-Lo range.

DIFFERENTIAL

Planetary gear with controlled traction.

SPEEDS - Standard Drive

First		1.6 MPH
Second		3.7 MPH
Third		6.1 MPH
Reverse		3.1 MPH

SPEEDS - Hi-Lo Drive (Optional)

First	Hi	1.6 MPH
	Lo	.5
Second	Hi	3.7
	Lo	1.2
Third	Hi	6.1
	Lo	2.0
Reverse	Hi	3.1
	Lo	1.0

DIMENSIONS

Height (At Steering Wheel)	.37-3/4 "
Height (At Hood Line)	.33-1/4 "
Width	.34-1/4 "
Length	.68 "
Wheel Tread	.26 "
Wheel Base.	.44 "
Clearance (Front Axle).	.9 "
Clearance (Differential)	.6 "
Clearance (Drawbar).	.7 "
Clearance (Center Housing).	.15-1/4 "

SHIPPING WEIGHT - Approx. 685 lbs.

TIRE PRESSURE

	Standard Tractor	With Loader	With Fork Lift
Rear	.8 PSI	12 PSI	20 PSI
Front	10 PSI	25 PSI	20 PSI

CAPACITY

Engine Crankcase	4 pts.
Fuel Tank	6 qts. "regular" gas
Transmission	1-1/2 qts. 80EP Oil
Bevel Gear Housing	1 pt. 80EP Oil

Allis-Chalmers Manufacturing Company reserves the right to make changes in the above specifications or to add improvements at any time without notice or obligation.

SPECIFICATIONS
Model B-112 Wheel Tractor

ENGINE

Make Briggs & Stratton
Type 4 cycle - air cooled
Horse Power 12
Bore and Stroke 3-1/4 x 3-7/16
Displacement 30.16
R.P.M. 3600 RPM full throttle full load
Air Cleaner Oil Foam
Starter Electric
Governor Mechanical (flyweight)
Electrical System 12 volt-combination starter-generator
Ignition System Magneto

BATTERY

Make Allis-Chalmers-40 ampere hour-12 volt

TRANSMISSION

Sliding spur gear and spiral bevel gear. 21 speeds forward and 7 reverse with standard variable pitch sheave system.

DIFFERENTIAL

Planetary gear with controlled traction.

SPEEDS - Standard Drive

First	7 Speed Ranges	Min. 0.8 MPH	Max. 1.7 MPH
Second	7 Speed Ranges	2.0 MPH	4.0 MPH
Third	7 Speed Ranges	3.3 MPH	6.6 MPH
Reverse	7 Speed Ranges	1.7 MPH	3.4 MPH

DIMENSIONS

Height (At Steering Wheel) 37-3/4"
Height (At Hood Line) 33-1/4"
Width 36 "
Length 72"
Wheel Tread 27-1/2" rear, 30-1/4" front
Wheel Base 48"
Clearance (Front Axle) 9"
Clearance (Differential) 6"
Clearance (Drawbar) 7"
Clearance (Center Housing) 15-1/4"

SHIPPING WEIGHT - Approx. 745 lbs.

TIRE PRESSURE

	Standard Tractor	With Loader
Rear	8 PSI	12 PSI
Front	10 PSI	25 PSI

CAPACITY

Engine Crankcase 4 pts.
Fuel Tank 6 qts. "regular" gas
Transmission 1-1/2 qts. 80EP Oil
Bevel Gear Housing 1 pt. 80EP Oil

Allis-Chalmers Manufacturing Company reserves the right to add to or change these specifications at any time without notice.

SPECIFICATIONS
Model HB - 112 Wheel Tractor

ENGINE

Make Briggs & Stratton
Type 4 cycle - air cooled
Horse Power 12
Bore and Stroke 3-1/4 x 3-7/16
Displacement 30.16
R.P.M. 3600 RPM full throttle full load
Air Cleaner Oil Foam
Starter Electric
Governor Mechanical (flyweight)
Electrical System 12 volt-combination starter-generator
Ignition System Magneto

BATTERY

Make Allis-Chalmers-40 ampere hour-12 volt

TRANSMISSION

Hydrostatic drive with piston pump and piston motor.

DIFFERENTIAL

Planetary gear with controlled traction.

SPEEDS - Variable

Forward 0-7.2 MPH
Reverse 0-4.4 MPH

DIMENSIONS

Height (At Steering Wheel) 37-3/4"
Height (At Hood Line) 33-1/4"
Width 40"
Length 72"
Wheel Tread 29-1/2" rear, 30-1/4" front
Wheel Base 48"
Clearance (Front Axle) 9"
Clearance (Differential) 6"
Clearance (Drawbar) 7"
Clearance (Center Housing) 15-1/4"

SHIPPING WEIGHT - Approx. 745 lbs.

TIRE PRESSURE

	Standard Tractor	With Loader
Rear	8 PSI	12 PSI
Front	10 PSI	25 PSI

CAPACITY

Engine Crankcase 4 pts.
Hydrostatic Transmission 1 3/4 QTS. Dexron ATF
Transmission 1-1/2 qts. 80EP Oil
Final Drive Gearcase 1 1/2 QTS. 80 EP Oil

Allis-Chalmers Manufacturing Company reserves the right to add to or change these specifications at any time without notice.

SPECIFICATIONS

Model B-206 and B-206-E Wheel Tractor

ENGINE

Make Briggs & Stratton
Type 4 cycle - air cooled
Horse Power 6
Bore and Stroke 2 3/4 x 2 3/8
Displacement 14.11
R.P.M. 3600 RPM full throttle full load
Air Cleaner Oil Foam
Starter Recoil (12 volt elec. w/4 amp. alternator opt.)
Governor Mechanical (flyweight)
Electrical System (B-206-E) 12 volt-combination starter-generator
Ignition System Magneto

BATTERY

Make Allis-Chalmers-25 amp. Hour -12 volt
(Optional w/elec. start)

TRANSMISSION

Transaxle - 3 speeds Forward - 1 Reverse

DIFFERENTIAL

Bevel Gear, Internal to Transaxle

SPEEDS - Standard Drive

First 1.27 MPH
Second 2.48 MPH
Third 3.70 MPH
Reverse 1.72 MPH

DIMENSIONS

Height (At Steering Wheel) 34"
Height (At Hood Line) 28.75"
Width 25.5"
Length 53.25"
Wheel Tread 20.5"
Wheel Base 39.75"
Clearance (Front Axle) 8"
Clearance (Differential) 4.5"
Clearance (Drawbar) 8.5"
Clearance (Center Housing)

SHIPPING WEIGHT - B-206 335 lbs
 B-206-E 350 lbs

TIRE PRESSURE

Standard Tractor

Rear 12 PSI
Front Semi-pneumatic/No pressure

CAPACITY

Engine Crankcase 2 1/4 pts.
Fuel Tank 2 qts.
Transmission 1 1/2 pts. SAE 90

Allis-Chalmers Manufacturing Company reserves the right to add to or change these specifications at any time without notice.

SPECIFICATIONS

Model B-207 and B-207-E Wheel Tractor

ENGINE

Make Briggs & Stratton
Type 4 cycle - air cooled
Horse Power 7
Bore and Stroke 3" x 2 3/8
Displacement 16.79
R.P.M. 3600 RPM full throttle full load
Air Cleaner Oil Foam
Starter B-207 (Recoil) B-207-E (Electric)
Governor Mechanical (flyweight)
Electrical System (B-207-E) 12 volt-combination starter-generator
Ignition System Magneto

BATTERY

Make (B-207-E) Allis-Chalmers-40 ampere hour-12 volt

TRANSMISSION

Transaxle with 3 Speeds Forward and 1 Reverse

DIFFERENTIAL

Bevel Gear Internal to Transaxle

SPEEDS - Standard Drive

First 2.1 MPH
Second 3.8 MPH
Third 5.6 MPH
Reverse 2.9 MPH

DIMENSIONS

Height (At Steering Wheel) 35"
Height (At Hood Line) 29 1/2"
Width 31 1/2"
Length 58"
Wheel Tread 23 1/4"
Wheel Base 41"
Clearance (Front Axle) 8 5/8"
Clearance (Differential) 5"
Clearance (Drawbar) 6 3/4"

SHIPPING WEIGHT - B-207 w/mower 515 lbs
B-207-E w/mower 530 lbs

TIRE PRESSURE

Standard Tractor

Rear 7 to 9 PSI
Front 9 PSI

CAPACITY

Engine Crankcase 2 1/4 pts.
Fuel Tank 7/8 gallon
Transmission 90 SAE (Fill to Oil Level Check Plug)

Allis-Chalmers Manufacturing Company reserves the right to add to or change these specifications at any time without notice.

SPECIFICATIONS
Model B-208 and B-208-S Wheel Tractor

ENGINE

Make Briggs & Stratton
Type 4 cycle - air cooled
Horse Power 8
Bore and Stroke 3" x 2 3/4"
Displacement 19.4
R.P.M. 3600 RPM full throttle full load
Air Cleaner Oil Foam
Starter Electric
Governor Mechanical (flyweight)
Electrical System 12 volt-combination starter-generator
Ignition System Magneto

BATTERY

Make Allis-Chalmers-40 ampere hour-12 volt

TRANSMISSION

Transaxle with 3 Speeds Forward and 1 Reverse

DIFFERENTIAL

Bevel Gear Internal to Transaxle

SPEEDS - Standard Drive

First 2.1 MPH
Second 3.8 MPH
Third 5.6 MPH
Reverse 2.9 MPH

DIMENSIONS

	B-208	B-208-S
Height (At Steering Wheel)	35"	35 1/2"
Height (At Hood Line)	29 1/2"	30"
Width	31 1/2"	32 1/2"
Length	58"	58"
Wheel Tread	23 1/4"	23 1/4"
Wheel Base	41"	41"
Clearance (Front Axle)	8 5/8"	9 1/2"
Clearance (Differential)	5"	5 1/2"
Clearance (Drawbar)	6 3/4"	7 1/4"

SHIPPING WEIGHT - Approx. 530 lbs 540 lbs

TIRE PRESSURE

	Standard Tractor	With Loader
Rear	7 to 9 PSI	12 PSI
Front	9 PSI	25 PSI

CAPACITY

Engine Crankcase 2 1/4 pts.
Fuel Tank 7/8 gallon
Transmission 90 SAE (Fill to Oil Level Check Plug)

Allis-Chalmers Manufacturing Company reserves the right to add to or change these specifications at any time without notice.

Model B-210, B-212, and HB-212 Wheel Tractor

Make	Briggs & Stratton
Type	4 cycle - air cooled
Horse Power	B-210 (10 HP) B-212 and HB-212 (12HP)
Bore and Stroke	B-210 (3 1/16" x 3 1/4") B-212 and HB-212 (3 1/4" x 3 7/16")
Displacement	B-210 (23.94) B-212 and HB-212 (30.16)
R.P.M.	3600 RPM full throttle full load
Air Cleaner	Oil Foam
Starter	B-210 (Electric and Manual) B-212 and HB-212 Electric
Governor	Mechanical (flyweight)
Electrical System	12 volt-combination starter-generator
Ignition System	Magneto

Make Allis-Chalmers-40 ampere hour-12 volt

Sliding spur gear and spiral bevel gear. 21 speeds forward and 7 reverse with standard variable pitch sheave system.

Hydrostatic drive with piston pump and piston motor.

Planetary gear with controlled traction.

First	7 Speed Ranges	Min. 0.8 MPH	Max. 1.7 MPH
Second	7 Speed Ranges	2.0 MPH	4.0 MPH
Third	7 Speed Ranges	3.3 MPH	6.6 MPH
Reverse	7 Speed Ranges	1.7 MPH	3.4 MPH

Forward 0-7.2 MPH
Reverse 0-4.4 MPH

Height (At Steering Wheel)		.37-3/4"
Height (At Hood Line)		.33-1/4"
Width.		34"
Length		.72"
Wheel Tread	25 1/2" rear, 30-1/4" front	
Wheel Base		.43"
Clearance (Front Axle).		. 9"
Clearance (Differential)		5 1/2"
Clearance (Drawbar).		7 1/4"

SHIPPING WEIGHT - Approx. 745 lbs.

	Standard Tractor	With Loader
Rear	8 PSI	12 PSI
Front.	10 PSI	25 PSI

Engine Crankcase	4 pts.
Fuel Tank.	6 qts. "regular" gas
Transmission	1-1/2 qts. 80EP Oil
Bevel Gear Housing	1 pt. 80EP Oil

Allis-Chalmers Manufacturing Company reserves the right to add to or change these specifications at any time without notice.

INDEX

ENGINE

ENGINE, OPERATING AND
MAINTENANCE INSTRUCTIONS B-1

ENGINE, DRIVE SHAFT AND
COUPLING REMOVAL

B-1 B-21
B-10 PRIOR TO S/N 50001 B-22
B-10 Eff. W/S/N 50001 and Up B-23
Big TEN, B-12, B-110, B-112, HB-112 B-23
B-210, B-212, HB-212 B-23

STORING YOUR TRACTOR B-24
DIAGNOSING ENGINE DIFFICULTY..... B-25



THIS PAGE INTENTIONALLY BLANK

ENGINE OPERATING AND MAINTENANCE INSTRUCTIONS

TRACTOR MODEL	ENGINE MODEL	ENGINE H.P.	PAGE
B-1	19D	7-1/4	B-6
B-10	243431	10	B-11
Big Ten	242431	10	B-11
B-12	300401	12	B-16
B-110	243431	10	B-11
B-112	300401	12	B-16
HB-112	300401	12	B-16
B-206	146700	6	B-1
B-207	170700	7	B-1
B-210	243431	10	B-11
B-212	300401	12	B-16
HB-212	300401	12	B-16

NOTE: This chart is a listing of Tractors and Engines by model number. Refer to page number in right column for instructions.

MODELS 146700 and 170700

Section 1

BEFORE STARTING

- 1 **FILL SUMP WITH OIL** — Use a high quality detergent oil classified "For Service SC or SD or MS". Nothing should be added to the recommended oil.


Summer — (Over 40° F) Use SAE 30 Oil

Winter — (Under 40° F) Use SAE 5W-20
If not available use SAE 10W
(Below 0° F) Use SAE 10W
diluted with 10% kerosene

DIRECTIONS: Place the engine level. FILL THE OIL SUMP TO OVERFLOWING. Pour slowly. Capacity 2¼ pints.

- 2 **FILL FUEL TANK** — Use clean, fresh, leaded or non-leaded "REGULAR" grade automotive gasoline. Fill tank completely!

DO NOT MIX OIL WITH GASOLINE.




Section 2

STARTING


1 BE SURE THE STOP SWITCH IS AWAY FROM SPARK PLUG

CAUTION: ALWAYS KEEP HANDS AND FEET CLEAR OF MOWER BLADE OR OTHER ROTATING MACHINERY.



Move Stop Switch away from Spark Plug

2 OPEN FUEL VALVE



Opening Fuel Valve

3 CHOKE THE CARBURETOR

a. Manual Type


Move lever in direction of arrow to fully closed choke position. Set governor control in normal operating position.

b. Choke-A-Matic

Move lever to "Full Choke" or "Start" position.

Note: This should fully close choke on carburetor. If it does not, remote control must be re-adjusted. See "Choke-A-Matic Carburetor" Adjustments, Section 4.

Note: A warm engine requires less choking than a cold engine.




a. Manual Type

b. Choke-A-Matic

4 START ENGINE

a. Rewind Starter Grasp starter grip as illustrated and pull out cord rapidly. Repeat if necessary with choke opened slightly. When engine starts open choke gradually.

b. Rope Starter Wind the starter rope around the pulley in direction shown by arrow. Pull the rope with a quick full arm stroke. Repeat if necessary with choke opened slightly. When engine starts open choke gradually.




a. Rewind Starter

b. Rope Starter

c. Electric Starter Press starter button on powered equipment. When engine starts open choke gradually.

CAUTION: The 110 volt electric starter is equipped with a three-prong plug for your safety. If a longer cord is used it should also have three-prong and three-hole plugs. If the outlet or receptacle is the two-hole type, an adapter must be used. To get proper grounding, fasten the ground lead on the adapter to something electrically grounded, such as the metal box on the end of a grounded metal conduit.



Proper Grounding

Section 2


STARTING (cont'd)

SPECIAL LOW TEMPERATURE STARTING PROCEDURE

1. Turn needle valve on carburetor, 1/8 turn counterclockwise from normal summer adjustment. **Note:** If fuel drips out of carburetor while trying to start engine, the engine is over choked. Pull starter several times or push starter button with choke open. 2. Be sure to use the proper weight of oil for the air temperature expected. 3. Disconnect all external loads. Any V-belt drives must be removed or loosened so that the belts are standing still for satisfactory operation below freezing. Starter, motor and battery are designed to start the engine only. 4. Keep battery and engine warm if possible. If it is not possible to keep the entire unit warm, there is a big advantage in keeping the battery warm until it is required for starting. A warm battery has much more starting capacity than a cold battery.

5 STOP ENGINE

- Manual Choke** Push the stop switch against end of spark plug.
- Choke-A-Matic** Move control lever to "stop" position.



Section 3

MAINTENANCE



- CHECK OIL LEVEL** before starting engine and after every 5 hours of operation. (Take care to remove dirt around filler plug.) Be sure oil level is maintained FULL TO POINT OF OVERFLOWING.

- CHANGE OIL** after first 5 hours of operation. Thereafter change oil every 25 hours of operation. Remove oil drain plug and drain oil while engine is warm. Replace oil drain plug. Remove oil minder or oil filler plug and refill with new oil of proper grade. Replace oil filler plug.

- CLEAN AIR CLEANER** and re-oil element every 25 hours under normal conditions.

- Remove two screws and lift off complete air cleaner assembly.
- Remove screen and spacers from foam element.
- Remove foam element from air cleaner body.
- A - Wash foam element in kerosene or liquid detergent and water to remove dirt.
B - Wrap foam in cloth and squeeze dry.
C - Saturate foam in engine oil. Squeeze to remove.
D - Assemble parts - fasten to carburetor with screw.


When assembling make certain the lip of the foam element extends over edge of the air cleaner body. The foam element lip will form a protective seal.




Section 3

MAINTENANCE (cont'd)

- ④ **CLEAN COOLING SYSTEM** — Grass, chaff or dirt may clog the air cooling system, especially after prolonged service cutting dry grasses. To avoid overheating and engine damage, remove the blower housing and clean the area shown. This should be a regular maintenance operation.



- ⑤ **CLEAN SPARK PLUG** — Clean and reset gap at .030" every 100 hours of operation. **Caution:** Blast cleaning of spark plugs in machines that use abrasive grit is not recommended. Spark plugs should be cleaned by scraping or wire brushing and washing with a commercial solvent or gasoline.



- ⑥ **CLEAN FUEL SYSTEM** — Drain and clean fuel tank. Unscrew fuel outlet from tank and clean filter.

Section 4


ADJUSTMENTS

CARBURETOR ADJUSTMENTS

Minor carburetor adjustment may be required to compensate for differences in fuel, temperature, altitude and load.

To Adjust Carburetor Turn needle valve clockwise until it just closes. **Caution:** Valve may be damaged by turning it in too far.

Now open needle valve 1-1/8 turns counterclockwise. Close idle valve in same manner and open 1-1/8 turns. This initial adjustment will permit the engine to be started and warmed up prior to final adjustment.



Final Adjustment Turn needle valve in until engine misses (lean mixture). Then turn it out past smooth operating point until engine runs unevenly (rich mixture). Now turn needle valve to the mid-point between rich and lean so the engine runs smoothly. Hold throttle at idle position and set idle speed adjusting screw until fast idle is obtained (1750 RPM). Hold throttle in idle position and turn idle valve in (lean) and out (rich) until engine idles smoothly. Then reset idle speed adjusting screw so that engine idles at 1750 RPM. Release throttle — engine should accelerate without hesitation or sputtering. If engine does not accelerate properly, the carburetor should be re-adjusted to a slightly richer mixture.

Section 4

ADJUSTMENTS (cont'd)

CHOKE-A-MATIC CARBURETOR CONTROLS ADJUSTMENT

Proper choke and stop switch operation is dependent upon proper adjustment of remote controls on the powered equipment.

To Check Operation of Choke-A-Matic Controls:



- Move remote control lever to "Choke" position. The carburetor choke should be closed.
- Move remote control to "Stop" position. Governor control lever should make full contact with stop switch.

To Adjust:

Place remote control lever on equipment in FAST (high speed) position. Loosen control casing clamp screw "C". Move control casing "A" and wire until lever "E" lines up with bottom edge of tang "F". Tighten casing clamp screw "C".

SPEED CONTROL ADJUSTMENTS

The correct operating speed range is 1800 to 3600 RPM. Idle speed is 1750 RPM. There are several types of speed controls on these engines. Select the control on your engine. To increase engine speed move control in direction of arrow.



Section 5

GENERAL INFORMATION

These engines are single cylinder, L-head, air-cooled type

MODEL SERIES

146700 to 146707

Bore	2 3/4"
Stroke	2 3/8"
Displacement	14.11 cu. in.
Horsepower	6.0 H.P. max. @ 3600 RPM
Torque (Ft. Lbs.)	9.25 max. @ 2900 RPM

170700 to 170707

Bore	3"
Stroke	2 3/8"
Displacement	16.79 cu. in.
Horsepower	7.0 H.P. max. @ 3600 RPM
Torque (Ft. Lbs.)	11.0 max. @ 2600 RPM

The horsepower ratings listed above are established in accordance with the Society of Automotive Engineers Test Code J607. For practical operation, the horsepower loading should not exceed 85% of these ratings. Engine power will decrease 3 1/2% for each 1,000 feet above sea level and 1% for each 10° above 60° F.

TUNE-UP SPECIFICATIONS

	A.C.	Autolite	Champion
Spark Plug Type			
Short Plug	CS-45	A7N	CJ-8
Long Plug	GC-46	A71	J-8
Spark Plug Gap..	.030"		
Ignition Point Gap	.020"		
Intake Valve Clearance	.005"-.007"		
Exhaust Valve Clearance	.009"-.011"		

STORAGE INSTRUCTIONS

Engines to be stored over 30 days should be completely drained of fuel to prevent gum deposits forming on essential carburetor parts, fuel filter, fuel lines and tank.

- Drain fuel tank completely and clean fuel filter.
- Operate engine until gasoline in carburetor is completely consumed.
- While engine is still warm, drain oil from crankcase. Refill with fresh oil.
- Remove spark plug, pour 1 ounce (2 or 3 table-spoons) of SAE-30 oil into cylinder and crank slowly to distribute oil. Replace spark plug.
- Clean dirt and chaff from cylinder head fins and blower housing. (See Section 3).

Briggs & Stratton OPERATING AND MAINTENANCE INSTRUCTIONS

MODELS


19D, 19D-FB,
19D-R6

IMPORTANT: Do not start this engine before reading Section I and Section II of this manual.

CAUTION

PROVIDE EFFICIENT VENTILATION. Exhaust gases contain carbon monoxide, an odorless and deadly poison. Do not operate engine in an enclosed area.

KEEP ENGINE CLEAN. This engine is air-cooled. If cooling system becomes clogged, serious damage may result. Therefore, keep the blower screen, fins on flywheel, cylinder head and block free from grass or dirt.



SECTION I

BEFORE STARTING

"OIL-FOAM"® AIR CLEANER

"Oil-Foam"® air cleaners are oiled at the factory and do not require initial service.

FILL FUEL TANK

Use clean, fresh "regular" grade gasoline. Fill tank completely.

DO NOT FILL GASOLINE TANK WHILE ENGINE IS RUNNING. Avoid spilling gasoline on a hot engine - this may cause an explosion and serious injury.


DO NOT MIX OIL WITH GASOLINE

OIL RECOMMENDATIONS

WINTER	SUMMER
(Below 40° F.)	(Above 40° F.)
Use SAE 5W-20	Use SAE 30
If not Available	If not Available
Use SAE 10W	Use SAE 10W-30
Above 10° F.	

Nothing should be added to the recommended oils.

FILL CRANKCASE WITH OIL




Remove the oil filler plug. Place the engine level. Fill the crankcase to overflowing. **POUR SLOWLY.** CAPACITY 3 PINTS. Replace the filler plug.

Any high quality detergent oil having the American Petroleum Institute classification "For Service MS" can be used in your Briggs & Stratton engine. Detergent oils keep the engine cleaner and retard the formation of gum and varnish deposits.


SECTION II STARTING

TO START ENGINE

1. Open Fuel Valve




2. Close the Choke



3. Start Engine

a. Rope Starter




Place knot in pulley notch and wind rope around pulley in a clockwise direction. Pull rope with choke closed to prime the engine. Open choke slightly and repeat operation.

After engine warms up open choke gradually until engine runs smoothly with choke wide open (counter-clockwise position).

b. 12 Volt D.C. Electric Starter


Press starter button on powered equipment. When engine starts, open choke gradually.



STOPPING

To Stop Engine


Push the stop switch against end of spark plug.



SECTION III REGULAR MAINTENANCE


CHANGE OIL (Crankcase)

Change oil after 5 hours of operation. Remove the oil drain plug. Drain oil while engine is warm. Replace drain plug. Remove oil filler cap or plug and refill with new oil. Replace oil filler cap or plug. Add oil regularly after each 5 hours of operation. Thereafter change oil every 25 hours of operation.




CHANGE OIL (Gear Reduction)

The reduction gears are lubricated by engine crankcase oil. Remove drain plug from gear case cover to drain oil remaining in gear case when crankcase oil is changed.



TO CHECK SPARK PLUG GAP


Clean spark plug and reset gap at .025" every 100 hours of operation. When worn out replace with AC GC 46, Autolite A71 or Champion J-8. Size 14 mm.



SECTION III REGULAR MAINTENANCE (Cont'd.)

SERVICING "OIL-FOAM"® AIR CLEANER

Clean and re-oil the air cleaner frequently (every few hours under extremely dusty conditions). Clean and re-oil at least every 25 hours under normal conditions.




DRAINING FUEL TANK AND CLEANING FUEL FILTER

Loosen thumb screw below filter bowl.

Remove and clean filter bowl and screen.

Open shut-off valve to see if fuel flows freely from the tank. **IMPORTANT:** If you find a gummy, varnish-like substance use alcohol or acetone to dissolve it.




CLEAN COOLING SYSTEM

Grass or chaff may clog cooling system after prolonged service in cutting tall dry grasses or hay. Continued operation with a clogged cooling system causes severe overheating and possible engine dam-

age. Remove blower housing and clean regularly.

TO CLEAN AND ADJUST CONTACT POINTS



Remove cover.

Clean points with a carborundum contact point stone. Then insert a hard finished card or piece of paper and close and open points. The paper will absorb any dirt or filings on the points. Adjust breaker points as follows:

- Rotate crankshaft until points open to widest gap.
- Loosen lock nut illustrated above until it is just snug.

c. Rotate breaker point screw to obtain .020" gap.


d. When gap is .020" tighten lock-nut.

e. Replace breaker box cover.

CLEAN COMBUSTION CHAMBER EVERY 100-300 HOURS OF OPERATION

This industrial engine generally operates at constant speed and at relatively constant load. The use of regular automotive fuels under these conditions results in a gradual build-up of tetra-ethyl lead deposits in the combustion chamber.

This causes the engine to lose power and prevents the valves from seating properly. Removing the deposits is easy and will pay big dividends in reliability and increased valve life.



1. Remove cylinder head screws. Be sure to note if screws are of different length and have steel washers as they must be replaced in original position.

2. Turn crankshaft until piston is at top of cylinder bore and both valves are closed. Scrape and wire brush the lead and carbon deposits from cylinder head and combustion chamber.

3. Re-use cylinder head gasket only if in good condition. Replace cylinder head. Turn each screw in with wrench until screw head is lightly seated.

4. Use socket wrench with 6 inch handle and turn all screws 1/4 turn. Tighten screws in sequence illustrated. Run engine approximately 5 minutes and re-tighten all screws approximately 1/4 turn.

SECTION IV ADJUSTMENTS


CARBURETOR ADJUSTMENTS

Initial Adjustment

Turn needle valve clockwise until it just closes: **CAUTION:** Valve may be damaged by turning it in too far.

Now open needle valve 1-1/2 turns counterclockwise.

Close idle valve in same manner and open it 1/2 to 3/4 turns. This initial adjustment will permit the engine to be started and warmed up prior to final adjustment.



Final Adjustment

Turn needle valve in until engine misses (lean mixture), then turn it out past smooth operating point until engine runs unevenly (rich mixture). Now turn needle valve to the mid-point between rich and lean so the engine runs smoothly.

Hold throttle at idle position, set idle speed adjusting screw until fast idle is obtained (1200 RPM). Hold throttle in idle position and turn idle valve in (lean) and out (rich) until engine idles smoothly. Then reset idle speed so that engine idles at 1200 RPM. Release throttle—engine should accelerate without hesitation or sputtering. If engine does not accelerate properly, re-adjust carburetor to a slightly richer mixture.

GOVERNOR ADJUSTMENTS

The correct operating speed range is 1800 to 3600 RPM. The standard speed setting (no load) is 2900 RPM. Idle speed is 1200 RPM.


Thumb Nut Adjustment

To increase speed, turn nut (clockwise) or move lower end of governor spring farther away from governor lever shaft.


To reduce speed, turn nut counterclockwise) or move lower end of spring closer to governor lever shaft.

If the speed of the engine is not steady although the carburetor has been properly adjusted, move the spring farther away from the governor lever shaft.

If the speed variation between no load and full load is too great, move spring closer to governor lever shaft.



REMOTE GOVERNOR CONTROL



Engine speed is controlled by movement of the control lever. To adjust: Move control lever to HIGH speed position. Loosen screw on swivel. Move wire through swivel until desired operating speed is obtained. Retighten swivel screw, bend loose end of wire around swivel. Cut off excess wire. Be sure to remove or loosen thumb screw on governor control rod.

SECTION V GENERAL INFORMATION

These engines are single cylinder, L-Head, air-cooled type

Bore – 3"; Stroke – 2 5/8"; Displacement – 18.56 cu. in.; Horsepower: –

3.65 h.p. at 1800 r.p.m.	5.45 h.p. at 2400 r.p.m.
6.70 h.p. at 3000 r.p.m.	7.25 h.p. at 3600 r.p.m.

Torque (Ft.-Lbs.)	11.95 at 2400 RPM
Intake Valve Clearance	.007" - .009"
Exhaust Valve Clearance	.017" - .019"

The horsepower ratings listed above are established by standard I.C.E.I. procedures. For practical operation, the horsepower loading should not exceed 85% of these ratings. Engine power will decrease 3½% for each 1,000 ft. above sea level and 1% for each 10 degrees above 60 degrees F.

Major engine repairs should not be attempted unless you have the proper tools and a thorough knowledge of internal combustion engines.

STORAGE INSTRUCTIONS

Engines stored for over 30 days should be completely drained of fuel to prevent gum deposits forming on essential carburetor parts, fuel filter, fuel lines and tank.

- a. Remove filter bowl, open shut-off valve and drain tank completely.
- b. Replace filter bowl. Leave fuel valve open.
- c. Operate engine until it stops from lack of fuel.
- d. While engine is still warm, drain and clean the oil sump. Refill with fresh oil.
- e. Remove spark plug, pour one ounce of SAE 30 oil into cylinder and crank slowly to spread oil. Replace spark plug.
- f. Clean dirt and chaff from cylinder, cylinder head fins and blower housing.

MODEL 243431

Section 1

BEFORE STARTING

READ THE OPERATING INSTRUCTIONS OF
THE EQUIPMENT THIS ENGINE POWERS

- ① **FILL CRANKCASE WITH OIL** — Use a high quality detergent oil classified "For Service SC or SD or MS". Nothing should be added to the recommended oil.

SUMMER
(Above 40° F.)
Use SAE 30

If not available,
Use SAE 10W-30

or
SAE 10W-40

WINTER
(Under 40° F.)
Use SAE 5W-20 or SAE 5W-30

If not available,
Use SAE 10W or SAE 10W-30


Below 0° F.,
Use SAE 10W or SAE 10W-30
Diluted 10% with Kerosene

DIRECTIONS: Place the engine level. Remove oil filler plug or Oil-Minder. FILL THE OIL SUMP TO OVERFLOWING or to the FULL mark on dipstick. Pour slowly. Capacity 4 pints.

EXTENDED OIL FILL. (Optional) Remove cap and dipstick. When checking oil level push dipstick assembly firmly but slowly until cap bottoms on tube. Do not overfill. Dipstick assembly must be pushed fully into tube at all times when engine is operating.


- ② **FILL FUEL TANK** — Use clean, fresh, lead-free or leaded "regular" grade automotive gasoline. Fill tank completely!

DO NOT MIX OIL WITH GASOLINE.




1 OPEN FUEL VALVE

CAUTION: ALWAYS KEEP HANDS AND FEET CLEAR OF MOWER BLADE OR OTHER ROTATING MACHINERY.



2 CLOSE THE CHOKE — Engine may be equipped with manual or remote choke.




3 START ENGINE — Engine may be equipped with rope or electric starter.

a. Rope Starter


Place knot in pulley notch and wind rope around pulley in a clockwise direction. Pull rope with choke closed to prime the engine. Open choke slightly and repeat operation.

After engine warms up open choke gradually until engine runs smoothly with choke wide open (counter-clockwise position).




b. 12 Volt D.C. Electric Starter

Press starter button on powered equipment. When engine starts, open choke gradually.



4 TO STOP ENGINE

Push the stop switch against end of spark plug, or turn off ignition switch on equipment.



Section 3


MAINTENANCE

1 CHECK OIL LEVEL

Check before starting and after every 5 hours of operation. BE SURE OIL LEVEL IS MAINTAINED.

2 CHANGE OIL (Crankcase)

Change oil after first 5 hours of operation. Thereafter change oil every 25 hours of operation. Remove the oil drain plug. Drain oil while engine is warm. Remove oil filler cap or plug and refill with new oil. Replace oil filler cap or plug. Add oil regularly after each 5 hours of operation.




3 SERVICING HEAVY DUTY AIR CLEANER

Clean and re-oil foam pre-cleaner at 3 month intervals or every 25 hours, whichever occurs first.

1. Remove wing nut and cover.
2. Remove foam pre-cleaner element by sliding it up off of the paper cartridge.
3. A – Wash foam in liquid detergent and water.
B – Squeeze dry.
C – Oil with one ounce engine oil. Squeeze to distribute oil evenly.
4. Assemble to paper cartridge. Reassemble cover and wing nut. Screw wing nut down tight.

Yearly or every 100 hours, whichever occurs first, remove paper cartridge. Clean by tapping gently on flat surface. If very dirty, replace cartridge, or wash in liquid detergent and water. Rinse until water remains clear. Cartridge must be air dried thoroughly before using.

NOTE: Service more often under dusty conditions.





4 CLEAN COOLING SYSTEM

Grass or chaff may clog cooling system after prolonged service in cutting dry grasses or hay. Continued operation with a clogged cooling system causes severe overheating and possible engine damage. Remove blower housing and clean regularly.

5 CLEAN COMBUSTION CHAMBER every 100-300 hours of operation. If the engine operates at constant speed and at relatively constant load, the use of regular automotive fuels results in a gradual build-up of lead deposits in the combustion chamber.

This causes the engine to lose power and prevents the valves from seating properly. Removing the deposits is easy and will pay big dividends in reliability and increased valve life.

1. Remove cylinder head screws.
2. Turn crankshaft until piston is at top of cylinder bore and both valves are closed. Scrape and wire brush the lead and carbon deposits from cylinder head and combustion chamber.
3. Re-use cylinder head gasket only if in good condition. Replace cylinder head. Turn each screw in with wrench until screw head is lightly seated.
4. Use socket wrench with 6 inch handle and turn all screws 1/4 turn. Tighten screws in sequence illustrated. Run engine approximately 5 minutes and retighten all screws approximately 1/4 turn.




Section 3

MAINTENANCE (cont'd)

6 CLEAN AND ADJUST CONTACT POINTS

Remove cover. Clean points with a carborundum contact point stone. Then insert a hard finished card or piece of paper and close and open points. The paper will absorb any dirt or filings on the points. Adjust breaker points as follows:

- Rotate crankshaft until points open to widest gap.
- Loosen lock nut illustrated below until it is just snug.
- Rotate breaker point screw to obtain .020" gap.
- When gap is .020" tighten locknut.
- Replace breaker box cover.




7 CLEAN SPARK PLUG – Clean and reset gap at .030" every 100 hours of operation.

CAUTION: First cleaning of spark plugs in machines that use abrasive grit is not recommended. Spark plugs should be cleaned by scraping or wire brushing and washing with a commercial solvent or gasoline.

8 DRAIN FUEL TANK AND CLEAN FUEL FILTER

Loosen thumb screw below filter bowl. Remove and clean filter bowl and screen. Open shut-off valve to see if fuel flows freely from the tank. **IMPORTANT:** If you find a gummy, varnish-like substance use alcohol or acetone to dissolve it.



Section 4

ADJUSTMENTS


CARBURETOR ADJUSTMENTS

Minor carburetor adjustment may be required to compensate for differences in fuel, temperature, altitude and load.

Initial Adjustment

Turn needle valve clockwise until it just closes. – **CAUTION:** Valve may be damaged by turning it in too far.

Now open needle valve 1-1/2 turns counterclockwise. Close idle valve in same manner and open it 1/2 to 3/4 turns. This initial adjustment will permit the engine to be started and warmed up prior to final adjustment.



Final Adjustment Turn needle valve in until engine misses (lean mixture), then turn it out past smooth operating point until engine runs unevenly (rich mixture). Now turn needle valve to the mid-point between rich and lean so the engine runs smoothly. Hold throttle at idle position, set idle speed adjusting screw until fast idle is obtained (1200 RPM). Hold throttle in idle position and turn idle valve in (lean) and out (rich) until engine idles smoothly. Then reset idle speed so that engine idles at 1200 RPM. Release throttle – engine should accelerate without hesitation or sputtering. If engine does not accelerate properly, re-adjust needle valve to a slightly richer mixture.

Section 4

ADJUSTMENTS

(cont'd)

GOVERNOR SPEED ADJUSTMENTS

The governor controls the engine speed from idle through the full operating range. Idle speed should be no lower than 1000 RPM and top no load speed should be no higher than 3800 RPM. See illustration to adjust governor.



Governed Idle Speed Adjustment

The shorter spring keeps the engine on governor, even at idle speed. If moderate loads are applied at idle, the engine will not stall.

First make final carburetor mixture adjustments. Then place remote control in idle position. Hold throttle shaft in closed position and adjust idle speed screw to 1000 RPM. Release the throttle. With remote control in idle position, adjust upper elastic stop nut to 1200 RPM.

REMOTE SPEED CONTROL ADJUSTMENT

Engine speed is controlled by movement of the control lever. To adjust: Move control lever to HIGH speed position. Loosen screw on swivel. Move wire through swivel until desired operating speed is obtained. Retighten swivel screw, bend loose end of wire around swivel. Cut off excess wire.



Section 5

GENERAL INFORMATION

These engines are single cylinder, L-head, air-cooled type

Model Series 243431 to 243434

Bore 3 1/16"
Stroke 3 1/4"
Displacement 23.94 cu. in.
Horsepower 10.0 max. @ 3600 RPM
Torque (Ft. Lbs.) 16.75 max. @ 2400 RPM

The horsepower ratings listed above are established in accordance with the Society of Automotive Engineers Test Code-J607. For practical operation, the horsepower loading should not exceed 85% of these ratings. Engine power will decrease 3 1/2% for each 1000 feet above sea level and 1% for each 10° above 60° F.

TUNE-UP SPECIFICATIONS

Spark Plug Type	A.C.	Autolite	Champion
Short Plug	CS-45	A7N	CJ-8
Long Plug	GC-46	A71	J-8
Spark Plug Gap	.030"		
Ignition Point Gap	.020"		
Intake Valve Clearance	.007"-.009"		
Exhaust Valve Clearance	.017"-.019"		

STORAGE INSTRUCTIONS

Engines stored for over 30 days should be completely drained of fuel to prevent gum deposits forming on essential carburetor parts, fuel filter, fuel lines and tank.

- Remove filter bowl, open shut-off valve and drain tank completely.
- Replace filter bowl. Leave fuel valve open.
- Operate engine until it stops from lack of fuel.
- While engine is still warm, drain and clean the oil sump. Refill with fresh oil.
- Remove spark plug, pour one ounce of SAE 30 oil into cylinder and crank slowly to spread oil. Replace spark plug.
- Clean dirt and chaff from cylinder, cylinder head fins and blower housing.

Major engine repairs should not be attempted unless you have the proper tools and a thorough knowledge of internal combustion engines.

MODEL 300401

Section 1

BEFORE STARTING

READ THE OPERATING INSTRUCTIONS OF
THE EQUIPMENT THIS ENGINE POWERS

- ① **FILL CRANKCASE WITH OIL** — Use a high quality detergent oil classified "For Service MS". Nothing should be added to the recommended oil.

Summer — (Over 40° F) Use SAE 30 Oil


Winter — (Under 40° F) Use SAE 5W-20
If not available use SAE 10W
(Below 0° F) Use SAE 10W
diluted with 10% kerosene

DIRECTIONS: Place the engine level. Remove oil filler plug or Oil Minder. FILL THE OIL SUMP TO OVERFLOWING or to the FULL mark on dipstick. Pour slowly. Capacity 4 pints.

EXTENDED OIL FILL. (Optional). Remove cap and dipstick. When checking oil level push dipstick assembly firmly but slowly until cap bottoms on tube. Do not overfill. Dipstick assembly must be pushed fully into tube at all times when engine is operating.


- ② **FILL FUEL TANK** — Use clean, fresh, leaded or non-leaded "REGULAR" grade automotive gasoline. Fill tank completely!

DO NOT MIX OIL WITH GASOLINE.




1 OPEN FUEL VALVE

CAUTION: ALWAYS KEEP HANDS AND FEET CLEAR OF MOWER BLADE OR OTHER ROTATING MACHINERY.



2 CLOSE THE CHOKE — Engine may be equipped with manual or remote choke.




3 START ENGINE — Engine may be equipped with rope or electric starter.

a. Rope Starter


Place knot in pulley notch and wind rope around pulley in a clockwise direction. Pull rope with choke closed to prime the engine. Open choke slightly and repeat operation.

After engine warms up open choke gradually until engine runs smoothly with choke wide open (counter-clockwise position).




b. 12 Volt D.C. Electric Starter

Press starter button on powered equipment. When engine starts, open choke gradually.



4 TO STOP ENGINE

Push the stop switch against end of spark plug, or turn off ignition switch on equipment.



Section 3


MAINTENANCE

1 CHECK OIL LEVEL

Check before starting and after every 5 hours of operation. BE SURE OIL LEVEL IS MAINTAINED.

2 CHANGE OIL (Crankcase)

Change oil after first 5 hours of operation. Thereafter change oil every 25 hours of operation. Remove the oil drain plug. Drain oil while engine is warm. Remove oil filler cap or plug and refill with new oil. Replace oil filler cap or plug. Add oil regularly after each 5 hours of operation.




Change Oil

3 SERVICING "OIL-FOAM"® AIR CLEANER

Clean and re-oil the air cleaner frequently (every few hours under extremely dusty conditions): Clean and re-oil at least every 25 hours under normal conditions.

1. Remove wing nut and cover.
2. Lift off foam element from base.
3. Push down foam element as shown, and pull out air cleaner cup.
4. A—Wash foam element in kerosene or liquid detergent and water to remove dirt.
B—Wrap foam in cloth and squeeze dry.
C—Saturate foam in engine oil. Squeeze to remove excess oil.
D—Put air cleaner cup inside element. Be sure sealing lip is over end of cup (top and bottom).
5. Reassemble parts as shown. Screw wing nut down tight.



Clean Air Cleaner


4 CLEAN COOLING SYSTEM

Grass or chaff may clog cooling system after prolonged service in cutting dry grasses or hay. Continued operation with a clogged cooling system causes severe overheating and possible engine damage. Remove blower housing and clean regularly.


5 CLEAN COMBUSTION CHAMBER every 100-300 hours of operation. If the engine operates at constant speed and at relatively constant load, the use of regular automotive fuels results in a gradual build-up of lead deposits in the combustion chamber.

This causes the engine to lose power and prevents the valves from seating properly. Removing the deposits is easy and will pay big dividends in reliability and increased valve life.

1. Remove cylinder head screws.
2. Turn crankshaft until piston is at top of cylinder bore and both valves are closed. Scrape and wire brush the lead and carbon deposits from cylinder head and combustion chamber.
3. Re-use cylinder head gasket only if in good condition. Replace cylinder head. Turn each screw in with wrench until screw head is lightly seated.
4. Use socket wrench with 6 inch handle and turn all screws 1/4 turn. Tighten screws in sequence illustrated. Run engine approximately 5 minutes and re-tighten all screws approximately 1/4 turn.



Clean Cooling System



Tighten Head Screws


Section 3

MAINTENANCE (cont'd)

6 CLEAN AND ADJUST CONTACT POINTS

Remove cover. Clean points with a carborundum contact point stone. Then insert a hard finished card or piece of paper and close and open points. The paper will absorb any dirt or filings on the points. Adjust breaker points as follows:

- Rotate crankshaft until points open to widest gap.
- Loosen lock nut illustrated below until it is just snug.
- Rotate breaker point screw to obtain .020" gap.
- When gap is .020" tighten locknut.
- Replace breaker box cover.




7 CLEAN SPARK PLUG — Clean and reset gap at .030" every 100 hours of operation.

CAUTION: Blast cleaning of spark plugs in machines that use abrasive grit is not recommended. Spark plugs should be cleaned by scraping or wire brushing and washing with a commercial solvent or gasoline.

8 DRAIN FUEL TANK AND CLEAN FUEL FILTER

Loosen thumb screw below filter bowl. Remove and clean filter bowl and screen. Open shut-off valve to see if fuel flows freely from the tank. **IMPORTANT:** If you find a gummy, varnish-like substance use alcohol or acetone to dissolve it.



Section 4

ADJUSTMENTS


CARBURETOR ADJUSTMENTS

Minor carburetor adjustment may be required to compensate for differences in fuel, temperature, altitude and load.

Initial Adjustment

Turn needle valve clockwise until it just closes. — **CAUTION:** Valve may be damaged by turning it in too far.

Now open needle valve 1-1/2 turns counterclockwise. Close idle valve in same manner and open it 1/2 to 3/4 turns. This initial adjustment will permit the engine to be started and warmed up prior to final adjustment.



Final Adjustment Turn needle valve in until engine misses (lean mixture), then turn it out past smooth operating point until engine runs unevenly (rich mixture). Now turn needle valve to the mid-point between rich and lean so the engine runs smoothly. Hold throttle at idle position, set idle speed adjusting screw until fast idle is obtained (1200 RPM). Hold throttle in idle position and turn idle valve in (lean) and out (rich) until engine idles smoothly. Then reset idle speed so that engine idles at 1200 RPM. Release throttle — engine should accelerate without hesitation or sputtering. If engine does not accelerate properly, re-adjust needle valve to a slightly richer mixture.

Section 4

ADJUSTMENTS

(cont'd)

GOVERNOR SPEED ADJUSTMENTS

The governor controls the engine speed from idle through the full operating range. Idle speed should be no lower than 1000 RPM and top no load speed should be no higher than 3800 RPM. See illustration to adjust governor.



Governed Idle Speed Adjustment

The shorter spring keeps the engine on governor, even at idle speed. If moderate loads are applied at idle, the engine will not stall.

First make final carburetor mixture adjustments. Then place remote control in idle position. Hold throttle shaft in closed position and adjust idle speed screw to 1000 RPM. Release the throttle. With remote control in idle position, adjust upper elastic stop nut to 1200 RPM.

REMOTE SPEED CONTROL ADJUSTMENT

Engine speed is controlled by movement of the control lever. To adjust: Move control lever to HIGH speed position. Loosen screw on swivel. Move wire through swivel until desired operating speed is obtained. Retighten swivel screw, bend loose end of wire around swivel. Cut off excess wire.



Section 5

GENERAL INFORMATION

These engines are single cylinder, L-head, air-cooled type

MODEL SERIES 300401 to 300427

Bore	3-7/16"
Stroke	3-1/4"
Displacement	30.16 cu. in.
Horsepower	12.0 H.P. max. @ 3600 RPM
Torque (Ft. Lbs.)	21.1 max. @ 2600 RPM

320401 to 320427

Bore	3-9/16"
Stroke	3-1/4"
Displacement	32.4 cu. in.
Horsepower	14.0 H.P. max. @ 3600 RPM
Torque (Ft. Lbs.)	23.85 max. @ 2600 RPM

The horsepower ratings listed are established in accordance with the Society of Automotive Engineers Test Code J607. For practical operation, the horsepower loading should not exceed 85% of these ratings. Engine power will decrease 3½% for each 1,000 feet above sea level and 1% for each 10° above 60° F.

Major engine repairs should not be attempted unless you have the proper tools and a thorough knowledge of internal combustion engines.

TUNE-UP SPECIFICATIONS

	A.C.	Autolite	Champion
Spark Plug Type			
Short Plug	CS-45	A7N	CJ-8
Long Plug	GC-46	A71	J-8
Spark Plug Gap			.030"
Ignition Point Gap			.020"
Intake Valve Clearance			.007"-.009"
Exhaust Valve Clearance			.017"-.019"


STORAGE INSTRUCTIONS

Engines stored for over 30 days should be completely drained of fuel to prevent gum deposits forming on essential carburetor parts, fuel filter, fuel lines and tank.

- Remove filter bowl, open shut-off valve and drain tank completely.
- Replace filter bowl. Leave fuel valve open.
- Operate engine until it stops from lack of fuel.
- While engine is still warm, drain and clean the oil sump. Refill with fresh oil.
- Remove spark plug, pour one ounce of SAE 30 oil into cylinder and crank slowly to spread oil. Replace spark plug.
- Clean dirt and chaff from cylinder, cylinder head fins and blower housing.

ENGINE, DRIVE SHAFT AND COUPLING REMOVAL

B-1 Tractor




1. Remove hood.
2. Remove grille and grille support.
3. If equipped with electric starter, remove battery ground clamp.
4. Disconnect wire running from starter switch to starter.
5. Disconnect fuel line from tank.
6. Remove ignition wire from switch.
7. Disconnect choke and throttle cables from tractor when engine is being removed.

8. Disconnect front drive shaft coupling from engine.
9. Disconnect complete drive shaft when repairs are needed on the shaft or couplings.
10. Remove capscrews holding engine to frame.
11. Remove oil drain pipe.
12. Remove engine.

Installation is the reverse of engine removal.

ENGINE, DRIVE SHAFT AND COUPLING REMOVAL


B-10 (9 H. P.), B-10 (10 H. P.), Big Ten, B-12 Tractors Prior to S/N 50001 Tractors



1. Remove hood, grille and grille support.
2. Disconnect battery ground clamp.
3. Disconnect ignition wire.
4. Remove fuel line.
5. Remove starter generator wires.
6. Remove choke and throttle cables when engine is being removed.
7. Remove oil drain pipe.
8. Disconnect front coupling of drive shaft from engine.
9. Disconnect complete drive shaft when repairs are needed on the shaft or couplings.
10. Remove capscrews holding engine to frame.
11. Slide engine forward to remove.

Installation is the reverse of removal.

ENGINE, DRIVE SHAFT AND COUPLING REMOVAL
B-12, B 110, B 112, HB-112, B-210, B-212, HB-212



1. Remove hood, side panels.
 2. Remove battery, fuel tank.
 3. Remove dash assembly.
 4. Remove shift lever ball and brake lock.
 5. Remove frame cover assembly.
 6. Remove choke and throttle cables, when engine is being removed.
 7. Disconnect front coupling of drive shaft from engine.
 8. Disconnect complete drive shaft when repairs are needed on the shaft or couplings.
 9. Remove oil drain plug.
 10. Remove capscrews holding engine to frame.
 11. Remove engine.
- Installation is the reverse of removal.

NOTE: On units equipped with hydraulic system, removal of quadrant and lever assembly will simplify removal of drive shaft from engine.

STORING YOUR TRACTOR

When your tractor is not to be used for some time, it should be stored in a dry protected place. Leaving your tractor outdoors, exposed to the elements, will result in materially shortening its life.

PREPARING TRACTOR FOR STORAGE

1. Clean and completely lubricate the tractor.
2. Block tractor up to remove weight from tires and to keep tires from contact with moist floor. Protect tires from light.
3. Remove spark plug and pour one tablespoon of light motor oil on top of piston. Crank engine over a few times and replace spark plug.
4. To avoid gum content collections, drain the fuel tank and carburetor and clean out the fuel strainer and sediment bowl.
5. Clean the exterior of the engine.
6. Remove battery and store in a cool dry place above freezing. Keep battery fully charged.

7. When tractor is removed from storage, it should be serviced thoroughly, including draining and refilling the crankcase with fresh oil.

STARTING ENGINE AFTER STORAGE

1. Remove spark plug and wipe dry, crank engine rapidly until excess oil has been blown out of spark plug hole. Replace spark plug.
2. Fill the fuel tank.
3. Install a fully charged battery and be sure the proper connections are made.
4. Service air cleaner.
5. Drain crankcase and refill with fresh clean oil.
6. Start engine and let it run slowly for the first few minutes. Move tractor outside of storage room, or keep all doors open. Do not operate engine at high speeds immediately after first starting.
7. Inflate tires to the correct operating pressure before operating tractor.

DIAGNOSING ENGINE DIFFICULTY

ENGINE HARD STARTING

1. Loose or grounded high tension, or breaker point leads.
2. Improper breaker point gap.
3. Faulty spark plug.
4. Faulty condenser or coil.
5. Incorrect spark timing.
6. Gasoline not getting to carburetor.
7. Dirt or gum in carburetor or fuel line.
8. Carburetor improperly adjusted.
9. Valves leaking or sticking.
10. Piston rings worn excessively.
11. Cylinder head gasket leaking.

ENGINE OVERHEATING

1. Insufficient available cool air.
2. Dirty air intake screen, shroud or cooling fins.
3. Improper fuel.
4. Fuel mixture too lean.
5. Improper ignition timing.

ENGINE BACKFIRING

1. Fuel mixture too lean.
2. Sticky intake valve.
3. Improper ignition timing.

ENGINE MISSING AT HIGH SPEED

1. Spark plug gap too wide.
2. Improper carburetor adjustment, or lack of fuel.
3. Wrong type spark plug, use spark plug that is recommended.
4. Improper timing.

ENGINE MISSING UNDER SLOW HARD PULL

1. Spark plug gap too wide.
2. Pitted breaker points.
3. Partially fouled spark plug.
4. Defective ignition cable.

ENGINE KNOCKING

1. Fuel octane rating too low.
2. Engine overheated.
3. Improper timing.
4. Loose connecting rod.
5. Excessive carbon in combustion chamber.

ENGINE OPERATING ERRATICALLY

1. Clogged fuel line.
2. Water in fuel.
3. Faulty choke control.
4. Improper fuel.
5. Loose ignition system connections.
6. Air leaks in manifold or carburetor connections.

ENGINE WILL NOT IDLE

1. Improper carburetor idling adjustment.
2. Carburetor jets clogged.
3. Spark plug gap too narrow.
4. Leaking carburetor or manifold gaskets.
5. Sticking or leaking valves.
6. Weak coil or condenser.

INDEX

TRACTOR

STEERING GEAR REMOVAL

B-1	C-1
B-10 Prior to S/N 50001	C-1
Big TEN, B-10 S/N 50001 & Up	C-1
B-12, B-110, B-112, HB-112	C-1
B-210, B-212, HB-212	C-1
B-207, B-208	C-2

FRONT AXLE ASSEMBLY

All Models Except B-207, B-208	C-3
B-207, B-208	C-4

LUBRICATION	C-5
-------------------	-----

ADJUSTMENTS	C-12
-------------------	------

CONTROLLED TRACTION DIFFERENTIAL

ADJUSTMENT	C-15
------------------	------

REAR LIFT DRAWBAR	C-16
-------------------------	------

CLUTCH & BRAKE

B-10 Prior to S/N 50001	C-17
B-1	C-18
BigTEN, B-12, B-10 S/N 50001 & Up, B-110	C-19
B-112 Prior to S/N 20001	C-19
B-112 S/N 20001 & Up	C-20
HB-112, HB-212	C-20
B-207, B-208	C-21

C



THIS PAGE INTENTIONALLY BLANK

STEERING GEAR REMOVAL




Figure 1

B-1 & B-10 Prior to S/N 50001

B-1 Tractor Figure 1

1. Tilt seat assembly rearward, remove hood.
2. Loosen setscrew, remove steering wheel.
3. Remove keys and washers from top of steering shaft.
4. Remove battery.
5. Disconnect fuel line at tank.
6. Remove capscrews holding frame cover to frame.
7. Remove gear shift lever ball.
8. Remove capscrew from gear shift rod guide.
9. Lift off frame cover and tank assembly.
10. Disconnect rear tie rod ball joint.
11. Loosen setscrew and remove steering arm, woodruff key and washer from steering gear.
12. Remove steering driven gear.
13. Removal of shaft and pinion gear - remove snap ring and washer from lower end of shaft.
14. Lift shaft out of bearing.
15. Remove capscrews to remove bearing.

Installation is the reverse of removal.

B-10 Tractor Figure 1

1. Remove hood, side panels and battery.
2. Loosen setscrew and remove steering wheel and key.




Figure 2

Big Ten, B-10 S/N 50001 & Up, B-12, B-110, B-112, HB, 112, B-210, B-212, HB-212

3. Lift off dash.
4. Remove tank support.
5. Disconnect rear tie rod ball joint.
6. Loosen setscrews, remove steering arm.
7. Remove steering driven gear.
8. Remove snap ring and washer from lower end of shaft.
9. Lift out shaft assembly.
10. Remove capscrews from main frame to remove bearings.

Reassembly is the reverse of removal.


Figure 2

1. Remove hood and side panels.
2. Remove steering wheel and key.
3. Remove battery and fuel tank.
4. Remove dash assembly.
5. Remove locking collar or steering shaft.
6. Disconnect universal joint in steering shaft, remove shaft.
7. Disconnect tie rod.
8. Remove steering gear.
9. Remove steering bracket.

Installation is the reverse of removal.


STEERING GEAR REMOVAL

B-207 and B-208



1. Remove hood and steering wheel.
2. Disconnect ignition wire and choke and throttle cables.
3. Unbolt and lift off dash assembly and upper steering shaft support.
4. Raise front of tractor and disconnect drag link from steering gear.
5. Unbolt and remove steering gear.
6. Remove nut securing steering pinion to frame and remove upper steering shaft, "U" joint and steering pinion.
7. When reassembling the steering units, move steering gear closer to steering pinion to remove excessive steering wheel play.
8. To reassemble, reverse disassembly procedure.

FRONT AXLE ASSEMBLY
All Models



AXLE MAIN FRAME

1. Raise tractor front end.
2. Disconnect tie rod ball joint.
3. Remove capscrew and spacer from center of axle.
4. Lower front of axle and pull forward to slide stabilizer out of frame angle. The frame angle is replaceable if it is excessively worn.

DRAG LINK

1. Remove bolts, washers and spacers that hold


tie rod to spindles.

STEERING SPINDLES

1. Raise tractor front end, remove wheels.
2. Remove drag link.
3. Remove steering arm and key from left spindle and remove spindle.
4. Remove cotter key from right spindle and remove spindle.
5. There are 4 spindle bearings. Two in each end of axle frame.

FRONT AXLE ASSEMBLY

B-207 and B-208



1. Front axle main member on the B-207 and the B-208 is welded to the frame. New frame assembly is necessary if axle cannot be repaired.
2. Refer to the figure above for disassembly and assembly of components.
3. Inspect the bushings on the spindle assemblies and the bearings in the front wheels.
4. Replace where needed.
5. Clean dirt and grease off of all parts.
6. Lubricate both of the spindle end and assembly unit.

LUBRICATION
B-1 Tractor




FIG. 1




FIG. 3

The tractor has a total of 5 grease fittings which require lubrication with general purpose automotive grease. Use a standard grease gun for the following fittings:

- (2) Front Spindles - Fig. 1
- (2) Steering Mechanism - Fig. 3
- (1) Rear Axle Tube - Fig. 4

Before lubricating, wipe each grease fitting with a rag to prevent grit and dirt from being carried into bearings with new grease.

The Starter-Generator was equipped with two oil cups requiring lubrication with SAE 20 motor oil. Apply 8 to 10 drops of oil every 100 hours operating time. **DO NOT OVER OIL.** See Fig. 5. On later units, bearings require no lubrication as they are prelubricated for life.




FIG. 2




FIG. 4




FIG. 5




FIG. 6

The transmission has a capacity of 1-1/2 qts. of SAE 90 oil and is filled at the factory. It will not normally require replenishment, but occasionally check drain plug for tightness and axle tube oil seals for leakage. Keep oil up to level of filler plug. Remove vent plug from top of transmission and allow oil to settle to normal level before checking. (See Fig. 6).

The bevel gear housing has a capacity of 1 pint of SAE 90 oil and is filled at the factory. It will not normally require replenishment, but occasionally check drain plug for tightness and oil seals for leakage. Keep oil up to level of filler plug. (See Fig. 7).

ENGINE

Engine - Service air cleaner and crankcase as recommended in engine service manual. Be sure oil in air cleaner is maintained in clean condition. Never use oil in crankcase for more than 25 hours of operation. (See Fig. 8).
CLEAN AIR AND CLEAN ENGINE OIL WILL GIVE LONG TROUBLE-FREE OPERATION. DIRT WILL RUIN YOUR ENGINE IN A SHORT TIME. A funnel and extension are included with the tractor for use in changing oil.

TIRES

The tires of the tractor are inflated with air pressure in excess of the normal amount for shipment. For comfort of operation, release some of the pressure until a pressure of 12 lbs. per square inch is attained for front tires and 14 lbs. per square inch is attained for rear tires. Maintain tires at these pressures.




FIG. 7




FIG. 8

BATTERY

The battery should be kept clean and dry at all times. Keep battery snugly fastened in place and check battery cables for tight connections. Vent caps should be kept tight and vent holes in vent caps must be kept open at all times to permit gases formed in battery to escape. Do not over-fill. Keep filled so solution is 1/16" above separators. When installing battery, install shield to prevent battery terminals from contacting hood. Full maintenance instructions are provided on separate instruction card for battery.

If tractor is not used for an extended period during winter, remove battery and store in a fully charged condition in a cool place.

LUBRICATING
B-10 (9 H. P.) Tractor




FIG. 1




FIG. 3




FIG. 2




FIG. 4

The tractor has a total of 5 grease fittings which require lubrication with general purpose automotive grease. Use a standard grease gun for the following fittings:

- (2) Front Spindles - Fig. 1
- (2) Steering Mechanism - Fig. 3
- (1) Rear Axle Tube - Fig. 4

Before lubricating, wipe each grease fitting with a rag to prevent grit and dirt from being carried into bearings with new grease.

The transmission has a capacity of 1-1/2 qts. of SAE 90 oil and is filled at the factory. It will not normally require replenishment, but occasionally check drain plug for tightness and axle tube oil seals for leakage. Keep oil up to level of filler plug. Remove vent plug from top of transmission and allow oil to settle to normal level before checking. (See Fig. 5).




FIG. 5




FIG. 6

The bevel gear housing has a capacity of 1 pint of SAE 90 oil and is filled at the factory. It will not normally require replenishment, but occasionally check drain plug for tightness and oil seals for leakage. Keep oil up to level of filler plug. (See Fig. 6).

ENGINE

Service air cleaner and crankcase as recommended in engine service manual. Never use oil in crankcase for more than 25 hours of operation. (See Fig. 7). CLEAN AIR AND CLEAN ENGINE OIL WILL GIVE LONG TROUBLE-FREE OPERATION. DIRT WILL RUIN YOUR ENGINE IN A SHORT TIME. A funnel and extension are included with the tractor for use in changing oil.




FIG. 7

TIRES


The tires of the tractor are inflated with air pressure in excess of the normal amount for shipment. For comfort of operation, release some of the pressure until a pressure of 12 lbs. per square inch is attained for front tires and 8 lbs. per square inch is attained for rear tires. Maintain tires at these pressures.

BATTERY

The battery should be kept clean and dry at all times. Keep battery snugly fastened in place and check battery cables for tight connections. Vent caps should be kept tight and vent holes in vent caps must be kept open at all times to permit gases formed in battery to escape. Do not overfill. Keep filled so solution is 1/16" above separators. When installing battery, install shield to prevent battery terminals from contacting hood. Full maintenance instructions are provided on separate instruction card for battery.

If tractor is not used for an extended period during winter, remove battery and store in a fully charged condition in a cool place.

MAINTENANCE
Big Ten, B-10 (10 H. P.), B-12 Tractors



Check daily or every 5 hours of operation.

OIL RECOMMENDATIONS

WINTER

(Below 40°F.)
Use SAE 5W-20
If not available
Use SAE 10W
Above 10°F.

SUMMER

(Above 40°F.)
Use SAE 30
If not available
Use SAE 10W-30

Any high quality detergent oil having the American Petroleum Institute classification "For Service MS" can be used in your Briggs and Stratton engine. Detergent oils keep the engine cleaner and retard the formation of gum and varnish deposits.

Nothing should be added to the recommended oils.

CRANKCASE OIL



Remove the oil filler plug. Place the engine level. Fill the crankcase to overflowing. POUR SLOWLY. CAPACITY 4 PINTS. REPLACE THE FILLER PLUG.

CHANGE OIL (Crankcase)

Change oil after 5 hours of operation. Remove the oil drain plug. Drain oil while engine is warm. Replace drain plug. Remove oil filler cap or plug and refill with new oil. Replace oil filler cap or plug. Add oil regularly after each 5 hours of operation. Thereafter change oil every 25 hours of operation.

SERVICING "OIL-FOAM" AIR CLEANER

Clean and re-oil the air cleaner frequently (every few hours under extremely dusty conditions). Clean and re-oil at least every 25 hours under normal conditions.



1. Remove wing nut and cover.
2. Lift off foam element from base.
3. Push down foam element as shown and pull out screen.
4. A - Wash foam element in kerosene or solvent.

B - Squeeze dry and blot to remove all solvent. Re-oil with 6 tablespoons engine oil.



C - Squeeze again to spread oil through foam element.

D - Put screen inside element. Be sure sealing lip is over end of screen (top and bottom).

5. Reassemble parts as shown. Fasten to engine. Screw wing nut down tight.

CLEAN COOLING SYSTEM

Grass or chaff may clog cooling system after prolonged service in cutting dry grasses or hay. Continued operation with a clogged cooling system causes severe overheating and possible engine damage. Remove blower housing and clean regularly.



DRAINING FUEL TANK AND CLEANING FUEL FILTER

Loosen thumb screw below filter bowl.



Remove and clean filter bowl and screen.

Open shut-off valve to see if fuel flows freely from the tank.

IMPORTANT: If you find a gummy, varnish-like substance use alcohol or acetone to dissolve it.

NOTE: See Engine Service Manual for complete engine service.

Lubricate grease fittings every 25 hours of operation.



The tractor has a total of 3 grease fittings which require lubrication with general purpose automotive grease. Use a standard grease gun for the following fittings:

Before lubricating, wipe each grease fitting with a rag to prevent grit and dirt from being carried into bearings with new grease.

- (2) Front Spindles - (Fig. 1)
- (1) Rear Axle Tube - (Fig. 3)




FIG. 4

CHECK PERIODICALLY

TRANSMISSION

The transmission has a capacity of 1-1/2 qts. of SAE 90 oil and is filled at the factory. It will not normally require replenishment, but occasionally check drain plug for tightness and axle tube oil seals for leakage. Maintain oil level at lower edge of filler plug hole. Remove vent plug from top of transmission and allow oil to settle to normal level before checking. (See Fig. 4).

BEVEL GEAR HOUSING

The bevel gear housing has a capacity of 1 pint of SAE 90 oil and is filled at the factory. It will not normally require replenishment, but occasionally check drain plug for tightness and oil seals for leakage. Keep oil up to level of filler plug. (See Fig. 5).




FIG. 5

TIRES

Periodically check tire pressure. Maintain pressure to specified pressure as given.

	Tractor	With Loader	With Fork Lift
Front	8 PSI	20 PSI	20 PSI
Rear	12 PSI	14 PSI	20 PSI

BATTERY

The battery should be kept clean and dry at all times. Keep battery snugly fastened in place and check battery cables for tight connections. Vent caps should be kept tight and vent holes in vent caps must be kept open at all times to permit gases formed in battery to escape. Full maintenance instructions are provided on separate instruction card for battery.

If tractor is not used for an extended period during winter, remove battery and store in a fully charged condition, in a cool place.

ADJUSTMENTS

B-1 Tractor




FIG. 1




FIG. 2




FIG. 3

PARKING BRAKE

Depress foot pedal until brake holds securely; flip capscrew toward rear for park. (See Fig. 1). Adjust length of screw to permit screw head to wedge on bottom of frame and hold lever in depressed position with brake applied.

CLUTCH AND BRAKE

1. With clutch and brake pedal in normal position (i. e., clutch engaged and brake released), adjust hex nuts (A) to give 3/4" clearance between rod guide assembly (B) and nuts. (See Fig. 2).
2. Pull brake band up by hand so that it is tight around brake drum. Adjust hex screw (C) to have a clearance of 1" between brake band and screw as shown in Fig. 3.
3. Adjust nut (D) to permit clutch link (E) to pivot freely without excessive play. (See Fig. 4).





FIG. 4

4. Adjust nut (F) to permit clutch link (E) to pivot freely without excessive play and check to see that nut has at least 1-1/2" of travel before touching transmission case. (See Fig. 4).
5. When clutch is disengaged and brake is applied, the clutch and brake lever assembly should have at least 1" of travel before touching bevel gear housing.
6. To compensate for belt stretch or other variances it may be necessary to move idler pulley (G) Fig. 4 into the alternate hole provided in its lever arm.


ADJUSTMENTS
B-10 (9 H. P.) Tractor



CLUTCH

With clutch and brake pedal in normal position (i. e., clutch engaged and brake released), adjust hex nuts (A) to give $\frac{3}{4}$ " clearance between rod guide assembly (B) and nuts. (See Fig. 1).


Position the set collar on the clutch rod to compress the spring about $\frac{5}{8}$ ". Then recheck and position the locknuts "A" to leave a spacing of about $\frac{3}{4}$ " between them and the end of the rod guide "B", Fig. 1. Check to see that when the pedal is operated, the spring is completely decompressed as the locknuts engage the end of the rod guide.



BRAKE ADJUSTMENT

Pull the brake band up by hand so that it is tight around the brake drum. Adjust the hex screw (C) Fig. 2 to give a clearance of about $\frac{3}{4}$ " between the brake band and the screw head. Then check to see that the idler pulley releases the belt properly before the brake is applied. If the brake does not hold properly when the pedal is pushed all the way forward, reduce slightly the spacing between the head of the hex bolt and the brake band. Then recheck the clutch rod adjustment for proper idler release.

ADJUSTMENTS
Big Ten, B-10 (10 H.P.), B-12 Tractors




Seasonal adjustments should be made on the Big Ten tractor.

CLUTCH ADJUSTMENT

Adjust locknuts on clutch rod to give 11/16" space between them and idler pulley pivot arm. (See Fig. 1).


BRAKE ADJUSTMENT

Pull the brake band up by hand so that it is tight




around the brake drum. Adjust the locknuts to give a clearance of about 11/16" between the brake band and the locknut. Then check to see that the idler pulley releases the belt properly before the brake is applied. If the brake does not hold properly when the pedal is pushed all the way forward, reduce slightly the spacing between the locknuts and the brake band. Now recheck the clutch rod adjustment for proper idler release. (See Fig. 2).


CONTROLLED TRACTION DIFFERENTIAL ADJUSTMENT
All Models




Adjust traction differential within the R. H. rear wheel hub. Adjustment is made by tightening the two capscrews within the R. H. rear wheel hub to 20 ft. lbs.

CAUTION: Maintain 20 ft. lbs. of torque on these capscrews. Under torque will allow excessive wheel slippage under slippery conditions. Over torque will cause hard steering due to lack of differential action.







CLUTCH & BRAKE (B-10) Prior to S/N 50001



CLUTCH & BRAKE (B-1)




CLUTCH & BRAKE
Big TEN, B-12, B-10, S/N 50001 & UP, B-110





CLUTCH & BRAKE
(Model B-112 Prior to S/N 20001)

CLUTCH & BRAKE
(Model B-112 Eff. W/S/N 20001 & up)



CLUTCH & BRAKE
MODEL HB-112, HB-212





CLUTCH BRAKE SYSTEM

B-207, B-208

C-21

INDEX

	Page
HYDROSTATIC DRIVE UNIT	
INTRODUCTION	D-1
Purpose of Manual	D-1
Description	D-1
General Information	D-1
GENERAL OVERHAUL PROCEDURES	D-2
DISASSEMBLY	D-2
Tools	D-4
Disassembly of Motor	D-4
Disassembly of Pump	D-7
Disassembly of Valve Plate	D-8
Disassembly of Transfer Block	D-9
INSPECTION AND REPAIR	D-10
ASSEMBLY	D-10
Piston Pump	D-11
Replenishing Pump and Valving	D-11
START-UP AFTER REPAIR	D-11
GENERAL MAINTENANCE	D-11
Lubrication	D-11
Replacement Parts	D-11
Adjustments	D-12
Adding Fluid to System	D-12
Oil Filter	D-12
Troubleshooting	D-12

CHARTS

TRANSMISSION TROUBLESHOOTING GUIDE	D-12
SYSTEM TROUBLESHOOTING GUIDE	D-13

TYPICAL MODEL CODING

T66*-2A-(S)-2-10(L)
TA6-2A-S-10*-.***
TB6-2A-S-10*-.***

THIS PAGE INTENTIONALLY BLANK

SECTION I — INTRODUCTION

A. PURPOSE OF MANUAL

This manual describes the basic operational characteristics and provides service and overhaul information for the Vickers T66 and TA6 Series-10 Design Transmission Packages.

B. DESCRIPTION

Both transmission packages are hydraulic drive assemblies capable of high pressure operation in two directions of flow output. Drive speeds of both transmissions vary with model and circuit applications. Figure 1 illustrates the T66 transmission and its four major components: a variable displacement, reversible piston pump, a transfer block that also houses control valves, and the fixed displacement piston motor.

The TA6 transmission pump and the TB6 transmission motor are composed of identical components of the T66 transmission package except they are not joined by a common transfer block and valve plate.

C. GENERAL INFORMATION

1. Related Documentation — Installation information and dimensions are not contained in this manual. If required, installation drawings are available from your local Vickers Mobile Sales Office.

2. Model Codes — The basic TA6, TB6 and T66 transmission packages are designed and manufactured to meet the requirements of a variety of applications. Optional features are then incorporated to fulfill the operating demands of the particular application. A model code that represents the basic design plus the optional features is assigned to each model. To identify the specific design characteristics of your transmission, copy the model number stamped on the back side of the transfer block. For a breakdown of the code refer to the TA6 installation drawing, or the T66 installation drawing.

Be sure to include the complete model number and date code when addressing service inquiries to Vickers. This will help to provide prompt and accurate answers to your inquiry.




Figure 1

SECTION II — GENERAL OVERHAUL PROCEDURES

CAUTION

Block vehicle if it is on a slope. The transmission cannot act as a parking brake.

Before breaking a circuit connection, make certain that the power is off and the system pressure has been released.

Lower all vertical cylinders, discharge all accumulators, and block any load whose movement could generate pressure.

Completely drain the oil from the vehicle hydraulic system. Discard this oil and use new, clean oil when restoring the unit to service.

After removing the hydrostatic transmission from the vehicle, and before disassembly, cap or plug all ports and disconnected hydraulic lines, and clean the outside of the unit thoroughly to prevent entry of dirt into the system.

CAUTION

Absolute cleanliness is essential when working on a hydraulic system. Always work in a clean area. The presence of dirt and foreign materials in the system can result in serious damage or inadequate operation.

SECTION III — DISASSEMBLY

The exploded views of the assemblies in Figures 2, 3, 4 and 5 are provided as additional visual aids that support the sequential disassembly procedures that follow. Both the T66 and TA6 transmission are composed of identical assemblies, except the TA6 is not equipped with a motor. The motor disassembly procedure can obviously be disregarded when working on the TA6 transmission. Also, only disassemble the

transmission to the level that is necessary to repair the unit.

NOTE

Keep parts for each unit clean and separate from those of another unit or assembly. Although some parts may look similar they could have slightly different and critical dimensions.




Figure 2 T66 and TA6 Pump




Figure 3 T66 Motor




Figure 4 T66 and TA6 Valve Plate Assembly




Figure 5 T66 and TA6 Transfer Block Assembly

TOOLS

Figure 6 illustrates the recommended set of tools that are used during disassembly or reassembly. Some equivalent tools are noted in the instruction.

1. Bearing puller
2. Shaft seal driver
3. Bearing puller
4. Torque wrench (150 ft-lb)
5. No. 5 Truarc (90°) pliers
6. No. 24 Truarc (straight) pliers
7. No. 23 Truarc (90°) pliers
8. No. 22 Truarc (90°) pliers
9. No. 21 Truarc (straight) pliers






Figure 6

DISASSEMBLY OF MOTOR




①

Place the transmission on a clean workbench. Have a supply of clean, lint-free rags, shop paper, or craft paper handy to lay parts on and to cover parts from dirt and foreign particles.




②

Separate the motor assembly from the transfer block by removing four hex head screws. Discard "O" rings and replace with new ones.




③


Separate motor valve plate from the motor housing by removing four screws.




If valve plate doesn't separate easily from motor housing, tap corner of valve plate with plastic mallet.




Remove swash plate from shoe plate.




With one hand under rotating group end, tilt housing until rotating group slides into your hand.




Remove assembled parts as shown. Be careful not to scratch the pistons or cylinder running surfaces.




If this group does not need to be disassembled, place it on a clean surface and proceed to step 14. To disassemble this group proceed to step 8.




Generally, no further disassembly is required. However, if the cylinder block is to be disassembled, proceed to step 10.




To relieve cylinder block spring tension, refer to Figure 10. **WARNING**—exercise extreme caution. Spring is under a great deal of tension.




Remove shaft. The spacer and press fit bearing should come out with it. Replace shaft seal.




To remove the motor shaft, first remove the large snap ring with the 90° Truarc pliers.



Remove snap ring and key from motor shaft before you remove the bearing.




Remove the shaft by tapping on the small end with a soft tipped hammer or mallet.




If it is necessary to remove the bearing, first remove the key; then use an Owatanna 10-11 bearing puller, or equivalent puller, or an arbor press. Any other method of removal may damage bearing.

DISASSEMBLY OF PUMP




16

To disassemble the pump, remove the valve plate and transfer blocks as a unit by removing two recessed Allen head screws, and then the two hex head screws.




19

Now to remove the pump shaft. First remove the snap ring with 90° snap ring pliers.




17

Pull valve plate and transfer block straight up from pump housing. Set it down on its painted side. Assembly Note: Line up pins with holes in valve plate and gerotor key with drive shaft slot.




20

Remove the pump shaft by tapping the small end of the shaft with a plastic tip hammer. Remove the shaft with the loose spacer and the press fit bearing installed on it. Replace shaft seal.



18


Pick up pump housing with one hand and slowly tilt it forward to remove group as assembled unit. To disassemble rotating group perform steps 7 thru 10.



21


To remove the bearing, remove the key, and then the snap ring. Refer to step 15 for bearing removal.

DISASSEMBLY OF VALVE PLATE




22

To remove both pintles and yoke from the housing, set a 3/16-inch punch on the roll pin. Tap punch with a hammer until roll pin is disengaged from yoke.




23

Now place a 1/4-inch brass rod on the pintle, and tap the pintle out of the yoke.




24

Repeat this procedure on the other pintle. Remove yoke from housing. Pintles must not be installed backward.




25

To disassemble the valve plate, remove the two recessed Allen-head screws.



26


Separate valve plate from transfer blocks by pulling them apart. If required, tap valve plate with a plastic mallet to separate them.



27


Remove replenishment pump from valve plate. Assembly Note: Dots not to be visible when replenishing pump is in pocket.

DISASSEMBLY OF TRANSFER BLOCK




28

Remove the two replenishing system check valves by removing the Allen-head plugs. Don't interchange valve parts.




31

Set transfer block with finished surface facing up. Remove caps and take out both the soft-ride valve and high-pressure relief valve.




29

Remove replenishing pump relief valve. (Some models have only one valve.)




32

To remove high pressure check valves, first remove three "O" rings. Assembly Note: Be sure open ends of guide point outward.



30

To remove bearing, place valve plate on protective surface. Put brass shim stock or other protective stock under puller. Use Owatanna MD956-B-1, an equivalent puller, or an arbor press.



33

Remove high-pressure check valve seats with an Allen-head wrench. Assembly Note: During assembly, torque valve seats to 30-35 ft-lbs.

SECTION IV — INSPECTION AND REPAIR

Clean all parts thoroughly with mineral spirits prior to inspection and after any stoning or machining operation. Inspection and repair procedures are as follows:

1. Valve Plate — Inspect the flat surface mates with the cylinder block for wear or scoring. Remove minor defects by lightly stoning the surface with a hard Arkansas stone that is flat within 0.001 inch. Be sure to stone lightly; the surface is hardened and excessive stoning will remove hardened surface. If wear or damage is extensive, replace the valve plate.

2. Rotating Group — Inspect the bores and the valve plate mating surface of the cylinder block for wear and scoring. Remove minor defects on the running face by lightly stoning or lapping the surface. If the defects cannot be removed by these methods, replace cylinder block.

If one or more piston and shoe sub-assemblies need to be replaced, check that all piston and shoe subassemblies in the unit ride properly on the swash plate (Figure 7). In a set of nine pistons, variations in thickness greater than 0.001 of an inch from one shoe to another, will result in excessive internal leakage and shoe wear. The replacement of all nine piston and shoe sub-assemblies in the pump and motor, as well as the cylinder block, is recommended for maximum service between overhauls.

If necessary, hand-lap the shoes with 500-A emery paper (Tuff-Bak Durite Silicon Carbide) backed-up by a lapping plate. Good results may be obtained by dipping the emery paper in kerosene and keeping it wet during polishing.

SECTION V — ASSEMBLY

The procedures for assembling the transmission are basically the reverse of the disassembly procedures shown in detail in Section 3. However, the following instructions describe certain additional procedures that should be adhered to:

Install new gaskets, seals, and "O" rings during assembly. To ease assembly of the gaskets and seals, apply a thin film of Vaseline or clean hydraulic oil to the "O" rings. If a new




Figure 7

3. Swash Plate — Inspect the swash plate for wear and scoring. If the defects are minor, lightly stone the swash plate. If wear or damage is extensive, replace the swash plate.

4. Bearings and Drive Shaft — Inspect all bearings for roughness or excessive play; replace if necessary. Examine the sealing area of the shaft for scoring or wear. If the drive shaft is bent or worn excessively, replace it.

5. Replenishing Pump — Inspect the surface of all parts subject to wear. Remove light scoring from the face of the inner and outer rotor with crocus cloth laid over a flat surface, with a medium India stone, or by lapping.

rotating group is being used, squirt clean oil on it.

PISTON PUMP

1. Yoke — Install the yoke in the housing. With "O" rings in place, insert the pintles through the housing and into the yoke. Check that the yoke does not rub against the housing. Align the pintle holes with the holes in the yoke. Press in roll pins until they are 0.10 inch from top of yoke.

2. Drive Shaft and Bearing — Install new shaft seal in the housing. Place the flat washer over the shaft seal. Then install the drive shaft in the housing. Secure the drive shaft bearing with the retaining snap ring.

3. Swash Plate — Install the chamfered edge of the swash plate toward the shaft seal. Be sure that the swash plate is properly seated in the yoke and that it can be freely rotated with the fingers.

4. Rotating Group Assembly — If the spring and washers were removed from the cylinder block, reassemble them. When properly assembled with the three pins in place, the spring can be compressed about 1/8 inch.

REPLENISHING PUMP AND VALVING

1. Carefully install the inner and outer rotor elements (with key in key slot) into the valve plate. The key must mate with the slot on the drive shaft and must be installed on the side of the rotor that is toward the drive shaft.

SECTION VI — START-UP AFTER REPAIR

Take the following precautions when starting a vehicle after repair:

1. Before connecting drain lines and before installing transmission in vehicle, fill transmission pump and motor with new, clean oil through case drain openings.

2. Connect all hydraulic lines to the proper transmission port lines and set hydraulic controls in neutral position.

3. Loosen or remove reservoir cap and add new, clean oil to reservoir.

4. Jog the starter several times (about one minute) with engine coil wire disconnected. Recheck reservoir oil level. If necessary, add oil to maintain operating oil level.

5. Replace engine coil wire. Start the engine and run it to a speed of about 800 rpm

2. Oil the cartridge with clean hydraulic oil for prelubrication. The key can be coated with Vaseline to hold it in place during assembly.

3. Be sure the locating pins are in the valve plate, and that the "O" ring seals are in place.

4. New sealant must be applied to the valve plate before reassembly. Remove all old sealant and residue with lacquer thinner or acetone on a cloth. Purchase Ford Perfect Seal (8A-19554-B) R134-A from a local Ford Dealer or purchase Sealing Compound Grade No. 4 direct from P. & O.B. Mfg. Co., 11100 Kenwood Road, Cincinnati, Ohio—Phone (513) 793-6332.

Apply sealant compound on valve plate approximately 0.38 wide around perimeter, then proceed with assembly. (See Illustration 26)

5. Assemble Remaining Parts — Relief valve, springs, "O" ring seals and plugs. (Refer to exploded views and photos for details.)

(avoid high speed start-up). Recheck reservoir oil level again.

6. Increase pump speed to 1800 rpm and move the controls to the forward position and run vehicle slowly on level ground for a few yards.

7. Then, after a short interval (about 10 seconds), place controls in reverse and move vehicle slowly backwards an equal distance.

8. After several short trips back and forth, the air should be dispelled from your hydraulic system. Check oil level; add oil if necessary.

After all the above steps are complete, you may operate the vehicle at regular speeds and loads. In cold weather, make sure the hydraulic components are warm to the touch before operating the vehicle.

SECTION VII — GENERAL MAINTENANCE

LUBRICATION

Internal lubrication is provided by the system oil flow.

REPLACEMENT PARTS

Use only genuine parts manufactured or sold by Vickers Incorporated as replacement

parts for these transmissions. Only Vickers knows the true quality level required of each part.

ADJUSTMENTS

No periodic adjustments are required other than maintaining proper shaft alignment with the driving medium.

ADDING FLUID TO THE SYSTEM

When adding hydraulic fluid to the system, pour it through a 10-micron filter. If such a filter is not available, use a funnel with a fine wire screen (200 mesh or better).

OIL FILTER

The oil filter controls the cleanliness of the oil. Experience with various kinds of duty and operating conditions will help you to determine how often to schedule a filter cartridge change. Check the condition of the oil periodically until you can establish a replacement pattern. In the

meantime, change the cartridge after the first 50 hours of vehicle operation.

TROUBLESHOOTING

The cause of improper functioning in a hydraulic system is best diagnosed with the use of proper and adequate testing equipment and a thorough understanding of the complete hydraulic system.

CAUTION

A hydraulic transmission unit that exhibits an excessive increase in heat or noise is a potential failure. When either of these conditions are noticed, immediately shut down the machine, locate the trouble, and correct it.

Detailed troubleshooting information is given in the following charts.

TRANSMISSION TROUBLESHOOTING GUIDE

Has Malfunction Been	Probable Cause	
	Code	Code Legend
Steady?	1, 2, 3, 4, 5, 6, 7, 8	1. Charge system
Intermittent?	6	2. Inlet check valve
In one direction of travel?	2, 4, 5	3. Pump rotating group
In both directions of travel?	1, 3, 4, 6, 7, 8	4. Motor rotating group
Occurring under light load?	2, 5, 6, 8	5. High-pressure check valves
Occurring under heavy load?	1, 2, 3, 4, 5, 6, 7, 8	6. Soft-ride valve
Independent of load?	1, 3, 4, 6, 7, 8	7. High-pressure relief valve
Occurring at maximum vehicle speed?	1, 4	8. Tow valve
At minimum vehicle speed?	1, 3, 4	
Independent of vehicle speed?	1, 2, 5, 6, 7, 8	
Occurring at wide open throttle?	3	
Occurring at partial throttle?	1, 3, 5, 8	
Independent of throttle?	1, 2, 3, 4, 5, 6, 7, 8	
Occurring when system is hot?	1, 3, 4, 6	
When system is cold?	1, 6	
Independent of temperature?	1, 2, 3, 4, 5, 6, 7, 8	
Deteriorating rapidly?	3, 4, 5, 6, 7, 8	
Deteriorating slowly?	1, 2, 3, 4, 5, 6	

SYSTEM TROUBLESHOOTING GUIDE

Trouble	Cause	Remedy
I. Excessive noise in hydrostatic transmission	Air in the system	1. Check for air leaks on suction line. 2. "Bleed" hydraulic lines at highest point downstream of replenishing pump and while system is under pressure.
	Vacuum condition	1. Check inlet (suction) lines and fittings for air leaks. 2. Check replenishing pump function.
	Oil too thick	Be certain correct type of oil is used for refilling or adding to the system.
	Cold weather	Run hydraulic system until unit is warm to the touch and noise disappears.
II. Hydraulic transmission overheating	Heat exchanger not functioning	Locate trouble and repair and replace.
	Cooling fan not operating	Repair.
	Cooling fins packed with accumulated debris	Remove material from between fins.
	Fluid level low	Add oil to operating level.
III. System not developing pressure	1. Sheared shaft key 2. Misadjusted or broken control linkage 3. Disconnected or broken drive mechanisms	Locate and repair.
IV. Loss of fluid	1. Ruptured hydraulic lines 2. Loose fittings 3. Leaking gaskets or seals in hydrostatic transmission	1. Check all external connections, tubing, and hoses. Tighten connections, replace ruptured tube or hose. 2. Observe mating sections of hydrostatic transmission for leaks. Replace seals or gaskets if possible.

INDEX

POWER TRAIN


BEVEL GEAR	E-1
DIFFERENTIAL	E-2
3 SPEED TRANSMISSION REMOVAL	E-3
3 SPEED TRANSMISSION DISASSEMBLY	E-6
3 SPEED TRANSMISSION ASSEMBLY	E-11
3 SPEED TRANSMISSION INSTALLATION	E-14
HYDROSTATIC TRANSMISSION	E-17
B-207 & B-208 TRANSAXLE	E-18
B-206 TRACTOR	E-19
TWO SPEED PULLEY	E-40
VARIABLE SPEED PULLEY	E-45

E



THIS PAGE INTENTIONALLY BLANK


BEVEL GEAR
All Models



1. Remove seat assembly.
2. Remove dash assembly.
3. Remove top frame cover.
4. Support tractor under frame just ahead of bevel gear housing.
5. Disconnect brake linkage, clutch-brake rod and transmission shift rod.
6. Remove transmission drive belt and cap-screws securing transmission to side plates.
7. Roll transmission rearward from tractor.
8. Disconnect drive shaft.
9. Remove gear shaft flange from bevel gear shaft.
10. Remove capscrews holding bevel gear housing to frame, lift off housing.
11. Remove rope starter pulley.
12. Remove transmission drive pulley.
13. Remove P. T. O. drive pulley.
14. Remove side plates and rear cover.
15. Back up the driven bevel gear and carefully drive the driven shaft to the left until the key is free of gear.
16. Remove key and drive shaft out left side of housing.
17. Remove bearing clamp plate.
18. Drive front shaft, bearing and bevel gear assembly out of housing.
19. Remove bevel gear retaining capscrew and washer.
20. Remove bevel gear and bearing from shaft.
21. Inspect bearings and seal, renew if necessary.

Installation is reverse of removal.

DIFFERENTIAL All Models




REMOVAL

1. Block up tractor and remove wheels.
2. Remove left wheel hub and key.
3. Loosen setscrews and remove collar and washers on left side of transmission.
4. Remove right hub, differential and axle assembly.
5. Remove set collar from right end of axle shaft.
6. Remove bolts from outer edge of case.
7. Remove nuts from inner row of capscrews.
8. Separate case halves. Leave capscrews in position to hold parts in place.
9. When removing parts identify to aid in re-assembly.
10. Reference to above illustration will aid in disassembly and assembly.
11. When installing the assembled differential, the axle and differential are properly seated so the seal between them is compressed. The axle is held in place by the collar on the left side of the transmission.

Tractors


SERVICE INFORMATION
Removal of the B-Series Transmission



NOTE: Before attempting removal of the transmission from the tractor, place the tractor on a level surface and drain all of the lubricating oil from the transmission. For fastest draining, remove the upper pipe plug from the transmission cover to allow air to enter transmission case.

To remove the transmission from the tractor, follow the sequence of steps as outlined below:

1. It is necessary to lift or jack up the tractor to a point where the rear wheels will be free of the ground. Place a support (strong enough to bear the weight of tractor) at a point under the frame and ahead of P. T. O. assembly.
2. If the tractor is equipped with a rear light, raise the tractor hood and disconnect the ground cable from the negative terminal of the battery.



Depending upon the style of battery, the negative terminal of the battery will be either on the R. H. or L. H. side of the tractor.

3. Remove the rear light from the tractor seat back by removing the hex capscrew holding the light mounting bracket to the seat back. Remove the cable clip from the R. H. arm assembly as shown in Fig. 1. This clip is held in place by a hex capscrew, flat washer, lockwasher and hex nut.
4. Remove the hex capscrew and lock nut from each arm assembly at point "A" as shown in Fig. 1. The seat assembly may now be lifted free of the tractor.
5. To remove the left rear wheel and hub complete; loosen the locknuts and setscrews "A" and "B" shown in Fig. 2. Setscrew "A" locks against the key located in the axle shaft and setscrew "B" locks into a hole in the axle shaft. It will be necessary to loosen "B" until the screw is free of the hole in the axle shaft. If necessary, tap the edge of the wheel hub with a lead mallet to loosen from the axle shaft.




FIG. 3




FIG. 4




FIG. 5




FIG. 6

6. Loosen the 2 setscrews holding the set collar on the axle shaft, as shown in Fig. 3, and remove the collar. Should the collar stick or bind on the paint on the axle shaft, remove the paint and sandpaper shaft. After the collar is removed, clean the axle shaft of any remaining paint and remove any burrs from edge of key-way or setscrew lock points by using a fine file. Burrs or paint, etc., will damage bearings when the axle shaft is removed, so be certain the axle shaft is smooth and clean.
7. From the right hand side of the tractor, remove the axle shaft, right hand wheel, hub and differential in one piece by tapping the edge of the differential hub with a lead mallet. When the differential hub is free of the 2 keys on the transmission axle tube as shown in Fig. 4, pull the axle shaft, etc., straight out of the transmission.

8. Remove the V-Belt and pulley from the transmission pulley shaft, taking care not to use excessive thrust force on shaft. Use a wheel puller if necessary. The pulley is held in place by a setscrew and key. Do not hammer or the snap rings on the shaft inside transmission may be damaged.
9. Dis-connect the lift rod clevis from the rear lift bracket by removing the cotter pin, spacer, and pin as shown in Fig. 5. Remove hex capscrews "A", "B", and "C" from both sides of the arm assembly and lift off the drawbar, rear lift bracket, and arm assembly as one piece.
10. Dis-connect the shifter rod assembly from the transmission shift rod as shown in Fig. 6.

Dis-connect the brake band linkage as shown in Fig. 3, by removing the cotter pin and clevis pin and spring.

Add blocking to support the weight of the transmission at points shown in Fig. 6.

Remove the hex capscrews "A", "B", & "C" from the left hand side of the transmission and "A" & "B" from the right hand side. Now loosen "C" on the right hand side and steady the transmission by gripping the pulley shaft with one hand while removing "C" with the other hand.

NOTE: Before starting to dis-assemble the transmission, it will be necessary to remove the brake band and linkage as shown in Fig. 7. To do this, remove the 2 hex capscrews, lockwashers, and hex nuts. Remove the brake drum by loosening the setscrew, and pull the drum from the shaft with a wheel puller as shown. Do not hammer or the snap rings on the shaft inside the transmission may be damaged.




FIG. 7

DISASSEMBLY OF THE B SERIES TRANSMISSION




FIG. 1

Before beginning to dis-assemble the transmission be certain to file on the edges of the key-way on the brake drum shaft to avoid cutting the oil seal if any burrs have been raised there. Remove the 2 keys from the axle tube and check for burrs. File if necessary. Remove the grease fitting from the axle tube, and also the snap ring. Check for burrs. Check the drive pulley shaft for burrs and file if necessary.

After having made sure that the axle tube, brake drum shaft, and drive pulley shaft are free of burrs or sharp protrusions that might cut or damage the oil seals during dis-assembly, proceed by following the steps outlined below.

1. Remove the oil drain plug and allow any remaining oil to drain from the transmission. Draining will be speeded by removing the upper pipe plug from the transmission case, and setting the transmission in an upright position as if in place on the tractor.
2. Remove the 14 hex head capscrews and lockwashers from around the edge of the transmission cover. Drive the 2 dowel pins down into the transmission case holes and insert a screw driver at several points between the cover and the case and pry upwards to break the cover loose from the case. See Fig. 1. When cover is free, lift off.




FIG. 2




FIG. 3

3. Remove the flat washer from shaft 'A', shaft 'C', and shaft 'D'. Now remove the gear from the end of shaft 'B'. Remove the axle tube and gear assembly 'E' from the transmission case. See Fig. 2.
4. Lift out shaft 'C' with gear assembly and then remove shaft 'D' with its gear assembly. See Fig. 3.




FIG. 4

5. To remove the pulley shaft "A" and its gear assembly it will be necessary to position the shift forks as follows:

- A. Place shift fork "Y" in Neutral so that the lower edge of shift stem slot is even with the end of roll pin in the transmission case.
- B. Place the shift fork "Z" in top-most position. **CAUTION**--do not raise too far, or it may come off of the shaft and the lock ball or spring may be lost.

Now, lift the pulley shaft "A" with one hand to clear the lower bearing, and with the other hand, raise the cluster of gears on shaft "B" slightly to allow pulley shaft "A" and its gears to be moved away from the shift forks. When the yokes of the shift forks disengage from the shift rings on the gear clusters on shaft "A", the shaft and gears may be lifted free of the transmission. Now, lift out shaft "B" and its gear. See Fig. 4.

6. The reverse gear "F" may be removed now, by undoing the lock nut on the back-side of the transmission case, and removing the hex head capscrew from the bracket on the inside of the case. (See Fig. 5).
7. Remove the shifter forks and shafts from the transmission case by loosening the setscrews




FIG. 5




FIG. 6

located as shown in Fig. 6. Loosen these screws sufficiently to clear the locating holes in the shafts.

8. To remove the shift rod, first loosen the lock nut on the shift stem, and unscrew the shift stem from the shift rod. The shift rod may then be pulled from the case. See Fig. 4.

SHIFTER FORKS FOR THE B SERIES TRANSMISSION

NOTE: Before attempting any dis-assembly or assembly of shifter forks, it should be understood that they are to be removed from the transmission case by following the sequence of steps completely as outlined in the transmission dis-assembly procedure.

Dis-Assembly

1. To remove the shifter forks from the shifter shafts, slide the fork towards the end of the shaft without the retaining ring. Cup one hand over the lock ball loading hole while withdrawing the shaft to prevent the loss of the shift lock ball or spring.



The lock ball and spring are under tension when the fork is in place on the shaft, and unless care is taken the ball may fly out as the shaft is removed and be lost.

Assembly

The shifter shafts are of unequal length and the position of the fork is reversed from one shaft to the other. To properly assemble the shafts and forks, proceed as follows:

1. Identify the long shaft, (it has a retaining ring on the end of the shaft farthest from the setscrew hole) and insert the setscrew hole end into the hub of a shift fork. See Fig. 1. Before pushing the shaft through the hub of fork, insert the shift lock spring and ball through the loading hole and depress with a $3/8$ " rod so that the shaft may slide through.

Identify the short shaft, (it has a retaining ring located near the setscrew hole) and insert the end without the retaining ring into the hub of the shifter fork. Before pushing the shaft through the hub of the fork, insert the shift lock spring and ball through the loading hole and depress with a $3/8$ " rod so that the shaft may slide through. See Fig. 1.



To obtain a clear idea of the position of the shift forks when properly installed on the shifter shafts, refer to Fig. 2. This shows the general appearance of the shift forks and shafts and the shift rings that the forks engage. In this particular view, the parts are shown in their relative positions as they would be seen if the end of the transmission were to be cut off. Note that the gear cluster nearest the pulley end of the shaft is engaged by the shift fork on the short shaft, and the other gear cluster is engaged by the shift fork on the long shaft. Also note the relative position of the shift forks to each other.

BEARINGS FOR THE B SERIES TRANSMISSION

The Transmission contains a total of 12 bearings. 4 needle bearings and 1 bronze bearing are located in the transmission case, 4 needle bearings and 1 bronze bearing are located in the transmission cover and 2 bronze bearings are located in the axle tube.

TRANSMISSION CASE

<u>Location</u>	<u>Description</u>
"A"	Needle Brg., sealed on one end
"B"	Needle Brg., open on both ends
"C"	Needle Brg., sealed on one end
"D"	Needle Brg., sealed on one end
"E"	Bronze Brg.

TRANSMISSION COVER

<u>Location</u>	<u>Description</u>
"A"	Needle Brg., open on both ends
"B"	Needle Brg., sealed on one end
"C"	Needle Brg., sealed on one end
"D"	Needle Brg., sealed on one end
"E"	Bronze Brg.,

AXLE TUBE

<u>Location</u>	<u>Description</u>
Each end of tube	Bronze

REMOVAL

To remove the bearings, disassemble the transmission as outlined in transmission disassembly instructions. For best results, use a rod slightly smaller than the outside diameter of the bearing and press the bearing from its housing. Use caution to avoid damaging the bearing housing.


INSTALLATION

NEEDLE BEARINGS

Be sure to use the correct size bearing for each location as listed in the chart above. Press bearings "A", "C", & "D" into the cover and case until the end of the bearing case is flush with the machined face of the bearing housing. This machined face of bearing housing is on inside of transmission. Bearing "B" is to be installed 1/16" below surface of bearing housing.

NOTE: The needle bearings all have a number stamped on one end of bearing case. This is the end of bearing to press against, when installing.

DO NOT press against the un-numbered end of the bearing or damage may result.



The bearings with the sealed end, are to be installed with the sealed end facing the outside of the transmission.

BRONZE BEARINGS

Press one bronze bearing into the "E" bearing housing of the transmission case until it is flush with the inside machined face of bearing housing. Now insert the axle tube into the bearing and place the transmission cover over the dowel pins of case and slide the other bronze bearing into place in the housing of the cover. Press the bearing into the housing until the outer end of bearing is flush with bottom face of the smaller of two counter-bores in housing.

NOTE: The axle tube acts as an aligning mandrel for the bearings, and must be used to prevent cocking the bearings when they are being installed.

AXLE TUBE

Press a bronze bearing into one end of the tube until it is flush with the end of the tube. Now insert the axle shaft through the axle tube and slide the other bronze bearing over the axle tube until it starts to enter the opposite end of axle tube. Press the bearing into position flush with the end of axle tube.

NOTE: The axle shaft acts as an aligning mandrel for the bearings and must be used to prevent cocking the bearings when they are being installed.

OIL SEALS FOR THE B SERIES TRANSMISSION

The Transmission contains a total of 4 oil seals; 2 seals are in the transmission cover, and 2 seals are in the transmission case. See Fig. 1 and order the proper seals for replacement.

Transmission Cover

- (A) One Seal for Pulley Shaft
- (B) One Seal for Axle Tube

Transmission Case

- (C) One Seal for Brake Drum Shaft
- (D) One Seal for Axle Tube

REMOVAL

To remove old seals, carefully pry the seals out of their positions in the case and cover.

Use caution to avoid damage to either the bearings or the cast iron seats or bores that the seals rest in.

DO NOT ATTEMPT TO RE-USE OR SALVAGE SEALS. When seals are removed from their positions in the transmission, they are not fit for re-use, and must be discarded.

INSTALLATION

The importance of properly installing oil seals cannot be minimized if they are expected to do their job and do it well.

Failure to observe correct installation procedure will account for more seal failure than any other cause.

Inspect the surface of each shaft to be certain that no nicks, burrs, scratches, or sharp edges will be able to damage the seals during installation. Be particularly critical of the area of the shaft that the seal covers when in position. If a shaft shows any nicks, scratches, or burrs at this area, **DISCARD THE SHAFT** and replace with a new one. Any attempt to file or remove flaws at this point will only result in a flat spot and oil leakage.

1. Make sure that the seal is correct size. See Fig. 1, for correct location.
2. Check the cast iron seat or bore that the seal will rest in. Remove all nicks, burrs, scratches, or foreign material.
3. When installing the seal, it is advisable to use a thimble that will fit over the shaft as shown in Fig. 2. This will aid in stretching the spring element in the seal to allow it to slide over the shaft, and at the same time will protect the seal from damage or cutting by the edges of key-ways. **NOTE:** The thimble should be long enough to protect the




FIG. 1




FIG. 2

seal until it is completely past all holes or key-ways. The maximum diameter of the thimble should equal the shaft diameter plus 1/32". Lubricate the surface of the thimble with clean grease to aid in sliding the seal in place.

If a thimble is unavailable, wrap the shaft with a heavy grade of paper lubricated with oil or grease. When wrapping the shaft, start at the seal end of the shaft and wrap in an overlapping spiral fashion, being sure to cover the key-ways.

4. Remove the seal from its wrapper or package, and gently lubricate the sealing element with a light coating of absolutely clean grease. Do not run your finger roughly around the sealing element, as it is easily deformed and ruined.
5. As these seals are to be installed flush with the outer surface of the bore or seat, use a pressing tool at least 1/8" larger in diameter than the outside diameter of seal as shown in Fig. 2. Place the seal on the thimble with the spring element of the seal facing the liquid to be retained, and with the pressing tool, gently slide the seal towards its seat. Avoid cocking the seal as it starts into its seat, and gently tap the pressing tool with a hammer until the seal is in place. **NEVER HAMMER ON THE SEAL ITSELF.**

ASSEMBLY OF THE B SERIES TRANSMISSION




FIG. 1

Before beginning to assemble the transmission, make certain that the transmission case, cover, and all of the parts that go into the transmission have all been completely cleaned. Scrape the mating surfaces of the case and cover to remove any pieces of gasket material that may have stuck. As you put the various gear shafts into their bearings, apply a light coating of clean transmission oil to the bearing surfaces of each shaft.

To proceed with the transmission assembly, follow the sequence of steps as outlined below:

1. Before beginning assembly, check the 2 roll pins that limit the movement of the shift stem. See Fig. 1. It is imperative that both of these pins be checked for proper height and adjusted if necessary. Note the dimensions shown: pin "A" in the transmission case is set to give a dimension of $1-39/64$ " from the end of the pin to the face of transmission case, and pin "B" in the transmission cover is set to give a dimension of $1-3/16$ " from the end of the pin to the face of cover. When replacing pins, the groove of the pin should face the top of the transmission case.
2. Insert the shift rod into the transmission case and position it to allow the shift stem




FIG. 2

with lock nut to be screwed into the shift rod as shown in Fig. 2.

Screw the shift stem into the shift rod until a distance of $5/8$ " from the round surface of the rod to the shoulder of shift stem is obtained, as shown in Fig. 2. This setting is important to insure proper shifting, so check and adjust until correct. Be sure the lock nut is tight enough to hold the shifter stem at this setting.

3. Assemble the shifter fork assembly with the longer shaft into the "Y" shaft hole of the transmission. Take care to be sure that the setscrew, which holds the shaft in place, is actually locked into the setscrew hole of the shifter shaft. Now assemble the shorter shaft into the "Z" shaft hole of the transmission and lock in place in same manner as other shifter fork assembly. See Fig. 3.




FIG. 3

4. Assemble the reverse gear "F" as shown in Fig. 3. When properly assembled, insert the gear assembly into the transmission case and position the bracket over the mounting hole in the case. See Fig. 3. Fasten the bracket to the case with a hex capscrew and tighten to 20 ft. lbs. $\begin{smallmatrix} +0 \\ -3 \end{smallmatrix}$ lbs.

Add a lock nut to the pin protruding through the transmission case and tighten to 55 ft. lbs. $\begin{smallmatrix} +0 \\ -5 \end{smallmatrix}$ lbs.

5. Place shaft "B" and gears into bearing "B" in the transmission case. See Fig. 4.
6. Place a greased flat washer over face of bearing "A" in transmission case. See Fig. 3 & 4. To install shaft "A" and gears, first move the "Y" shift fork into Neutral (See dis-assembly instructions) and move the "Z" fork into raised position (see dis-assembly instructions). Raise the gear cluster on shaft "B" slightly and move shaft "A" toward the shift forks. When you slide the shift rings on the gear assemblies into position against the shift forks, it should be possible to lower shaft "A" into place in its bearing.




FIG. 4




FIG. 5




FIG. 6

7. Place a greased flat washer over face of bearing "D" and place shaft "D" and gears in place in the bearing. See Fig. 5.
8. Place a greased flat washer over face of bearing "C" and place shaft "C" and gears in place in the bearing. See Fig. 5.
9. Place 2 greased flat washers over face of bearing "E" and place axle tube and gear in place in the bearing. See Fig. 6.
10. Assemble the gear to end of shaft "B", with the beveled edge facing gear cluster on shaft "A". Place a greased flat washer on shaft "A" and on end of shaft "C" and shaft "D". Add 2 flat washers to axle tube. See Fig. 6.
11. Before putting gasket in position, drive the 2 dowel pins up until they protrude approximately 1/4" to 5/16" above the machined face of the transmission case. Now position the new gasket in place and seat the cover over the 2 dowel pins before inserting the capscrews. When cover seats properly, insert and tighten the capscrews.
12. Attach a pulley to the pulley shaft and rotate by hand to check gears for binding. Check all gear ranges to see that gears rotate freely. If a slight bind is noticed, tap the end of the pulley shaft and brake drum shaft with a raw-hide mallet. It may be that one




FIG. 7

of the bearings is not seated far enough into the cover or case, and the impact of the mallet will drive it into position and remove the binding. If a severe binding is noticed, it will be necessary to dis-assemble the transmission and locate the cause.

13. Assemble the grease fitting and snap ring to the axle tube as shown in Fig. 7.

INSTALLATION OF THE B SERIES TRANSMISSION




FIG. 1




FIG. 2




FIG. 3




FIG. 4

To properly install the transmission to the tractor, follow the sequence of steps as outlined below:

1. Assemble the brake drum to the shaft with the key and setscrew. The setscrew side of the brake drum faces away from the transmission. See Fig. 1.

Add the brake band and adjusting linkage and secure in place with 2 hex capscrews, lockwashers, and hex nuts.

2. Position the transmission case on supports so that hole "C" on R.H. side of transmission lines up with the mounting hole of side plate. See Fig. 2. Insert the capscrew and tighten partially. Hold the pulley shaft with one hand and by using your knee for a brace, position

the transmission so that bolt "A" may be inserted and partially tightened. Add bolt "B". Now add bolts "A" & "B" to the L.H. side of the transmission. With the spring bracket in place on bolt "C" and positioned as shown in Fig. 3, tighten the bolt. Now tighten all 6 mounting bolts securely.

3. Insert the clevis pin through the hole of brake adjusting clevis, through the hole in lever of clutch and brake shaft assembly, and through the end loop of spring. After the pin is in place, secure with cotter pin. See Fig. 3.
4. Use "Vise-Grip" pliers and attach the large spring from the Power Take-Off to the mounting hole on the spring retainer.
5. Attach the clevis of the shifter rod to the transmission shift rod, using hex capscrew, lockwasher, and hex nut as shown in Fig. 4.




FIG. 5




FIG. 7

6. Mount the drawbar, rear lift bracket, and arm assembly to the transmission as shown in Fig. 5 and fasten with hex capscrews (3 on each side) "A", "B", & "C".

Connect the lift rod clevis to rear lift bracket with pin, spacer and cotter pin. The spacer is to be placed on R.H. side of the lift bracket.

7. Place the key in the key-way of pulley shaft and mount the pulley with the hub facing away from the transmission. Do not tighten the setscrew until after the V-belt is in place and the pulley is aligned with the pulley on the bevel gear box. See Fig. 6.
8. Insert the axle shaft into the axle tube on the R.H. side of the transmission and place the 2 keys in the slots on the axle tube. Align the key-ways in the differential hub with the keys and while holding the keys in place, push the




FIG. 6




FIG. 8

axle shaft through the transmission. The differential hub is to seat against the snap ring on the axle tube. See Fig. 6.

9. Make sure that the axle and differential are properly seated so that the seal between the differential and the wheel hub is compressed. See Fig. 6. The axle is then held in this position by placing the set collar over the L.H. end of the axle shaft and locking it securely against the axle tube by means of the 2 setscrews. It is very important that this set collar be securely locked at all times to eliminate any end play of the axle shaft. See Fig. 7.

NOTE: Later production models have 3 washers between the set collar and the axle tube for the purpose of moving the set collar farther out on the axle shaft. Use washers No. 105050.

10. Place the key in the slot of the axle shaft and mount the L.H. wheel and hub in place over the key. Tighten the setscrew "B" into the setscrew hole on the axle shaft. See Fig. 8. Tighten the setscrew "A" and lock both setscrews with the lock nuts. Tighten securely.

11. Mount the seat assembly to the tractor, placing the arms of the seat pivot assembly between the vertical arm assembly fastened to transmission. Fasten with hex capscrews and lock nuts as shown at "A" in Fig. 9. Tighten enough to take out excessive "play" but leave loose enough to pivot properly.

Mount the rear light support bracket to the seat back as shown, using a hex capscrew and lockwasher. Fasten the cable clip to the arm assembly as shown, with a hex capscrew, flat washer, lockwasher, and hex nut.

12. Attach the ground cable to the negative terminal of the battery.

13. Refill transmission with 1-1/2 quarts of SAE #90 Oil, and check drain plug, filler plug, and vent plug for tightness.




FIG. 9

HYDROSTATIC TRANSMISSION HB-112 and HB-212

A gear reduction unit is used on all models equipped with a hydrostatic transmission. A sliding drive gear is used in the gear reduction unit so that tractor may be moved manually. When gear shift lever (4—Fig. 1) is in vertical position, drive gear (21) will be engaged with reduction gear (43). To disengage gears, turn shift lever away from reduction housing.

CAUTION: Tractor brakes are inoperative when shift lever is in disengaged position.

REMOVE AND REINSTALL

All Models So Equipped

To remove the gear reduction unit, support tractor under main frame just ahead of bevel gear housing. Remove seat deck and fender assembly. Drain reduction unit housing. Remove rear wheels, hubs, differential assembly and axle shaft. Remove bevel gear pto belt pulley and disconnect pto tension spring. Support gear reduction housing and remove left side plate. Drain hydrostatic transmission reservoir, disconnect oil lines and

control rod, then unbolt and remove reservoir, oil cooler, shroud and cooler fan. Unbolt and remove hydrostatic transmission and brake band. Remove capscrews securing gear reduction unit to right side plate and lift the unit from tractor.

Reinstall by reversing the removal procedure. Fill reduction unit to level plug opening with SAE 90 EP gear oil. Fill hydrostatic reservoir with Dexron Type "A" automatic transmission fluid. Adjust brake and clutch idler linkage as required.

OVERHAUL

All Models So Equipped

To disassemble the gear reduction unit, remove brake drum and clean all paint, burrs and rust from

keyed end of axle tube (37—Fig. 1). Unbolt and remove cover (40) from case (17). Remove washer (27) and first reduction gear (23). Remove snap ring (14), then withdraw output gear and axle tube assembly (28 thru 37). Remove second reduction gear and shaft assembly (41 thru 45). Loosen set screw (46) and remove as a unit, the shift fork and rail assembly (7 thru 10) and the brake shaft assembly (18 thru 22). Use caution when removing shift rail (10) from shift fork (9) as poppet ball and spring (7 and 8) will be released. Loosen locknut (5), remove shifter stem (6) and withdraw shift lever (4). Oil seals and needle bearings can now be removed from case and cover as required.

Clean and inspect all parts and renew any showing excessive wear or other damage. Using Fig. 1 as a guide, reassemble by reversing the disassembly procedure.




Fig. 1—Exploded view of gear reduction unit used on models equipped with a hydrostatic transmission.

- | | | | | | |
|-----------------------------|----------------|------------------|----------------|---------------|-------------------|
| 1. Hydrostatic transmission | 8. Spring | 16. Bearing | 24. Washer | 32. Ring gear | 40. Cover |
| 2. Lever latch | 9. Shift fork | 17. Case | 25. Input gear | 33. Spacer | 41. Washer |
| 3. "O" ring | 10. Shift rail | 18. Brake shaft | 26. "O" ring | 34. Washers | 42. Shaft |
| 4. Gear shift lever | 11. Bearing | 19. Washer | 27. Washer | 35. Bearing | 43. Pinion & gear |
| 5. Nut | 12. Oil seal | 20. "E" ring | 28. Snap ring | 36. Bushing | 44. Washer |
| 6. Shift stem | 13. Bearing | 21. Sliding gear | 29. Washers | 37. Axle tube | 45. Snap ring |
| 7. Ball | 14. Snap ring | 22. "E" ring | 30. Washer | 38. Bearing | 46. Set screw |
| | 15. Oil seal | 23. Gear | 31. Spacer | 39. Bearing | |

B-207 and B-208 TRANSAXLE

Models B207-B208-Homesteader 8

REMOVE AND REINSTALL.

To remove transaxle, remove drive belt from transaxle pulley and remove brake band. Remove gear shift lever knob. Support rear of tractor frame and remove axle "U" bolts. Roll transaxle away from tractor.




Fig. 1—To position shifter assembly in neutral for reassembly, align notches in shifter forks with notch in shifter stop.

OVERHAUL. To overhaul transaxle, drain lubricant and remove input pulley, brake drum and wheel and hub assemblies. Place shift lever in neutral position, unscrew shift housing cap screws and withdraw shift assembly from case. Remove all paint, rust and burrs from axle shafts and place transaxle in a vise with right (longer) axle pointing down. Unscrew case cap screws and drive out dowel pins.




Fig. 2—Exploded view of transaxle used on models B207, B208.

Separate cover from case and lift cover up off the axle. Brake shaft (30—Fig. 2) and idler gear (29) will be removed with cover. Remove output shaft (41) with output gear (40), spacer (39) and washer (38). Withdraw the differential and axle shaft assembly and lay aside for later disassembly. Hold upper ends of shifter rods together and lift out shifter rods, forks, shifter stop, shaft (20) and sliding gears (22 and 23) as an assembly. Remove reverse idler gear (27), idler shaft (28) and spacer (26), then remove idler shaft (31) along with idler gears (32, 34 and 36) and spacers (33 and 35). Withdraw input shaft (24) and gear (25) from case. To remove brake shaft (30) and gear (29) from cover, block up under gear (29) and press shaft out of gear while being careful that pressure is not applied to cover during operation. Renew seals and bushings in axle housings (51 and 60) as required.

To disassemble differential, unscrew four cap screws and separate axle shaft and carriage assemblies from ring gear (68). Drive blocks (65), bevel pinion gears (66) and drive pin (67) can now be removed from ring gear. Remove snap rings (43) and slide axle shafts (45 and 57) from axle gears (44) and carriages (48 and 62).

Clean and inspect all parts for damage or excessive wear and renew as required. When installing needle bearings, press bearings into case and cover from inside until bearings are 0.015-0.020 below thrust surfaces. Renew all seals and gaskets and reassemble transaxle assembly by reversing disassembly procedure and noting the following points: Install reverse idler gear (27) in case so that rounded edge of gear teeth and spacer (26) will be toward cover. When installing idler shaft (31), place short spacer (35) between gears (34 and 36) and long spacer (33) between gears (32 and 34). Bevels on gear teeth of gears (32 and 34) must be on side of gear nearest large gear (36). When installing shifter assembly, position shifter rods in neutral position as shown in Fig. 1.

Tighten transaxle cap screws to the following torque:


Differential cap screws . . . 7 ft.-lbs.
Case to cover cap screws . 10 ft.-lbs.
Axle housing cap screws . 13 ft.-lbs.
Shift lever housing
cap screws 10 ft.-lbs.

ITEM	QTY.	DESCRIPTION	ITEM	QTY.	DESCRIPTION
—	—	TRANSAXLE ASSY., complete	34	1	GEAR, spur 16T
1	1	LEVER & HOUSING ASSY.	35	1	SHAFT, idler
2	1	KNOB, shifter	36	1	PINION & BUSHING ASSY., idler
3	1	LEVER, shift	37	1	GEAR, idler
4	1	SCREW, sckt-hd. cup-pt. 1 4NC x 3 4	38	1	WASHER
5	1	HOUSING, shift lever	39	1	SPACER
6	1	RING, quad.	40	1	GEAR, output
7	1	PIN, roll	41	1	PINION, output
8	1	KEEPER, shifter lever	42	1	AXLE, R.H.
9	1	RING, snap	43	2	SEAL, oil
10	2	BALL, steel	44	1	BUSHING
11	2	SPRING	45	1	HOUSING & BUSHING ASSY., axle
12	2	FORK, shifter	46	8	WASHER, thrust
13	1	ROD, shifter	47	1	CARRIER, differential
14	2	RING, snap	48	2	BEARING, thrust
15	1	ROD ASSY., shift	49	1	GEAR, bevel
16	1	STOP, shifter	50	1	RING, snap
17	1	ROD, shifter	51	1	COVER ASSY., transaxle
18	1	ROD, assy., shifter	52	1	BEARING
19	1	BEARING	53	2	PIN, dowel
20	4	BEARING	54	1	AXLE, L.H.
21	1	SHAFT & BEARING ASSY., shifter	55	1	HOUSING & BUSHING ASSY., axle
22	1	GEAR, shifting	56	1	CARRIER, differential
23	1	GEAR, shifting	57	1	BLOCK, drive
24	1	SHAFT, input	58	2	PINION, bevel
25	1	SPUR GEAR, input shaft	59	1	PIN, drive
26	1	SPACER, reverse idler	60	1	GEAR, ring
27	1	IDLER, reverse	61	6	LOCKWASHER, 1 4, pltd.
28	1	SHAFT, reverse idler	62	8	CAPSCREW, 1 4NC x 2-1 4 lg. gr. 5, pltd.
29	1	GASKET, case to cover	63	2	PLUG, pipe
30	1	GEAR, spur 26T	64	1	CASE ASSY., transaxle
31	1	SPACER	65	1	SEAL, oil
32	1	GEAR, spur 22T	66	1	BEARING
33	1	SPACER	67	1	GASKET, shift lever housing

TRACTOR
B-206

INDEX

Adjustments	E-24, E-25, E-26
Assembly of Transaxle to Tractor	E-36
Diagnosing Engine Difficulties	E-21
Differential	E-30, E-31
Lift Lever Kit	E-36
Maintenance	E-22, E-23, E-24
Removal of Transaxle	E-26
Rotary Mower, 26"	E-37
Seat Adjustment	E-39
Shifting Assembly and Disassembly	E-33, E-34, E-35
Shifting Lever Assembly and Disassembly	E-32
Snow Blade, 36"	E-36
Specifications	E-20, E-38
Storing the Tractor	E-23
Transaxle Assembly	E-30
Transaxle Disassembly	E-27, E-28, E-29



B-206 TRACTOR SPECIFICATIONS

ENGINE COMPONENTS AND DRIVE

Horsepower	6
Make	Briggs & Stratton, Series 146700
Bore and Stroke	2 3/4 x 2 3/8
Displacement	14.11 cu. in.
RPM	3600
Starter	Recoil (12 volt elec. w./4 amp. alternator opt.)
Governor	Mechanical-Adjustable-Full Lubrication
Transmission	Transaxle-3 speeds forward - 1 reverse
Differential	Bevel Gear, Internal to Transaxle
Eng./Trans. Drive	Heat and Oil Resistant Belt
Battery	25 AMP Hour (Optional w/Elec. Start)
Brake	Band Type, Combination Brake and Clutch Pedal
Clutch	Belt Type, Belt Tightening Idler Pulley

CAPACITY

Eng. Crankcase	2 1/4 pts.
Fuel Tank	2 quarts

SPEEDS

First	1.27 MPH
Second	2.48 MPH
Third	3.70 MPH
Reverse	1.72 MPH

DIMENSIONS

Height (at top hood)	28.75"
Height (at steering wheel)	34"
Width Overall	25.5" (27.5 with tires reversed)
Length Overall	53.25"
Wheel Tread (Center to Center).....	20.5" (22.5 with tires reversed)
Wheel Base	39.75"
Clearance (front axle)	8"
Clearance (differential)	4.5"
Clearance (drawbar)	8.5"
Front Tire Size	11.00 x 3.75-5
Rear Tire Size	4.80/4.00-8
Turning Radius	36" (inside rear wheel)

SHIPPING WEIGHT

B-206	335 lbs.
B-206E	350 lbs.

DIAGNOSING ENGINE DIFFICULTY

Engine Hard Starting

1. Loose or grounded high tension, or breaker point leads.
2. Improper breaker point gap.
3. Faulty spark plug.
4. Faulty condenser or coil.
5. Incorrect spark timing.
6. Gasoline not getting to carburetor.
7. Dirt or gum in carburetor or fuel line.
8. Carburetor improperly adjusted.
9. Valves leaking or sticking.
10. Piston rings worn excessively.
11. Cylinder head gasket leaking.

Engine Overheating

1. Insufficient available cool air.
2. Dirty air intake screen, shroud or cooling fins.
3. Improper fuel.
4. Fuel mixture too lean.
5. Improper ignition timing.

Engine Backfiring

1. Fuel mixture too lean.
2. Sticky intake valve.
3. Improper ignition timing.

Engine Missing at High Speed

1. Spark plug gap too wide.
2. Improper carburetor adjustment, or lack of fuel.
3. Wrong type spark plug, use spark plug that is recommended.
4. Improper timing.

Engine Missing Under Slow Hard Pull

1. Spark plug gap too wide.
2. Pitted breaker points.
3. Partially fouled spark plug.
4. Defective ignition cable.

Engine Knocking

1. Fuel octane rating too low.
2. Engine overheated.
3. Improper timing.
4. Loose connecting rod.
5. Excessive carbon in combustion chamber.

Engine Operating Erratically

1. Clogged fuel line.
2. Water in fuel.
3. Faulty choke control.
4. Improper fuel.
5. Loose ignition system connections.
6. Air leaks in manifold or carburetor connections.

Engine Will Not Idle

1. Improper carburetor idling adjustment.
2. Carburetor jets clogged.
3. Spark plug gap too narrow.
4. Leaking carburetor or manifold gaskets.
5. Sticking or leaking valves.
6. Weak coil or condenser.

Oil Changes

NOTE: Tractor should be on a level surface before changing oil.

The oil should be changed after the FIRST 5 hours of operation then each 25 hours of operation thereafter.

To change the oil, first remove any dirt or trash buildup from around oil filler plug. Then drain the crankcase, while the engine is warm, by removing the oil drain plug (Fig. 3). Once all of the oil has been drained, replace the oil drain plug and remove the oil filler plug. Refill the crankcase with a high quality detergent oil classified "For Service MS" (motor severe). Nothing should be added to the recommended oil.

Summer Winter (Below 40°F)
Use SAE 30 Use SAE 5W-20 or SAE 10W

Fill the crankcase, pouring oil slowly, to capacity (2 1/4 pints).




FIG. 3

CLEAN AIR AND CLEAN ENGINE OIL WILL GIVE LONG TROUBLE-FREE OPERATION. DIRT WILL RUIN YOUR ENGINE IN A SHORT TIME.

Air Cleaner

The air cleaner element should be removed, cleaned and reoiled after every 25 hours of operation under normal conditions. More often in dusty, dry, or windy conditions.

To service air cleaner (Fig. 4) loosen the 2 hood holddown knobs and tilt the hood forward.




FIG. 4

1. Remove the two screws and lift off the entire air cleaner assembly.
2. Remove the cover, then the spacers and screen from the foam element.
3. Remove the foam element from the air cleaner body.
 - A. Wash foam element in liquid detergent and water or kerosene to remove dirt.
 - B. Wrap foam element in clean, dry cloth and squeeze to remove wetness.
 - C. Saturate foam element in engine oil, then squeeze to remove excess oil.
 - D. Assemble air cleaner completely, making sure that the tongs on the cup type spacer are positioned as shown-- then mount to carburetor with screws.

NOTE: When assembling air cleaner, make sure that the lip of the foam element extends over the edge of air cleaner body. The element lip will form a seal when tightened down.

Engine Cooling

The flywheel screen should be checked each time the air cleaner is serviced and any dirt, grass, etc., should be removed.

Also, the engine shroud should be removed periodically in order to dislodge any foreign matter that may have accumulated around the cylinder and fins at front of engine. If not corrected, these conditions will restrict air flow around the engine, causing it to run hot and therefore, shorten engine life. To service engine shroud, remove (4) four screws.

Alternator (Fig. 5)

The Alternator on this tractor is equipped with a fuse for safety purposes. If a fuse needs changing, heed WARNING before replacing the fuse.

WARNING: For electrical safety always remove cable from negative (-) side of battery before removing fuse. Replace fuse, then battery cable.



FIG. 5

STORING YOUR TRACTOR

When your tractor is not to be used for some time, it should be stored in a dry protected place. Leaving your tractor outdoors, exposed to the elements, will result in materially shortening its life.

Preparing Tractor for Storage

If the tractor is to be stored for more than 30 days, follow this recommended procedure.

1. Disconnect the spark plug wire, drain the fuel tank completely, then reconnect spark plug wire.
2. Start engine and run until all fuel has been consumed.
3. While engine is still warm, drain and refill crankcase with fresh oil (See Oil Changes)
4. Remove spark plug and pour 2 or 3 tablespoons of SAE-30 oil into the plug port. Turn the crankshaft over a few revolutions by pulling the recoil handle out a couple of times or on electric start models by turning the key to the "Start" position for a couple of seconds. This distributes oil throughout the internal engine system and prevents damage (rust, etc.) to the engine while stored! Replace the spark plug.
5. Clean any dirt or grass from the cylinder fins and flywheel screen.
6. Remove battery and store in a cool dry place above freezing. Keep battery fully charged.
7. When tractor is removed from storage, it should be serviced thoroughly, including draining and refilling the crankcase with fresh oil.

Starting Engine After Storage

1. Remove spark plug and wipe dry, crank engine rapidly until excess oil has been blown out of spark plug hole. Replace spark plug.
2. Fill the fuel tank.
3. Install a fully charged battery and be sure the proper connections are made.
4. Service air cleaner.
5. Drain crankcase and refill with fresh clean oil.
6. Start engine and let it run slowly for the first few minutes. Move tractor outside of storage room, or keep all doors open. Do not operate engine at high speeds immediately after first starting.



7. Inflate tires to the correct operating pressure before operating tractor.

MAINTENANCE - B-206 TRACTOR

Lubrication

The B-206 Tractor should be lubricated at the points designated below with a good grade of light machine oil or Allis Chalmers Chain and Cable Lube. (Fig. 1 and 2).

1. Front Axle Vertical spindles.
2. Steering.
3. Axle Linkages.
4. All pivot points.



Oil Checks

The oil level should be checked before starting the engine and after each 5 hours of operation.

Battery - Electric Start Models Only

The battery should be kept clean and dry at all times. Keep battery snugly fastened in place and check battery cables for tight connections. Vent caps should be kept tight and vent holes in vent caps must be kept open at all times to permit gases formed in battery to escape. Do not overfill. Keep filled so solution is 3/16" above separators.

The battery is shipped installed in the tractor, but contains no electrolyte. Remove battery from tractor. Fill each cell to the indicator level with an electrolyte solution of 1.250-1.265 specific gravity. Temperature of battery and electrolyte must be between 60°F and 90°F. Allow battery to stand 20 minutes. Check each cell and add electrolyte as necessary to restore level to indicator. Give battery minimum charge at 20 amperes for 10 minutes or until the temperature of the electrolyte reaches 80°F. Reinstall battery in tractor.

Check each time engine is serviced to insure that the electrolyte level is maintained at approximately 3/16" above the plates. Add distilled water, when necessary, to bring electrolyte (battery solution) up to proper level.

Should the battery become discharged and need charging it can be charged on equipment with a 110 volt plug-in battery charger. Before charging read CAUTION carefully.

CAUTION: 110-volt plug-in charger will not bring battery up to charge unless cable is disconnected from negative (-) side

WIRING DIAGRAM




FIG. 6

of battery. Do NOT run engine with battery disconnected unless the fuse is removed from the fuse holder. Failure to remove the fuse can result in electrical sparking and alternator damage.

If tractor is not used for an extended period during winter, remove battery and store in a fully charged condition in a cool place.

Transmission (Fig. 7)

The transmission has a capacity of 1 1/2 pints of SAE 90 oil and is filled at the factory. It will not normally require replenishment, but occasionally check drain plug for tightness and axle tube oil seals for leakage. Keep oil up to level of filler plug.



FIG. 7

Tires

The tires of the tractor are inflated with air pressure in excess of the normal amount for shipment. For comfort of operation, release some of the pressure until a pressure of 12 lbs. per square inch is attained for rear tires. Maintain tires at this pressure. Front tires are semi-pneumatic no pressure.

ADJUSTMENTS

Carburetor (Fig 8)

The carburetor has been adjusted at the factory, but due to different locations and climatic conditions, minor adjustments may be necessary.

Initial Adjustment

Turn needle valve clockwise until it closes.

CAUTION: Be careful not to close needle valve too tight as this may damage the valve.

Now open the needle valve approximately 1 1/8 turns counterclockwise. Close and reopen the idle valve in the same manner. The initial adjustment will be sufficient to start the engine and make final adjustments.




FIG. 8

NOTE: Let the engine warm up before going to the final adjustment procedures.

Final Adjustment

Close the needle valve until the engine makes a misfire (skips). This misfire indicates a "lean mixture" of air and fuel. Now, open the needle valve out past the smooth operating point until the engine begins to run unevenly (bouncy). This indicates a "rich mixture" of air and fuel. Then close the needle valve slowly to the midpoint between the "lean" and "rich" points so that the engine runs smoothly.

Now move the throttle lever to the idle position, then set (turn) the idle speed adjusting screw until the engine runs at a fast idle (approximately 1,150 RPM). Next, turn the idle valve in (lean mixture) then back out (rich mixture) and then set the valve to the midpoint or until the engine idles smoothly. Now reset the idle speed adjusting screw until the engine idles at 1,750 RPM.

To check for correct settings of final adjustments, move the throttle control lever to the "Fast" position--the engine should accelerate without hesitation or skipping. If hesitation and/or skipping is encountered, readjust the carburetor to a slightly richer setting.

General Tune-Up

The engine manufacturer recommends the following spark plugs for replacement:

A-C	Autolite	Champion
CS-45 or GS-46	A7N or A71	CJ-8 or J-8
Spark Plug Gap	.030"	
Ignition Point Gap	.020"	
Intake Valve Clearance	.005"-.007"	
Exhaust	.009"-.011"	

Clutch-Brake Adjustments (Fig. 9, 10, 11)

NOTE: When adjusting Clutch or Brake follow the entire procedure.

With the Idler Pulley held tight against the belt position and lock the Set Collar 1/8"




FIG. 9

from the Angle Clip. This adjustment is made with an Allen wrench through a slot on the right side of the frame (Fig. 3). To adjust the Compression Spring on the Brake Rod, compress the Spring to a length of 5 1/2" with Set Collar and then lock in place with set screw in collar.

For Brake Band adjustment, pull lower flange of the Brake Band forward to tighten brake and lock set collar 1/4" to 5/16" from flange.





FIG. 10



Power Take Off Control Lever (Fig. 12)

The P.T.O. Lever need not be adjusted unless an implement such as a rotary mower is to be used.

To adjust P.T.O., with mower attached, position Set Collar on P.T.O. Rod Assembly such that the Spring is compressed to a length of 2 3/4" with the P.T.O. Lever in the "ENGAGED" (Forward) position.





Fig. 12

Removal of Transaxle (Figs. 13 & 14).


To remove the transaxle from the tractor, proceed in the following sequence of steps.

1. Lift or jack up the tractor to a point where the rear wheels are free of the ground. Place a support strong enough to bear the weight of the tractor at a point under the frame ahead of the P.T.O. pulley.
2. Disengage and remove transmission drive belt.
3. Remove hub caps from wheels.
4. Remove (2) snap rings from grooves (one at each end of transaxle). Slide wheels off axle. Remove axle spacers and washer from each end of axle.
5. Remove shifter lever knob.
6. Loosen and remove 3 capscrews connecting 1602064 bracket to frame and transaxle on left side - remove bracket.
7. Remove 4 washers and nuts and 2 "U" brackets holding transaxle to frame.
8. Standing at rear of tractor, lower the left side of the transaxle until the shift lever has passed through the frame and then slide the transaxle to the left until free of the brake band and frame.

Note: The Brake band and rod do not have to be disassembled to remove the transaxle.



LEFT SIDE FIG. 13



RIGHT SIDE FIG. 14

Transaxle Disassembly

1. Clean the outside surface of the transaxle, away from the area where disassembly will take place. (Position shift lever in neutral position to help disassembly. See Figure 15. Remove screws (3) holding shift lever and shift lever housing. Remove shift lever housing. Drain oil through the shift lever opening (for service of shift lever assembly, refer to Page 15. Remove all keys from keyways, remove all burrs and dirt from shafts. On hardened shafts, use a stone to remove burrs. All seals should be replaced whenever a shaft is pulled through a seal. Always use a new gasket whenever the gasket surfaces have been separated.
2. After removing axle housings, place the unit in a receptacle, bench or clamp the transaxle in a soft jaw vise. Position the transaxle so that the socket head capscrews are facing up.
3. Remove the socket head capscrews holding the case and cover together. Drive out the dowel pins used for alignment of the case and cover.
4. Lift off the cover assembly. Use a seal protector on axle shaft and lift off transaxle cover assembly. Because this seal is a single lip type, it may be reused, if care is taken to see that it isn't scratched or cut. Discard gasket.




Figure 15




Figure 16




Figure 17




Figure 18

5. To remove differential assembly, it may be necessary to replace two or three screws to hold center plate assembly down. Pull assembly straight up. If tight, tap on lower axle with soft mallet. **CAUTION:** Do Not Use Steel Hammer. Refer to Page 13 for differential assembly service. Remove gear on top of shifter shaft.




Figure 19

6. Remove temporary holding screws, if used, and lift off center plate assembly. Discard gasket.




Figure 20

7. Remove complete shifter assembly by grasping shifter gears, shaft and both shifter rods as a unit. **NOTE:** Examine assembly carefully; if no service is required, retain assembly as a unit for easy reassembly. If service is necessary, refer to Page 16. Also, refer to illustrations 25 and 26 and paragraph (13) on next page.




Figure 21

8. Remove reverse idler shaft and spacer, cluster gear assembly and thrust washer. For removal and replacement of gears on cluster, see paragraph (11) on next page.




Figure 22

9. Lift idler gear assembly out of case.
 NOTE: For sequence of thrust washers and bearings, See Figure 22).
 NOTE: Caution required as needles from shifter and brake shaft bearing may fall out.




Figure 23

10. Remove input shaft oil seal to allow access to snap ring. Remove snap ring and input shaft will slide out. A removed seal must be replaced by a new seal.




Figure 24

11. Cluster Gear Sub-Assembly
 (a) The cluster gear can be disassembled. All gears are replaceable if damaged or worn. Preferably use a press to drive the gears squarely.
 (b) The small and middle gear bevel faces down, there is no beveled edge on large gear. Shorter section between middle and large gear.
 (c) Key edge ends must align with shaft ends.




Figure 25

12. Shifting Assembly
 The shifting assembly is usually removed from and installed into the transaxle as a unit. The assembly is removed and replaced by grasping the shifting rods firmly. This will cause the binding necessary to hold the assembly together. Before removal or installation of the shifting assembly, notches in the shifter forks should be aligned with notches in the shifter stop. This indicates that shifting assembly is in a neutral position. The shifter stop must be so positioned that the notch aligns with notches in shifter forks. For service of the shifting assembly, refer to Page 16.




Figure 26

13. Transaxle Assembly

(a) Install thrust washers and bearing on input shaft. Note sequence, Fig 27.

(b) Install input shaft into case assembly. Lock on with snap ring retainer. Install oil seal.

(c) Set case assembly open side up. Insert the idler shaft gear assembly, thrust washers and bearing. Note sequence of washers and bearings (Fig 22).

Note: Place reverse idler shaft into bearing to aid in holding washers, thrust bearing, idler shaft and gear assembly prior to installing shifter assembly.

(d) Insert the washer and then the three gear cluster assembly.

(e) Insert shifter assembly. Check that rods are seated properly.

Note: Reverse idler shaft will be pushed out at this time.

(f) Install reverse idler. Make sure beveled edge is up. Spacer on top of gear.

(g) Place new gasket on case and install center plate.

(h) Place new gasket on center plate and install differential assembly, longer axle in down position. Be sure gear on shifter shaft is on shaft.

(i) Install gear case dowel pins. Leave dowel pins slightly exposed on top to locate cover assembly.

(j) Install transaxle cover assembly, and secure with eight (8) cap screws.

(k) Install bearings and/or bushings, if necessary. Install seal.

(l) Install axle housing assembly. Fill with 1 1/2 pints S.A.E. EP 90 oil.

(m) Inspection Note: For a neutral position, shift notches in forks and notch in shifter stop must be aligned and centrally located.




Figure 27




Figure 28




Figure 29




Figure 30




Figure 31

DIFFERENTIAL

C. Model 600

1. Disassembly

(a) Drive out roll pin that secures drive pin with suitable driver.

(b) Remove drive pin.




Figure 32

(c) Thrust washers must be removed before attempting to remove the pinions. Remove bevel pinions simultaneously by rotating the gears in opposite directions; gears will move out of position.




Figure 33

(d) Drive out double roll pin and slide axle out. On roll pin drive types, drive the bevel gears from the axle. See Figure 34.

(e) On double "D" type drives, remove snap ring, bevel gear and thrust washer. Slide axle out. See Figure 36.

(f) Inspect bushings and gears for wear and replace when necessary.




Figure 34

2. Reassembly of Differential Assembly

(a) Place axles (left and right) into differential gear assembly. Install thrust washers.

Note: The axles differ in length so select the proper axle.

(b) On roll pin drive models, install double roll pins into holes in each shaft. Place bevel gears on shaft. Roll pins fit into the recess in back of the gears, bevel gears must be seated tightly on the roll pins or binding will occur. See Figure 35




Figure 35

(c) On double "D" type drives, place bevel gears on the shaft and install snap ring in groove on the shaft. See Figure 36

(d) Install bevel pinions **SIMULTANEOUSLY FROM OPPOSITE SIDES** by rotating pinions in opposite directions while sliding into position in gear assembly. See Figure 33. Check alignment by inserting fingers into drive pin holes. If not aligned, drive pin cannot be inserted. Remove and replace bevel pinions as only one tooth out of position will cause misalignment.

(e) After aligning, insert thrust washers behind each pinion. Insert drive pin and secure with roll pin.




Figure 36

A. SHIFT LEVER ASSEMBLY

1. General

(a) Prior to removing a shift lever assembly from a transaxle, make note of the position of the shift lever so that it may be assembled correctly to the shift lever housing.

(b) Move the shift lever to Neutral, if possible, before removing it from the transaxle. Clean around the lever housing to prevent dirt from falling into the transaxle. Cover this opening, if possible.




Figure 37

2. Disassembly

(a) Place the shift lever in a vise so that the shift lever housing is at least one inch from the top of the vise jaws.

(b) Dowel Pin Type. Locate the dowel pin holding the retainer in the housing from the outside (Fig.38). Place a 1/4" flat face punch on the gasket surface directly over the dowel pin. Strike the punch sharply but lightly with a hammer to dislodge the retainer from the shift lever housing. Always use a new dowel pin for reassembly.

Snap Ring Type. Use the proper compressing type tool for removing the snap ring. Loosen the vise and disassemble the pieces (Fig 39).




Figure 38 Dowel Pin Type Shift Lever

- (c) Remove the shift lever from the shift lever housing. Examine the roll pin in the ball of the shift lever, (Fig.38) if bent or worn, replace. When inserting a new roll pin in the ball, position so that equal lengths protrude from both sides of the ball.
- (d) Oil leakage past the point where the shift lever enters the shift lever housing will require replacement of the quad ring seal in the shift lever housing.
- (e) Prior to reassembly, be sure that bends in the shift lever correspond to the mounting on the vehicle.




Figure 39 Snap Ring Type Shift Lever

3. Reassembly

- (a) Dowel Pin Type. Secure with a new dowel pin. A second dowel pin is used in some assemblies for alignment. This dowel pin is located in the gasket surface of the shift lever housing and fits into a mating hole in the transaxle.




Figure 40 Three Stop Three-Speed Transaxle Shifter Rod and Fork Assembly

- (b) Snap Ring Type. Secure parts with the snap ring. Before installing the shift lever and housing to the transaxle housing, check the shifting forks for Neutral position.
- (c) Always use new gaskets between the shift lever housing and the transaxle.

C. SHIFTING ASSEMBLY

1. General

- (a) Shifting assemblies are removed from and installed into transaxles by squeezing the top end of the shifter rods. This causes a binding that retains all parts during removal or installation.




Figure 41 Four Stop, Three-Speed and Four-Speed Transaxle Shifter and Fork Assembly

2. Disassembly

Follow the illustrations in order. Figs. 46, 45, 44, 43, 42, 41. Prior to disassembly compare the assembly with the illustrations. This will aid during the reassembly.

3. Inspection

- (a) Replace the shifter stop if worn or damaged.
- (b) Examine the teeth and internal splines of the two shifter gears. Replace damaged gears. The gears must slide freely on the shifter shaft. Excessive wear of the internal spline in the gears will create cocking and difficult shifting. Replace the gear if this condition is present.
- (c) Replace the shifter shaft needle bearing if wear is evident. Replace if the bearing surface of this shaft should it be scuffed, pitted or worn to a diameter less than .750".
- (d) Replace other parts showing wear, looseness, cracks, etc.




Figure 42 Assemble Shifter Forks to Shifter Rods




Figure 43 Shifter Forks and Rods Positioned In Neutral

4. Assembly

- (a) Reassemble the shifting assembly by following the illustrations beginning with Figure 41 through 46. Pay particular attention to either Figure 39 or 40 during the reassembly of the shifter forks and shifter rods. Lay the parts on the bench in the same manner as illustrated in Figure 39 or 40 on a clean paper or shop cloth. Pay particular attention to the annular grooves in the shifter rods and the snap ring.




Figure 44 Two Flanged Gears onto Shifter Shaft

- (1) Assemble the shifter forks to the shifter rods as illustrated in Fig. 41. The shifter forks are interchangeable.
- (2) Refer to Fig. 41. Slide the shifter fork onto the shifter rod until it comes to the hole with the indexing ball and spring. With a flat blade screw driver press the indexing ball into the hole and move the shifting fork completely onto the shifter rod.




Figure 45 Assembling Shift Fork, Gears and Shaft Assemblies




Figure 46 Positioning Shifter Stop




Figure 47 Final Assembly

- (3) Move the shifting fork to the Neutral position. The neutral groove is the center groove. If the shifter rod has four grooves, the neutral groove is the second groove from the shortest end. This neutral groove can be seen through the hole in the shifter fork. See Figures 39 and 40, the arrow from the "Neutral Groove" is passing through the hole for view.
- (4) When the shifter forks are properly assembled to the shifter rods and positioned in neutral, the ends of the notches in the shifter forks are in alignment. (Figure 47).

(b) Assemble the two flanged gears onto the shifter shaft. (Figure 43) Note that the large gear is placed on the shaft first with the flange side toward the needle bearing in the end of the shifter shaft. Slide on the smaller gear with the flange toward that of the larger gear. (Figure 43,44).

(c) When assembling the shifter fork and rod to the flanged gears on the shifter shaft, Figure 45, that shifter fork which is on shifter rod "A" always engages in flange in the larger gear. To determine which is shifter rod "A" compare the parts to illustrations. Figure 39 and 40. Hold the shifter shaft in the hand as illustrated (Figure 43) during assembly.

- (d) After the shifter fork and rod assemblies have been engaged with the flanged gears allow the shifter rods to lay open in the hand and position the shifter stop. (Figure 45). The notch in the shifter stop is the guide for correct positioning. Align this notch with the corresponding notches in the shifter forks and insert the shifter stop. Move the shifter rods together, (Figure 46) and insert into the transaxle. Remember to squeeze the ends of the shifter rods to cause the assembly to bind and stay together.

(e) In three speed transaxles the needle bearing end is inserted first into the case to engage the end of input shaft.

(f) When placing the shifting assembly in into the four speed transaxle be sure the thrust washer is on the bearing. Place the assembly into the transaxle with the needle bearing end of the shifter shaft up. Allow the end of the shifter shaft to protrude below the ends of the shifter rods, this will ease the alignment of the assembly.

(g) The shifter assembly is correctly installed in the transaxle if the notches in the shifter forks are just about in the center of the opening in the case or cover of the transaxle.

ASSEMBLY OF TRANSAXLE

Care should be taken when reassembling the transaxle to the frame of the tractor not to damage the brake band and brake rod. The following sequence of steps should be followed:

1. Standing at the rear of the tractor:
Hold the transaxle with the brake drum on the left and the shift lever up, tilt the right end of the transaxle up slightly and slide it to the right allowing the shift lever to pass through the hole in the frame. The brake drum should fit inside the brake band.
2. Reassemble 2 "U" brackets (one on each end of axle shaft) to frame and fasten to frame with 4 washers and nuts.
3. Fasten 1602064 bracket to frame and transaxle with 3 capscrews, washers, and nuts the long side of the bracket should extend down and rearward from the bottom of the frame.
4. Slide a wheel spacer on each end of the transaxle. Assemble wheels on axle and assemble snap ring in groove outside of each wheel. Replace hub caps. Note: Wheel width of rear wheels can be changed by reversing the face of the wheel hub on the axle.
If both wheels are assembled with deep dish side of hub toward the transaxle a narrow stance can be obtained.
5. Install transmission drive belts.
6. Adjust brake and clutch per this manual page 8

LIFT LEVER KIT

Assembly

The Lift Lever Kit is necessary if you wish to mount the 36" Snow Plow and Dozer Blade to your B-206 Tractor. To assemble on B-206 Tractor, proceed as follows:

1. Assemble quadrant to tractor frame by inserting hub of quadrant into hole on right side of frame below B-206 decal with the flange up and out from tractor. Fasten quadrant to frame by inserting two capscrews into two holes through the quadrant and frame. Fasten each cap-screw with a lockwasher under each hex nut.
2. Put handle grip onto Lift Lever.
3. Slide Lift Lever shaft into hole in quadrant and through the frame.

4. Assemble Lift Arm Assembly with the headed pin toward the Lift Lever. The Spindle Collar should slide onto the end of the Lift Lever Shaft. Align the holes in the spindle collar and lift lever shaft. Insert the grooved pin through the spindle collar hole.
5. The remaining washer and quick pin are assembled on the headed pin of the lift arm assembly when attaching the Dozer Blade.




FIG. 48

36" Snow Plow and Dozer Blade

Attaching the Blade

The Blade is attached to the B-206 Tractor by means of the Blade Support Plate which comes with the Blade Assembly Kit. For effective operation, the Lift Lever Kit is required when the Blade is used.

Mount the Blade Support Plate to the front of the tractor with the (3) three bolts, lockwashers and nuts provided. Once the plate is secured, align the holes of the Push Bar Assembly with the holes in the Blade Support Plate and connect with the Pivot Bar. Make sure that the Pivot Bar is secured with the Quick Pins on both sides of the Push Bar.

Now align the holes in the Lift Rod Yoke with the hole in the upper right arm of the Push Bar Assembly, insert Yoke Pin and lock in with the Quick Pin.

Put the rear end of the Lift Rod through the hole in the Lift Lever and lock in with the washer and Quick Pin. The blade is ready to use.




Fig. 49

Blade Adjustment

The blade is adjustable to (5) angle positions: straight ahead, 2 positions to the left and 2 positions to the right. To position the Blade, remove the Pivot Pin, swing Blade to desired position and replace Pivot Pin.

To adjust the Blade lift height, pull the Quick Pin from the Yoke Pin, remove the Yoke Pin, loosen the Jam Nut on the Lift Rod and turn the Yoke clockwise to raise or counter-clockwise to lower. Tighten the Jam Nut back up to the Yoke and fasten the Lift Rod back up with Yoke Pin and Quick Pin.




FIG. 50

The Blade can be adjusted to operate at three different heights. To change the operating height, remove two bolts holding each shoe assembly and reassemble the shoes to another pair of holes in the Blade. Lowering the shoe assembly on the Blade will raise the operating height of the Blade and vice versa.

NOTE: When using the Blade for plowing snow, added traction can be obtained by using Wheel Weights and Tire Chains.

26" Rotary Mower

The B-206 Lawn and Garden Tractor is equipped so that the Rotary Mower can be attached with ease.

The mower comes assembled and has all the necessary hardware included so that it can be attached to the tractor.

Blade Installation

When installing a mower blade, observe that blade tips are up and bolt is securely tightened.

Attaching the Mower

To attach the mower to the tractor, first park the tractor on level ground. Move the P.T.O. Lever to the "Disengaged" (rear) position. Put the mower down on the right side of the tractor so that it faces perpendicularly away from the tractor (Fig. 51). Turn the front wheels of the tractor hard to the left to give a clear access to the underneath. Push the mower straight in under the tractor to the point where it can be turned 90° to face in the same direction as the tractor (Figure 52).




FIG. 51

Once the Mower is aligned into position the Mower Drive Belt must be connected.

The mower drive belt must be looped up and over the two power takeoff (P.T.O.) pulleys. The belt must be twisted slightly so that it will pass between the outside lip of the pulley and the belt retainers. Next, run the belt over the center crossbar (between the crossbar and the retainer loop—Fig 53). and connect it around the Engine Pulley (Fig 53). This satisfies the power hookup for the mower.

Now the Mower Brake Lever must be connected. This is done by putting the stud of the Guide Assy. through the hole in the Mower Brake Arm and securing with the flat washer and hair cotter pin provided (Figure 54).

Now lift the front of the mower up and back so that the lock studs on each side of the Mower Arm will drop down into the slots of the Mower Quick-Disconnect Assembly, (Fig. 52)




FIG. 52

Put the MOWER TRANSPORT LIFT HANDLE attached to the MOWER LIFT CHAIN up through the hole in the frame and screw the KNOB provided onto the HANDLE. The Mower can now be raised or lowered from the operator's seat. (Fig. 53).

Leveling the Mower

Rotate the blade to the front and engage the PTO Control Lever. Measure the distance from the floor to the bottom of the blade tips both at the front and at the rear. The front blade tip should be approximately 1/8" lower (nearer the floor) than the rear tip.

To raise the blade tip at the front, turn the Yokes on the Adjusting Rods clockwise (counterclockwise to lower) (Fig 51).




FIG. 53

Once the front blade tip is in adjustment, disengage PTO Control Lever, rotate the blade 90° (tips of blade pointing to tractor sides) and then engage PTO Control Lever. Measure the distance from the floor to the blade tips. The measurements should be the same within 1/8".

Adjusting the Mower Brake

Position the brake so that the face touches both tips of pulley, then tighten the two (2) bolts holding the Brake Bracket to the Mower Housing (Fig. 51).

Engage the PTO Control Lever and pull the Brake Assembly into the disengaged position. Move the rear Set Collar up against back face of the Guide Assembly and lock into place with the Setscrew. Now position the front Set Collar approximately 1/8" to 3/16" out in front of the Guide Assembly and lock it into place with the Setscrew. Be sure that the Setscrews in the Set Collars are positioned out to the side (Fig. 54).




FIG. 54

MOWER SPECIFICATIONS

Blade-----Single Blade

Width of Cut----- 26"

Mower Brake-Positive Stop PTO Activated from Seat.

Cutting Heights----- 1" - 3"

Mower Blade- Clutch Mounted for Protection from Internal Damage

Mower Mounting-----Quick Attach to Front Axle




FIG. 55

Mower Arbor Tube Assembly (Fig. 55)
Should it be necessary, the following steps for assembling the Mower Arbor Tube Assembly should be followed.

1. Press 1601505 Bearing, with shield side out flush against upper shoulder of 1602259 Tube Arbor Assy. (Use equal pressure on inner and outer races of bearings).
2. Insert 1602265 Spacer into center of 1602259 Tube-Arbor Assy.
3. With the upper bearing resting on both inner and outer races, press 1601505 Bearing, with shield side out, flush against lower end of 1602265 spacer. (Use Equal pressure on inner and outer races of bearing).

Seat Adjustment

The seat may be adjusted to three positions front to back. Follow the steps outlined below: (Fig. 56, & 57).

1. Untie the string at right rear of seat and lift seat cushion from seat pan.
2. Loosen and remove four nuts and screws underneath frame holding seat pan.
3. Slide seat pan so that four holes for desired seat position line up with holes in frame.

4. Replace four screws and nuts and tighten.
5. Replace seat cushion on seat pan and tie securely.




FIG. 56






FIG. 57

Two Speed Pulley

A. Removing Pulley Kit from the tractor:

1. Block up the rear of the tractor and remove the right rear wheel. Fig. 1.
2. Remove the Shift Fork Assembly by removing the locknut and long pivot bolt.
3. Next remove the capscrews holding the support to the drawbar and seat support. The support, pivot bracket and stop can now be removed from the tractor in one piece.
4. Disconnect the spring from the belt idler arm and remove the belt from the pulley.
5. Shift the pulley assembly into low range by grasping the shift ring with both hands and pulling out.
6. Rotate the shift ring and cover assemblies until the setscrew over the shaft keyway is aligned with one of the holes in the pulley hub. Loosen setscrew. The other setscrew in the collar need not be loosened at this point as it merely holds the collar in position on the Spider Assembly. Fig. 2.

Slide the Pulley Kit off the transmission shaft.




B. Disassembly of Pulley Kit


1. Place pulley kit in a vise with pulley side up. Clamp lightly on outer cover assembly so as not to deform the cover. Fig. 3.
2. Before attempting to remove the set collar, back the long setscrew out a few more turns to make sure it is not engaging the hole in the shaft. Loosen second setscrew and remove the set collar and pulley assembly by lifting upward. Fig. 4.



3. Remove the six flange nuts and cap-screws holding the two cover assemblies, ring gear and shift ring together. Carefully lift the L.H. (inner) cover assembly and shift ring so as not to tear the gaskets. Fig. 5.



4. To remove the R.H. (outer) cover assembly from the Spider Assembly, grasp the spider shaft in the left hand and hold the cover a couple inches above a bench. Insert a bar into the spider shaft bore and drive the cover out of Spider Assembly. Fig. 6.




5. The ring gear and pinions can be disassembled by removing the three locknuts that hold the ring assembly and pinions to the spider. Fig. 7.
6. Thoroughly clean and inspect all parts. Replace bearings, gears and other parts that are excessively worn.




C. Assembly & Lubrication

1. Place Ring Assembly on a flat surface with studs pointing up. Fig. 8.
2. Install three spacers and three pinions on studs. Apply a small quantity of Shell Durina EP #1 grease to bore and sides of pinions before placing over the spacers.
3. Place ring gear on ring assembly and engage with pinion gears.



4. Attach Spider Assembly to Ring Assembly with three locknuts and torque to 15 ft/lbs. Fig. 9.




D. Replacement of Bronze Bearings to Spider Assembly


Place the Spider in press and install the long 1601460 bearing. Bearing should be pressed into the bore $.598 \pm .001$ inches from the end of the hub. A special pressing tool must be made for this operation in order to obtain the required dimension. Illustration 1, Step 1.

Insert the 1601461 Snap Ring and press the short 1601459 bearing flush with the spider hub. The snap ring must be free to expand and not pressed tight between the two bearings. Illustration 1, Step 2.


NOTE: If pressing equipment is not available, it is recommended that the entire Spider and Bearing Assembly be replaced rather than attempting to replace the bearings.




5. Apply Shell Durina EP #1 grease liberally to the area around the gears and in the bore of the spider. Fig. 10.



6. Place one gasket on the R.H. Cover Assembly and press the Spider Assembly on to the Cover Assembly until the snap ring engages the first detent groove. Fig. 11.
7. Clamp the Cover Assembly in a vise and align the holes. Place the second gasket on the Ring Gear and align holes.





8. Place shift ring on the ring gear and align holes. Fig. 12.




E. Installation of Needle Bearing in Pulley and Gear Assembly

9. Place pulley on a solid surface or in a press and install one needle bearing with marked end out. Press bearing flush with surface of pulley hub. Turn pulley over and press the second bearing flush with hub. Marked end of bearing should also be out. Illustration 2.
10. Work grease into needles of both bearings and fill the area between the bearings with grease to the approximate thickness of the bearings. Fig. 13.
11. With Pulley Assembly resting on bench, place the L.H. Cover Assembly on the pulley and position the third gasket on the cover. Fig. 13.




12. Holding the Pulley and L.H. Cover Assemblies together, place on top of Shift Ring. Carefully align pulley gears with pinions in the Spider Assembly. Align holes in cover before engaging gear teeth. Fig. 14.
13. Install six capscrews with heads toward pulley. Assemble nuts to screws and turn finger tight but do not tighten. Holding Cover Assemblies, turn the pulley in both directions to center gears. Tighten nuts to 75 inch pounds in 180° sequence.

NOTE: If pulley seems locked and will not turn, the Spider Assembly may have slipped out of low detent. If this has occurred, the unit will have to be disassembled and step six repeated.



14. If pulley turns freely and no binding exists, the set collar may be installed. Turn pulley until one hole in the hub aligns with the keyway in the spider shaft. Place the set collar over the shaft with the setscrews angled toward the pulley hole. Turn the long setscrew until end just protrudes into hole in shaft. Turn pulley until hole in pulley hub lines up with the short setscrew in collar. Tighten this setscrew securely to the shaft. Fig. 15.



15. Install on tractor, reversing steps 1-6 in Disassembly (Section A).

VARIABLE SPEED PULLEY For B-112 Tractor




FIGURE 1

DISASSEMBLY

The variable speed pulley is designed to provide easy access to all parts. To replace the bearing assembly or bushing in the pulleys, observe the following steps:

1. Remove the drive belt.
2. Remove the locknut on the pulley shaft.
3. On the rear pulley it will be necessary to remove transmission fork assembly.
4. Remove pulley halves and bearing assembly.

5. Inspect and replace teflon bushing and bearing assembly if necessary.

NOTE: The bearing and bearing retainer are serviced assembled with "Loctite".

6. Clean all parts, lightly oil the teflon bushing and reassemble pulleys.

7. Do not exceed 50 lb. torque on the locknut when reassembling. Over-torquing will cause the pulley halves to bind.

TURNBUCKLE REMOVAL

A. Remove the 3/8" nut and bolt from the arm and rocker assembly, reference letter "A", Fig. 2.

B. Remove the locknuts, reference letter "B", Fig. 2 and lift out bolt and rocker assembly.




FIGURE 2

C. Remove the transmission fork assembly and turnbuckle as follows:

1. Adjust the turnbuckle so that holes of the eyebolts are parallel. The distance between the holes is 6-13/32". Note that one end of the turnbuckle body is grooved to identify the R.H. thread end. The grooved end should be

placed forward when assembling in the tractor. Assemble both eyebolts with the same length of threads engaged in the turnbuckle. (See Fig. 2.)

2. Install the turnbuckle assembly.

IMPORTANT: After tightening the locknuts, reference letter "B", Fig. 2, insure that there is free movement of the fork assemblies.

CLUTCH - BRAKE & BELT ADJUSTMENT

The variable speed mechanism is adjusted at the factory under "no load" conditions. In most instances, this adjustment should provide satisfactory operation. If, however, under load or after the "break-in" period, erratic or improper operation is noted, follow the procedures outlined below to make necessary adjustments.

NOTE: All adjustments require the variable speed lever to be placed in the "High" or the "Low" position. Carefully observe which position the variable speed lever should be placed in before making each adjustment. **DO NOT ATTEMPT TO MOVE VARIABLE SPEED LEVER WHEN ENGINE IS NOT RUNNING OR WHEN CLUTCH PEDAL IS DE-PRESSED.**

CHECK THE FOLLOWING ASSEMBLY ADJUSTMENTS

1. Check bolt and locknut holding arm assembly to rocker arm. (See No. 1.) (This adjustment to be made in "High" speed position.)
2. Check for proper clearance on front belt guard. (See No. 2.) (This adjustment to be made in "High" speed position.)
3. Check for proper clearance of idler pulley belt stop. (See No. 3.) (This adjustment to be made in "Low" speed position.)
4. Check for proper clearance between the nuts on clutch rod and the set collar. (See No. 4.) (This adjustment to be made in the "Low" speed position.)
5. With variable speed lever in the "Low" speed position, the belt in the large, rear pulley should be approximately 1/8" below the top of pulley. (See No. 5.)
6. Check brake adjustment. (See No. 6.) (This adjustment to be made in "Low" speed position.)

OPERATING INSTRUCTIONS

1. Do not attempt to move variable speed lever when tractor engine is not running or when clutch pedal is depressed.
2. Insure that parking brake is fully disengaged before placing tractor in motion.
3. Occasionally check and remove foreign objects and debris from variable speed belt and pulleys.

GEAR RANGE AND SPEED SELECTIONS

1. To obtain the most desirable results with various attachments on the Sovereign Tractor, it is recommended the tractor engine be operated at 3/4 to full throttle setting.
2. When operating attachments such as the 10" Plow, Spring Tooth Harrow or Cultivator, which place a heavy draw-bar load on the tractor, it is preferable to operate tractor in I or II speed rather than III speed, low range.

BELT SLIPPAGE

If belt slippage is noted, check the following:

1. Check to insure the parking brake is fully disengaged.
2. Check No. 4 under Assembly Adjustments.
3. Check No. 5 under Assembly Adjustments.
4. On early production models the spring is normally in the top hole. If less spring tension is desired, move spring to next lowest hole of pivot lever assembly. Less tension can be used when mowing on level terrain and if clutch pedal is found to be uncomfortably hard for the operator to depress. (See Fig. 3.) Greater belt tension is necessary to prevent variable speed belt from slipping when tractor and attachment are under heavy load. A slight chattering of the variable speed belt on the pulleys will be noticeable until the belt loses its stickiness and becomes smooth.

On later production models no further spring adjustment is necessary.

LUBRICATION

If sliding pulley halves stick, lubricate bushing on which pulley rides lightly with a few drops of oil. Excessive lubrication will tend to collect dirt and dust and tend to hamper operation. Also lubricate all clutch and brake lever pivot points and all places where pull rods or links join levers.




FIGURE 3



INDEX



WIRING DIAGRAM



B-SERIES LIGHTING CIRCUIT.....	F-1
B-10 & Big TEN ELECTRIC	F-1
STATER & GENERATOR	
B-1 ELECTRIC STATER & GENERATOR	F-2
B-1, B-10, Big TEN LIGHTING CIRCUIT	F-2
B-10, B-12 LIGHTING CIRCUIT	F-3
B-10, Big TEN FRONT LIGHTS	F-3
B-1, FRONT LIGHTS.....	F-4
B-1, B-10, Big TEN REAR LIGHTS	F-4
B-110, B-112, HB-112 WIRING DIAGRAM	
KEY & PUSH BUTTON START	F-5
B-206 WIRING DIAGRAM.....	F-6
B-207, B-208, B-210, B-212, HB-212	
WIRING DIAGRAM	F-6


F

THIS PAGE INTENTIONALLY BLANK











ELECTRIC LIGHT (Front) (B-1)




ELECTRIC LIGHT (Rear) (B-1, B-10, Big Ten)

WIRING DIAGRAM
MODEL B-110, B-112, HB-112




KEY START MODELS




PUSH-BUTTON START MODELS


WIRING DIAGRAM B-206



WIRING DIAGRAM B-207, B-208, B-210, B-212, HB-212



KEY START MODELS



PUSH-BUTTON START MODELS

B - SERIES ATTACHMENTS

INDEX

CENTER P.T.O.	A
HI-LOW RANGE	B
ROTARY MOWERS	C
REEL MOWERS	D
SICKLE BAR MOWER	E
ROTARY TILLER	F
SNOW THROWER	G
GRADER BLADES	H
HITCH ADAPTER	I
PLOW - 10"	J
DISC HARROW, 8-12"	K
SPRING TOOTH HARROW & CULTIVATOR	L
LAWN ROLLER	M
MOBILE GENERATOR	N
SUMMER CAB	O
VACUUM COLLECTOR & TRAILER FRAME	P
FORK LIFT & LOADER	Q
L-12 LOADER	R

G



THIS PAGE INTENTIONALLY BLANK




FIG. 1

POWER TAKE-OFF KIT

For operation of Rotary Mower and Sickle bar attachments, a power take-off attachment is required. This consists of the power take-off assembly, "V" pulley for bevel gear shaft, drive belt, belt guard and belt stop packaged in one carton.

For ease of attachment follow the steps outlined.

1. Install belt stop (2025718)
2. Mount belt guard support to inside surface of side plate nearest drive pulley.
3. Holding the P.T.O. assembly in L.H. (Fig. 2) position the tube of the drive bracket assembly between the bevel gear housing side plates. Align the holes in the side plates with the hole in drive bracket assembly tube and insert pivot pin through holes in side plates and drive bracket assembly tube, so the cotter key hole in pin lines up at "A". (Fig. 3)
4. Remove hex capscrew "D" from frame of tractor and mount bracket in place on left lever quadrant (Fig. 4). Position the pivot bar assembly flush against bottom of left quadrant and reinstall the hex capscrew and tighten securely. Check alignment of drive pulley on bevel gear shaft, driven pulley of P.T.O. and idler pulley and adjust driving pulley if necessary.
5. Mount drive pulley to shaft of bevel gear assembly (Fig. 1). Hub of drive pulley is to face




FIG. 2




FIG. 3




FIG. 4

inward. Place the drive on drive pulley and P.T.O. pulley. Align belt and secure in place with key and setscrew.

6. Attach the belt guard to the guard support as shown in Fig. 1. Allow approximately $3/16$ " clearance between belt and guard.

7. Remove front hex capscrew from pull bar and replace with stud #2026431 provided, short end inserted. Slip on handle assembly and tighten with locknut provided to allow free handle movement. Mount bolt in place on drive pulley (Fig. 5) and attach spring to hole provided in bottom of bracket assembly. Mount belt stop as shown with $3/8$ " bolt, flat washer, lockwasher and hex nut. When implement is attached to tractor and P.T.O. is engaged, $1/8$ " clearance between belt stop and back of belt is required.

LUBRICATION

The P.T.O. is lubricated by means of one grease fitting located on the bottom front of the drive bracket assembly. Occasionally apply grease by means of a standard grease gun loaded with automotive type grease. Be sure to wipe dirt and grit from grease fitting before applying grease gun. Lubricate all pivot points and idler pulley bearings with SAE 20 oil every few hours of operation.

OPERATION

Operation of the P.T.O. is controlled by movement of the clutch lever assembly. (See Fig. 4). When the clutch lever is in the forward raised position, the clutch rod releases the tension holding the idler pulley against the drive belt and power will not be transmitted to the driven pulley of the P.T.O. assembly. When the clutch lever is in the back, depressed position, the clutch rod applies tension to the idler pulley and as the idler pulley takes-up the slack in the drive belt, power is transmitted from the drive pulley on bevel gear box shaft to the driven pulley of the P.T.O. Fig. 4 shown clutch lever in drive position.

ADJUSTMENT

At points "A" and "B" of Fig. 4, check tightness





FIG. 5

of hex nut to be sure that clutch lever assembly and clutch rod are free to pivot without binding.

Place clutch lever in "drive" position and observe clearance between collar "C" (Fig. 4) and end of bracket. When implement is attached to tractor, this clearance should normally be approximately $3/4$ "; at this setting the idler pulley should be snugly against the drive belt. If additional tension is required, release clutch lever and loosen setscrew on collar and slide collar farther back on clutch rod. Retighten setscrew in collar and put clutch lever in drive position. Recheck clearance. The tension of the idler pulley against the drive belt must be sufficient to operate whichever tractor attachment is being used. Any additional tension is unnecessary and will only cause premature failure of belts and idler pulley bearings.



POWER TAKE-OFF
B-1 & B-10 Tractor


BUSHING REPLACEMENT

1. Remove pivot rod.
2. Drive out old bushings using driver large enough to contact bushing evenly.
3. Drive in new bushings. Be careful not to distort them.
4. Reinsert pivot rod.

BEARING REPLACEMENT

1. Remove pulleys from each end of P.T.O. shaft.

2. Remove P.T.O. shaft.
3. Drive out old bearings.
4. Insert new bearings being careful not to distort them.
5. Replace P.T.O. shaft.
6. Grease well with general purpose gun grease.
7. Replace pulleys back on shaft.




POWER TAKE-OFF
Big Ten Tractor (B-10, B-12)

BEARING REPLACEMENT


1. Remove U-bolt and remove bearing and pulley assembly from unit.
2. Remove P.T.O. pulley.
3. Remove P.T.O. shaft assembly.
4. Remove old bearings.
5. Install new bearings being careful not to distort them.
6. Reinstall P.T.O. shaft and P.T.O. pulley.
7. Grease well with general purpose gun grease.
8. Reinstall unit on tractor.

B-10 (9 H.P. - S/N 15001 - 31227) CENTER P.T.O. CATALOG NO. 2025045



B-10 (9HP S/N 15001 - 31227) Center P.T.O.

BIG TEN, B-10 (10 H.P.) AND B-12 CENTER P.T.O. CATALOG NO. 2025062



Big Ten, B-10 (10HP) And B-12 Center P.T.O.

This information shows each center P.T.O. package, pulley part numbers and diameters and

belt numbers and lengths. The belt lengths are then measured around the outer circumference.




FIG. 1




FIG. 2

ASSEMBLY AND INSTALLATION

1. Depress the clutch and brake pedal and apply the parking brake.
2. Remove the belt from the transmission pulley.
3. Remove the transmission pulley and key from the transmission shaft.
4. Place the drive belt around the transmission shaft close to the transmission case.
5. Install the two belt stop fingers as indicated in Fig. 1.
6. Install the two-speed pulley key in place in the transmission shaft.
7. Attach the two-speed pulley and gear case to the transmission shaft. Place the drive belt around the pulley and loosen the parking brake. Align the two-speed pulley with the idler pulley and the bevel gear housing pulley.
8. Tighten the setscrew on the key and then the other setscrew 90° away.
9. Remove the clutch hand brake spring from the cap screw on the transmission.
10. Remove this cap screw from the transmission case and also the other upper cap screw from the transmission case.
11. Insert the two long studs into the vacant cap screw holes in the upper end of the transmission case. Put the shifter handle assembly in place on these two long studs, making sure that the two pivots are properly positioned over the outer rim of the shift-ring. Refer to Fig. 3. Secure with hex nuts and lockwashers.





FIG. 3

12. Remove the cap screw from the right side of the tractor frame above the parking brake. Use this screw to attach the shift lever bracket as shown in Fig. 3. Align to permit proper movement of the shift lever and then tighten in place.
13. Secure all bolts and nuts tightly. Check the clearance between the belt and the belt-stop fingers. When the belt is engaged, the clearance should be 1/16".
14. Reinstall the clutch and brake spring on the bracket. (Refer to Fig. 1).
15. Make sure that the stop plate (Fig. 3) is positioned next to the two-speed pulley gear case. Approximately 1/16" clearance is required between the stop plate end cover. With this minimum clearance the stop plate will lodge properly between the nuts.

NOTE: For purposes of illustration only, the tractor is shown with the wheel removed. It is not necessary to remove wheel to install the two-speed pulley assembly.



TWO-SPEED PULLEY

TWO-SPEED PULLEY

1. Remove unit from tractor by removing two capscrews from the shaft support assembly.
2. Remove the 6 bolts holding the cover assembly together.
3. Remove the pulley gear assembly.
4. Separate cover assembly, remove shift ring.
5. Remove ring gear and spider assembly from R.H. cover by inserting a shaft and gently tapping.
6. Disassemble pinions by removing locknut on ring pin bolts.
7. Clean and inspect for excessive wear.
8. Replace necessary parts.
9. Reassemble pinion and ring gear assembly and place in cover assembly.
10. Replace shift ring on cover.
11. Place cover assembly halves together, insert pulley gear assembly.
12. Bolt halves together alternating thick and thin attaching nuts.
13. Replace unit on tractor. Tightening securely setscrews holding unit to shaft.

ROTARY MOWER




FIG. 1

ROTARY MOWER

ADJUSTMENT (Fig. 1)

1. Before the mower is attached to tractor, both clevises should be adjusted until the distance between the locknut and the head of the bolt is 1-1/2". This will position the front worker arms level or equi-distant from the floor.


2. Attach mower to tractor.

3. Lower mower to floor. Set the mower to the lowest cutting height by turning the adjusting screw handles to prevent possible distortion of lift linkage and to better stabilize cutting height adjustment. Counter-clockwise will lower the mower and clockwise will raise the mower. Rotate the center blade to the front and measure the distance from its front tip to the floor. Then rotate each of the side blades so the tip can be measured at the rear. The front blade should be adjusted 1/2" higher than the rear of the side blades. This can be done by removing the pins

and lengthening the clevises at the front mount to raise the front of the mower and shorten the front of the mower.

4. With the height adjusting screws and the mower at its lowest position, rotate the side blades and measure from the outside tips to the floor. This should measure the same on both sides. If one side is lower, the clevis on the front mount on that side should be lengthened slightly. With the adjustment properly made, it will aid the cutting height adjusting screws to keep the unit level.

5. Set the mower to the top of the cutting height adjustment. On the units with two adjusting screws at the roller, use caution and see that they hold the unit level. They must be adjusted the same amount of turns each time the cutting height is changed. Because of the linkage at the front mounting points, the mower will maintain the fore and aft adjustment. Start the mowing operation with a long or high stubble. Lower the mower evenly to the desired cut. If at first the cut is too high, the area can be removed.




BAIL ASSEMBLY (FIG. 2)
42" Rotary Mower

The mower rocker arms have a spacer where they fasten to the housing. This as well as other

fastening locations may wear after prolonged usage. (See Fig. 2).

ROLLER MAINTENANCE




FRONT ROLLERS (FIG. 3)
1st Type w/Bolted Housing

A. FRONT ROLLERS (Figs. 3 & 4)


1. Remove 2 cotter keys between rollers.
2. Slide shaft to the left. Remove R.H. roller.
3. Slide shaft to right. Remove L.H. roller.

1967 MODEL MOWER (W/Nylon Inserts)



FRONT ROLLERS (FIG. 4)
2nd Type w/Bolted Housing

1. Remove brackets and roller assembly from baffle.
2. Remove cotter keys from between rollers. Remove rollers. Shaft is welded into R. H. bracket.



REAR ROLLER ASSEMBLY (FIG. 5)
42" Rotary Mower

B. REAR ROLLERS (Fig. 5)

1. Remove cotter keys from each end.
2. Remove washers and rollers from shaft. In later models, the shaft is welded in the lift bar on the right side. The lift bar must be removed along with the shaft.


ASSEMBLY PROCEDURE (Left to Right)

1. Cotter Key
2. One large Flat Washer
3. Large Roller
4. Three Small Washers
5. Lift Brace
6. Five Flat Washers
7. Large Roller

8. One Flat Washer
9. Small Roller
10. Flat Washer
11. Large Roller
12. Five Flat Washers
13. Lift Bar
14. Three Small Washers
15. Large Roller
16. One Flat Washer
17. One Cotter Key

The groups of 5 flatwashers are spacers. Some units may contain less washers.

The mower rollers should not require lubrication. However, if they are lubricated oil should not be used. Hydraulic brake fluid should be




DECK ASSEMBLY
1st Type w/Bolted Frame

DECK ASSEMBLY (1st Type)

The deck assembly is serviced in components.

When replacing a part, remove the bolts attaching that part.




DECK ASSEMBLY
2nd Type - 1 Piece Housing

DECK ASSEMBLY (2nd Type)

The housing is available through service parts.

When replacing the housing remove all components from the old and install in the new.



ARBORS (FIG. 6)
42" Rotary Mower

ARBOR SERVICE (Fig. 6)

1. Remove R.H. and L.H. deck covers.
2. Loosen idler pulley. Remove spindle drive belt.
3. Remove 3 bolts holding arbor assembly.
4. Remove entire arbor assembly.
5. Remove lock nut.
6. On the front arbor assembly, remove cross drive pulley and cross drive pulley spacer.
7. Remove arbor pulley.
8. Remove arbor assembly from arbor tube assembly.
9. Remove spacers and bearings from arbor tube assembly.
10. Wash bearings, spacers and tube assembly to remove grit and old grease.
11. Replace bearings if necessary,
12. Pack bearings with grease before installing in arbor tube assembly.




FIG. 7

1. Install the upper bearing "A" so that the green face of the bearing is toward the backing ring "B" in the tube assembly. Use a tube "C" or sleeve to press against the outer race of bearing and press the bearing firmly against the backing ring. (Refer to Fig. 7).

2. Insert a "dummy shaft" "D" through the bore of the upper bearing and invert the tube assembly. Rest the upper bearing "A" on a surface "E" that will give equal support to both the inner race and outer race of the bearing. Refer to Fig. 8.

3. Install the sleeve "F" over the "dummy shaft" and place the lower bearing "G" in position over the "dummy shaft" in the tube assembly. Press the lower bearing into the tube, with the green face of the bearing facing the upper bearing, until the inner race is in firm contact with the end of the sleeve.

NOTE: Use a pressing tool with a .005" counter bore or relief slightly larger than the diameter of inner race, or a cylinder with a .005" shim




FIG. 8

washer to press on outer race only. Press the inner race and outer race at the same time. Refer to Fig. 8. In effect, the pressing tool should push the outer race of the bearing .005" deeper into the tube than the inner race.


4. Remove the "dummy shaft" and install the lower washers on arbor shaft and insert arbor shaft through both bearings. Install the upper washers, key, pulley and hex lock nut.

NOTE: When using a "New" lock nut, tighten to 70 ft. lbs. torque. Use a torque wrench. When using a "Used" locknut, tighten to 45 ft. lbs. torque. If the lock nut has been tightened once and then loosened, it is a used lock nut and will require the 45 ft. lbs. torque.


5. When correctly assembled, the arbor shaft can be rotated by a twisting force of approximately 1 inch lb.

NOTE: 1 inch lb. is equal to the force applied by a 1 lb. weight 1 inch from the center line of the arbor shaft.


CROSS DRIVE BELT
42" Rotary Mower



BELT IDLER



SPRING LOADER IDLER



The leaf mulcher attachment is available as a machinery item and its components are available through service parts.

TROUBLE SHOOTING 42" ROTARY MOWER

1. Be sure unit is properly adjusted and attached to tractor.
2. Remove mower from tractor and clean all grass clippings and material from mower housing.
3. Rotate blade and see that all blade ends are level with each other and will cut even and on a horizontal plane.
4. Check blade conditions - may need to be sharpened.
5. Check curved baffle plate to see it is not bent or damaged.
6. Check mower and P.T.O. drive belt for proper adjustments and tension.
7. For some mowing conditions, it may be advisable to use a ground speed reduction group. The 2025005 is a 10" transmission drive pulley and belt available for field installation. The 8" pulley 2025271 with belt 2025492 normally used for the tiller can be obtained from parts.


By slowing the ground speed and maintaining rotor speed will produce better mowing job.

8. Due to the fact the 42" rotary mower is a heavy unit it will tend to ride down the grass stubble and a 2" cut will be very short. The mower is designed to cut from 2" to 3" for lawn work. A better looking lawn and best care for grass is maintained by cutting often and not too short.

9. With the 42" rotary mower working behind the travel of the tractor front wheels, it may be necessary to over-cut the width of the wheel mark in the mowed grass. This would leave no uncut grass for best appearance on estate lawns, etc.

10. If mower is properly adjusted and in apparent good condition, but seems to require excess engine power - Check all blade drive assemblies. The rotor spindles should turn with 1" to 2" lbs. pull. This can be checked by removing mower drive belt shield and drive belt. If this pull is up to 5" lb. or more the unit will rob power from the tractor. Repair or replace necessary parts of the rotor spindle. Tight bearings, bent rotor shaft or spindle housings may be caused by hitting obstructions.

REEL MOWERS



REEL MOWERS

1st Type

PERIODIC SERVICE (1st Type)


1. Remove wheel bolt and washer.
2. Remove wheel assembly.
3. Remove pinion and pawl.
4. Clean pinion, pawl and inside of wheel assembly to remove debris and old grease.

5. Inspect for wear, replace if necessary.

6. Grease well and reassemble.

Clearance between cylinder knives and the stationary knife is adjusted by loosening and tightening the castback regulating setscrew.


Height of cut is regulated by moving the roller and roller brackets up or down.



REEL MOWER HITCH

1st Type

The hitch assembly is serviced by components available through service parts stock.



PERIODIC SERVICE (2nd Type)


1. Remove wheel stud.
2. Remove drive wheel assembly.
3. Remove pinions, pawl and bearing.
4. Clean pinions, pawl and bearing and drive wheel.

5. Inspect, replace if necessary.

6. Grease well and reassemble.

Clearance between lower knife and cutter assembly regulated by adjusting screws in side plates.


Height of cut regulated by roller height.



The hitch assembly is serviced through service parts stock.


E

SICKLE BAR MOWER



FRAME ASSEMBLY (1st Type w/o Cable Lift)
46" Sickle Bar Mower


The idler pulleys contain bearings. During sickle bar service inspect these bearings.




SICKLE (1st Type w/o Cable Lift)
46" Sickle Bar Mower

SICKLE BAR REMOVAL

1. Remove sickle head from the section bar.
2. Slide section bar out through under tractor.




The idler pulleys contain bearings. During sickle bar service, inspect these bearings.



SICKLE BAR REMOVAL

1. Remove sickle head from the section bar.
2. Slide section bar out through under tractor.



DRIVE GROUP (2nd Type w/ Cable Lift Cutter Bar)
46" Sickle Mower

46" SICKLE BAR DRIVE (2nd Type)


1. Remove sickle head from sickle bar.
2. Remove rod ends from sickle head and from rocker arm assembly.
3. Remove rocker arm assembly.
4. Remove pitman clevis assembly.
5. Remove drive pulley.
6. Remove crankshaft.
7. Disassemble pitman bearing and housing.
8. Clean and inspect parts.
9. Replace necessary parts.
10. Oil bearing surfaces before reassembly.

KNIFE CARE


1. Keep knife straight and sections sharp.
2. Sections should be replaced when they are worn or ground down shorter than their original length.
3. Remove knife section by shearing the rivets. Let knife back rest on vise jaw with point of section down. Strike the section a sharp blow with a hammer.
4. Always shear rivets instead of punching them out. Be careful not to enlarge holes in knife back or new rivets will be loose.
5. After shearing, drive the rivets out of knife back (from the sheared end) with a drift punch.
6. Place section on knife back with bevel side up. Insert rivet through knife back and section. Place knife on repair block or anvil with rivet heads down to hold them in place.
7. Expand the rivet with hammer to make it tight, then set the rivet with a rivet set. Check to be sure that the section is tight and rivet heads well formed.
8. After sections have been replaced, check knife for straightness.
9. The value of a sharp knife cannot be over-emphasized. Dull knives cause uneven cutting, clogging, increased draft and excessive mower wear. Remember a tractor doesn't know when a knife is dull, but a team of horses pulling a mower will pretty soon let a farmer know the knife needs sharpening.
10. When sharpening a section, maintain the original width of bevel and angle of shear. A narrow blunt bevel will not shear the stems easily. A wide keen edge nicks too easily.
11. Knife sections should be replaced when they are bent, nicked, worn or ground to a point. Any sharpening after the section is worn to a point reduces its length and its effective cutting surface.

ROTARY TILLER

F



TILLER HOUSING (1st Type)
32" Rotary Tiller




TILLER HOUSING (2nd Type)
32" Rotary Tiller

32" TILLER HOUSING DISASSEMBLY
(1st & 2nd Type)

1. Remove drive pulley.
2. Remove cover shield by removing capscrews.
3. Remove tine assemblies by removing pin and cotter key next to housing.
4. Remove hitch assemblies. Remove lower hitch by taking out the long capscrew, slide the frame assembly forward to clear housing. Remove capscrew from belt tension arm (R.H.) remove lock ring from pivot pin and setscrew. Separate belt tension arm and remove from the housing.
5. Remove bearing collar on chain guard plate assembly side.
6. Remove capscrews and carriage bolt holding plate to chain guard assembly.
7. Remove plate, bearing and gasket. Remove bearing and bearing flanges from plate.
8. Wash entire assembly to remove grease.
9. Remove drive chain by removing it from drive shaft sprocket and then from the sprocket assembly.
10. Remove sprocket assembly from rotor chain. Remove sprocket assembly from housing. Shaft can be pressed out of sprocket.
11. Remove R.H. bearing collar and remove bearing flange.
12. Remove bearing, tine shaft, and rotor chain and sprocket.
13. Inspect chains, sprockets, bearings and bushings for wear. Replace if necessary.

32" TILLER HOUSING ASSEMBLY
(1st & 2nd Type)

1. Install guard assembly bearing.
2. Install tine shaft and drive shaft.
3. Install chains.
4. Install sprocket assembly holding it in place with one capscrew.
5. Install guard spacers using the long capscrews to hold them in place.
6. Grease chain assemblies liberally (use approximately 1.16 of general purpose grease.
7. Reinstall cover plate, being sure the spacers and the sprocket assembly line up correctly.
8. Remove long capscrews.
9. Reinstall belt tension lever assembly, secure pivot pin with lock ring and shaft with setscrew.
10. Reinstall frame assembly with long capscrew. Reinstall long capscrew through housing.
11. Reinstall tine assemblies.
12. Reinstall cover assembly.
13. Reinstall drive pulley.



TINES
32" Rotary Tiller

32" ROTARY TILLER

Disassembly tine sections by removing the four capscrews holding the tines to the plate assembly.


REASSEMBLY

1. Place plate assembly on table with long tube up.
2. Place one tine below the plate on the side nearest you. Point down, pointing to the left. On the side farthest from you, place a tine, point

down, pointing to the right. Hold in place with capscrews.

3. On the left side of the plate assembly, place a tine on the top with the point up pointing away from you. On the right side, place a tine on the top with the point up pointing toward you.
4. Fasten all tines in place securely with the lockwashers and nuts provided.

NOTE: Some assemblies have a spacer between the tine and plate assembly.



Between the double pulleys there is a bearing.
During service this should be checked.

SNOW THROWER
Tractor Mounted

G




FIG. 1

ASSEMBLY

1. Attach left and right hand shoe to body assembly with 3/8-16NC-3/4 long carriage bolt, 3/8 plain and 3/8 lockwasher. Secure with 3/8-16NC hex full nut, which is on outside of shoe at desired elevation for your specific needs. (See Fig. 1).
2. Attach left and right hand drift cutters to outside of body assembly with 5/16-18NC-3/4 long hex capscrews, 5/16 plain and 5/16 lockwashers. Secure with 5/16-18NC hex full nut. (See Fig. 1).
3. Attach hitch assembly to rotor body assembly with 3/8-24NF-1-1/2 long hex head bolt, 3/8 plain and 3/8 spring washer. Secure in place with 3/8-24NF hex full locknut. (See Fig. 1).
4. Place V-belt around pulley in rotor body housing.
5. Remove 5/16-18-1/4 long hex capscrew, lock and plain washer from tractor directly below front mounted P.T.O. shaft. Insert through two belt fingers and reassemble. DO NOT TIGHTEN. (See Fig. 2).
6. Attach front mounted P.T.O. pulley to shaft. Secure 3/8-24NF setscrew down on key. (See Fig. 2).
7. Attach hitch assembly to tractor with two pins and two spring clips. (See Fig. 2).
8. Place belt around front mounted P.T.O. pulley. (See Fig. 2). The belt should be a minimum of 54-1/4" in length.
9. Install belt stops so the left belt stop is nearest the tractor frame and the right belt stop nearest the bolt head. They should be adjusted to approximately 1/32" from the belt and pulley when the thrower is in the engaged position.
10. Apply a light coating of oil to neck of discharge spout. Install spout and extension as shown. (See Fig. 1).
11. Attach rod guide support to top hole of lift rod bracket with 3/8-16NC-1/4 long capscrew, 3/8 lockwasher and 3/8-16NC hex full nut. DO NOT TIGHTEN. (See Fig. 1).
12. Insert handle assembly into spout control tube assembly and secure with 5/32" x 1" long cotter pin. Insert spout control tube assembly into bearing and secure in place with 2-1/8" x 3/4" long cotter pins. Insert handle assembly through rod guide. Tighten 3/8-16NC hex full nut on rod guide support which is in top hole of lift for bracket, at desired angle of operator while on seat. (Fig. 1)




FIG. 2

13. Position discharge spout directly forward. Position control tube so that cord clamp faces side of spout. Provide two (2) coils of cord on both sides of clamp. Position free ends of cord around spout and clamp securely into position after removing all slack from cord. (See Fig. 2).

14. Remove forward, top capscrew from R.H. side panel. Insert clutch handle bracket between side panel and side member of fuel tank and steering post support assembly. Secure with same capscrew and lockwasher. (Fig. 2)

15. Insert clutch control rod through bracket and attach to clutch pivot and secure in place with spring clip. (See Fig. 2). The addition of plain washers, nylon washers and locknut to the clutch linkage assembly will assure a positive disengagement when the clutch handle is pulled in the disengaged position. The locknut should be set to a torque setting of 4 ft. lbs. It should require

movement of the lever to engage or disengage the thrower.

16. The set collar should be adjusted up or down to assure the backside of the belt rides properly in the idler pulley. A good starting adjustment is approximately 3" overall spring length, engaged. Be sure spring is not fully collapsed. Be sure setscrew is properly indexed not to strike housing.

17. The lift lever quadrant on the side of the tractor contains a series of holes and a pin. Place pin in the foremost hole of quadrant and secure in place with hair pin cotter. Release lift lever and place in a forward position. Attach yoke end of front lift rod to lift lever arm using top hole in R.H. side of tractor, with yoke pin and hair pin cotter. Insert lower end of lift rod into lift arm bracket of push bar and secure with hair pin cotter. The lower end of front lift rod is to point away from tractor. (See Fig. 2).



FIG. 3

At this point when lift lever is about $1/4$ " away from pin in quadrant, rotor housing should be in contact with the ground. This will allow plow to follow contours of the surface being plowed but quadrant pin will prevent lift lever from latching in forward position if plow is driven over a curbing.

18. Position heat deflector over muffler and adjacent to engine. Flap of deflector to be positioned against air cleaner. Secure with clamp provided. (See Fig. 2).

This deflector is provided for winter use only and must be removed in warm weather to prevent overheating and damaging of engine. The deflector directs a flow of warm air around carburetor and allows for more efficient winter operation of tractor engine.

OPERATION & LUBRICATION (Fig. 3)

19. Engagement of snow thrower is accomplished

by pushing the clutch handle forward. Pull handle toward operator for disengagement. There are grease fittings on the snow thrower. Lubricate with a general purpose automotive grease every 15 hours of operation. The occasional application of light motor oil to shaft on which the pulleys operate, will prolong their life.


Late production snow throwers now include a drive belt shield.

The clutch assembly now has a stud on each side below the clutch cross shaft.

To Install the Shield:

1. Place on each stud a conical spring and cover clip. Secure in place with $5/16$ " lock nut.
2. Slide shield in place.

The use of the spring and clip allows the shield to be easily removed and replaced.




BODY & ROTOR
Rotary Snow Thrower
1st Type 3 Belt Drive

BODY & ROTOR (1st Type)

When servicing the 3 belt drive snow thrower, check all bearings and sprockets for excessive


wear. All parts are serviced through service parts.

After replacing the bearings use care so as not to distort the new bearings when installing them.




SPOUT - 1st Type (Belt Control)
Rotary Snow Thrower

All parts for the three belt style snow thrower are available through service parts stock.



PUSH BAR - 1 Type (3 Belt Drive)
Rotary Snow Thrower

All components are available for service through service parts stock.



— ROTOR BODY & DRIVE - 2nd Type (Single Belt Drive) —
36" Rotary Snow Thrower

DRIVE SHAFT BEARING REPAIR


1. Remove chain guard.
2. Remove drive chain by opening at master link.
3. Loosen belt guard assembly and slide to the left so belt and pulley can be removed.
4. Remove belt and pulley, slide belt guard to the right and off bearing housing.
5. Remove bearing housing and drive shaft from rotor body.
6. Remove drive shaft from bearing housing.
7. Remove old bearings from housing.
8. Install new bearings in housing being careful not to distort them.
9. Reinstall drive shaft.
10. Reinstall bearing housing and drive shaft back on rotor body.
11. Reinstall belt guard.
12. Install belt pulley and belt. Position belt guard.

13. Reattach drive chain.

14. Install chain guard. Tighten all capscrews and nut securely.

ROTOR BEARING REPAIR


1. Remove chain guard.
2. Remove chain by opening at master link.
3. Remove rotor sprocket.
4. Remove bearing on L.H. side.
5. Slide rotor to left to clear R.H. bearing.
6. Remove rotor from housing.
7. Replace R.H. bearing.
8. Insert rotor in left side as far as it will go.
9. Swing rotor back into housing and slide into R.H. bearing.
10. Install L.H. bearing.
11. Install rotor sprocket.
12. Install chain.
13. Install chain guard.



HITCH & PULLEY - 2nd Type (Single Belt Drive)
36" Rotary Snow Thrower


All components are available through service parts.

Adjustment of linkage is critical. Refer to the front of this section for adjustment.




SPOUT - 2nd Type (Cord Control)
36" Rotary Snow Thrower


All components are available through service parts.



All components are available through service parts.




All components are available through service parts.



42" GRADER BLADE

The blade is reversible for longer lift. All components are available through service parts.



HITCH ADAPTER
f/10" Plow, Cultivator, Disc

All components are available through service parts.



PLOW - 10"




FIG. 1

PACKING

The plow is packed disassembled for easy shipment.

ASSEMBLY AND ADJUSTMENT (Fig. 1) (REQUIRED HITCH ADAPTER)

1. Remove varnish from moldboard and share, using a good grade of varnish remover. (Keep greased when not in use).
2. Bolt standard (1) to plow bottom (2).
3. Bolt beam (3) to standard at (4). Lock with jam nut so that beam is free to swing on standard.
4. Attach depth regulating yoke rod assembly (5). Pin and cotter pin.
5. Attach rolling coulter assembly (6) and adjust coulter standard (7) so that blade runs ap-

proximately 1/2" to the left of landsides. Set the rolling coulter for best depth depending upon the soil.

CAUTION: Be sure that the rolling coulter is out of the ground when the tractor is in reverse gear.

6. Attach the lift pin and chain assembly (9) to the beam at (8) by means of the pin and spring clip provided. The hitch clevis adapter (10) is then attached to the tractor hitch by means of the pivot pin. Connect the plow to the hitch adapter with the hitch pin and insert the lift pin (9) in the tractor rear lift assembly and secure in place with a pin and spring clip.

7. Wheel weights should be used when operating the 10" plow. The weights are designed so that as many weights as necessary may be added to the wheels.

8 - 12" DISC HARROWS FOR MODEL B SERIES WHEEL TRACTOR




FIG. 2

PACKING

For ease in shipping, the disc harrow is packaged unassembled. Assemble the disc harrow by following the sequence of steps outlined below.

ASSEMBLY (Fig. 2)

1. Remove the gang bolts (1) from the frames and assemble the discs (2) into right hand left hand gangs as shown in Fig. 1. Insert the gang bolts through the discs and wood bearings and

secure in place with nuts and washers.

2. Clamp the disc gangs in place on the tool bar (3) using clamps (4), carriage bolts (5) and lockwashers as shown in Fig. 2.

3. The drawbar end assembly is fastened to the harrow drawbar by two carriage bolts through the upper set of holes in the drawbar end assembly as shown in Fig. 3. Check to be sure that the upper set of holes are used when using the harrow on the tractor.

K




FIG. 3

OPERATION AND ADJUSTMENT (Fig. 3)

The disc gangs are reversible and can be set to "throw in" or "throw out". To reverse discs, remove the cotter pin from the adjustment link (5), swing disc gang around half way, and replace cotter pin.

To angle the discs for greater or less penetration, remove the cotter pin and swing discs to desired angle and replace cotter pin in adjustment link. Set both gangs at the same angle.

The tilt adjustment arm (7) provides for changing the tilt of the disc gang. Raising the arm causes the outside disc to penetrate deeper than the inside ones, as is desirable when hilling.

Tilting the adjustment arm also permits perfect leveling of the disc at any depth of penetration.

When disc harrowing with both gangs set to throw out, it is desirable to double disc by lapping to avoid leaving ridges.


Lubricate all bearings of the disc with an ordinary machine oil before each use.

ATTACHING

To attach the disc harrow to the tractor, it will first be necessary to attach the clevis assembly to the tractor tow assembly using the pivot pin and hair pin cotters. See Fig. 2. Mount the lift pin in place in the tube of the tractor lift and fasten with pin and hair pin cotter.

Position the disc harrow in back of the tractor and attach the drawbar end assembly to the clevis assembly by inserting the hitch pin. Connect the lift chain to the harrow at point shown in Fig. 3, using pin and hair pin cotter.


SPRING TOOTH HARROW



All parts for the spring tooth harrow are available through service parts.

The spring teeth can be adjusted for depth and spacing. Pitch is controlled by tilting the whole tool bar.

CULTIVATOR FOR MODEL B SERIES TRACTOR



PACKING

The cultivator is packed in one carton disassembled for ease of shipment.

ASSEMBLY

1. Attach parallel bars to drawbar assembly as shown at (1). Lock with jam nuts so bars are free to swing.
2. Attach depth crank (2) as illustrated. Adjusting nuts (3) should be equally spaced on the threads.
3. Clamp wheel standards to drawbar assembly as shown at (4).
4. Clamp tool holders to tool bar as shown at (5).
5. Attach the tool standards to the tool assemblies.

ATTACHING (REQUIRES HITCH ADAPTER)

To attach the assembled cultivator to the tractor:

1. Pull the lift lever all the way back.
2. Mount the lift pin and chain (6) on the tractor rear lift assembly being certain to drop in the lock pin and spring clip.
3. Mount the clevis (7) to the tractor tow assembly and secure the spring clip.

4. Bring up the cultivator and drop in the drawbar pin and spring clip.

5. Pin the lift chain to the cultivator at (8), secure with spring clip.

6. To transport the cultivator, move the lift lever to its forward position.

ADJUSTMENTS

1. A hand screw (2) is provided to permit the adjustment of the depth of the sturdy carbon steel shovels, together.
2. Each shovel may be adjusted separately in its bracket.
3. The middle shovel (9) can be freed to be flipped forward to straddle the middle row by first removing its pivot lock pin (10).
4. Grease wheel bearings daily with grease gun.

OPERATION

The garden can be more easily cared for by planting rows the long way of the plot.



Select the proper number cultivating shovels so the maximum results are obtained. Seedlings require different attention than sturdy plants.

NOTE: Since the principal purpose or function of cultivation is weed control, it follows that cultivation should be done at the time most fa-

avorable for killing weeds, which is just as they are breaking through the surface. Practically all the benefits derived from cultivation are secured from shallow cultivation. Deep cultivation, if practiced, should be carried on during the

early stages of growth and the depth lessened as the plants grow larger and the roots increase in length. All tools on this cultivator have an individual adjustment for depth and an individual adjustment for pitch.


CULTIVATOR



All parts of the two-section cultivator are available through service parts stock.

All shovels can be adjusted for spacing, depth and pitch.

LAWN ROLLER
For Model B - Series Wheel Tractor



The lawn roller hitch is shipped in a carton, and the drum separately.

ASSEMBLY

1. Place the frame on the roller axle, being sure washers are on each side of the frame. Insert the pins (1) to hold the frame on the roller axle.

2. Bolt the tongue (2) to the frame in such a manner that the front end is lower than the rear. The tongue is bent so the roller can be properly

mounted on the tractor.

3. A scraper is provided with the lawn roller hitch. To install the scraper (3) mount to frame with two pivot pins (4). The scraper arms should be pinned between the two side bars of the frame. Put the cotter pins in the ends of the pivot pins. Fasten scraper spring (5) to hole in extension pin.

The roller drum, when filled with water, weighs 370 lbs. Do not leave your roller filled with water where it may freeze.

M

MOBILE GENERATOR

INTRODUCTION

Your mobile generator is a rugged, quality constructed, conservatively rated, heavy duty unit designed to increase the usefulness of your tractor and to assist you in accomplishing your job faster electrically. For the generator to provide its maximum usefulness, it is necessary for you to be thoroughly acquainted with the following installation and operating procedures. We, therefore, request your co-operation in carefully studying the following information.

GENERATOR RATING AND CONSTRUCTION

Your mobile generator is rated at 115 volts, 13 amps, 1500 watts at 60 cycles. The 60 cycle frequency is produced at a generator speed of 3600 rpm.

The generator is designed and built to the latest AC generator design principles. These include many features, such as sealed for life ball bearings, modern high temperature insulation, no commutator assembly to cause maintenance and sparking difficulties, built in voltmeter, outlets with ground polarizing pin, and a new exclusive rectifier field excitation circuit which greatly improves the voltage control and motor starting ability of your generator.

This generator is intended to handle all electrical loads up through 1500 watts in capacity. In determining the amount of load that may be applied to your generator, the name plate rating of the load to be connected should first be checked. This will be expressed in either watts or amperes at 115 volts. The generator will handle combined loads which add up to 1500 watts or combined amperes loads which do not exceed 13 amps. For example: fifteen 100 watt electric bulbs may be operated from the generator or six 250 watt bulbs.

The following is a brief list of various loads with their average wattage requirements.

RATING OF VARIOUS EQUIPMENT



6" Hand Saw	1000 watts
10" Hand Saw	2000 watts
1/2" Electric Drill	750 watts
3" Belt Sander	1000 watts
14" Chain Saw	1000 watts
Concrete Vibrator	2500 watts
Television Set	250 watts
Electric Toaster	1000 watts
8-1/2" Hand Saw	1500 watts
1/4" Electric Drill	250 watts
1" Electric Drill	1000 watts
4-1/2" Belt Sander	1250 watts
9" Disc Sander	1200 watts
Frying Pan	1300 watts
Electric Iron	900 watts

When considering the operation of electric motors, it must be understood that electric motors require a great deal more amperage to start the motor than that which is required to keep it running. Your generator has a large amount of reserve capacity for motor starting purposes. It will deliver up to 25 amps momentarily for starting motors, although the continuous duty rating is only 13 amps.

As a general rule of thumb this generator would be expected to start the following types of motors.

Motor Type	Maximum size motor which may be started	
	With Load	No Load
Split phase induction motor	1/4 h. p.	1/2 h. p.
Capacitor start, induction run motor	1/2 h. p.	3/4 h. p.
Repulsion induction type motor	3/4 h. p.	1 h. p.
Universal motor	1 h. p.	1-1/2 h. p.

N



GENERATOR INSTALLATION

Your generator is supplied with the generator and mounting bracket completely assembled to facilitate the installation of the generator to the tractor.

The present rope starting pulley, located on the side of the transmission must be removed and replaced with the generator drive pulley, V, Fig. 4, and the new shallow rope starting pulley, U, Fig. 4. Use capscrews, A, Fig. 1, and lockwashers for the re-assembly of these two parts to the transmission drive pulley.

The generator assembly is then held in place at the rear of the tractor and the pivot rod, C, Fig. 2, is inserted through the rear tractor arms and through the tubular portion of the mounting bracket, Fig. 2. The pivot rod is then secured by spring clips at each end.

The belt, B, Fig. 1, is then applied between

the pulley, U, Fig. 4, mounted on the tractor transmission and the pulley on the mobile generator.

The adjusting rod, Q, Fig. 4, is inserted in place on the tractor as shown, and the spring clip, J, Fig. 4, attached to it. The wing nut, E, Fig. 3, and spring, M, Fig. 4, are then assembled to the tension rod, and the rod is inserted through the generator tension arm, K, Fig. 4. The cotter key, L, Fig. 4, is then inserted in the end of the adjusting rod as shown in Fig. 3.

With the belt on the generator, the wing nut should be tightened to provide a spring length of one inch.

GENERATOR OPERATION

After the generator has been properly installed as outlined, the unit may be placed in operation by first applying the tractor parking brake,

secondly place the tractor transmission in neutral.

The engine should now be started and the speed set so that the voltmeter hand points to the black line in the green zone. This corresponds to 120 volt generator output and 60 cycles. The voltmeter hand must be kept in the green zone at all times when power is being taken from the generator. With exceptionally heavy loads, it may be necessary to reset the engine speed in order to keep the voltmeter hand in the green operating zone.


Loads may be applied to the generator by plugging into one or both of the receptacles at the rear of the machine. It is very important that polarized plugs be used in order to maintain a common ground between the generator and its load. Failure to do so could result in electrical shocks from faulty loads connected to the unit.

The generator is equipped with a built in automatic reset type circuit breaker which will automatically shut the generator off if excessive loads are applied to the unit for too long a period.

Basically the generator will supply 13 amps on a continuous duty basis and overload of up to 20 amps may be obtained for approximately 5 minutes, 25 amps for approximately a minute and one-half, and 30 amps for approximately 30 seconds. Loads above these values and for time periods greater than specified will result in the circuit breaker automatically shutting the generator down. After the generator has cooled sufficiently, the breaker will again place the unit in operation.


The generator may be used as an auxiliary source of power around the home or barn in case of power line failures. To connect the unit into the power line, the following procedure should be followed. First, pull the main line fuses or open the main line circuit breaker as the case may be, at the service entrance to the building. It is absolutely imperative that these fuses be pulled or breaker be opened prior to connecting the generator to the house electrical power. Failure to do so will result in severe damage and could possibly cause electrical shock injuries. This is an absolute must, first step if the unit is to be connected to the house electrical system.

Secondly, after opening the house electrical circuit to the power line, a No. 14 wire size extension cord should be obtained which has a polarized plug on each end. With the tractor engine turned off, one end of the plug should be inserted into the tractor generator and the other end into an outlet receptacle which is wired into the house electrical circuit. If your present house circuits do not contain the three prong polarized outlet, it will be necessary to have such an outlet installed prior to using the generator for emergency power in your home. The polarized outlet is necessary in order to provide a common ground between the generator and the house electrical system. With the extension cord connected to both the house and the generator, the tractor engine should be started and be brought up to the proper operating speed as indicated by the voltmeter hand as previously described. A note of caution here, the heavy electrical loads in the house should all be turned off prior to starting your tractor engine and then load applied to the generator after it is operating at its proper speed.



When servicing the generator be sure and check the condition of the bearings. Worn bearings can lead to the failure of the entire unit.

SUMMER CAB



A SSEMBLY

1. Attach (G) to lift support members with 4 screws provided.
2. Bolt (H) to tractor foot rests with 4 screws provided. (Older models must have holes drilled in foot rests as shown in Fig. 4).
3. Bolt together (D), (F) and (U) on both sides as detailed in Fig. 1.
4. Thread member (C) into channel in canvas canopy (AA) (See Fig. 2) and bolt (C), (A), (D) and (E) together on each side as detailed in Fig. 2.
5. Now attach this canopy assembly to (G) on each side (Fig. 1), leaving the attaching bolt on (G).
6. Attach both front support members (B) to the inside front corners of (A) as shown in the exploded view.
7. Grasp two supports (B) and pull the whole assembly forward until the bottom ends of (B) can be bolted to (H), Fig. 4.
8. Fasten down top of canopy around (A), and back and sides around (F) and (D) as illustrated.
9. The operator should take care to avoid thorns or other sharp objects that might damage the canvas covering.

CONVERSION OF SUMMER CAB TO WINTER CAB




FIGURE 2




FIGURE 1





FIGURE 4




FIGURE 3

1. Install summer cab in accordance with the instructions furnished with that unit.
2. Remove screw (#1, Fig. 1) and attach the rear end of member (AD) to outside as shown.
3. Repeat above step on opposite side, attaching member (AE) in a similar manner.
4. Remove nuts holding (B) to (H) and tilt whole canopy assembly all the way to the rear.

5. Thread member (AB) through channel in bottom part of front window section (AH).
6. Attach one end of each member (AC) to the lower front corners of (AB) through the openings at that point in the front window assembly (AH).
7. Now, with the whole main assembly still tilted to the rear, raise (AE) and (B) and join them to (AB) with the drilled screw (#1, Fig. 4) provided. Note that (AE) is positioned on the outside of the other two members.

11. Fasten the side panels (AJ) and (AK) into place as shown, and then fasten down the front and sides of the top canopy cover.

12. Then the sides and rear of the top canopy panel are fastened into position as illustrated. Note that the side panels front edges are snapped in place over the rear edges of the front panel.

13. Tilt the whole assembly forward into position and secure the front members to (H) at each side by means of a spring clip (AN) through the hole in the drilled bolt (Fig. 4).

8. Attach the upper end of rods (AC) to (A) at the front corners making sure that the upper corner of the front window assembly (AH) is fastened to the same point by means of the screw passing through the eyelet provided in the canvas (Fig. 2).

9. The top of the front window assembly is then snapped on the fasteners at the front of (A) and the sides are snapped to members (B).

10. The seat protector panel (AL) is then snapped to (F) and (AE). See Fig. 3.

GENERAL INSTRUCTIONS

A. Stop plate tabs (#2, Fig. 1) must be properly lined up with the rear member so that it will not slip to the side. The purpose of these stop plates is to eliminate the possibility of interference between the rear counterweight and the cab when the cab is tilted to the rear.

B. Be careful not to scratch the plastic window material.


C. Do not remove the canvas from the frame when wet, as it may change shape.

D. Be especially careful in extreme cold as plastic may become brittle.


E. In summer, when storing canvas panels, protect plastic windows with kraft paper and roll up carefully.

VACUUM COLLECTOR

P



The components are all available through service parts stock for repair.



COLLECTOR & BLOWER HOUSING
Vacuum Collector - B1 & B10

VACUUM COLLECTOR Blower Housing

1. Remove intake hose from blower housing.
2. Remove housing support assembly.
3. Remove belt guard.
4. Separate housing halves.
5. Remove fan assembly by loosening set-screw and pulling fan from shaft.
6. Remove pulley from shaft.
7. Remove flange assembly and shaft from housing.
8. Remove shaft from flange assembly.
9. Inspect shaft and bearing, replace if necessary.

REASSEMBLY

1. Place shaft back in flange assembly.
2. Re-bolt flange assembly and shaft back into housing half.
3. Replace fan back on shaft, secure in place.
4. Bolt housing halves back together.
5. Replace pulley back on shaft. Secure in place.
6. Bolt housing support assembly back in place.
7. Reinstall intake hose.
8. Attach to tractor and readjust clutch.

FORK LIFT & LOADER

FORK LIFT

SPECIFICATIONS

Model Designation	B Series
Shipping Weight w/Forks	333 lbs.
Total Operational Weight (Included Tractor & Counterweight) (Less Operator)	1000 lbs.
Counterweight Recommended	230 lbs.
No. of Lift Cylinders	.1
No. of Tilt Cylinders	.1
Mast Type	Single Stage
Fork Length	32"

OPERATIONAL SPECIFICATIONS

Lift Capacity @ 15" Load Center	500 lbs.
Overall Length	115-3/4"
Overall Height, Mast Down	59-1/4"
Overall Height, Mast Fully Raised	92"
Maximum Lifting Height	66"
Time of Lift	.7 seconds
Reach (Center/Line Rear Axle to Fork Face)	.21-1/2"
Tilt Forward, Degrees	.10°
Tilt Back, Degrees	.10°
Ground Clearance	5"
Tire Pressure	
Front, B-1 & B-10	.20 PSI
Rear, B-1	.20 PSI
B-10	.10 PSI

HYDRAULIC SYSTEM SPECIFICATIONS

Pump Capacity @ 2000 R. P. M.	1.5 GPM
Hydraulic System Capacity	2-1/2 Qts.
Maximum Operating Pressure	1250 PSI
Type of Filter (Suction Line)	Screen
Cylinder Size	
Tilt (Bore x Stroke)	1-3/4" x 4"
Lift (Bore x Stroke)	1-1/4" x 33"

MAINTENANCE AND SERVICE

HYDRAULIC CYLINDERS

When properly installed and operated, the cylinders should require very little servicing other than the occasional replacement of the piston packing or rod packing.

TILT CYLINDER DISASSEMBLY

Remove the cylinder. Push cylinder head assembly and wiper seal into barrel far enough to remove retaining snap ring. Remove snap ring.

Pull piston rod and head assembly out of barrel. Place rod assembly in vise and remove piston retaining nut. Remove piston rod from cylinder head assembly. See Fig. 1.

Clean, inspect and replace the necessary seals and parts. Reverse procedure for assembly.

LIFT CYLINDER



To remove lift cylinder from mast assembly, disconnect lift chain. Disconnect hydraulic hose from control valve. Remove pin attaching chain roller bracket to cylinder from inner mast assembly. Remove roller and the roller bracket. Lift cylinder from top of mast assembly.

DISASSEMBLY

Remove plug from side of cylinder barrel. Position piston rod to locate lock ring through pipe plug hole.

Use a screw driver and move lock ring toward top end of piston rod and into the small diameter area of piston rod. Pull piston rod from cylinder tube. Remove the wiper ring from cylinder tube.

Clean, inspect and replace the necessary seals and parts. Reverse procedure for assembly. Install new seals in cylinder tube. Install the piston rod. Position piston rod to locate retain-



ing ring through pipe plug hole, use a screw driver and position the lock ring on the piston rod. Install the wiper seal over piston rod and into cylinder tube. Reinstall cylinder in unit. See Fig. 2.

HYDRAULIC CONTROL VALVE

The control valve should require very little service other than the occasional replacement of the oil seals. See Fig. 3.

DISASSEMBLY

Remove the control valve from the unit. Remove the ring clips and remove the centering spring assemblies. Note assembly of parts so they can be replaced in the same order as removed. Remove the spools from the valve body.

Clean, inspect and replace the necessary seals and parts. Install the O-ring seals in valve body. Install the spools in the body. Push the spools into the body far enough to allow installation of the V block seals at the lever end of the spools. Lubricate the seals and position the spools forward through V block seals. Install centering spring assemblies and ring clips.

HYDRAULIC PUMP

General overhaul in the field is not recommended. For pump overhaul and rebuild, see your Allis-Chalmers dealer.





FIG. 3

The hydraulic pump is designed to deliver 1.5 G.P.M. at 2000 R.P.M. The maximum operating pressure is 1250 P.S.I., and is controlled by the main relief valve in the pump.

To check pump pressure, install a tee and pressure gauge in the pressure line. Actuate a cylinder to the end of the stroke and read pressure gauge. The main relief valve in the pump is adjusted by the use of shims.

SERIES "G" CESSNA GEAR PUMP
(Used on B Series Loader and Fork Lift)



(FIG. 4) MODEL "G" PUMP

The series "G" pump should require very little maintenance other than the occasional replace-

ment of seal and wear plates. Refer to Fig. 4 for parts and maintenance procedure.

DISASSEMBLY

1. Remove pump and reservoir from tractor.
2. Drain oil from reservoir.
3. Remove key from shaft.
4. Clean outside of pump thoroughly.
5. Remove reservoir from pump body.
 - a. Remove two bolts holding screen.
 - b. Remove one bolt holding reservoir to pump.
6. Scribe line on pump to assure correct re-assembly.
7. Clamp pump in vise shaft down.
8. Remove tie bolts.
9. Bump shaft on wood block to separate pump.
10. Remove gears and shaft assembly.
11. Remove diaphragm from front plate.
12. Remove springs and balls from front plate.
13. Remove phenolic gasket, protector and moulded seal.
14. Remove shaft seal from front plate.
15. Remove relief valve from housing assembly, hex-plug, shims, spring and poppet assembly.

INSPECT PARTS FOR WEAR

1. Clean all parts and remove nicks and burrs.
2. Inspect gear face for scoring and excessive wear.
3. If edge of gear teeth are sharp, break with emery cloth.
4. Check for scoring of housing assembly, if worn excessively housing should be replaced.
5. Check poppet assembly and seat. Seat may be replaced if necessary.

REASSEMBLY

1. The diaphragm, phenolic gasket, protector gasket and moulded seal, and shaft seal should be replaced as new parts.
2. Tuck moulded seal into grooves in front plate with open part of seal down, using a dull tool.
3. Press phenolic gasket and protector gasket into moulded seal.
4. Drop steel balls in seats followed by springs. Note one ball on each side of front plate followed by the spring.
5. Place diaphragm on top of phenolic gasket bronze side up coined area on suction side. Entire diaphragm must fit inside rim of moulded seal.
6. Dip gear assemblies in oil and slip into front plate bearings.
7. Housing assembly, relief valve seat may be replaced if necessary. Install seat to depth of $1.906 \pm .010$ from outside surface to top of seat
— .000

surface, using loctite and loquic on threads.

8. Put thin coat of grease on both surfaces of body.
9. Slide housing over gears until dowels engage.
10. Install bolts, torque to 7-10 ft. lbs.
11. Oil shaft seal, slide over shaft using wax paper over keyway to protect damage to seal, seat seal with plastic hammer.
12. Rotate shaft by hand, there should be a slight drag.
13. Install poppet valve, spring and by use of shims, correct pump pressure is 1250 PSI.
14. Install O-ring on housing, reservoir tank, and screen. Torque bolts to 10-15 ft. lbs.
15. Mount pump on unit, fill reservoir operate pump set pressure as stated in Item 13.

PLACING PUMP INTO SERVICE

If shop test stand is not available the following procedure for testing rebuilt pumps is recommended.

1. Mount pump on equipment and run pump at $1/2$ engine speed at zero pressure.
2. By operating control valve build pressure intermittently for three minutes.
3. Increase engine speed to full throttle and build pressure intermittently for three minutes.
4. Idle engine and check for leaks.

GENERAL INFORMATION AND SPECIFICATIONS For B Series Loader

B-1 and B-10 tractors should be equipped with Dual Rear Wheel attachment for stability.

NOTE: The B-10 tractor must be equipped with the rear wheel spacers. Dual wheels must not be used for digging purposes or over rough ground where the load is concentrated on outer wheels.

Shipping Weight less bucket and counterweight box	220 lbs.
Bucket.	65 lbs.
Counterweight Box	60 lbs.

33" Bucket Capacity	Struck	Heaped
	2.5 cu. ft.	3 cu. ft.

OPERATIONAL SPECIFICATIONS

Lifting Capacity Full Height (55-1/2")	300 lbs.
Lifting Capacity at Ground Level (break away).	500 lbs.
Maximum Clearance at Full Height.	55-1/2"
Reach at Maximum Height for 45° Dump	18"
Dumping Height at 45° Dump	44"
Reach at Ground Level	31"
Digging Depth	1-1/2"
Bucket Control.	Manual
Cycle Time, Seconds	
Up	4
Down	2
Maximum Weight in Ballast Box	100 lbs.

HYDRAULIC SYSTEM SPECIFICATIONS

Pump Capacity at 2000 R. P. M.	1.5 GPM
Hydraulic System Capacity	2 Qt.
Maximum Operating Pressure.	1250 PSI
Oil Filter (Suction Line).	Screen Type
Cylinders, No.	2
Type	Displacement
Bore x Stroke	1-1/4" x 12"
Valve, Single Spool, Single Acting	

GENERAL INFORMATION & SPECIFICATIONS FOR L-TEN SERIES LOADER

Shipping Weight less bucket and counterweight box	220 lbs.
Bucket.	65 lbs.
Counterweight Box	60 lbs.

42" Bucket Capacity 4 cu. ft. heaped

OPERATIONAL SPECIFICATIONS

Lifting Capacity Full Height (55-1/2")	300 lbs.
Lifting Capacity at Ground Level (break away).	500 lbs.
Maximum Clearance at Full Height	55-1/2"
Reach at Maximum Height for 45° Dump	.18"
Dumping Height at 45° Dump	.44"
Reach at Ground Level	.31"
Digging Depth	1-1/2"
Bucket Control	Manual
Cycle Time, Seconds	
Up	.4
Down	.2
Maximum Weight in Ballast Box	100 lbs.

HYDRAULIC SYSTEM SPECIFICATIONS

Pump Capacity at 2000 RPM.	1.5 GPM
Hydraulic System Capacity	2 Qts.
Maximum Operating Pressure.	1250 PSI
Oil Filter (Suction Line)	Screen Type
Cylinders, No.	2
Type	Displacement
Bore x Stroke	1-1/4" x 12"
Valve, Single Spool, Single Acting	

LOADER HYDRAULIC SYSTEM




FIG. 5 (LOADER HYDRAULIC CONTROL VALVE)

HYDRAULIC CONTROL VALVE (Fig. 5)

The control valve used on this loader is a single spool, single acting. The control valve is not normally serviced in the field, except for the occasional replacement of seals. Before attempting any service, wash the valve with solvent to remove any dirt or grit that might damage the hydraulic system.

Disassembly - Replacement of Seals

1. Remove control valve from loader.
2. Remove retaining snap ring from end of spool.
3. Slide spool out of valve housing.
4. Remove O-ring and seal and clean all parts thoroughly.
5. Install new O-ring in lower end of valve.
6. Dip spool in oil and insert in housing.
7. Push spool into valve housing and install V-Block Ring Seal. Use caution not to upset lips of seal and pull spool back through top seal.
8. Reassemble spool centering spring and washers and install retaining snap ring.




FIG. 6 (LOADER LIFT CYLINDER)

LIFT CYLINDER (Fig. 6)

Cylinder service consists of replacing the packing rings and seals. Slight scratches on the piston rod show dirt or grit wear. Slight scratches may be removed with a dry medium grit emery cloth. Deep scratches on the piston rod or scored cylinder walls require replacement of the affected part.

Disassembly

Remove hose from side of cylinder barrel. Position piston rod to locate lock ring through pipe plug hole.

Use a screw driver and move lock ring toward top end of piston rod and into the small diameter area of piston rod. Pull piston rod from cylinder tube. Remove the wiper ring from cylinder tube.

Clean, inspect and replace the necessary seals and parts. Reverse procedure for assembly.

Install new seals in cylinder tube. Install the piston rod. Position piston rod to locate retaining ring through hose connecting port, use a screwdriver and position the lock ring on the piston rod. Install the wiper seal over piston rod and into cylinder tube. Reinstall cylinder in unit. Install cylinder on unit.

HYDRAULIC PUMP

General overhaul in the field is not recommended. For pump overhaul and rebuild, see your Allis-Chalmers dealer.

The hydraulic pump is designed to deliver 1.5 G.P.M. at 2000 R.P.M. The maximum operating pressure is 1250 P.S.I., and controlled by the main relief valve in the pump.

To check pump pressure, install a tee and pressure gauge in the pressure line. Actuate a cylinder to the end of the stroke and rear pressure gauge. The main relief valve in the pump is adjusted by the use of shims.

L-12 LOADER

(2023556)

INDEX

BUCKET, Cylinder	R-8
Disassembly	R-8
CONTROL VALVE, Service Instructions	R-5
Disassembly	R-5
Inspection	R-5
Reassembly	R-7
HYDRAULIC PRESSURE CHECK	R-3
HYDRAULIC PUMP DRIVE BELT	R-3
Belt	R-3
Pump Drive Alignment	R-3
Relief Valve	R-4
LOADER ASSEMBLY	R-13
LOADER HYDRAULICS	R-6
LOADER, LIFT CYLINDERS SERVICE INSTRUCTIONS	R-8
Disassembly	R-8
Inspection	R-8
Reassembly	R-8
LOADER PUMP	R-9
Disassembly	R-9
Inspect Parts for Wear	R-9
Body	R-10
Front and Back Plates	R-10
Gear Assembly	R-9
General Information	R-10
Reassembly	R-10
Relief Valve	R-10
Placing Pump Back into Service	R-11
LUBRICATION & MAINTENANCE	R-2
Daily Maintenance	R-2
Hydraulic Oil	R-2
Monthly Maintenance	R-2
Semi-Annual Maintenance	R-2
Tire Pressure	R-2
Weekly Maintenance	R-2
SPECIFICATIONS	R-1
SERVICE GUIDE FOR PUMP	R-12

R

L-12 LOADER

SPECIFICATIONS

General

Model Designation	L-12
Loader	
Shipping Weight (Less Bucket).	260 lbs.
Recommended Ballast	Min. 200 lbs. Max. 300 lbs.
Bucket	
Shipping Weight	93 lbs.
Width.	43"
Capacity Heaped.	4 Cu. Ft.

Operational

NOTE: All measurements made with loader installed as follows:
 Tractor Model Allis-Chalmers B-12
 Tire Size, Front 16 x 6.50-8 2 Ply, Rear 23 x 8.50-12 2 Ply
 Tread Width, Front 30", Rear 32"


Lifting Capacity to Full Height	300 lbs.
Breakout Force	500 lbs.
Height to Bucket Hinge Pin	63-1/2"
Reach at Maximum Height	20"
Clearance, Bucket Dumped 45°	49-1/2"
Reach, Bucket on Ground.	35"
Bucket Roll Back	0°
Maximum Dumping Angle at Full Height	45°
Digging Depth Below Ground Level.	1-1/2"
Turning Clearance Circle.	18'-6"
Raising Time to Full Height, Seconds	3-1/2 Sec.
Lowering Time, Seconds	2 Sec.
Bucket Dumping Time	2-1/2

Hydraulic Specifications

Pump Capacity at 2000 RPM	1.5 G.P.M.
Hydraulic System Capacity	2-1/2 Qts.
System Relief Valve Setting	1500 P.S.I.
Hydraulic Cylinder (Bore-Stroke-Rod Dia.)	
Bucket	1-3/4" x 9" x 3/4"
Lift	1-1/4" x 12" x 1-1/4"
Oil Filter	.40 Micron Element

The Allis-Chalmers Manufacturing Company reserves the right to make changes in the above specifications or to add improvements at any time without notice or obligation.

LUBRICATION AND MAINTENANCE



(L-12 Loader Lubrication & Maintenance)

Use regular grade chassis lubricant for all grease fittings.

HYDRAULIC OIL

Oil used should be non-foaming and have high oxidation resistance. The oil should have a high viscosity index. Detergent type oils are satisfactory if they are non-foaming.

Oil should meet API classification MM-MS.

For highest temperatures of 0°F. use SAE 5.
For highest temperatures 0°F. to 70°F. use SAE 10.

For temperatures above 70°F. use SAE 20.
SAE 10W-30 may be used for all temperature ranges.

NOTE: Use only clean oil and clean containers. Dirt can destroy hydraulic system components.

DAILY MAINTENANCE

1. Check and tighten all mountings.
2. Check hydraulic system for leaks.
3. Check hydraulic system for proper oil level. Add only recommended oil.

4. Follow Tractor Operator's Manual for daily service.

WEEKLY MAINTENANCE

1. Follow daily service.
2. Lubricate all pivot points with chassis lubricant.
3. Follow Tractor Operator's Manual for weekly service.

MONTHLY MAINTENANCE

1. Inspect all hydraulic hoses and fittings. Tighten if necessary. Be sure hoses hang freely to prevent chaffing.


SEMI-ANNUAL MAINTENANCE

1. Drain oil, flush system and breather and replace with new oil of proper grade.

TIRE PRESSURES

Front Tires	25 PSI
Rear Tires.	10 PSI

HYDRAULIC PRESSURE CHECK PROCEDURE



1. Obtain from parts stock the fitting for the base end of the bucket cylinder. Drill and tap one side for 1/8" pipe for a test port.

2. Remove the hose from the fitting on the base end of the bucket cylinder. Remove fitting from cylinder. Install special fitting in cylinder and re-attach hose. Install hydraulic test gauge in

the test port.

3. Activate the bucket control valve and extend the bucket cylinder to the end of its stroke. The pressure should read 1500 PSI -50 ± 0 .

4. After checking pressure, remove the special fitting and replace with original fitting.

HYDRAULIC PUMP DRIVE BELT

PUMP DRIVE ALIGNMENT

Check the alignment of the V-belt from the hydraulic pump pulley to the front PTO pulley. The PTO pulley can be moved in either direction to insure satisfactory alignment. A straight edge can be used to insure direct alignment.


Tighten securely front PTO pulley.


CAUTION: Do NOT start tractor before filling hydraulic system with oil. Refer to Lubrication and Maintenance section for proper oil.

BELT

Inside Diameter - 29.8 in.
Outside Diameter - 32.0 in.
Width - 0.5 in.

The belt tension idler is designed to allow for normal variations and expansions of the belt and still maintain proper belt tension.





A suction line filter is built integrally into the loader hydraulic system. The filter is located in the reservoir in the loader main frame. This filter should be cleaned or replaced after the first 10 hours of operation and every 100 hours thereafter. If this 40 micron filter is damaged in any way it should be replaced.

To clean the filter, remove the loader as follows:


1. Drain the loader hydraulic oil reservoir.
2. Remove the capscrews holding the loader main frame to the sub-frame.
3. Remove pump drive belt from front PTO pulley.
4. Slip loader forward.

5. Remove suction tube assembly from pump and reservoir.
6. Remove connector and filter.
7. Wash filter in solvent or kerosene, dry and reinstall.
8. Reinstall suction tube assembly.
9. Reinstall loader on tractor.
10. Fill to proper level with recommended oil.

RELIEF VALVE

1. Low Pressure (Below specifications)
Remove relief valve and add shims as required. Use caution so as not to exceed maximum specification of 1500 PSI.

SERVICE INSTRUCTIONS FOR THE CONTROL VALVE



DISASSEMBLY

1. Plug all ports and clean outside of valve thoroughly.
2. Clamp valve in vise, spool down.
3. Unscrew end cap and remove.
4. Remove spool assembly from valve body. It is not necessary to remove the spool screw from the spool unless the spool centering spring is broken or the spool spacer is worn.
5. Remove bushing from body bore. Remove O-ring from body bore.
6. Remove lift check plug, spring and plunger from body.
7. Remove O-rings from body bore and plug.

To replace springs, remove spool screw from end of spool, remove washer, spacer and spring. Replace in proper order, clean threads of spool and screw and lock tite back in place. 8 ft. lbs.

INSPECTION

1. Remove all nicks and burrs from parts and inspect for excessive wear.


2. Inspect spool spring for breakage.

3. Inspection of O-rings is unnecessary as they should be replaced as new items.

REASSEMBLY

1. Thoroughly clean and dry all parts. Metal parts should be lightly oiled prior to assembly.
2. Position new O-ring in groove in spool bore.
3. Install new O-ring on lift check plug.
4. Slide bushing over spool and spring assembly. Slide new O-ring over spool and seat against bushing.
5. Clamp valve body in vise, port end up.
6. Oil spool and O-ring liberally and install in spool bore by hand. Do not force.
7. Screw end cap in valve body and tighten.
8. Install lift check poppet, spring and plug assembly in body.

CAUTION: Make certain that each spool is installed back in the valve body in the correct spool bore.



(L-12 LOADER HYDRAULICS)


L-12

R-6

L-12 LOADER HYDRAULICS

ITEM	QTY.	DESCRIPTION
1	1	LEVER ASSY., idler 1 LOCKNUT, 3/8NF
2	1	CAPSCREW, 1/2" NC x 2" 2 FLATWASHER, 1/2 1 LOCKWASHER, 1/2 1 NUT, 1/2NC
3	1	SPACER
4	5	CONNECTOR, 9/16 ST. (Incl. O-RING) 1 O-RING, .468" I.D.
5	1	SPRING, tension
6	3	CONNECTOR, 9/16, 90° elbow (Incl. O-RING) 1 O-RING, .468" I.D.
7	1	SHIELD, "V" belt 1 CAPSCREW, 1/2NC x 1/2 1 LOCKWASHER, 1/4 1 NUT, 1/4NC
8	1	PULLEY, "V" belt
9	1	PUMP ASSY., (Refer to Loader Pump for Components)
10	1	TUBE ASSY., lift
11	2	HOSE ASSY., 1/4 x 18 (1 wire)
12	2	HOSE ASSY., 1/4 x 50 (1 wire) (Incl. O-RINGS) 1 O-RING, .468" I.D.
13	1	VALVE ASSY., control 2 CAPSCREW, 1/4NC x 2 1 LOCKWASHER, 1/4 1 NUT, 1/4NC
14	2	LINK, chain
15	1	CAPSCREW, 1/4NF x 2-3/4 1 LOCKNUT, 1/4NF
16	2	KNOB, control handle
17	1	HANDLE, bucket control
18	1	HANDLE, lift control
19	1	ORIFICE PLATE, restrictor, 3/32" hole
20	1	CONNECTOR, 9/16" run tee (Incl. O-RING) 1 O-RING, .468" I.D.
21	1	TUBE ASSY., return
22	1	TUBE ASSY., pressure
23	4	CAPSCREW, 5/16NC x 1 1 LOCKWASHER, 5/16 1 NUT, 5/16NC
24	1	CONNECTOR, 3/4 St. (Incl. O-RING) 1 O-RING, .644" I.D.
25	1	TUBE ASSY., suction
26	1	KEY, 1/4" Sq.
27	1	CONNECTOR, filter st. (Incl. O-RING) 1 O-RING, .644" I.D.
28	1	PULLEY, "V" belt, 4-1/4"
29	1	"V" BELT
30	1	IDLER
31	1	SPACER, control handles

SERVICE INSTRUCTIONS FOR LOADER LIFT CYLINDERS



DISASSEMBLY

1. Thoroughly clean outside of cylinder assembly.
2. Pull rod out until end of rod and snap ring can be seen through inlet port.
3. Insert screw driver in inlet port and slide snap ring into deep groove in the rod assembly.
4. Remove rod assembly from barrel assembly.
5. Remove shaft seal, O-rings and back-up washers from I.D. of barrel assembly.
6. It is not necessary to inspect shaft seal, back-up washers, O-rings or lock ring. These parts should be replaced as new items and are included in the seal repair kit available for this cylinder.

INSPECTION

1. Thoroughly clean all parts and remove all nicks and burrs with emery cloth.
2. Inspect I.D. of barrel assembly for excessive wear or scoring.

3. Inspect O. D. of rod for nicks, scratches or scoring.

REASSEMBLY

1. All the parts should be cleaned and dried thoroughly. Metal parts should be lightly oiled prior to reassembly.
2. Install new O-ring and back-up washer in I.D. of bearing. Install new shaft seal and bearing with lips facing outboard.
3. Install new lock ring in deep groove of rod end.
4. Oil outside of piston rod and carefully insert rod in barrel assembly.
5. Push rod into barrel assembly until snap ring area of rod can be seen through port.
6. By using screw driver through port, pop snap ring into lock position.
7. Extend rod to full out position to make sure snap ring is locked.


CYLINDER DISASSEMBLY

Remove the cylinder. Push cylinder head assembly and wiper seal into barrel far enough to remove retaining snap ring. Remove snap ring.


Pull piston rod and head assembly out of barrel. Place rod assembly in vise and remove piston retaining nut. Remove piston rod from cylinder head assembly.

Clean, inspect and replace the necessary seals and parts. Reverse procedure for assembly.

BUCKET CYLINDER



LOADER PUMP



DISASSEMBLY

1. Clean outside of pump thoroughly.
2. Clamp pump in vise, shaft down.
3. Use sharp tool to mark across front plate and rear housing. This will assure proper reassembly.
4. Remove 4 capscrews (A).
5. Remove pump from vise - Hold pump in hands and bump shaft against wooden block to separate front plate (L) from rear housing (B).
6. Remove diaphragm (E) from front plate by prying with sharp tool.
7. Lift springs (J) 2 each and steel balls (K) 2 each from front plate.
8. Lift back-up gasket (F) from front plate.
9. Lift protector gasket (G) from front plate.
10. Lift moulded "V" seal (H) from front plate.
11. Remove shaft seal (M) from front plate.
12. Remove relief valve plug (N) from back plate housing and remove shim (O), spring (P) and poppet (Q).

INSPECT PARTS FOR WEAR

GENERAL

1. Clean and dry all parts.
2. Remove nicks and burrs from all parts with emery cloth.

GEAR ASSEMBLY

1. Inspect drive gear shaft (D) for broken tang.
2. Inspect both the drive gear and idler gear shafts at bearing points and seal areas for rough surfaces and excessive wear.
3. If shafts measure less than .4360 in bearing area, the gear assembly should be replaced. (Shafts and gears are available as assemblies only).
4. Inspect gear face for scoring and excessive wear.
5. If gear width is below .331, gear assembly should be replaced.
6. If edge of gear teeth is sharp - break edge with emery cloth.

FRONT AND BACK PLATES

1. Oil grooves in bearings in both front plate and back plate should be in line with dowel pin hole and 180° apart. This positions the oil grooves nearest to the respective dowel pin holes.
2. If I. D. of bearings in front plate or back plate exceed .4375 front or back plate should be replaced. (Bearings are not available as separate items).
3. Bearings in front plate should be flush with islands in groove pattern.
4. Check for scoring on face at bottom of gear pocket. If wear exceeds .001, housing should be replaced.

BODY

1. Check I. D. of gear pockets for excessive scoring or wear.
2. Housing should be replaced if I. D. of gear pocket exceeds 1.1695.

RELIEF VALVE

1. Inspect relief valve poppet for excessive wear. Inspect relief valve spring for breakage.
2. Do not attempt to remove relief valve seat in rear housing assembly as it is pre-set for depth and locked in place.
3. If relief valve pressure needs to be adjusted, shims (O) may be added to increase relief pressure or removed to decrease pressure.

REASSEMBLY

1. The diaphragm, protector gasket, back-up gasket, "V" seal and shaft seal should be replaced as new parts.
2. Tuck moulded "V" seal (H), shown cut-a-way in drawing, into grooves in front plate with open part of "V" section down. (Use dull tool).
3. Press protector gasket (G) into moulded "V" seal.
4. Press back-up gasket (F) into moulded "V" seal.

5. Drop steel balls (K) into respective seats and place springs (J) over balls.

6. Place diaphragm (E) on top of gasket - bronze face up - coined areas must be on suction side.

7. Entire diaphragm (E) must fit inside the raised rim of the moulded "V" seal.

8. Dip gear assemblies into oil and slip into front plate bearings.

9. Apply a thin coat of heavy grease to milled face of rear housing.

10. Note the small passage in the rear housing. Be sure this passage is open and is on the pressure side.

11. Make certain dowel pins (C) are in place. Slide rear housing (B) over gear shafts until dowel pins are engaged.

12. Install bolts (A) and draw up evenly to 8 ft. lbs. torque.

13. Work shaft seal (M) over drive gear shaft taking care not to cut rubber sealing lip. (Oil seal liberally before assembly).

14. Seat shaft seal by tapping with plastic hammer.

15. Install poppet (Q), spring (P) and shim (O) in rear housing. Install new O-ring (R) on plug (N) and install in rear housing.

16. Rotate pump shaft by hand or with pliers. Pump will have small amount of drag, but should turn freely after short period of use.

GENERAL INFORMATION

Direction of rotation on all "G" series pumps may be reversed by removing the tie bolts and rotating rear housing 180°. It is important that relationship of the rear housing and front plate is correct. You will note a small drilled hole in one side of rear housing. This hole must be on the pressure side of the pump. Suction side of back plate is always side with larger port boss.

PLACING PUMP BACK INTO SERVICE

1. If shop test stand is available the following procedure for testing rebuilt pumps is recommended:

a. Mount pump on test stand making sure that the proper level of clean oil is available in reservoir. Check suction line for leaks and obstructions.

b. Start pump and run for three minutes at zero pressure.

c. Intermittently load pump to 500 P.S.I. for three minutes.

d. Intermittently load pump to 1000 P.S.I. for three minutes.

e. Intermittently load pump to 2000 P.S.I. for three minutes.

f. Remove pump from test stand and check for freeness of drive shaft. Check for leaks.

2. If shop test stand not available the following procedure for testing rebuilt pumps is recommended:

a. Mount pump on equipment and run pump at 1/2 engine speed at zero pressure.

b. By operating control valve build pressure intermittently for three minutes.

c. Increase engine speed to full throttle and build pressure intermittently for three minutes.

d. Idle engine and check for leaks.

TROUBLE SHOOTING

POSSIBLE PUMP CONDITION

1. Noisy pump caused
by cavitation

2. Oil heating

3. Shaft seal leakage.

4. Foaming oil.

CAUSE

- a. Oil supply low.
- b. Oil too heavy.
- c. Oil filter plugged.
- d. Suction line plugged or too small .

- a. Oil supply low.
- b. Contaminated oil.
- c. Setting of relief valve too high or too low.
- d. Oil in system too light.

- a. Worn shaft seal.
- b. Broken moulded "V" seal or back-up gasket.
- c. Bearings out of position.
- d. Excessive internal wear.

- a. Low oil level.
- b. Air leaking into suction line.
- c. wrong kind of oil.


REMEDIES

- a. Fill reservoir.
- b. Change to proper viscosity.
- c. Clean filters.
- d. Clean line and check for size.

- a. Fill reservoir.
- b. Drain reservoir and refill with proper viscosity oil.
- c. Set to correct pressure.
- d. Drain reservoir and refill with proper viscosity oil.

- a. Replace shaft seal.
- b. c. d.
If replacing the shaft seal does not stop leakage the pump should be disassembled and checked for items b, c, d.

- a. Fill reservoir.
- b. Tighten fittings.
- c. Drain and fill reservoir with non-foaming oil.



L-12 LOADER ASSEMBLY

ITEM	QTY.	DESCRIPTION
1	1	BUCKET, snow, 42"
2	7	PIN, loader
		1 PIN, roll, 3/16 x 1-1/4
3	1	CYLINDER, bucket
4	1	CLAMP, hose
		1 LOCKWASHER, 1/4
		1 NUT, 1/4NC
5	3	PIN, lift arm cylinder
		1 PIN, roll, 3/16 x 1-1/4
6	1	ARM ASSY., lift
		2 FITTING, lube, 1/4 st.
7	2	CYLINDER, lift arm
8	1	BREATHER
9	1	FRAME ASSY., main
		1 FILTER
		2 PLUG, pipe, 1/4 sq-hd.
10	5	SPACER, (R.H. wheel only)
11	2	ADAPTER ASSY., wheel spacer
		2 SCREW, 7/16NF x 1/2 (R.H. wheel only)
		5 CAPSCREW, 7/16NF x 1 (L.H. wheel)
		5 LOCKWASHER, pltd, 7/16
		5 CAPSCREW, 7/16NF x 1-1/2 (R.H. wheel)
12	8	CAPSCREW, 1/2UNC x 1-1/4
		1 LOCKWASHER, 1/2
		1 NUT, 1/2NC
13	1	FRAME, sub left

Continued

L-12 LOADER ASSEMBLY (Cont'd)

ITEM	QTY.	DESCRIPTION
14	4	SPACERS
15	2	BOARD, floor
16	1	BRACKET, rear left
17	1	BRACKET, rear right
18	1	BRACKET, front mount
19	1	CAPSCREW, 1/2" UNF x 4-1/2" 1 LOCKNUT, 1/2NF
20	1	MOUNT, front
21	4	CAPSCREW, 1/2" UNC x 2-3/4" 1 LOCKWASHER, 1/2 1 NUT, 1/2NC
22	1	FRAME, sub right

PARTS CATALOG

B-1

B-10

B-12

BIG TEN

WHEEL TRACTORS

FOREWORD

This catalog contains complete parts information for the Models B-1, B-10, B-12 & Big Ten Wheel Tractors.

Except for some common hardware, all parts are identified with an item number. Common hardware not identified such as bolts, nuts, cotter pins and lubrication fittings, are listed in the text under the part which they attach or fit into. Note particularly that the quantity of hardware listed is always the quantity required for one part.

Common attaching hardware listed under a part is not included in the assembly, or included with the part unless specified. Example: (Incl. BOLT, LOCKWASHER and NUT).

The extreme right hand column in the parts list entitled "Assembly or Packaged Parts" indicates if an individual part is one of many in a large assembly, or one of several kinds in a package. All numbers shown in the right hand column are listed numerically in the back of this catalog showing the quantity and description of the various parts that make up the assembly or package.

The last section of this catalog contains a part number index to indicate on which page or pages a part number appears.

All illustrations will be found to precede the text of each group or section of which it is a part.

Any changes or corrections for this catalog will appear on the regular supplement form.

INDEX

AXLES, STEERING & WHEELS

AXLE

Front

Models B-1, B-10 Prior S/N 50001 28

Models B-10 Eff. S/N 50001 & up, Big Ten & B-12 30

Rear 26

STEERING

Models B-1 & B-10 Prior S/N 50001 28

Models B-10 Eff. S/N 50001 & up, Big Ten & B-12 30

WHEELS

Dual Rear 25

Front

Models B-1 & B-10 Prior S/N 50001 28

Models B-10 Eff. S/N 50001 & up, Big Ten & B-12 30

Rear 26

CLUTCH & BRAKE SYSTEM

CLUTCH & BRAKE SYSTEM

Model B-1 34

Model B-10 Prior to S/N 50001 36

Models B-10 Eff. S/N 50001 & up, Big Ten & B-12 38

DRIVE TRAIN

DIFFERENTIAL 26

ENGINE

Model B-1 8

Model B-10 Prior to S/N 50001 10

Models B-10 Eff. S/N 50001 & up, & Big Ten 12

Model B-12 14

FUEL SYSTEM (See ENGINE)

Choke Control

Model B-1 19

Models B-10, Big Ten & B-12 22

Filter (See ENGINE Group)

Tank (See ENGINE Group)

Throttle Control

Model B-1 19

Models B-10, Big Ten & B-12 22

GEAR BOX, Bevel 32

MUFFLER (See ENGINE Group)

P.T.O.

Models B-1 & B-10 Prior S/N 50001 44

Models B-10 Eff. S/N 50001 & up, Big Ten & B-12 46

SHAFT, drive (See ENGINE Group)

TRANSMISSION

Controls

Gear Shift

Model B-1 19

Models B-10, Big Ten & B-12 22


Two Speed Pulley

51

Drive Pulley & Belt 50

INDEX

ELECTRICAL SYSTEM	
AMMETER	.42
BATTERY (See ELECTRICAL SYSTEM Group)	
ELECTRICAL SYSTEM	
Model B-1	.40
Models B-10, Big Ten & B-12	42
GENERATOR (See ELECTRICAL SYSTEM Group)	
IGNITION (See ELECTRICAL SYSTEM Group)	
LIGHTING	
Front	
Model B-1	.61
Models B-10 & Big Ten Prior to S/N 1001	63
Models B-10 & Big Ten Eff. S/N 1001 & up, B-12	.62
Rear Work	
First Type	.64
Second Type	65
REGULATOR (See ELECTRICAL SYSTEM Group)	
STARTING MOTOR (See ELECTRICAL SYSTEM Group)	
HITCH & LIFT	
IMPLEMENT HITCH & LIFT	
Controls	
Hydraulic	
Models Big Ten Prior to S/N 44345, B-10 Prior to S/N 50001	.58
Models Big Ten Eff. S/N 44345 & up, B-10 Eff. S/N 50001 & up, B-12	.53
Manual	
L.H.	.16
R.H.	18
Drawbar	16
HYDRAULIC SYSTEM	
CYLINDER, Lift	
Models Big Ten Prior S/N 44345 & B-10 Prior S/N 50001	60
Models Big Ten Eff. S/N 44345 & up, B-10 Eff. S/N 50001 & up, B-12	57
PUMP & LINES	
Models Big Ten Prior S/N 44345, B-10 Prior to S/N 50001	58
Models Big Ten Eff. S/N 44345 & up, B-10 Eff. S/N 50001 & up, B-12	55
SHEET METAL, FRAME & SEAT	
FRAME COUNTERWEIGHTS	66
FRAME & FRONT SHEET METAL	
Model B-1	19
Models B-10, Big Ten & B-12	22
SEAT & SUPPORT	
Models B-1, B-10 & Big Ten	.4
Model B-12	6



SEAT & SUPPORT

* B1 Tractor

** B10 Tractor

*** Big Ten Tractor

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
		* ** ***		
1	2025518	1 - -	FENDER, R.H. (Used prior to Tr. S/N. 5501) - Use 2025870	
			1 907727 CAPSCREW, pltd, 1/4NC x 5/8	
			1 916964 LOCKWASHER, pltd, 1/4	
			1 916622 NUT, pltd, 1/4NC	
			6 922122 SCREW, S-tap, gimlet pt, #10 x 1/2	
	2025870	1 - -	FENDER, R.H. (Eff. on Tr. S/N 5501)	
			3 916019 CAPSCREW, pltd, 1/4NC x 3/4	
			3 916622 NUT, pltd, 1/4NC	
			3 922122 SCREW, S-tap, gimlet pt, #10 x 1/2	
	2026042	- 1 1	FENDER, R.H.	
2			1 908295 CAPSCREW, pltd, 1/4NC x 1/2	
			1 916964 LOCKWASHER, pltd, 1/4	
			1 916622 NUT, pltd, 1/4NC	
			6 922122 SCREW, S-tap, gimlet pt, #10 x 1/2	
	2025580	2 2 -	SUPPORT, back cushion, B10 prior S/N 50001	
3	2026658	- 2 -	SUPPORT, back cushion, B10 Eff. S/N 50001 & up	
	2026389	- - 2	SUPPORT, back cushion	
	2025805	1 - -	CUSHION, backrest	
	2026091	- 1 -	CUSHION, backrest, prior B10 S/N 50001	
	2026657	- 1 -	CUSHION, backrest, B10 S/N 50001 & up	
4	2026390	- - 1	CUSHION, backrest	
			2 907729 CAPSCREW, pltd, 5/16NC x 1-1/4	4 Used Big Ten Tractor
			2 917356 LOCKWASHER, pltd, 5/16NC	
	2025806	1 - -	CUSHION, seat	
	2026092	- 1 1	CUSHION, seat	
			4 916431 CAPSCREW, pltd, 5/16NC x 1	B1 Tractor only
			4 917356 LOCKWASHER, pltd, 5/16	

Continued


SEAT & SUPPORT (Cont'd)

* BlTractor

** B10 Tractor

*** Big Ten Tractor

ITEM	PART NUMBER	* QTY.	**	***	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
5	2025517	1	-	-	FENDER, L. H.	
					1 907727 CAPSCREW, pltd, 1/4NC x 5/8	
					1 916964 LOCKWASHER, pltd, 1/4	
					1 916622 NUT, pltd, 1/4NC	
					6 922122 SCREW, s-tap, gimlet pt, #10 x 1/2	
6	2026043	-	1	1	FENDER, L. H.	
					1 908295 CAPSCREW, pltd, 1/4NC x 1/2	
					1 916964 LOCKWASHER, pltd, 1/4	
					1 916622 NUT, pltd, 1/4NC	
					6 922122 SCREW, s-tap, gimlet pt, #10 x 1/2	
7	2025520	1	1	1	COVER ASSY., seat	
					2 919357 CAPSCREW, pltd, 3/8NC x 7/8	
					2 918006 NUT, lock, coated, 3/8NC	
8	2025834	12	12	12	NUT, speed	
9	2025800	1	1	1	SUPPORT, arm, R. H.	
10	2025799	1	1	1	SUPPORT, arm, L. H.	
11	2025798	2	-	-	PAD, arm rest	
					PAD, arm rest	
					2 908297 CAPSCREW, pltd, 1/4NC x 1-1/4	
12	2026090	-	2	2	2 916964 LOCKWASHER, pltd, 1/4	
					CONNECTOR, cushion	
					1 917372 NUT, pltd, 5/16NC	
13	2026044	4	4	4	1 917356 LOCKWASHER, pltd, 5/16	
					GUARD, starting cup (Eff. on Tr. S/N 5501 & up)	
					3 916019 CAPSCREW, pltd, 1/4NC x 3/4	
14	2025871	1	1	1	3 916964 LOCKWASHER, pltd, 1/4	
					3 916622 NUT, pltd, 1/4NC	
					EMBLEM, trade mark (backrest cushion)	
15	246869	-	-	1		




SEAT & SUPPORT (B12 Tractor)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025520	1	COVER ASSY., seat	
		2	907731 CAPSCREW, pltd, 3/8NC x 1	
		2	918006 NUT, lokut, 3/8NC-2	
		2	922109 BOLT, pltd, 3/8NC x 1-1/4	
		2	916964 LOCKWASHER, pltd, 1/4	
		2	916622 NUT, pltd, 1/4	
2	2025871	1	GUARD, starter, cup	
		3	908295 CAPSCREW, pltd, 1/4NC x 1/2	
		3	916964 LOCKWASHER, pltd, 1/4	
		3	916622 NUT, pltd, 1/4	
3	2025834	12	NUT, speed	
4	2026042	1	FENDER, R.H.	
		6	922122 SCREW, s-tap, #10 x 1/2	
5	2026690	1	PANEL, seat	
6	2026673	2	BAR, backrest support	

Continued

SEAT & SUPPORT (Cont'd)
(B12 Tractor)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
7	2026674	1	SUPPORT, backrest	
		2	920304 SCREW, pltd, 1/4NC x 1-1/4	
		2	916965 LOCKWASHER, pltd, 1/4	
		2	916622 NUT, pltd, 1/4NC	
		2	907729 CAPSCREW, pltd, 5/16NC x 1-1/4	
		2	917356 LOCKWASHER, pltd, 5/16	
		2	917372 NUT, pltd, 5/16NC	
8	2026676	2	PAD, arm rest	
		2	918240 CAPSCREW, 1/4NC x 1-1/2	
		2	916964 LOCKWASHER, 1/4	
9	2026695	1	PLATE, outer	
		4	907729 CAPSCREW, pltd, 5/16NC x 1-1/4	
		4	917356 LOCKWASHER, pltd, 5/16	
10	2026692	1	PAD, seat	
11	2026675	1	CUSHION, backrest	
12	2026043	1	FENDER, L. H.	
		6	922122 SCREW, s-tap, #10 x 1/2	
13	2026847	4	CONNECTOR, cushion	
		4	917372 NUT, pltd, 5/16NC	
		4	917356 LOCKWASHER, pltd, 5/16	
	2026669	1	BRACKET ASSY., seat support, L. H.	
14	2026670	1	BRACKET ASSY., seat support, R. H.	
		2	917356 LOCKWASHER, pltd, 5/16	
		2	917372 NUT, pltd, 5/16NC	
--	2026691	-	TAPE, seat pan (2 ft. per pan)	




**ENGINE, DRIVE SHAFT, FUEL SYSTEM & MUFFLER
(Model B-1)**

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025602	1	FLANGE, drive shaft (Also order 2026033 Setscrew)	
		1	922139 KEY, hi-pro, 3/16 x 3/4	
		1	911712 SETSCREW (1st Type, 5/16NC x 5/16)	
		1	2026033 SETSCREW (2nd Type, 3/8 x 3/8)	
2	2025598	8	SPACER, coupling	
3	2025600	1	COUPLING ASSY., drive	
		2	919360 CAPSCREW, pltd, 3/8NC x 1-1/2	
		2	916965 LOCKWASHER, pltd, 3/8	

Continued

ENGINE, DRIVE SHAFT, FUEL SYSTEM & MUFFLER(Cont'd) (Model B-1)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
4	2025601	1	SHAFT ASSY., drive	
		4	919360 CAPSCREW, pltd, 3/8NC x 1-1/2 (to coupling)	
		4	916965 LOCKWASHER, pltd, 3/8	
		4	916950 NUT, pltd, 3/8NC	
5	2025600	1	COUPLING ASSY.	
		2	919361 CAPSCREW, pltd, 3/8NC x 1-3/4	
		2	916965 LOCKWASHER, pltd, 3/8	
6	2025868	1	SCREEN, engine (Eff. w/Tractor Serial No. 5501 & up)	
		3	908297 CAPSCREW, pltd, 1/4NC x 1-1/4	
		3	916955 WASHER, plain, pltd, 1/4 x 9/16 x #18	
		3	916964 LOCKWASHER, pltd, 1/4	
7	2025869	3	SPACER, screen (Eff. w/Tractor Serial No. 5501 & up)	
8	2025859	1	CONNECTOR, fuel bowl	
9	2025860	1	FILTER ASSY., fuel	
10	2025861	1	FITTING, fuel line	
11	2025688	2	CLAMP, fuel hose	
12	2025687	1	HOSE, fuel flexible	
13	2025857	1	TANK, fuel	
14	2025862	2	STRAP, fuel tank	
		1	917492 SCREW, pltd, fil-hd, 1/4NC x 1-1/2	
		1	916622 NUT, pltd, 1/4NC	
15	2025858	1	CAP, fuel tank	
16	2025851	1	DECAL, "Caution" - Battery	
17	2025668	1	SCREW ASSY., engine, L.H. rear	
18	2025691	1	MUFFLER, exhaust	
18	2025989	1	NUT, lock muffler	
19	2025675	1	GUARD, crankshaft extension	
20	2025509	2	SPACER, engine	
		3	917402 CAPSCREW, pltd, 3/8NC x 2	
		4	916965 LOCKWASHER, pltd, 3/8	
		4	916950 NUT, pltd, 3/8NC	
21	2025676	1	NIPPLE, pipe	
		1	901752 CAP, pipe, 3/8	
22	-----	1	ENGINE ASSY., (Order Parts & Service from local Briggs & Stratton Service Agency)	
23	2025867	1	SEAL, blower housing (Eff. w/Tractor Serial No. 5501 & up)	
24	2025652	1	NUT, lock	
25	2025623	1	PULLEY, engine (Used prior to Tractor Serial No. 5501)	
	2025866	1	PULLEY, engine (Eff. w/Tractor Serial No. 5501 & up)	
--	2025988	1	KIT, air screen (f/converting Tractor prior to Serial No. 5501 to Rotary Screen) (Incl. items 6, 7, 23 & 25)	




ENGINE, DRIVE SHAFT, FUEL SYSTEM & MUFFLER
{Model B-10 Prior to S/N 50001}

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025999	1	TANK ASSY., fuel	
2	2026000	1	CAP, fuel tank	
3	2025998	1	VALVE ASSY., shut-off	
4	2025688	2	CLAMP, hose	
5	2025996	1	HOSE, fuel, flexible	
6	2025652	1	NUT, lock	
7	2025668	1	SCREW ASSY., engine, L.H. rear	
8	2026003	1	SPACER, air cleaner	
			1 921959 CAPSCREW, pltd, Gr. 5, 1/4 NC x 5/8	
			1 917377 WASHER, plain, pltd, 5/16 x 3/4 x #16	
			1 916965 LOCKWASHER, pltd, 1/4	
9	2025691	1	MUFFLER, exhaust	
10	-----	1	ENGINE ASSY. (Order parts and service from local Briggs and Stratton Service Agency)	
			3 917402 CAPSCREW, pltd, 3/8NC x 2	
			4 916965 WASHER, pltd, 3/8	
			4 916950 NUT, pltd, 3/8NC	
			4 917378 WASHER, plain, pltd, 7/16 x 1 x #14	
11	2025675	1	GUARD, crankshaft extension	
12	2025994	1	STOP, axle	
13	2025676	1	NIPPLE, pipe	
			1 901752 CAP, pipe, 3/8	
14	2025995	1	SHROUD, engine	
15	2025997	1	PULLEY, engine	
			2 922127 CAPSCREW, pltd, Gr. 5, 5/16NC x 1-3/4	
			2 917356 LOCKWASHER, pltd, 5/16	

Continued

ENGINE, DRIVE SHAFT, FUEL SYSTEM & MUFFLER(Cont'd)
(Model B-10 Prior to S/N 50001)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
16	2025869	3	SPACER, screen 1 908297 CAPSCREW, pltd, 1/4NC x 1-1/4 1 916955 WASHER, plain, pltd, 1/4 x 9/16 x #18 1 916964 LOCKWASHER, pltd, 1/4NC	
17	2025868	1	SCREEN, engine	
18	912267	2	SCREW, socket head, Gr. 8, 3/8NC x 1 1 916965 LOCKWASHER, pltd, 3/8 1 922132 NUT, lokut, 3/8NF	
19	2026002	2	SPACER	
20	2025600	1	COUPLING ASSY.	
21	2025598	2	SPACER 1 917402 CAPSCREW, pltd, 3/8NC x 2 1 916965 LOCKWASHER, pltd, 3/8NC	
22	2026306	1	SHAFT ASSY., drive	
23	2025598	2	SPACER 1 919360 CAPSCREW, pltd, 3/8NC x 1-1/2 1 916965 LOCKWASHER, pltd, 3/8	
24	2025600	1	COUPLING ASSY.	
25	2025598	2	SPACER 1 919360 CAPSCREW, pltd, 3/8NC x 1-1/2 1 916965 LOCKWASHER, pltd, 3/8 1 922132 NUT, lock, pltd, 3/8NC	
26	2025602	1	FLANGE, drive shaft 1 922139 KEY, hi-pro, 3/16 x 3/4	
27	2026033	1	SETSCREW, flange	
28	2026105	1	DECAL, caution, battery	
29	2026001	2	STRAP, tank 1 919316 CAPSCREW, pltd, 1/4NC x 1-3/4 1 916622 NUT, pltd, 1/4NC	




ENGINE, DRIVE SHAFT, FUEL SYSTEM & MUFFLER
(Model B-10 Eff. W/S/N 50001 & up & Big Ten)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025999	1	TANK ASSY., fuel	
2	2026000	1	CAP, fuel tank	
3	2025998	1	VALVE ASSY., shut-off	
4	2025688	2	CLAMP, fuel hose	
5	2026504	1	HOSE, fuel flexible	
6	2026508	1	SPACER, flywheel	
7	2026507	1	SHROUD, flywheel	
		4	908295 CAPSCREW, pltd, 1/4NC x 1/2	
		4	916964 LOCKWASHER, pltd, 1/4	
8	2025995	1	SHROUD, engine	
9	-----	1	ENGINE ASSY. (Order parts & service from local Briggs & Stratton Agency)	
		3	917402 CAPSCREW, pltd, 3/8NC x 2	
		4	916965 LOCKWASHER, pltd, 3/8	
		4	916950 NUT, pltd, 3/8NC	
		4	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
10	2026850	1	SCREW ASSY., eng. L.H. rear	
11	2026003	1	SPACER, air cleaner	
		1	921959 CAPSCREW, pltd, Gr. 5, 1/4NC x 5/8	
		1	917377 WASHER, plain, pltd, 5/16 x 3/4 x #16	
		1	916964 LOCKWASHER, pltd, 1/4	
12	2026596	1	MUFFLER, exhaust	
13	2025675	1	GUARD, crank, shaft ext.	
14	2025994	2	STOP, axle	

Continued

ENGINE, DRIVE SHAFT, FUEL SYSTEM & MUFFLER (Cont'd)
(Model B-10 Eff. W/S/N 50001 & up & Big Ten)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
15	2026597	1	NIPPLE, pipe 1 901752	CAP, pipe, 3/8
16	2026505	1	PULLEY, engine	
17	2026509	1	HUB, drive 2 919354	CAPSCREW, pltd, 5/16NC x 2
			2 917356	LOCKWASHER, pltd, 5/16
			2 917642	WASHER, plain, pltd, 11/32 x 1-1/2 x #12
18	2026506	1	SCREEN, engine	
19	2026002	4	SPACER, coupler	
20	2026579	2	COUPLING 2 917400	CAPSCREW, pltd, 3/8 NC x 1-1/4
			2 916950	NUT, pltd, 3/8NC
			2 916965	LOCKWASHER, pltd, 3/8
21	2026580	14	WASHER, special	
22	917402	2	CAPSCREW, pltd, 3/8NC x 2 1 916965	LOCKWASHER, pltd, 3/8
23	2026306	1	SHAFT ASSY., drive	
24	2025602	1	FLANGE, drive shaft 2 917400	CAPSCREW, pltd, 3/8NC x 1-1/4
			2 916965	LOCKWASHER, pltd, 3/8
25	2026033	1	SETSCREW	
26	2025602	1	FLANGE, drive shaft (1st type)	
27	2025598	2	SPACER (1st type) 1 919360	CAPSCREW, pltd, 3/8NC x 1-1/2
			1 916965	LOCKWASHER, pltd, 3/8
			1 916950	NUT, pltd, 3/8NC
28	2025600	1	COUPLING (1st Type)	
29	2025598	2	SPACER, coupling (1st Type) 1 917402	CAPSCREW, pltd, 3/8NC x 2
			1 916965	LOCKWASHER, pltd, 3/8
30	2025600	1	COUPLING ASSY., drive (1st Type) 2 912267	CAPSCREW, hex-sock-hd, Gr. 8, 3/8NC x 1
			2 916965	LOCKWASHER, pltd, 3/8
			2 916950	NUT, pltd, 3/8NC-2
31	2026002	2	SPACER, coupling (1st Type)	
32	2026581	1	KEY, square (Eff. w/Tr. S/N 39097)	
	922139	1	KEY, hi-pro, 3/16 x 3/4 (Used prior to Tr. S/N 39097)	
33	2026001	2	STRAP, tank 1 919316	CAPSCREW, 1/4NC x 1-3/4
			1 916622	NUT, 1/4NC
--	2026583	1	DECAL, engine (Not Illustrated)	




ENGINE, DRIVE SHAFT, FUEL SYSTEM & MUFFLER (Model B-12)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026001	2	STRAP, tank 1 919316 CAPSCREW, 1/4NC x 1-3/4 1 916622 NUT, 1/4NC	
2	2026000	1	CAP, fuel tank	
3	2025999	1	TANK, fuel	
4	2025998	1	VALVE, shut-off	
5	2025688	2	CLAMP, hose	
6	2026713	1	HOSE, fuel flexible	
7	-----	1	ENGINE ASSY., 12 HP. (Order parts & Service from local Briggs & Stratton Agency) 1 917402 CAPSCREW, pltd, 3/8NC x 2 2 919361 CAPSCREW, pltd, 3/8NC x 1-3/4 4 916965 LOCKWASHER, pltd, 3/8 4 917378 WASHER, pltd, 7/16 x 1 x #14 4 916950 NUT, pltd, 3/8NC	
8	2026003	1	SPACER, air cleaner 1 921959 CAPSCREW, pltd, Gr. 5, 1/4NC x 5/8 1 917377 WASHER, pltd, 5/16 x 3/4 x #16 1 916964 LOCKWASHER, pltd, 1/4	
9	{ 2025668	1	SCREW ASSY., eng, L.H. rear (Prior S/N 1001)	
	{ 2026850	1	SCREW ASSY., eng, L.H. rear (Eff. S/N 1001)	
10	2025989	1	NUT, lock	
11	2026596	1	MUFFLER, exhaust	

Continued

ENGINE, DRIVE SHAFT, FUEL SYSTEM & MUFFLER(Cont'd)
(Model B-12)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
12	2025675	1	GUARD, crankshaft, extension	
13	2025994	2	STOP, axle	
14	2026597	1	NIPPLE, pipe, 3/8" x 1"	
		1	901752 CAP, pipe, 3/8	
15	2026712	1	PULLEY, engine	
		2	921972 CAPSCREW, pltd, 3/8NC x 2-1/2	
		2	916965 LOCKWASHER pltd, 3/8	
16	2026002	2	SPACER	
17	2026580	10	WASHER, special	
18	2026579	2	COUPLING	
19	2026306	1	SHAFT ASSY., drive	
		4	917400 CAPSCREW, pltd, 3/8NC x 1-1/4	
		6	916965 LOCKWASHER, pltd, 3/8	
		4	916950 NUT, pltd, 3/8NC	
20	2025602	1	FLANGE, drive shaft	
		2	917400 CAPSCREW, pltd, 3/8NC x 1-1/4	
		2	916965 LOCKWASHER, pltd, 3/8	
21	2026033	1	SETSCREW, cup pt, 3/8NC x 5/8	
22	2026581	1	KEY	



**IMPLEMENT LIFT & HITCH
(L.H. Manual Controls)
(Hydraulic & Manual Lift Drawbar)**

*B1 & B10 Tractors prior S/N 50001

**Big Ten Tractor

***B10 Tractor S/N 50001 & up, B12


ITEM	PART NUMBER	*	QTY.		DESCRIPTION	ASSEMBLY OR PACKAGE NO.
			**	***		
1	2025603	2	2	2	ARM ASSY. 1 918212 CAPSCREW, pltd, 7/16NC x 1 1 918199 LOCKWASHER, pltd, 7/16	
2	2025717	2	2	2	COLLAR, set 1 911712 SETSCREW, hex-sock, cup-pt, 5/16NC x 5/16	
3	2025610	1	1	1	LIFT ASSY., tiller	
4	2025231	1	-	-	SPACER, yoke end	
Continued						

Continued

IMPLEMENT LIFT & HITCH (Cont'd)
(L.H. Manual Controls)
(Hydraulic & Manual Lift Drawbar)


*B1 & B10 Tractors prior S/N 50001
**Big Ten Tractor
***B10 Tractor S/N 50001 & up, B12

ITEM	PART NUMBER	*	QTY. **	***	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
5	2025660	2	1	1	YOKE, rod end	
6	2025661	1	-	-	PIN, yoke	
					1 918452 PIN, cotter, pltd, 1/8 x 1	
	2025609	1	-	-	ROD, rear lift	
7	2026553	-	1	1	2 919423 NUT, pltd, 1/2NF	
					1 919423 NUT, pltd, 1/2NF	
8	2025606	1	1	1	QUADRANT, lift lever	
9	2025499	1	1	1	PIN	
10	2025612	1	-	1	LATCH, lift lever	
	2026006	1	1	1	LEVER ASSY., lift (B10 & Big Ten)	
11	2025611	1	-	-	LEVER ASSY., lift (B1 Tractor)	
					1 909007 SETSCREW, hex-sock, cup-pt, 5/16NC x 3/4	
					1 918113 PIN, roll, 3/8 x 1	
12	2026007	1	1	1	GRIP, lift handle (B10 & Big Ten)	
	2025662	1	-	-	GRIP, lift handle (B1 Tractor)	
13	2025614	1	1	1	SPACER, lift lever	
14	2025491	1	1	1	SPRING, lift lever	
15	2025615	1	1	1	BUTTON, thumb	
	2026701	-	-	1	ROD, latch	
16	2025613	1	1	-	ROD, latch	
					1 918448 PIN, cotter, pltd, 3/32 x 1	
17	2025607	2	2	2	BEARING, lift lever	
					3 917400 CAPSCREW, pltd, 3/8NC x 1-1/4	
					1 919357 CAPSCREW, pltd, 3/8NC x 7/8	
					4 916965 LOCKWASHER, pltd, 3/8	
18	2025757	2	2	2	COLLAR, set	
					1 911712 SETSCREW, hex-sock, cup pt, 5/16NC x 5/16	
19	2025552	4	-	-	KEY, lift shaft	
	2026046	-	4	4	KEY, lift shaft	
	2026004	1	-	1	SHAFT ASSY., lift (B10 Tractors)	
20	2026539	-	1	-	SHAFT ASSY., lift (Big Ten Tractor)	
	2025608	1	-	-	SHAFT ASSY., lift (B1 Tractor)	
	2025670	1	-	-	LEVER ASSY., front lift (B1 only)	
21	2026005	1	1	1	LEVER ASSY., front lift (B10 & Big Ten)	
					1 909007 SETSCREW, hex-sock, cup pt, 5/16NC x 3/4	
22	2025604	1	1	1	BAR ASSY., draw	
					4 918212 CAPSCREW, pltd, 7/16NC x 1	
					2 917378 WASHER, plain, pltd, 7/16 x 1 x #14	
					4 918199 LOCKWASHER, pltd, 7/16	
					2 918213 NUT, pltd, 7/16NC	
23	2026009	2	2	2	BAR, pull	
					1 916432 CAPSCREW, 7/16NC x 1-1/4	
					1 918199 LOCKWASHER, pltd, 7/16	
					1 916609 CAPSCREW, pltd, 7/16NC x 1-3/4	
					* 917378 WASHER, plain (As req'd), pltd, 7/16 x 1 x #14	
					1 918199 LOCKWASHER, pltd, 7/16	
					1 918213 NUT, pltd, 7/16NC	
24	2026010	2	2	2	PIN, pull bar	
25	2025739	2	2	2	CLIP, spring	
26	2026008	1	-	1	STOP, seat	
					1 919319 CAPSCREW, pltd, 5/16NC x 7/8	
					1 917356 LOCKWASHER, pltd, 5/16	
					1 917372 NUT, pltd, 5/16NC	
	2026011	1	1	1	PIN, yoke (B10 & Big Ten)	
27	2025661	1	-	-	PIN, yoke (B1 Tractor)	
					1 918452 PIN, cotter, pltd, 1/8 x 1	
28	2025739	1	1	1	CLIP, pin	



**IMPLEMENT HITCH & LIFT
(R.H. Manual Controls)
(Models B-10, Big Ten & B-12)**

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026127	1	LEVER, lift	
		1	919357 CAPSCREW, pltd, 3/8NC x 7/8	
		1	916965 LOCKWASHER, pltd, 3/8	
		1	916950 NUT, pltd, 3/8NC	
2	2026126	1	LATCH, lift lever	
3	2026125	1	ROD, latch, R.H.	
		1	918448 PIN, cotter, pltd, 3/32 x 1	
4	2025615	1	BUTTON, thumb	
5	2025491	1	SPRING, thumb button	
6	2025614	1	SPACER, lever	
7	2026007	1	GRIP, handle	
8	2026122	1	LEVER ASSY., R.H. lift	
		1	916608 CAPSCREW, pltd, 7/16NC x 1-1/2	
		1	918199 LOCKWASHER, pltd, 7/16	
9	2026021	1	NUT, retainer	
10	2026123	1	QUADRANT ASSY., lift lever	
		1	917356 LOCKWASHER, pltd, 5/16	
		1	921332 CAPSCREW, pltd, Gr. 5, 5/16NC x 3/4	
11	2025739	2	CLIP, spring	
12	2025333	1	ROD, front lift	
13	2026124	1	SPACER, lever	
14	2026128	2	WASHER, plain	



**CHOKE & THROTTLE CONTROL
TRANSMISSION GEAR SHIFT CONTROLS
FRAME & FRONT SHEET METAL
(Model B-1)**

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025514	1	SUPPORT ASSY., seat	
		4	916431 CAPSCREW, pltd, 5/16NC x 1	
		4	917356 LOCKWASHER, pltd, 5/16	
		4	917372 NUT, pltd, 5/16NC	
2	2025648	1	PLUG, button	
3	2025720	1	BALL	
4	2025519	1	COVER ASSY., frame	
		6	922125 SCREW, thd, cutting, pltd, 1/4NC x 7/8	
		6	916964 LOCKWASHER, pltd, 1/4	
5	2025653	1	CONTROL, throttle lever	
		2	922124 SCREW, s-tap, pltd, #10NC x 1	
6	2025649	1	BUSHING, steering post	
7	2025818	1	SUPPORT ASSY., steering post	
		1	917396 CAPSCREW, pltd, 1/4NC x 1	
		3	916019 CAPSCREW, pltd, 1/4NC x 3/4	
		4	916964 LOCKWASHER, pltd, 1/4	
		4	916622 NUT, pltd, 1/4NC	
8	2025655	1	WIRE, throttle	
9	2025654	1	CABLE, throttle	
	2025833	2	LOCKNUT, control cable	

Continued


CHOKE & THROTTLE CONTROL (Cont'd)
TRANSMISSION GEAR SHIFT CONTROLS
FRAME & FRONT SHEET METAL
(Model B-1)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
10	338338	2	TRANSFER, Allis-Chalmers	
11	2025507	1	BAR, hood latch	
		2	917397 CAPSCREW, pltd, 5/16NC x 3/4	
		2	917356 WASHER, pltd, 5/16	
		2	917372 NUT, pltd, 5/16NC	
12	2025747	2	BUSHING, latch bar	
13	2025794	1	HOOD ASSY.	
14	2025595	2	PIVOT ASSY., hood	
		2	917400 CAPSCREW, pltd, 3/8NC x 2-1/4	
		10	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		2	916965 LOCKWASHER, pltd, 3/8	
		2	916950 NUT, pltd, 3/8NC	
		2	918006 NUT, lock, coated, 3/8NC	
15	2025669	2	BUMPER, hood	
16	2025801	1	PLATE, side, L.H.	
		3	922122 SCREW, s-tap, gimlet pt, #10NC x 1/2	
17	2025708	1	PLATE, cover	
		2	922122 SCREW, s-tap, gimlet pt, #10NC x 1/2	
18	2025796	1	GRILLE	
19	2025707	1	SUPPORT ASSY., grille	
		4	918228 CAPSCREW, side, pltd, 3/8NC x 5/8	
		2	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		4	917356 LOCKWASHER, pltd, 3/8	
		1	907729 CAPSCREW, front, pltd, 5/16NC x 1-1/4	
		1	917642 WASHER, plain, pltd, 11/32 x 1-1/2 x #12	
		1	917356 LOCKWASHER, pltd, 5/16	
20	2025693	1	BRACKET ASSY.	
		1	916431 CAPSCREW, pltd, 5/16NC x 1	
		1	917356 LOCKWASHER, pltd, 5/16	
		1	917372 NUT, pltd, 5/16NC	
21	2025510	1	ANGLE, frame, front	
		4	919357 CAPSCREW, pltd, 3/8NC x 7/8	
		4	916965 LOCKWASHER, pltd, 3/8	
		4	916950 NUT, pltd, 3/8NC	
22	2025710	1	ANGLE, frame rear	
23	2025516	1	FRAME ASSY., main - Use 2026028	
		4	916608 CAPSCREW, pltd, 7/16NC x 1-1/2	
		4	918199 LOCKWASHER, pltd, 7/16	
24	2025512	1	FOOT REST	
		2	907731 CAPSCREW, pltd, 3/8NC x 1	
		2	916965 LOCKWASHER, pltd, 3/8	
		2	916950 NUT, pltd, 3/8NC	
25	2025704	1	CLIP, speed	
26	2025355	1	CLIP, choke cable	
		1	908295 CAPSCREW, pltd, 1/4NC x 1/2	
		1	916964 LOCKWASHER, pltd, 1/4	
		1	916622 NUT, pltd, 1/4NC	
27	2025701	1	CABLE, choke	
28	2025702	1	WIRE, choke cable	
29	2025620	1	CLAMP, choke cable	
30	2025793	1	COLLAR	
		1	922116 CAPSCREW, pltd, 5/16NC x 3/8	
		1	917356 LOCKWASHER, pltd, 5/16	
31	2025620	1	CLAMP, choke cable	
		1	917377 WASHER, plain, pltd, 5/16 x 3/4 x #16	
		1	922125 SCREW, s-tap, pltd, 1/4NC x 7/8	
32	2025581	1	ROD ASSY., shifter	
		1	919933 CAPSCREW, pltd, 5/16NC x 1-1/2	
		1	917356 LOCKWASHER, pltd, 5/16	
		1	917372 NUT, pltd, 5/16NC	
33	2025650	1	GROMMET, rubber	
34	2025671	1	DECAL, shift instruction	
35	2025706	1	WASHER, spacer	
36	2025443	1	DECAL, choke	
37	2025705	1	LEVER, choke	
		1	922125 SCREW, s-tap, pltd, 1/4NC x 7/8	
		1	917377 WASHER, plain, pltd, 5/16 x 3/4 x #16	
38	2025703	1	CLAMP, wire	
39	2025659	2	WASHER, plain nylon	

Continued

CHOKE & THROTTLE CONTROL (Cont'd)
TRANSMISSION GEAR SHIFT CONTROLS
FRAME & FRONT SHEET METAL
(Model B-1)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
40	2025802	1	PLATE, side, R.H.	
		3	922122 SCREW, s-tap, gimlet-hd, #10 x 1/2	
41	2025834	2	NUT, speed	
42	2025803	1	EDGE, rubber, grille	
43	{ 2025811	1	TRANSFER, side panel, L.H.	
	{ 2025812	1	TRANSFER, side panel, R.H.	
44	2025807	1	STRIPING, black	
45	2025813	2	LABEL, Model No.	
46	{ 2025809	1	EMBLEM, A-C front	
	{ 2025810	2	NUT, speed emblem attaching	
47	2025797	1	SPACER, hood	
48	2025852	1	DECAL (Choke On)	



**CHOKE & THROTTLE CONTROLS
TRANSMISSION GEAR SHIFT CONTROLS
FRAME & FRONT SHEET METAL**

*** B10 Tractor(Prior S/N 50001)**

**** Big Ten Tractor**

***** B10 S/N 50001 & up, B12**

ITEM	PART NUMBER	*	QTY. **	***	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026034	1	1	1	FOOT REST	
				2	908127 CAPSCREW, pltd, 3/8NC x 3/4	
				2	916965 LOCKWASHER, pltd, 3/8	
				2	916950 NUT, pltd, 3/8	
2	(2026035	1	1	1	PAD, foot rest, L.H.	
	2026036	1	1	1	PAD, foot rest, R.H.	
3	2026028	1	1	1	FRAME ASSY., main	
				6	918199 LOCKWASHER, pltd, 7/16	
				6	916608 CAPSCREW, pltd, 7/16NC x 1-1/2	
				2	918213 NUT, pltd, 7/16NC	

Continued

CHOKE & THROTTLE CONTROLS (Cont'd)

TRANSMISSION GEAR SHIFT CONTROLS

FRAME & FRONT SHEET METAL

* B10 Tractor (Prior S/N 50001)

** Big Ten Tractor

*** B10 S/N 50001 & up, B12

ITEM	PART NUMBER	* QTY.	**	***	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
4	2026013	1	1	1	RETAINER, nut	
5	2026038	1	1	1	GUIDE ASSY., shift rod	
6	2026037	1	1	1	ROD ASSY., shifter	
					1 919933 CAPSCREW, pltd, 5/16NC x 1-1/2	
					1 917356 LOCKWASHER, pltd, 5/16	
					1 917372 NUT, pltd, 5/16NC	
7	2026013	2	2	2	RETAINER, nut	
8	2026012	1	1	1	COVER, frame	
					8 921959 CAPSCREW, pltd, Gr. 5, 1/4NC x 5/8	
					8 916964 LOCKWASHER, pltd, 1/4	
9	2025720	1	1	1	BALL, shift rod knob	
10	2026016	1	1	1	PANEL, side, R.H.	
					3 921959 CAPSCREW, pltd, Gr. 5, 1/4NC x 5/8	
					3 916964 LOCKWASHER, pltd, 1/4	
11	2026018	1	1	1	DASH ASSY.	
					8 921959 CAPSCREW, pltd, Gr. 5, 1/4NC x 5/8	
					8 916964 LOCKWASHER, pltd, 1/4	
12	2026027	4	4	4	SPRING, conical	
					1 918005 NUT, lock, coated, 5/16NC	
13	2026025	4	-	-	SCREW, shoulder, hood attaching	
14	2026356	-	4	4	TEE, handle assy.	
	2026013	8	8	8	RETAINER, nut	
	2026716	-	-	1	CONTROL, dual, throttle & choke	
	2026039	1	1	-	CONTROL, dual, throttle & choke	
15					2 918240 CAPSCREW, pltd, 1/4NC x 1-1/2	
					2 916964 LOCKWASHER, pltd, 1/4	
					2 916622 NUT, pltd, 1/4NC	
16	2026015	1	1	1	BUSHING, steering	
17	2026511	-	1	1	RING, snap	
18	2026024	1	1	1	HOOD	
19	2026019	1	1	1	NUT, flange, whiz lock	
20	2026017	1	1	1	PANEL, side, L.H.	
					3 921959 CAPSCREW, pltd, Gr. 5, 1/4NC x 5/8	
					3 916964 LOCKWASHER, pltd, 1/4	
21	2026103	1	-	-	TRANSFER, hood, L.H.	
	2026393	-	1	1	TRANSFER, hood, L.H.	
	2026104	1	-	-	TRANSFER, hood, R.H.	
	2026392	-	1	1	TRANSFER, hood, R.H.	
22	2026040	1	-	-	CLIP, choke cable	
	2026032	-	1	1	CLIP, choke cable	
23	2025833	4	2	2	LOCKNUT, control	
24	2026026	4	4	4	NUT	
25	2026097	1	1	1	TRIM, grille	
	2026096	1	-	-	BRACKET, grille	
26	2026387	-	1	1	BRACKET, grille	
	2026095	1	-	-	GRILLE	
27	2026386	-	1	1	GRILLE	
	2026098	1	1	1	PLATE, side, L.H.	
28	2026099	1	1	1	PLATE, side, R.H.	
					3 922122 SCREW, self-tap, gimlet hd, #10 x 1/2	
29	-----	1	-	-	EMBLEM (Discontinued)	
	246869	-	1	1	EMBLEM, A-C	
30	2026593	1	1	1	COVER & TUBE ASSY.	
					1 907729 CAPSCREW, pltd, 5/16NC x 1-1/4	
					1 917356 LOCKWASHER, pltd, 5/16	
					1 917642 WASHER, plain, pltd, 11/32 x 1-1/2 x #12	
31	2026023	1	1	1	BRACKET, grille (B10)	
	2026715	-	-	1	BRACKET, grille (B12)	
32	2026041	1	-	-	CLIP, throttle cable	
					1 921280 SCREW, thd-cut, 1/4NC x 1/2	
					1 916964 LOCKWASHER, pltd, 1/4	
33	2026032	1	1	1	CLAMP	
34	2026013	4	4	4	RETAINER, nut	
35	2026014	1	1	1	SUPPORT ASSY.	
					4 919318 CAPSCREW, pltd, 5/16NC x 5/8	
					4 917356 LOCKWASHER, pltd, 5/16	
					4 917372 NUT, pltd, 5/16NC	

Continued

CHOKE & THROTTLE CONTROLS (Cont'd)

TRANSMISSION GEAR SHIFT CONTROLS


FRAME & FRONT SHEET METAL

* B10 Tractor (Prior S/N 50001)

** Big Ten Tractor


*** B10 S/N 50001 & up, B12

ITEM	PART NUMBER	*	QTY.			DESCRIPTION	ASSEMBLY OR PACKAGE NO.
			**	***			
36	2026021	2	2	2		NUT, retainer	
37	{ 2026022	1	1	-		BRACKET ASSY.	
	2026714	-	-	1		BRACKET ASSY.	
38	2026029	1	1	1		WEIGHT, base	
					2 919933	CAPSCREW, pltd, 5/16NC x 1-1/2	
					2 917356	LOCKWASHER, pltd, 5/16	
					2 913620	CAPSCREW, pltd, 7/16NF x 1-1/2	
					2 918199	LOCKWASHER, pltd, 7/16	
39	2026030	1	1	1		SUPPORT	
40	2026020	2	2	2		NUT, retainer	
41	{ 2026600	1	1	1		ANGLE, frame (B10)	
	2026600	-	-	1		ANGLE, frame (B12)	
42	2026304	1	1	1		INSULATOR, control cable	
43	2026403	-	1	1		PLATE ASSY., emblem	
44	2026510	-	1	1		BRACKET, throttle cable	
45	{ 2025620	-	1	-		CLAMP, throttle cable	
	2026717	-	-	1		CLAMP, throttle cable	
46	2026402	1	-	-		BRACKET, hood fastening (Used if fastening ears break)	
--	2026848	1	1	1		TRANSFER, safety, dash assy. (Not Illustrated)	
--	2026102	1	1	-		FILM, shift pattern (Not Illustrated)	
--	2026093	1	-	-		FILM, decorative, dash (Not Illustrated)	
	{ 2026394	-	1	-		TRANSFER, "Big Ten"	
--	2026665	-	-	1		PLATE ASSY (B10, B12)	
	2026666	-	-	1		DECAL (B10)	
	2026668	-	-	1		DECAL (B12)	
--	{ 2026664	-	-	2		DECAL, side panel, B10	
	2026667	-	-	2		DECAL, side panel, B12	



DUAL REAR WHEELS

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025761	2	WHEEL, rear (less tire)	
2	2025690	2	ADAPTOR ASSY., dual wheel	
3	2025689	5	STUD, adaptor	
		1	913901 NUT, pltd, 7/16NF	
		1	918199 LOCKWASHER, pltd, 7/16	



REAR WHEELS, AXLE & DIFFERENTIAL

* B1, Big Ten, B10 Prior S/N 50001

** B10 S/N 50001 & up, B12

ITEM	PART NUMBER	QTY.		DESCRIPTION	ASSEMBLY OR PACKAGE NO.
		*	**		
-	2027198	-	1	DIFFERENTIAL ASSY., (Incl. R.H. WHEEL HUB ASSY. 10, 17 thru 29)	
-	2025841	1	-	DIFFERENTIAL ASSY., (Incl. R.H. WHEEL HUB ASSY. Item 10 & Items 17 thru 29)	
1	2025760	10	10	BOLT, wheel hub	
2	2026089	2	-	WHEEL, rear (Less Tires) (B10 Tractors)	
	2025761	2	-	WHEEL, rear (Less Tires) (B1 Tractor)	
	2026698	-	2	WHEEL, rear (Less Tires)	
3	-----	2	-	TIRES & TUBES, 6 x 12, 2 ply (B1 Tractor) (Not serviced-Obtain locally)	
	-----	2	2	TIRES, tubeless, 8 x 12, 2 ply (B10 tractor) (Not Serviced-Obtain Locally)	
4	2025525	2	2	COLLAR, axle	
			2	911712 SETSCREW, hex-socket, cup-pt, 5/16NC x 5/16 (R.H.)	


Continued

REAR WHEELS, AXLE DIFFERENTIAL (Cont'd)

* B1, Big Ten, B10 Prior S/N 50001

** B10 S/N 50001 & up, B12

ITEM	PART NUMBER	QTY.		DESCRIPTION	ASSEMBLY OR PACKAGE NO.
		*	**		
5	2025233	1	1	BEARING, R.H. outer	
6	2025494	1	1	BEARING, R.H. center (nylon)	
7	2025500	1	1	BEARING, R.H. inner	
8	2025760	2	2	BOLT, traction control	
9	2017493	2	2	SETSCREW (Used when mtg. Loader on B10 Tractor)	
9	2025495	2	2	PLUG, hub	
10	2025840	1	1	HUB ASSY., wheel, R.H. (Incl. HUB & Items 5, 6, 7, 8, 9 & 11)	
				5 916227 PIN, roll, 1/4 x 1	
				5 921450 PIN, roll, 5/32 x 1	
11	2025700	1	1	GEAR, differential	
12	2025524	1	-	AXLE, rear (B1 Tractor)	
12	2026047	1	1	AXLE, rear (B10 & Big Ten)	
13	2025490	1	-	KEY, drive (B1 Tractor)	
13	2026046	1	1	KEY, drive (B10 & Big Ten)	
14	2025230	3	3	WASHER, axle	
15	2026573	1	1	KEY, L.H. hub	
16	2025605	1	1	HUB, wheel, L.H.	
17	2025441	1	1	SEAL, oil, differential cover	
18	2025489	1	1	COVER, differential	
19	917642	8	8	WASHER, plain, pltd, 3/8 x 7/8 x #16	
20	2025444	6	6	PINION, differential	
21	2025437	8	8	SPINDLE, pinion, differential	
22	2025438	8	8	SPACER, differential	
23	2025643	1	1	WASHER, axle	
24	2025651	1	1	RING, retaining	
25	2025502	3	3	WASHER, axle	
26	2025445	1	1	GEAR, differential	
27	2025511	1	1	WASHER, axle	
28	2025439	1	1	COVER, differential	
				6 908295 CAPSCREW, pltd, 1/4NC x 1/2	
				6 916622 NUT, pltd, 1/4NC	
				6 916964 LOCKWASHER, pltd, 1/4	
29	2026045	-	1	CARRIER, differential (B10 & Big Ten)	
29	2025523	1	-	CARRIER, differential (B1 Tractor)	
				7 919362 CAPSCREW, pltd, 3/8NC x 2-1/4	
				7 918006 NUT, lock, coated, 3/8NC	
30	2025826	2	2	SETSCREW, L.H. collar	
31	2025835	1	1	KEY, hi-pro, axle	
32	2025829	1	1	SETSCREW, L.H. hub	
				1 922131 NUT, jam, hy, 3/8NC	
33	2025825	1	1	SETSCREW, L.H. hub	
				1 922131 NUT, jam, hy, 3/8NC	
34	2026048	2	2	STEM, valve	
35	2026107	2	2	CAP, hub (chrome) optional	




FRONT AXLE, STEERING & WHEELS
(Models B10 Prior to S/N 50001 & B1)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025717	2	COLLAR, set	
		1	909007 SETSCREW, hex-sock, cup-pt, 5/16NC x 3/4	
2	2025353	8	WASHER, axle	
3	2025697	4	CONE, bearing (Incl. SEAL) (Inside)	2026591
4	328002	4	CUP, bearing cone	2026591
5	2025711	2	WHEEL ASSY., front (Incl. Item 4)	
6	-----	2	WHEEL ASSY., front (Incl. Items 3, 4, 5 & TIRES & TUBES)(Obtain Locally)	
	-----	2	TIRES, 4.80 x 4.00 (Not Serviced, Obtain Locally)	
	2025498	2	TUBES, 4.00 x 4.00	
7	2025589	1	SPINDLE ASSY., R.H.	
		1	917400 CAPSCREW, pltd, 3/8NC x 1-1/4	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		1	916965 LOCKWASHER, pltd, 3/8	
		1	916950 NUT, pltd, 3/8	
		1	918459 PIN, cotter, pltd, 3/16 x 1-1/2	
8	2025649	4	BEARING, axle	
9	2025722	4	WASHER, axle	
10	2025593	2	SPACER, spindle	
11	2025592	1	LINK, drag	

Continued

FRONT AXLE, STEERING & WHEELS (Cont'd)
(Models B10 Prior to S/N 50001 & B1)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
12	2025624	1	AXLE ASSY., front	
		2	912808 FITTING, lube, str, taper, 1/4-28NS x 1/2	
13	2025594	1	SPACER, axle capscREW	
14	2025588	1	SPINDLE ASSY., L.H.	
		1	917400 CAPSCREW, pltd, 3/8NC x 1-1/4	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		1	916965 LOCKWASHER, pltd, 3/8	
		1	916950 NUT, pltd, 3/8NC	
15	2025590	1	ARM ASSY., steering, L.H.	
		1	922139 KEY, hi-pro, 3/16 x 3/4	
16	2025657	2	JOINT, ball	
		2	916966 LOCKWASHER, pltd, 1/2	
		1	919423 NUT, pltd, 1/2NF	
	2025591	1	ROD, tie (B1 Tractor)	
		2	919262 NUT, jam, pltd, 1/2NF	
17	2026571	1	ROD, tie (B10 Tractor)	
		2	918403 NUT, jam, pltd, 3/8NF	
18	2025817	1	SHAFT ASSY., steering	
		1	905123 KEY, woodruff, 3/16 x 3/4	
19	2025504	2	SPACER, steering shaft capscREW	
20	2025582	1	PIN, universal joint	
		2	921965 CAPSCREW, pltd, Gr. 5, 3/8NC x 3/4	
		2	916965 LOCKWASHER, pltd, 3/8	
		2	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
21	2025583	1	SHAFT ASSY., steer pin	
		1	905123 KEY, woodruff, 3/16 x 3/4	
		1	918005 NUT, lock, pltd, 5/16NC	
22	2025586	1	GEAR ASSY., steering	
		1	905123 KEY, woodruff, 3/16 x 3/4	
23	2025722	2	WASHER, steering gear bearing	
24	2025585	2	BEARING, steering gear	
		1	912808 FITTING, lube, str, taper, 1/4-28NS x 1/2	
		3	919318 CAPSCREW, pltd, 5/16NC x 5/8	
		3	917356 LOCKWASHER, pltd, 5/16	
25	2025587	1	ARM ASSY., steering	
26	2025632	2	RING, retaining	
27	2025584	1	PINION, steering gear	
28	2025353	3	WASHER	
29	2025699	2	CUP, spring	
30	2025698	1	SPRING, compression	
31	2025656	1	WHEEL, steering	
		1	911712 SETSCREW, hex-sock, cup-pt, 5/16NC x 5/16	
32	2025826	1	SETSCREW, L.H. steering arm	
33	2025830	1	CAPSCREW, steer pin	
34	2025826	2	SETSCREW	
35	2025804	2	CAP, hub (Plastic)	
36	2025697	2	CONE, bearing, w/Seal (Used prior to Tr. S/N 5501)	
	327527	2	CONE, bearing, w/o Seal (Eff. w/Tr. S/N 5501 & up)	2026591
37	2025872	2	CAP, hub (Metal)	
	2026106	2	CAP, hub, chrome (Optional)	
	2026049	1	CAPSCREW, front axle (B10 Tractor)	
38	917404	1	CAPSCREW, front axle (B1 Tractor), pltd, 1/2NC x 1-1/2	
		1	918431 WASHER, plain, pltd, 9/16 x 1-3/8 x #10	
		1	918008 NUT, lock, pltd, 1/2NC	
39	2025717	1	COLLAR, set	
		1	909007 SETSCREW, hex-sock, cup-pt, 5/16NC x 3/4	



FRONT AXLE, STEERING & WHEELS
 * Big Ten Tractor
 ** B10 Tractor S/N 50001 & up, B12)

ITEM	PART NUMBER	QTY.		DESCRIPTION	ASSEMBLY OR PACKAGE NO.
		*	**		
1	2025717	2	-	COLLAR, set 1 909007 SETSCREW, hex-sock, cup-pt. 5/16 x 3/4	
2	{ 2025353	8	8	WASHER, axle (Use 6 on B-12)	
	{ 2025722	2	2	WASHER, axle (B-12)	
3	327527	2	2	CONE, bearing	2026591
4	328002	4	4	CUP, bearing	2026591
5	{ 2025711	2	-	WHEEL ASSY., front (Incl. item 2)	
	{ 2026699	-	2	WHEEL ASSY., front (Incl. item 2)(B10 S/N 50001 & up)	
	{ 2026696	-	2	WHEEL ASSY., front (Incl. item 2)(B12)	
6	{ -----	2	2	TIRES, 4.80 x 4.00 (Big Ten & B10 S/N 50001 & up) (Obtain Locally)	
	{ -----	-	2	TIRE, tubeless, (B12)(Obtain Locally)	
	{ 2025498	2	2	TUBE, tire (Big Ten & B10 S/N 50001 & up)(B12)	
7	2025697	2	2	CONE, bearing (Incl. SEAL)	2026591
	{ 2026513	1	-	SPINDLE ASSY., R.H. (Big Ten)	
	{ 2026704	-	1	SPINDLE ASSY., R.H. (B10 S/N 50001 & up & B12)	
8			1	917400 CAPSCREW, pltd., 3/8NC x 1-1/4	
			1	917378 WASHER, plain, pltd., 7/16 x 1 x #14	
			1	916965 LOCKWASHER, pltd., 3/8	
			1	916950 NUT, pltd., 3/8NC	


Continued

FRONT AXLE, STEERING & WHEELS (Cont'd)

* Big Ten Tractor

** B10 Tractor S/N 50001 & up, B12)

ITEM	PART NUMBER	QTY. * **	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
9	2025722	4 4	WASHER, spindle	
10	2025593	2 2	SPACER, drag link	
11	2025592	1 -	LINK, drag (Big Ten)	
	2026711	- 1	LINK, drag (B10 S/N 50001 & up & B12)	
12	2026524	1 1	RING, retaining	
13	2025649	4 4	BEARING, spindle	
	2025624	1 -	AXLE ASSY., front (Big Ten)	
14	2026706	- 1	AXLE ASSY., front (B10 S/N 50001 & up & B12)	
		2	912808 FITTING, lube, str, taper, 1/4, 28NS x 1/2	
	2026514	1 -	SPINDLE ASSY., L.H.	
	2026705	- 1	SPINDLE ASSY., L.H. (B10 S/N 50001 & up & B12)	
15		1	917400 CAPSCREW, pltd, 3/8NC x 1-1/4	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		1	916965 LOCKWASHER, pltd, 3/8	
		1	916950 NUT, pltd, 3/8NC	
16	2026049	1 1	CAPSCREW, front axle	
		1	918431 WASHER, plain, pltd, 9/16 x 1-3/8 x #10	
		1	918008 NUT, lock, pltd, 1/2NC	
17	2025594	1 -	SPACER, axle capscrow (Big Ten)	
	2026707	- 1	SPACER, axle capscrow (B10 S/N 50001 & up & B12)	
	2025590	1 -	ARM ASSY., steering, L.H. (Big Ten)	
18	2026708	- 1	ARM ASSY., steering, L.H. (B10 S/N 50001 & up & B12)	
		1	922139 KEY, hi-pro, 3/16 x 3/4	
19	2025826	1 1	SETSCREW	
20	2025657	2 2	JOINT, ball	
		2	916966 LOCKWASHER, pltd, 1/2	
		1	919423 NUT, pltd, 1/2NF	
21	2026571	1 1	ROD, tie	
		2	919262 NUT, jam, pltd, 1/2NF	
22	2025656	1 -	WHEEL, steering	
	2026697	- 1	WHEEL, steering	
		1	911712 SETSCREW, hex-sock, cup-pt, 5/16NC x 5/16	
23	2025717	1 1	COLLAR, set	
		1	909007 SETSCREW, hex-sock, cup-pt, 5/16NC x 3/4	
24	2026511	1 1	RING, snap	
25	2026516	1 1	SHAFT ASSY., steering	
		1	905123 KEY, woodruff, 3/16 x 3/4	
26	2026523	1 1	GEAR, steering	
		1	918213 NUT, pltd, 7/16NC	
		1	918199 LOCKWASHER, pltd, 7/16	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
27	2025354	1 1	WASHER, arbor	
28	2025722	2 2	WASHER, gear	
29	2026522	1 1	ARM ASSY., steering	
30	2025626	2 2	BEARING, needle	
31	2026521	1 1	BRACKET, steering	
		1	917091 SETSCREW, sq-hd, cup pt, 1/4NC x 5/8	
		1	917356 LOCKWASHER, pltd, 5/16	
		1	919318 CAPSCREW, pltd, 5/16NC x 5/8	
32	2026518	1 1	BUSHING	
33	2026517	1 1	BUSHING ASSY., eccentric	
34	2025504	2 2	SPACER, eccentric bushing	
		1	921965 CAPSCREW, pltd, Gr. 5, 3/8NC x 3/4	
		1	916965 LOCKWASHER, pltd, 3/8NC	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
35	2026519	1 1	PIN, eccentric	
36	2025830	2 2	CAPSCREW, U-joint	
		1	918005 NUT, lock, pltd, 5/16NC	
37	2025582	1 1	PIN, U-joint	
38	2026520	1 1	RING, retaining	
39	2025872	2 2	CAP, hub	
	2025804	2 2	CAP, hub, plastic	
--	2026663	- 1	DECAL, steering wheel (B-10)	
--	2026721	- 1	CAP, steering	



BEVEL GEAR BOX

* B1 Tractor

** B10, B12 & Big Ten Tractors

ITEM	PART NUMBER	QTY.		DESCRIPTION	ASSEMBLY OR PACKAGE NO.
		*	**		
1	2025725	1	1	KEY, drive pulley	
2	2025640	1	1	PULLEY, drive (Std.)	
	2025709	1	1	PULLEY, drive (f/Low Speed Drive)	
				1 911712 SETSCREW, hex-sock, cup-pt, 5/16NC x 5/16	
3	2025641	1	1	V-BELT, drive pulley (Std.) (Belt No. 154273)	
	2025712	1	1	V-BELT, drive pulley (f/low Speed Drive) (Belt #155004)	
4	2025579	1	1	PLATE, side	
				3 918212 CAPSCREW, pltd, 7/16NC x 1	
				3 918199 LOCKWASHER, pltd, 7/16	
				1 916432 CAPSCREW, top, pltd, 7/16NC x 1-1/4	
5	2025574	-	-	SHIM, (Use as req'd.)	
6	2025575	1	1	SHIM, pulley	
7	2025573	1	1	SPACER, pulley	
8	2025644	1	1	SEAL, oil	
9	2025427	1	1	BEARING, ball	
10	2026582	1	1	SHAFT, drive	
11	2025433	1	1	RING, snap	
12	2025515	1	1	PLATE, bearing clamp	
				1 919318 CAPSCREW, pltd, 5/16NC x 5/8	
				1 917356 LOCKWASHER, pltd, 5/16NC	


Continued

BEVEL GEAR BOX (Cont'd)

* B1 Tractor

** B10, B12 & Big Ten Tractors

ITEM	PART NUMBER	QTY.		DESCRIPTION	ASSEMBLY OR PACKAGE NO.
		*	**		
13	2025576	1	1	GEAR, bevel, driven	
14	2025647	1	1	GASKET, housing	
15	2025578	1	1	COVER ASSY., gear housing	
				6 907727 CAPSCREW, pltd, 1/4NC x 5/8	
				1 901652 PLUG, pipe, sq-hd, solid, 1/8	
				1 901653 PLUG, pipe, sq-hd, solid, 3/8	
				1 910149 ELBOW, street, 45°, 3/8	
				1 909367 LOCKWASHER, int-tooth, pltd, 1/4	
16	2025646	1	1	CAPSCREW	
17	2025508	1	1	WASHER	
18	2025572	1	1	SHAFT, driven	
				1 905123 KEY, woodruff, 3/16 x 3/4	
				1 922133 NUT, jam, pltd, 1/2NC	
19	2025564	1	1	GEAR, bevel, driven	
20	2025427	1	1	BEARING	
21	2026581	1	1	KEY, square	
	922139	1	1	KEY, hi-pro, 3/16 x 3/4	
22	2025674	1	1	PLUG, pipe, gear housing	
23	2025579	1	1	PLATE, side	
				3 918212 CAPSCREW, pltd, 7/16NC x 1	
				3 918199 LOCKWASHER, pltd, 7/16	
				1 916432 CAPSCREW, pltd, 7/16NC x 1-1/4	
24	2025432	1	1	SEAL, oil	
25	2025645	1	1	BEARING, needle	
26	2025631	1	1	SEAL, oil	
27	2025626	1	1	BEARING, needle	
28	2025522	1	1	HOUSING ASSY., bevel gear (Incl. BEARINGS)	
29	2025555	1	1	GUARD ASSY., belt	
30	2025554	1	-	PULLEY, forward	
				2 911712 SETSCREW, hex-sock, cup-pt, 5/16NC x 5/16	
				1 905123 KEY, woodruff, 3/16 x 3/4	
31	2025692	1	-	PULLEY, rope, starter	
				2 919319 CAPSCREW, pltd, 5/16NC x 7/8	
				2 917356 LOCKWASHER, pltd, 5/16	
32	2026052	-	1	PULLEY, half	
33	2026054	-	1	BEARING	
34	2026051	-	1	PULLEY, half	
				1 911712 SETSCREW, hex-sock, cup-pt, 5/16NC x 5/16	
				1 905123 KEY, woodruff, 3/16 x 3/4	
35	2025692	1	1	PULLEY, rope starter	
				2 919319 CAPSCREW, pltd, 5/16NC x 7/8	
				2 917356 LOCKWASHER, pltd, 5/16	
36	2026358	-	1	WASHER, thrust	
37	2026053	-	1	WASHER, thrust	
--	2026088	1	1	KIT, pulley, conversion (Incl. Items 32 thru 37)	



CLUTCH & BRAKE (Model B-1)


ITEM.	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025344	1	PULLEY, idler	
		1	919361 CAPSCREW, pltd, 3/8NC x 1-3/4	
		5	917642 WASHER, plain, pltd, 11/32 x 1-1/2 x #12	
		1	916965 LOCKWASHER, pltd, 3/8	
		1	916950 NUT, pltd, 3/8NC	
2	2025593	1	BUSHING, idler pulley	
3	2025724	1	SPACER, idler lever	
		1	919362 CAPSCREW, pltd, 3/8NC x 2-1/4	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		1	916965 LOCKWASHER, pltd, 3/8	
		1	916950 NUT, pltd, 3/8NC	
4	2025556	1	LEVER ASSY., idler	
		1	918006 NUT, lock, pltd, 3/8NC	
5	2025557	1	LINK, clutch	
6	2025559	1	LEVER ASSY., clutch & brake	
		1	909007 SETSCREW, hex-sock, cup-pt, 5/16NC x 3/4	
7	2025560	1	GUIDE ASSY., rod	
		1	918005 NUT, pltd, lock, 5/16NC	
8	2025561	1	ROD, brake & clutch	
		2	917372 NUT, pltd, 5/16NC	
9	2025521	1	BAND, brake	

Continued

CLUTCH & BRAKE (Cont'd)

(Model B-1)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
10	2025621	1	RETAINER, spring	
11	2025642	1	SPRING	
12	2025348	1	CLEVIS, adjustable	
13	2025349	1	PIN, clevis	
		1	918448 PIN, cotter, pltd, 3/32 x 1	
14	2025558	1	SHAFT ASSY., clutch & brake	
		2	918454 PIN, cotter, pltd, 1/8 x 1-1/2	
		1	910224 KEY, woodruff, 5/32 x 5/8	
15	2025568	1	DRUM, brake	
		1	905123 KEY, woodruff, 3/16 x 3/4	
16	2025570	1	LINING, brake	
		4	911005 RIVET, tub, fl-ctsk-hd, br, 3/16 x 5/16	
17	2025569	1	BAND ASSY., brake (Incl. items 9 & 16)	
		1	918725 CAPSCREW, pltd, 3/8NC x 3-1/4 (2-1/4 thd)	
		1	916950 NUT, pltd, 3/8NC	
18	2025351	1	PIVOT, foot pedal lever	
		1	904002 PIN, cotter, 1/8 x 2	
19	2025435	1	SPRING, lever	
20	2025562	1	CLIP, spring	
21	2025563	1	LEVER ASSY., foot pedal	
		1	909007 SETSCREW, hex-sock, cup-pt, 5/16NC x 3/4	
22	2025770	2	BUSHING, lever pedal bearing	
23	2025565	1	BEARING ASSY., foot pedal	
		2	916431 CAPSCREW, pltd, 5/16NC x 1	
		2	917372 NUT, pltd, 5/16NC	
		2	917356 LOCKWASHER, pltd, 5/16	
24	2025566	1	PEDAL ASSY., foot, brake & clutch	
		1	910224 KEY, woodruff, 5/32 x 5/8	
25	2025571	1	BRACKET, brake band	
		2	919357 CAPSCREW, pltd, 3/8NC x 7/8	
		2	916965 LOCKWASHER, pltd, 3/8	
		2	916019 CAPSCREW, pltd, 1/4NC x 3/4	
		2	916964 LOCKWASHER, pltd, 1/4	
		2	916622 NUT, pltd, 1/4NC	
26	2025827	1	SETSCREW	
27	2025831	1	CAPSCREW, pivot	
		1	916950 NUT, pltd, 3/8NC	




CLUTCH & BRAKE
(Model B10 Prior to S/N 50001)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025344	1	PULLEY, idler	
		1	917400 CAPSCREW, pltd, 3/8NC x 1-1/4	
		2	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		1	916950 NUT, pltd, 3/8NC	
		1	916965 LOCKWASHER, pltd, 3/8	
2	2025593	1	BUSHING, pulley	
3	2026055	1	SUPPORT ASSY., seat	
4	2026056	1	LINK, clutch lever	
		2	918448 PIN, cotter, pltd, 3/32 x 1	
5	2025559	1	LEVER ASSY., clutch & brake	
		1	909007 SETSCREW, hex-sock, cup-pt, 5/16NC x 3/4	
6	2025560	1	GUIDE ASSY., rod	
		1	918005 NUT, lock, pltd, 5/16NC	
7	2026060	1	ROD, brake & clutch	
8	2025752	1	COLLAR, set	
9	2026057	1	SPRING, compression	
10	2025823	1	SETSCREW, collar	
11	2025621	1	RETAINER, spring	
12	2025348	1	CLEVIS, brake adjusting	
13	2025349	1	PIN, clevis	
		1	918448 PIN, cotter, pltd, 3/32 x 1	

Continued

CLUTCH & BRAKE (Cont'd)
(Model B10 Prior to S/N 50001)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
14	2025558	1	SHAFT ASSY., clutch & brake 2 918454 PIN, cotter, pltd, 1/8 x 1-1/2 1 910224 KEY, woodruff, 5/32 x 5/8	
15	2025827	1	SETSCREW, brake drum	
16	2025568	1	DRUM, brake 1 905123 KEY, woodruff, 3/16 x 3/4	
17	2025570	1	LINING, brake	
18	2025569	1	BAND ASSY., brake (Incl. Items 16 & 19) 1 918725 CAPSCREW, 3/8NC x 3-1/4 (2-1/4 thd.) 1 916950 NUT, pltd, 3/8	
19	2025521	1	BAND, brake 4 911005 RIVET, tub, fl-ctsk-hd, br, 3/16 x 5/16	
20	2026058	1	COLLAR, parking brake	
21	2026061	1	LEVER ASSY., foot pedal	
22	2026059	1	LOCK, parking brake	
23	2025571	1	BRACKET, brake band 1 916019 CAPSCREW, pltd, 1/4NC x 3/4 1 916965 LOCKWASHER, pltd, 3/8 1 916964 LOCKWASHER, pltd, 1/4 1 916622 NUT, pltd, 1/4NC 1 919357 CAPSCREW, pltd, 3/8NC x 7/8	
24	907729	1	CAPSCREW, pltd, 5/16NC x 1-1/4 1 917372 NUT, pltd, 5/16NC 1 918005 NUT, lock, pltd, 5/16NC 1 918452 PIN, cotter, pltd, 1/8 x 1	
25	2025770	2	BUSHING, foot pedal bearing	
26	2025565	1	BEARING ASSY., foot pedal 2 916431 CAPSCREW, pltd, 5/16NC x 1 2 917356 LOCKWASHER, pltd, 5/16 2 917372 NUT, pltd, 5/16NC	
27	2026062	1	PEDAL ASSY., foot, brake & clutch 1 910224 KEY, woodruff, 5/32 x 5/8	
28	2025686	1	SPRING, tension	
29	2026147	1	HOLDER, spring	



CLUTCH & BRAKE
Big Ten Tractor
B-12 Tractors
B10 Tractor S/N 50001 & up)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026357	1	PULLEY, idler	
2	917400	1	CAPSCREW, pltd. 3/8NC x 1-1/4	
		1	916950 NUT, pltd, 3/8NC	
		1	916965 LOCKWASHER, pltd, 3/8	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
3	2026530	1	SPRING, tension	
4	2026055	1	SUPPORT ASSY., seat	
5	2026056	1	LINK, clutch lever	
		2	918448 PIN, cotter, pltd, 3/32 x 1	
6	2026527	1	LEVER ASSY., pivot	
7	2026536	1	ROD, brake	
		1	918448 PIN, cotter, pltd, 3/32 x 1	
		2	916950 NUT, pltd, 3/8NC	
8	2025521	1	BAND, brake, tub, fl-ctsk-hd, br, 3/16 x 5/16	
		*	911005 RIVET (As req'd)	
9	2025569	1	BRAKE ASSY., (Incl. BAND & LINING)	
			1 916019 CAPSCREW, pltd, 1/4NC x 3/4	
			1 916964 LOCKWASHER, pltd, 1/4	
			1 916622 NUT, pltd, 1/4NC	
	2025570	1	LINING, brake	
10	2026534	1	DRUM, brake	
11	916950	1	NUT, to brake shaft, pltd, 3/8NC	
		1	916965 LOCKWASHER, pltd, 3/8	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	


Continued

CLUTCH & BRAKE (Cont'd)
Big Ten Tractor
B-12 Tractors
B10 Tractor S/N 50001 & up)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
12	2026535	2	WASHER, special	
13	2025571	1	BRACKET, brake band	
		2	919357 CAPSCREW, pltd, 3/8NC x 7/8	
		2	916965 LOCKWASHER, pltd, 3/8	
14	2026528	1	ROD, clutch & brake	
		2	917372 NUT, pltd, 5/16NC	
		1	918452 PIN, cotter, pltd, 1/8 x 1	
15	2026531	1	ARM, foot pedal	
16	2025565	1	BEARING ASSY., foot pedal	
		1	916431 CAPSCREW, pltd, 5/16NC x 1	
		1	917356 LOCKWASHER, pltd, 5/16	
		1	917372 NUT, pltd, 5/16NC	
17	2025770	2	BUSHING, pedal	
18	2026570	1	PEDAL ASSY., foot	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		1	916965 LOCKWASHER, pltd, 3/8	
		1	916950 NUT, pltd, 3/8NC	
19	2026529	1	SPRING, tension	
20	2026533	1	SPACER, bracket	
21	2026532	1	BRACKET	
22	2026059	1	LOCK, parking brake	
23	2025560	1	GUIDE ASSY., rod	
		1	918005 NUT, lock, pltd, 5/16NC	

ELECTRICAL SYSTEM(Cont'd)
(Model B-1)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
14	243742	1	REGULATOR, voltage - Use 1601269	
		2	908295 CAPSCREW, pltd, 1/4NC x 1/2	
		2	916964 LOCKWASHER, pltd, 1/4	
		2	916622 NUT, pltd, 1/4NC	
15	2025453	2	WIRE, regulator to generator	
16	2025506	1	BRACKET, voltage regulator	
		1	917397 CAPSCREW, pltd, 5/16NC x 3/4	
		1	917642 WASHER, plain, pltd, 11/32 x 1-1/2 x #12	
		1	917356 LOCKWASHER, pltd, 5/16	
		1	917372 NUT, pltd, 5/16NC	
17	243745	1	MOTOR - GENERATOR (Delco-Remy No. 1101980)	
		2	907729 CAPSCREW, pltd, 5/16NC x 1-1/4	
		2	917372 NUT, pltd, 5/16NC	
		2	917356 LOCKWASHER, pltd, 5/16	
18	2025622	1	SUPPORT ASSY., motor-generator	
		2	917397 CAPSCREW, pltd, 5/16NC x 3/4	
		2	917356 LOCKWASHER, pltd, 5/16	
19	2025461	1	BELT, generator drive (Belt No. 122060)	
20	2025652	1	NUT, lock	
21	2025727	1	CLIP, cable	
		1	917642 WASHER, plain, pltd, 11/32 x 1-1/2 x #12	
22	2025460	1	LINING, clamp	
23	2025836	1	KEY, ignition (set of 2 keys)	
24	2025873	1	INSULATOR, battery	
25	2025455	1	CABLE, battery ground	
26	244403	1	PULLEY, generator	
		1	918945 KEY, woodruff, 1/8 x 5/8	
27	231237	1	NUT, generator pulley (Not Illustrated)	
28	4054800	1	LOCKWASHER, pulley nut (Not Illustrated)	



AMMETER & ELECTRICAL SYSTEM

* B10 Tractor Prior to S/N 50001, Big Ten Tractor

** B10 Tractor S/N 50001 & up, B12 Tractor

ITEM	PART NUMBER	QTY. * **	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026064	1 1	CABLE, generator to starter 1 916950 NUT, pltd, 3/8NC (starter switch) 1 916965 LOCKWASHER, pltd, 3/8	
2	243744	1 1	SWITCH, starter 2 916622 NUT, pltd, 1/4NC 2 916964 LOCKWASHER, pltd, 1/4	
3	2026078	1 1	WIRE, switch to engine	
4	2025836	1 1	KEY, ignition switch	
5	2025458	1 1	SWITCH ASSY., ignition - Use 1601213	
6	2026074	1 1	AMMETER ASSY., (Incl. CLAMP & hardware)	
7	2026070	1 1	CABLE, battery to starter	
8	-----	1 -	WIRE, ammeter to starter	2026648
9	2026650	- 1	WIRE, fuse to ammeter	2026648
10	2026652	- 1	CLIP, fuse	2026648
11	2026651	- 1	FUSE, 20 amp.	2026648
12	2026649	- 1	WIRE, fuse to starter	2026648
12	2026703	- 1	J-BOLT 1 916964 LOCKWASHER, pltd, 1/4 1 916622 NUT, pltd, 1/4NC	
13	2026858	- 1	BRACKET, battery	
14	2026072	1 1	INSULATOR, battery	
15	2026076	1 1	WIRE, ammeter to regulator	
16	2026073	1 1	INSULATOR, fuel tank	
17	243474	1 1	BATTERY, 12 volt	
18	2026065	1 1	WIRE, regulator to generator	
19	243743	- 1	REGULATOR, voltage (B12 Only) - Use 1601269	
19	250544	1 -	REGULATOR, voltage, (All B10 & Big Ten) 3 916019 CAPSCREW, pltd., 1/4NC x 3/4 3 916964 LOCKWASHER, pltd., 1/4 3 916622 NUT, pltd., 1/4NC	


Continued

AMMETER & ELECTRICAL SYSTEM (Cont'd)

* B10 Tractor Prior to S/N 50001, Big Ten Tractor

** B10 Tractor S/N 50001 & up, B12 Tractor

ITEM	PART NUMBER	QTY.		DESCRIPTION	ASSEMBLY OR PACKAGE NO.
		*	**		
20	2026077	1	1	WIRE, ground to ground	
21	2026071	1	1	CABLE, battery to ground	
				1 907727 CAPSCREW, pltd, 1/4NC x 5/8	
				1 916964 LOCKWASHER, pltd, 1/4	
				1 916622 NUT, pltd, 1/4NC	
22	2026069	1	1	BRACE, generator adjusting	
				2 917397 CAPSCREW, pltd, 5/16NC x 3/4	
				2 917642 WASHER, pltd, 11/32 x 1-1/2 x #12	
				2 917356 LOCKWASHER, pltd, 5/16	
				2 917372 NUT, pltd, 5/16NC	
23	2025506	1	1	BRACKET, generator mounting	
24	2025448	1	1	COVER, terminal	
25	243745	1	1	GENERATOR (Delco-Remy No. 1101980)	
				2 907729 CAPSCREW, pltd, 5/16NC x 1-1/4	
				2 917372 NUT, pltd, 5/16NC	
				2 917356 LOCKWASHER, pltd, 5/16NC	
26	2026067	1	1	SUPPORT ASSY., generator	
				2 917397 CAPSCREW, pltd, 5/16NC x 3/4	
				2 917356 LOCKWASHER, pltd, 5/16	
27	2026066	1	1	BELT, v (Belt No. 122146)(All Except B12)	
	2026869	-	1	BELT, v (Belt No. 157524)(B12 Only)	
28	244403	1	1	PULLEY, generator	
				1 918945 KEY, woodruff, 1/8 x 5/8	
				1 231237 NUT, pulley	
				1 4054800 LOCKWASHER	
29	2026914	1	1	WASHER, lock, external type	
--	2026648	1	1	WIRE KIT (Incl. 1 each items 8 thru 11)	




P. T. O.
(Models B10 Prior to S/N 50001 & B1)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026080	1	PULLEY, power take-off (B10 Tractor)	
	2025679	1	PULLEY, power take-off (B1 Tractor)	
2	2025626	2	BEARING, needle, P. T. O. shaft	
	2026079	1	SHAFT, power take-off (B10 Tractor)	
3	2025618	1	SHAFT, power take-off (B1 Tractor)	
	2	905123	KEY, woodruff, 3/16 x 3/4	
4	2025617	1	ROD, pivot	
	1	918459	PIN, cotter, pltd., 3/16 x 1-1/2	
5	2025721	2	BUSHING, pivot rod	
6	2025616	1	BRACKET ASSY., drive	
	1	918186	FITTING, lube, 45°, taper thd, 1/4-28NS	
7	2025686	1	SPRING, tension	
8	2025681	1	LEVER ASSY., idler	
	2	917642	WASHER, plain, pltd, 11/32 x 1-1/2 x #12	
	1	917400	CAPSCREW, pltd, 3/8NC x 1-1/4	
	1	916965	LOCKWASHER, pltd, 3/8	
	1	916950	NUT, pltd, 3/8NC	
	1	918452	PIN, cotter, pltd, 1/8 x 1	

Continued

P.T.O. (Cont'd)
(Models B10 Prior to S/N 50001 & B1)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
9	2025593	1	BUSHING, pulley (B1 Only)	
10	{ 2025665	1	PULLEY, idler (B1 Tractor)	
	2026082	1	PULLEY, idler (B10 Tractor)	
11	2025718	1	STOP, belt	
		1	919357 CAPSCREW, pltd, 3/8NC x 7/8	
		1	916965 LOCKWASHER, pltd, 3/8	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		1	916950 NUT, pltd, 3/8NC	
12	{ 2025666	1	PULLEY (B1 Tractor)	
	2026084	1	PULLEY (B10 Tractor)	
	2025619	1	GUARD ASSY., belt (B1 Tractor)	
	2026085	1	GUARD ASSY., belt (B10 Tractor)	
13	{	1	907731 CAPSCREW, pltd, 3/8NC x 1	
		1	916965 LOCKWASHER, Pltd, 3/8	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		1	916950 NUT, pltd, 3/8	
14	2025725	1	KEY, pulley	
15	{ 2025663	1	BELT, "V", PTO drive (B1 Tractor) (Belt No. 154307)	
	2026081	1	BELT, "V", PTO drive (B10 Tractor) (Belt No. 106390)	
16	2025683	1	ROD ASSY., clutch	
		1	917642 WASHER, plain, pltd, 11/32 x 1-1/2 x #12	
		1	918005 NUT, lock, pltd, 5/16NC	
17	2025447	1	KNOB, clutch lever	
18	2025680	1	LEVER ASSY., clutch	
19	2025682	1	PIVOT BAR ASSY.	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		1	918006 NUT, lock, pltd, 3/8NC	
20	2025752	1	COLLAR, set	
21	2025753	1	SPRING, clutch rod	
22	2025684	1	GUIDE ASSY., rod	
		1	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
		1	918006 NUT, lock, pltd, 3/8NC	
23	2025664	1	PULLEY	
24	2025354	1	WASHER	
25	2025685	1	CLIP, spring	
		2	917378 WASHER, plain, pltd, 7/16 x 1 x #14	
26	2025823	1	SETSCREW	
27	2026083	1	GUARD, support (B10 Tractor)	
		1	916431 CAPSCREW, pltd, 5/16NC x 1	
		1	917356 LOCKWASHER, pltd, 5/16	
		1	917372 NUT, pltd, 5/16NC	



P.T.O.

* Big Ten Tractor


** B10 Tractor S/N 50001 & up, B12 Tractor

ITEM	PART NUMBER	QTY.		DESCRIPTION	ASSEMBLY OR PACKAGE NO.
		*	**		
1	2026082	1	1	PULLEY, idler	
				2 917642 WASHER, plain, pltd, 11/32 x 1-1/2 x #12	
				1 917400 CAPSCREW, pltd, 3/8NC x 1-1/4	
				1 916965 LOCKWASHER, pltd, 3/8	
				1 916950 NUT, pltd, 3/8NC	
2	2026424	1	1	LEVER ASSY., idler	
3	2026428	1	1	GUIDE ASSY., rod	
				1 918006 NUT, lock, pltd., 3/8NC	
				1 917378 WASHER, plain, pltd., 3/8	
4	2026380	1	1	BAR ASSY., pivot (Clutch lever pivot f/hyd. lift tractors)	
				1 917378 WASHER, plain, pltd., 7/16 x 1x #14	
				1 918006 NUT, lock, pltd., 3/8NC	
5	2025447	1	1	KNOB, clutch rod	
6	2026575	-	1	WASHER, special	
7	2025680	1	1	LEVER ASSY., clutch	
8	2025682	1	1	BAR ASSY., pivot (f/hand lift only)	
				1 917378 WASHER, plain, pltd., 7/16 x 1x #14	
				1 918006 NUT, lock, pltd., 3/8NC	
9	2025683	1	1	ROD ASSY., clutch	
				2 917642 WASHER, plain, pltd., 11/32 x 1-1/2 x #12	
				1 924433 NUT, lokut, pltd., 5/16NC	
				1 2026595 WASHER	
10	2025752	1	1	COLLAR, set, clutch rod	
11	2025823	1	1	SETSCREW, set collar	
12	2025753	1	1	SPRING, clutch rod	
13	2026578	1	1	STOP, P.T.O. handle	
14	2026592	1	1	PLATE, support	

Continued
46

P. T. O. (Cont'd)
 * Big Ten Tractor
 ** B10 Tractor S/N 50001 & up, B12 Tractor

ITEM	PART NUMBER	QTY.		DESCRIPTION	ASSEMBLY OR PACKAGE NO.
		*	**		
15	2026419	1	1	BRACKET, P. T. O.	
16	2025617	1	1	ROD, pivot	
				1 918459 PIN, cotter, pltd, 3/16 x 1-1/2	
17	2025725	1	1	KEY, pulley	
18	2026084	1	1	PULLEY	
19	2026085	1	1	GUARD ASSY., belt	
				1 907731 CAPSCREW, pltd, 3/8NC x 1	
				1 917378 WASHER, plain, pltd, 7/16 x 1 x #14	
				1 916965 LOCKWASHER, pltd, 3/8	
				1 916950 NUT, pltd, 3/8NC	
20	2026083	1	1	SUPPORT, belt guard	
				2 916431 CAPSCREW, pltd, 5/16NC x 1	
				2 917356 LOCKWASHER, pltd, 5/16	
				2 917372 NUT, pltd, 5/16NC	
21	2025663	1	1	BELT, drive (Belt No. 154307)	
22	2025718	1	1	STOP, belt	
				1 919357 CAPSCREW, pltd, 3/8NC x 7/8	
				1 917378 WASHER, plain, pltd, 7/16 x 1 x #14	
				1 916965 LOCKWASHER, pltd, 3/8	
				1 916950 NUT, pltd, 3/8NC	
23	2026080	1	1	PULLEY, P. T. O.	
				1 911712 SETSCREW, cup-pt, 5/16NC x 5/16	
				1 905123 KEY, woodruff, 3/16 x 3/4	
24	2026426	1	1	RING, retaining, idler lever	
25	2026420	1	1	HOUSING, includes bearings - Use 2027893	
				1 914687 FITTING, lube, 1/4NF-2	
26	2025626	2	-	BEARING, needle, housing	
27	2026518	-	2	BEARING, needle, housing - Use 2025626	
27	2026422	1	1	U-BOLT, bearing housing	
				2 917356 LOCKWASHER, pltd, 5/16	
				2 917372 NUT, pltd, 5/16NC	
28	2026431	1	1	STUD, rod handle	
				1 918007 NUT, lokut, pltd, 7/16 NC	
29	2026429	1	1	HANDLE ASSY., spring tension rod	
30	2026430	1	1	ROD, spring tension	
				1 907729 CAPSCREW, pltd, 5/16NC x 1-1/4	
				1 918005 NUT, lokut, pltd, 5/16NC	
31	2026427	1	1	SPRING, tension	
32	2026423	1	1	SHAFT ASSY., P. T. O.	
				1 905123 KEY, woodruff, 3/16 x 3/4	
33	2025722	2	2	WASHER, shaft	
34	2026425	1	1	SPACER, idler lever	
35	2026198	1	1	PIN, belt guide	
				1 916431 CAPSCREW, pltd., 5/16NC x 1	
				1 917642 WASHER, plain, pltd., 11/32 x 1-1/2 x #12	
				1 917356 LOCKWASHER, pltd., 5/16	
				1 917372 NUT, pltd., 5/16NC	




TRANSMISSION

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025636	2	RING, snap	
2	2025637	2	SEAL	
3	2025631	2	SEAL, oil	
4	2025597	1	COVER ASSY., gear case (Incl. BEARINGS)	
	3	901653	PLUG, pipe, sq-hd, solid, 3/8	
	14	916431	CAPSCREW, pltd, 5/16NC x 1	
	14	917356	LOCKWASHER, pltd, 5/16	
5	2025638	1	GASKET, gear case	
6	2025626	2	BEARING, needle	
7	2025531	2	WASHER	
8	2025632	3	RING, retaining	
9	2025530	1	SHAFT, pulley (B1 & B10 Prior to S/N 50001)	
	2026537	1	SHAFT, pulley (Big Ten & B10 S/N 50001 & up) B12	
	2025633	1	KEY, pulley shaft (B1 & B10 prior S/N 50001)	
10	2025678	1	KEY, pulley shaft (Big Ten & B10 S/N 50001 & up) B12	
11	2025533	1	PINION ASSY., reverse, 1st & 3rd	
12	2025532	1	PINION ASSY., reverse & 2nd	
13	2025630	2	BALL, shift lock	
14	2025672	1	SPRING, shift fork	
15	2025723	2	RING, retaining	
16	2025527	1	SHAFT, shifter, reverse & medium	
17	2025528	1	SHAFT, shifter, high & low	

Continued


TRANSMISSION (Cont'd)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE N O.
18	2025625	2	BEARING, needle	
19	2025540	1	PINION, reverse	
20	2025539	1	SPACER, 2nd & reverse gear	
21	2025538	1	GEAR, driven, 2nd	
22	2025722	3	WASHER, spacer, transmission gear	
23	2025678	1	KEY, intermediate shaft	
24	2025534	1	SHAFT, 1st intermediate (B1 & B10 Tractors prior S/N 50001)	
	2026538	1	SHAFT, 1st intermediate (B10 S/N 50001 & up, B12, Big Ten)	
25	2025537	1	PINION, driven 3rd	
26	2025536	1	PINION, 1st intermediate	
27	2025535	1	GEAR, driven 1st	
28	2025639	1	BEARING, needle	
29	2025513	5	WASHER	
30	2025546	1	SPACER	
31	2025542	1	SHAFT, 2nd intermediate	
32	2025635	1	KEY, 2nd intermediate shaft	
33	2025545	1	GEAR, 2nd intermediate	
34	2025544	1	PINION, 2nd intermediate	
35	2025634	2	RING, snap, retaining	
36	2025627	3	BEARING, needle	
37	2025549	1	GEAR, 3rd intermediate	
38	2025548	1	PINION, 3rd intermediate	
		2	910224 KEY, woodruff, 5/32 x 5/8	
39	2025547	1	SHAFT, 3rd intermediate	
40	2025628	2	BEARING, axle tube	
41	2025822	3	WASHER	
42	2025567	2	WASHER, axle tube	
43	2025551	1	GEAR, drive	
44	2025553	1	SPACER, axle tube	
45	2026087	2	BEARING, axle tube (B10, B12, Big Ten)	
	2025500	2	BEARING, axle tube (B1 Tractor)	
46	2025552	2	KEY, axle tube	
47	2025550	1	TUBE, axle (B1 Tractor)	
	2026598	1	TUBE ASSY., (Incl. item 45) (B10 Big Ten & B12)	
		1	912808 FITTING, lube, str, taper 1/4-28NC x 1/2	
48	2025677	1	PIN ASSY., reverse gear	
		1	917400 CAPSCREW, plt d, 3/8NC x 1-1/4	
49	2025673	1	WASHER, reverse gear pin	
50	2025541	1	SPACER, reverse gear	
51	2025543	1	GEAR, reverse	
52	2025629	1	STEM, shift	
		1	916602 NUT, pltd, 3/8NF	
53	2025526	1	ROD, shift	
54	2025596	1	CASE ASSY., gear (Incl. BEARINGS & PINS)	
		2	917231 SETSCREW, hex-sock, cone-pt, 5/16NC x 1/2	
		2	918113 PIN, roll, 3/8 x 1	
55	2025529	2	FORK, shift	
56	2026302	1	PIN ASSY., roll	
57	2026301	1	PIN ASSY., roll	



TRANSMISSION DRIVE PULLEY & BELT

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2025641	1	BELT, "V", 6" (Pulley) (Std.)	
	2025492	1	BELT, "V", 45", 8" pulley	
	2025712	1	BELT, "V" f/ground speed reduction 10" pulley	
	2025271	1	PULLEY, drive, 8"	
2		1	911712 SETSCREW, hex-sock, cup-pt, 5/16NC x 5/16	
	2025709	1	PULLEY, drive, 10"	
	2025640	1	PULLEY, drive, 6"	
3	2025725	1	KEY, pulley	




TRANSMISSION CONTROLS
(TWO-SPEED PULLEY)
 (Models B10 Eff. W/S/N 50001 & up, Big Ten & B12)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026461	1	PULLEY ASSY. (Incl. GEAR)	
2	2026277	1	STOP, belt	
3	2026463	1	COLLAR, set, pulley	
		2	905564 SETSCREW, hex-sock, cup-pt, 5/16NC x 3/8	
4	2026464	1	KEY, square, pulley	
5	2026569	1	GUARD, starting cup	
6	2026469	1	COVER ASSY., L.H.	
		6	905661 CAPSCREW, 5/16NC x 5/8	
		6	917356 LOCKWASHER, 5/16	
7	2026474	1	SUPPORT ASSY., shift	
8	2026475	1	STOP, shift support	
9	2026478	1	SUPPORT, shift rod	
		1	917396 CAPSCREW, pltd, 1/4NC x 1	
		1	916964 LOCKWASHER, pltd, 1/4	
10	2026479	1	KNOB, hand	
11	2026477	1	FORK ASSY., shift	
12	2026476	2	BOLT, support stop	
		1	917356 LOCKWASHER, pltd, 5/16	
13	2026480	2	PIVOT, shift fork	

Continued

TRANSMISSION CONTROLS (Cont'd)
(TWO-SPEED PULLEY)
(Models B10 Eff. W/S/N 50001 & up, Big Ten & B12)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
14	2026481	2	BEARING, pivot	
15	2026348	2	SPACER	
		1	916019 CAPSCREW, pltd, 1/4NC x 3/4	
		1	916964 LOCKWASHER, pltd, 1/4	
		1	917377 WASHER, plain, pltd, 5/16 x 3/4 x #16	
16	2026466	3	PINION	
17	2026468	3	BEARING, needle, pinion	
18	2026471	1	COVER ASSY., R.H.	
		1	915019 FITTING, lube, 90°, taper, 1/4 NS x 25/32	
		1	917214 CAPSCREW, 1/4NF x 1/2	
19	2026473	4	NUT, special, cover attaching	
20	2026472	2	NUT, special	
21	2026462	1	SPIDER ASSY., (Incl. BEARING)	
22	2026482	1	GEAR, ring	
23	2026465	1	RING, bolt	
24	2026467	3	PIN, bolt ring	
		1	918005 NUT, lock, pltd, 5/16NC	
25	2026470	1	RING, shift	




IMPLEMENT HITCH & LIFT (HYDRAULIC CONTROLS)
(Big Ten Tractor S/N 44345 & up)
(B10 Tractor S/N 50001 & up)
(B12 Tractor)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
-	2026604	1	Hyd. Conv. Kit (Incl. items 3, 4, 6 & 8)	
1	2026379	1	PULLEY, drive	
2	2026378	1	BELT, drive	
3	2026637	1	PULLEY, pump	
4	2026361	4	CAPSCREW	
5	2026019	4	NUT	
6	2026635	1	SUPPORT, pump	
7	2026366	1	ROD, latch	
8	2026636	1	BRACKET, angle	
9	2026368	2	LINK, connecting	
10	2026367	1	SPRING	
11	2026365	1	LEVER ASSY.	
12	2026364	1	SPACER	
13	2026362	1	QUADRANT	
14	2026363	1	PLATE, stop	
		2	903625 CAPSCREW, 1/4NC x 3/4	
		2	916964 LOCKWASHER, 1/4	
		2	916622 NUT, hex, 1/4NC	
		2	917377 WASHER, plain, 1/4"	
15	2026380	1	BAR ASSY., pivot	
		1	916431 CAPSCREW, 5/16NC x 1, pltd.	
		1	917396 CAPSCREW, 1/4NC x 1, pltd.	
		1	916964 LOCKWASHER, 1/4, pltd.	
		1	916622 NUT, hex, 1/4, pltd.	
16	2026385	1	CLAMP, hose	
17	2025607	2	BEARING, lift lever	
		2	922129 CAPSCREW, 3/8NC x 7/8, pltd.	
		2	916965 LOCKWASHER, 3/8, pltd.	
18	2025757	2	COLLAR, set	
		1	911712 SETSCREW, 5/16NC x 5/16	
19	2026539	1	SHAFT ASSY., lift	
20	2026046	2	KEY	
21	2026005	1	LEVER ASSY., lift, front	
		1	909007 SETSCREW, 5/16NC x 3/4	

Continued

IMPLEMENT HITCH & LIFT (HYDRAULIC CONTROLS)(Cont'd)
(Big Ten Tractor S/N 44345 & up)
(B10 Tractor S/N 50001 & up)
(B12 Tractor)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
22	2025660	1	END, yoke, adjustable	
23	2026553	1	ROD, lift	
		1	918452 PIN, cotter, 1/8 x 1	
24	2025717	2	COLLAR, set	
		1	911712 SETSCREW, 5/16NC x 5/16	
25	2025610	1	LIFT ASSY., tiller	



HYDRAULIC PUMP & LINES
(Big Ten Tractor S/N 44345 & up)
(B10 Tractor S/N 50001 & up)

(B-12 Tractor)


ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
-	2026897	1	PUMP ASSY., tank & valve (Incl. items 1 thru 33)	
1	2026610	1	SEAL, rotary	
2	2026612	2	O-RING	
3	2026609	1	SEAL	
4	2026622	1	COVER ASSY., front	
5	2026621	2	PIN, dowel	
6	2026607	1	GASKET	
7	2026606	1	SHIELD, heat (Service only)	
8	2026608	1	PLATE, wear	
9	2026620	1	GEAR ASSY., drive	
10	2026614	1	KEY, drive shaft	
11	2026624	1	GEAR ASSY., driven	
12	2026626	1	SECTION, center	
13	2026623	1	COVER ASSY., back	
14	2026611	1	O-RING	
15	2026625	4	BOLT	
16	2026630	1	PLUG, filler cap	
17	2026629	1	SCREW	
18	2026613	1	SEAL, stat-o-seal	
19	2026634	1	TANK ASSY.	
20	2026631	1	PLUG, drain	
21	2026628	2	SCREW	
22	2026633	1	ELBOW, inlet	
23	2026632	1	NIPPLE, inlet	
24	2026551	2	O-RING	
			917377 WASHER, plain, pltd, 5/16 x 3/4 x #16	
			916964 LOCKWASHER, 1/4, pltd.	

Continued

HYDRAULIC PUMP & LINES (Cont'd)
 (Big Ten Tractor S/N 44345 & up)
 (B10 Tractor S/N 50001 & up)


(B-12 Tractor)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
25	2026552	1	O-RING	
26	2026617	2	PIN, cam	
27	2026616	1	BALL	
28	2026618	1	SPRING	
29	2026615	1	O-RING	
30	2026619	1	CAGE	
31	2026550	2	O-RING	
32	2026627	1	VALVE ASSY., relief	
33	2026546	1	O-RING	
34	2026369	4	FITTING	
35	2026370	1	HOSE ASSY.	
36	2026371	1	HOSE ASSY.	
37	2026374	1	PIN	
		2	918452 PIN, cotter, 1/8 x 1	
38	2026373	2	BAR, side	
		2	917356 LOCKWASHER, 5/16, pltd.	
		2	917372 NUT, hex, 5/16NC, pltd.	
39	2026376	2	BRACKET, ram	
		1	919364 CAPSCREW, 7/16NC x 2-1/4, pltd.	
		1	918199 LOCKWASHER, 7/16, pltd.	
40	2026375	1	PIN, ram bracket	
		1	918452 PIN, cotter, 1/8 x 1	
41	2026372	1	CYLINDER ASSY (Refer to Cylinder Group for Components)	
42	2026689	1	VALVE ASSY., control (Incl. items 24 thru 31)	
43	2026688	1	PUMP ASSY., hydraulic (Incl. items 1 thru 15, 32)	



HYDRAULIC LIFT CYLINDER
 (Models B10 Eff. W/S/N 50001 & up, Big Ten Eff.
 W/S/N 44345 & up & B-12)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026640	1	YOKE ASSY., (Incl. YOKE & Item 2)	
	2026558	1	YOKE	
2	2026559	1	ROD, piston	
3	2026639	1	GUIDE, end	2026564
4	2026560	4	BOLT, stud	2026564, 2026565
5	2026561	1	PISTON	
6	913901	1	NUT, hex, pltd, 7/16NF	
7	2026562	1	CYLINDER	
8	2026638	1	BASE, cylinder	2026565
9	919262	1	NUT, hex, jam, pltd, 1/2NF.	2026565
10	2026563	1	BOLT, eye	
11	2026381	2	O-RING	2026564, 2026565
12	2026384	1	O-RING	
13	-----	1	BUSHING (Not Serviced separately).	2026564
14	2026383	1	O-RING	




**HYDRAULIC PUMP, LINES & IMPLEMENT HITCH &
LIFT CONTROLS**
(Big Ten Prior S/N 44345) (B10 Prior S/N 50001)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026363	2	STOP, plate	
		2	903625 CAPSCREW, 1/4NC x 3/4	
		2	916964 LOCKWASHER, pltd, 1/4	
		2	917377 WASHER, plain, pltd, 5/16 x 3/4 x #16	
		2	916622 NUT, hex, pltd, 1/4NC	
2	2026362	1	QUADRANT	
		2	903625 CAPSCREW, 1/4NC x 3/4	
3	2026365	1	LEVER ASSY.	
4	2026368	1	LINK, connecting	
5	2026540	1	VALVE ASSY., relief (Incl. items 6 thru 11)	
6	2026542	1	PLUNGER, relief valve	
7	2026546	1	"O" RING	
8	2026545	1	SHIM	
9	2026544	1	CAP, relief valve	
10	2026543	1	SPRING, relief valve	
11	2026541	1	SEAT, relief valve	
12	2026366	1	ROD, latch	
		1	918448 PIN, cotter, pltd, 3/32 x 1	
13	2026360	1	SUPPORT ASSY., pump	
14	2026019	3	NUT, hex, special	
15	2026377	1	PULLEY, pump	
		1	911712 SETSCREW, hex-sock, cup-pt, 5/16NC x 5/16	
			Continued	

HYDRAULIC PUMP, LINES & IMPLEMENT HITCH & LIFT CONTROLS


(Big Ten Prior S/N 44345) (B10 Prior S/N 50001)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
16	2026379	1	PULLEY, drive	
17	2026378	1	V-BELT, (Belt No. 157230)	
18	2026547	1	VALVE ASSY., control (Incl. items 21 & 22)	
19	2026552	1	"O" RING	
20	2026551	2	"O" RING	
21	2026550	2	"O" RING	
22	2026548	4	BOLT, special	
23	2026374	1	PIN	
		2	918452 PIN, cotter, pltd, 1/8 x 1	
24	2026557	1	IUMP ASSY., (Incl. SHAFT, SEAL & item 5)	
25	2026589	1	GASKET, pump to tank	
	2026590	1	TANK ASSY., (Incl. item 27 & PIPE PLUG)	
26	2026566	1	PLUG, pipe	
	2026567	4	BOLT, tank attaching	
27	2026588	1	CAP, filter	
28	2026370	1	HOSE ASSY.	
29	2026369	4	FITTING, hose to cylinder	
30	2026373	2	BAR, side	
		2	917356 LOCKWASHER, pltd, 5/16	
		2	917372 NUT, pltd, 5/16NC	
31	2026376	1	BRACKET, ram	
		2	919364 CAPSCREW, plated, 7/16NC x 2-1/4	
32	2026375	1	PIN, ram bracket	
		1	918452 PIN, cotter, pltd, 1/8 x 1	
33	2026371	1	HOSE ASSY.	
34	2026385	1	CLAMP, hose	
35	2026005	1	LEVER ASSY., lift, front	
		1	909007 SETSCREW, hex-sock, cup-pt, 5/16NC x 3/4	
36	2026380	1	BAR ASSY., pivot	
		1	916431 CAPSCREW, pltd, 5/16NC x 1	
		1	917396 CAPSCREW, pltd, 1/4NC x 1	
		1	916964 LOCKWASHER, pltd, 1/4	
		1	916622 NUT, pltd, 1/4NC	
37	2025717	2	COLLAR, set	
		1	911712 SETSCREW, hex-sock, cup-pt, 5/16NC x 5/16	
38	2025610	1	LIFT ASSY., tiller	
39	2026553	1	ROD, lift	
		1	918452 PIN, cotter, pltd, 1/8 x 1	
40	2025660	1	YOKE END, adjusting	
41	2025607	2	BEARING, lift lever	
		2	919357 CAPSCREW, pltd, 3/8NC x 7/8	
		2	916965 LOCKWASHER, pltd, 3/8	
42	2025757	2	COLLAR, set	
		1	911712 SETSCREW, hex-sock, cup-pt, 5/16NC x 5/16	
43	2026539	1	SHAFT ASSY., lift	
44	2026046	2	KEY	
45	2026364	2	SPACER	
46	2026367	1	SPRING	
47	2026361	3	CAPSCREW, special	
48	2026372	1	CYLINDER ASSY., (See Cylinder Group for components)	
49	2026568	1	SEAL, bearing, pump shaft	
--	2026549	1	"O" RING KIT (Incl. items 19, 20 & 21)	




HYDRAULIC LIFT CYLINDER
 (Big Ten Prior S/N 44345)
 (B10 Prior S/N 50001)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026558	1	YOKE	
2	2026559	1	ROD, piston	
		1	919262 NUT, pltd, 7/16NF	
3	2026564	1	GUIDE ASSY., cyl. end (Incl. GUIDE & items 10 & 12)	
4	2026561	1	PISTON, cylinder	
5	2026562	1	CYLINDER	
6	2026565	1	BASE ASSY., cylinder (Incl. item BASE, JAM NUT & 1 of item 10 & 12)	
7	2026563	1	BOLT, eye	
8	2026383	1	"O" RING	
9	2026382	1	BUSHING	
10	2026381	2	"O" RING	
11	2026384	1	"O" RING	
12	2026560	4	STUD	




FRONT LIGHTS
(Model B-1)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	249518	1	LAMP ASSY., front (Incl. items 6 & 7)	
		1	916966 LOCKWASHER, pltd., 1/2	
		1	916951 NUT, pltd., 1/2NC	
2	236887	1	BRACKET, front lamp	
3	236886	1	CAPSCREW, lamp bracket	
		2	916966 LOCKWASHER, pltd., 1/2	
		2	916951 NUT, pltd., 1/2NC	
4	200479	1	CLIP, f/head capscREW	
5	920661	1	TERMINAL, wire, spade type, #10	
6	230232	1	UNIT ASSY., sealed beam (Not illustrated)	
7	230233	1	MOLDING, (Not illustrated)	
		1	915872 SCREW, rd-hd., br., #8NC x 3/4	
8	244519	1	SWITCH, toggle	




FRONT LIGHTS
 (Model B10 & Big Ten Eff. W/S/N 1001 & up)
 (Model B-12)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
-	-----	1*	FRONT LIGHT KIT (Incl. items 1 thru 12)	
1	2026679	2	LAMP ASSY.	
2	2026293	2	SPACER	
		1	916951 NUT, pltd., 1/2NC	
		1	916966 LOCKWASHER, pltd., 1/2	
3	2026292	1	SUPPORT, lamp	
	2026294	2	SPACER (B10 & Big Ten Tractors)(S/N 1001 & up)	
		1	919933 CAPSCREW, pltd., 5/16NC x 1-1/2	
4		1	917372 NUT, pltd., 5/16NC	
		1	917356 LOCKWASHER, 5/16	
	2025747	1	BUSHING (B12)	
		1	916431 CAPSCREW, 5/16NC x 1	
		1	917372 NUT, pltd., 5/16NC	
		1	917356 LOCKWASHER, 5/16	
5	2026680	1	CONNECTOR, insulated	
6	2026682	1	EXTENSION, wire	
7	2026681	1	WIRE, switch to connector	
8	2026683	1	SWITCH, toggle (Incl. Hardware)	
9	2026684	1	WIRE, fuse to switch	
10	2026651	1	FUSE, 20 amp.	
11	2026685	1	WIRE, fuse to voltage regulator	
12	2026686	1	CLAMP	



FRONT LIGHTS
(Models B-10 & Big Ten Prior to S/N 1001)


ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	2026295	1	WIRE, regulator to front lamp	
2	2026292	1	SUPPORT, light	
3	2026294	2	SPACER, lamp	
		1	919933 CAPSCREW, pltd, 5/16NC x 1-1/2	
		1	917372 NUT, pltd, 5/16NC	
		1	917356 LOCKWASHER, pltd, 5/16	
4	249518	2	LAMP ASSY., front (Incl. items 5 & 6)	
		1	919804 SCREW (lamp wire), #10 x 3/8	
		1	909055 LOCKWASHER, int-tooth, pltd. #10	
		1	917415 NUT, pltd, #10NF	
		1	916966 LOCKWASHER, pltd, 1/2	
		1	916951 NUT (lamp base to support), pltd, 1/2NC	
5	249519	1	SWITCH, toggle	
6	230233	2	MOLDING, lamp (Not illustrated)	
		1	915872 SCREW, molding, rd-hd., br., #8NC x 3/4	
7	230232	2	UNIT ASSY., sealed beam (Not illustrated)	



REAR WORK LIGHT (First Type)


ITEM	PART NUMBER	QTY.	DESCRIPTION
1	249518	1	LAMP ASSY., rear (Incl. items 7 & 8)
2	236888	1	BRACKET, rear lamp
3	228525	1	CLIP, wire
4	230240	1	TERMINAL, female
5	200479	1	CLIP
6	236885	1	CABLE ASSY.
7	230232	1	UNIT ASSY., sealed beam (Not Illustrated)
8	230233	1	MOLDING, lamp (Not Illustrated)
9	249519	1	SWITCH, (Not illustrated)

ASSEMBLY OR
PACKAGE NO.



REAR WORK LIGHT (Second Type)

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	228402	1	CONNECTOR, line	
2	2026861	1	CLIP, wire	
3	2026862	1	WIRE (To rear lamp)	
4	2026860	1	CLIP	
5	2026679	1	LAMP ASSY.	
		1	916926 LOCKWASHER, 1/2	
		1	916951 NUT, 1/2NC	
6	2026859	1	BRACKET, rear lamp	
		1	917397 CAPSCREW, 5/16NC x 3/4	
		1	917356 LOCKWASHER, 5/16	
		1	917372 NUT, 5/16NC	



FRAME COUNTERWEIGHTS

ITEM	PART NUMBER	QTY.	DESCRIPTION	ASSEMBLY OR PACKAGE NO.
1	-----	-	WEIGHT, wheel (See Machinery Price List)	
			2 922100 BOLT, carriage, pltd, 1/2NC x 2-1/2	
			2 2026109 BOLT, carriage, pltd.	
			4 918431 WASHER, plain, pltd, 9/16 x 1-3/8 x #10	
			4 916951 NUT, pltd, 1/2NC	
2	{ -----	-	WEIGHT, tiller (See Machinery Price List)	
	2025845	1	SETSCREW	
3	{ -----	-	WEIGHT, counter balance (See Machinery Price List)	
	2026849	1	PIN	
	2025739	1	CLIP, spring	
4	{ -----	-	COUNTERWEIGHT, front	
	2025739	6	CLIP, spring	
	2025429	4	PIN	
5	{ -----	1	ROD	
	2025992	1	BOX, tool (Not Illustrated) (Order from machinery)	
		2	918265 WASHER, plain, pltd, 11/32 x 11/16 x 1/16	

ASSEMBLIES & PACKAGED PARTS

ASSEMBLY OR
PACKAGE NO.

DESCRIPTION

2026564

GUIDE ASSY., cylinder end

1	2026639	GUIDE
2	2026560	BOLT
1	2026381	O-RING
1	-----	BUSHING

2026565

GUIDE ASSY., cylinder base

1	2026638	BASE
1	919262	NUT
2	2026560	BOLT

2026591

KIT, wheel bearing

1	327527	CONE
1	328002	CUP
1	2025697	CONE, inner

2026648

WIRE KIT

1	2026650	WIRE, fuse to ammeter
1	2026652	CLIP, fuse
1	2026651	FUSE, 20 amp.
1	2026649	WIRE, fuse to starter

NUMERICAL INDEX

PART NO. PAGE	PART NO. PAGE	PART NO. PAGE	PART NO. PAGE
0200479... 61, 64	0917377... 10	2025349... 35, 36	2025538... 49
0228402... 65	0917378... 10	2025351... 35	2025539... 49
0228525... 64	0917396... 19	2025353... 28, 29, 30	2025540... 49
0230232... 61, 63, 64	0917397... 20	2025354... 31, 45	2025541... 49
0230233... 61, 63, 64	0917400... 13	2025355... 20	2025542... 49
0230240... 64	0917402... 9	2025427... 32, 33	2025543... 49
0231237... 41, 43	0917404... 29	2025429... 66	2025544... 49
0236885... 64	0917415... 63	2025432... 33	2025545... 49
0236886... 61	0917492... 9	2025433... 32	2025546... 49
0236887... 61	0917642... 13	2025435... 35	2025547... 49
0236888... 64	0918005... 23	2025437... 27	2025548... 49
0243474... 42	0918006... 5	2025438... 27	2025549... 49
0243475... 40	0918007... 47	2025439... 27	2025550... 49
0243742... 41	0918008... 29	2025441... 27	2025551... 49
0243743... 42	0918113... 17	2025443... 20	2025552... 17, 49
0243744... 40, 42	0918186... 44	2025444... 27	2025553... 49
0243745... 41, 43	0918199... 16	2025445... 27	2025554... 33
0244403... 41, 43	0918212... 16	2025447... 45, 46	2025555... 33
0244519... 61	0918213... 17	2025448... 40, 43	2025556... 34
0246869... 5, 23	0918228... 20	2025449... 40	2025557... 34
0249518... 61, 63, 64	0918240... 7	2025450... 40	2025558... 35, 37
0249519... 63, 64	0918265... 66	2025452... 40	2025559... 34, 36
0250544... 42	0918403... 29	2025453... 41	2025560... 34, 36, 39
0327527... 29, 30, 67	0918431... 29	2025455... 41	2025561... 34
0328002... 28, 30, 67	0918448... 17	2025457... 40	2025562... 35
0338338... 20	0918452... 17	2025458... 40, 42	2025563... 35
0901652... 33	0918454... 35	2025459... 40	2025564... 33
0901653... 33	0918459... 28	2025460... 41	2025565... 35, 37, 39
0901752... 9	0918725... 35	2025461... 41	2025566... 35
0903625... 53	0918945... 41	2025470... 40	2025567... 49
0904002... 35	0919262... 29	2025489... 27	2025568... 35, 37
0905123... 29	0919316... 11	2025490... 27	2025569... 35, 37, 38
0905564... 51	0919318... 23	2025491... 17, 18	2025570... 35, 37, 38
0905661... 51	0919319... 17	2025492... 50	2025571... 35, 37, 39
0907727... 4	0919354... 13	2025494... 27	2025572... 33
0907729... 4	0919357... 5	2025495... 27	2025573... 32
0907731... 6	0919360... 8	2025498... 28, 30	2025574... 32
0908127... 22	0919361... 9	2025499... 17	2025575... 32
0908295... 4	0919362... 27	2025500... 27, 49	2025576... 33
0908297... 5	0919364... 56	2025502... 27	2025578... 33
0909007... 17	0919423... 17	2025504... 29, 31	2025579... 32, 33
0909055... 63	0919804... 63	2025505... 40	2025580... 4
0909367... 33	0919933... 20	2025506... 41, 43	2025581... 20
0910149... 33	0920304... 7	2025507... 20	2025582... 29, 31
0910224... 35	0920661... 61	2025508... 33	2025583... 29
0911005... 35	0921280... 23	2025509... 9	2025584... 29
09111712... 8	0921332... 18	2025510... 20	2025585... 29
0912267... 11	0921450... 27	2025511... 27	2025586... 29
0912808... 29	0921959... 10	2025512... 20	2025587... 29
0913620... 24	0921965... 29	2025513... 49	2025588... 29
0913901... 25	0921972... 15	2025514... 19	2025589... 28
0914687... 47	0922000... 53	2025515... 32	2025590... 29, 31
0915019... 52	0922100... 66	2025516... 20	2025591... 29
0915872... 61	0922109... 6	2025517... 5	2025592... 28, 31
0916019... 4	0922116... 20	2025518... 4	2025593... 28, 31, 34, 36
0916227... 27	0922122... 4	2025519... 19	45
0916431... 4	0922124... 19	2025520... 5, 6	2025594... 29, 31
0916432... 17	0922125... 19	2025521... 34, 37, 38	2025595... 20
0916602... 49	0922127... 10	2025522... 33	2025596... 49
0916608... 18	0922129... 53	2025523... 27	2025597... 48
0916609... 17	0922131... 27	2025524... 27	2025598... 8, 11, 11, 11
0916622... 4	0922132... 11	2025525... 26	13, 13
0916926... 65	0922133... 33	2025526... 49	2025600... 8, 9, 11, 11
0916950... 9	0922139... 8	2025527... 48	13, 13
0916951... 61	0924433... 46	2025528... 48	2025601... 9
0916955... 9	2017493... 27	2025529... 49	2025602... 8, 11, 13, 13
0916964... 4	2025066... 62	2025530... 48	15
0916965... 7	2025230... 27	2025531... 48	2025603... 16
0916966... 29	2025231... 16	2025532... 48	2025604... 17
0917091... 31	2025233... 27	2025533... 48	2025605... 27
0917214... 52	2025271... 50	2025534... 49	2025606... 17
0917231... 49	2025333... 18	2025535... 49	2025607... 17, 53, 59
0917356... 4	2025344... 34, 36	2025536... 49	2025608... 17
0917372... 5	2025348... 35, 36	2025537... 49	2025609... 17

NUMERICAL INDEX

PART NO. PAGE	PART NO. PAGE	PART NO. PAGE	PART NO. PAGE
2025610... 16, 54, 59	2025684... 45	2025831... 35	2026042... 4, 6
2025611... 17	2025685... 45	2025833... 19, 23	2026043... 5, 7
2025612... 17	2025686... 37, 44	2025834... 5, 6, 21	2026044... 5
2025613... 17	2025687... 9	2025835... 27	2026045... 27
2025614... 17, 18	2025688... 9, 10, 12, 14	2025836... 41, 42	2026046... 17, 27, 53,
2025615... 17, 18	2025689... 25	2025840... 27	2026047... 27
2025616... 44	2025690... 25	2025841... 26	2026048... 27
2025617... 44, 47	2025691... 9, 10	2025845... 66	2026049... 29, 31
2025618... 44	2025692... 33, 33	2025851... 9	2026051... 33
2025619... 45	2025693... 20	2025852... 21	2026052... 33
2025620... 20, 20, 24	2025697... 28, 29, 30, 67	2025857... 9	2026053... 33
2025621... 35, 36	2025698... 29	2025858... 9	2026054... 33
2025622... 41	2025699... 29	2025859... 9	2026055... 36, 38
2025623... 9, 40	2025700... 27	2025860... 9	2026056... 36, 38
2025624... 29, 31	2025701... 20	2025861... 9	2026057... 36
2025625... 49	2025702... 20	2025862... 9	2026058... 37
2025626... 31, 33, 44, 47	2025703... 20	2025866... 9, 40	2026059... 37, 39
48	2025704... 20	2025867... 9	2026060... 36
2025627... 49	2025705... 20	2025868... 9, 11	2026061... 37
2025628... 49	2025706... 20	2025869... 9, 11	2026062... 37
2025629... 49	2025707... 20	2025870... 4	2026064... 42
2025630... 48	2025708... 20	2025871... 5, 6	2026065... 42
2025631... 33, 48	2025709... 32, 50	2025872... 29, 31	2026066... 43
2025632... 29, 48	2025710... 20	2025873... 41	2026067... 43
2025633... 48	2025711... 28, 30	2025988... 9	2026069... 43
2025634... 49	2025712... 32, 50	2025989... 9, 14	2026070... 42
2025635... 49	2025717... 16, 28, 29, 30	2025992... 66	2026071... 43
2025636... 48	31, 54, 59	2025994... 10, 12, 15	2026072... 42
2025637... 48	2025718... 45, 47	2025995... 10, 12	2026073... 42
2025638... 48	2025720... 19, 23	2025996... 10	2026074... 42
2025639... 49	2025721... 44	2025997... 10	2026076... 42
2025640... 32, 50	2025722... 28, 29, 30, 31	2025998... 10, 12, 14	2026077... 43
2025641... 32, 50	31, 47, 49	2025999... 10, 12, 14	2026078... 42
2025642... 35	2025723... 48	2026000... 10, 12, 14	2026079... 44
2025643... 27	2025724... 34	2026001... 11, 13, 14	2026080... 44, 47
2025644... 32	2025725... 32, 45, 47, 50	2026002... 11, 13, 13, 15	2026081... 45
2025645... 33	2025727... 41	2026003... 10, 12, 14	2026082... 45, 46
2025646... 33	2025739... 17, 17, 18, 66	2026004... 17	2026083... 45, 47
2025647... 33	66	2026005... 17, 53, 59	2026084... 45, 47
2025648... 19	2025747... 20, 62	2026006... 17	2026085... 45, 47
2025649... 19, 28, 31	2025752... 36, 45, 46	2026007... 17, 18	2026087... 49
2025650... 20	2025753... 45, 46	2026008... 17	2026088... 33
2025651... 27	2025757... 17, 53, 59	2026009... 17	2026089... 26
2025652... 9, 10, 41	2025760... 26, 27	2026010... 17	2026090... 5
2025653... 19	2025761... 25, 26	2026011... 17	2026091... 4
2025654... 19	2025770... 35, 37, 39	2026012... 23	2026092... 4
2025655... 19	2025793... 20	2026013... 23, 23, 23, 23	2026093... 24
2025656... 29, 31	2025794... 20	2026014... 23	2026095... 23
2025657... 29, 31	2025796... 20	2026015... 23	2026096... 23
2025659... 20	2025797... 21	2026016... 23	2026097... 23
2025660... 17, 54, 59	2025798... 5	2026017... 23	2026098... 23
2025661... 17, 17	2025799... 5	2026018... 23	2026099... 23
2025662... 17	2025800... 5	2026019... 23, 53, 58	2026102... 24
2025663... 45, 47	2025801... 20	2026020... 24	2026103... 23
2025664... 45	2025802... 21	2026021... 18, 24	2026104... 23
2025665... 45	2025803... 21	2026022... 24	2026105... 11
2025666... 45	2025804... 29, 31	2026023... 23	2026106... 29
2025667... 40	2025805... 4	2026024... 23	2026107... 27
2025668... 9, 10, 14	2025806... 4	2026025... 23	2026109... 66
2025669... 20	2025807... 21	2026026... 23	2026122... 18
2025670... 17	2025809... 21	2026027... 23	2026123... 18
2025671... 20	2025810... 21	2026028... 22	2026124... 18
2025672... 48	2025811... 21	2026029... 24	2026125... 18
2025673... 49	2025812... 21	2026030... 24	2026126... 18
2025674... 33	2025813... 21	2026032... 23, 23	2026127... 18
2025675... 9, 10, 12, 15	2025817... 29	2026033... 8, 11, 13, 15	2026128... 18
2025676... 9, 10	2025818... 19	2026034... 22	2026147... 37
2025677... 49	2025822... 49	2026035... 22	2026198... 47
2025678... 48, 49	2025823... 36, 45, 46	2026036... 22	2026277... 51
2025679... 44	2025824... 27	2026037... 23	2026292... 62, 63
2025680... 45, 46	2025826... 27, 29, 29, 31	2026038... 23	2026293... 62
2025681... 44	2025827... 35, 37	2026039... 23	2026294... 62, 63
2025682... 45, 46	2025829... 27	2026040... 23	2026295... 63
2025683... 45, 46	2025830... 29, 31	2026041... 23	2026301... 49

NUMERICAL INDEX

PART NO. PAGE	PART NO. PAGE	PART NO. PAGE	PART NO. PAGE
2026302... 49	2026481... 52	2026591... 67	2026691... 7
2026304... 24	2026482... 52	2026592... 46	2026692... 7
2026306... 11, 13, 15	2026504... 12	2026593... 23	2026695... 7
2026348... 52	2026505... 13	2026595... 46	2026696... 30
2026356... 23	2026506... 13	2026596... 12, 14	2026697... 31
2026357... 38	2026507... 12	2026597... 13, 15	2026698... 26
2026358... 33	2026508... 12	2026598... 49	2026699... 30
2026360... 58	2026509... 13	2026600... 24, 24	2026701... 17
2026361... 53, 59	2026510... 24	2026604... 53	2026703... 42
2026362... 53, 58	2026511... 23, 31	2026606... 55	2026704... 30
2026363... 53, 58	2026513... 30	2026607... 55	2026705... 31
2026364... 53, 59	2026514... 31	2026608... 55	2026706... 31
2026365... 53, 58	2026516... 31	2026609... 55	2026707... 31
2026366... 53, 58	2026517... 31	2026610... 55	2026708... 31
2026367... 53, 59	2026518... 31, 47	2026611... 55	2026711... 31
2026368... 53, 58	2026519... 31	2026612... 55	2026712... 15
2026369... 56, 59	2026520... 31	2026613... 55	2026713... 14
2026370... 56, 59	2026521... 31	2026614... 55	2026714... 24
2026371... 56, 59	2026522... 31	2026615... 56	2026715... 23
2026372... 56, 59	2026523... 31	2026616... 56	2026716... 23
2026373... 56, 59	2026524... 31	2026617... 56	2026717... 24
2026374... 56, 59	2026527... 38	2026618... 56	2026721... 31
2026375... 56, 59	2026528... 39	2026619... 56	2026847... 7
2026376... 56, 59	2026529... 39	2026620... 55	2026848... 24
2026377... 58	2026530... 38	2026621... 55	2026849... 66
2026378... 53, 59	2026531... 39	2026622... 55	2026850... 12, 14
2026379... 53, 59	2026532... 39	2026623... 55	2026858... 42
2026380... 46, 53, 59	2026533... 39	2026624... 55	2026859... 65
2026381... 57, 60, 67	2026534... 38	2026625... 55	2026860... 65
2026382... 60	2026535... 39	2026626... 55	2026861... 65
2026383... 57, 60	2026536... 38	2026627... 56	2026862... 65
2026384... 57, 60	2026537... 48	2026628... 55	2026869... 43
2026385... 53, 59	2026538... 49	2026629... 55	2026897... 55
2026386... 23	2026539... 17, 53, 59	2026630... 55	2026914... 43
2026387... 23	2026540... 58	2026631... 55	2027198... 26
2026389... 4	2026541... 58	2026632... 55	4054800... 41, 43
2026390... 4	2026542... 58	2026633... 55	
2026392... 23	2026543... 58	2026634... 55	
2026393... 23	2026544... 58	2026635... 53	
2026394... 24	2026545... 58	2026636... 53	
2026402... 24	2026546... 56, 58	2026637... 53	
2026403... 24	2026547... 59	2026638... 57, 67	
2026419... 47	2026548... 59	2026639... 57, 67	
2026420... 47	2026549... 59	2026640... 57	
2026422... 47	2026550... 56, 59	2026648... 43, 67	
2026423... 47	2026551... 55, 59	2026649... 42, 67	
2026424... 46	2026552... 56, 59	2026650... 42, 67	
2026425... 47	2026553... 17, 54, 59	2026651... 42, 62, 67	
2026426... 47	2026557... 59	2026652... 42, 67	
2026427... 47	2026558... 57, 60	2026657... 4	
2026428... 46	2026559... 57, 60	2026658... 4	
2026429... 47	2026560... 57, 60, 67, 67	2026663... 31	
2026430... 47	2026561... 57, 60	2026664... 24	
2026431... 47	2026562... 57, 60	2026665... 24	
2026461... 51	2026563... 57, 60	2026666... 24	
2026462... 52	2026564... 60, 67	2026667... 24	
2026463... 51	2026565... 60, 67	2026668... 24	
2026464... 51	2026566... 59	2026669... 7	
2026465... 52	2026567... 59	2026670... 7	
2026466... 52	2026568... 59	2026673... 6	
2026467... 52	2026569... 51	2026674... 7	
2026468... 52	2026570... 39	2026675... 7	
2026469... 51	2026571... 29, 31	2026676... 7	
2026470... 52	2026573... 27	2026679... 62, 65	
2026471... 52	2026575... 46	2026680... 62	
2026472... 52	2026578... 46	2026681... 62	
2026473... 52	2026579... 13, 15	2026682... 62	
2026474... 51	2026580... 13, 15	2026683... 62	
2026475... 51	2026581... 13, 15, 33	2026684... 62	
2026476... 51	2026582... 32	2026685... 62	
2026477... 51	2026583... 13	2026686... 62	
2026478... 51	2026588... 59	2026688... 56	
2026479... 51	2026589... 59	2026689... 56	
2026480... 51	2026590... 59	2026690... 6	

