









WIRING DIAGRAM

8FG(D)U15-32, 8FGCU20-32

CHAPTER 1 INTRODUCTION	E1
CHAPTER 2 ELECTRICAL WIRING ROUTING AND RELAY LOCATION	E2
CHAPTER 3 SYSTEM CIRCUITS	E3
CHAPTER 4 GROUND POINTS	E4
CHAPTER 5 FUSES FOR POWER SUPPLY	E5
CHAPTER 6 CONNECTOR LIST	E6

8FGCU15, 18, SU20

CHAPTER 7 ELECTRICAL WIRING ROUTING AND RELAY LOCATION	E7
CHAPTER 8 SYSTEM CIRCUITS	E8
CHAPTER 9 GROUND POINTS	E9
CHAPTER 10 FUSES FOR POWER SUPPLY	E10
CHAPTER 11 CONNECTOR LIST	E11



CHAPTER 1 INTRODUCTION

E1

CHAPTERS OF THIS SECTION E1-2

HOW TO READ CHAPTERS

Chapter 2 ELECTRICAL WIRING ROUTINGS and RELAY LOCATIONS

 ELECTRICAL WIRING ROUTINGS E1-3

 RELAY LOCATIONS

 JUNCTION BLOCK (J/B) / RELAY BLOCK (R/B) E1-4

Chapter 3 SYSTEM CIRCUITS

 POWER SUPPLY CIRCUIT E1-6

 REFERENCE PAGE E1-10

Chapter 4 GROUND POINTS

 GROUND POINTS E1-11

Chapter 5 FUSES FOR POWER SUPPLY

 FUSES FOR POWER SUPPLY E1-11

Chapter 6 CONNECTOR LIST

 CONNECTOR LIST E1-12

 WIRE TO WIRE..... E1-13

ABBREVIATIONS E1-14

GLOSSARY OF TERMS AND SYMBOLS E1-15

INTRODUCTION

CHAPTERS OF THIS SECTION

This section consists of the following 6 chapters:

Chapter 1 INTRODUCTION	Gives brief explanation of each chapter, provides instructions on how to use this manual, and defines the abbreviations used in the electrical circuit diagrams.
Chapter 2 ELECTRICAL WIRING ROUTINGS and RELAY LOCATIONS	Electrical wiring routings show installation positions, ground points, connector numbers, and part names related to wire harnesses, connectors, relay blocks and junction blocks used in the forklift, such as in the engine room, instrument panel and mast area. Relay locations show design drawings and internal circuit diagrams related to relays, relay blocks (R/B), junction blocks (J/B), fusible links (F/L) and junction connectors (J/C).
Chapter 3 SYSTEM CIRCUITS	Show power supply circuit diagrams and wiring diagrams for each system, such as the engine. (Only wiring information for complete circuits is shown.)
Chapter 4 GROUND POINTS	Show related systems for each ground point.
Chapter 5 FUSES FOR POWER SUPPLY	Show power distribution from each power supply (fuse or fusible link) to various systems.
Chapter 6 CONNECTOR LIST	Shows shapes and part numbers of connectors used in electrical wiring routings and electrical wiring diagrams.

INTRODUCTION


HOW TO READ CHAPTERS

Chapter 2 ELECTRICAL WIRING ROUTINGS and RELAY LOCATIONS

ELECTRICAL WIRING ROUTINGS

Electrical wiring routings show installation positions, ground points, connector numbers, and part names related to wire harnesses, connectors, relay blocks and junction blocks used in the forklift.

(Connector codes are the same as those used in the electrical wiring diagrams.)



- [A] Title
Indicates a location on the forklift.
- [B] Wire harness
Indicates a wire harness name.
- [C] Reference page for electrical wiring routing
Indicates a reference page showing a wire harness location when the wire harness continues to the different electrical wiring routing.
- [D] Junction block
Indicates a junction block name and a connector code to be connected.
- [E] Junction block connector
Indicates a connector code connected to a junction block.
- [F] Wire harness and junction block connection
Indicates a junction block name and a wire harness name to be connected.
- [G] Ground point code
Indicates a ground point code.
- [H] Ground point name
Indicates a ground point name.
- [I] Harness to harness connector
Indicates a connector code that joins two wire harnesses.
- [J] Wire harness names
Indicate two wire harness names for a wire harness and wire harness connection.
- [K] Part connector
Indicates a connector code connected to a part.
- [L] Part name
Indicates a part name connected to a connector.


INTRODUCTION

- [A] Junction block /relay block
Indicates a junction block or relay block name, its location and a reference page for an internal circuit diagram.
- [B] Connector code and color
Indicates the code and color of a connector connected to a junction block.
- [C] Connector part number
Indicates the part number of a connector.
- [D] Connector shape and terminal number
Indicates a connector shape on the junction block side.
Numbers indicate terminal numbers.
- [E] Connector shape and terminal number
Indicates a connector shape on the wire harness side.
Numbers indicate terminal numbers.
- [F] Fuse
Indicates a fuse name and capacity.
Terminal 1 is on the primary side and terminal 2 is on the secondary side.
- [G] Internal circuit diagram
Indicates an internal circuit diagram of a junction block.
- [H] Connector code and terminal number
Indicates a connector code and a terminal number connected to a junction block.

INTRODUCTION

Chapter 3 SYSTEM CIRCUITS (1) SYSTEM CIRCUITS

A system circuit consists of a power source circuit diagram and respective system circuit diagrams. A power source circuit diagram shows the connections from the power source to fuses. A system diagram shows the connections from fuses to ground points of each system.



INTRODUCTION

[A] Section page
Indicates the page number for the section.

[B] System title
Indicates a system name.

[C] Part name and connector code
Indicates a part name and connector code to be connected. For connector shapes, refer to chapter 6 CONNECTOR LIST.

[G] Page-to-page connection code
Indicates a wire harness continues onto the following page from the matching code.

[H] Harness to harness connector
Indicates a connector code that connects two wire harnesses.
For the connector shape, refer to chapter 6 CONNECTOR LIST.

C7 Part connector

- The wire harness in which the connector is located.
Example: "C" indicates a connector used in the C wire harness.
For wire harness names, refer to Chapter 2 ELECTRICAL WIRING ROUTINGS and RELAY LOCATIONS.
- Serial number allocated to the connector

D11 (A), D42 (D)

- Connector number
- Used to indicate different connectors when multiple connectors are connected to a part, or multiple types of connectors are used according to specifications.



Harness to harness connector

- Terminal number
- Wire harness to be connected
Example: "AK" means a connection of the female connector*1 of the "A" wire and the male connector*2 of the "K" wire.
*1: A female connector has a female terminal.
*2: A male connector has a male terminal.
- Serial number of a connector
- Male terminal side

[D] Fuse
Indicates a fuse name and capacity.
Terminal 1 is on the primary side and terminal 2 is on the secondary side.
For fuse installation positions, refer to chapter 2 ELECTRICAL WIRING ROUTINGS and RELAY LOCATIONS.


[E] Power supply information
Indicates the ignition key position when power is supplied to a fuse.

[F] Specification information
Indicates that connectors or wire colors vary depending on forklift models, engine types or specifications.




INTRODUCTION

- [I] Terminal number
Indicates a terminal number of a connector to be connected.
- [J] Junction block connector
Indicates a connector code connected to a junction block.
For a connector shape, refer to chapter 2 ELECTRICAL WIRING ROUTINGS and RELAY LOCATIONS.




- [L] Wire color
Indicates a wire harness color.
When two alphabetical codes are indicated, for example "W-B", the first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Code	Wire Color	Code	Wire Color	Code	Wire Color
B	Black	L	Blue	SB	Sky Blue
BR	Brown	LG	Light Green	V	Violet
DG	Dark Gray	O	Orange	W	White
G	Green	P	Pink	Y	Yellow
GR	Gray	R	Red	AM	Amber



- [M] Switch
Circuit diagrams are shown with the switches in the OFF position.
For switch operation conditions, refer to the repair manual.

- [K] Ground point code
Indicates a ground point code.
For ground point positions, refer to chapter 2 ELECTRICAL WIRING ROUTINGS and RELAY LOCATIONS.



REFERENCE PAGE

[A] PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 20	E2-8	G 7	E2-2	G 21	E2-2	K 6	E2-2
A 25	E2-10	G 8	E2-2	G 25	E2-2	O 2	E2-14
A 27	E2-10	G 9	E2-2	G 26	E2-2	Q 1	E2-8
A 35	E2-10	G 10	E2-2	G 27	E2-10	S 12	E2-14
A 36	E2-10	G 11	E2-2	G 28	E2-10	T 6	E2-16
A 65	E2-10	G 12	E2-2	G 29	E2-10	a 1	E2-8
A 66	E2-10	G 13	E2-2	G 73	E2-10		
C 1	E2-16	G 16	E2-2	K 1	E2-2		
C 3	E2-16	G 18	E2-2	K 2	E2-2		
G 6	E2-2	G 19	E2-2	K 3	E2-2		

[B] RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Blocks Name or Joining Wire Harness and J/B
1	E2-10	Engine Room R/B
1C	E2-19	BODY MAIN WIRE to J/B
1D	E2-18	ENGINE WIRE to J/B
1E	E2-18	LH SIDE WIRE to J/B

[C] WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AC2	E2-10	BODY MAIN WIRE to SIDE RH WIRE
AC3	E2-10	BODY MAIN WIRE to SIDE RH WIRE
AG1	E2-10	BODY MAIN WIRE to ENGINE WIRE
AO1	E2-10	BODY MAIN WIRE to LH SIDE WIRE
Aa1	E2-8	BODY MAIN WIRE to SUB ACCEL WIRE
GK1	E2-2	ENGINE WIRE to ENGINE SUB WIRE
GK2	E2-2	ENGINE WIRE to ENGINE SUB WIRE
QA1	E2-8	INSTRUMENT PANEL WIRE to BODY MAIN WIRE
SO1	E2-14	REAR UPPER MAIN WIRE to LH SIDE WIRE
TC2	E2-16	REAR UPPER SUB RH WIRE to SIDE RH WIRE
TS1	E2-16	REAR UPPER SUB RH WIRE to REAR UPPER MAIN WIRE

[D] EARTH

Code	See Page	Name
AB	E2-10	FRONT PLATE LEFT OUTSIDE EARTH
GF	E2-2	ENGINE UPPER EARTH
GG	E2-2	ENGINE UPPER EARTH
OK	E2-14	REAR PILLER LEFT UNDER EARTH

[A] Parts

Indicates pages showing electrical wiring routings for the parts.

[B] Relay blocks and junction blocks

Indicates titles and pages showing electrical wiring routings for the relay blocks or junction blocks.

[C] Connections of wire harness and wire harness

Indicates titles and pages showing electrical wiring routings for the connections of two wire harnesses.

[D] Ground points

Indicates titles and pages showing electrical wiring routings for the ground points.

INTRODUCTION

Chapter 4 GROUND POINTS
GROUND POINTS

These tables describe related systems for each ground point.


E4-2			
GROUND POINTS			
CODE	GROUND POINT LOCATION	SYSTEM NAME	PAGE
AA	FRONT PLATE LEFT OUTSIDE	SAS/OPS SYSTEM	E3-36
		CLEARANCE LAMP	E3-72
		STOP LAMP	E3-76
		STROBE LIGHT	E3-52
		TURN SIGNAL LAMP	E3-70
		BACK UP LAMP BUZZER	E3-74
		HEAD LAMP	E3-68
		POWER SHIFT TRANSMISSIN	E3-32
AB	FRONT PLATE LEFT OUTSIDE	SAS/OPS SYSTEM	E3-36
		ENGINE CONTROL (4Y-E)	E3-10
		COOLER	E3-80
		CLEARANCE LAMP	E3-72
		COMBINATION METER	E3-54
		BACK UP LAMP BUZZER	E3-74
AC	FRONT PLATE LEFT OUTSIDE	WET BRAKE	E3-34
		DIAG	E3-42
		COOLER	E3-80
		STARTING	E3-6
		STROBE LIGHT	E3-52
		TURN SIGNAL LAMP	E3-70
		HEATER	E3-78
		FRONT WIPER AND WASHER	E3-60
		HEAD LAMP	E3-68
		HORN	E3-64
		REAR WIPER AND WASHER	E3-62
		REAR WIPER	E3-28

Chapter 5 FUSES FOR POWER
FUSES FOR POWER

These tables describe power distribution from each power supply (fuse or fusible link) to various systems.

E5-3			
FUSE FOR POWER SUPPLY			
FUSIBLE LINK BLOCK ASSY			
FUSE		SYSTEM	Page
100A	GLOW	GLOW	E3-76
		INTAKE HEATER	E3-84
120A	ALT	CHARGING	E3-96
ENGINE ROOM R/B			
FUSE		SYSTEM	Page
7.5A	ACC-B	OPS SYSTEM	E3-250
		SAS/OPS SYSTEM	E3-258
7.5A	ALT-S	CHARGING	E3-194
7.5A	ECU-B	SAS/OPS SYSTEM	E3-234
10A	BACK LP	BACK UP LAMP BUZZER	E3-220
		REAR WORKING LAMP	E3-204
		STROBE LIGHT	E3-182
		GLOW	E3-162
		INTAKE HEATER	E3-166
		ENGINE CONTROL (4Y-E)	E3-170
		FUEL	E3-278

Chapter 6 CONNECTOR LIST CONNECTOR LIST



[A] Connector shape and terminal number

Indicates the connector shape on the wire harness side, which is connected to a part.

Numbers indicate terminal numbers that are used in the circuit diagrams.

[B] Connector color

Indicates a connector color.

[C] Part connector

Indicates a connector number connected to a part.


The code is the same as that used in the electrical wiring routing.

[D] Connector part number

Indicates the part number of a connector.

INTRODUCTION

HARNESS TO HARNESS CONNECTOR



[A] Connector shape and terminal number

Indicates the connector shape that connects two wire harnesses.

On left: Female connector^{*1} shape (This example indicates a connector for the G wire)

On right: Male connector^{*2} shape (This example indicates a connector for the K wire)

*1: A female connector has a female terminal.

*2: A male connector has a male terminal.

B] Connector color

Indicates a connector color.

[C] Harness to harness connector

Indicates a connector code that connects two wire harnesses

The code is the same as that used in the electrical wiring routing and wiring diagram.

[D] Connector part number

Indicates the part number of a connector










ABBREVIATIONS




The following abbreviations are used in this section.

Abbreviations	Explanation
ASC	Auto Speed Control
ASSY	Assembly
CNG	Compressed Nutural Gas
DPF	Diesel Particulate Filter
ECU	Electronic Control Unit
FR	Front
J/B	Junction Block
LH	Left-Hand
LPG	Liquefied Petroleum Gas
M/T	Manual Transmission
OPS	Operator Presence Sensing
PS	Power Steering
R/B	Relay Block
RH	Right-Hand
RR	Rear
SAS	System of Active Stability
SOL	Solenoid
SPEC.	Specification
T/C	Torque Converter & Transmission
W/	With
W/O	Without






INTRODUCTION

GLOSSARY OF TERMS AND SYMBOLS

BATTERY 	GROUND 	RELAY  1. NORMALLY CLOSED	SWITCH, MANUAL  1. NORMALLY OPEN
CAPACITOR (Condenser) 	HEADLIGHTS  1. SINGLE FILAMENT	 2. NORMALLY OPEN	 2. NORMALLY CLOSED
CIGARETTE LIGHTER 	 2. DOUBLE FILAMENT	RELAY, DOUBLE THROW 	SWITCH, DOUBLE THROW 
DIODE 	HORN 	RESISTOR, TAPPED 	SWITCH, IGNITION 
DIODE, ZENER 	LIGHT 	SENSOR (Termistor) 	
LED (Light Emitting Diode) 	METER, ANALOG 	SENSOR 	SWITCH, WIPER PARK 
PHOTODIODE 	METER, DIGITAL 	SHORT PIN 	WIRES  1. NOT CONNECTED
MOTOR 	RESISTOR 	FUSE 	 2. SPLICED
SPEAKER 	RESISTOR, VARIABLE or RHEOSTAT 	SOLENOID 	HIGH-TENSION WIRE 
TRANSISTOR 			



MEMO



CHAPTER 2 ELECTRICAL WIRING ROUTINGS AND RELAY LOCATIONS

E2




ELECTRICAL WIRING ROUTINGS

ENGINE ROOM (4Y-E)	E2-2
ENGINE ROOM (1DZ)	E2-4
INSTRUMENT PANEL	E2-6
FRONT BODY	E2-8
MAST AREA	E2-10
REAR BODY (NO.1)	E2-12
REAR BODY (NO.2)	E2-14

RELAY LOCATIONS

JUNCTION BLOCK (J/B) / RELAY BLOCK (R/B)	E2-16
--	-------


SYMBOLS	WIRE NAME	SYMBOLS	WIRE NAME
A	BODY MAIN WIRE	T	RR UPR SUB RH WIRE
B	BODY SUB NO.1 WIRE	U	HEAD GUARD SW WIRE
C	SIDE RH WIRE	X	HOOD MAIN WIRE
D	T/C HEAT GAUGE WIRE	Y	HOOD SUB NO.1 WIRE
G	ENGINE WIRE	Z	RR LWR WIRE
H	BATTERY STARTER WIRE	a	SUB ACCEL WIRE
I	BATTERY EARTH WIRE	b	MAST SENSOR WIRE
J	ENGINE EARTH WIRE	d	FR STAY WIRE LH
K	ENGINE SUB WIRE	g	CNG PRESSURE SENSOR WIRE
M	LPG PRESSURE SWITCH WIRE	h	WIPER SUB WIRE
O	SIDE LH WIRE	i	DIGITAL METER WIRE
Q	INSTRUMENT PANEL WIRE	j	INSTRUMENT PANEL SW WIRE
R	FR STAY WIRE RH	k	EZ PEDAL LIMIT SW WIRE
S	RR UPR MAIN WIRE	m	INSTRUMENT PANEL WIRE



ELECTRICAL WIRING ROUTINGS

G2	ALTERNATOR	GK1	} ENGINE WIRE to ENGINE SUB WIRE
G4	ALTERNATOR	GK2	
G6	THROTTLE POSITION SENSOR(WITH MOTOR)	KM1	ENGINE SUB WIRE to LPG PRESSURE SWITCH WIRE
G8	INJECTOR NO.1	Kg1	ENGINE SUB WIRE to CNG PRESSURE SENSOR WIRE
G9	INJECTOR NO.2		
G10	INJECTOR NO.3		
G11	INJECTOR NO.4	GF	ENGINE UPPER EARTH
G12	VACUUM SENSOR	GG	ENGINE UPPER EARTH
G13	FCM STEP MOTOR	IH	REAR PILLAR LEFT UNDER EARTH
G14	WATER TEMPERATURE SENDER		
G16	WATER TEMPERATURE SENSOR		
G18	G2 SENSOR		
G19	DISTRIBUTOR		
G21	IGNITION COIL		
G22	OIL PRESSURE SWITCH		
G23	STARTER		
G24	FUSIBLE LINK BLOCK ASSY		
G25	IGNITER		
G26	TACHO CHECK		
G74	LPG INJCTOR		
G75	ALTERNATOR		
G76	FUSIBLE LINK BLOCK-1		
G77	DISCONNECT SWITCH(BATT)		
G78	DISCONNECT SWITCH(ALT)		
G79	DISCONNECT SWITCH(ALT)		
G80	DISCONNECT SWITCH(BATT)		
G86	BATTERY		
G88	GASOLINE/LPG SWITCH		
H1	STARTER		
H3	BATTERY		
I1	BATTERY		
J1	STARTER		
J3	BATTERY		
K1	LPG SOLENOID(SLOW)		
K2	LPG RESISTOR		
K3	LPG SOLENOID(MAIN)		
K5	CNG SOLENOID		
K6	CNG RESISTOR		
M1	LPG PRESSURE SWITCH		
M2	LPG PRESSURE SWITCH		
g1	CNG PRESSURE SENSOR		

ENGINE ROOM(1DZ)



ELECTRICAL WIRING ROUTINGS

G1	ALTERNATOR
G4	ALTERNATOR
G14	WATER TEMPERATURE SENDER
G17	WATER TEMPERATURE SENSOR
G22	OIL PRESSURE SWITCH
G24	FUSIBLE LINK BLOCK ASSY
G30	GLOW PLUG
G31	INJECTOR PUMP
G32	STARTER
G33	GLOW PLUG RELAY
G34	FUEL CUT SOLENOID
G36	OPEN CLOSE SWITCH
G37	STEP MOTOR
G75	ALTERNATOR
G76	FUSIBLE LINK BLOCK-1
G77	DISCONNECT SWITCH(BATT)
G78	DISCONNECT SWITCH(ALT)
G79	DISCONNECT SWITCH(ALT)
G80	DISCONNECT SWITCH(BATT)
G82	GLOW PLUG NO.1
G83	GLOW PLUG NO.2
G84	GLOW PLUG NO.3
G85	GLOW PLUG NO.4
G87	FUSIBLE LINK BLOCK-2
H2	STARTER
H3	BATTERY
I2	BATTERY
J2	STARTER
GJ	JUNCTION BLOCK IN FRONT INSIDE EARTH
GL	JUNCTION BLOCK IN FRONT INSIDE EARTH
IH	REAR PILLAR LEFT UNDER EARTH
JL	FRONT PLATE LEFT INSIDE EARTH

INSTRUMENT PANEL

- A

BODY MAIN WIRE
- B

BODY SUB NO.1 WIRE
- Q

INSTRUMENT PANEL WIRE
- R

FR STAY WIRE RH
- U

HEAD GUARD SW WIRE
- a

SUB ACCEL WIRE
- b

MAST SENSOR WIRE
- d

FR STAY WIRE LH
- h


WIPER SUB WIRE
- i

DIGITAL METER WIRE
- j



INSTRUMENT PANEL SW WIRE
- m

INSTRUMENT PANEL WIRE
- k

EZ PEDAL LIMIT SW WIRE







[W/ CNG DIGITAL METER]



ELECTRICAL WIRING ROUTINGS

A1	HORN SWITCH	AQ1	BODY MAIN WIRE to INSTRUMENT PANEL WIRE
A2	IGNITION SWITCH	Aa1	BODY MAIN WIRE to SUB ACCEL WIRE
A3	STEERING SENSOR	Ah1	BODY MAIN WIRE to WIPER SUB WIRE
A4	LIGHT CONTROL SWITCH	Ai1	BODY MAIN WIRE to DIGITAL METER WIRE
A6	STOP LAMP SWITCH	Ak1	BODY MAIN WIRE to EZ PEDAL LIMIT SW WIRE
A7	BRAKE WARNING SWITCH	mA1	INSTRUMENT PANEL WIRE to BODY MAIN WIRE
A8	OPS WARNING BUZZER	QA1	INSTRUMENT PANEL WIRE to BODY MAIN WIRE
A9	PARKING BRAKE SWITCH	hA1	WIPER SUB WIRE to BODY MAIN WIRE
A10	TILT SOLENOID	jA1	INSTRUMENT PANEL SW WIRE to BODY MAIN WIRE
A11	LIFT SOLENOID		
A12	UNLOAD SOLENOID		
A13	TILT SWITCH		
A14	LIFT SWITCH		
A15	NEUTRAL TILT SWITCH		
A18	PRESSURE SENSOR		
A19	SPEED SENSOR		
A20	SAS/OPS ECU		
A21	SAS/OPS ECU		
A23	MINI LEVER ECU		
A41	LEFT T/C SHIFT SWITCH		
A42	TILT ANGLE SENSOR		
A49	HORN		
A51	CONTROL VALVE PUSH SOLENOID		
A52	CONTROL VALVE PULL SOLENOID		
A56	BACK TILT SOLENOID		
A68	WET BRAKE BUZZER		
A69	WET BRAKE LAMP		
A70	PRESSURE SWITCH		
A78	EZ PEDAL DIRECTION SWITCH		
A80	PARKING WARNING LAMP		
A86	SHORT CONNECTOR		
A87	SHORT CONNECTOR		
Q1	COMBINATION METER		
Q2	DISPLAY		
a1	ACCEL SENSOR		
h1	FRONT WIPER RELAY		
h2	FRONT WIPER MOTOR		
i1	CNG DIGITAL METER		
i2	CNG DIGITAL METER		
i3	CNG DIGITAL METER		
i4	CNG DIGITAL METER		
j1	INPANE SWITCH(+)		
j2	INPANE SWITCH(-)		
k1	ACCEL SWITCH		
m1	12V POWER SUPPLY		

FRONT BODY




ELECTRICAL WIRING ROUTINGS

A24	FUSIBLE LINK BLOCK ASSY	1A	BODY MAIN WIRE to J/B
A25	DIAGNOSIS	1B	
A26	DIODE	1C	
A27	JUNCTION CONNECTOR	1D	ENGINE WIRE to J/B
A29	CAN JOINT CONNECTOR	1E	SIDE LH WIRE to J/B
A31	CAN JOINT CONNECTOR		
A32	CAN JOINT CONNECTOR		
A33	CAN JOINT CONNECTOR	AC2	BODY MAIN WIRE to SIDE RH WIRE
A34	CAN JOINT CONNECTOR	AC4	
A35	ENGINE ECU	AG1	BODY MAIN WIRE to ENGINE WIRE
A36	ENGINE ECU	AG2	
A37	LPG WARNING RELAY	AG4	
A38	LPG WARNING BUZZER	AO1	BODY MAIN WIRE to SIDE LH WIRE
A45	MATCHING CONNECTOR	AO2	
A46	MATCHING CONNECTOR	AO3	
A47	SHIFT SOLENOID2	DA1	T/C HEAT GAUGE WIRE to BODY MAIN WIRE
A48	SHIFT SOLENOID2		
A54	SHIFT SOLENOID1		
A55	SHIFT SOLENOID1		
A64	JUNCTION CONNECTOR(J)	AA	FRONT PLATE LEFT OUTSIDE EARTH
A65	JUNCTION CONNECTOR(A)	AB	FRONT PLATE LEFT OUTSIDE EARTH
A66	JUNCTION CONNECTOR(B)	AC	FRONT PLATE LEFT OUTSIDE EARTH
A71	DIODE(WET BRAKE)	AD	TRANSMISSION UPPER EARTH
A73	T/C INTERLOCK(FR)		
A74	SHORT CONNECTOR(FR)		
A75	T/C INTERLOCK(RR)		
A76	SHORT CONNECTOR(RR)		
A79	BUZZER DIODE		
A81	PARKING LAMP DIODE		
A82	FRONT SOLENOID RELAY		
A83	REAR SOLENOID RELAY		
A84	EZ PEDAL MAIN RELAY		
A85	NEUTRAL START RELAY		
D1	T/C OIL TEMPERATURE SENSOR		
G27	ENGINE ECU		
G28	ENGINE ECU		
G29	JUNCTION CONNECTOR(B)		
G35	GLOW PLUG TIMER		
G38	ASC ECU		
G39	ASC ECU		
G43	JUNCTION CONNECTOR(E)		
G73	JUNCTION CONNECTOR(A)		

MAST AREA

*1:V MAST
*2:FSV MAST




ELECTRICAL WIRING ROUTINGS

- R1 FRONT COMBINATION LAMP RIGHT
- R6 HEAD LAMP RIGHT
- U1 HEATER SWITCH
- U2 FRONT WIPER SWITCH
- U3 REAR WIPER SWITCH
- U5 LPG WARNING SWITCH
- U6 FAN SWITCH
- U7 FAN MOTOR(B)
- U8 FAN MOTOR(E)
- b1 MAST SWITCH
- d1 FRONT COMBINATION LAMP LEFT
- d6 HEAD LAMP LEFT

- Ab1 BODY MAIN WIRE to MAST SENSOR WIRE
- BA1 BODY SUB NO.1 WIRE to BODY MAIN WIRE
- RA2 FR STAY WIRE RH to BODY MAIN WIRE
- UA1 } HEAD GUARD SW WIRE to BODY MAIN WIRE
- UA2 }
- UB1 HEAD GUARD SW WIRE to BODY SUB NO.1 WIRE
- dA2 FR STAY WIRE LH to BODY MAIN WIRE

*1:CABIN
*2:EXCEPT CABIN



ELECTRICAL WIRING ROUTINGS

- O1 YAW RATE SENSOR
- O2 FUEL SENDER GAUGE & FUEL PUMP
- O3 SEDIMENTARY SWITCH
- O4 STEERING SOLENOID
- S2 REAR WIPER MOTOR
- S3 REAR COMBINATION LAMP LEFT
- S4 REAR COMBINATION LAMP RIGHT
- S8 REAR WIPER RELAY
- S11 REAR HORN SWITCH
- S13 LED REAR COMBINATION LAMP LEFT
- S14 LED REAR COMBINATION LAMP RIGHT
- S15 SMART ALARM(+)
- S16 SMART ALARM(-)
- S17 BEACON LAMP LEFT(B)
- S18 BEACON LAMP LEFT(E)
- S19 BEACON LAMP RIGHT(B)
- S20 BEACON LAMP RIGHT(E)
- S21 RESISTOR(STOP LAMP)
- S22 RESISTOR(TURN LAMP)
- S23 DIODE(LED REAR COMBINATION)
- X1 SEAT SWITCH
- Y1 NEUTRAL TILT SWITCH
- Y2 ATTACHMENT LEVER1
- Y3 ATTACHMENT LEVER2
- Y4 T/C SHIFT SWITCH
- Y5 TILT LEVER
- Y6 LIFT LEVER
- Y7 LOAD INDICATOR SWITCH
- Y8 CONTROL VALVE LEVER 3,4SELECT SWITCH
- Y9 SHORT CONNECTOR
- Z1 SWING LOCK SOLENOID
- Z3 TIRE ANGLE SENSOR

- S01
- S02 } RR UPR MAIN WIRE to SIDE LH WIRE
- S03 }
- X01
- X02 } HOOD MAIN WIRE to SIDE LH WIRE
- X03 }
- X04 }
- YX1
- YX2 } HOOD SUB NO.1 WIRE to HOOD MAIN WIRE
- ZO1 } RR LWR WIRE to SIDE LH WIRE

- OK REAR PILLAR LEFT UNDER EARTH


E2-14

ELECTRICAL WIRING ROUTINGS

REAR BODY(NO.2)

*1:DX CABIN

*2:W/ HEATER W/O DX CABIN




ELECTRICAL WIRING ROUTINGS

B1	FRONT WASHER MOTOR
B3	HEATER BLOWER MOTOR
B5	HEATER RELAY
B6	REAR WASHER MOTOR
C1	O2 SENSOR
C3	IN AIR SENSOR
C4	AIR CLEANER WARNING SWITCH
C5	AIR CLEANER WARNING SWITCH
C6	RADIATOR WARNING SWITCH
C7	BACK UP BUZZER
T8	COMPARTMENT LAMP
T9	COMPARTMENT LAMP SWITCH(+)
T10	COMPARTMENT LAMP SWITCH(-)
T11	WORK LAMP
T12	WORK LAMP SWITCH(+)
T13	WORK LAMP SWITCH(-)
ST1	RR UPR MAIN WIRE to RR UPR SUB RH WIRE


FUSIBLE LINK BLOCK ASSY (INNER CIRCUIT : SEE PAGE E2-22)

(EXCEPT UL-GS, UL-LPS AND UL-DS TYPE)

[FRONT]




[REAR]



RELAY LOCATIONS


FUSIBLE LINK BLOCK-1 : ENGINE ROOM LEFT

(UL-GS TYPE, UL-LPS TYPE, UL-DS TYPE)




FUSIBLE LINK BLOCK -2 : ENGINE ROOM LEFT

(UL-DS TYPE)




① ENGINE ROOM R/B : ENGINE ROOM LEFT

- * 1:15A E-THRO (4Y-E)
7.5A ECU-B2 (1DZ)
- * 2:LPG MAIN RELAY (4Y-E)
ASC RELAY (1DZ)
- * 3:15A (4Y-E)
7.5A (1DZ)




RELAY LOCATIONS

○ J/B : LEFT STEP (INNER CIRCUIT : SEE PAGE E2-24)




CAN JOINT CONNECTOR : INSIDE OF THE ECU BOX
(INNER CIRCUIT : SEE PAGE E2-27)




RELAY LOCATIONS

JUNCTION CONNECTOR


BLACK (A65) ----- JUNCTION CONNECTOR (A) ----- BLACK (G73)




BLUE (A66) ----- JUNCTION CONNECTOR (B) ----- BLUE (G29)




GRAY (A27) JUNCTION CONNECTOR
GRAY (G43) JUNCTION CONNECTOR (E)





(A64) JUNCTION CONNECTOR (J)









[FUSIBLE LINK BLOCK ASSY INNER CIRCUIT]






MEMO




RELAY LOCATIONS

[J/B INNER CIRCUIT (1/3)]



RELAY LOCATIONS


[J/B INNER CIRCUIT (2/3)]



E2-26


RELAY LOCATIONS




[J/B INNER CIRCUIT (3/3)]








RELAY LOCATIONS




[CAN JOINT CONNECTOR INNER CIRCUIT]











MEMO







MEMO



.....This Page Intentionally Left Blank.....

CHAPTER 3 SYSTEM CIRCUITS

POWER SOURCE	
POWER SOURCE	E3-2
CHARGING	E3-4
STARTING	E3-6
ENGINE	
FUEL	E3-8
ENGINE CONTROL (4Y-E)	E3-10
GLOW	E3-16
ASC	E3-20
LPG WARNING SYSTEM (4Y-E)	E3-24
CHASSIS	
POWER SHIFT TRANSMISSION	E3-26
EZ PEDAL	E3-30
WET BRAKE	E3-34
BODY	
SAS/OPS SYSTEM	E3-36
MINI LEVER	E3-40
DIAG	E3-42
REAR WORKING LAMP	E3-44
COMPARTMENT LAMP	E3-46
STROBE LIGHT	E3-48
INSTRUMENT PANEL	
COMBINATION METER	E3-50
MULTI DISPLAY	E3-54
FRONT WIPER & WASHER	E3-56
REAR WIPER & WASHER	E3-58
HORN & W/ REAR HORN SWITCH	E3-60
CNG DIGITAL METER	E3-62
LIGHTING SYSTEM	
HEAD LAMP	E3-64
TURN SIGNAL LAMP	E3-66
CLEARANCE LAMP	E3-70
BACK UP LAMP BUZZER & SMART ALARM	E3-72
STOP LAMP	E3-76
HEATER SYSTEM	
HEATER	E3-78
FAN	E3-80
COMMUNICATION SYSTEM	
CAN	E3-82
OTHER	
EARTH TO EARTH	E3-84



POWER SOURCE

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 2	E2-6	G 77	E2-2,4	G 87	E2-4	m 1	E2-6
A 24	E2-8,16	G 80	E2-2,4	I 1	E2-2		
G 76	E2-2,4	G 86	E2-2	I 2	E2-4		

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1C	E2-8,18	BODY MAIN WIRE to J/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AG4	E2-8	BODY MAIN WIRE to ENGINE WIRE
mA1	E2-6	INSTRUMENT PANEL WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
AB	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
AC	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
IH	E2-2,4	REAR PILLAR LEFT UNDER EARTH



CHARGING

PARTS


Code	See Page	Code	See Page	Code	See Page	Code	See Page
G 1	E2-4	G 24	E2-2,4,16	G 78	E2-2,4		
G 2	E2-2	G 75	E2-2,4	G 79	E2-2,4		
G 4	E2-2,4	G 76	E2-2,4	Q 1	E2-6		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1D	E2-8,18	ENGINE WIRE to J/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AG1	E2-8	BODY MAIN WIRE to ENGINE WIRE
QA1	E2-6	INSTRUMENT PANEL WIRE to BODY MAIN WIRE



STARTING

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 41	E2-6	G 39	E2-8	I 2	E2-4	j 1	E2-6
G 23	E2-2	H 1	E2-2	J 1	E2-2	j 2	E2-6
G 27	E2-8	H 2	E2-4	J 2	E2-4		
G 32	E2-4	H 3	E2-2,4	J 3	E2-2		
G 35	E2-8	I 1	E2-2	Y 4	E2-12		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1D	E2-8,18	ENGINE WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
AG1	E2-8	BODY MAIN WIRE to ENGINE WIRE
AG2	E2-8	BODY MAIN WIRE to ENGINE WIRE
AO3	E2-8	BODY MAIN WIRE to SIDE LH WIRE
XO1	E2-12	HOOD MAIN WIRE to SIDE LH WIRE
YX2	E2-12	HOOD SUB NO.1 WIRE to HOOD MAIN WIRE
jA1	E2-6	INSTRUMENT PANEL SW WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
AB	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
AC	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
IH	E2-2,4	REAR PILLAR LEFT UNDER EARTH
JL	E2-4	FRONT PLATE LEFT INSIDE EARTH

E3-8

FUEL




FUEL

PARTS


Code	See Page	Code	See Page	Code	See Page	Code	See Page
G 31	E2-4	G 34	E2-4				


RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1D	E2-8,18	ENGINE WIRE to J/B




```
* 1:LPG TYPE,CNG TYPE
* 2:LPG TYPE
* 3:EXCEPT LPG TYPE
* 4:G TYPE
* 5:G/LP TYPE,CNG TYPE
* 6:CNG TYPE
```





ENGINE CONTROL (4Y-E)



E3-14

ENGINE CONTROL (4Y-E)

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 20	E2-6	G 6	E2-2	G 19	E2-2	G 88	E2-2
A 25	E2-8	G 8	E2-2	G 21	E2-2	K 1	E2-2
A 27	E2-8	G 9	E2-2	G 25	E2-2	K 2	E2-2
A 35	E2-8	G 10	E2-2	G 26	E2-2	K 3	E2-2
A 36	E2-8	G 11	E2-2	G 27	E2-8	K 5	E2-2
A 65	E2-8	G 12	E2-2	G 28	E2-8	K 6	E2-2
A 66	E2-8	G 13	E2-2	G 29	E2-8	O 2	E2-12
C 1	E2-14	G 16	E2-2	G 73	E2-8	Q 1	E2-6
C 3	E2-14	G 18	E2-2	G 74	E2-2	a 1	E2-6

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1D	E2-8,18	ENGINE WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE







Code	See Page	Joining Wire Harness and Wire Harness
AC2	E2-8	BODY MAIN WIRE to SIDE RH WIRE
AG1	E2-8	BODY MAIN WIRE to ENGINE WIRE
AO1	E2-8	BODY MAIN WIRE to SIDE LH WIRE
Aa1	E2-6	BODY MAIN WIRE to SUB ACCEL WIRE
GK1	E2-2	ENGINE WIRE to ENGINE SUB WIRE
GK2	E2-2	ENGINE WIRE to ENGINE SUB WIRE
QA1	E2-6	INSTRUMENT PANEL WIRE to BODY MAIN WIRE

EARTH


Code	See Page	Name
AB	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
GF	E2-2	ENGINE UPPER EARTH
GG	E2-2	ENGINE UPPER EARTH




MEMO



GLOW



GLOW



E3-18

GLOW

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 41	E2-6	G 30	E2-4	G 75	E2-2,4	G 85	E2-4
G 4	E2-2,4	G 33	E2-4	G 82	E2-4	G 87	E2-4
G 17	E2-4	G 35	E2-8	G 83	E2-4	Q 1	E2-6
G 24	E2-2,4,16	G 43	E2-8	G 84	E2-4	Y 4	E2-12

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1D	E2-8,18	ENGINE WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE







Code	See Page	Joining Wire Harness and Wire Harness
AG1	E2-8	BODY MAIN WIRE to ENGINE WIRE
AO3	E2-8	BODY MAIN WIRE to SIDE LH WIRE
QA1	E2-6	INSTRUMENT PANEL WIRE to BODY MAIN WIRE
XO1	E2-12	HOOD MAIN WIRE to SIDE LH WIRE
YX2	E2-12	HOOD SUB NO.1 WIRE to HOOD MAIN WIRE


EARTH


Code	See Page	Name
GJ	E2-4	JUNCTION BLOCK IN FRONT INSIDE EARTH
OK	E2-12	REAR PILLAR LEFT UNDER EARTH



MEMO







```

* 1:SHIELDED WIRE
* 3:UL-DS TYPE
* 4:EXCEPT UL-DS TYPE

```

E3-22

ASC

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 34	E2-8,19	G 36	E2-4	G 38	E2-8	G 43	E2-8
G 31	E2-4	G 37	E2-4	G 39	E2-8	a 1	E2-6

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1D	E2-8,18	ENGINE WIRE to J/B

WIRE TO WIRE







Code	See Page	Joining Wire Harness and Wire Harness
AG2	E2-8	BODY MAIN WIRE to ENGINE WIRE
Aa1	E2-6	BODY MAIN WIRE to SUB ACCEL WIRE

EARTH

Code	See Page	Name
AB	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
GJ	E2-4	JUNCTION BLOCK IN FRONT INSIDE EARTH




MEMO



E3-24

LPG WARNING SYSTEM (4Y-E)

* 1: LPG TYPE
* 2: G/LP TYPE



LPG WARNING SYSTEM (4Y-E)

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 36	E2-8	A 65	E2-8	G 73	E2-8	M 2	E2-2
A 37	E2-8	A 66	E2-8	G 88	E2-2	U 5	E2-10
A 38	E2-8	G 29	E2-8	M 1	E2-2		

RELAY BLOCK , JUNCTION BLOCK




Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B



WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AG1	E2-8	BODY MAIN WIRE to ENGINE WIRE
GK1	E2-2	ENGINE WIRE to ENGINE SUB WIRE
KM1	E2-2	ENGINE SUB WIRE to LPG PRESSURE SWITCH WIRE
UA2	E2-10	HEAD GUARD SW WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
AC	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
GF	E2-2	ENGINE UPPER EARTH
GG	E2-2	ENGINE UPPER EARTH





E3-28

POWER SHIFT TRANSMISSION

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 20	E2-6	A 47	E2-8	A 64	E2-8	A 76	E2-8
A 21	E2-6	A 48	E2-8	A 73	E2-8	Y 4	E2-12
A 26	E2-8	A 54	E2-8	A 74	E2-8		
A 41	E2-6	A 55	E2-8	A 75	E2-8		

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE







Code	See Page	Joining Wire Harness and Wire Harness
AO3	E2-8	BODY MAIN WIRE to SIDE LH WIRE
XO1	E2-12	HOOD MAIN WIRE to SIDE LH WIRE
YX2	E2-12	HOOD SUB NO.1 WIRE to HOOD MAIN WIRE

EARTH


Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
AD	E2-8	TRANSMISSION UPPER EARTH




MEMO



EZ PEDAL



EZ PEDAL



E3-32

EZ PEDAL

PARTS



Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 9	E2-6	A 21	E2-6	A 82	E2-8	A 84	E2-8
A 20	E2-6	A 78	E2-6	A 83	E2-8	A 85	E2-8

RELAY BLOCK , JUNCTION BLOCK







Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B





EARTH

Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH



MEMO





WET BRAKE

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 68	E2-6	A 70	E2-6	G 4	E2-2,4		
A 69	E2-6	A 71	E2-8	G 75	E2-2,4		


RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1D	E2-8,18	ENGINE WIRE to J/B


EARTH


Code	See Page	Name
AB	E2-8	FRONT PLATE LEFT OUTSIDE EARTH

SAS/OPS SYSTEM



SAS/OPS SYSTEM





SAS/OPS SYSTEM

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 3	E2-6	A 15	E2-6	A 45	E2-8	X 1	E2-12
A 6	E2-6	A 18	E2-6	A 46	E2-8	Y 1	E2-12
A 8	E2-6	A 19	E2-6	A 56	E2-6	Y 7	E2-12
A 9	E2-6	A 20	E2-6	A 86	E2-6	Y 8	E2-12
A 10	E2-6	A 21	E2-6	A 87	E2-6	Z 1	E2-12
A 11	E2-6	A 23	E2-6	D 1	E2-8	Z 3	E2-12
A 12	E2-6	A 27	E2-8	O 1	E2-12	b 1	E2-10
A 13	E2-6	A 29	E2-8,19	O 4	E2-12	k 1	E2-6
A 14	E2-6	A 42	E2-6	Q 1	E2-6		

RELAY BLOCK , JUNCTION BLOCK


Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AO1	E2-8	BODY MAIN WIRE to SIDE LH WIRE
AO3	E2-8	BODY MAIN WIRE to SIDE LH WIRE
Ab1	E2-10	BODY MAIN WIRE to MAST SENSOR WIRE
Ak1	E2-6	BODY MAIN WIRE to EZ PEDAL LIMIT SW WIRE
DA1	E2-8	T/C HEAT GAUGE WIRE to BODY MAIN WIRE
QA1	E2-6	INSTRUMENT PANEL WIRE to BODY MAIN WIRE
XO3	E2-12	HOOD MAIN WIRE to SIDE LH WIRE
XO4	E2-12	HOOD MAIN WIRE to SIDE LH WIRE
YX2	E2-12	HOOD SUB NO.1 WIRE to HOOD MAIN WIRE
ZO1	E2-12	RR LWR WIRE to SIDE LH WIRE

EARTH

Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
AB	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
OK	E2-12	REAR PILLAR LEFT UNDER EARTH



MINI LEVER

PARTS



Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 21	E2-6	A 52	E2-6	Y 3	E2-12		
A 23	E2-6	A 64	E2-8	Y 5	E2-12		
A 51	E2-6	Y 2	E2-12	Y 6	E2-12		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AO3	E2-8	BODY MAIN WIRE to SIDE LH WIRE
XO2	E2-12	HOOD MAIN WIRE to SIDE LH WIRE
XO3	E2-12	HOOD MAIN WIRE to SIDE LH WIRE
YX1	E2-12	HOOD SUB NO.1 WIRE to HOOD MAIN WIRE



DIAG

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 25	E2-8	A 31	E2-8,19	A 66	E2-8		
A 27	E2-8	A 36	E2-8	G 29	E2-8		

RELAY BLOCK , JUNCTION BLOCK


Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

EARTH

Code	See Page	Name
GG	E2-2	ENGINE UPPER EARTH
OK	E2-12	REAR PILLAR LEFT UNDER EARTH

E3-44

REAR WORKING LAMP



REAR WORKING LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
T 11	E2-14	T 12	E2-14	T 13	E2-14		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B


WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
SO1	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
SO2	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
ST1	E2-14	RR UPR MAIN WIRE to RR UPR SUB RH WIRE

EARTH

Code	See Page	Name
OK	E2-12	REAR PILLAR LEFT UNDER EARTH

COMPARTMENT LAMP



COMPARTMENT LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
T 8	E2-14	T 9	E2-14	T 10	E2-14		

RELAY BLOCK , JUNCTION BLOCK





Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
SO1	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
SO2	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
ST1	E2-14	RR UPR MAIN WIRE to RR UPR SUB RH WIRE
dA2	E2-10	FR STAY WIRE LH to BODY MAIN WIRE

EARTH

Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH



STROBE LIGHT

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
S 17	E2-12	S 18	E2-12	S 19	E2-12	S 20	E2-12

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B


WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
AO1	E2-8	BODY MAIN WIRE to SIDE LH WIRE
SO1	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
SO2	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
dA2	E2-10	FR STAY WIRE LH to BODY MAIN WIRE

EARTH

Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH

COMBINATION METER





E3-52

COMBINATION METER

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 7	E2-6	A 81	E2-8	G 4	E2-2,4	G 75	E2-2,4
A 9	E2-6	C 4	E2-14	G 14	E2-2	O 2	E2-12
A 20	E2-6	C 5	E2-14	G 22	E2-2,4	O 3	E2-12
A 36	E2-8	C 6	E2-14	G 35	E2-8	Q 1	E2-6

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1D	E2-8,18	ENGINE WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE







Code	See Page	Joining Wire Harness and Wire Harness
AC2	E2-8	BODY MAIN WIRE to SIDE RH WIRE
AC4	E2-8	BODY MAIN WIRE to SIDE RH WIRE
AG1	E2-8	BODY MAIN WIRE to ENGINE WIRE
AO1	E2-8	BODY MAIN WIRE to SIDE LH WIRE
QA1	E2-6	INSTRUMENT PANEL WIRE to BODY MAIN WIRE





EARTH

Code	See Page	Name
AB	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
OK	E2-12	REAR PILLAR LEFT UNDER EARTH



MEMO





MULTI DISPLAY

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 27	E2-8	A 33	E2-8,19	Q 2	E2-6		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AQ1	E2-6	BODY MAIN WIRE to INSTRUMENT PANEL WIRE

EARTH

Code	See Page	Name
OK	E2-12	REAR PILLAR LEFT UNDER EARTH

FRONT WIPER & WASHER

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
B 1	E2-14	U 2	E2-10	h 1	E2-6	h 2	E2-6

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B


WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
Ah1	E2-6	BODY MAIN WIRE to WIPER SUB WIRE
BA1	E2-10	BODY SUB NO.1 WIRE to BODY MAIN WIRE
UA1	E2-10	HEAD GUARD SW WIRE to BODY MAIN WIRE
UB1	E2-10	HEAD GUARD SW WIRE to BODY SUB NO.1 WIRE
hA1	E2-6	WIPER SUB WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
AC	E2-8	FRONT PLATE LEFT OUTSIDE EARTH

REAR WIPER & WASHER



REAR WIPER & WASHER

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
B 6	E2-14	S 2	E2-12	S 8	E2-12	U 3	E2-10

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
AO2	E2-8	BODY MAIN WIRE to SIDE LH WIRE
BA1	E2-10	BODY SUB NO.1 WIRE to BODY MAIN WIRE
SO2	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
SO3	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
UA2	E2-10	HEAD GUARD SW WIRE to BODY MAIN WIRE
UB1	E2-10	HEAD GUARD SW WIRE to BODY SUB NO.1 WIRE

EARTH

Code	See Page	Name
AC	E2-8	FRONT PLATE LEFT OUTSIDE EARTH

E3-60

HORN & W/ REAR HORN SWITCH



HORN & W/ REAR HORN SWITCH

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 1	E2-6	S 11	E2-12	j 2	E2-6		
A 49	E2-6	j 1	E2-6				

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B


WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
SO1	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
jA1	E2-6	INSTRUMENT PANEL SW WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
AC	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
OK	E2-12	REAR PILLAR LEFT UNDER EARTH

CNG DIGITAL METER



CNG DIGITAL METER

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
G 4	E2-2,4	g 1	E2-2	i 2	E2-6	i 4	E2-6
Q 1	E2-6	i 1	E2-6	i 3	E2-6		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1D	E2-8,18	ENGINE WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
AG1	E2-8	BODY MAIN WIRE to ENGINE WIRE
Ai1	E2-6	BODY MAIN WIRE to DIGITAL METER WIRE
GK2	E2-2	ENGINE WIRE to ENGINE SUB WIRE
Kg1	E2-2	ENGINE SUB WIRE TO CNG PRESSURE SENSOR WIRE
QA1	E2-6	INSTRUMENT PANEL WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
OK	E2-12	REAR PILLAR LEFT UNDER EARTH

E3-64

HEAD LAMP



HEAD LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 4	E2-6	R 6	E2-10	d 6	E2-10		

RELAY BLOCK , JUNCTION BLOCK





Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
RA2	E2-10	FR STAY WIRE RH to BODY MAIN WIRE
dA2	E2-10	FR STAY WIRE LH to BODY MAIN WIRE

EARTH

Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH





E3-68

TURN SIGNAL LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 4	E2-6	S 4	E2-12	S 22	E2-12		
R 1	E2-10	S 13	E2-12	S 23	E2-12		
S 3	E2-12	S 14	E2-12	d 1	E2-10		

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE







Code	See Page	Joining Wire Harness and Wire Harness
RA2	E2-10	FR STAY WIRE RH to BODY MAIN WIRE
SO1	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
dA2	E2-10	FR STAY WIRE LH to BODY MAIN WIRE

EARTH


Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
AB	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
AC	E2-8	FRONT PLATE LEFT OUTSIDE EARTH



MEMO



CLEARANCE LAMP



CLEARANCE LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 4	E2-6	S 3	E2-12	S 13	E2-12	d 1	E2-10
R 1	E2-10	S 4	E2-12	S 14	E2-12		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
RA2	E2-10	FR STAY WIRE RH to BODY MAIN WIRE
SO1	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
dA2	E2-10	FR STAY WIRE LH to BODY MAIN WIRE

EARTH

Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH

E3-72

BACK UP LAMP BUZZER & SMART ALARM





E3-74

BACK UP LAMP BUZZER & SMART ALARM

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 9	E2-6	A 80	E2-6	S 4	E2-12	S 15	E2-12
A 41	E2-6	A 81	E2-8	S 13	E2-12	S 16	E2-12
A 79	E2-8	C 7	E2-14	S 14	E2-12	Y 4	E2-12

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE







Code	See Page	Joining Wire Harness and Wire Harness
AC2	E2-8	BODY MAIN WIRE to SIDE RH WIRE
AC4	E2-8	BODY MAIN WIRE to SIDE RH WIRE
SO1	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
XO1	E2-12	HOOD MAIN WIRE to SIDE LH WIRE
YX2	E2-12	HOOD SUB NO.1 WIRE to HOOD MAIN WIRE
dA2	E2-10	FR STAY WIRE LH to BODY MAIN WIRE





EARTH

Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
AB	E2-8	FRONT PLATE LEFT OUTSIDE EARTH



MEMO





STOP LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 6	E2-6	S 4	E2-12	S 14	E2-12		
S 3	E2-12	S 13	E2-12	S 21	E2-12		

RELAY BLOCK , JUNCTION BLOCK


Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1B	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
SO1	E2-12	RR UPR MAIN WIRE to SIDE LH WIRE
dA2	E2-10	FR STAY WIRE LH to BODY MAIN WIRE

EARTH

Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH



HEATER

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
B 3	E2-14	B 5	E2-14	U 1	E2-10		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B
1A	E2-8,18	BODY MAIN WIRE to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
BA1	E2-10	BODY SUB NO.1 WIRE to BODY MAIN WIRE
UB1	E2-10	HEAD GUARD SW WIRE to BODY SUB NO.1 WIRE

EARTH

Code	See Page	Name
AC	E2-8	FRONT PLATE LEFT OUTSIDE EARTH

E3-80

FAN



FAN

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
U 6	E2-10	U 7	E2-10	U 8	E2-10		

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-8,17	ENGINE ROOM R/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
UA2	E2-10	HEAD GUARD SW WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH



CAN

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 20	E2-6	A 29	E2-8,19	A 33	E2-8,19	G 39	E2-8
A 25	E2-8	A 31	E2-8,19	A 34	E2-8,19	Q 2	E2-6
A 27	E2-8	A 32	E2-8,19	A 36	E2-8		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1C	E2-8,18	BODY MAIN WIRE to J/B
1E	E2-8,18	SIDE LH WIRE to J/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
AG2	E2-8	BODY MAIN WIRE to ENGINE WIRE
AQ1	E2-6	BODY MAIN WIRE to INSTRUMENT PANEL WIRE

EARTH

Code	See Page	Name
OK	E2-12	REAR PILLAR LEFT UNDER EARTH

E3-84

EARTH TO EARTH






EARTH TO EARTH

WIRE TO WIRE






Code	See Page	Joining Wire Harness and Wire Harness
AO1	E2-8	BODY MAIN WIRE to SIDE LH WIRE

EARTH

Code	See Page	Name
AA	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
AB	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
AC	E2-8	FRONT PLATE LEFT OUTSIDE EARTH
AD	E2-8	TRANSMISSION UPPER EARTH
GF	E2-2	ENGINE UPPER EARTH
GG	E2-2	ENGINE UPPER EARTH
GJ	E2-4	JUNCTION BLOCK IN FRONT INSIDE EARTH
GL	E2-4	JUNCTION BLOCK IN FRONT INSIDE EARTH
OK	E2-12	REAR PILLAR LEFT UNDER EARTH



MEMO



CHAPTER 4 GROUND POINTS

E4

E4-2

GROUND POINTS

CODE	LOCATION	SYSTEM NAME	PAGE
AA	FRONT PLATE LEFT OUTSIDE EARTH	BACK UP LAMP BUZZER & SMART ALARM	E3-72
		CLEARANCE LAMP	E3-70
		COMPARTMENT LAMP	E3-46
		EZ PEDAL	E3-30
		FAN	E3-80
		HEAD LAMP	E3-64
		POWER SHIFT TRANSMISSIN	E3-26
		SAS/OPS SYSTEM	E3-36
		STOP LAMP	E3-76
		STROBE LIGHT	E3-48
		TURN SIGNAL LAMP	E3-66
AB	FRONT PLATE LEFT OUTSIDE EARTH	ASC	E3-20
		BACK UP LAMP BUZZER & SMART ALARM	E3-72
		COMBINATION METER	E3-50
		ENGINE CONTROL (4Y-E)	E3-10
		POWER SOURCE	E3-2
		SAS/OPS SYSTEM	E3-36
		STARTING	E3-6
		TURN SIGNAL LAMP	E3-66
AC	FRONT PLATE LEFT OUTSIDE EARTH	WET BRAKE	E3-34
		FRONT WIPER & WASHER	E3-56
		HEATER	E3-78
		HORN & W/ REAR HORN SWITCH	E3-60
		LPG WARNING SYSTEM (4Y-E)	E3-24
		POWER SOURCE	E3-2
		REAR WIPER & WASHER	E3-58
		STARTING	E3-6
AD	TRANSMISSIN UPPER EARTH	TURN SIGNAL LAMP	E3-66
		POWER SHIFT TRANSMISSIN	E3-26
GF	ENGINE UPPER EARTH	ENGINE CONTROL (4Y-E)	E3-10
		LPG WARNING SYSTEM (4Y-E)	E3-24
GG	ENGINE UPPER EARTH	DIAG	E3-42
		ENGINE CONTROL (4Y-E)	E3-10
		LPG WARNING SYSTEM (4Y-E)	E3-24
GJ	JUNCTION BLOCK IN FRONT INSIDE EARTH	ASC	E3-20
		GLOW	E3-16
IH	REAR PILLAR LEFT UNDER EARTH	POWER SOURCE	E3-2
		STARTING	E3-6
JL	FRONT PLATE LEFT INSIDE EARTH	STARTING	E3-6
OK	REAR PILLAR LEFT UNDER EARTH	CAN	E3-82
		CNG DIGITAL METER	E3-62
		COMBINATION METER	E3-50
		DIAG	E3-42
		GLOW	E3-16
		HORN & W/ REAR HORN SWITCH	E3-60
		MULTI DISPLAY	E3-54
		REAR WORKING LAMP	E3-44
		SAS/OPS SYSTEM	E3-36

CHAPTER 5 FUSES FOR POWER SUPPLY

E5

FUSES FOR POWER SUPPLY

FUSIBLE LINK BLOCK ASSY

FUSE		SYSTEM NAME	PAGE
60A	GLOW	GLOW	E3-16
100A	ALT	CHARGING	E3-4

FUSIBLE LINK BLOCK-1

FUSE		SYSTEM NAME	PAGE
100A	ALT	CHARGING	E3-4

FUSIBLE LINK BLOCK-2




FUSE		SYSTEM NAME	PAGE
60A	GLOW	GLOW	E3-16

ENGINE ROOM R/B






FUSE		SYSTEM NAME	PAGE
7.5A	ALT-S	CHARGING	E3-4
7.5A	ECU-B	SAS/OPS SYSTEM	E3-36
7.5A	ECU-B2	ASC	E3-20
7.5A	HORN	HORN & W/ REAR HORN SWITCH	E3-60
7.5A	HOURL MET	COMBINATION METER	E3-50
7.5A	IGN	ASC	E3-20
		FUEL	E3-8
		GLOW	E3-16
7.5A	SFT	BACK UP LAMP BUZZER & SMART ALARM	E3-72
		EZ PEDAL	E3-30
		POWER SHIFT TRANSMISSIN	E3-26
7.5A	ST	EZ PEDAL	E3-30
		GLOW	E3-16
		STARTING	E3-6
7.5A	STOP	SAS/OPS SYSTEM	E3-36
		STOP LAMP	E3-76
7.5A	TAIL	CLEARANCE LAMP	E3-70
7.5A	TURN	TURN SIGNAL LAMP	E3-66
10A	BACK LP	BACK UP LAMP BUZZER & SMART ALARM	E3-72
		STROBE LIGHT	E3-48
10A	BLR	FAN	E3-80
10A	ECU-IG	DIAG	E3-42
		MINI LEVER	E3-40
		MULTI DISPLAY	E3-54
		POWER SHIFT TRANSMISSIN	E3-26
		SAS/OPS SYSTEM	E3-36

FUSES FOR POWER SUPPLY

FUSE		SYSTEM NAME	PAGE
10A	GAUGE	BACK UP LAMP BUZZER & SMART ALARM	E3-72
		CHARGING	E3-4
		CLEARANCE LAMP	E3-70
		CNG DIGITAL METER	E3-62
		COMBINATION METER	E3-50
		COMPARTMENT LAMP	E3-46
		ENGINE CONTROL (4Y-E)	E3-10
		FRONT WIPER & WASHER	E3-56
		GLOW	E3-16
		HEAD LAMP	E3-64
		HEATER	E3-78
		REAR WIPER & WASHER	E3-58
		SAS/OPS SYSTEM	E3-36
		STOP LAMP	E3-76
		STROBE LIGHT	E3-48
		TURN SIGNAL LAMP	E3-66
		WET BRAKE	E3-34
15A	EFI	ENGINE CONTROL (4Y-E)	E3-10
		LPG WARNING SYSTEM (4Y-E)	E3-24
15A	E-THRO	ENGINE CONTROL (4Y-E)	E3-10
15A	HEAD	HEAD LAMP	E3-64
15A	HTR	HEATER	E3-78
15A	IGN	ENGINE CONTROL (4Y-E)	E3-10
15A	WORK LP	COMPARTMENT LAMP	E3-46
		REAR WORKING LAMP	E3-44
20A	FR WIP	FRONT WIPER & WASHER	E3-56
20A	RR WIP	REAR WIPER & WASHER	E3-58
30A	STA	STARTING	E3-6



MEMO

















CHAPTER 6 CONNECTOR LIST














CONNECTOR LIST
PARTS CONNECTOR E6-2

WIRE TO WIRE
WIRE TO WIRE E6-8

CONNECTOR LIST

A 1  90980-10935	A 2  90980-10171	A 3  90980-10996	A 4  90980-10807	A 6  90980-11155	A 7  90980-10214	
A 8 DARK GRAY  90980-10899	A 9 GRAY  90980-11349	A 10 GRAY  90980-11486	A 11  90980-11002	A 12 BLACK  90980-10959	A 13 BLACK  90980-10941	A 14 DARK GRAY  90980-11028
A 15 DARK GRAY  90980-10900	A 18 GRAY  90080-98200	A 19 BLACK  90980-11156	A 20  90980-12528			
A 21  90980-12529			A 23  90980-12556			A 24 BLACK  90980-11881
A 25 GRAY  57671-U2230-71	A 26  90980-11251	A 27 GRAY  90980-11542	A 29 BLUE  90980-12355	A 31 BROWN  90980-12355	A 32  90980-10871	
A 33  90980-12355	A 34 BLACK  90980-12355	A 35  90980-12529		A 36  90980-12525		
A 37  90980-10173	A 38  90980-10214	A 41 		A 42 BLACK  90980-10845	A 45 DARK GRAY  90980-11162	A 46 DARK GRAY  90980-11168

CONNECTOR LIST

A 47 DARK GRAY  90980-10942	A 48 DARK GRAY  90980-10941	A 49 BLACK  90980-11235	A 51 GRAY  90980-10896	A 52  90980-10890	A 54 GRAY  90980-10899	
A 55 GRAY  90980-10899	A 56  90980-11168	A 64  90980-11915	A 65 BLACK  90980-11661	A 66 BLUE  90980-11661		
A 68  90980-11003	A 69 BLACK  90980-11162	A 70 GRAY  90980-11162	A 71  90980-11251	A 73  90980-10942	A 74  90980-10941	A 75  90980-10942
A 76  90980-10941	A 78  90980-11020	A 79 GRAY  90980-11071	A 80  90980-10355	A 81 GRAY  90980-11071	A 82  90980-10173	
A 83  90980-10173	A 84  90980-10173	A 85  90980-10173	A 86  90980-10887	A 87  90980-10886	B 1  90980-10214	B 3  180900
B 5 GRAY  82660-53010	B 6  90980-10214	C 1 DARK GRAY  90980-10869	C 3 BLACK  90980-10622	C 4  7316-2095	C 5  7316-2095	C 6  90980-11140
C 7  90980-10825	D 1 GRAY  90980-11025	G 1  90980-09213	G 2  90980-09567	G 4 BLACK  90980-11349	G 6 BLACK  90980-11858	
G 8 DARK GRAY  90980-11153	G 9 GREEN  90980-11153	G 10 DARK GRAY  90980-11153	G 11 GREEN  90980-11153	G 12  90980-10845	G 13 BLACK  90980-11144	

E6-4


CONNECTOR LIST


G 14
(1DZ)

90980-10786

G 14
GRAY (4Y-E)

90980-10786

G 16
GREEN

90980-11062

G 17
GREEN

90980-10109

G 18
BLACK

90980-10947

G 19
GRAY

90980-11286

G 21
DARK GRAY

90980-11038

G 22
BLACK

90980-10703

G 23
BLACK

90980-10179

G 24
BLACK


90980-11996


G 25
BLACK

90980-11024

G 26

99144-12239

G 27

90980-12528


G 28

90980-12527

G 29
BLUE

90980-11661


G 30

7010-3025-02

G 31

90980-10690


G 32
BLACK

90980-10165

G 33
GRAY

7254-1548-40


G 34


90980-10179


G 35

90980-10043


G 36


90980-10476


G 37
DARK GRAY

90980-11194

G 38

90980-11391

G 39

90980-11390


G 43
GRAY

90980-11542

G 73
BLACK

90980-11661

G 74
BLACK

90980-10108

G 75
BLACK

90980-10341

G 76
BLACK

57630-16640-71

G 77

99141-13010

G 78

99141-11006

G 79

99141-11006

G 80

99141-13010

G 82

99141-14005

G 83

99141-13005














G 84

99141-14005

G 85









99141-14005

CONNECTOR LIST

G 86 (1 D Z)  99141- 12008	G 86 (4 Y - E)  99142- 16080	G 87 BLACK  57630- 16650- 71	G 88  90980- 11016	H 1  99142- 16080	H 2  7003- 1191- 02	H 3  90980- 09222	
I 1  99142- 15080	I 2  99142- 16080	J 1  7003- 1172- 02	J 2  7003- 1182- 02	J 3  90980- 09481	K 1 DARK GRAY  90980- 11162	K 2 DARK GRAY  90980- 10626	K 3 BLACK  90980- 11235
K 5 DARK GRAY  90980- 11156	K 6 DARK GRAY  90980- 10626	M 1  7010- 3015	M 2  7010- 3015	O 1  90980- 11016	O 2 GRAY  90980- 11077	O 3 GRAY  90980- 10256	
O 4 BLACK  90980- 11070	Q 1  90980- 12553	Q 2 GREEN  IL- AG5- 7S- S3C1	R 1 BLACK  90980- 11349	R 6  90980- 10860			
S 2  90980- 11742	S 3  90980- 10795	S 4  90980- 11011	S 8 BLACK  82660- 20340	S 11 DARK GRAY  90980- 11155	S 13 GRAY  90980- 11034		
S 14 GRAY  90980- 11034	S 15  99144- 12239	S 16  99143- 22040	S 17  99144- 12239	S 18  99143- 22040	S 19  99144- 12239	S 20  99143- 22040	
S 21 BLACK  90980- 11162	S 22 GRAY  90980- 11162	S 23 BLUE  90980- 10716	T 8  90980- 10214	T 9  CUT OFF	T 10  CUT OFF		
T 11 DARK GRAY  90980- 10860	T 12  CUT OFF	T 13  CUT OFF	U 1 BLACK  90980- 10795	U 2 BLACK  90980- 10797	U 3 BLACK  90980- 10799		


E6-6

CONNECTOR LIST

U 5 BLUE  90980-10799	U 6 BLUE  90980-10795	U 7  99144-12239	U 8  99141-11005	X 1  90980-11142	Y 1  90980-11245	Y 2 BLACK  90980-11885
Y 3 BLACK  90980-11885	Y 4  90980-11594	Y 5 BLACK  90980-11885	Y 6 BLACK  90980-11885	Y 7  90980-11245		
Y 8 BLACK  90980-10887	Z 1 BLACK  90980-11255	Z 3 BLACK  90980-10845	a 1 BLACK  90980-11858	b 1 GRAY  90980-11607	d 1 BLACK  90980-11349	
d 6  90980-10860	g 1 BLACK  282087-1	h 1 BLACK  82660-20340	h 2  90980-11742	i 1  480509-FA	i 2  480509-FA	i 3  480509-FA
i 4  480509-FA	j 1  99141-11004	j 2  99141-11004	k 1  90980-10887	m 1 GRAY  90980-11162		


CONNECTOR LIST

1A




90980- 12506

1B




90980- 12383

1C




90980- 12320

1D



90980- 12308


1E




90980- 12311

E6-8

WIRE TO WIRE




WIRE TO WIRE




E6-10

WIRE TO WIRE



WIRE TO WIRE



.....This Page Intentionally Left Blank.....

CHAPTER 8 ELECTRICAL WIRING ROUTINGS AND RELAY LOCATIONS

E8

ELECTRICAL WIRING ROUTINGS

ENGINE ROOM E8-2

INSTRUMENT PANEL E8-4

FRONT BODY E8-6

MAST AREA E8-8

REAR BODY E8-10


RELAY LOCATIONS

RELAY BLOCK (R/B) E8-12

SYMBOLS	WIRE NAME	SYMBOLS	WIRE NAME
A	BODY MAIN WIRE	K	SIDE LH WIRE
B	SIDE RH WIRE	L	INSTRUMENT PANEL WIRE
C	T/C HEAT GAUGE WIRE	M	FR STAY WIRE RH
D	FLASHER WIRE	N	FR STAY WIRE LH
E	ENGINE WIRE	O	RR UPR MAIN WIRE
F	BATTERY STARTER WIRE	P	RR UPR SUB RH WIRE
G	BATTERY EARTH WIRE	Q	HEAD GUARD SW WIRE
H	ENGINE EARTH WIRE	R	HOOD MAIN WIRE
I	ENGINE SUB WIRE	S	MAST SENSOR WIRE
J	LPG PRESSURE SWITCH WIRE		

ELECTRICAL WIRING ROUTINGS

ENGINE ROOM(4Y-E)




ELECTRICAL WIRING ROUTINGS

E1	THROTTLE POSITION SENSOR(WITH MOTOR)	IE1	ENGINE SUB WIRE to ENGINE WIRE
E2	LPG INJECTOR	IE2	
E3	INJECTOR NO.3	IJ1	ENGINE SUB WIRE to LPG PRESSURE SWITCH WIRE
E4	INJECTOR NO.4		
E5	VACUUM SENSOR		
E6	INJECTOR NO.2	EC	ENGINE UPPER EARTH
E7	FCM STEP MOTOR	ED	ENGINE UPPER EARTH
E8	INJECTOR NO.1	GE	REAR PILLAR LEFT UNDER EARTH
E9	ALTERNATOR	HF	BODY EARTH
E10	ALTERNATOR		
E11	WATER TEMPERATURE SENDER		
E12	WATER TEMPERATURE SENSOR		
E13	G2 SENSOR		
E14	DISTRIBUTOR		
E15	IGNITION COIL		
E16	OIL PRESSURE SWITCH		
E17	STARTER		
E18	TACHO CHECK		
E30	ALTERNATOR		
F1	STARTER		
F2	BATTERY		
G1	BATTERY		
H1	STARTER		
I1	LPG SOLENOID(SLOW)		
I2	LPG SOLENOID(MAIN)		
I3	LPG RESISTOR		
I4	LPG WARNING BUZZER		
I5	LPG WARNING RELAY		
J1	LPG PRESSURE SWITCH(+)		
J2	LPG PRESSURE SWITCH(-)		

INSTRUMENT PANEL

- | | | |
|--------------------------------|-----------------------------|---------------------------|
| A BODY MAIN WIRE | M FR STAY WIRE RH | S MAST SENSOR WIRE |
| D FLASHER WIRE | N FR STAY WIRE LH | |
| L INSTRUMENT PANEL WIRE | Q HEAD GUARD SW WIRE | |




ELECTRICAL WIRING ROUTINGS

- A1 HORN SWITCH
- A2 IGNITION SWITCH
- A3 LIGHT CONTROL SWITCH
- A4 STOP LAMP SWITCH
- A5 PARKING BRAKE SWITCH
- A6 PRESSURE SENSOR
- A7 TILT SOLENOID
- A8 LIFT SOLENOID
- A9 UNLOAD SOLENOID
- A10 TILT SWITCH
- A11 LIFT SWITCH
- A12 NEUTRAL TILT SWITCH
- A13 HORN
- A14 SPEED SENSOR
- A15 SAS/OPS ECU
- A16 SAS/OPS ECU
- A17 JUNCTION CONNECTOR(A)
- A18 LEFT T/C SHIFT SWITCH
- A19 TILT ANGLE SENSOR
- A20 SHIFT SOLENOID
- A22 DIODE
- A23 BACK TILT SOLENOID
- A24 BRAKE WARNING SWITCH
- A27 OPS WARNING BUZZER
- A28 JUNCTION CONNECTOR(B)
- A29 JUNCTION CONNECTOR(B)
- A30 FRONT SOLENOID RELAY
- A31 REAR SOLENOID RELAY
- A32 EZ MAIN RELAY
- A33 BACK LAMP RELAY
- A34 EZ PEDAL DIRECTION SWITCH
- D1 FLASHER RELAY
- L1 COMBINATION METER
- L2 DISPLAY
- L3 12V POWER SUPPLY

- AL1 BODY MAIN WIRE to INSTRUMENT PANEL WIRE
- DA1 FLASHER WIRE to BODY MAIN WIRE
- LA1 INSTRUMENT PANEL WIRE to BODY MAIN WIRE
- LA2

FRONT BODY



ELECTRICAL WIRING ROUTINGS


A25	MATCHING CONNECTOR
A26	MATCHING CONNECTOR
B1	O2 SENSOR
B2	IN AIR SENSOR
B3	AIR CLEANER WARNING SWITCH(+)
B4	AIR CLEANER WARNING SWITCH(-)
B5	BACK UP BUZZER
C1	T/C OIL TEMPERATURE SENSOR
E20	ENGINE ECU
E21	ENGINE ECU
E22	LPG CHANGE SWITCH
E23	ACCEL SENSOR
E24	DIAGNOSIS
E25	FUSIBLE LINK BLOCK
E26	ENGINE ECU
E27	ENGINE ECU
E28	JUNCTION CONNECTOR(C)
E29	JUNCTION CONNECTOR(C)
E32	DISCONNECT SWITCH(BATT)
E33	DISCONNECT SWITCH(BATT)
E34	DISCONNECT SWITCH(ALT)
E35	DISCONNECT SWITCH(ALT)

AE1	BODY MAIN WIRE to ENGINE WIRE
AK1	BODY MAIN WIRE to SIDE LH WIRE
AK2	
CA1	T/C HEAT GAUGE WIRE to BODY MAIN WIRE
EA1	ENGINE WIRE to BODY MAIN WIRE
EB1	ENGINE WIRE to SIDE RH WIRE
EK1	ENGINE WIRE to SIDE LH WIRE

AA	FRONT PLATE LEFT OUTSIDE EARTH
AB	FRONT PLATE LEFT OUTSIDE EARTH

ELECTRICAL WIRING ROUTINGS


MAST AREA



ELECTRICAL WIRING ROUTINGS

- M1 HEAD LAMP RIGHT
 - M2 FRONT COMBINATION LAMP RIGHT
 - N1 HEAD LAMP LEFT
 - N2 FRONT COMBINATION LAMP LEFT
 - Q1 LPG WARNING SWITCH
 - S1 MAST SWITCH
-
- AQ1 BODY MAIN WIRE to HEAD GUARD SW WIRE
 - AS1 BODY MAIN WIRE to MAST SENSOR WIRE
 - MA1 FR STAY WIRE RH to BODY MAIN WIRE
 - NA1 FR STAY WIRE LH to BODY MAIN WIRE

REAR BODY



ELECTRICAL WIRING ROUTINGS

- K1 SWING LOCK SOLENOID
- K2 YAW RATE SENSOR
- K3 FUEL SENDER GAUGE & FUEL PUMP
- K4 RADIATOR WARNING SWITCH
- K5 IGNITER
- O1 REAR COMBINATION LAMP LEFT
- O2 REAR COMBINATION LAMP RIGHT
- O3 BEACON LAMP(+)
- O4 BEACON LAMP(-)
- O5 SMART ALARM(+)
- O6 SMART ALARM(-)
- O7 REAR HORN SWITCH
- O8 LED REAR COMBINATION LAMP LEFT
- O9 RESISTOR(STOP LAMP)
- O10 RESISTOR(TURN LAMP)
- O11 LED REAR COMBINATION LAMP RIGHT
- O12 DIODE(LED REAR COMBINATION)
- P1 COMPARTMENT LAMP
- P2 COMPARTMENT LAMP SWITCH(+)
- P3 COMPARTMENT LAMP SWITCH(-)
- P4 WORK LAMP
- P5 WORK LAMP SWICH(+)
- P6 WORK LAMP SWICH(-)
- R1 SEAT SWITCH


- OK1 RR UPR MAIN WIRE to SIDE LH WIRE
- OK2
- OP1 RR UPR MAIN WIRE to RR UPR SUB RH WIRE
- OP2
- RK1 HOOD MAIN WIRE to SIDE LH WIRE

- KG RR PILLAR LEFT UNDER EARTH

E8-12


RELAY LOCATIONS

FUSIBLE LINK BLOCK ASSY : ENGINE ROOM LEFT



RELAY LOCATONS


① ENGINE ROOM R/B : ENGINE ROOM LEFT



E8-14


RELAY LOCATIONS


② T/C R/B : INSTRUMENT PANEL RIGHT



RELAY LOCATIONS





JUNCTION CONNECTOR





E8-16


MEMO



CHAPTER 9 SYSTEM CIRCUITS

E9

POWER SOURCE	
POWER SOURCE	E9-2
CHARGING	E9-4
STARTING	E9-6
ENGINE	
ENGINE CONTROL	E9-8
LPG WARNING SYSTEM	E9-14
CHASSIS	
EZ PEDAL	E9-16
POWER SHIFT TRANSMISSION	E9-20
BODY	
SAS/OPS SYSTEM	E9-22
DIAG	E9-26
REAR WORKING LAMP	E9-28
COMPARTMENT LIGHT	E9-30
STROBE LIGHT	E9-32
INSTRUMENT PANEL	
COMBINATION METER	E9-34
MULTI DISPLAY	E9-38
HORN & W/ REAR HORN SWITCH	E9-40
LIGHTING SYSTEM	
HEAD LAMP	E9-42
TURN SIGNAL LAMP	E9-44
CLEARANCE LAMP	E9-46
BACK UP LAMP BUZZER & SMART ALARM	E9-48
STOP LAMP	E9-50
COMMUNICATION SYSTEM	
CAN	E9-52
OTHER	
EARTH TO EARTH	E9-54



POWER SOURCE

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 2	E8-4	E 32	E8-6	G 1	E8-2		
E 25	E8-6,12	E 33	E8-6	L 3	E8-4		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
EA1	E8-6	ENGINE WIRE to BODY MAIN WIRE
LA2	E8-4	INSTRUMENT PANEL WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
GE	E8-2	REAR PILLER LEFT UNDER EARTH

CHARGING

* 1:EXCEPT LPS TYPE
* 2:LPS TYPE



CHARGING

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
E 9	E8-2	E 25	E8-6,12	E 34	E8-6	L 1	E8-4
E 10	E8-2	E 30	E8-2	E 35	E8-6		


RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
LA1	E8-4	INSTRUMENT PANEL WIRE to BODY MAIN WIRE

STARTING



STARTING

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 5	E8-4	E 27	E8-6	F 1	E8-2	H 1	E8-2
A 18	E8-4	E 28	E8-6	F 2	E8-2		
E 17	E8-2	E 29	E8-6	G 1	E8-2		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E2-13	ENGINE ROOM R/B


WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE


EARTH

Code	See Page	Name
AA	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
AB	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
EC	E8-2	ENGINE UPPER EARTH
GE	E8-2	REAR PILLER LEFT UNDER EARTH
HF	E8-2	BODY EARTH


ENGINE CONTROL




ENGINE CONTROL



ENGINE CONTROL



ENGINE CONTROL



E9-12

ENGINE CONTROL

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 15	E8-4	E 5	E8-2	E 18	E8-2	E 28	E8-6
A 17	E8-4	E 6	E8-2	E 20	E8-6	E 29	E8-6
B 1	E8-6	E 7	E8-2	E 21	E8-6	I 1	E8-2
B 2	E8-6	E 8	E8-2	E 22	E8-6	I 2	E8-2
E 1	E8-2	E 12	E8-2	E 23	E8-6	I 3	E8-2
E 2	E8-2	E 13	E8-2	E 24	E8-6	K 3	E8-10
E 3	E8-2	E 14	E8-2	E 26	E8-6	K 5	E8-10
E 4	E8-2	E 15	E8-2	E 27	E8-6	L 1	E8-4

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE







Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
EA1	E8-6	ENGINE WIRE to BODY MAIN WIRE
EB1	E8-6	ENGINE WIRE to SIDE RH WIRE
EK1	E8-6	ENGINE WIRE to SIDE LH WIRE
IE1	E8-2	ENGINE SUB WIRE to ENGINE WIRE
IE2	E8-2	ENGINE SUB WIRE to ENGINE WIRE
LA1	E8-4	INSTRUMENT PANEL WIRE to BODY MAIN WIRE

EARTH


Code	See Page	Name
EC	E8-2	ENGINE UPPER EARTH
ED	E8-2	ENGINE UPPER EARTH
KG	E8-10	REAR PILLER LEFT UNDER EARTH



MEMO



LPG WARNING SYSTEM



LPG WARNING SYSTEM

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
E 21	E8-6	I 4	E8-2	J 1	E8-2	Q 1	E8-8
E 22	E8-6	I 5	E8-2	J 2	E8-2		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B


WIRE TO WIRE




Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
AQ1	E8-8	BODY MAIN WIRE to HEAD GUARD SW WIRE
EA1	E8-6	ENGINE WIRE to BODY MAIN WIRE
IE1	E8-2	ENGINE SUB WIRE to ENGINE WIRE
IE2	E8-2	ENGINE SUB WIRE to ENGINE WIRE
IJ1	E8-2	ENGINE SUB WIRE to LPG PRESSURE WIRE

EARTH

Code	See Page	Name
AB	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
EC	E8-2	ENGINE UPPER EARTH
ED	E8-2	ENGINE UPPER EARTH

EZ PEDAL





E9-18

EZ PEDAL

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 5	E8-4	A 28	E8-4	A 33	E8-4	O 5	E8-10
A 15	E8-4	A 29	E8-4	A 34	E8-4	O 6	E8-10
A 16	E8-4	A 30	E8-4	B 5	E8-6	O 8	E8-10
A 20	E8-4	A 31	E8-4	E 28	E8-6	O 11	E8-10
A 22	E8-4	A 32	E8-4	O 2	E8-10		

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B
2	E8-14	T/C R/B

WIRE TO WIRE







Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
AK1	E8-6	BODY MAIN WIRE to SIDE LH WIRE
EB1	E8-6	ENGINE WIRE to SIDE RH WIRE
OK1	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE
OK2	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE

EARTH


Code	See Page	Name
AA	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
AB	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
EC	E8-2	ENGINE UPPER EARTH
KG	E8-10	REAR PILLER LEFT UNDER EARTH



MEMO



POWER SHIFT TRANSMISSION



POWER SHIFT TRANSMISSION

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 15	E8-4	A 18	E8-4	A 22	E8-4	A 29	E8-4
A 16	E8-4	A 20	E8-4	A 28	E8-4		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B
2	E8-14	T/C R/B


WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE

EARTH


Code	See Page	Name
AA	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
AB	E8-6	FRONT PLATE LEFT OUTSIDE EARTH


SAS/OPS SYSTEM



SAS/OPS SYSTEM

* 1:W/ EZ PEDAL
* 3:EXCEPT STANDARD
* 4:W/ MULTIDISPLAY
* 5:TWISTED WIRE





SAS/OPS SYSTEM

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 4	E8-4	A 11	E8-4	A 23	E8-4	K 1	E8-10
A 5	E8-4	A 12	E8-4	A 25	E8-6	K 2	E8-10
A 6	E8-4	A 14	E8-4	A 26	E8-6	L 1	E8-4
A 7	E8-4	A 15	E8-4	A 27	E8-4	R 1	E8-10
A 8	E8-4	A 16	E8-4	A 28	E8-4	S 1	E8-8
A 9	E8-4	A 17	E8-4	A 29	E8-4		
A 10	E8-4	A 19	E8-4	C 1	E8-6		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B
2	E8-14	T/C R/B


WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
AK1	E8-6	BODY MAIN WIRE to SIDE LH WIRE
AK2	E8-6	BODY MAIN WIRE to SIDE LH WIRE
AS1	E8-8	BODY MAIN WIRE to MAST SENSOR WIRE
CA1	E8-6	T/C HEAT GAUGE WIRE to BODY MAIN WIRE
EA1	E8-6	ENGINE WIRE to BODY MAIN WIRE
LA1	E8-4	INSTRUMENT PANEL WIRE to BODY MAIN WIRE
RK1	E8-10	HOOD MAIN WIRE RH to SIDE LH WIRE

EARTH

Code	See Page	Name
AA	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
KG	E8-10	REAR PILLER LEFT UNDER EARTH

* 1:TWISTED WIRE



DIAG

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 17	E8-4	E 21	E8-6	E 24	E8-6		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B


WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
AK1	E8-6	BODY MAIN WIRE to SIDE LH WIRE
EA1	E8-6	ENGINE WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
EC	E8-2	ENGINE UPPER EARTH
KG	E8-10	REAR PILLER LEFT UNDER EARTH

REAR WORKING LAMP



REAR WORKING LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
P 4	E8-10	P 5	E8-10	P 6	E8-10		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
EK1	E8-6	ENGINE WIRE to SIDE LH WIRE
OK1	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE
OK2	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE
OP1	E8-10	RR UPR MAIN WIRE to HOOD MAIN WIRE

EARTH

Code	See Page	Name
KG	E8-10	REAR PILLER LEFT UNDER EARTH

E9-30

COMPARTMENT LIGHT



COMPARTMENT LIGHT

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
P 1	E8-10	P 2	E8-10	P 3	E8-10		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
EK1	E8-6	ENGINE WIRE to SIDE LH WIRE
OK1	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE
OK2	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE
OP2	E8-10	RR UPR MAIN WIRE to HOOD MAIN WIRE

EARTH

Code	See Page	Name
KG	E8-10	REAR PILLER LEFT UNDER EARTH

E9-32

STROBE LIGHT



STROBE LIGHT

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
O 3	E8-10	O 4	E8-10				

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
AK1	E8-6	BODY MAIN WIRE to SIDE LH WIRE
OK2	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE


EARTH

Code	See Page	Name
KG	E8-10	REAR PILLER LEFT UNDER EARTH



COMBINATION METER

* 1:W/ OK MONITOR



E9-36

COMBINATION METER

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 5	E8-4	A 29	E8-4	E 11	E8-2	K 3	E8-10
A 15	E8-4	B 3	E8-6	E 16	E8-2	K 4	E8-10
A 24	E8-4	B 4	E8-6	E 21	E8-6	L 1	E8-4
A 28	E8-4	E 9	E8-2	E 30	E8-2		

RELAY BLOCK , JUNCTION BLOCK



Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE







Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
AK1	E8-6	BODY MAIN WIRE to SIDE LH WIRE
EA1	E8-6	ENGINE WIRE to BODY MAIN WIRE
EB1	E8-6	ENGINE WIRE to SIDE RH WIRE
LA1	E8-4	INSTRUMENT PANEL WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
AA	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
AB	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
KG	E8-10	REAR PILLER LEFT UNDER EARTH




MEMO



E9-38

MULTI DISPLAY



MULTI DISPLAY

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 17	E8-4	L 2	E8-4				

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B


WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AK1	E8-6	BODY MAIN WIRE to SIDE LH WIRE
AL1	E8-4	BODY MAIN WIRE to INSTRUMENT PANEL WIRE
EA1	E8-6	ENGINE WIRE to BODY MAIN WIRE

EARTH

Code	See Page	Name
KG	E8-10	REAR PILLER LEFT UNDER EARTH

HORN & W/ REAR HORN SWITCH



HORN & REAR HORN SWITCH

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 1	E8-4	A 13	E8-4	O 7	E8-10		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
EK1	E8-6	ENGINE WIRE to SIDE LH WIRE
OK2	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE

EARTH

Code	See Page	Name
AA	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
KG	E8-10	REAR PILLER LEFT UNDER EARTH

E9-42

HEAD LAMP



HEAD LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 3	E8-4	M 1	E8-8	N 1	E8-8		

RELAY BLOCK , JUNCTION BLOCK





Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
EA1	E8-6	ENGINE WIRE to BODY MAIN WIRE
MA1	E8-8	FR STAY WIRE RH to BODY MAIN WIRE
NA1	E8-8	FR STAY WIRE LH to BODY MAIN WIRE

EARTH

Code	See Page	Name
AA	E8-6	FRONT PLATE LEFT OUTSIDE EARTH



TURN SIGNAL LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 3	E8-4	N 2	E8-8	O 8	E8-10	O 12	E8-10
D 1	E8-4	O 1	E8-10	O 10	E8-10		
M 2	E8-8	O 2	E8-10	O 11	E8-10		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B


WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
AK1	E8-6	BODY MAIN WIRE to SIDE LH WIRE
DA1	E8-4	FLASHER WIRE to BODY MAIN WIRE
MA1	E8-8	FR STAY WIRE RH to BODY MAIN WIRE
NA1	E8-8	FR STAY WIRE LH to BODY MAIN WIRE
OK1	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE
OK2	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE

EARTH

Code	See Page	Name
AA	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
KG	E8-10	REAR PILLER LEFT UNDER EARTH

CLEARANCE LAMP



CLEARANCE LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 3	E8-4	N 2	E8-8	O 2	E8-10	O 11	E8-10
M 2	E8-8	O 1	E8-10	O 8	E8-10		

RELAY BLOCK , JUNCTION BLOCK





Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
AK1	E8-6	BODY MAIN WIRE to SIDE LH WIRE
MA1	E8-8	FR STAY WIRE RH to BODY MAIN WIRE
NA1	E8-8	FR STAY WIRE LH to BODY MAIN WIRE
OK1	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE
OK2	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE

EARTH

Code	See Page	Name
AA	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
KG	E8-10	REAR PILLER LEFT UNDER EARTH



BACK UP LAMP BUZZER & SMART ALARM

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 18	E8-4	O 2	E8-10	O 6	E8-10	O 11	E8-10
B 5	E8-6	O 5	E8-10	O 8	E8-10		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
AK1	E8-6	BODY MAIN WIRE to SIDE LH WIRE
EB1	E8-6	ENGINE WIRE to SIDE RH WIRE
OK1	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE
OK2	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE

EARTH

Code	See Page	Name
AB	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
KG	E8-10	REAR PILLER LEFT UNDER EARTH

E9-50

STOP LAMP



STOP LAMP

PARTS

Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 4	E8-4	O 2	E8-10	O 9	E8-10		
O 1	E8-10	O 8	E8-10	O 11	E8-10		

RELAY BLOCK , JUNCTION BLOCK

Code	See Page	Relay Block Name or Joining Wire Harness to J/B
1	E8-13	ENGINE ROOM R/B

WIRE TO WIRE


Code	See Page	Joining Wire Harness and Wire Harness
AE1	E8-6	BODY MAIN WIRE to ENGINE WIRE
AK1	E8-6	BODY MAIN WIRE to SIDE LH WIRE
OK1	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE
OK2	E8-10	RR UPR MAIN WIRE to SIDE LH WIRE

EARTH

Code	See Page	Name
KG	E8-10	REAR PILLER LEFT UNDER EARTH

CAN

* 1:TWISTED WIRE
* 2:W/ MULTI DISPLAY



CAN

PARTS


Code	See Page	Code	See Page	Code	See Page	Code	See Page
A 15	E8-4	E 21	E8-6	L 2	E8-4		
A 17	E8-4	E 24	E8-6				

WIRE TO WIRE

Code	See Page	Joining Wire Harness and Wire Harness
AL1	E8-4	BODY MAIN WIRE to INSTRUMENT PANEL WIRE
EA1	E8-6	ENGINE WIRE to BODY MAIN WIRE

E9-54

EARTH TO EARTH






EARTH TO EARTH

WIRE TO WIRE






Code	See Page	Joining Wire Harness and Wire Harness
AK2	E8-6	BODY MAIN WIRE to SIDE LH WIRE

EARTH

Code	See Page	Name
AA	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
AB	E8-6	FRONT PLATE LEFT OUTSIDE EARTH
EC	E8-2	ENGINE UPPER EARTH
ED	E8-2	ENGINE UPPER EARTH
KG	E8-10	REAR PILLER LEFT UNDER EARTH



MEMO



CHAPTER 10 GROUND POINTS

E10

E10-2

GROUND POINTS

CODE	LOCATION	SYSTEM NAME	PAGE
AA	FRONT PLATE LEFT OUTSIDE EARTH	CLEARANCE LAMP	E9-46
		COMBINATION METER	E9-34
		EZ PEDAL	E9-16
		HEAD LAMP	E9-42
		HORN & W/ REAR HORN SWITCH	E9-40
		POWER SHIFT TRANSMISSIN	E9-20
		SAS/OPS SYSTEM	E9-22
		STARTING	E9-6
AB	FRONT PLATE LEFT OUTSIDE EARTH	TURN SIGNAL LAMP	E9-44
		BACK UP LAMP BUZZER & SMART ALARM	E9-48
		COMBINATION METER	E9-34
		EZ PEDAL	E9-16
		LPG WARNING SYSTEM	E9-14
EC	ENGINE UPPER EARTH	POWER SHIFT TRANSMISSIN	E9-20
		STARTING	E9-6
		DIAG	E9-26
		ENGINE CONTROL	E9-8
ED	ENGINE UPPER EARTH	EZ PEDAL	E9-16
		LPG WARNING SYSTEM	E9-14
GE	REAR PILLER LEFT UNDER EARTH	ENGINE CONTROL	E9-8
		LPG WARNING SYSTEM	E9-14
HF	FRONT PLATE LEFT INSIDE EARTH	POWER SOURCE	E9-2
		STARTING	E9-6
KG	REAR PILLER LEFT UNDER EARTH	STARTING	E9-6
		BACK UP LAMP BUZZER & SMART ALARM	E9-48
		CLEARANCE LAMP	E9-46
		COMBINATION METER	E9-34
		COMPARTMENT LAMP	E9-30
		DIAG	E9-26
		ENGINE CONTROL	E9-8
		EZ PEDAL	E9-16
		HORN & W/ REAR HORN SWITCH	E9-40
		MULTI DISPLAY	E9-38
		REAR WORKING LAMP	E9-28
		SAS/OPS SYSTEM	E9-22
		STOP LAMP	E9-50
		STROBE LIGHT	E9-32
		TURN SIGNAL LAMP	E9-44

CHAPTER 11 FUSES FOR POWER SUPPLY

E11

E11-2

FUSES FOR POWER SUPPLY

FUSIBLE LINK BLOCK ASSY

FUSE		SYSTEM NAME	PAGE
100A	ALT	CHARGING	E9-4

ENGINE ROOM R/B

FUSE		SYSTEM NAME	PAGE
7.5A	ALT-S	CHARGING	E9-4
7.5A	ECU-B	SAS/OPS SYSTEM	E9-22
7.5A	HORN	HORN & W/ REAR HORN SWITCH	E9-40
7.5A	HOUR MET	COMBINATION METER	E9-34
7.5A	SFT	EZ PEDAL	E9-16
		POWER SHIFT TRANSMISSIN	E9-20
		STARTING	E9-6
7.5A	ST	EZ PEDAL	E9-16
		STARTING	E9-6
7.5A	STOP	SAS/OPS SYSTEM	E9-22
		STOP LAMP	E9-50
7.5A	TAIL	CLEARANCE LAMP	E9-46
7.5A	TURN	TURN SIGNAL LAMP	E9-44
10A	BACK LP	BACK UP LAMP BUZZER & SMART ALARM	E9-48
		EZ PEDAL	E9-16
		STROBE LIGHT	E9-32
10A	ECU-IG	DIAG	E9-26
		MULTI DISPLAY	E9-38
		SAS/OPS SYSTEM	E9-22
10A	GAUGE	CHARGING	E9-4
		COMBINATION METER	E9-34
		ENGINE CONTROL	E9-8
		SAS/OPS SYSTEM	E9-22
10A	WORK LP	COMPARTMENT LAMP	E9-30
		REAR WORKING LAMP	E9-28
15A	EFI	ENGINE CONTROL	E9-8
		LPG WARNING SYSTEM	E9-14
15A	E-THRO	ENGINE CONTROL	E9-8
15A	HEAD	HEAD LAMP	E9-42
15A	IGN	ENGINE CONTROL	E9-8
		LPG WARNING SYSTEM	E9-14
30A	STA	STARTING	E9-6

CHAPTER 12 CONNECTOR LIST

CONNECTOR LIST

PARTS CONNECTOR E12-2



















WIRE TO WIRE

WIRE TO WIRE E12-5

E12


E12-2

CONNECTOR LIST

A 1  90980-10935	A 2  90980-10171	A 3  90980-10807	A 4  90980-11155	A 5 BLACK  90980-11349	A 6 GRAY  90080-98200
A 7 GRAY  90980-11486	A 8  90980-11002	A 9 BLACK  90980-10959	A 10 BLACK  90980-10941	A 11 DARK GRAY  90980-11028	A 12 DARK GRAY  90980-10900
A 13 BLACK  90980-11235	A 14 BLACK  90980-11156	A 15  90980-12528	A 16  90980-12529		
A 17 DARK GRAY  90980-10891	A 18  90980-11594	A 19 BLACK  90980-10845	A 20 BLACK  90980-10942	A 22  90980-11251	
A 23  90980-11168	A 24  90980-10214	A 25 DARK GRAY  90980-11162	A 26 DARK GRAY  90980-11168	A 27 GRAY  90980-10899	A 28 GRAY  90980-10896
A 29 GRAY  90980-10897	A 30  90980-10173	A 31  90980-10173	A 32  90980-10171	A 33  90980-10171	A 34  90980-11020
B 1 DARK GRAY  90980-10869	B 2 BLACK  90980-10622	B 3  7316-2095	B 4  7316-2095	B 5  90980-10825	C 1 GRAY  90980-11025
	D 1  90980-11314				
E 1 BLACK  90980-11858	E 2 BLACK  90980-10108	E 3 DARK GRAY  90980-11153	E 4 GREEN  90980-11153	E 5  90980-10845	E 6 GREEN  90980-11153

CONNECTOR LIST

E 7
BLACK




90980-11144

E 8
DARK GRAY



90980-11153

E 9
BLACK



90980-11349

E 10



90980-09213

E 11



90980-10786

E 12
GREEN



90980-11062

E 13
BLACK



90980-10947

E 14
GRAY



90980-11286

E 15
DARK GRAY



90980-11038

E 16
BLACK



90980-10703

E 17
BLACK




90980-10179

E 18




99144-12239

E 20



90980-12529

E 21




90980-12525

E 22




90980-11016

E 23
BLACK




90980-11858

E 24
GRAY




57671-U2230-71

E 25
BLACK




57630-16640-71

E 26




90980-12527

E 27




90980-12528

E 28



90980-11256

E 29



90980-11257

E 30
BLACK



90980-10341

E 32



99141-13010

E 33



99141-13010

E 34



99141-11006

E 35



99141-11006

F 1



99142-16080

F 2



99142-16080

G 1



99142-15080

H 1



7003-1172-02

I 1
DARK GRAY



90980-11162

I 2
BLACK



90980-11235

I 3
DARK GRAY



90980-10626

I 4
DARK GRAY



90980-10899

I 5



90980-10173

J 1



7010-3015

J 2



7010-3015

K 1
BLACK




90980-11255

K 2



90980-11016

K 3
GRAY



90980-11077

























K 4
BLUE




90980-10216

E12-4

CONNECTOR LIST



WIRE TO WIRE



E12-6

WIRE TO WIRE

