J1 Troubleshooting

Index

Code	Name (Main Controller)	Page	Name (eps Controller)	Page
6			SERIAL ERR#1	66
8	WATCHDOG	9		
13	EEPROM KO	10	EEPROM KO	67
16			LOGIC FAILURE #4	68
17	LOGIC FAILURE #3	15	LOGIC FAILURE #3	69
18	LOGIC FAILURE #2	16	LOGIC FAILURE #2	70
19	LOGIC FAILURE #1	17	LOGIC FAILURE #1	71
30	VMN LOW	18		

Code	Name (Main Controller)	Page	Name (eps Controller)	Page
31	VMN HIGH	19		
32			VMN NOT OK	72
37	CONTACTOR CLOSED	20		
38	CONTACTOR OPEN	21		
48			MAIN CONT.OPEN	73
49	I=0 EVER	22		
53	STBY I HIGH	23	STBY I HIGH	74
60	CAPACITOR CHARGE	24		
61	HIGH TEMPERATURE	25	HIGH TEMPERATURE	75
65	MOTOR TEMPERAT.	26	MOTOR TEMPERAT	76
66	BATTERY LOW	27		

Code	Name (Main Controller)	Page	Name (eps Controller)	Page
69	CURRENT SENS. KO	28		
70			HIGH CURRENT	77
71			POWER FAILURE #3	78
72			POWER FAILURE #2	79
73			POWER FAILURE #1	80
74	DRIVER SHORTED	29		
75	CONTACTOR DRIVER	30		
76	COIL SHORTED	31		
78	VACC NOT OK	36		
79	INCORRECT START	37		
80	FORW + BACK	42		

Code	Name (Main Controller)	Page	Name (eps Controller)	Page
83			BAD ENCODER SIGN	81
99	INPUT ERROR #1	47	INPUT ERROR#1	82
212			MICRO SLAVE #8	83
218			CLOCK PAL NOT KO	84
219			STEPPER MOTOR MISM	85
220			MOTOR LOCKED	86
221			MICRO SLAVE #4	87
222			FB SENS LOCKED	88
225			CURRENT GAIN	89
226			NO SYNC	90
227			SLAVE COM,ERROR	91

Code	Name (Main Controller)	Page	Name (eps Controller)	Page
228			POSITION ERROR	92
230	PUMP CONT. OPEN	48		
231	PUMP CONT.CLOSED	49		
232	VACC OUT RANGE	50		
234	EPS RELE OPEN	51		
235	CAN BUS KO EPS	52		
236	WRONG SET BAT.	53		
238	LIFT LOW. ACTIVE	54		
239	LIFT + LOWER	59		
242			Q LINE SENSOR KO	93
243			D LINE SENSOR KO	94
244			GAIN EEPROM KO	95

Code	Name (Main Controller)	Page	Name (eps Controller)	Page
246			MICRO SLAVE KO	96
247			CAN BUS KO	97
248	CAN BUS KO	60		
250	THERMIC SENS. KO	61	MICRO SLAVE	98
251			KM OPEN	99
252	WAITING FOR NODE	62	KS OPEN	100
253	ENCODER ERROR	63	KM CLOSED	101
254	AUX OUTPUT KO	64	KS CLOSED	102

Appendix A: Parts Photo ---------- Page 103-106
Appendix B: Check Wires and Cables detail ---------- Page 107

Main Controller



ALARM #8 on NODE #2 WATCH DOG



ALARM #13 on NODE #2 EEPROM KO



Clear Eeprom in Handset

Turn on ZAPI Handset

Push and hold the power button for 3s

Cons AFG ZP021*

The Display will show:

Press ^ or v button until CAN CONSOLE shows on the display

Cons AFG ZP021*
CAN CONSOLE

The Display will show :

Press OK to go into the CANCONSOLE Menu

The Display will show:

Push 》, or 《
To select Node 2

CANCONSOLE
SELECT NODE

The Display will show:

SELECT NODE
NODE 2

Press OK to go into the
Traction controller

The Display will show:

ACOT2BESK EP0.45
24V 150A 0H

Press OK to go into the
Main Menu

The Display will show:

Main Menu

Press ^ or v button until CLEAR EEPROM on the display

The Display will show:

MAIN MENU
CLEAR EEPROM

Press OK to go into the CLEAR EEPROM function

The Display will ask:
ARE YOU SURE?

ARE YOU SURE?
YES= OK NO=ESC

Press OK to CLEAR EEPROM

The display will show:

EEPROM CLEARED!
KEY OFF, PLEASE

Rekey truck, and restart handset

ALARM #17 on NODE #2 LOGIC FAILURE #3



ALARM #18 on NODE #2 LOGIC FAILURE #2



ALARM #19 on NODE #2 LOGIC FAILURE #1



ALARM #30 on NODE #2 VMN LOW



ALARM #31 on NODE #2 VMN HIGH



ALARM #37 on NODE #2 CONTACTOR CLOSED



ALARM #38 on NODE #2 CONTACTOR OPEN



ALARM #49 on NODE #2 I=0 EVER



ALARM #53 on NODE #2 STBY I HIGH



ALARM #60 on NODE #2 CAPACITOR CHARGE



ALARM #61 on NODE #2 HIGH TEMPERATURE



ALARM #65 on NODE #2 MOTOR TEMPERAT



ALARM #66 on NODE #2 BATTERY LOW



ALARM #69 on NODE #2 CURRENT SENS. KO



ALARM #74 on NODE #2 DRIVER SHORTED



ALARM #75 on NODE #2 CONTACTOR DRIVER



ALARM #76 on NODE #2 COIL SHORTED




Check the voltage between Main Contactor and Main Controller (CAN #1) 4
The Voltage under 22V
The Voltage is about or Higher than 24 V
Check this wire 2
. . . . . .
Open or Short Circuit
Wire is OK
Reconnect wire
Replace Contactor
OK
Fault still Exists
OK
Fault still Exists


Check the voltage between Brake and Main Controller (CAN #3) 4
The Voltage under 22V
The Voltage is about or Higher than 24 V
Check this wire 2
. . . . . .
Open or Short Circuit
Wire is OK
Reconnect wire
Replace Brake
OK
Fault still Exists
OK
Fault still Exists


Check the voltage between Pump Contactor and Main Controller (CAN #4) 4
The Voltage under 22V
The Voltage is about or Higher than 24 V
Check this wire 2
. . . . . .
Open or Short Circuit
Wire is OK
Reconnect wire
Replace Pump Contactor
OK
Fault still Exists
OK
Fault still Exists


Check the voltage about Main Controller (CAN #6) 4
The Voltage under 22V
The Voltage is about or Higher than 24 V
Check this wire 2
Open or Short Circuit
Wire is OK
Reconnect wire
OK
Fault still Exists

ALARM #78 on NODE #2 VACC NOT OK



ALARM #79 on NODE #2 INCORRECT START



Check Tiller Switch in Handset

Turn on ZAPI Handset

Push and hold the power button for 3s

Cons AFG ZP021*

The Display will show:

Press ^ or v button until CAN CONSOLE shows on the display

Cons AFG ZP021*
CAN CONSOLE

The Display will show :

Press OK to go into the CANCONSOLE Menu

The Display will show:

CANCONSOLE
SELECT NODE

Push 》, or 《
To select Node 2

The Display will show:

SELECT NODE
NODE 2

Press OK to go into the
Traction controller

The Display will show:

ACOT2BESK EP0.45
24V 150A 0H

Press OK to go into the
Main Menu

The Display will show:

Main Menu

Press ^ or v button until TEST shows on the display

The Display will show:

MAIN MENU
TEST

Press OK to go into the TEST function

The Display will show:

TEST

Press ^ or v button until HANDLE/ SEAT SW shows on the display

The display will show:

HANDLE/ SEAT SW OFF

Press Pedal and Push the accelerator and hold on



The display will show:

HANDLE/ SEAT SW ON

When finished , press and hold power button for 3s to turn off the Console

ALARM #80 on NODE #2 FORW+BACK



Check Forward and Backward in Handset

Turn on ZAPI Handset

Push and hold the power button for 3s

Cons AFG ZP021*

The Display will show:

Press ^ or v button until CAN CONSOLE shows on the display

Cons AFG ZP021*
CAN CONSOLE

The Display will show :

Press OK to go into the CANCONSOLE Menu

The Display will show:

CANCONSOLE
SELECT NODE

Push 》, or 《
To select Node 2

The Display will show:

SELECT NODE
NODE 2

Press OK to go into the
Traction controller

The Display will show:

ACOT2BESK EP0.45
24V 150A 0H

Press OK to go into the
Main Menu

The Display will show:

Main Menu

Press ^ or v button until TEST shows on the display

The Display will show:

MAIN MENU
TEST

Press OK to go into the TEST function

The Display will show:

TEST

Press ^ or v button until FORWARD shows on the display

The display will show:

FORWARD OFF

Push the accelerator forward and hold on



The display will show:

FORWARD ON

Repeat step for reverse direction

BACKWARD OFF
BACKWARD ON

When finished , press and hold power button for 3s to turn off the Console

ALARM #99 on NODE #2 INPUT ERROR #1



ALARM #230 on NODE #2 PUMP CONT. OPEN



ALARM #231 on NODE #2 PUMP CONT. CLOSED



ALARM #232 on NODE #2 VACC OUT RANGE



ALARM #234 on NODE #2 EPS RELE OPEN



ALARM #235 on NODE #2 CAN BUS KO EPS



ALARM #236 on NODE #2 WRONG SET BAT.



ALARM #238 on NODE #2 LIFT LOW. ACTIVE



Check Lift and Lower Switch in Handset

Turn on ZAPI Handset

Push and hold the power button for 3s

Cons AFG ZP021*

The Display will show:

Press ^ or v button until CAN CONSOLE shows on the display

Cons AFG ZP021*
CAN CONSOLE

The Display will show :

Press OK to go into the CANCONSOLE Menu

The Display will show:

Push 》, or 《
To select Node 2

The Display will show:

Press OK to go into the
Traction controller

The Display will show:

Press OK to go into the
Main Menu

CANCONSOLE
SELECT NODE

SELECT NODE
NODE 2

ACOT2BESK EP0.45
24V 150A 0H

The Display will show:

Main Menu

Press ^ or v button until TEST shows on the display

The Display will show:

MAIN MENU
TEST

Press OK to go into the TEST function

The Display will show:

TEST

Press ^ or v button until LIFT SW shows on the display

The display will show:

LIFT SW OFF

Press Pedal and Press the Lift Switch and hold on

The display will show:

LIFT SW ON

Repeat Step for Lower Switch:

LOWER SW OFF

LOWER SW ON

When finished , press and hold power button for 3s to turn off the Console

ALARM #239 on NODE #2 LIFT + LOWER



ALARM #248 on NODE #2 CAN BUS KO



ALARM #250 on NODE #2 THERMIC SENS. KO



ALARM #252 on NODE #2 WAITING FOR NODE



ALARM #253 on NODE #2 ENCODER ERROR



ALARM #254 on NODE #2 AUX OUTPUT KO



EPS Controller



ALARM #6 on NODE #6 SERIAL ERR #1



ALARM #13 on NODE #6 EEPROM KO



ALARM #16 on NODE #6 LOGIC FAILURE #4



ALARM #17 on NODE #6 LOGIC FAILURE #3



ALARM #18 on NODE #6 LOGIC FAILURE #2



ALARM #19 on NODE #6 LOGIC FAILURE #1



ALARM #32 on NODE #6 VMN NOT OK



ALARM #48 on NODE #6 MAIN CONT. OPEN



ALARM #53 on NODE #6 STBY I HIGH



ALARM #61 on NODE #6 HIGH TEMPERATURE



ALARM #65 on NODE #6 MOTOR TEMPERAT



ALARM #70 on NODE #6 HIGH CURRENT



ALARM #71 on NODE #6 POWER FAILURE #3



ALARM #72 on NODE #6 POWER FAILURE #2



ALARM #73 on NODE #6 POWER FAILURE #1



ALARM #83 on NODE #6 BAD ENCODER SIGN



ALARM #99 on NODE #6 INPUT ERROR #1



ALARM #212 on NODE #6 MICRO SLAVE #8



ALARM #218 on NODE #6 CLOCK PAL NOT KO



ALARM #219 on NODE #6 STEPPER MOTOR MISM



ALARM #220 on NODE #6 MOTOR LOCKED



ALARM #221 on NODE #6 MICRO SLAVE #4



ALARM #222 on NODE #6 FB SENS LOCKED



ALARM #225 on NODE #6 CURRENT GAIN



ALARM #226 on NODE #6 NO SYNC



ALARM #227 on NODE #6 SLAVE COM. ERROR



ALARM #228 on NODE #6 POSITION ERROR



ALARM #242 on NODE #6 Q LINE SENSOR KO



ALARM #243 on NODE #6 D LINE SENSOR KO



ALARM #244 on NODE #6 GAIN EEPROM KO



ALARM #246 on NODE #6 MICRO SLAVE KO



ALARM #247 on NODE #6 CAN BUS KO



ALARM #250 on NODE #6 MICRO SLAVE



ALARM #251 on NODE #6 KM OPEN



ALARM #252 on NODE #6 KS OPEN



ALARM #253 on NODE #6 KM CLOSED



ALARM #254 on NODE #6 KS CLOSED



Appendix A


Main Contactor
Fuses
Main Controller UVW Cables
Main Controller Wires
EPS Controller UVW Cables
EPS Controller Wires


EPS Motor UVW Cables
EPS Motor Encode
Traction Motor Encode
EPS Motor Temperature Sensor (White Wire)


Electrical Brake
Traction Motor UVW Cables
Traction Motor Temperature Sensor (White Wire)
Toggle Switch

Battery Cables

Emergency Stop

Accelerator

Lift, Lower, Bell Button
and Key Switch

Steel Wheel

Appendix B

1. Check if cables are opened or shorted. A shorted cable means the cable jacketing is damaged and it is shorting to another cable or it is in contact with a metal object like the frame. An open cable means one of the inside metal wires are cut/damaged. If you are not sure, pleasure measure the resistance of the individual wire or cable. If the resistance is more than 1 ohm, it is open.



Check the connection points of the motor cables, and controller cables. Check the cable terminals for burn marks. Check if hardware is loose or burned. Ensure connections re tightened properly.



2. Check if cables are opened or shorted. A shorted cable means the cable jacketing is damaged and it is shorting to another cable or it is in contact with a metal object like the frame. An open cable means one of the inside metal wires are cut/damaged. If you are not sure, pleasure measure the resistance of the individual wire or cable. If the resistance is more than 1 ohm, it is open.





Check the connectors and pins on the Controller. Ensure connector locks are not damaged and no pins are broken or pushed out of the connector. Ensure no wires at pin terminations are cut/damaged



Check the connections between Controller wires and switches/sensors. Ensure wires are not cut or damaged.

Check if connectors are loose or burned (such as the 2 pin connectors on the Main Contact). Ensure the parts are properly tightened.



3. Check if cables are opened or shorted. A shorted cable means the cable jacketing is damaged and it is shorting to another cable or it is in contact with a metal object like the frame. An open cable means one of the inside metal wires are cut/damaged. If you are not sure, pleasure measure the resistance of the individual wire or cable. If the resistance is more than 1 ohm, it is open



Check the Connectors between Battery and truck to see if they fit loose or are burned (Concentrate on the inside of the connector). If they do not fit correctly, replace cable lugs and/or connector housing to correct the issue.



Check if the fuses are blown out or not.



4. Check the voltage from the wire you want to check to the Controller negative (red circled).



5. Open the battery case.

Check the no load battery voltage for every battery.

- Check the load voltage when the truck is lifting empty.

- Then check the load voltage when the truck is lifting with a load (red circled load, load should be no more than 150 pound). If the no load voltage is less than 11V, or the voltage difference between the empty lifting and loaded lifting is more than 5V. Please replace battery.