E30 Troubleshooting

Index

Code	Name (Main Controller)	Page	Code	Name (Main Controller)	Page
4，5	BATTERY DISCONNECT FAULT	4	2，4	MAIN ON FAULT	13
3，4	BRAKE OFF FAULT	5	1，5	OVERVOLTAGE FAULT	14
3，2	BRAKE ON FAULT	6	3，3	PRECHARGE FAULT	15
4，1	CURRENT SENSE FAULT	7	1，3	SPEED POT FAULT	16
4，3	EEPROM CHECKSUM FAULT	8	1，1	THERMAL FAULT	17
4，2	HARDWARE FAILSAFE	9	1，2	THROTTLE FAULT	18
3，5	HPD FAULT	10	1，4	UNDERVOLTAGE FAULT	19
2，3	MAIN FAULT	11	3，1	WIRING FAULT	20
2，1	MAIN OFF FAULT	12			

Appendix A: Check Wires and Cables detail ---------- Page 20

Main Controller

ALARM 4, 5 BATTERY DISCONNECT FAULT



ALARM 3, 4 BRAKE OFF FAULT



ALARM 3, 2 BRAKE ON FAULT



ALARM 4, 1 CURRENT SENSE FAULT



ALARM 4, 3 EEPROM CHECK FAULT



ALARM 4, 2 HARDWARE FAILSAFE



ALARM 3, 5 HPD FAULT



ALARM 2, 3 MAIN FAULT



ALARM 2, 3 MAIN OFF FAULT



ALARM 2, 1 OVERVOLTAGE FAULT



ALARM 3, 3 PRECHARGE FAULT



ALARM 1, 3 SPEED POT FAULT



ALARM 1, 1 THERMAL FAULT



ALARM 1, 2 THROTTLE FAULT



ALARM 1,4 UNDERVOLTAGE FAULT



ALARM 3, 1 WIRING FAULT



Appendix A

1. Check if cables are opened or shorted. A shorted cable means the cable jacketing is damaged and it is shorting to another cable or it is in contact with a metal object like the frame. An open cable means one of the inside metal wires are cut/damaged. If you are not sure, pleasure measure the resistance of the individual wire or cable. If the resistance is more than 1 ohm, it is open.



Check the connection points of the motor cables, and controller cables. Check the cable terminals for burn marks. Check if hardware is loose or burned. Ensure connections are tightened properly.





2. Check if cables are opened or shorted. A shorted cable means the cable jacketing is damaged and it is shorting to another cable or it is in contact with a metal object like the frame. An open cable means one of the inside metal wires are cut/damaged. If you are not sure, pleasure measure the resistance of the individual wire or cable. If the resistance is more than 1 ohm, it is open.





Check the connectors and pins on the Controller. Ensure connector locks are not damaged and no pins are broken or pushed out of the connector. Ensure no wires at pin terminations are cut/damaged



Check the connections between Controller wires and switches/sensors. Ensure wires are not cut or damaged.

Check if connectors are loose or burned (such as the 2 pin connectors on the Main Contact). Ensure the parts are properly tightened.



3. Check if cables are opened or shorted. A shorted cable means the cable jacketing is damaged and it is shorting to another cable or it is in contact with a metal object like the frame. An open cable means one of the inside metal wires are cut/damaged. If you are not sure, pleasure measure the resistance of the individual wire or cable. If the resistance is more than 1 ohm, it is open



Check the Connectors between Battery and truck to see if they fit loose or are burned (Concentrate on the inside of the connector). If they do not fit correctly, replace cable lugs and/or connector housing to correct the issue.



Check if the fuses are blown out or not.



4. Check the voltage from the wire you want to check to the Controller negative (red circled).



5. Open the battery case.

Check the no load battery voltage for every battery.



- Check the load voltage when the truck is lifting empty.
- Then check the load voltage when the truck is lifting with a load (red circled load, load should be no more than 2000 pound). If the no load voltage less than 11V, or the voltage difference between the empty lifting and loaded lifting is more than 5V. Please replace battery.