



2020 Utility and Passenger Van Models Catalog

- Parts Manual -

Table of Contents

Parts Manual

Leaf Spring Assembly.....	Page 1
Fuel Dideline and Fuel Pump	Page 1
Wheel and Tire	Page 2
Console Box.....	Page 2
Gear Shift Control System	Page 3
Final Drive and Differential Gear Assembly	Page 3
Spare Tire Carrier.....	Page 4
Frong Brake	Page 4
Absorber & Strut Assembly, FR Suspension	Page 5
RR Brake.....	Page 6
FR Suspension	Page 7
Fuel Tank.....	Page 8
Propeller Shaft	Page 8
Battery.....	Page 9
Wiper Assembly	Page 9
FR Seat Belt	Page 10
FR Stabilizer Bar.....	Page 11
Parking Brake.....	Page 11
Steering Gear Assembly.....	Page 12
Steering Wheel	Page 12
Steering Shaft.....	Page 13

Table of Contents

FR Upper Member and Dash Panel	Page 13
Side Body Panel (Single Cab Model)	Page 14
Side Body Panel (Double Cab Model).....	Page 14
Accelerator Pedal Assembly	Page 15
Brake Master Cylinder.....	Page 15
Brake Pipe (without ABS)	Page 16
Light System	Page 17
Lock Set	Page 17
Cooling System.....	Page 18
Washer Assembly.....	Page 18
Switch Assembly, Combination and Electrical Control.....	Page 19
Combination Meter	Page 19
Wiring Harness	Page 20
Seat Assembly, FR	Page 20
Seat Assembly, 3rd (Double Cab Model)	Page 21
ACK Assembly	Page 21
Carpet Assembly	Page 22
Instrument Panel	Page 22
Air Pipe	Page 23
A/C System	Page 23
Radio and Antenna	Page 24
FR Windshield	Page 24
Glass and Weatherstrip, FR Door	Page 25

Table of Contents



FR Door Lock and Inner Trim	Page 26
FR Hood and Accessories	Page 27
Roof Panel (Single Cab)	Page 27
Roof Panel (Double Cab)	Page 27
FR Fender	Page 28
Body Frame Welding Assembly	Page 28
Clutch Cable Assembly.....	Page 28
Accelerator Cable.....	Page 29
RR Axle.....	Page 29
Half Shaft, RR Axle	Page 30
Deck	Page 30
Back Panel	Page 31
FR Bumper.....	Page 31
Roof Lining, Sunvisor.....	Page 32
Rearview Mirror.....	Page 32
Mudguard Flap.....	Page 33
Outer Garnish, FR Triangle	Page 33
Wind Guiding Cover.....	Page 33
Floor Side Granish, Wheel Arch	Page 34
Intake Manifold.....	Page 34
Oil Pump Cover Assembly, Timing Belt Front and Oil Sump Assembly.....	Page 35
Fuel and Ventilation System	Page 36
Cooling System	Page 37



Table of Contents



Eelectrical Equipments	Page 38
Engine Assembly	Page 39
Cylinder Head and Cover.....	Page 39
Crankcase	Page 40
Exhaust System	Page 40
Harness Assembly, Engine and Accessories	Page 41
Timing System	Page 41
Engine Bracket	Page 42
Clutch	Page 42
Air Cleaner.....	Page 43
Motor Assembly, Starting and Accessories	Page 43
Pipe Assembly, Muffler	Page 44
Transmission Assembly and Accessories	Page 44
Case Assembly, Gear Shift.....	Page 45
Tranmission Case	Page 46
Clutch Fork	Page 46
Input Shaft.....	Page 47
Countershaft	Page 48
Shaft, Reverse Gear	Page 48
Output Shaft	Page 49
Countershaft	Page 48
Shaft, Reverse Gear	Page 48
Output Shaft	Page 49



Table of Contents


Crankshaft and Connecting Rods System.....	Page 49
Gearshift Lever	Page 50
Extension Case.....	Page 51


Picture	NO.	Changan NO.	Part name	SC1027DA A4.C3DU1	SC1027S A.C3DU1
	12103-10 后悬架钢板弹簧总成				
	12103-10 LEAF SPRING ASSY				
	1	MD201045-0004	U-BOLT, RR LEAF SPRING	4	4
	2	MD201045-0019	ABSORBER ASSY, RR SHOCK	2	2
	3	MD201045-0002	CUSHION, SADDLE	2	2
	4	MD201045-0003	CUSHION, RR SPRING	2	2
	5	MD201045-0001	LEAF SPRING ASSY	2	2
	6	CM5045-0700	JOINT PLATE, INNER	2	2
	7	BX109-055	BUSH- II, RR SUSPENSION	4	4
	8	CM5045-0901	JOINT PLATE, OUTER	2	2
	9	Y043-150	NUT M10	1	1
	53107-20 燃油管路及燃油泵				
	53107-20 FUEL DIDELINE AND FUEL PUMP				
	1	M201015-1200	CANISTER ASSY, WITH HOSE	1	
	1	M201015-1201	CANISTER ASSY, WITH HOSE		1
	2	M201046-0700	PIPE, FUEL EVAPORATION	1	1
	3	Y013-060	PLATE, FUEL PUMP	1	1
	4	CB10013-0103	FUEL PUMP ASSY	1	1
	5	Y101-150	CLAMP	1	1
	6	1101012-Y01	HOSE, FUEL EVAPORATION	1	1
	7	M201015-0700	FUEL PIPE, NYLON	1	1
	8	M201015-0800	PIPE, NYLON FUEL, RETURN	1	1
	9	CM5013-0201	FILTER ASSY, FUEL	1	1
	10	C201130-1400	CLIP	1	1
	11	Y101-150	CLAMP	1	1
	12	M201039-0005	HOSE, FUEL	1	
	12	1104051-Y01	HOSE, FUEL		1

	12104-10 轮胎及轮盘轮辋			
	12104-10 WHEEL AND TIRE			
	1	MD201048-0003-AA	TIRE (175/70R14LT)	55
	2	MD201048-0001	WEEL ASSY, STEEL(14X5J)	55
	3	Y048-040	VALVE, TYRE	55
	4	BX048-002	CAP, WHEEL CENTER	44
	5	MD201078-1103	NUT, WHEEL	2020
	95106-20 控制箱			
	95106-20 CONSOLE BOX			
	1	M201077-0100	BOX ASSY, CONSOLE	11
	2	M201077-0300	CUP, CONSOLE BOX, RR	11
	3	M201077-0400	COVER, CONSOLE BOX, RR	11


	63404-10 换挡操纵总成			
	63404-10 GEAR SHIFT CONTROL SYSTEM			
	1	M201023-0100	LEVER ASSY, GEAR SHIFT CONTROLLER	1 1
	2	M201023-0300	CABLE ASSY, GEAR SHIFT CONTROL	1 1
	3	M201023-0200	CABLE ASSY, GEAR SELECT CONTROL	1 1
	22203-10 主减速器及差速器总成			
	22203-10 FINAL DRIVE AND DIFFERENTIAL GEAR ASSY			
	1	MD201026-0000	FINAL DRIVE AND DIFFERENTIAL GEAR ASSY	1 1
	2	M201025-0106	BEARING 30306	1 1
	3	M201025-0104	SPACER, BEVEL PINION	1 1
	4	Q001037-0500	BEARING 30305	1 1
	5	P028-0700	OIL SEAL, DRIVE BEVEL GEAR	1 1
	6	MD201025-0003	FLANGE, UNIVERSAL JOINT	1 1
	7	M201025-0107	NUT	1 1

[illegible]



[illegible]






32302-10 后轮制动器 (鼓式)				
32302-10 RR BRAKE				
1	MD201037-0000	RR BRAKE ASSY, LH	1	1
1	MD201037-0001	RR BRAKE ASSY, RH	1	1
2	MD201037-0003	PIN, SHOE HOLD	4	4
3	MD201037-0002	PLATE ASSY, RR WHEEL BRAKE, LH	1	1
3	MD201037-0012	PLATE ASSY, RR WHEEL BRAKE, RH	1	1
4	MD201037-0004	CYLINDER , RR WHEEL BRAKE, LH	1	1
4	MD201037-0014	CYLINDER , RR WHEEL BRAKE, RH	1	1
5	M201037-0301	RETURN SPRING, UPPER	2	2
6	M201037-0302	SPRING, SHOE RETURN UPPER , LH	2	2
7	M201037-0303	ANCHOR, ADJUST BRAKE SHOE, LH	1	1
7	M201037-0304	ANCHOR, ADJUST BRAKE SHOE, RH	1	1
8	M201037-0305	BOARD, BRAKE SHOE ADJUST, LH	1	1
8	M201037-0306	BOARD, BRAKE SHOE ADJUST, RH	1	1
9	MD201037-0010	SHOE ASSY, RR BRAKE, LH	1	1
9	MD201037-0011	SHOE ASSY, RR BRAKE, RH	1	1
10	M201037-1100	SPRING, BRAKE SHOE HOLD	4	4
11	M201037-1200	SEAT, BRAKE SHOE HOLD SPRING	4	4
12	MD201037-0013	SPRING, LOWER SHOE RETURN	2	2
13	CM10040-0100	DRUM ASSY, RR BRAKE	2	2

[illegible]



	53107-10 燃油箱总成			
	53107-10 FUEL TANK			
	1	MD201046-0001	FUEL TANK ASSY	1
	1	MS201046-0900	FUEL TANK ASSY	1
	2	Y101-140	HOOP	1
	3	1101012-Y01	HOSE, FUEL EVAPORATION	1
	4	Y101-150	CLAMP	1
	5	M201046-0700	PIPE, FUEL EVAPORATION	1
	6	Y101-080	CLAMP, FUEL FILLER HOSE	2
	7	MD201046-0002	HOSE, FUEL TANK FILLER	1
	7	M201046-0101	HOSE, FUEL TANK FILLER	1
	8	MD201046-0005	BREATHER HOSE, FUEL TANK	1
	8	M201046-0102	BREATHER HOSE, FUEL TANK	1
	9	MD201046-0008	NECK ASSY, FUEL FILLER	1
	9	M201046-0109	NECK ASSY, FUEL FILLER	1
	10	MD201069-0100	CAP ASSY, FUEL FILLER	1
	10	C201129-1000	CAP ASSY, FUEL FILLER	1
	22204-10 传动轴带万向节总成			
	22204-10 PROPELLER SHAFT			
	1	MD201024-0001	SHAFT ASSY, PROPELLER	1



	53110-10 蓄电池			
	53110-10 BATTERY			
	1	Y063-240	BOLT, BATTERY HOLDING	1 1
	2	Y063-230	PLATE, BATTERY HOLDING	1 1
	3	Y030-011	BATTERY ASSY	1 1
	4	Y030-050	BRACKET, BATTERY	1 1
	84307-10 刮水器总成			
	84307-10 WIPER ASSY			
	1	M201099-0100	ARM AND BLADE ASSY, FR WIPER, SUB	1 1
	2	M201099-0112	BLADE ASSY, FR WIPER, SUB	1 1
	3	M201099-0111	ARM ASSY, FR WIPER SUB	1 1
	4	Y038-080	CAP, WIPER ARM HOLE	2 2
	5	M201099-0400	ARM AND BLADE ASSY, FR WIPER, MAIN	1 1
	6	M201099-0412	BLADE, FR WIPER, SUB	1 1
	7	M201099-0411	ARM, FR WIPER, SUB	1 1
	8	M201099-0600	MOTOR AND ARM, FR WIPER	1 1



[illegible]


	12102-30 前稳定杆			
	12102-30 FR STABILIZER BAR			
	1	M201043-0100	FR STABILIZER BAR	1
	2	M201049-6301	STABILIZER LINK	2
	3	F202043-0600	CUSHION, STABILIZER LINK	4
	4	Y044-090	WASHER	4
	5	Y043-150	NUT M10	1
	6	F202046-0101	BUSHING, FR STABILIZER BAR	2
	7	F202043-0200	BRACKET, FR STABILIZER BAR	2
	32304-10 驻车制动器总成			
	32304-10 PARKING BRAKE			
	1	F202038-0100	LEVER ASSY, PARKING BRAKE	1
	2	M201038-0300	CABLE ASSY, PARKING BRAKE NO.1	1
	3	MD201038-0005	CABLE ASSY, PARKING BRAKE NO.2, RH	1
	4	MD201038-0004	CABLE ASSY, PARKING BRAKE NO.2, LH	1


	42402-20 转向器总成			
	42402-20 STEERING GEAR ASSY			
	1	M201041-0100	STEERING GEAR ASSY	1 1
	2	Y052-270	WASHER, STEERING TIE-ROD LOCK	2 2
	3	F202041-0200	TIE-ROD ASSY, STEERING, LH	1 1
	4	F202041-0300	TIE-ROD ASSY, STEERING, RH	1 1
	42404-10 方向盘			
	42404-10 STEERING WHEEL			
	1	M201039-0200	STEERING WHEEL ASSY	1 1
	2	P050-0800	NUT	1 1
	3	M201039-0100	COVER, STEERING WHEEL	1 1

	42404-11 转向柱			
	42404-11 STEERING SHAFT			
	1	R101040-0600	DUSTPROOF COVER, STEERING SHAFT	1 1
	2	M201040-0200	SHAFT ASSY, STEERING, LOWER	1 1
	3	MD201040-0001	SHAFT ASSY, STEERING, UPPER	1 1
	4	P050-0800	NUT	1 1
	95201-50 前上构件、前壁板			
	95201-50 FR UPPER MEMBER AND DASH PANEL			
	1	MD201053-0001	UPPER MEMBER, FR	1 1
	2	M201053-0200	DASH PANEL ASSY	1 1


	95202-40 侧围焊接总成 (单排)				
	95202-40 SIDE BODY PANEL (single cab)				
	1	MD201051-1600	PANEL ASSY, SIDE BODY, LH	1	
	1	MD201051-1601	PANEL ASSY, SIDE BODY, RH	1	
	95202-60 侧围焊接总成 (双排)				
	95202-60 SIDE BODY PANEL (double cab)				
	1	MS201051-1300	PANEL ASSY, SIDE BODY, LH		1
	1	MS201051-1400	PANEL ASSY, SIDE BODY, RH		1
	2	MS201069-0700	LID ASSY, FUEL FILLER		1

	53112-10 油门踏板总成			
	53112-10 ACCELERATOR PEDAL ASSY			
	1	M201032-0101	PEDAL ASSY, ACCELERATOR	1
	2	M201032-0102-AA	PEDAL ASSY, WITH BRAKE LAMP SWITCH	1
	32305-10 制动总泵			
	32305-10 BRAKE MASTER CYLINDER			
	1	MD201600-0004	CYLINDER ASSY, BRAKE MASTER	1
	1	MD201033-0001	CYLINDER ASSY, BRAKE MASTER	1

	32305-30 制动管路			
	32305-30 BRAKE PIPE(without ABS)			
	1	M201053-0001	BRAKE PIPE, MA PRI TO 6 WAY	1
	2	M201053-0002	BRAKE PIPE, MA SEC TO 6 WAY	1
	3	M201053-0003	BRAKE PIPE, RR BK HOSE TO W/CR	1
	4	M201053-0004	BRAKE PIPE, RR BK HOSE TO W/CL	1
	5	P056-1900	HOSE ASSY, FR BRAKE FLEXIBLE	2
	6	M201053-0012	JOINT, BRAKE 6 WAY	1
	7	MD201035-0005	BRAKE PIPE, 6 WAY TO LSPV SEC	1
	8	MD201035-0006	BRAKE PIPE, 6 WAY TO LSPV SEC	1
	9	MD201035-0009	BRAKE PIPE, LSPV TO RR BK HOSE L	1
	10	Y057-210	HOSE, RR BRAKE FLEXIBLE	1
	11	MD201035-0007	BRAKE PIPE, LSPV TO W/C	1
	12	Y057-230	CLAMP	2
	13	MD201035-0008	BRAKE PIPE, R W/CR TO W/C L	1
	14	Y057-240	CLAMP	1
	15	MD201035-0022	VALVE, LSP	1
	15	MS201054-0500	VALVE, LSP	1
	16	M201035-2300	VACUUM PIPE, BRAKE NO.1	1
	17	M201035-2400	VACUUM HOSE, BRAKE NO.4	1



84306-00 照明系统				
84306-00 LIGHT SYSTEM				
1	M201096-0300	LAMP ASSY, FR FOG, LH	1	1
1	M201096-0400	LAMP ASSY, FR FOG, RH	1	1
2	MD201096-0003	LAMP ASSY, FR COMBINATION, LH	1	1
2	MD201096-0004	LAMP ASSY, FR COMBINATION, RH	1	1
3	F202099-2000	READING LAMP	1	1
4	BX034-010	LAMP ASSY, RR COMBINATION, LH	1	1
5	Y034-090	LAMP ASSY, LICENSE	2	2
6	BX034-011	LAMP ASSY, RR COMBINATION, RH	1	1



[illegible]



This diagram shows the exploded view of a cooling system. Key components include: 1. Upper radiator bracket, 2. Radiator assembly, 3. Radiator inlet hose, 4. Radiator outlet hose, 5. Radiator mounting bracket, 6. Radiator fan assembly, 7. 3-way hose connector, 8. Water tank, 9. Heater inlet hose, 10. Heater jointing with tube, 11. Water pipe assembly for the floor, 12. Hose from engine to heater, 13. Water pipe from engine outlet, 14. Water pipe from engine inlet, and 15. Water tank bracket. The diagram illustrates the spatial arrangement and assembly sequence of these parts.



53104-10 冷却系统				
53104-10 COOLING SYSTEM				
1	M201098-0300	BRACKET, RADIATOR, UPPER	2	2
2	M201098-0100	RADIATOR ASSY	1	1
3	M201098-0104	HOSE, RADIATOR, INLET	1	1
4	M201098-0102	HOSE, RADIATOR, OULET	1	1
5	Y016-040	BRACKET, REDIATOR MOUNTING	2	2
6	F202098-0900	FAN ASSY, RADIATOR	1	1
7	M201098-0800	3 WAY	1	1
8	M201098-0900	WATER TANK	1	1
9	M201098-1000	HOSE, HEATER INLET	1	1
10	M201098-1200	JOINTING WITH TUBE, HEATER	1	1
11	M201098-1305	WATER PIPE ASSY, FLOOR	1	
12	M201098-1600	HOSE, ENGINE TO HEATER	1	1
13	M201098-1700	WATER PIPE, ENGINE, OUTLET	1	1
14	M201098-1400	WATER PIPE, ENGINE, INLET	1	1
15	M201098-0201	BRACKET, WATER TANK	1	1
16	M201098-0311	AIR HOSE, RADIATOR OVERFLOW	1	1



This diagram shows the exploded view of a washer system. Key components include: 1. Nozzle assembly for the washer, 2. Washer hose assembly, and 3. Washer assembly for the front windshield. The diagram illustrates the spatial arrangement and assembly sequence of these parts.



84307-20 洗涤器总成				
84307-20 WASHER ASSY				
1	Y039-020	NOZZLE ASSY, WASHER, FR	2	2
2	M201099-0200	HOSE ASSY, WASHER	1	1
3	M201099-0500	WASHER ASSY, FR WINDSHIELD	1	1



	84301-10 开关及电控设备			
	84301-10 SWITCH ASSY, COMBINATION AND ELECTRICAL CONTROL			
	1	M201100-0200-AA	SWITCH ASSY, POWER WINDOW, MAIN	1 1
	2	M201100-0300	SWITCH ASSY, COMBINATION	1 1
	3	M201100-0600	SWITCH ASSY, HAZARD	1 1
	4	M201100-0700-AA	SWITCH ASSY, POWER WINDOW, SUB	1 1
	5	M201164-0008	SWITCH, FR DOOR SIGNAL LAMP	2 2
	6	B201030-0900	CAP, OPTION SWITCH HOLE	3 3
	84302-10 组合仪表总成			
	84302-10 COMBINATION METER			
	1	MD201101-0101	METER ASSY, COMBINATION	1 1
	2	R101101-0200	SENSOR, SPEED	1 1


	84315-00 线束			
	84315-00 WIRING HARNESS			
	1	4000020-Y308-BA	WIRING HARNESS, CHASSIS	1
	1	MD201103-4109	WIRING HARNESS, CHASSIS	1
	2	MD201101-0105	WIRE HARNESS ASSY, DASHBOARD	1
	2	MS201103-1114	WIRE HARNESS ASSY, DASHBOARD	1
	3	MD201101-0020	WIRING HARNESS, ROOF	1
	3	MS201103-1300	WIRING HARNESS, ROOF	1
	4	MD201101-0023	WIRING HARNESS, FR DOOR, RH	1
	4	MS201103-1500	WIRING HARNESS, FR DOOR, RH	1
	5	MD201101-0022	WIRING HARNESS, FR DOOR, LH	1
	5	MS201103-1400	WIRING HARNESS, FR DOOR, LH	1
	6	M201103-0700	WIRING HARNESS, BATTERY GROUND	1
	7	MS201103-1800	WIRING HARNESS, TRANSMISSION GROUND	1
	8	M201103-0800	WIRING HARNESS,FUEL PUMP	1
	95103-40 前排座椅总成			
	95103-40 SEAT ASSY,FR			
	1	MD201600-0014	SEAT ASSY, DRIVER	1
	1	MD201600-0015	SEAT ASSY, CO-DRIVER	1
	1	MS201086-0101-AA	SEAT ASSY, DRIVER	1
	1	MS201086-0201-AA	SEAT ASSY, CO-DRIVER	1
	2	BX097-013	LOCK, DRIVER'S SEAT	2

	95103-30 乘客三人座总成 (双排)			
	95103-30 SEAT ASSY,3RD (double cab)			
	1	MS201700-0008	SEAT ASSY, 3RD	1
	01101-10 千斤顶总成			
	01101-10 ACK ASSY			
	1	R101090-3000	JACK ASSY	1
	2	M201087-0100	HANDLE, JACK	1


	95109-20 地毯总成			
	95109-20 CARPET ASSY			
	1	MD201089-0100	CARPET, FR FLOOR	1
	1	MS201072-2200	CARPET, FR FLOOR	1
	2	Y082-040	CLIP	2
	3	MS201072-2000	CARPET, RR FLOOR	1
	95106-10 仪表台板			
	95106-10 INSTRUMENT PANEL			
	1	M201090-0101	INSTRUMENT PANEL ASSY	1
	2	M201090-0200	VENT ASSY, SIDE	2
	3	M201090-1101	BOX ASSY, GLOVE	1
	4	M201090-1001	ASHTRAY ASSY	1
	5	5306160-Y03	PANEL, CENTER CONTROL	1
	6	M201090-0204	VENT ASSY, CENTRAL, RH	1
	7	M201090-0203	VENT ASSY, CENTRAL, LH	1
	8	M201090-0701	LOWER COVER, INSTRUMENT PANEL, LH	1
	9	M201090-0500	STEERING COVER, LOWER	1
	10	M201090-0400	STEERING COVER, UPPER	1
	11	M201090-0301	COVER, STEERING LOCK	1
	12	M201090-0300	COVER, COMBINATION METER	1
	13	M201090-1400	CAP, INSTRUMENT PANEL	1
	14	M201090-1500	CAP, INSTRUMENT PANEL	1
	15	M201090-1600	CAP, INSTRUMENT PANEL	1
	16	Y036-150	FLASHER ASSY	1
	17	M201090-1011	LIGHTER, CIGARETTE	1




	95106-30 风道系统				
	95106-30 AIR PIPE				
	1	M201098-0103	PIPE ASSY, DEFROSTER, CENTER	1	1
	2	M201098-0200	PIPE ASSY, DEFROSTER, LH	1	1
	3	M201098-0500	AIR PIPE, LH	1	1
	4	M201098-0400	AIR PIPE, CENTER	1	1
	5	M201098-0600	AIR PIPE, RH	1	1
	6	M201098-0202	PIPE ASSY, DEFROSTER, RH	1	1
	74101-10 空调系统				
	74101-10 A/C SYSTEM				
	1	M201093-0100	CONDENSER ASSY, A/C	1	1
	2	MD201093-0005	HOSE, FR EVAPORATOR, INLET	1	1
	3	M201093-1000	HVAC (HEATING, VENTILATING AND A/C)	1	1
	4	MS201093-2100	HOSE ASSY, DISCHARGE, NO.1(HIGH PRESSURE)	1	1
	5	EA013-0800	COMPRESSOR ASSY	1	1
	6	MD201093-0013	CONTROLLER ASSY, A/C	1	1
	7	MD201093-0017	HOSE ASSY, SUCTION, NO.1(LOW PRESSURE)	1	1
	8	M201093-0600	HOSE, FR EVAPORATOR, OUTLET	1	1
	9	F202098-0800	FAN, CONDENSER	1	1




	84305-00 多媒体			
	84305-00 RADIO AND ANTENNA			
	1	Y041-060	ANTENNA, AM/FM	1 1
	2	MD201095-0600-AA	HORN ASSY	1 1
	3	MD201095-0013	RADIO ASSY	1 1
	4	MD201095-0400	SPEAKER ASSY	2 2
	95101-10 前挡风玻璃			
	95101-10 FR WINDSHIELD			
	1	M201060-1402	GLASS, FR WINDSHIELD	1 1
	2	M201060-1401	WEATHERSTRIP, FR WINDSHIELD	1 1







95102-50 前门玻璃及密封条				
95102-50 GLASS AND WEATHERSTRIP, FR DOOR				
1	M201057-2700	WEATHERSTRIP, FR DOOR OPNG LH	1	1
1	M201057-2800	WEATHERSTRIP, FR DOOR OPNG, RH	1	1
2	M201057-2900	GLASS RUN, FR DOOR, LH	1	1
2	M201057-3000	GLASS RUN, FR DOOR, RH	1	1
3	MD201057-2700	WEATHERSTRIP, FR DOOR FRAME, LH	1	
3	MD201057-2800	WEATHERSTRIP, FR DOOR FRAME, RH	1	
3	M201057-3100	WEATHERSTRIP, FR DOOR FRAME		2
4	6104510-Y01-AA	RR RUN, FR DOOR, LH	1	1
4	6104520-Y01-AA	RR RUN, FR DOOR, RH	1	1
6	M201057-3600	GLASS, FR DOOR WINDOW, LH	1	1
6	M201057-3700	GLASS, FR DOOR WINDOW, RH	1	1
7	M201057-3800	OUTER WEATHERSTRIP, FR DOOR, LH	1	1
7	M201057-3900	OUTER WEATHERSTRIP, FR DOOR, RH	1	1
8	Y088-210	WEATHERSTRIP, FR DOOR GLASS	4	4
9	Y088-180	CHANNEL COMP, FR DOOR WINDOW BOTTOM	2	2
10	M201057-2901	REGULATOR, FR DOOR POWER WINDOW, LH	1	1
10	M201057-3001	REGULATOR, FR DOOR POWER WINDOW, RH	1	1



[illegible]



	95110-10 前罩及附件			
	95110-10 FR HOOD AND ACCESSORIES			
	1	M201060-0700	LATCH ASSY, FR HOOD	1
	2	Y065-060	CLIP, FR HOOD SUPPORT	1
	3	M201060-0500	STAY, FR HOOD	1
	4	Y065-070	SEAT, FR HOOD SUPPORT	1
	5	Y065-090	SIDE CUSHION, FR HOOD	2
	6	M201060-0200	HINGE, FR HOOD, RH	1
	7	M201060-0100	PANEL ASSY, FR HOOD	1
	8	M201060-1500	COWL GARNISH	1
	9	M201060-1502	END COVER, COWL, RH	1
	10	Y084-200	PLASTIC CLIP	4
	11	M201060-1400	WEATHERSTRIP, FR HOOD	1
	12	M201060-1501	END COVER, COWL, LH	1
	13	M201060-1201	HANDLE, FR HOOD CABLE	1
	14	M201060-1000	HINGE, FR HOOD, LH	1
	15	M201060-1200	CABLE, FR HOOD	1
	95201-40 顶盖 (单排)			
	95201-40 ROOF PANEL (single cab)			
	1	MD201055-0001	PANEL ASSY, ROOF	1
	2	MD201055-0002	CROSSMEMBER, ROOF, FR	1
	95201-60 顶盖 (双排)			
	95201-60 ROOF PANEL (double cab)			
	1	MS201055-0001	PANEL ASSY, ROOF	1
	2	MD201055-0002	CROSSMEMBER, ROOF, FR	1




	95201-80 前翼子板			
	95201-80 FR FENDER			
	1	M201063-0100	FR FENDER, LH	1
	2	M201063-0200	FR FENDER, RH	1
	2	MD201063-0101	LINING, FR FENDER, LH	1
	2	MD201063-0102	LINING, FR FENDER, RH	1
	95301-10 车架焊接分总成			
	95301-10 BODY FRAME WELDING ASSY			
	1	M201054-1002	CROSSMEMBER, FR	1
	2	M201054-0601	CROSSMEMBER, COMPRESSION ROD	1
	63401-20 离合器拉索总成			
	63401-20 CLUTCH CABLE ASSY			
	1	M201022-0100	CABLE ASSY, CLUTCH	1



	53105-30 油门拉索			
	53105-30 ACCELERATOR CABLE			
	1	M201018-0100	CABLE ASSY, ACCELERATE	1
	22203-20 后驱动桥总成			
	22203-20 RR AXLE			
	1	MD201027-0010	RR AXLE ASSY	1
	1	MS201024-0010	RR AXLE ASSY	1
	2	MD201027-0001	OIL SEAL, RR AXLE	2
	3	MD201026-0000	FINAL DRIVE AND DIFFERENTIAL GEAR ASSY	1
	4	MD201027-0003	HOUSING COMP, RR AXLE	1
	5	MD201027-0101	HALF SHAFT, RR AXLE	2
	6	Y047-070	PLUG AND GASKET, OIL DRAIN	1
	7	MD201027-0006	RR CAP, RR AXLE HOUSING	1
	8	Y047-050	PLUG AND GASKET, OIL FILLER	1
	9	M201027-0101	PLUG, AIR	1


[illegible]


	95202-50 后围总成			
	95202-50 BACK PANEL			
	1	MD201070-0005	WEATHERSTRIP, BACK DOOR WINDOW	1 1
	2	MD201070-0004	GLASS, BACK PANEL	1 1
	3	MD201070-0002	BACK PANEL ASSY	1 1
	95107-10 前保险杠总成			
	95107-10 FR BUMPER			
	1	Y084-200	PLASTIC CLIP	4 4
	2	MD201076-0000	GRILL, FR BUMPER, UPPER	1 1
	3	CM5104-2000	CHANA EMBLEM, FR	1 1
	4	M201076-0400	BRACKET, FR BUMPER, RH	1 1
	5	M201076-0001	FR BUMPER ASSY	1 1
	6	M201076-0300	BRACKET, FR BUMPER, LH	1 1
	7	Y074-070	NUT, LICENSE PLATE	4 4
	8	M201076-0200	GRILL, FR BUMPER, LOWER	1 1
	9	M201076-0301	BRACKET, FR BUMPER, SIDE	2 2
	10	M201075-1800	MOUNTING BEAM, FR BUMPER, UPPER	1


	95109-21 顶盖内衬及遮阳板				
	95109-21 ROOF LINING,SUNVISOR				
	1	MD201078-0600	ROOF LINING	1	
	1	L1S087-0300	ROOF LINING		1
	2	M201078-0100	SUN VISOR ASSY, LH	1	1
	3	M201078-0300	SUN VISOR ASSY, RH	1	1
	4	M201078-1100	SAFETY GRASP	1	3
	95105-10 后视镜				
	95105-10 REARVIEW MIRROR				
	1	M201079-0100	MIRROR ASSY, INSIDE VIEW	1	1
	2	M201079-0011	MIRROR ASSY, OUTSIDE VIEW, LH	1	1
	2	M201079-0022	MIRROR ASSY, OUTSIDE VIEW, RH	1	1


	95110-20 前、后挡泥板			
	95110-20 MUDGUARD FLAP			
	1	M201080-0100	FR MUDGUARD, LH	1
	2	M201080-0200	FR MUDGUARD, RH	1
	3	MD201080-0300	RR MUDGUARD, LH	1
	4	MD201080-0400	RR MUDGUARD, RH	1
	95111-60 三角窗外装饰件总成			
	95111-60 OUTER GARNISH, FR TRIANGLE			
	1	M201142-0002	OUTER GARNISH, FR TRIANGLE, RH	1
	2	M201142-0001	OUTER GARNISH, FR TRIANGLE, LH	1
	84312-10 导流板			
	84312-10 WIND GUIDING COVER			
	1	M201081-0101	WIND GUIDING COVER, FR	1
	2	M201081-0102	WIND GUIDING COVER, CENTER	1
	3	M201081-0105	CONNECTING PIPE, AIR CLEANER	1



	95110-22 全车门槛总成及鼓包罩				
	95110-22 FLOOR SIDE GARNISH,WHEEL ARCH				
	1	M201083-0200	THRESHOLD TRIM, FR FLOOR, RH	1	1
	2	M201083-0100	THRESHOLD TRIM, FR FLOOR, LH	1	1
	3	M201081-0100	TRIM ASSY, A PILLAR, LH	1	1
	3	M201081-0300	TRIM ASSY, A PILLAR, RH	1	1
	4	M201083-0700	ARCH, FR WHEEL HOUSE, LH	1	1
	5	M201083-0800	ARCH, FR WHEEL HOUSE, RH	1	1
	53105-12_A 进气系统				
	53105-12_A INTAKE MANIFOLD				
	1	EA003-1300	NUT	2	2
	2	EA007-0200	STUD, INTAKE MANIFOLD	2	2
	3	EA007-0400	GASKET, INTAKE MANIFOLD	1	1
	4	EA007-0500	HOSE, WATER RETURN	1	1
	5	K014-1110	CLIP , THROTTLE	6	6
	6	EA007-0700	MANIFOLD, INTAKE	1	1
	7	CV6009-1600	GASKET, THROTTLE BODY	1	1
	8	YC010-170	SENSOR, THROTTLE	1	1
	9	EA007-1200	THROTTLE BODY ASSY	1	1
	10	YC010-210	STEPPER MOTOR	1	1
	11	EA007-1500	REINFORCE PLATE, INTAKE MANIFOLD	1	1

[illegible]

[illegible]

	53104-10_A 冷却系统			
	53104-10_A COOLING SYSTEM			
	1	EA010-2100	VENT VALVE	1
	2	EA010-2400	WATER HOSE, INTAKE MANIFOLD	1
	3	EA010-0100	HOSE, GREATER CIRCULATION	1
	4	EA010-0300	HOSE NO.2, WATER OUTLET	1
	5	EA010-0500	HOSE, EXPAND	1
	6	EA010-0700	PAD, COMPRESSOR BRACKET	1
	7	EA003-1300	NUT	2
	8	EA010-0900	WATER PUMP ASSY	1
	9	EA003-1800	CAP WITH VAVAL, THERMOSTAT	1
	10	EA010-1200	THERMOSTAT ASSY	1
	11	EA010-1300	"O" RING, WATER PIPE	1
	12	K014-1110	CLIP , THROTTLE	6
	13	EA010-1500	OUTLET HOSE, THROTTLE BODY	1
	14	EA010-1600	PIPE ASSY, WATER INLET	1
	15	EA010-1800	INLET HOSE, THROTTLE BODY	1
	16	EA010-1900	PIPE NO.1, WATER OUTLET	1

[illegible]

	53101-00_A 发动机总成			
	53101-00_A ENGINE ASSY			
	1	JL473Q-F	ENGINE ASSY	1
	53102-10_A 气缸盖及气缸盖罩			
	53102-10_A CYLINDER HEAD AND COVER			
	1	EA003-0300	TRIM COVER, ENGINE	1
	2	EA003-0400	COVER, CYLINDER HEAD	1
	3	EA003-0600	GASKET, CYLINDER HEAD COVER	1
	4	EA003-0900	BOLT, CYLINDER HEAD	10
	5	EA003-1300	NUT	2
	6	EA003-1500	SEAT, WATER OUTLET	1
	7	EA003-1600	GASKET, WATER OULET SEAT	1
	8	EA003-1700	GASKET, CYLINDER HEAD	1
	9	EA003-2001	HEAD ASSY, CYLINDER	1
	10	EA003-2300	PLUG, PRESSURE OIL	1
	11	H15001-0100	CAP, OIL FILLER	1

53102-20_A 曲轴箱



53102-20_A CRANKCASE

1	EA002-0100	PLUG	2	2
2	EA002-0200	WASHER	2	2
3	EA002-0400	BACK-END COVER, CRANKSHAFT	1	1
4	Y006-200	PIN, FLYWHEEL	2	2
5	EA002-0600	OIL SEAL, CRANKSHAFT, RR	1	1
6	EA002-0701	CRANKSHAFT CASE	1	1
7	EA002-1700	PLATE, OIL PAN BAFFLE	1	1
8	EA002-2000	STUD M6×49.5	4	4
9	EA002-2100	BOLT	10	10
10	EA002-2510	THRUST WASHER, CRANKSHAFT	2	2
11	YJ060-0903	BEARING GROUP, CRANKSHAFT	1 set	1 set
12	EA002-2600	FUEL NOZZLE, TIMING CHAIN	1	1

53106-10_A 排气系统



53106-10_A EXHAUST SYSTEM



1	EA006-0100	INSULATOR, EXHAUST MANIFOLD, UPPER	1	1
2	EA006-0200	GASKET, EXHAUST MANIFOLD	1	1
3	EA006-0300	MANIFOLD, EXHAUST	1	1
4	EA006-0400	BOLT, EXHAUST MANIFOLD	3	3
5	EA006-0500	NUT M10	1	1
6	EA006-0600	INSULATOR, EXHAUST MANIFOLD, LOWER	1	1


	84315-90_A 发动机电线束总成及附件			
	84315-90_A HARNESS ASSY, ENGINE AND ACCESSORIES			
	1	EA013-0203	WIRING HARNESS ASSY, ENGINE	1
	53102-50_A 正时系统及前端轮系			
	53102-50_A TIMING SYSTEM			
	1	EA011-1200	HYDRAULIC TENSIONER	1
	2	EA011-1300	TENSION RAIL, CHAIN	1
	3	H16007-1800	BOLT, TIMEING CHAIN GUIDE	1
	4	EA011-0100	CHAIN, TIMING	1
	5	EA011-0200	GUIDE RAIL, CHAIN	1
	6	EA011-0400	PULLEY, CRANKSHAFT TIMING BELT	1
	7	EA011-0500	BELT, GENERATOR	1
	8	EA011-0600	PULLEY, CRANKSHAFT	1
	9	EA011-0700	1# BOLT, CRANKSHAFT PULLEY	1
	10	EA011-0800	BELT, COMPRESSOR	1
	11	EA011-1000	PULLEY, WATER PUMP	1



53101-20_A 发动机悬挂				
53101-20_A ENGINE BRACKET				
1	EA014-0100	BOLT, RR ENGINE SUSPENSION	2	2
2	EA014-0200	BRACKET ASSY, ENGINE MOUNTING, RR	1	1
3	EA006-0500	NUT M10	1	1
4	EA014-0402	BRACKET ASSY, ENGINE MOUNTING, LH	1	1
5	EA014-0700	BOLT M10×40	5	5
6	EA014-0401	BRACKET ASSY, ENGINE MOUNTING, RH	1	1
7	EA014-1100	BOLT M10×70	4	4
8	EA014-1200	BOLT M10×50	1	1


63402-10_A 离合器				
63402-10_A CLUTCH				
1	EA015-0100	COVER ASSY, CLUTCH	1	1
2	EA015-0200	COMBINATION BOLT, CLUTCH COVER	6	6
3	EA015-0300	DISC ASSY, CLUTCH	1	1

	53105-20_A 空气滤清器			
	53105-20_A AIR CLEANER			
	1	M201017-0300	FILTER, AIR	1 1
	2	M201017-0800	INLET PIPE, AIR CLEANER	1 1
	3	M201017-0200	AIR CLEANER ASSY	1 1
	4	M201017-0500	HOSE, AIR CLEANER OUTLET	1 1
	53109-10_A 起动机及配件			
	53109-10_A MOTOR ASSY , STARTING AND ACCESSORIES			
	1	EA017-0500	MOTOR ASSY, STARTING	1 1
	2	EA017-0501	HEAT INSULATION, STARTING MOTOR	1 1

	53106-20_A 消声器			
	53106-20_A PIPE ASSY,MUFFLER			
	1	M201016-0200	TWC	1
	2	MD201016-0100	MUFFLER ASSY	1
	63401-00_A 变速箱及附件			
	63401-00_A TRANSMISSION ASSY AND ACCESSORIES			
	1	YJ020-009	TRANSMISSION ASSY	1
	2	EA016-0200	BOLT	4
	3	EA016-0400	PLATE, TRANSMISSION DUSTPROOF	1
	4	EA006-0500	NUT M10	1
	5	EA016-0600	UPPER PLATE, CLUTCH	1
	6	EA014-1100	BOLT M10×70	4

[illegible]

	63403-60_A 前后箱			
	63403-60_A TRANSMISSION CASE			
	1	YJ023-0101	RR CASE, TRANSMISSION	1 1
	2	Y020-510	BOLT, REVERSE SHAFT	1 1
	3	YJ023-0105	FR CASE, TRANSMISSION	1 1
	4	YJ020-617	DOUBLE END STUD, TRANSMISSION NO.2	2 2
	5	YJ023-0707	LOCK BOLT, GEAR SHIFT	4 4
	63402-20_A 变速器离合器拨叉组件			
	63402-20_A CLUTCH FORK			
	1	Y019-050	BRACKET, FORK	1 1
	2	YJ023-0708	CIRCLIP, CLUTCH FORK	1 1
	3	Y019-090	RELEASE BEARING	1 1
	4	Y019-070	CIRCLIP	1 1
	5	YJ023-0508	FORK, CLUTCH	1 1
	6	Y019-100	SPRING, FORK RETURN	1 1



63403-10_A 变速器输入轴组件				
63403-10_A INPUT SHAFT				
1	YA020-230	CIRCLIP, OUTPUT SHAFT RR BEARING	1	1
2	YJ023-0406	SYNCHRONIZER ASSY, HIGH SPEED	1	1
3	YJ023-0405	RING, SYNCHRONIZER, HIGH SPEED	1	1
4	YJ023-0701	GEAR ASSY, INPUT SHAFT 3RD	1	1
5	CV6020-2100	NEEDLE BEARING, INPUT SHAFT 5TH	1	1
6	Y020-380	RING, SYNCHRONIZER, HIGH SPEED	1	1
7	CV6020-1200	CIRCLIP, HIGH SPEED SYNCHRONIZER	1	1
8	PA025-1006	SYNCHRONIZER ASSY, HIGH SPEED	1	1
9	Y020-380	RING, SYNCHRONIZER, HIGH SPEED	1	1
10	YJ023-0702	GEAR, INPUT SHAFT, 5TH SPEED	1	1
11	Y020-070	NEEDLE BEARING, INPUT SHAFT 3RD	1	1
12	YJ023-0703	SHAFT, INPUT	1	1
13	YJ023-0504	RING, INPUT SHAFT	1	1
14	YJ023-0401	BEARING, INPUT SHAFT	1	1
15	YA020-230	CIRCLIP, OUTPUT SHAFT RR BEARING	1	1

63403-20_A 变速器中间轴组件



63403-20_A COUNTERSHAFT



1	YA020-230	CIRCLIP, OUTPUT SHAFT RR BEARING	1	1
2	YJ020-502	BEARING, FR CASE, RR	1	1
3	PA025-1016	GASKET, COUNTERSHAFT FR BEARING	1	1
4	YJ023-0303	GEAR, COUNTERSHAFT, 1ST SPEED	1	1
5	Y020-300	NEEDLE BEARING, COUNTERSHAFT 1ST	1	1
6	CV6020-4000	RING, SYNCHRONIZER 1ST SPEED	1	1
7	CV6020-3500	CIRCLIP, SYNCHRONIZER LOW SPEED	1	1
8	Y020-330	SYNCHRONIZER ASSY, LOW SPEED	1	1
9	Y020-370	RING, SYNCHRONIZER 2ND SPEED	1	1
10	YJ023-0304	GEAR, COUNTERSHAFT, 2ND SPEED	1	1
11	Y020-300	NEEDLE BEARING, COUNTERSHAFT 1ST	1	1
12	YJ023-0704	COUNTERSHAFT	1	1
13	YJ020-502	BEARING, FR CASE, RR	1	1

63403-90_A 变速器倒档齿轮轴组件

63403-90_A SHAFT, REVERSE GEAR

1	Y020-500	GEAR, REVERSE IDLE	1	1
2	PA025-1026	WASHER, REVERSE IDLE GEAR SHAFT	1	1
3	PA025-1025	SHAFT, REVERSE IDLE GEAR	1	1

	63403-80_A 变速器主轴组件				
	63403-80_A OUTPUT SHAFT				
	1	YJ023-0403	NEEDLE BEARING, INPUT SHAFT	1	1
	2	YJ023-0404	SPRING, SYNCHRONIZER, HIGH SPEED	1	1
	3	YJ023-0405	RING, SYNCHRONIZER, HIGH SPEED	1	1
	4	YJ023-0202	OUTPUT SHAFT	1	1
	5	YJ023-407	BEARING, MAINSHAFT, FR	1	1
	6	YJ023-0305	GEAR, OUTPUT SHAFT	1	1
	7	YJ023-0401	BEARING, INPUT SHAFT	1	1
	8	YA020-230	CIRCLIP, OUTPUT SHAFT RR BEARING	1	1
	9	YJ023-0502	GEAR, SPEED METER DRIVE	1	1
	53102-31_A 曲柄连杆机构				
	53102-31_A CRANKSHAFTS AND CONNECTING RODS SYSTEM				
	1	EA004-0100	PISTON RING SET	1 set	1 set
	2	EA004-0410	PISTON PIN SET	1 set	1 set
	3	EA004-0600	BOLT, FLYWHEEL	6	6
	4	EA004-0700	FLYWHEEL ASSY	1	1
	5	EA004-0800	CRANKSHAFT	1	1
	6	EA004-0900	BEARING COMP, CONNECTING	1 set	1 set
	7	EA004-1100	BOLT, CONNECTING ROD	8	8
	8	EA004-1200	LOCATING PIN, SIGNAL PLATE	1	1
	9	EA004-1300	BOLT, SIGNAL PLATE	2	2
	10	EA004-1400	SPEED SIGNAL PLATE, CRANKSHAFT	1	1
	10	EA14004-1400	SPEED SIGNAL PLATE, CRANKSHAFT	1	1
	11	EA004-1197	ROD ASSY, CONNECTING	4	4
	12	EA004-1800	CHUCK, PISTON PIN	8	8
	13	EA004-1900	PISTON SET	4	4

	53102-40_A 配气机构				
	53102-40_A VALVE SYSTEM				
	1	EA006-0101	CAMSHAFT ASSY, INTAKE	1	1
	2	EA005-0200	TAPPET, VAVAL (308)	16	16
	3	EA005-0300	CAMSHAFT ASSY, EXHAUST	1	1
	4	EA005-0410	RETAINER, VALVE SPRING	1 set	1 set
	5	EA005-0510	COTTER, VALVE	1 set	1 set
	6	EA005-0610	SPRING, VALVE	1 set	1 set
	7	EA005-0710	SEAT, VALVE SPRING	1 set	1 set
	8	EA005-0810	SEAL, VALVE STEM	1 set	1 set
	9	EA005-0910	VALVE , EXHAUST	1 set	1 set
	10	EA005-1010	VALVE, INTAKE	1 set	1 set
	63403-50_A 变速器换档机构				
	63403-50_A GEARSHIFT LEVER				
	1	YJ023-0209	FORK, GEAR SHIFT LEVER, 1ST AND 2ND SPEED	1	1
	2	YJ023-0509	GEAR SHIFT LEVER, 1ST AND 2ND SPEED	1	1
	3	YJ023-0510	GEAR SHIFT LEVER, 3RD AND 4TH SPEED	1	1
	4	YJ023-0208	LEVER, GEAR SHIFT, 5TH SPEED	1	1
	5	YJ023-0204	ARM, GEAR SHIFT	1	1

	63403-61_A 变速器延伸箱			
	63403-61_A EXTENSION CASE			
	1	YA021-200	PLUG SCREW, OIL INLET	11
	2	YJ023-0103	EXTENSION CASE, TRANSMISSION	11
	3	YA021-210	PLUG, OIL DRAIN	11
	4	YA021-020	KNOCK PIN	22
	5	YJ020-615	GEAR, SPEED METER DRIVEN	11
	6	YJ023-0505	OIL SEAL, TRANSMISSION RR	11