

See Fig. 1 for a full view of the Caterpillar 3176B and 3406E engine wiring diagram, including cab and engine switch circuits. For partial (detailed) views of the Caterpillar 3176B and 3406E engine wiring diagram, see Fig. 2, see Fig. 3 and see Fig. 4. See Fig. 5 for the Caterpillar 3176B and 3406E engine brake wiring diagram.




Fig. 1, Caterpillar 3176B and 3406E Wiring Diagram (cab and engine switch circuits)

Specifications

Caterpillar 3176B and 3406E Wiring




Fig. 2, Caterpillar 3176B and 3406E Wiring Diagram (detail)




Fig. 3, Caterpillar 3176B and 3406E Wiring Diagram (detail)

Specifications




Fig. 4, Caterpillar 3176B and 3406E Wiring Diagram (detail)




Fig. 5, Caterpillar 3176B and 3406E Engine Brake Wiring Diagram