

Parts Catalogue

T224NH




Important tips of Parts Catalogue

We thank you for your purchasing our product, manufactured under strict quality control, by gathering plenty of experiences and new technology, designed for a comfort and pleasant work.

1. Part Composition

This catalogue deals with engine and chassis.

Detailed classifications are listed in the following page.



2. For locating parts easily, Please Note:


A. If you know the assembly where the part is used.

- Refer to the relevant figure from the identifying group symbol illustration,
- Locate the relevant chapter
- Refer to the particular chapter desired.

3. For ordering parts

To obtain spare parts please contact your nearest dealer and give him the details listed below.

- ① Tractor Model : Tractor T254NH
- ② Tractor Serial Number : H00001
- ③ Part Number : 11111010010
- ④ Description : COUPLING , PTO
- ⑤ Quantity required: 1



4. For ordering PARTS CATALOGUE

This is Priced item and one is to order the same on part No. 11119120030

This supersedes all our editions.

Note) When replacing parts, please use original spare parts to be sure of the performance and the longer life of the product

※ The information in this catalogue may at any time be modified without a prior notice for the improvement of performance, please consult our spare parts dept. for the detailed inquiry.

5. How to use parts catalogue




FIG 601 2	3 CYLINDER CASE	P1 4	Year 5 2014	
				
NOTE 13				

FIG 601 ② T254NH		③ CYLINDER CASE			P1 ④	Year ⑤ 2014	 ①	
KEY NO.	PART NO.	DESCRIPTION	SPEC.	QTY.	REPAIR	EFFECTIVE DATE	REMARKS	
601 001	11105010011M	CASE , CYLINDER		1				
601 002	V5201010018	PIN , PARALLEL/A	10X20(A)	2				
601 003	V2173610030	BOLT , HEX/S	M 10X30	8				
601 004	V2173610055	BOLT , HEX/S	M 10X55	1				
601 005	V2173610065	BOLT , HEX/S	M 10X65	1				
⑥ 006	⑦ 190 ⑧ 110	CAP ASSY , OIL ⑧	⑨	⑩	⑪	⑫	⑭	
NOTE ⑬								

① Group Indication : Indicate the relevant location of the part with a symbol illustration.

② Figure Number: Indicate the relevant section of the machine with a figure number.

③ Section Name : Indicate the section name of the machine

④ Section Page : Page number of the section in this catalogue.

⑤ Date : Show the Year of the section made or updated

⑥ Key number : Indicating number of each parts in the illustration.

⑦ Part Number : Unique part number maintained in our system

The part number starting with V or M means it is TYM s standard part

The alphabet at the end of part number means the status of material or the color of paint

Legend : M:Machining, DG:Dark Gray, BR:Bright Red, SW:Summer White,
PB:Pure Black, GB:Glossy Black, SR:Super Red, MS:Metallic Silver
DD:Heat proof Black, TY: Tangerine Yellow etc.

⑧ Description : Description of a part, Abbreviation means as follows.

- Indicate the mixture condition of a part

ASSY : Assembly with a mixture of several parts, so can be broke up retaining their original form

COMP : Assembly with a mixture of several parts, but can not be broke up retaining their original form

SUB : mean the same as ASSY but used in lower level in aid.

SET : Part consist of ASSY, COMP, and part(s) as a group

- Indicate the location of a part

LH: Left, RH: Right, FR: Front, RR: Rear, UPR: Upper, LOW: Lower

⑨ Type : Type of the standard items like bolt or nut

⑩ Quantity : Total quantity of the part referred to in the page.

Symbol below indicate options. So, show the quantity of each option.

Note) AR means as requested quantity.

⑪ Repair Parts consumption frequency class: indicate the level of a part in aid of stocking spares, anticipating the service requirements.

A :Fast moving part(frequently required)

B :Medium moving part (sometimes required)

C :Slow moving part(rarely required)

⑫ Modification :


Year/Month~ : From which the change starts

~ Year/Month : To which the part installed


⑬ Notes : explain some reference data

⑭ Remark : indicate reference data or abbreviation in the content.


ENGINEERING GROUP INDEX




1 ENGINE




6 HYDRAULICS & 3-POINT LINK




2 ENGINE ACCESSORIES & CONTROL




7 SHEET METAL & ROPS




3 CLUTCH, BRAKE, STEERING




8 ELECTRICALS & HARNESS



4 TRANSMISSION & REAR AXLE



9 LABEL, TOOLS



5 FRONT AXLE, SUPPORTER & DRIVE SHAFT

067 020	12305180020
077 036	12403160020
036 005	13022250030
037 010	13022250131
041 005	13022250232
046 002	13022250333

10 NUMERICAL INDEX

CONTENTS

ENGINE

1

ENGINE

FIG 101 CYLINDER BLOCK	04
FIG 102 GEAR HOUSING	06
FIG 103 FLYWHEEL HOUSING& OIL SUMP.....	08
FIG 104 CYLINDER HEAD & BONNET.....	10
FIG 105 EXHAUST MANIFOLD	12
FIG 106 CAMSHAFT & DRIVING GEAR	14
FIG 107 CRANKSHAFT & PISTON	16
FIG 108 LUB. OIL SYSTEM	18
FIG 109 COOLING WATER SYSTEM	20
FIG 110 FUEL INJECTION PUMP	22
FIG 111 GOVERNOR	24
FIG 112 FUEL INJECTION VALVE	26
FIG 113 FUEL PIPE.....	28
FIG 114 STARTING MOTOR	30
FIG 115 GENERATOR	32
FIG 116 ACCESSORY.....	34

CHASSIS

2 ENGINE ACCESSORIES & CONTROL

FIG 201 AIR CLEANER	40
FIG 202 RADIATOR	42
FIG 203 MUFFLER	44
FIG 204 FUEL TANK & FUEL LINE	46
FIG 205 ACCELERATOR	48
FIG 206 FUEL FILTER	50
FIG 207 ENGINE MOUNTING	52

3 BRAKE,STEERING

FIG 302 BRAKE PEDAL & LINKAGE	58
FIG 303 SPEED CONTROL	60
FIG 304 DASH COVER	62
FIG 305 STEERING VALVE	64
FIG 306 STEERING CYLINDER	66
FIG 307 TIRE	68

4 TRANSMISSION & REAR AXLE

FIG 401 INPUT SHAFT	74
FIG 402 HST	76
FIG 403 PTO CLUTCH SUB& RANGE GEAR SUB	78
FIG 404 SPIRAL BEVEL PINION & 4WD SHAFT SUB	80
FIG 405 INPUT METAL	82
FIG 406 P.T.O DRIVE SHAFT	84
FIG 407 MID P.T.O IDLE GEAR & MID P.T.O SUB	86
FIG 408 DIFF LOCK	88
FIG 409 REAR TRANSMISSION CASE	90
FIG 410 REAR AXLE HOUSING	92

FIG 411 RANGE SHIFT LEVER	94
FIG 412 P.T.O CHANGE LEVER	96
FIG 413 GEAR PUMP & PUMP IDLE GEAR SUB	98

5 FRONT AXLE

FIG 501 FRONT DRIVE SHAFT	104
FIG 502 FRONT DIFFERENTIAL GEAR	106
FIG 503 FRONT AXLE HOUSING	108
FIG 504 FRONT GEAR CASE (1)	110
FIG 505 FRONT GEAR CASE (2)	112

6 HYDRAULICS & 3-POINT LINK

FIG 601 CYLINDER CASE	118
FIG 602 LIFT ARM	120
FIG 603 FLOW CONTROL VALVE	122
FIG 604 MAIN CONTROL VALVE	124
FIG 605 HYDRAULIC SUB	126
FIG 606 HITCH & 3-POINT LINKAGE	130
FIG 607 MID MOWER.....	130

7 SHEET METAL & R.O.P.S

FIG 701 BONNET	136
FIG 702 FLOOR	138
FIG 703 SEAT	140
FIG 704 ROPS	142
FIG 705 LEVER COVER & FENDER	144

8 ELECTRICALS & HARNESS

FIG 801 BATTERY MOUNTING	150
FIG 802 INSTRUMENT PANEL.....	152
FIG 803 HARNESS(1)	154
FIG 804 HARNESS(2)	156

9 LABEL,TOOLS

FIG 901 TOOL & ACCESSORY	162
FIG 902 LABEL	164
FIG 905 AUXILIARY VALVE KIT(OPTION)	000

10 NUMERICAL INDEX

ENGINE	169
CHASSIS	172

ENGINE

E

1

ENGINE

FIG 101 CYLINDER BLOCK	04
FIG 102 GEAR HOUSING	06
FIG 103 MOUNTING FLANGE & OIL SUMP.....	08
FIG 104 CYLINDER HEAD & BONNET.....	10
FIG 105 EXHAUST MANIFOLD	12
FIG 106 CAMSHAFT & DRIVING GEAR	14
FIG 107 CRANKSHAFT & PISTON	16
FIG 108 LUB. OIL SYSTEM	18
FIG 109 COOLING WATER SYSTEM	20
FIG 110 FUEL INJECTION PUMP	22
FIG 111 GOVERNOR	24
FIG 112 FUEL INJECTION VALVE	26
FIG 113 FUEL PIPE.....	28
FIG 114 STARTING MOTOR	30
FIG 115 GENERATOR	32
FIG 116 ACCESSORY.....	34

CHASSIS

2 ENGINE ACCESSORIES & CONTROL

FIG 201 AIR CLEANER	40
FIG 202 RADIATOR	42
FIG 203 MUFFLER	44
FIG 204 FUEL TANK & FUEL LINE	46
FIG 205 ACCELERATOR	48
FIG 206 FUEL FILTER	50
FIG 207 ENGINE MOUNTING	52

3

BRAKE,STEERING

FIG 302 BRAKE PEDAL & LINKAGE -----	58
FIG 303 SPEED CONTROL -----	60
FIG 304 DASH COVER -----	62
FIG 305 STEERING VALVE -----	64
FIG 306 STEERING CYLINDER -----	66
FIG 307 TIRE -----	68

4

TRANSMISSION & REAR AXLE

FIG 401 INPUT SHAFT	74
FIG 402 HST	76
FIG 403 PTO CLUTCH SUB& RANGE GEAR SUB	78
FIG 404 SPIRAL BEVEL PINION & 4WD SHAFT SUB	80
FIG 405 INPUT METAL	82
FIG 406 P.T.O DRIVE SHAFT	84
FIG 407 MID P.T.O IDLE GEAR & MID P.T.O SUB	86
FIG 408 DIFF LOCK	88
FIG 409 REAR TRANSMISSION CASE	90
FIG 410 REAR AXLE HOUSING	92
FIG 411 RANGE SHIFT LEVER	94
FIG 412 P.T.O CHANGE LEVER	96
FIG 413 GEAR PUMP & PUMP IDLE GEAR SUB	98

5

FRONT AXLE

FIG 501 FRONT DRIVE SHAFT	104
FIG 502 FRONT DIFFERENTIAL GEAR	106
FIG 503 FRONT AXLE HOUSING	108
FIG 504 FRONT GEAR CASE (1)	110
FIG 505 FRONT GEAR CASE (2)	112

6 HYDRAULICS & 3-POINT LINK

FIG 601 CYLINDER CASE	118
FIG 602 LIFT ARM	120
FIG 603 FLOW CONTROL VALVE	122
FIG 604 MAIN CONTROL VALVE	124
FIG 605 HYDRAULIC SUB	126
FIG 606 HITCH & 3-POINT LINKAGE	130
FIG 607 MID MOWER.....	130

7

SHEET METAL & R.O.P.S

FIG 701 BONNET	136
FIG 702 FLOOR	138
FIG 703 SEAT	140
FIG 704 ROPS	142
FIG 705 LEVER COVER & FENDER	144

8

ELECTRICALS & HARNESS

FIG 801 BATTERY MOUNTING	150
FIG 802 INSTRUMENT PANEL.....	152
FIG 803 HARNESS(1)	154
FIG 804 HARNESS(2)	156

9 WEIGHT,LABEL,TOOLS

FIG 901 TOOL & ACCESSORY	162
FIG 902 LABEL	164
FIG 905 AUXILIARY VALVE KIT(OPTION)	000

10 NUMERICAL INDEX

ENGINE	-----	169
CHASSIS	-----	172


FIG 101

CYLINDER BLOCK


P1

Year

2019



T224



NOTE


FIG 102

GEAR HOUSING


P1

Year

2019



T224



NOTE

FIG 103



T224

FLYWHEEL HOUSING & OIL SUMP

P1

Year

2019



NOTE


FIG 104

CYLINDER HEAD & BONNET


P1

Year

2019



T224



NOTE


FIG 105

EXHAUST MANIFOLD


P1

Year

2019



T224



NOTE


FIG 106

CAMSHAFT & DRIVING GEAR


P1

Year

2019



T224



NOTE


FIG 108

LUB. OIL SYSTEM


P1

Year

2019



T224



NOTE


FIG 109

COOLING WATER SYSTEM


P1

Year

2019



T224



NOTE


FIG 110

FUEL INJECTION PUMP


P1

Year

2019



T224



NOTE

FIG 111



T224

GOVERNOR

P1

Year

2019



NOTE



FIG 112

FUEL INJECTION VALVE

P1

Year

2019



NOTE

FIG 113



T224

FUEL PIPE

P1

Year

2019



NOTE

FIG 114



T224

STARTING MOTOR

P1

Year

2019



NOTE


FIG 115

GENERATOR



P1

Year

2019



T224



NOTE

FIG 116



T224

ACCESSORY

P1

Year

2019



NOTE

FIG 201



T224

AIR CLEANER

P1

YEAR

2019



NOTE


FIG 202

RADIATOR

P1

YEAR

2019



T224




FIG.207-01

NOTE


FIG 203

MUFFLER


P1

YEAR

2019



T224



NOTE





FIG 205

ACCELERATOR




P2

YEAR

2019



T224



NOTE

FIG 206



T224

FUEL FILTER




P1

YEAR

2019



Engine



NOTE


FIG 207

ENGINE MOUNTING


P1

YEAR

2019



T224



NOTE

FIG 302

BRAKE PEDAL & LINKAGE


P1

YEAR

2019



T224



NOTE

FIG 303

SPEED CONTROL


P1

YEAR

2019



T224



NOTE

FIG 304

DASH COVER


P1

YEAR




2019



T224



NOTE



NOTE	
------	--

FIG 306

STEERING CYLINDER

P1


YEAR

2019



T224

FIG.504-01



NOTE




FIG 307B

TIRE(R3)

P1


YEAR

2019



T224

R3



NOTE

FIG 307C

TIRE(R4)

P1


YEAR

2019



T224

R4



NOTE

FIG 401



T224

INPUT SHAFT

P1

YEAR

2019



NOTE

FIG 402



T224

HST

P1

YEAR

2019



NOTE

FIG 403



T224

PTO CLUTCH SUB& RANGE GEAR SUB

P1

YEAR

2019



NOTE

FIG 404



T224

SPIRAL BEVEL PINION & 4WD SHAFT SUB

P1

YEAR

2019



NOTE

INPUT METAL

YEAR

FIG.404-07

82





FIG 407



T224

MID P.T.O IDLE GEAR & MID P.T.O SUB

P1

YEAR

2019



NOTE

FIG 408



T224

DIFF LOCK

P1

YEAR

2019



NOTE

FIG 409

REAR TRANSMISSION CASE

T224

P1

YEAR

2019





FIG.405-01

NOTE


FIG 410

REAR AXLE HOUSING


P1

YEAR

2019



T224



NOTE

FIG 411



T224

RANGE SHIFT LEVER

P1

YEAR

2019



NOTE


FIG 412

P.T.O CHANGE LEVER


P1

YEAR

2019



T224



NOTE

FIG 413



T224

GEAR PUMP & PUMP IDLE
GEAR SUB

P1

YEAR

2019



NOTE




FIG 502



FRONT DIFFERENTIAL GEAR

T224

P1

YEAR

2019



NOTE


FIG 503

FRONT AXLE HOUSING

P1


YEAR

2019



T224

FIG.207-01



NOTE


FIG 504

FRONT GEAR CASE (1)


P1

YEAR

2019



T224



NOTE


FIG 505

FRONT GEAR CASE (2)


P1

YEAR

2019



T224



NOTE


FIG 601

CYLINDER CASE


P1

YEAR

2019



T224



NOTE


FIG 602

LIFT ARM


P1

YEAR

2019



T224



NOTE


FIG 603

FLOW CONTROL VALVE


P1

YEAR

2019



T224



NOTE


FIG 604

MAIN CONTROL VALVE


P1

YEAR

2019



T224



NOTE


FIG 605

HYDRAULIC SUB


P1

YEAR

2019



T224



NOTE


FIG 606

HITCH & 3-POINT LINKAGE


P1

YEAR

2019



T224



NOTE


FIG 607

MID MOWER


P1

YEAR

2019



T224



NOTE


FIG 701

BONNET


P1

YEAR

2019



T224



NOTE


FIG 702

FLOOR


P1

YEAR

2019



T224



NOTE

FIG 703



T224

SEAT

P1

YEAR

2019



NOTE


FIG 704

ROPS


P1

YEAR

2019



T224



NOTE


FIG 705

LEVER COVER & FENDER


P1

YEAR

2019



T224



NOTE

FIG 706

REARVIEW MIRRORS


P1

YEAR

2019



T224



NOTE

CABIN OPTION

FIG 707

FRONT GLASS


P1

YEAR

2019



T224



NOTE

CABIN OPTION

FIG 708

DOOR-LH


P1

YEAR

2019



T224



NOTE

CABIN OPTION

FIG 709

DOOR-RH


P1

YEAR

2019



T224



NOTE

CABIN OPTION

FIG 710

REAR GLASS


P1

YEAR

2019



T224



NOTE

CABIN OPTION

FIG 711

ROOF


P1

YEAR

2019



T224



NOTE

CABIN OPTION

FIG 712

WORKING LAMP & FENDER COVER


P1

YEAR

2019



T224



NOTE

CABIN OPTION

FIG 713

HEATER SUB


P1

YEAR

2019



T224



NOTE

CABIN OPTION

FIG 714

CABIN HARNESS


P1

YEAR

2019



T224



NOTE

CABIN OPTION

FIG 715

REAR WIPER KIT(OPTION)


P1

YEAR

2019



T224



NOTE

CABIN OPTION


FIG 802

INSTRUMENT PANEL


P1

YEAR

2019



T224



NOTE


FIG 803

HARNESS(1)


P1

YEAR

2019



T224



NOTE


FIG 804

HARNESS(2)


P1

YEAR

2019



T224



NOTE


FIG 901 T224	https://truckmanualshub.com/ TOOL & ACCESSORY	P1	YEAR 2019	
1  2  3 				
NOTE				

FIG 902


T224

LABEL

P1

YEAR

2019



2



3



4



5



7



8



18

T224


1



19



20



21



25

26

27



22



23



24



9



10



11



13



12



16



14



15



17



32



28



29

NOTE

FIG 905

AUXILIARY VALVE KIT(OPTION)


P1

YEAR

2019



T224



NOTE