




ISEKI

Parts Catalogue



RIDING MOWER

SF224F
SF235F

SF224F-BGRE42,BGZRE42,GWZRE42

SF235F-BGRE42,BGZRE42,GWZRE42

1832-097-100-00

Printed in Japan October,2017

Directions for use of Parts Catalogue

1. Applicable model of machines

All component and option parts used for SFH224F/SF235F riding mower are listed in this parts catalogue.

1) MODEL TYPE

- B..... BLOWER CASE
- G..... WITH EXTRA SPECIFICATIONS
FOR LOCAL HOMOLOGATION
- R..... ROPS
- Z..... WITH SEAT
- W..... WITH WEIGHT
- 2..... TURF TIRE

2) AREA CODE

- E4..... EUROPE

2. Details of the Structure Table of Model

***** Structure Table of Model *****

MODEL	S	S									
	F	F									
M	3	3	3	3							
O	1	1	1	1							
D	0	0	0	0							
E	X	X	X	X							
L	W	W	W	W							
	E	E	E	E							
	4	4	4	4							
FIG.											
1	***	***									
2	*	*									
3		***									
4	***										
5		***									
6	***	***									
7	***	***									
8	*	*									
9											

①
③
②

- ① FIG. : Parts structure of the machine is classified by its functions.
FIG. number corresponds to the number written at the top of the parts illustration.
- ② Model : Shows the name of the model.
- ③ Structure Table : Shows which functions are originally equipped or can be equipped afterwards for each machines
- `\*` Standard Parts
- `T` Optional Parts
- `R` Repair Parts (parts which can only be used for repairs)

3. Explanation for head paragraph

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL						I T C	C O L	G R P	REMARKS
				SSM48M	SSM48F	SSM48G	SRM48M	SRM48F	SRM48G				
1	8595-211-001-20	CASE/UPPER	*	1									
1A	8657-201-081-00	CASE/UPPER	*	1			1						
2	8595-211-002-10	CASE/LOWER	*	1			1						
3	V523-100-801-80	PIN	*	2			2						
4	V211-260-803-00	BOLT, SEMS	*	6			6						
			*	2			2						
			*	2			2						
			*	2			2						
			*	1			1						

- ① KEY shows the location of parts diagramed in the illustration.
- ② Parts numbers begin with `V` and `W` are standard parts of the market.
- ③ `LH` and `RH` on the parts name are described against the moving direction of the machine or are described on the condition how to install parts on the machines.
- ④ SPC : The following symbol classifies parts to be used for machines.
- `\*` means standard parts.
- `T` shows that the parts can be installed as optional parts.
- `R` shows that the parts can be used as applicable parts to replace originally equipped parts.
- ⑤ Upper column : QTY shows the number of parts to be used for one unit of machine.

`M` is indicated for parts supplied by a meter long.

`l` is indicated for parts supplied by liter.

`AR` is indicated for parts need to be adjusted or regulated.

Lower column : serial number

—229 means serial number up to 229.

230— means serial number 230 and after.

⑥ ITC : Interchangeability

`1`...OLD ← NEW

New parts can be used in place of the old parts.

`2`...OLD → NEW

Old parts can be used in place of the new parts.

`3`...OLD →← NEW

Old parts and new parts can not be replaced each other.

⑦ COL : Color code

Color is signified with color code number for colored parts.

Please see the color list shown in the next page.

⑧ GRP : Parts shown in this column can be replaced by SET parts.

Example : Parts marked ① can be replaced by parts marked ②, and
④ for ③, so the rest follow in the same alphabetical
order.

⑨ Remarks

* Other maker's part code number is shown in this column.

* When Fig. No. is shown in the Remark column of SET parts or ASSY parts,
each of their component parts are listed in said Fig. No.

4. Color :

The following colors are used color parts.

COLOR CODE	COLOR	SPRAY TYPE PARTS CODE	PAINTS 4K DRUM PARTS CODE	PAINTS 16K DRUM PARTS CODE
4 L	NEO BLUE	1300-985-001-20	1300-985-003-00	1300-985-004-00
6 G	SUMMER WHITE	1300-958-001-20	1300-958-003-00	1300-958-004-00
7 F	MIRROR BLACK	1300-954-001-20	1300-954-003-00	1300-954-004-00

NOTE : Color code is signified only for the parts assigned by the maker as color parts.

5. Serial Numbers :

- 1) For engines serial number is stamped on CYLINDER BLOCK ASSY.

Please see Fig. No. 6-1.

- 2) For chassies serial number is shown on the LABEL.


Please see



6. Parts Order

- 1) When you order parts, please make sure of correct numbers.
- 2) When substitute parts is available, the part number ordered will be automatically turned to a new part number.
- 3) Please be sure to use "ISEKI GENUINE PARTS" .

Any other similar parts other than ISEKI parts when used may cause a trouble that makes us unable to repair or guarantee the warrant.



Contents

SF224F

ENGINE(E3112-G08)

SHORT BLOCK ENGIASSY.....	Fig. 1
CYLINDER HEAD.....	Fig. 2
CYLINDER HEAD COVER.....	Fig. 3
INLET MANIFOLD.....	Fig. 4
EXHAUST MANIFOLD.....	Fig. 5
CYLINDER BLOCK.....	Fig. 6
BEARING/UNDER SIZE (OPTION).....	Fig. 7
OIL PAN.....	Fig. 8
REAR PLATE.....	Fig. 9
TIMING GEAR CASE.....	Fig. 10
HANGER.....	Fig. 11
VALVE.....	Fig. 12
CAM SHAFT.....	Fig. 13
PISTON.....	Fig. 14
PISTON/OVER SIZE (OPTION).....	Fig. 15
CRANK SHAFT.....	Fig. 16
OIL PUMP.....	Fig. 17
WATER PUMP.....	Fig. 18
COOLING FAN.....	Fig. 19
INJECTION NOZZLE.....	Fig. 20
INJECTION PUMP.....	Fig. 21
FUEL PIPE.....	Fig. 22
ADAPTER.....	Fig. 23
ELECTRIC (1).....	Fig. 24

ELECTRIC (2).....	Fig. 25
REPAIR PARTS(OPTION).....	Fig. 26
REPAIR PARTS(OPTION).....	Fig. 27
COMPONENT PARTS	
FOR 6215-300-036-10 ON Fig.20.....	Fig. 28
COMPONENT PARTS	
FOR 6215-600-103-30 ON Fig.21.....	Fig. 29
COMPONENT PARTS	
FOR 6281-200-015-00 ON Fig.24.....	Fig. 30

Contents

SF235F

ENGINE(E3CD-VG04)

SHORT BLOCK ENGIASSY.....	Fig. 1
CYLINDER HEAD.....	Fig. 2
CYLINDER HEAD COVER.....	Fig. 3
INLET MANIFOLD.....	Fig. 4
EXHAUST MANIFOLD.....	Fig. 5
CYLINDER BLOCK.....	Fig. 6
BEARING/UNDER SIZE (OPTION).....	Fig. 7
OIL PAN.....	Fig. 8
REAR PLATE.....	Fig. 9
TIMING GEAR CASE.....	Fig. 10
HANGER.....	Fig. 11
VALVE.....	Fig. 12
CAM SHAFT.....	Fig. 13
PISTON.....	Fig. 14
PISTON/OVER SIZE (OPTION).....	Fig. 15
CRANK SHAFT.....	Fig. 16
OIL PUMP.....	Fig. 17
WATER PUMP.....	Fig. 18
COOLING FAN.....	Fig. 19
INJECTION NOZZLE.....	Fig. 20
INJECTION PUMP.....	Fig. 21
FUEL PIPE.....	Fig. 22
ADAPTER.....	Fig. 23
ELECTRIC (1).....	Fig. 24

ELECTRIC (2).....	Fig. 25
REPAIR PARTS(OPTION).....	Fig. 26
COMPONENT PARTS	
FOR 6215-300-045-10 ON Fig.20.....	Fig. 27
COMPONENT PARTS	
FOR 6215-600-104-20 ON Fig.21.....	Fig. 28
COMPONENT PARTS	
FOR 6281-100-002-50 ON Fig.24.....	Fig. 29
COMPONENT PARTS	
FOR 6281-200-015-00 ON Fig.24.....	Fig. 30

Contents

CHASSIS

BRACKET(ENGINE)SYSTEM (SF235F TYPE).....	Fig. 1
BRACKET(ENGINE)SYSTEM (SF224F TYPE).....	Fig. 2
RADIATOR SYSTEM(SF235F TYPE).....	Fig. 3
RADIATOR SYSTEM(SF224F TYPE).....	Fig. 4
MUFFLER SYSTEM(SF235F TYPE).....	Fig. 5
MUFFLER SYSTEM(SF224F TYPE).....	Fig. 6
CLEANER(AIR)SYSTEM(SF235F TYPE).....	Fig. 7
CLEANER(AIR)SYSTEM(SF224F TYPE).....	Fig. 8
PIPING(FUEL)SYSTEM.....	Fig. 9
TANK(FUEL)SYSTEM.....	Fig. 10
BATTERY SYSTEM(SF235F TYPE).....	Fig. 11
BATTERY SYSTEM(SF224F TYPE).....	Fig. 12
LEVER(ACCELERATOR)SYSTEM.....	Fig. 13
CABLE(ACCELERATOR)SYSTEM.....	Fig. 14
SHAFT(INPUT)SET SYSTEM.....	Fig. 15
CASE(TRANSMISSION)SYSTEM.....	Fig. 16
METAL(HST)SYSTEM.....	Fig. 17
GEAR(INPUT)SYSTEM.....	Fig. 18
HST SYSTEM.....	Fig. 19
GEAR(INPUT)SYSTEM.....	Fig. 20
CASE(DIFFERENTIAL)SYSTEM.....	Fig. 21
DIFF-LOCK SYSTEM.....	Fig. 22
PEDAL(DIFF-LOCK)SYSTEM.....	Fig. 23
METAL(PTO/BLOWER)SYSTEM(B TYPE).....	Fig. 24
METAL(PTO/BLOWER)SYSTEM (EXCEPT B TYPE).....	Fig. 25

DRIVE(PTO/SIDE)SYSTEM.....	Fig. 26
DRIVE(PTO/BLOWER)SYSTEM	
(B TYPE SF235F).....	Fig. 27
DRIVE(PTO/BLOWER)SYSTEM	
(B TYPE SF224F).....	Fig. 28
COVER(PTO/SIDE)SYSTEM.....	Fig. 29
LINK(HST)SYSTEM.....	Fig. 30
PEDAL(HST)SYSTEM.....	Fig. 31
CASE(CHAIN)SYSTEM.....	Fig. 32
SHAFT(WHEEL/FRONT)SYSTEM.....	Fig. 33
BRAKE SYSTEM.....	Fig. 34
PEDAL(BRAKE)SYSTEM.....	Fig. 35
BRAKE(PARKING)SYSTEM.....	Fig. 36
WHEEL(FRONT)SYSTEM.....	Fig. 37
WHEEL(STEERING)SYSTEM.....	Fig. 38
COLUMN(STEERING)SYSTEM.....	Fig. 39
CONTROLLER(STEERING)SET SYSTEM.....	Fig. 40
CYLINDER(STEERING)SYSTEM.....	Fig. 41
FRAME SYSTEM(B TYPE).....	Fig. 42
FRAME SYSTEM(EXCEPT B TYPE).....	Fig. 43
COVER(SIDE)SYSTEM(B TYPE).....	Fig. 44
COVER(SIDE)SYSTEM(EXCEPT B TYPE).....	Fig. 45
MUD GUARD SYSTEM.....	Fig. 46
LEVER(4WD)SYSTEM.....	Fig. 47
AUTO(4WD)SYSTEM.....	Fig. 48
HOUSING(AXLE/REAR)SYSTEM(1/3)-(3/3).....	Fig. 49
ROD(TIE)SYSTEM.....	Fig. 50
WHEEL(REAR)SYSTEM.....	Fig. 51
CONTROL SYSTEM.....	Fig. 52
CYLINDER(LIFT)SYSTEM.....	Fig. 53
PIPING(PUMP)SYSTEM.....	Fig. 54
PIPING(CONTROL)SYSTEM(1/2)(2/2).....	Fig. 55
PIPING(HST)SYSTEM.....	Fig. 56

LINK(LIFT)SYSTEM.....	Fig. 57
HOOD SYSTEM.....	Fig. 58
COVER(STEERING)SYSTEM.....	Fig. 59
FENDER SYSTEM.....	Fig. 60
SEAT SYSTEM(Z TYPE-STANDARD/ EXCEPT Z TYPE-OPTION).....	Fig. 61
FLOOR SYSTEM.....	Fig. 62
LIGHT SYSTEM(B TYPE).....	Fig. 63
LIGHT SYSTEM(EXCEPT B TYPE).....	Fig. 64
PANEL(SWITCH)SYSTEM.....	Fig. 65
SWITCH(SAFETY)SYSTEM(1/2)(2/2).....	Fig. 66
HARNESS SYSTEM.....	Fig. 67
HARNESS SYSTEM(SF224F TYPE).....	Fig. 68
CONTROLLER SYSTEM.....	Fig. 69
FRAME(MAIN)SYSTEM.....	Fig. 70
FRAME(UPPER)SYSTEM.....	Fig. 71
BLOWER SYSTEM(B TYPE).....	Fig. 72
ORNAMENT(SF235F TYPE).....	Fig. 73
ORNAMENT(SF224F TYPE).....	Fig. 74
LABEL(CONTROL).....	Fig. 75
LABEL(CAUTION)(SF235F TYPE).....	Fig. 76
LABEL(CAUTION)(SF224F TYPE).....	Fig. 77
LABEL(CE).....	Fig. 78
WEIGHT(REAR)SET SYSTEM (EXCEPT B TYPE-STANDARD/ B TYPE-OPTION).....	Fig. 79

OPTIONAL PARTS

PLATE(BUMPER)&BOLT SYSTEM (OPTION).....	Fig. 80
WEIGHT(15)SET(OPTION).....	Fig. 81

COMPONENT PARTS

COMPONENT PARTS

FOR K500-008-000-00 ON Fig.19.....Fig. 82

COMPONENT PARTS

FOR 1672-105-210-10 ON Fig.9.....Fig. 83

COMPONENT PARTS

FOR 1720-221-210-00 ON Fig.48.....Fig. 84

COMPONENT PARTS

FOR 1725-219-720-20 ON Fig.27,28.....Fig. 85

COMPONENT PARTS

FOR 1772-654-210-00 ON Fig.63,64.....Fig. 86

COMPONENT PARTS

FOR 1825-127-300-00 ON Fig.26.....Fig. 87

WIRING DIAGRAM


WIRING DIAGRAM (1/2)

WIRING DIAGRAM (2/2)

E N G I N E

E3112G08...SF224F

FIG. 2 CYLINDER HEAD




6004-101I-0100,6004-101I-0200

[illegible]

This diagram shows the components of a car battery assembly in an exploded view. The parts are numbered as follows:

- 1**: The main battery housing, a rectangular plastic container with a central circular opening.
- 2**: A circular cap with the number '110' on its top surface, designed to fit into the central opening of the housing.
- 3**: A rectangular battery tray with a raised, irregular border, intended to hold the battery housing.
- 4**: A hexagonal bolt used for securing the top of the battery housing.
- 5**: A circular washer or spacer plate that fits between the bolt and the housing.
- 6**: A curved, L-shaped bracket or support arm that fits into a slot on the side of the battery housing.


FIG. 4 INLET MANIFOLD



6004-120E-0100

[illegible]


[illegible]

FIG. 6 CYLINDER BLOCK


6004-203I-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E3112 G08					
1	6211-210-113-10	CYLINDERBLOCK ASSY	*	1					
2	6209-000-004-10	BOLT	*	8					
3	6209-610-001-10	CUP/SEALING/28	*	2					
4	6209-610-009-00	CUP/SEALING/36	*	4					
5	6209-605-007-10	PLUG/PT1/8	*	3					
6	6212-531-014-00	PIN/IDLEGEAR	*	1					
7	6209-610-008-00	CUP/SEALING/12	*	2					
8	6211-258-001-00	SEAL,BEARING CAP	*	4					
9	6211-258-002-00	SEAL,BEARING CAP/7	*	2					
10	6211-510-021-00	BEARING/CRANKSET	*	1					
11	6211-511-023-00	BEARING/CRANK/UPPER	*	4					
12	6211-511-024-00	BEARING/CRANK/LOWER	*	4					
13	6211-599-012-00	BEARING/THRUST/CRANK	*	2					
14	6209-625-001-00	SEAL,OIL	*	1					
15	6209-749-001-20	PIN/TUBE	*	2					
16	6213-129-006-00	PIN/STRAIGHT	*	2					
17	6209-740-005-00	PIN	*	2					
18	6904-110-840-00	STUD/M8X40	*	1					
19	6904-110-818-00	STUD	*	1					
20	6904-110-822-00	STUD	*	2					
21	6294-453-002-00	DOWEL	*	2					
22	6909-902-299-00	NIPPLE	*	1					
23	V782-160-000-4T	PLUG/SCREW/SEAL	*	1					
24	6213-319-001-00	CONNECTOR,OIL FILTER	*	1					
25	6211-291-015-20	COVER/INJECTIONPUMP	*	1					
26	6211-292-001-20	GASKET/COVER	*	1					
27	V230-360-601-20	FLANGE BOLT/M6X12	*	4					
28	6215-549-013-00	PIN	*	1					
29	6211-760-035-20	LEVELGAGE	*	1					
30	6211-766-025-00	GUIDE/LEVELGAGE COMP	*	1					

[illegible]

[illegible]

[illegible]


FIG. 10 TIMING GEAR CASE

6004-240G-0100,6004-240G-0200

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E3112 G08					
1	6211-310-025-50	GEARCASE ASSY	*	1					
2	6209-605-007-10	PLUG/PT1/8	*	2					
3	6209-610-007-00	CUP/SEALING/16	*	1					
4	6904-110-822-00	STUD	*	1					
5	6904-110-855-00	STUD	*	2					
6	6904-110-850-00	STUD	*	1					
7	6209-625-002-00	SEAL,OIL	*	1					
8	V231-360-808-50	FLANGEBOLT/M8X85	*	1					
9	V231-360-805-50	FLANGEBOLT/M8X55	*	2					
10	3817-401-001-00	NUT/M08	*	1					
11	V231-360-801-60	FLANGEBOLT/M8X16	*	3					
12	V231-360-804-50	FLANGEBOLT/M8X45	*	5					
13	V231-360-807-50	FLANGEBOLT/M8X75	*	1					
14	1425-621-004-00	HOLDER/JE/9-9	*	1					
15	V231-360-803-00	FLANGEBOLT/M8X30	*	1					
16	6209-500-003-00	WASHER/08X14X01	*	1					
17	6215-546-003-30	STOPPER/FULLLOAD	*	1					
18	6209-409-001-00	NUT/M8	*	1					
19	V341-120-008-00	NUT,CAP/M8	*	1					
20	6209-920-002-00	PACKING	*	2					
21	6215-542-004-20	PIN/ARM	*	1					
22	P117-303-003-00	PIN/SNAP	*	2					
23	6215-542-005-20	PIN	*	1					
24	6209-600-004-00	PLUG/SCREW	*	1					
25	6209-500-003-00	WASHER/08X14X01	*	1					
26	6209-740-001-00	PIN,GROOVE	*	1					
27	6211-312-003-20	GASKET/GEARCASE	*	1					
28	6213-160-002-20	VALVE/RELIEF ASSY	*	1					
29	6213-161-001-20	PISTON/VALVE/RELIEF	*	1					
30	6213-164-001-00	SPRING/RELIEF VALVE	*	1					

29


FIG. 11 HANGER



6003-290 -0100

[illegible]


FIG. 12 VALVE



6004-301 -0100

[illegible]

FIG. 13 CAM SHAFT



6003-310 -0100


[illegible]

This diagram illustrates the exploded view of a piston and connecting rod assembly. The components are labeled with numbers 1 through 7:

- 1**: The piston body, showing the crown, skirt, and a side cooling passage.
- 2**: A set of three piston rings, including a top compression ring and a bottom oil control ring.
- 3**: A piston pin, which connects the piston to the connecting rod.
- 4**: Piston pin retainers (circlips) that secure the piston pin within the piston and the connecting rod.
- 5**: The connecting rod, which links the piston to the crankshaft.
- 6**: A connecting rod pin bolt, used to secure the connecting rod pin.
- 7**: A connecting rod pin cap, which covers the end of the connecting rod.


[illegible]

FIG. 15 PISTON/OVER SIZE (OPTION)



6004-349I-0100


[illegible]



6004-351L-0100

[illegible]

FIG. 17 OIL PUMP




6004-401A-0100

[illegible]

[illegible]


FIG. 19 COOLING FAN



6004-480U-0100

[illegible]

[illegible]


FIG. 21 INJECTION PUMP

6004-511D-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E3112 G08					
1	6215-600-103-30	INJECTIONPUMP ASSY	*	1					FIG 029
2	6215-619-010-00	WASHER/AIR BLEEDER	*	2					
3	6215-619-009-00	SCREW/HOLLOW	*	1					
4	6219-752-045-00	SHIM/INJECTIONPUMP	*	1					
5	6219-752-044-00	SHIM/INJECTIONPUMP	*	1					
6	6219-752-046-00	SHIM/INJECTIONPUMP	*	1					
7	6219-752-047-00	SHIM/INJECTIONPUMP	*	1					
8	V201-360-802-00	BOLT/M8X20/7T	*	2					
9	3817-401-001-00	NUT/M08	*	2					
10	6215-621-016-30	CAMSHAFT/INJECTION P	*	1					
11	6212-524-002-40	GEAR/INJECTIONPUMP	*	1					
12	6209-730-005-00	KEY/07X05X09	*	1					
13	V600-110-620-30	BEARING,RB/6203	*	1					
14	1729-202-001-00	BEARING/BALL	*	1					
15	6212-535-010-10	PLATE/THRUST/INJECTI	*	1					
16	V210-560-601-20	BOLT,S/M6X12/7T	*	1					
17	6215-520-001-00	FLYWEIGHT	*	1					
18	6209-030-043-00	BOLT/M6X10	*	3					
19	6215-526-004-00	THRUSTPIECE	*	1					
20	6215-541-001-10	ARM/FLOATING COMP	*	1					
21	6215-543-002-10	RINK/CONTROL	*	1					
22	6215-542-006-00	PIN,CONTROL	*	1					
23	V710-140-004-00	RING,SNAP/4 E	*	1					
24	6215-531-023-00	SPRING/GOVERNOR	*	1					
25	6215-541-024-50	LEVER/CONTROL COMP	*	1					
26	V720-101-900-80	O-RING/1A,P8	*	1					
27	6209-580-002-10	SPRING,RETURN	*	1					
28	6215-549-007-10	ARM/CONTROL	*	1					
29	V301-260-006-00	NUT/M6	*	1					
30	V411-260-006-00	WASHER,PL/M6	*	1					

41


FIG. 22 FUEL PIPE



6004-5500-0100

[illegible]


FIG. 23 ADAPTER



6005-560 -0100

[illegible]

FIG. 24 ELECTRIC (1)




6004-801V-0100,6004-801V-0200

[illegible]

[illegible]


FIG. 26 REPAIR PARTS(OPTION)



6005-998D-0100

[illegible]


FIG. 27 REPAIR PARTS(OPTION)



6004-999C-0100

[illegible]

FIG. 28 COMPONENT PARTS FOR 6215-300-036-10 ON Fig.20



6215-300-036-1B

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E3112 G08					
1	6215-330-024-10	HOLDER/NOZZLE ASSY	*	3					
2	6215-331-008-00	BODY/NOZZLE HOLDER	*	3					
3	6215-342-001-00	PIN,NOZZLE HOLDER	*	3					
4	6215-343-001-00	SPRING/NOZZLEHOLDER	*	3					
5	6215-332-013-00	NUT/NOZZLERETAINING	*	3					
6	6215-339-001-00	PIECE,DISTANCE	*	3					
7	6215-345-001-00	WASHER/0.9	*	3					
8	6215-345-002-00	WASHER/0.925	*	3					
9	6215-345-003-00	WASHER/0.95	*	3					
10	6215-345-004-00	WASHER/0.975	*	3					
11	6215-345-005-00	WASHER/1.0	*	3					
12	6215-345-006-00	WASHER/1.025	*	3					
13	6215-345-007-00	WASHER/1.05	*	3					
14	6215-345-008-00	WASHER/1.075	*	3					
15	6215-345-009-00	WASHER/1.1	*	3					
16	6215-345-010-00	WASHER/1.125	*	3					
17	6215-345-011-00	WASHER/1.15	*	3					
18	6215-345-012-00	WASHER/1.175	*	3					
19	6215-345-013-00	WASHER/1.2	*	3					
20	6215-345-014-00	WASHER/1.225	*	3					
21	6215-345-015-00	WASHER/1.25	*	3					
22	6215-345-016-00	WASHER/1.275	*	3					
23	6215-345-017-00	WASHER/1.3	*	3					
24	6215-345-018-00	WASHER/1.325	*	3					
25	6215-345-019-00	WASHER/1.35	*	3					
26	6215-345-020-00	WASHER/1.375	*	3					
27	6215-345-021-00	WASHER/1.4	*	3					
28	6215-345-022-00	WASHER/1.425	*	3					
29	6215-345-023-00	WASHER/1.45	*	3					
30	6215-345-024-00	WASHER/1.475	*	3					


This exploded view diagram illustrates the assembly of a multi-layered cylindrical component. The parts are labeled as follows:

- 1**: A bracket on the left side grouping the main body components (2, 3, 4, 6, 5).
- 2**: The upper main body section, featuring a hexagonal top flange and a threaded section.
- 3**: A small cylindrical spacer or bush.
- 4**: A threaded rod or screw passing through the assembly.
- 5**: The lower main body section, featuring a hexagonal bottom flange and a threaded section.
- 6**: A circular gasket or seal ring.
- 7~49**: A series of small, thin circular components, likely O-rings or seals, positioned between the main body sections.
- 50**: A hexagonal nut used to secure the assembly.
- 51**: A small cylindrical component, possibly a pin or a plug, located at the bottom of the assembly.

Dashed lines indicate the vertical alignment and assembly path of the components.

[illegible]


FIG. 29 COMPONENT PARTS FOR 6215-600-103-30 ON Fig.21



6215-600-103-3J

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E3112 G08					
1	6215-643-006-00	SPRING/DELIVERYVALVE	*	3					
2	6215-644-007-00	HOLDER/DELIVERYVALVE	*	3					
3	6215-649-019-00	ORING	*	3					
4	6215-649-002-00	GASKET/DELIVERYVALVE	*	3					
5	6215-641-006-00	VALVE ASSY	*	3					
6	6215-611-001-00	HOUSING ASSY	*	1					
7	6215-631-019-00	ELEMENT ASSY	*	3					
8	6215-619-022-00	BOLT/WASHERHEAD	*	2					
9	6215-612-001-00	PLATE/ADJUSTING	*	2					
10	6215-629-001-00	PIN/INJECTIONPUMP	*	3					
11	6215-629-002-00	PLATE	*	1					
12	6215-622-001-00	TAPPET/INJECTIO ASSY	*	3					
13	6215-637-001-00	RACK/CONTROL ASSY	*	1					
14	6215-635-001-00	SLEEVE/PLUNGER	*	3					
15	6215-639-004-00	SEAT/SPRING/UPPER	*	3					
16	6215-634-001-00	SPRING/PUMPPLUNGER	*	3					
17	6215-639-005-00	SEAT/SPRING/LOWER	*	3					
18	6215-629-003-00	PLATE/TAPPET/AD 0.6	*	1					
19	6215-629-004-00	PLATE/TAPPET/AD 0.7	*	1					
20	6215-629-005-00	PLATE/TAPPET/AD 0.8	*	1					
21	6215-629-006-00	PLATE/TAPPET/AD 0.9	*	1					
22	6215-629-007-00	PLATE/TAPPET/AD 1.0	*	1					
23	6215-629-008-00	PLATE/TAPPET/AD 0.2	*	1					
24	6215-629-009-00	PLATE/TAPPET/AD 0.3	*	1					
25	6215-629-010-00	PLATE/TAPPET/AD 0.4	*	1					
26	6215-629-011-00	PLATE/TAPPET/AD 0.5	*	3					
27	6215-629-012-00	PLATE/TAPPET/AD 0.25	*	1					
28	6215-629-013-00	PLATE/TAPPET/AD 0.35	*	1					
29	6215-629-014-00	PLATE/TAPPET/AD 0.45	*	1					
30	6215-629-015-00	PLATE/TAPPET/AD 0.55	*	1					

**FIG. 29 COMPONENT PARTS
FOR 6215-600-103-30 ON Fig.21**



6215-600-103-3J

[illegible]

This exploded view diagram illustrates the assembly of a 12V 100Ah battery. The components are numbered as follows:

- 1**: Battery case (top)
- 2**: Nut
- 3**: Washer
- 4**: Battery case (bottom)
- 5**: Washer
- 6**: Nut
- 7**: Battery case (middle)
- 8**: Washer
- 9**: Nut
- 10**: Washer
- 11**: Nut
- 12**: Battery case (bottom)
- 13**: Battery case (middle)
- 14**: Battery case (top)
- 15**: Washer
- 16**: Washer
- 17**: Washer
- 18**: Washer
- 19**: Washer
- 20**: Washer
- 21**: Washer
- 22**: Washer
- 23**: Washer
- 24**: Washer
- 25**: Washer
- 26**: Washer


[illegible]

ENGINE

E3CDVG04...SF235F

ENGINE


FIG. 2 CYLINDER HEAD



6005-101S-0100,6005-101S-0200

[illegible]


57



6005-120 -0100

[illegible]

[illegible]

FIG. 6 CYLINDER BLOCK

6005-204F-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E3CD VG04					
1	6211-210-116-00	CYLINDERBLOCK ASSY	*	1					
2	6209-000-006-00	BOLT	*	8					
3	6209-610-007-00	CUP/SEALING/16	*	2					
4	6209-610-001-10	CUP/SEALING/28	*	2					
5	6209-610-009-00	CUP/SEALING/36	*	1					
6	6209-610-003-00	CUP/SEALING/50	*	3					
7	6209-605-007-10	PLUG/PT1/8	*	8					
8	6212-531-008-30	PIN/IDLEGEAR	*	1					
9	6211-258-001-00	SEAL, BEARING CAP	*	4					
10	6211-258-002-00	SEAL, BEARING CAP/7	*	2					
11	6211-510-008-00	BEARING/CRANK SET	*	1					
12	6211-511-007-00	BEARING/CRANK/UPPER	*	4					
13	6211-511-008-00	BEARING/CRANK/LOWER	*	4					
14	6211-599-004-00	BEARING/THRUST/CRANK	*	2					
15	6209-625-003-20	OILSEAL	*	1					
16	6209-749-001-20	PIN/TUBE	*	2					
17	6213-129-006-00	PIN/STRAIGHT	*	2					
18	6209-740-005-00	PIN	*	2					
19	6904-110-840-00	STUD/M8X40	*	1					
20	6904-110-822-00	STUD	*	3					
21	V251-340-806-00	STUD/M8X60/7T	*	1					
22	6294-453-002-00	DOWEL	*	2					
23	V782-160-000-4T	PLUG/SCREW/SEAL	*	1					
24	6213-721-015-00	PIPE/WATER/HOUSING	*	1					
25	6211-291-015-20	COVER/INJECTIONPUMP	*	1					
26	6211-292-001-20	GASKET/COVER	*	1					
27	V230-360-601-20	FLANGE BOLT/M6X12	*	4					
28	6215-549-013-00	PIN	*	1					
29	6211-760-057-10	LEVELGAGE	*	1					
30	6211-766-025-00	GUIDE/LEVELGAGE COMP	*	1					

This exploded view diagram illustrates the assembly of a 4-cylinder engine. The components are numbered 1 through 37. The diagram shows the following parts and their assembly sequence:


- 1**: Main engine block.
- 2**: Piston and connecting rod assembly (shown in a separate exploded view).
- 3**: Piston pin.
- 4**: Piston pin clip.
- 5**: Piston pin clip.
- 6**: Piston pin clip.
- 7**: Piston pin clip.
- 8**: Piston pin clip.
- 9**: Piston pin clip.
- 10**: Piston pin clip.
- 11**: Piston pin clip.
- 12**: Piston pin clip.
- 13**: Piston pin clip.
- 14**: Piston pin clip.
- 15**: Piston pin clip.
- 16**: Piston pin clip.
- 17**: Piston pin clip.
- 18**: Piston pin clip.
- 19**: Piston pin clip.
- 20**: Piston pin clip.
- 21**: Piston pin clip.
- 22**: Piston pin clip.
- 23**: Piston pin clip.
- 24**: Piston pin clip.
- 25**: Piston pin clip.
- 26**: Piston pin clip.
- 27**: Piston pin clip.
- 28**: Piston pin clip.
- 29**: Piston pin clip.
- 30**: Piston pin clip.
- 31**: Piston pin clip.
- 32**: Piston pin clip.
- 33**: Piston pin clip.
- 34**: Piston pin clip.
- 35**: Piston pin clip.
- 36**: Piston pin clip.
- 37**: Piston pin clip.

The diagram also includes a legend for the following parts:

- 1: Piston and connecting rod assembly
- 2: Piston pin
- 3: Piston pin clip
- 4: Piston pin clip
- 5: Piston pin clip
- 6: Piston pin clip
- 7: Piston pin clip
- 8: Piston pin clip
- 9: Piston pin clip
- 10: Piston pin clip
- 11: Piston pin clip
- 12: Piston pin clip
- 13: Piston pin clip
- 14: Piston pin clip
- 15: Piston pin clip
- 16: Piston pin clip
- 17: Piston pin clip
- 18: Piston pin clip
- 19: Piston pin clip
- 20: Piston pin clip
- 21: Piston pin clip
- 22: Piston pin clip
- 23: Piston pin clip
- 24: Piston pin clip
- 25: Piston pin clip
- 26: Piston pin clip
- 27: Piston pin clip
- 28: Piston pin clip
- 29: Piston pin clip
- 30: Piston pin clip
- 31: Piston pin clip
- 32: Piston pin clip
- 33: Piston pin clip
- 34: Piston pin clip
- 35: Piston pin clip
- 36: Piston pin clip
- 37: Piston pin clip

[illegible]


FIG. 7 BEARING/UNDER SIZE (OPTION)



6005-209 -0100

[illegible]


FIG. 8 OIL PAN



6005-210I-0100


[illegible]

FIG. 9 REAR PLATE



6005-221C-0100

[illegible]

FIG. 10 TIMING GEAR CASE

6005-241R-0100,6005-241R-0200

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E3CD VG04					
1	6211-310-075-00	GEARCASE ASSY	*	1					
2	6209-605-003-20	PLUG/PT1/4	*	1					
3	6209-610-004-00	CUP/SEALING/20	*	1					
4	6904-110-822-00	STUD	*	1					
5	6904-110-855-00	STUD	*	2					
6	6904-110-850-00	STUD	*	1					
7	6209-625-002-00	SEAL,OIL	*	1					
8	V231-360-808-50	FLANGEBOLT/M8X85	*	1					
9	V231-360-807-50	FLANGEBOLT/M8X75	*	1					
10	V231-360-807-00	FLANGEBOLT/M8X70	*	1					
11	3817-401-001-00	NUT/M08	*	2					
12	V231-360-801-60	FLANGEBOLT/M8X16	*	3					
13	V231-360-805-00	FLANGEBOLT/M8X50	*	3					
14	V231-360-806-00	FLANGEBOLT/M8X60	*	4					
15	1425-621-004-00	HOLDER/JE/9-9	*	1					
16	V231-360-803-00	FLANGEBOLT/M8X30	*	1					
17	6209-500-003-00	WASHER/08X14X01	*	1					
18	6215-546-003-30	STOPPER/FULLLOAD	*	1					
19	6209-409-001-00	NUT/M8	*	1					
20	V341-120-008-00	NUT,CAP/M8	*	1					
21	6209-920-002-00	PACKING	*	2					
22	6215-542-004-20	PIN/ARM	*	1					
23	P117-303-003-00	PIN/SNAP	*	2					
24	6215-542-005-20	PIN	*	1					
25	6209-600-004-00	PLUG/SCREW	*	1					
26	6209-500-003-00	WASHER/08X14X01	*	1					
27	6209-740-006-00	PIN/GROOVE	*	1					
28	6211-312-005-10	GASKET/GEARCASE	*	1					
29	6213-160-005-00	VALVE/RELIEF ASSY	*	1					
30	6213-161-003-10	PISTON/VALVE/RELIEF	*	1					


This exploded view diagram illustrates the assembly of a mechanical component, possibly a pump or engine part. The components are numbered 1 through 52. The diagram shows the following parts and their assembly relationships:

- Base and Housing (1-10):** The main housing (1) contains internal components like the shaft (2) and impeller (3). The base plate (4) is secured with screws (5, 6, 7, 8, 9, 10).
- Internal Components (11-20):** Includes the impeller (3), shaft (2), and various internal seals and bearings (11, 12, 13, 14, 15, 16, 17, 18, 19, 20).
- Seals and Gaskets (21-28):** Various O-rings and gaskets (21, 22, 23, 24, 25, 26, 27, 28) are used to ensure a leak-proof assembly.
- External Components (29-38):** Includes the outer casing (29), mounting flange (30), and various external seals and gaskets (31, 32, 33, 34, 35, 36, 37, 38).
- Fasteners (39-52):** A variety of screws, bolts, and nuts (39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52) are used to secure the assembly.

The diagram uses dashed lines to show the alignment and fit of the components, indicating the correct assembly sequence and orientation.

[illegible]


FIG. 11 HANGER




6005-290 -0100

[illegible]

FIG. 12 VALVE


[illegible]



6005-310 -0100

[illegible]

FIG. 14 PISTON




6005-340P-0100

[illegible]

[illegible]

FIG. 16 CRANK SHAFT



6005-352C-0100

[illegible]

The image contains three exploded view diagrams of a mechanical assembly, likely a pump or engine component. The diagrams are labeled FIG. 6, FIG. 10, and FIG. 11.

FIG. 6 shows the main assembly with various components labeled with numbers: 9, 11, 12, 10, 15, 14, 18-1, 13, 6-24, 6, 5, 7, and 8. The main body is labeled FIG. 6.

FIG. 10 shows a sub-assembly with components labeled 4-3, 16, and 4-1.

FIG. 11 shows a sub-assembly with components labeled 2, 2, 3, and 1.

[illegible]


The diagram illustrates the assembly of an engine, showing various components and their assembly sequence. The components are labeled with numbers 1 through 20. The assembly sequence is indicated by arrows and letters A and B.

- FIG. 1** shows the main engine assembly with components 1 through 20. The components are:
 - 1: Main engine block
 - 2: Gasket
 - 3: Bolt
 - 4: Bolt
 - 5: Bolt
 - 6: Bolt
 - 7: Bolt
 - 8: Bolt
 - 9: Bolt
 - 10: Bolt
 - 11: Bolt
 - 12: Bolt
 - 13: Bolt
 - 14: Bolt
 - 15: Bolt
 - 16: Bolt
 - 17: Bolt
 - 18: Bolt
 - 19: Bolt
 - 20: Bolt
- FIG. 2** shows the engine assembly with components 1 through 20. The components are:
 - 1: Main engine block
 - 2: Gasket
 - 3: Bolt
 - 4: Bolt
 - 5: Bolt
 - 6: Bolt
 - 7: Bolt
 - 8: Bolt
 - 9: Bolt
 - 10: Bolt
 - 11: Bolt
 - 12: Bolt
 - 13: Bolt
 - 14: Bolt
 - 15: Bolt
 - 16: Bolt
 - 17: Bolt
 - 18: Bolt
 - 19: Bolt
 - 20: Bolt

[illegible]


[illegible]

FIG. 20 INJECTION NOZZLE



6005-501E-0100


[illegible]

FIG. 21 INJECTION PUMP

6005-511Z-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E3CD VG04					
1	6215-600-104-20	INJECTIONPUMP ASSY	*	1					FIG 028
2	6219-752-045-00	SHIM/INJECTIONPUMP	*	1					
3	6219-752-044-00	SHIM/INJECTIONPUMP	*	1					
4	6219-752-046-00	SHIM/INJECTIONPUMP	*	1					
5	6219-752-047-00	SHIM/INJECTIONPUMP	*	1					
6	V231-360-802-00	FLANGEBOLT/M8X20	*	2					
7	3817-401-001-00	NUT/M08	*	2					
8	6215-621-017-10	CAMSHAFT/INJPUMP	*	1					
9	6212-524-006-30	GEAR/INJECTIONPUMP	*	1					
10	6209-730-005-00	KEY/07X05X09	*	1					
11	V600-110-620-30	BEARING,RB/6203	*	1					
12	1729-202-001-00	BEARING/BALL	*	1					
13	6212-535-009-00	PLATE/THRUST/INJPUMP	*	1					
14	V210-560-601-20	BOLT,S/M6X12/7T	*	1					
15	6215-520-007-10	FLYWEIGHT ASSY	*	1					
16	6209-030-043-00	BOLT/M6X10	*	3					
17	6215-526-004-00	THRUSTPIECE	*	1					
18	6215-541-001-10	ARM/FLOATING COMP	*	1					
19	6215-543-002-10	RINK/CONTROL	*	1					
20	6215-542-006-00	PIN,CONTROL	*	1					
21	V710-140-004-00	RING,SNAP/4 E	*	1					
22	6215-549-031-10	SPRING/SETTING	*	1					
23	6215-531-019-00	SPRING/GOVERNOR	*	1					
24	6215-541-045-10	LEVER/CONTROL COMP	*	1					
25	V720-101-900-80	O-RING/1A,P8	*	1					
26	6209-580-002-10	SPRING,RETURN	*	1					
27	6215-549-076-10	ARM/CONTROL	*	1					
28	V301-260-006-00	NUT/M6	*	1					
29	V411-260-006-00	WASHER,PL/M6	*	1					
30	V401-160-006-00	WASHER,SP/M6	*	1					


FIG. 21 INJECTION PUMP



6005-511Z-0100

[illegible]


FIG. 22 FUEL PIPE



6005-550J-0100

[illegible]

FIG. 23 ADAPTER




6005-561N-0100

[illegible]

[illegible]

FIG. 25 ELECTRIC (2)



6005-821F-0100,6005-821F-0200

[illegible]

10-40



[illegible]


**FIG. 27 COMPONENT PARTS
FOR 6215-300-045-10 ON Fig.20**



6215-300-045-1B

[illegible]

**FIG. 28 COMPONENT PARTS
FOR 6215-600-104-20 ON Fig.21**



6215-600-104-2E

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E3CD VG04					
1	6215-631-015-00	PLUNGER ASSY	*	3					
2	6215-641-002-00	VALVE, DELIVERY	*	3					
3	6215-643-005-00	SPRING/DELIVERY VALVE	*	3					
4	6215-649-008-00	GASKET	*	3					
5	6215-644-009-00	HOLDER/DELIVERY VALVE	*	3					
6	6215-649-014-00	ORING	*	3					
7	6215-635-004-00	SLEEVE FLANGE	*	3					
8	6215-649-013-00	ORING	*	6					
9	6215-649-011-00	BOLT	*	6					
10	6215-622-003-00	TAPPET	*	3					
11	6215-629-017-00	PIN	*	3					
12	6215-629-035-00	SNAPRING	*	1					
13	6215-634-003-00	SPRING/PLUNGER	*	3					
14	6215-639-008-00	SPRINGSEAT	*	3					
15	6215-639-009-00	SPRINGSEAT	*	3					
16	6215-629-060-00	PLATE/T=2.60	*	1					
17	6215-629-061-00	PLATE/T=2.65	*	1					
18	6215-629-062-00	PLATE/T=2.70	*	1					
19	6215-629-063-00	PLATE/T=2.75	*	1					
20	6215-629-064-00	PLATE/T=2.80	*	1					
21	6215-629-065-00	PLATE/T=2.85	*	1					
22	6215-629-066-00	PLATE/T=2.90	*	1					
23	6215-629-067-00	PLATE/T=2.95	*	1					
24	6215-629-036-00	PLATE/T=3.00	*	1					
25	6215-629-037-00	PLATE/T=3.05	*	1					
26	6215-629-038-00	PLATE/T=3.10	*	1					
27	6215-629-039-00	PLATE/T=3.15	*	1					
28	6215-629-040-00	PLATE/T=3.20	*	1					
29	6215-629-041-00	PLATE/T=3.25	*	1					
30	6215-629-042-00	PLATE/T=3.30	*	1					

This diagram illustrates the exploded view of a hydraulic cylinder assembly. The components are numbered as follows:

- 1**: Piston rod
- 2**: Piston rod seal
- 3**: Piston rod seal
- 4**: Piston rod seal
- 5**: Piston rod seal
- 6**: Piston rod seal
- 7**: Piston rod seal
- 8**: Piston rod seal
- 9**: Piston rod seal
- 10**: Piston rod seal
- 11**: Piston rod seal
- 12**: Piston rod seal
- 13**: Piston rod seal
- 14**: Piston rod seal
- 15**: Piston rod seal
- 16~46**: Piston rod seal
- 47**: Piston rod seal
- 48**: Piston rod seal
- 49**: Piston rod seal
- 50**: Piston rod seal
- 51**: Piston rod seal
- 52**: Piston rod seal

[illegible]

This exploded view diagram illustrates the assembly of a mechanical device, likely a pump or motor. The components are numbered as follows:

- 1**: Main cylindrical housing.
- 2**: Motor or actuator assembly.
- 3**: Small circular component, possibly a seal or gasket.
- 4**: Small circular component, possibly a seal or gasket.
- 5**: Piston rod assembly, shown in a detailed inset.
- 6**: Small circular component, possibly a seal or gasket.
- 7**: Small circular component, possibly a seal or gasket.
- 8**: Gear or flywheel component.
- 9**: Flange or mounting bracket.
- 10**: Small cylindrical component.
- 11**: Flat plate or cover.
- 12**: Small cylindrical component.
- 13**: Main rectangular housing or base.
- 14**: Small screw or fastener.
- 15**: Small screw or fastener.
- 16**: Small cylindrical component.
- 17**: Small circular component, possibly a seal or gasket.
- 18**: Small cylindrical component.
- 19**: Large circular component, possibly a diaphragm or piston head.
- 20**: Small cylindrical component.
- 21**: Small screw or fastener.
- 22**: Small screw or fastener.
- 23**: Small cylindrical component.

[illegible]


This exploded view diagram illustrates the assembly of a 12V 100Ah battery. The components are numbered as follows:

- 1, 2:** Front terminal cap and its securing screw.
- 3:** Front terminal post.
- 4:** Battery case (top half).
- 5, 6:** Rear terminal cap and its securing screw.
- 7:** Battery case (bottom half).
- 8, 9:** Rear terminal post and its securing screw.
- 10, 11:** Internal terminal bracket and its securing screw.
- 12:** Battery case (bottom half, alternative view).
- 13, 14:** Battery case (bottom half, alternative view) and its securing screw.
- 15, 16:** Battery case (bottom half, alternative view) and its securing screw.
- 17, 18:** Battery case (bottom half, alternative view) and its securing screw.
- 19, 20:** Battery case (bottom half, alternative view) and its securing screw.
- 21, 22:** Battery case (bottom half, alternative view) and its securing screw.
- 23, 24:** Battery case (bottom half, alternative view) and its securing screw.
- 25, 26:** Battery case (bottom half, alternative view) and its securing screw.

[illegible]

CHASSIS


**FIG. 1 BRACKET(ENGINE)SYSTEM
(SF235F TYPE)**



1832-101 -0100


[illegible]

**FIG. 2 BRACKET(ENGINE)SYSTEM
(SF224F TYPE)**



1832-101A-0100

[illegible]

FIG. 3 RADIATOR SYSTEM(SF235F TYPE)

1832-102 -0100


KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1832-102-330-00	RADIATOR ASSY	*		1				
2	1832-102-220-00	SHROUD COMP	*		1				
3	1770-102-004-00	INSULATOR/10X10X450	*		2				
4	1809-102-027-00	INSULATOR	*		1				
5	V210-360-601-60	BOLT,SP/M6X16	*		4				
6	1832-102-310-00	FAN/RADIATOR/23 ASSY	*		1				
7	V210-360-601-60	BOLT,SP/M6X16	*		4				
8	1832-102-004-00	HOSE/RADIATOR/IN/235	*		1				
9	1832-102-005-00	HOSE/RADIATOR/OUT/23	*		1				
10	J061-236-044-00	CLAMP/WIRE/36-44	*		2				
11	J061-230-038-00	CLAMP/WIRE/30-38	*		2				
12	1728-102-220-00	HOSE/290 ASSY	*		1				
13	J062-147-159-00	CLIP/HOSE/14.7-15.9	*		2				
14	1809-102-330-00	STAY/PLUG	*		1				
15	V231-360-801-60	FLANGEBOLT/M8X16	*		1				
16	1832-102-210-20	FRAME/RADIATOR COMP	*		1				
17	V211-360-802-00	BOLT,SP/M8X20	*		4				
18	V362-260-008-00	NUT/WASHER/M8	*		4				
19	1421-603-004-00	BUSH,LEVER	*		2				
20	1752-102-005-00	INSULATOR/15X15X280	*		2				
21	1716-601-009-00	TUBE/07X09X30	*		2				
22	1423-616-004-00	CUSHION/RUBBER/10X25	*		6				
23	V201-260-803-50	BOLT/M8X35	*		2				
24	1719-312-001-00	U-NUT	*		2				
25	4101-102-038-00	WASHER/24X9X3.2	*		2				
26	1832-102-230-10	COVER/RADIATOR COMP	*		1		7F		
27	V120-366-001-20	SCREW,SP/M6X12	*		4				
28	1729-604-003-00	SPRING	*		2				
29	1724-102-012-00	TRIM/188	*		1				
30	1685-604-003-00	INSULATOR/90	*		1				

This exploded view diagram illustrates the assembly of a machine frame. The components are numbered as follows:

- Frame and Structural Components:** 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46.
- Fasteners and Hardware:** 10 (ENGINE), 13, 19, 22, 25, 40, 41.
- Assembly Instructions:**
 - Arrows indicate the direction of assembly for various components.
 - Labels **A**, **B**, and **C** are placed near specific assembly points.
 - Labels **(ENGINE)** are placed near components 10 and 9.

The diagram shows the relationship between the main frame (1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46) and the various fasteners and hardware (10, 13, 19, 22, 25, 40, 41) used to assemble it. The assembly instructions (A, B, C, (ENGINE)) provide guidance on the correct orientation and placement of the components.


[illegible]

FIG. 4 RADIATOR SYSTEM(SF224F TYPE)

1832-102A-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1832-102-330-00	RADIATOR ASSY	*	1					
2	1832-102-220-00	SHROUD COMP	*	1					
3	1770-102-004-00	INSULATOR/10X10X450	*	2					
4	1809-102-027-00	INSULATOR	*	1					
5	V210-360-601-60	BOLT,SP/M6X16	*	4					
6	1832-102-320-00	FAN/RADIATOR/22 ASSY	*	1					
7	V210-360-601-60	BOLT,SP/M6X16	*	4					
8	1832-102-051-00	HOSE/RADIATOR/IN/224	*	1					
9	1832-102-052-00	HOSE/RADIATOR/OUT/22	*	1					
10	J061-236-044-00	CLAMP/WIRE/36-44	*	2					
11	J061-230-038-00	CLAMP/WIRE/30-38	*	2					
12	1728-102-220-00	HOSE/290 ASSY	*	1					
13	J062-147-159-00	CLIP/HOSE/14.7-15.9	*	2					
14	1809-102-330-00	STAY/PLUG	*	1					
15	V231-360-801-60	FLANGEBOLT/M8X16	*	1					
16	1832-102-210-20	FRAME/RADIATOR COMP	*	1					
17	V211-360-802-00	BOLT,SP/M8X20	*	4					
18	V362-260-008-00	NUT/WASHER/M8	*	4					
19	1421-603-004-00	BUSH,LEVER	*	2					
20	1752-102-005-00	INSULATOR/15X15X280	*	2					
21	1716-601-009-00	TUBE/07X09X30	*	2					
22	1423-616-004-00	CUSHION/RUBBER/10X25	*	6					
23	V201-260-803-50	BOLT/M8X35	*	2					
24	1719-312-001-00	U-NUT	*	2					
25	4101-102-038-00	WASHER/24X9X3.2	*	2					
26	1832-102-230-10	COVER/RADIATOR COMP	*	1				7F	
27	V120-366-001-20	SCREW,SP/M6X12	*	4					
28	1729-604-003-00	SPRING	*	2					
29	1724-102-012-00	TRIM/188	*	1					
30	1685-604-003-00	INSULATOR/90	*	1					

FIG. 4 RADIATOR SYSTEM(SF224F TYPE)




1832-102A-0100

[illegible]

[illegible]

FIG. 6 MUFLER SYSTEM(SF224F TYPE)



1832-103A-0100

[illegible]


99



99

99


FIG. 8 CLEANER(AIR)SYSTEM(SF224F TYPE)



1832-104A-0100

[illegible]


FIG. 9 PIPING(FUEL)SYSTEM



1832-105 -0100

[illegible]

FIG. 10 TANK(FUEL)SYSTEM




1832-111 -0100

[illegible]

[illegible]

FIG. 12 BATTERY SYSTEM(SF224F TYPE)




1832-112A-0100

[illegible]

[illegible]

FIG. 14 CABLE(ACCELERATOR)SYSTEM



1832-118 -0100


[illegible]

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or engine housing. The central part is a main housing (2) with a flange (1). To the right, a cover plate (1) is shown with mounting pins (3) and a screw (4). Below the housing, a base plate (5) is shown with a screw (5). To the left, a long arm (11) is shown with a pin (12), a screw (15), and a bracket (13) with a pin (14) and a screw (16). A central vertical assembly includes a pin (6), a bracket (9), a pin (8), and a screw (10). A screw (7) is shown at the bottom of the housing. The diagram uses dashed lines to indicate the assembly path and alignment of the parts.

[illegible]

[illegible]

FIG. 18 GEAR(INPUT)SYSTEM




1832-204 -0100

[illegible]

[illegible]


FIG. 20 GEAR(INPUT)SYSTEM



1832-213 -0100

[illegible]

FIG. 22 DIFF-LOCK SYSTEM




1832-215 -0100

[illegible]

[illegible]


FIG. 24 METAL(PTO/BLOWER)SYSTEM(B TYPE)



1832-241 -0100


[illegible]

117



1832-241B-0100

[illegible]

FIG. 26 DRIVE(PTO/SIDE)SYSTEM

1832-244 -0100


KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1832-204-002-00	GEAR/HELICAL/31	*	1	1				
2	8680-201-009-00	BEARING/BALL/HPS	*	2	2				
3	1832-244-001-00	GEAR/HELICAL/28	*	1	1				
4	V600-110-620-60	BEARING, RB/6206	*	1	1				
5	V600-110-620-40	BEARING, RB/6204	*	1	1				
6	1825-127-300-00	CLUTCH/PTO ASSY	*	1	1				FIG 087
7	1832-244-200-00	GEAR/SPUR/26 COMP	*	1	1				
8	V600-110-620-40	BEARING, RB/6204	*	2	2				
9	V600-110-620-30	BEARING, RB/6203	*	1	1				
10	V704-140-017-00	RING, SNAP/17 C	*	1	1				
11	1832-244-002-00	GEAR/SPUR/33	*	1	1				
12	8680-201-009-00	BEARING/BALL/HPS	*	2	2				
13	1832-244-005-00	GEAR/SPUR/34	*	1	1				
14	V600-110-620-40	BEARING, RB/6204	*	2	2				
15	V705-140-034-00	RING, SNAP/34 C	*	1	1				
16	1614-222-007-00	SEAL/OIL	*	1	1				
17	V723-102-003-40	O-RING/1A, S34	*	1	1				
18	1832-244-004-00	METAL/PTO/MOWER	*	1	1				
19	V523-101-002-20	PIN, ST, B/10X22	*	2	2				
20	V231-360-802-50	FLANGE BOLT/M8X25	*	9	9				
21	1832-244-003-00	SHAFT/465	*	1	1				
22	1673-431-001-10	COUPLING/16X27X55	*	2	2				
23	1832-244-230-00	TUBE/540 COMP	*	1	1				
24	1771-244-011-10	METAL/PTO/B	*	1	1				
25	V211-661-003-00	BOLT, SP/M10X30/7T	*	4	4				
26	1832-244-006-00	SHAFT/PTO	*	1	1				
27	1729-202-014-00	BEARING/BALL	*	1	1				
28	1832-244-007-00	BEARING/BALL/HPS	*	1	1				
29	V705-140-052-00	RING, SNAP/52 C	*	1	1				

119




119

119

[illegible]


[illegible]

FIG. 30 LINK(HST)SYSTEM


1832-271 -0100


KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1832-271-210-00	ARM/TRUNNION COMP	*	1	1				
2	1646-226-053-00	BOLT/SM/M10X23	*	1	1				
3	1689-271-006-00	WASHER/38X12X2	*	2	2				
4	V600-150-620-10	BEARING,RB/6201SS	*	1	1				
5	V401-160-012-00	WASHER,SP/M12	*	1	1				
6	V305-260-012-00	NUT/M12	*	1	1				
7	1832-271-240-00	BRACKET/NEUTRAL COMP	*	1	1				
8	V211-560-802-00	BOLT,S/M8X20/7T	*	2	2				
9	1832-271-230-00	PLATE/ADJUST COMP	*	1	1				
10	V363-260-010-00	NUT/WASHER/M10	*	1	1				
11	1832-271-260-00	ARM/NEUTRAL ASSY	*	1	1				
12	2504-135-008-10	BUSH/18X20X20	*	1	1				
13	2144-419-022-00	WASHER/18X26X02	*	1	1				
14	V704-140-018-00	RING,SNAP/18 C	*	1	1				
15	2500-210-016-00	SPRING/HE108	*	1	1				
16	1832-271-002-00	ROD/M08X47	*	1	1				
17	V304-260-008-00	NUT/M8	*	2	2				
18	1560-695-021-00	JOINT BALL M08RH	*	1	1				
19	V304-260-008-00	NUT/M8	*	1	1				
20	1683-271-560-00	ROD/M08X110 COMP	*	1	1				
21	1560-132-007-30	NUT/LH/M08	*	1	1				
22	1560-695-022-00	JOINT BALL M08LH	*	1	1				
23	V401-160-008-00	WASHER,SP/M8	*	2	2				
24	V304-260-008-00	NUT/M8	*	2	2				
25	1832-271-250-00	ARM/HST ASSY	*	1	1				
26	2504-135-008-10	BUSH/18X20X20	*	1	1				
27	2144-419-022-00	WASHER/18X26X02	*	1	1				
28	V704-140-018-00	RING,SNAP/18 C	*	1	1				
29	1832-271-001-00	PIN/COUNTER/HST	*	1	1				
30	3504-418-007-10	WASHER,SUPPORT	*	1	1				

FIG. 30 LINK(HST)SYSTEM



1832-271 -0100

[illegible]

FIG. 31 PEDAL(HST)SYSTEM


1832-272 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1689-272-260-00	PEDAL/HST/F COMP	*	1	1				
2	1747-640-067-00	PAD/HST	*	1	1				
3	V211-360-801-60	BOLT,SP/M8X16	*	1	1				
4	1832-272-210-00	ARM/HST/F COMP	*	1	1				
5	V411-260-006-00	WASHER,PL/M6	*	1	1				
6	V760-150-000-00	NIPPLE,GREASE	*	1	1				
7	1832-272-001-10	PLATE/I/16X217	*	1	1				
8	V411-260-008-00	WASHER,PL/M8	*	2	2				
9	V500-162-502-00	PIN,SPLIT/2.5X20	*	2	2				
10	1832-272-260-10	ARM/COUNTER/FRONT	*	1	1				
11	1725-433-202-10	BUSH/22X25X25	*	2	2				
12	1832-272-003-00	PLATE/I/16X1105	*	1	1				
13	V411-260-008-00	WASHER,PL/M8	*	2	2				
14	V500-162-502-00	PIN,SPLIT/2.5X20	*	2	2				
15	1689-272-240-00	PEDAL/HST/RH COMP	*	1	1				
16	1774-272-071-00	PAD/HST/R	*	1	1				
17	V211-360-801-60	BOLT,SP/M8X16	*	1	1				
18	1832-272-220-10	ARM/HST/R COMP	*	1	1				
19	V411-260-006-00	WASHER,PL/M6	*	1	1				
20	V760-150-000-00	NIPPLE,GREASE	*	1	1				
21	V411-260-022-00	WASHER,PL/M22	*	1	1				
22	V704-140-022-00	RING,SNAP/22 C	*	1	1				
23	1832-272-001-10	PLATE/I/16X217	*	1	1				
24	V411-260-008-00	WASHER,PL/M8	*	2	2				
25	V500-162-502-00	PIN,SPLIT/2.5X20	*	2	2				
26	1832-272-270-10	ARM/COUNTER/REA ASSY	*	1	1				
27	1725-433-202-10	BUSH/22X25X25	*	2	2				
28	1832-272-003-00	PLATE/I/16X1105	*	1	1				
29	V411-260-008-00	WASHER,PL/M8	*	2	2				
30	V500-162-502-00	PIN,SPLIT/2.5X20	*	2	2				

125

This diagram shows an exploded view of a mechanical assembly. The main components are labeled with numbers 1 through 13. Part 1 is a long, central shaft or frame. Part 2 is a small pin or bolt. Part 3 is a large, complex housing or bracket. Part 4 is a small pin or bolt. Part 5 is a small pin or bolt. Part 6 is a small pin or bolt. Part 7 is a small pin or bolt. Part 8 is a small pin or bolt. Part 9 is a small pin or bolt. Part 10 is a small pin or bolt. Part 11 is a small pin or bolt. Part 12 is a long, thin plate or bracket. Part 13 is a small pin or bolt. Part 16-1 is a large, complex housing or bracket, shown in a dashed outline to indicate its position relative to the other parts.

[illegible]


<https://truckmanualshub.com/>



<https://truckmanualshub.com/>


<https://truckmanualshub.com/>

FIG. 34 BRAKE SYSTEM



1832-310 -0100


[illegible]

FIG. 35 PEDAL(BRAKE)SYSTEM

1832-312 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1832-312-220-00	ARM/BRAKE COMP	*	1	1				
2	V411-260-006-00	WASHER,PL/M6	*	1	1				
3	V760-150-000-00	NIPPLE,GREASE	*	1	1				
4	V411-260-022-00	WASHER,PL/M22	*	1	1				
5	V704-140-022-00	RING,SNAP/22 C	*	1	1				
6	1650-135-002-00	SPRING/HE095	*	1	1				
7	1832-312-210-00	PEDAL/BRAKE COMP	*	1	1				
8	1524-122-001-10	PAD	*	1	1				
9	V231-361-002-00	FLANGEBOLT/M10X20	*	2	2				
10	1832-312-280-00	PLATE/BRAKE COMP	*	1	1				
11	V411-260-008-00	WASHER,PL/M8	*	1	1				
12	V500-162-502-00	PIN,SPLIT/2.5X20	*	1	1				
13	1832-312-230-00	ARM/COUNTER/BRAKE	*	1	1				
14	V411-260-006-00	WASHER,PL/M6	*	1	1				
15	V760-150-000-00	NIPPLE,GREASE	*	1	1				
16	V411-260-022-00	WASHER,PL/M22	*	1	1				
17	V704-140-022-00	RING,SNAP/22 C	*	1	1				
18	1832-312-002-00	PLATE/I/19X927	*	1	1				
19	V411-260-008-00	WASHER,PL/M8	*	2	2				
20	V500-162-502-00	PIN,SPLIT/2.5X20	*	2	2				
21	1832-312-240-10	SHAFT/BRAKE COMP	*	1	1				
22	V411-260-022-00	WASHER,PL/M22	*	2	2				
23	V500-164-003-00	PIN,SPLIT/4X30	*	2	2				
24	1832-312-270-00	HUB/BRAKE/SHAFT COMP	*	1	1				
25	V411-260-006-00	WASHER,PL/M6	*	1	1				
26	V760-150-000-00	NIPPLE,GREASE	*	1	1				
27	V211-561-002-00	BOLT,S/M10X20/7T	*	2	2				
28	1832-312-260-00	ARM/BRAKE/SHAFT COMP	*	2	2				
29	V530-160-803-20	PIN/GROOVE	*	2	2				
30	1832-312-003-00	RBB/FLANGE	*	1	1				

FIG. 35 PEDAL(BRAKE)SYSTEM




1832-312 -0100

[illegible]

131

FIG. 37 WHEEL(FRONT)SYSTEM




1832-317 -0100

[illegible]

[illegible]


FIG. 39 COLUMN(STEERING)SYSTEM



1832-405 -0100

[illegible]

FIG. 40 CONTROLLER(STEERING)SET SYSTEM


[illegible]

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor. The main assembly is shown in the center, with various parts numbered 1 through 18. Callouts A and B indicate specific assembly points or orientations. The diagram includes several sub-figures: FIG. 40 shows a detailed view of a component with multiple ports; FIG. 49 shows a component with a flange and a mounting bracket; and FIG. 42-13 and FIG. 43-13 show components with mounting brackets. The main assembly consists of a central shaft (1) with various seals (3, 10, 11), bearings (4, 5, 6), and a housing (2). The housing is secured with bolts (13, 14) and a cover (12). The diagram also shows a mounting bracket (17) and a component (18) that fits into the assembly.

[illegible]

[illegible]

FIG. 43 FRAME SYSTEM(EXCEPT B TYPE)



1832-410B-0100

[illegible]

This exploded view diagram illustrates the assembly of a mechanical component, likely a door or panel. The parts are numbered as follows:

- 1**: Main vertical panel or door.
- 2**: Side panel or frame component.
- 3**: Small L-shaped bracket.
- 4**: Long horizontal bracket or rail.
- 5**: Small pin or fastener.
- 6**: Small circular fastener or pin.
- 7**: Small angled bracket.
- 8**: Top frame or header component.
- 9**: Small circular fastener or pin.
- 10**: Small circular fastener or pin.
- 11**: Small rectangular plate or gasket.
- 12**: Small circular fastener or pin.
- 13**: Small rectangular plate or gasket.
- 14**: Small circular fastener or pin.
- 15**: Small circular fastener or pin.
- 16**: Long horizontal plate with multiple holes.
- 17**: Small circular fastener or pin.
- 18**: Small rectangular plate with multiple holes.
- 19**: Small circular fastener or pin.
- 20**: Small L-shaped bracket.
- 21**: Small circular fastener or pin.
- 42-6**: Sub-assembly or component.
- 42-13**: Sub-assembly or component.

[illegible]

This exploded view diagram illustrates the assembly of a mechanical component, likely a bracket or support structure. The parts are numbered as follows:

- 1**: Main vertical support plate.
- 2**: Horizontal plate with mounting holes.
- 3**: Small L-shaped bracket.
- 4**: Horizontal plate with mounting holes.
- 5**: Small L-shaped bracket.
- 6**: Small L-shaped bracket.
- 7**: Small L-shaped bracket.
- 8**: Main vertical support plate.
- 9**: Small L-shaped bracket.
- 10**: Small circular component, possibly a washer or pin.
- 11**: Horizontal plate with mounting holes.
- 12**: Small L-shaped bracket.
- 13**: Horizontal plate with mounting holes.
- 14**: Small L-shaped bracket.
- 15**: Small L-shaped bracket.
- 16**: Horizontal plate with mounting holes.
- 17**: Horizontal plate with mounting holes.
- 18**: Horizontal plate with mounting holes.
- 19**: Horizontal plate with mounting holes.
- 20**: Horizontal plate with mounting holes.
- 21**: Horizontal plate with mounting holes.

The diagram shows the relative positions and assembly sequence of these parts, with dashed lines indicating the alignment and fit of the components.

[illegible]

[illegible]

FIG. 47 LEVER(4WD)SYSTEM




[illegible]

FIG. 48 AUTO(4WD)SYSTEM

1832-431 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1832-431-210-00	SHAFT/4WD ASSY	*	1	1				
2	2213-312-013-00	BOLT/SEAL/M8X30X9T	*	2	2				
3	1832-431-003-00	CASE/4WD	*	1	1				
4	V782-160-000-4B	PLUG/SCREW/SEAL	*	2	2				
5	V705-140-045-00	RING,SNAP/45 C	*	1	1				
6	V744-125-450-80	SEAL,OIL/TC25458	*	1	1				
7	V721-103-106-50	O-RING/1A,G65	*	1	1				
8	1832-431-004-00	HUB/12X22X30	*	2	2				
9	1832-431-005-00	HUB/12X22X97	*	2	2				
10	V411-260-010-00	WASHER,PL/M10	*	4	4				
11	V401-160-010-00	WASHER,SP/M10	*	4	4				
12	1832-431-006-00	BOLT/M10X190	*	4	4				
13	1720-221-210-00	CLUTCH ASSY	*	1	1				FIG 084
14	1720-221-230-00	SLEEVE ASSY	*	1	1				
15	1832-431-001-00	SHAFT/OUTPUT	*	1	1				
16	V600-110-620-40	BEARING,RB/6204	*	2	2				
17	V744-120-350-70	SEAL,OIL/TC20357	*	1	1				
18	V705-140-047-00	RING,SNAP/47 C	*	1	1				
19	1832-431-002-00	METAL/4WD	*	1	1				
20	V782-160-000-2B	PLUG/SCREW/SEAL	*	2	2				
21	V523-101-002-20	PIN,ST,B/10X22	*	2	2				
22	V231-360-802-50	FLANGEBOLT/M8X25	*	4	4				
23	1832-431-220-00	ARM/4WD COMP	*	1	1				
24	V720-103-502-40	O-RING/1A,P24	*	1	1				
25	1832-431-007-00	PLATE	*	1	1				
26	V231-360-801-60	FLANGEBOLT/M8X16	*	2	2				
27	1560-531-020-00	SPRING/HE068	*	1	1				
28	V304-260-008-00	NUT/M8	*	1	1				
29	V201-360-804-00	BOLT/M8X40/7T	*	1	1				
30	1832-431-230-10	COVER/4WD COMP	*	1	1			7F	

FIG. 48 AUTO(4WD)SYSTEM




1832-431 -0100

[illegible]


FIG. 49 HOUSING(AXLE/REAR)SYSTEM(1/3)

20~30-PLEASE SEE 2/3 PAGE



1832-433 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1725-432-101-00	PINION/BEVEL/09	*	1	1				
2	1773-434-012-00	BEARING/BALL	*	3	3				
3	1725-432-110-00	WASHER/25X42X02	*	1	1				
4	1725-218-109-00	RING/SNAP/CS25	*	1	1				
5	1725-432-107-00	COLLAR/48X52X17	*	1	1				
6	1725-219-121-00	RING/SNAP/CR52	*	1	1				
7	1776-432-003-00	SEAL/OIL	*	1	1				
8	1725-432-711-00	CASE/DIFFERENTIAL/FR	*	1	1				
9	1725-432-712-10	PINION/BEVEL/11	*	2	2				
10	1725-432-713-00	GEAR/BEVEL/15	*	2	2				
11	1725-432-714-00	PIN/12X75	*	1	1				
12	1725-432-715-00	PIN/SPRING	*	1	1				
13		WIRE	*	1	1				
14	1725-432-801-00	BEARING/6010/KBC	*	2	2				
15	1725-432-113-00	RING/SNAP/CS50	*	1	1				
16	1725-432-108-00	GEAR/BEVEL/21	*	1	1				
17	1725-432-114-00	RING/SNAP/CS40	*	1	1				
18	1832-433-200-00	HOUSING/AXLE ASSY	*	1	1				
19	1725-433-202-10	BUSH/22X25X25	*	2	2				
20	1725-434-101-00	CASE/FINAL/UPPER/LH	*	1	1				
21	1725-434-114-00	RING/O/1A/G90	*	1	1				
22	1725-434-115-00	BOLT/S/M12X30	*	4	4				
23	1725-304-713-00	PIN/B	*	2	2				
24	1725-434-111-00	CASE/FINAL/UPPER/RH	*	1	1				
25	1725-434-114-00	RING/O/1A/G90	*	1	1				
26	1725-434-115-00	BOLT/S/M12X30	*	4	4				
27	1725-304-713-00	PIN/B	*	2	2				
28	1832-434-001-00	GEAR/BEVEL/11	*	2	2				
29	1725-434-116-00	BEARING/6206/KBC	*	2	2				
30	1725-308-103-00	RING/SNAP/CR62	*	2	2				

FIG. 49 HOUSING(AXLE/REAR)SYSTEM(2/3)


47~54,60-PLEASE SEE 3/3 PAGE

1832-433 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
31	1832-434-002-00	GEAR/BEVEL/17	*	2	2				
32	1725-201-806-00	BEARING/6205/KBC	*	2	2				
33	1725-434-005-00	SEAL/OIL ASSY	*	2	2				
34	1725-434-047-00	BEARING/BALL/6909	*	2	2				
35	1836-432-204-00	R.B.B/6908/KOYO	*	2	2				
36	1725-432-114-00	RING/SNAP/CS40	*	2	2				
37	1725-308-103-00	RING/SNAP/CR62	*	2	2				
38	1832-434-102-00	CASE/FINAL/LOWER/LH	*	1	1				
39	1725-219-121-00	RING/SNAP/CR52	*	1	1				
40	1725-434-122-00	PLUG/52X10	*	1	1				
41	1832-434-101-00	CASE/FINAL/LOWER/RH	*	1	1				
42	1725-434-121-00	PLUG/SCREW/R1/4	*	2	2				
43	1725-219-121-00	RING/SNAP/CR52	*	1	1				
44	1725-434-122-00	PLUG/52X10	*	1	1				
45	1725-434-113-00	GEAR/BEVEL/09	*	2	2				
46	1725-219-122-00	BEARING/6304/KBC	*	2	2				
47	1725-434-106-00	SHAFT/WHEEL	*	2	2				
48	1725-434-107-00	GEAR/BEVEL/35	*	2	2				
49	1725-434-123-00	WASHER/27X36X03	*	4	4				
50	1725-434-013-00	SEAL/OIL ASSY	*	2	2				
51	1725-201-806-00	BEARING/6205/KBC	*	2	2				
52	1725-434-116-00	BEARING/6206/KBC	*	2	2				
53	1725-434-108-00	COVER/WHEEL	*	2	2				
54	1725-434-124-00	BOLT/SP/M10X30	*	12	12				
55	1832-434-004-00	SHAFT/450	*	1	1				
56	1832-434-003-00	SHAFT/100	*	1	1				
57	1518-432-250-10	CAP,OIL	*	1	1				
58	1518-306-203-10	PACKING	*	1	1				
59	V782-160-000-4B	PLUG/SCREW/SEAL	*	2	2				
60	1832-433-250-00	PIN/PIVOT COMP	*	1	1				

[illegible]


FIG. 50 ROD(TIE)SYSTEM



1725-436A-0100

[illegible]


[illegible]

FIG. 52 CONTROL SYSTEM

1832-503 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1832-503-250-00	BRACKET/VALVE COMP	*	1	1				
2	V211-261-002-50	BOLT,S/M10X25	*	2	2				
3	1832-503-210-00	ARM/SPOOL COMP	*	3	3				
4	1832-503-003-00	PIN/10X101	*	1	1				
5	V411-260-010-00	WASHER,PL/M10	*	1	1				
6	V500-162-502-50	PIN,SPLIT/2.5X25	*	1	1				
7	1771-503-003-00	PIN/05X17	*	3	3				
8	V411-260-005-00	WASHER,PL/M5	*	3	3				
9	V560-160-005-00	PIN/SNAP	*	3	3				
10	1832-503-220-00	ARM/LIFT/MOWER COMP	*	1	1				
11	1809-503-220-10	LEVER/LIFT COMP	*	1	1				
12	2145-586-002-00	PIN/6X42	*	1	1				
13	V411-260-006-00	WASHER,PL/M6	*	1	1				
14	V500-162-002-00	PIN,SPLIT/2X20	*	1	1				
15	1809-503-003-00	SPRING/PLATE	*	1	1				
16	V230-360-601-00	FLANGEBOLT/M6X10	*	2	2				
17	1444-307-007-00	GRIP	*	1	1				
18	1832-503-001-00	PLATE/I/19X254	*	1	1				
19	V411-260-008-00	WASHER,PL/M8	*	2	2				
20	V560-160-008-00	PIN/SNAP	*	2	2				
21	1832-503-230-00	ARM/LIFT/COLLECTOR	*	1	1				
22	1832-503-270-10	LEVER/COLLECTOR COMP	*	1	1				
23	2145-586-002-00	PIN/6X42	*	1	1				
24	V411-260-006-00	WASHER,PL/M6	*	1	1				
25	V500-162-002-00	PIN,SPLIT/2X20	*	1	1				
26	1809-503-003-00	SPRING/PLATE	*	1	1				
27	V230-360-601-00	FLANGEBOLT/M6X10	*	2	2				
28	1444-307-007-00	GRIP	*	1	1				
29	1832-503-002-00	PLATE/I/19X140	*	1	1				
30	V411-260-008-00	WASHER,PL/M8	*	2	2				


FIG. 52 CONTROL SYSTEM




1832-503 -0100

[illegible]

1832-504 -0100






1832-508 -0100

[illegible]

FIG. 55 PIPING(CONTROL)SYSTEM(1/2)

17~30-PLEASE SEE 2/2 PAGE



1832-509 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1728-508-280-10	VALVE/1S-2D ASSY	*	1	1				
2	K275-001-003-00	PLUG(PF1/4)	*	4	4				
3	V210-360-603-50	BOLT,SP/M6X35	*	2	2				
4	V301-260-006-00	NUT/M6	*	2	2				
5	V210-360-602-00	BOLT,SP/M6X20	*	1	1				
6	1832-509-280-00	HOSE/HYDRO/1800 ASSY	*	1	1				
7	1725-509-260-00	ADAPTER/G1/4 ASSY	*	1	1				
8	V720-112-401-10	O-RING/1B,P11	*	1	1				
9	3829-387-410-00	ADPTER/G1/4.1/4	*	2	2				
10	V720-112-401-10	O-RING/1B,P11	*	2	2				
11	1832-509-330-00	HOSE/HYDRO/600 ASSY	*	1	1				
12	1705-408-230-00	ADAPTER/L/G1/4 ASSY	*	1	1				
13	V720-112-401-10	O-RING/1B,P11	*	1	1				
14	1832-509-320-00	HOSE/HYDRO/1000 ASSY	*	1	1				
15	1832-509-290-00	HOSE/HYDRO/1550 ASSY	*	1	1				
16	1832-509-003-00	ADAPTER/G1/4	*	1	1				
17	K200-282-000-00	VALVE/282 ASSY	*	1	1				
18	K200-152-110-20	VALVE/REDUCE/21 SET	*	1	1				
19	V720-112-402-20	O-RING/1B,P22	*	1	1				
20	V720-112-401-60	O-RING/1B,P16	*	3	3				
21	K290-003-000-30	VALVE/PRV/B ASSY	*	2	2				
22	V720-112-402-00	O-RING/1B,P20	*	2	2				
23	K290-001-001-00	O-RING/AS568/013	*	2	2				
24	K290-001-002-00	O-RING/AS568/014	*	2	2				
25	K290-001-003-00	O-RING/AS568/015	*	2	2				
26	V780-140-000-1T	PLUG/SCREW/SEAL	*	1	1				
27	1832-509-270-00	RELIEFVALVE/090 ASSY	*	1	1				
28	K250-090-002-00	SPRING/HC045	*	1	1				
29	K250-090-003-00	POPPET/1.3	*	1	1				
30	1832-509-230-00	ADAPTER/G1/4XG3/8	*	1	1				

155

[illegible]

This diagram shows an exploded view of a mechanical assembly. The components are numbered as follows:

- 1: Cable with connector
- 2: Cable with connector
- 3: Mounting plate
- 4: Cylindrical component
- 5: Small connector
- 6: Small connector
- 7: Cable with connector
- 8: Cable with connector
- 9: Cable with connector
- 10: Small connector
- 11: Coiled cable
- 12: Small connector
- 13: Cable with connector
- 14: Cable with connector
- 15: Cable with connector
- 16: Cable with connector
- 17: Cable with connector
- 18: Cable with connector
- 19: Cable with connector
- 19-1: Cable with connector
- 20: Cable with connector
- 21: Cable with connector
- 22: Cable with connector
- 23: Cable with connector
- 24: Cable with connector
- 25: Cable with connector
- 42-13: Cable with connector
- 43-13: Cable with connector
- 42-6: Cable with connector
- 43-6: Cable with connector
- 55-11: Cable with connector
- 55-16: Cable with connector

[illegible]



[illegible]

FIG. 58 HOOD SYSTEM




1832-601 -0100

[illegible]

[illegible]

FIG. 60 FENDER SYSTEM




1832-606 -0100

[illegible]


[illegible]

FIG. 62 FLOOR SYSTEM



1832-630 -0100


[illegible]

FIG. 63 LIGHT SYSTEM(B TYPE)

1832-650 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1832-650-210-00	STAY/LAMP/FRONT COMP	*	1	1				
2	V231-361-007-00	FLANGEBOLT/M10X70	*	2	2				
3	1725-611-087-00	U-NUT/M10X1.5	*	2	2				
4	1809-650-006-00	CAP/PIPE	*	2	2				
5	1809-650-230-00	LAMP/HEAD/LH ASSY	*	1	1				
6	1774-650-212-00	BULB/H4/60/55W	*	1	1				
7	1772-654-216-00	BULB/12V21W	*	1	1				
8	1809-650-232-00	BULB/12V4W	*	1	1				
9	1809-650-233-00	UNUT(M8)	*	2	2				
10	1809-650-240-00	LAMP/HEAD/RH ASSY	*	1	1				
11	1774-650-212-00	BULB/H4/60/55W	*	1	1				
12	1772-654-216-00	BULB/12V21W	*	1	1				
13	1809-650-232-00	BULB/12V4W	*	1	1				
14	1809-650-233-00	UNUT(M8)	*	2	2				
15	1674-619-300-10	MIRROR ASSY	*	2	2				
16	1674-619-310-00	ARM/MIRROR ASSY	*	2	2				
17	V230-360-601-60	FLANGEBOLT/M6X16	*	4	4				
18	1832-650-310-00	BUMPER/REAR COMP	*	1	1				
19	V231-361-202-50	FLANGEBOLT/M12X25	*	4	4				
20	1772-654-210-00	LAMP/COMBINATION/REA	*	2	2				FIG 086
21	1772-654-001-00	INSULATOR/LAMP	*	2	2				
22	1772-654-002-10	PLATE/U/70X85	*	2	2				
23	1560-666-004-00	BAND	*	2	2				
24	P113-201-007-00	TRIM/70	*	4	4				
25	V411-260-012-00	WASHER,PL/M12	*	4	4				
26	1674-654-270-00	LAMP/NUMBERPLAT SET	*	1	1				
27	1674-654-271-00	BULB/12V/5W	*	1	1				
28	1674-654-272-00	HARNESS/LAMP	*	1	1				
29	4335-512-004-00	GROMMET/9	*	2	2				
30	1809-650-012-00	STOPPER/B	*	2	2				

FIG. 63 LIGHT SYSTEM(B TYPE)



1832-650 -0100

[illegible]


165



165


165

FIG. 65 PANEL(SWITCH)SYSTEM



1832-670 -0100


[illegible]

FIG. 66 SWITCH(SAFETY)SYSTEM(1/2)

1832-680 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	1719-650-250-00	RELAY ASSY	*	1	1				
2	V360-260-005-00	NUT/WASHER/M5	*	1	1				
3	1719-650-250-00	RELAY ASSY	*	1	1				
4	V111-165-001-20	SCREW/M5X12	*	1	1				
5	1800-652-400-00	RELAY/5P ASSY	*	2	2				
6	1800-652-400-00	RELAY/5P ASSY	*	2	2				
7	1800-652-400-00	RELAY/5P ASSY	*	2	2				
8	1800-652-400-00	RELAY/5P ASSY	*	2	2				
9	1800-652-400-00	RELAY/5P ASSY	*	2	2				
10	1800-652-400-00	RELAY/5P ASSY	*	2	2				
11	1719-650-250-00	RELAY ASSY	*	4	4				
12	V360-260-005-00	NUT/WASHER/M5	*	4	4				
13	1774-680-250-00	UNIT/TIMER ASSY	*	1	1				
14	V360-260-006-00	NUT/WASHER/M6	*	1	1				
15	1739-681-220-20	RELAY/FLASHER/EEC	*	1	1				
16	V360-260-006-00	NUT/WASHER/M6	*	1	1				
17	1740-680-530-20	HORN ASSY	*	1	1				
18	V360-260-006-00	NUT/WASHER/M6	*	2	2				
19	1690-650-320-00	HORN ASSY	*	1	1				
20	V360-260-006-00	NUT/WASHER/M6	*	1	1				
21	2515-665-210-00	BUZZER	*	1	1				
22	V210-360-601-60	BOLT,SP/M6X16	*	1	1				
23	1772-654-250-10	SWITCH/PUSH ASSY	*	1	1				
24	1772-654-251-00	NUT	*	2	2				
25	1772-654-280-10	SWITCH/PUSH ASSY	*	1	1				
26	1772-654-281-00	NUT	*	2	2				
27	1772-654-282-00	BOOT	*	1	1				
28	1716-680-330-10	SWITCH/LEVER ASSY	*	1	1				
29	1716-680-222-00	ARM	*	1	1				
30	V210-360-601-60	BOLT,SP/M6X16	*	1	1				

FIG. 66 SWITCH(SAFETY)SYSTEM(2/2)




1832-680 -0100

[illegible]

[illegible]

FIG. 68 HARNESS SYSTEM(SF224F TYPE)




1832-690A-0100

[illegible]

[illegible]

FIG. 70 FRAME(MAIN)SYSTEM




1832-701 -0100

[illegible]


[illegible]

FIG. 72 BLOWER SYSTEM(B TYPE)



1832-801 -0100


[illegible]



1832-901 -0100

[illegible]

FIG. 74 ORNAMENT(SF224F TYPE)




1832-901A-0100

[illegible]

[illegible]

FIG. 76 LABEL(CAUTION)(SF235F TYPE)



1832-903 -0100

[illegible]

179




[illegible]


FIG. 78 LABEL(CE)



1709-905 -0100

[illegible]


**FIG. 79 WEIGHT(REAR)SET SYSTEM
(EXCEPT B TYPE-STANDARD/
B TYPE-OPTION)**



1771-923 -0100

[illegible]

**FIG. 80 PLATE(BUMPER)&BOLT SYSTEM
(OPTION)**




1728-410B-0100

[illegible]

[illegible]

FIG. 82 COMPONENT PARTS FOR K500-008-000-00 ON Fig.19



K500-008-000-0A

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SF224F	SF235F				
1	K 500-008-001-00	CASE/HMP1/008	*	1	1				
2	K 500-008-004-00	BLOCK/PORT/HMP1/008	*	1	1				
3	K 500-006-300-10	BLOCK/CYLINDER/HMP1	*	2	2				
4	K 500-006-006-10	PLATE/SWASH/HMP1/006	*	1	1				
5	K 510-001-010-00	PLATE/VALVE/PUMP	*	1	1				
6	K 510-001-011-00	PLATE/VALVE/MOTOR	*	1	1				
7	K 500-008-012-00	SHAFT/PUMP/HMP1/008	*	1	1				
8	K 500-008-013-00	SHAFT/MOTOR/HMP1/008	*	1	1				
9	V 600-110-630-50	BEARING,RB/6305	*	2	2				
10	K 500-006-015-00	PLATE/THRUST/HMP1/00	*	2	2				
11	K 510-001-016-00	NEEDLE	*	2	2				
12	K 500-006-017-00	BUSH/40X44X15	*	2	2				
13	K 510-001-020-00	SPRING/HC030	*	2	2				
14	K 510-003-021-00	SPRING/HC021	*	1	1				
15	K 510-003-022-00	POPPET/RELIEF	*	1	1				
16	K 510-003-037-00	PLATE/SPRING	*	1	1				
17	K 510-005-023-00	POPPET/CHECK/0.5	*	1	1				
18	K 500-008-023-00	POPPET/CHECK/0.9X2	*	1	1				
19	K 500-008-026-00	GASKET/HMP1/008	*	1	1				
20	K 510-001-029-00	PLUG(G3/8)	*	2	2				
21	K 275-001-003-00	PLUG(PF1/4)	*	4	4				
22	V 720-112-401-40	O-RING/1B,P14	*	2	2				
23	V 720-112-401-10	O-RING/1B,P11	*	4	4				
24	V 704-140-025-00	RING,SNAP/25 C	*	2	2				
25	1 710-241-053-00	RING,SNAP/R62	*	3	3				
26	V 705-140-032-00	RING,SNAP/32 C	*	2	2				
27	3 640-547-007-00	PLUG,CAP/62X6	*	1	1				
28	K 510-001-039-00	OIL SEAL	*	3	3				
29	K 500-008-034-00	COVER/BUSH/HMP1/008	*	1	1				
30	K 500-008-035-00	COVER/TRUNNION/HMP1/	*	1	1				

[illegible]


[illegible][illegible]

This diagram illustrates the exploded view of a mechanical assembly, showing 13 numbered components arranged in a linear sequence from left to right. The components are as follows:

- 1:** A small circular ring or washer.
- 2:** A small circular ring or washer.
- 3:** A small circular ring or washer.
- 4:** A larger circular ring or washer.
- 5:** A circular component with a central hole and a flange.
- 6:** A circular component with a central hole and a flange.
- 7:** A circular component with a central hole and a flange.
- 8:** A circular component with a central hole and a flange.
- 9:** A circular component with a central hole and a flange.
- 10:** A circular component with a central hole and a flange.
- 11:** A small circular component, likely a pin or screw.
- 12:** A circular component with a central hole and a flange.
- 13:** A circular component with a central hole and a flange.

[illegible]


**FIG. 85 COMPONENT PARTS
FOR 1725-219-720-20 ON Fig.27,28**



1725-219-720-2C

[illegible]

**FIG. 86 COMPONENT PARTS
FOR 1772-654-210-00 ON Fig.63,64**



1772-654-210-0B



[illegible]

This diagram shows an exploded view of a mechanical assembly, likely a pump or valve. The components are numbered 1 through 14. The assembly is shown in a perspective view, with a dashed line indicating the assembly path. The components are arranged in a linear sequence, with the following parts identified by their numbers:



- 1: A central shaft or rod.
- 2: A large, flanged component, possibly a valve or pump head.
- 3: A small, circular component, possibly a seal or gasket.
- 4: A threaded component, possibly a nut or bolt.
- 5: A series of five small, circular components, possibly seals or gaskets.
- 6: A series of five larger, circular components, possibly seals or gaskets.
- 7: A small, circular component, possibly a seal or gasket.
- 8: A small, circular component, possibly a seal or gasket.
- 9: A small, circular component, possibly a seal or gasket.
- 10: A small, circular component, possibly a seal or gasket.
- 11: A small, circular component, possibly a seal or gasket.
- 12: A series of three small, circular components, possibly seals or gaskets.
- 13: A small, circular component, possibly a seal or gasket.
- 14: A small, circular component, possibly a seal or gasket.

[illegible]

WIRING DIAGRAM (1/2)



WIRING DIAGRAM (2/2)



Numerical Index

6004-097-690-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
1373-121-001-00	24 4	6209-610-009-00	6 4	6211-511-023-00	6 11
1425-621-004-00	10 14	6209-625-001-00	6 14	6211-511-024-00	6 12
1729-202-001-00	21 14		27 10	6211-540-018-00	7 1
1729-202-002-00	10 44	6209-625-002-00	10 7	6211-560-007-00	7 3
3625-540-004-00	10 35		27 12	6211-599-012-00	6 13
3640-586-004-00	22 4	6209-630-002-10	25 7		7 2
3805-355-002-20	8 2		27 22		7 4
3817-401-001-00	10 10	6209-730-002-00	16 4	6211-751-001-10	3 2
	12 20	6209-730-005-00	13 3	6211-760-035-20	6 29
	18 7		21 12	6211-766-025-00	6 30
	18 12	6209-740-001-00	10 26	6211-777-007-30	11 1
	21 9	6209-740-005-00	6 17	6212-111-094-20	14 1
6004-010-170-00	1 1	6209-749-001-20	6 15	6212-114-094-20	15 1
6209-000-002-00	12 18		10 41	6212-116-094-20	15 3
6209-000-004-10	6 2	6209-920-002-00	10 20	6212-121-014-20	14 2
6209-000-043-00	16 9		17 12	6212-124-014-10	15 2
6209-000-044-00	2 7		27 13	6212-126-014-10	15 4
6209-030-043-00	21 18	6209-940-004-00	12 14	6212-211-001-10	14 3
6209-030-044-00	19 5	6211-110-057-50	2 1	6212-230-004-10	14 5
6209-046-015-00	16 7	6211-141-029-20	2 6	6212-235-005-00	14 6
6209-050-001-00	10 32		27 3	6212-271-016-00	14 7
6209-050-002-00	10 33	6211-170-004-20	3 1	6212-274-016-00	7 5
6209-300-014-00	2 8	6211-173-003-00	3 3	6212-276-016-00	7 6
6209-360-011-00	22 3		27 4	6212-310-019-60	16 1
6209-360-028-20	3 6	6211-210-113-10	6 1	6212-330-083-10	16 5
6209-360-143-00	22 6	6211-258-001-00	6 8	6212-333-009-00	16 6
6209-409-001-00	10 18		27 8	6212-371-081-00	16 8
6209-409-003-00	12 17	6211-258-002-00	6 9	6212-511-002-00	13 1
6209-440-005-00	25 4		27 9	6212-521-008-00	16 3
6209-440-007-00	24 6	6211-291-015-20	6 25	6212-522-010-00	13 2
6209-490-002-10	3 4	6211-292-001-20	6 26	6212-523-023-00	13 6
6209-500-003-00	10 16		27 11	6212-524-002-40	21 11
	10 25	6211-310-025-50	10 1	6212-530-022-00	10 43
	27 23	6211-311-007-40	10 36	6212-531-014-00	6 6
6209-572-003-00	3 5	6211-312-003-20	10 27	6212-535-010-10	21 15
	27 5		27 14	6212-535-014-00	13 4
6209-580-002-10	21 27	6211-312-004-20	10 37	6212-551-028-00	12 1
6209-587-001-00	14 4		27 15	6212-552-014-00	12 2
6209-600-004-00	10 24	6211-319-003-00	10 39	6212-561-001-10	12 3
6209-605-004-10	2 3	6211-321-022-00	10 47	6212-563-005-00	12 4
6209-605-007-10	6 5	6211-322-002-00	10 48	6212-565-001-00	12 5
	10 2	6211-340-006-10	9 1	6212-569-002-00	2 4
6209-610-001-10	6 3	6211-342-001-30	9 2		27 2
6209-610-007-00	10 3	6211-361-104-00	8 1	6212-571-006-00	12 6
6209-610-008-00	6 7	6211-510-021-00	6 10	6212-575-002-00	12 7

Numerical Index

6004-097-690-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
6212-600-002-30	12 8	6214-145-001-30	27 7	6215-345-036-00	28 42
6212-611-004-10	12 9	6215-300-036-10	20 1	6215-345-037-00	28 43
6212-616-002-00	12 16	6215-311-027-00	28 51	6215-345-038-00	28 44
6212-620-001-20	12 10	6215-315-002-00	20 3	6215-345-039-00	28 45
6212-626-002-10	12 11	6215-330-024-10	28 1	6215-345-040-00	28 46
6212-628-004-00	12 12	6215-331-008-00	28 2	6215-345-041-00	28 47
6212-628-005-00	12 13	6215-332-013-00	28 5	6215-345-042-00	28 48
6213-100-003-30	17 1	6215-339-001-00	28 6	6215-345-043-00	28 49
6213-111-001-30	17 2	6215-342-001-00	28 3	6215-359-001-00	20 2
6213-119-001-00	17 4	6215-343-001-00	28 4	6215-359-002-00	28 50
6213-129-003-00	17 3	6215-345-001-00	28 7	6215-411-126-10	20 4
6213-129-006-00	6 16	6215-345-002-00	28 8	6215-411-127-00	20 5
6213-140-032-10	17 6	6215-345-003-00	28 9	6215-411-128-00	20 6
6213-149-001-00	17 8	6215-345-004-00	28 10	6215-411-198-00	22 2
6213-160-002-20	10 28	6215-345-005-00	28 11	6215-412-004-00	22 1
6213-161-001-20	10 29	6215-345-006-00	28 12	6215-520-001-00	21 17
6213-164-001-00	10 30	6215-345-007-00	28 13	6215-526-004-00	21 19
6213-240-002-20	17 13	6215-345-008-00	28 14	6215-531-023-00	21 24
6213-311-006-00	17 10	6215-345-009-00	28 15	6215-541-001-10	21 20
6213-319-001-00	6 24	6215-345-010-00	28 16	6215-541-016-40	23 2
6213-610-005-50	18 1	6215-345-011-00	28 17	6215-541-024-50	21 25
6213-612-004-00	18 3	6215-345-012-00	28 18	6215-542-004-20	10 21
6213-613-002-10	18 2	6215-345-013-00	28 19	6215-542-005-20	10 23
6213-614-018-00	18 5	6215-345-014-00	28 20	6215-542-006-00	21 22
	27 18	6215-345-015-00	28 21	6215-543-002-10	21 21
6213-614-019-00	18 9	6215-345-016-00	28 22	6215-546-003-30	10 17
	27 19	6215-345-017-00	28 23	6215-548-029-20	23 1
6213-619-001-00	18 8	6215-345-018-00	28 24	6215-549-007-10	21 28
6213-619-003-00	18 4	6215-345-019-00	28 25	6215-549-012-00	21 32
6213-641-022-20	19 2	6215-345-020-00	28 26	6215-549-013-00	6 28
6213-660-023-00	19 1	6215-345-021-00	28 27	6215-600-103-30	21 1
6213-669-008-00	19 4	6215-345-022-00	28 28	6215-611-001-00	29 6
6213-669-022-00	19 3	6215-345-023-00	28 29	6215-612-001-00	29 9
6213-671-054-00	19 6	6215-345-024-00	28 30	6215-619-009-00	21 3
6213-674-046-00	24 2	6215-345-025-00	28 31	6215-619-010-00	21 2
6213-711-004-00	18 20	6215-345-026-00	28 32	6215-619-022-00	29 8
6213-716-001-60	18 15	6215-345-027-00	28 33	6215-621-016-30	21 10
6213-729-013-10	18 13	6215-345-028-00	28 34	6215-622-001-00	29 12
6213-743-002-10	18 16	6215-345-029-00	28 35	6215-629-001-00	29 10
	27 20	6215-345-030-00	28 36	6215-629-002-00	29 11
6214-111-011-20	4 1	6215-345-031-00	28 37	6215-629-003-00	29 18
6214-115-001-20	4 2	6215-345-032-00	28 38	6215-629-004-00	29 19
	27 6	6215-345-033-00	28 39	6215-629-005-00	29 20
6214-141-010-10	5 1	6215-345-034-00	28 40	6215-629-006-00	29 21
6214-145-001-30	5 2	6215-345-035-00	28 41	6215-629-007-00	29 22

Numerical Index

6004-097-690-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
6215-629-008-00	29 23	6281-229-015-00	30 22	V231-360-802-00	18 11
6215-629-009-00	29 24	6281-229-016-00	30 23		18 17
6215-629-010-00	29 25	6281-229-017-00	30 24		24 3
6215-629-011-00	29 26	6281-229-018-00	30 25	V231-360-802-50	18 22
6215-629-012-00	29 27	6281-229-032-00	30 6	V231-360-803-00	10 15
6215-629-013-00	29 28	6281-229-033-00	30 11	V231-360-804-50	10 12
6215-629-014-00	29 29	6281-229-040-00	30 14		18 6
6215-629-015-00	29 30	6281-271-003-00	26 1	V231-360-805-00	12 19
6215-629-016-00	29 31	6281-271-008-00	30 26	V231-360-805-50	10 9
6215-631-019-00	29 7	6281-410-023-10	25 3	V231-360-807-50	10 13
6215-634-001-00	29 16	6281-910-013-00	25 6		18 18
6215-635-001-00	29 14	6281-971-001-10	25 1	V231-360-808-50	10 8
6215-637-001-00	29 13	6282-450-011-00	25 2	V233-361-002-00	11 2
6215-639-004-00	29 15	6287-810-015-30	27 1	V233-361-007-00	24 5
6215-639-005-00	29 17	6294-453-002-00	6 21	V301-260-006-00	10 34
6215-641-006-00	29 5	6513-770-022-10	18 19		21 29
6215-643-006-00	29 1	6901-911-020-00	9 3	V304-260-008-00	10 45
6215-644-007-00	29 2	6901-911-025-00	24 8		10 49
6215-649-002-00	29 4	6902-050-816-00	10 38	V341-120-008-00	10 19
6215-649-019-00	29 3	6904-110-818-00	6 19	V401-160-006-00	21 31
6219-732-017-00	25 5	6904-110-822-00	6 20	V401-160-008-00	10 46
6219-752-044-00	21 5		10 4		10 50
6219-752-045-00	21 4		10 42	V411-260-006-00	21 30
6219-752-046-00	21 6	6904-110-840-00	6 18	V523-101-001-80	16 2
6219-752-047-00	21 7		18 10	V600-110-620-30	21 13
6281-100-023-00	24 7	6904-110-850-00	10 6	V682-200-000-60	2 5
6281-200-015-00	24 1	6904-110-855-00	10 5	V704-140-016-00	12 15
6281-213-013-00	30 7	6909-902-299-00	6 22	V705-140-012-00	10 31
6281-214-007-00	30 12	6909-906-105-10	17 11	V710-140-004-00	21 23
6281-214-008-00	30 13	6911-129-006-00	2 2	V720-101-900-80	21 26
6281-215-001-00	30 17	J061-210-015-00	18 14	V720-102-401-50	17 7
6281-216-001-00	30 18	J062-076-082-00	22 5		27 17
6281-217-002-00	30 16	P117-303-003-00	10 22	V720-102-401-80	8 3
6281-221-004-00	30 4	V201-360-802-00	21 8	V723-102-005-00	10 40
6281-222-002-00	30 1	V210-560-601-20	13 5		27 16
6281-229-002-00	30 2		21 16	V723-102-005-50	18 21
6281-229-003-00	30 3	V210-560-602-50	17 5		27 21
6281-229-004-00	30 5	V211-560-802-00	10 51	V782-160-000-4T	6 23
6281-229-006-00	30 8	V211-560-802-50	5 3		
6281-229-007-00	30 9	V230-360-601-00	8 4		
6281-229-008-00	30 10	V230-360-601-20	6 27		
6281-229-011-00	30 15	V230-360-601-60	25 8		
6281-229-012-00	30 19	V231-360-801-60	10 11		
6281-229-013-00	30 20		17 9		
6281-229-014-00	30 21	V231-360-802-00	4 3		

Numerical Index

6005-097-245-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
1373-121-001-00	24 4	6209-610-003-00	6 6	6211-341-126-00	9 1
1425-621-004-00	10 15	6209-610-004-00	10 3	6211-342-002-10	9 2
	17 16	6209-610-007-00	6 3	6211-361-076-00	8 1
1729-202-001-00	21 12	6209-610-009-00	6 5	6211-510-008-00	6 11
1729-202-002-00	10 45	6209-625-002-00	10 7	6211-511-007-00	6 12
3640-586-004-00	22 4		26 12	6211-511-008-00	6 13
3805-355-002-20	8 2	6209-625-003-20	6 15	6211-530-008-00	7 1
3817-401-001-00	10 11		26 10	6211-540-008-00	7 3
	12 20	6209-630-002-10	25 7	6211-599-004-00	6 14
	18 3		26 21		7 2
	18 9	6209-730-002-00	16 4		7 4
	21 7	6209-730-005-00	13 3	6211-751-001-10	3 5
6005-010-285-00	1 1		21 10	6211-751-002-00	6 31
6115-639-008-00	28 50	6209-740-005-00	6 18	6211-760-057-10	6 29
6209-000-005-00	2 7	6209-740-006-00	10 27	6211-766-025-00	6 30
6209-000-006-00	6 2	6209-740-008-00	6 35	6211-777-007-30	11 1
6209-000-043-00	16 9	6209-749-001-20	6 16	6212-111-095-40	14 1
6209-030-043-00	21 16		10 42	6212-114-095-40	15 1
6209-030-044-00	19 4	6209-920-002-00	10 21	6212-116-095-40	15 3
6209-030-091-00	9 3	6211-110-084-40	2 1	6212-121-028-30	14 2
6209-046-015-00	16 7	6211-141-057-10	2 6	6212-124-028-30	15 2
6209-050-001-00	10 34		26 3	6212-126-028-30	15 4
6209-050-002-00	10 35	6211-170-007-30	3 1	6212-211-002-00	14 3
6209-300-014-00	2 8	6211-173-005-00	3 6	6212-230-011-30	14 5
6209-360-011-00	22 3		26 4	6212-235-004-10	14 6
6209-360-109-10	3 9	6211-179-011-20	3 2	6212-251-003-30	26 22
6209-360-143-00	22 6	6211-210-116-00	6 1	6212-271-009-00	14 7
6209-360-145-00	17 14	6211-258-001-00	6 9	6212-273-009-00	7 5
6209-409-001-00	10 19		26 8	6212-274-009-00	7 6
6209-440-005-00	25 4	6211-258-002-00	6 10	6212-310-049-00	16 1
6209-440-007-00	24 6		26 9	6212-330-091-20	16 5
6209-490-002-10	3 7	6211-291-010-00	3 3	6212-333-007-10	16 6
6209-500-003-00	10 17	6211-291-015-20	6 25	6212-371-081-00	16 8
	10 26	6211-292-001-20	6 26	6212-511-005-10	13 1
	26 13		26 11	6212-521-008-00	16 3
6209-572-003-00	3 8	6211-299-012-00	6 37	6212-522-004-20	13 2
	26 5	6211-310-075-00	10 1	6212-523-006-50	13 6
6209-580-002-10	21 26	6211-311-013-20	10 37	6212-524-006-30	21 9
6209-600-004-00	10 25	6211-312-005-10	10 28	6212-530-022-00	10 44
6209-605-003-20	10 2		26 14	6212-531-008-30	6 8
6209-605-004-10	2 3	6211-312-006-10	10 38	6212-535-007-00	13 4
6209-605-007-10	6 7		26 15	6212-535-009-00	21 13
	6 36	6211-319-003-00	10 40	6212-551-020-10	12 1
6209-610-001-10	6 4	6211-321-022-00	10 48	6212-552-008-00	12 2
6209-610-003-00	2 2	6211-322-002-00	10 49	6212-561-003-00	12 3

Numerical Index

6005-097-245-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
6212-563-005-00	12	4	6213-743-002-10	18	13	6215-542-005-20	10	24
6212-565-001-00	12	5		26	19	6215-542-006-00	21	20
6212-569-002-00	2	4	6214-110-003-00	4	1	6215-543-002-10	21	19
	26	2	6214-115-003-10	4	2	6215-546-003-30	10	18
6212-571-002-30	12	6		26	6	6215-548-121-00	23	1
6212-575-003-00	12	7	6214-141-023-00	5	1	6215-549-013-00	6	28
6212-600-019-00	12	8	6214-145-004-20	5	2	6215-549-031-10	21	22
6212-611-014-00	12	9		26	7	6215-549-039-00	21	31
6212-620-017-00	12	10	6215-300-045-10	20	1	6215-549-076-10	21	27
6212-626-003-00	12	11	6215-311-036-00	27	16	6215-600-104-20	21	1
6212-628-022-00	12	12	6215-315-002-00	20	2	6215-619-023-00	28	49
6212-628-023-00	12	13	6215-315-005-00	20	4	6215-619-024-00	28	51
6212-629-006-00	12	14	6215-315-006-00	20	3	6215-621-017-10	21	8
6212-629-007-00	12	15	6215-315-007-00	20	5	6215-622-003-00	28	10
6212-629-008-00	12	16	6215-330-028-00	27	1	6215-629-017-00	28	11
6212-629-009-00	12	17	6215-332-014-00	27	15	6215-629-035-00	28	12
6212-629-010-00	12	18	6215-339-004-00	27	14	6215-629-036-00	28	24
6213-100-010-00	17	1	6215-342-013-00	27	13	6215-629-037-00	28	25
6213-119-001-00	17	3	6215-343-010-00	27	12	6215-629-038-00	28	26
6213-129-003-00	17	2	6215-345-044-00	27	2	6215-629-039-00	28	27
6213-129-006-00	6	17	6215-345-045-00	27	3	6215-629-040-00	28	28
6213-140-005-20	17	5	6215-345-046-00	27	4	6215-629-041-00	28	29
6213-149-003-20	17	7	6215-345-047-00	27	5	6215-629-042-00	28	30
6213-160-005-00	10	29	6215-345-048-00	27	6	6215-629-043-00	28	31
6213-161-003-10	10	30	6215-345-049-00	27	7	6215-629-044-00	28	32
6213-164-001-00	10	31	6215-345-050-00	27	8	6215-629-045-00	28	33
6213-240-011-00	17	9	6215-345-051-00	27	9	6215-629-046-00	28	34
6213-342-007-00	6	34	6215-345-052-00	27	10	6215-629-047-00	28	35
6213-342-013-00	6	33	6215-345-053-00	27	11	6215-629-048-00	28	36
6213-610-011-20	18	1	6215-359-003-00	27	17	6215-629-049-00	28	37
6213-614-001-10	26	18	6215-359-004-00	27	18	6215-629-050-00	28	38
6213-614-013-00	18	2	6215-359-006-00	28	52	6215-629-051-00	28	39
6213-614-014-00	18	5	6215-411-133-00	20	6	6215-629-052-00	28	40
6213-619-006-00	18	4	6215-411-134-00	20	7	6215-629-053-00	28	41
6213-641-022-20	19	2	6215-411-135-00	20	8	6215-629-054-00	28	42
6213-660-023-00	19	1	6215-411-136-00	22	2	6215-629-055-00	28	43
6213-669-008-00	19	3	6215-412-004-00	22	1	6215-629-056-00	28	44
6213-671-058-00	19	5	6215-520-007-10	21	15	6215-629-058-00	28	45
6213-674-012-20	24	2	6215-526-004-00	21	17	6215-629-059-00	28	46
6213-711-004-00	18	17	6215-531-019-00	21	23	6215-629-060-00	28	16
6213-716-001-60	18	12	6215-537-002-10	21	32	6215-629-061-00	28	17
6213-721-015-00	6	24	6215-541-001-10	21	18	6215-629-062-00	28	18
6213-721-023-00	3	10	6215-541-016-40	23	2	6215-629-063-00	28	19
6213-729-026-00	17	13	6215-541-045-10	21	24	6215-629-064-00	28	20
6213-729-031-00	18	10	6215-542-004-20	10	22	6215-629-065-00	28	21

Numerical Index

6005-097-245-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
6215-629-066-00	28	22	6281-214-007-00	30	12	6904-110-855-00	10	5
6215-629-067-00	28	23	6281-214-008-00	30	13	6909-111-508-00	29	21
6215-631-015-00	28	1	6281-215-001-00	30	17	6909-950-115-00	14	4
6215-634-003-00	28	13	6281-216-001-00	30	18	J061-210-015-00	18	11
6215-635-004-00	28	7	6281-217-002-00	30	16	J061-216-020-00	17	15
6215-635-005-00	28	48	6281-221-004-00	30	4	J062-076-082-00	22	5
6215-637-004-00	28	47	6281-222-002-00	30	1	P117-303-003-00	10	23
6215-639-008-00	28	14	6281-229-002-00	30	2	V195-164-008-30	3	4
6215-639-009-00	28	15	6281-229-003-00	30	3	V210-560-601-20	13	5
6215-641-002-00	28	2	6281-229-004-00	30	5		21	14
6215-643-005-00	28	3	6281-229-006-00	30	8	V211-560-802-00	10	52
6215-644-009-00	28	5	6281-229-007-00	30	9	V211-560-802-50	5	3
6215-649-008-00	28	4	6281-229-008-00	30	10	V220-540-602-00	17	4
6215-649-011-00	28	9	6281-229-011-00	30	15	V230-360-601-00	8	4
6215-649-013-00	28	8	6281-229-012-00	30	19	V230-360-601-20	6	27
6215-649-014-00	28	6	6281-229-013-00	30	20	V230-360-601-60	25	8
6219-732-017-00	25	5	6281-229-014-00	30	21	V231-360-801-60	10	12
6219-752-044-00	21	3	6281-229-015-00	30	22		17	8
6219-752-045-00	21	2	6281-229-016-00	30	23	V231-360-802-00	18	8
6219-752-046-00	21	4	6281-229-017-00	30	24		18	14
6219-752-047-00	21	5	6281-229-018-00	30	25		21	6
6221-700-007-00	17	10	6281-229-032-00	30	6		24	3
6221-726-010-00	17	12	6281-229-033-00	30	11	V231-360-802-50	4	3
6221-726-015-00	17	11	6281-229-040-00	30	14		18	19
6281-100-002-50	24	7	6281-229-041-00	29	22	V231-360-803-00	10	16
6281-111-005-00	29	1	6281-271-008-00	30	26	V231-360-804-50	18	7
6281-115-008-00	29	10	6281-410-023-10	25	3	V231-360-805-00	10	13
6281-115-010-00	29	23	6281-910-013-00	25	6	V231-360-805-50	12	19
6281-115-016-00	29	20	6281-971-001-10	25	1	V231-360-806-00	10	14
6281-116-004-00	29	11	6282-450-011-00	25	2	V231-360-807-00	10	10
6281-121-006-00	29	2	6287-810-032-10	26	1	V231-360-807-50	10	9
6281-123-005-00	29	8	6294-453-002-00	6	22		18	15
6281-124-007-10	29	5	6513-770-022-10	18	16	V231-360-808-50	10	8
6281-129-003-00	29	19	6581-117-007-00	29	12	V233-361-002-00	11	3
6281-129-038-00	29	3	6581-129-092-00	29	17	V233-361-007-00	24	5
6281-129-039-00	29	4	6581-129-099-00	29	6	V251-340-806-00	6	21
6281-129-040-00	29	7	6901-911-020-00	11	2	V301-260-006-00	10	36
6281-129-041-10	29	9	6901-931-240-00	24	8		21	28
6281-129-042-00	29	15	6902-050-816-00	10	39	V304-260-008-00	10	46
6281-129-043-00	29	16	6904-110-822-00	6	20		10	50
6281-129-044-00	29	18		10	4	V304-260-012-00	24	9
6281-129-062-00	29	14		10	43	V341-120-008-00	10	20
6281-151-025-10	29	13	6904-110-840-00	6	19	V401-160-006-00	21	30
6281-200-015-00	24	1		18	6	V401-160-008-00	10	47
6281-213-013-00	30	7	6904-110-850-00	10	6		10	51

Numerical Index

6005-097-245-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V411-260-006-00	21 29				
V523-101-001-80	16 2				
V600-110-620-30	21 11				
V682-200-000-60	2 5				
V705-140-012-00	10 32				
V710-140-004-00	21 21				
V720-101-900-80	21 25				
V720-102-401-80	8 3				
	10 33				
V720-103-502-20	17 6				
	26 17				
V720-103-502-50	6 32				
V723-102-005-00	10 41				
	26 16				
V723-102-005-50	18 18				
	26 20				
V782-160-000-4T	6 23				

Numerical Index

1832-097-100-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
1102-611-006-10	60 7	1560-240-007-40	16 6	1672-301-002-00	21 2
1118-606-002-10	72 10	1560-531-020-00	48 27	1672-301-003-00	21 8
1342-402-006-00	67 19	1560-630-024-00	71 12	1672-301-004-00	21 10
1376-402-003-00	67 20	1560-666-004-00	63 23	1673-431-001-10	26 22
1376-606-005-00	60 3	1560-695-021-00	30 18	1673-525-002-30	71 7
1404-503-006-00	54 13	1560-695-022-00	30 22	1674-619-300-10	63 15
1415-102-007-00	83 1	1564-216-004-10	20 4		64 15
1415-102-008-00	83 3	1572-102-003-00	83 8	1674-619-310-00	63 16
1415-102-013-00	83 9	1575-261-018-00	27 8		64 16
1416-621-037-00	10 5		28 8	1674-654-270-00	63 26
1421-602-005-10	72 5	1575-616-005-00	70 4		64 25
1421-603-004-00	3 19	1593-117-003-10	13 5	1674-654-271-00	63 27
	4 19	1600-505-007-10	13 4		64 26
1423-616-004-00	3 22	1600-624-004-10	67 21	1674-654-272-00	63 28
	4 22	1614-129-003-00	66 44		64 27
1425-433-018-00	25 5	1614-203-015-00	20 2	1674-904-005-10	76 11
1427-301-002-20	21 6	1614-222-007-00	26 16		77 11
1427-301-005-00	21 9	1614-223-221-00	19 2	1674-904-008-00	76 5
1427-301-007-00	21 11	1614-702-551-20	71 8		77 5
1427-310-001-00	34 6	1614-702-552-00	71 9	1675-112-002-00	11 2
1427-310-220-10	34 7	1614-922-200-20	81 1		12 4
1432-616-002-00	60 9	1620-410-001-10	80 1	1675-116-001-00	13 11
1434-310-220-00	34 5	1632-273-200-00	27 17	1675-506-002-00	55 46
1440-103-201-00	83 4		28 17	1683-271-560-00	30 20
1442-313-202-00	36 2	1636-436-002-00	79 2	1684-112-230-00	12 1
1444-102-204-00	83 5	1636-611-011-00	62 4	1685-604-003-00	3 30
1444-122-002-00	35 35	1636-631-008-00	69 4		4 30
1444-307-007-00	52 17	1646-111-210-20	9 13		44 15
	52 28	1646-226-053-00	30 2		45 15
	52 39	1646-640-580-00	30 33	1688-211-057-00	27 9
1444-314-008-00	20 15	1650-104-200-10	7 1		28 9
1444-314-009-10	29 5		8 1	1688-211-505-00	87 4
1444-328-272-00	36 4	1650-104-201-00	7 3	1688-211-506-00	87 8
1444-328-273-00	36 3		8 3	1688-211-509-00	87 11
1444-411-006-00	21 7	1650-104-203-10	7 4	1688-211-522-00	87 13
1480-207-011-00	33 20		8 4	1689-205-005-10	22 3
1518-306-203-10	49 58	1650-104-210-00	7 2	1689-271-006-00	30 3
1518-432-250-10	49 57		8 2	1689-272-240-00	31 15
1524-122-001-10	35 8	1650-135-002-00	35 6	1689-272-260-00	31 1
1544-104-205-00	7 5	1650-509-280-00	55 44	1689-613-260-00	65 2
	8 5	1650-509-310-00	56 19	1690-102-210-00	3 31
1544-120-008-10	16 8	1650-650-222-00	67 5		4 31
1544-304-006-10	21 5	1659-650-200-20	11 1	1690-102-212-00	3 32
1560-132-007-30	30 21	1672-105-210-10	9 1		4 32
	35 36	1672-105-211-00	83 7	1690-102-213-00	3 33

Numerical Index

1832-097-100-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
1690-102-213-00	4 33	1716-680-330-10	66 28	1725-219-722-00	85 1
1690-102-214-00	3 34		66 32	1725-219-723-10	85 2
	4 34		66 38	1725-219-724-00	85 3
1690-102-215-00	3 35		66 46	1725-219-725-00	85 4
	4 35	1716-901-016-00	73 4	1725-219-726-00	85 5
1690-102-216-00	3 36		74 4	1725-219-727-00	85 6
	4 36	1719-312-001-00	3 24	1725-219-728-00	85 7
1690-102-217-00	3 37		4 24	1725-219-729-00	85 8
	4 37		46 9	1725-219-731-00	85 9
1690-241-003-00	16 5	1719-650-250-00	66 1	1725-219-732-00	85 10
1690-650-320-00	66 19		66 3	1725-219-733-00	85 11
1696-901-006-00	73 6		66 11	1725-219-734-00	85 12
	74 6	1720-221-210-00	48 13	1725-304-713-00	49 23
1703-670-320-00	65 3	1720-221-211-00	84 1		49 27
1703-670-322-00	65 4	1720-221-212-00	84 2	1725-308-103-00	49 30
1703-670-323-00	65 5	1720-221-213-00	84 3		49 37
1703-670-324-00	65 6	1720-221-214-00	84 4	1725-432-101-00	49 1
1703-670-325-00	65 7	1720-221-215-00	84 5	1725-432-107-00	49 5
1703-670-326-00	65 8	1720-221-216-00	84 6	1725-432-108-00	49 16
1704-740-008-10	60 5	1720-221-217-00	84 7	1725-432-110-00	49 3
1705-408-230-00	54 15	1720-221-218-00	84 8	1725-432-113-00	49 15
	55 12	1720-221-219-00	84 9	1725-432-114-00	49 17
	55 55	1720-221-221-00	84 10		49 36
1705-902-006-00	76 6	1720-221-222-00	84 11	1725-432-711-00	49 8
	77 6	1720-221-224-00	84 12	1725-432-712-10	49 9
1705-902-007-00	76 8	1720-221-225-00	84 13	1725-432-713-00	49 10
	77 8	1720-221-230-00	48 14	1725-432-714-00	49 11
1705-902-008-00	76 7	1724-102-012-00	3 29	1725-432-715-00	49 12
	77 7		4 29	1725-432-801-00	49 14
1705-904-002-10	76 2	1724-304-005-00	20 13	1725-433-202-10	31 11
	77 2	1725-103-002-00	5 7		31 27
1705-904-004-00	76 1		6 7		35 31
	77 1	1725-105-330-10	9 11		36 14
1705-904-011-00	77 14	1725-201-806-00	49 32		49 19
1710-241-053-00	33 16		49 51	1725-434-005-00	49 33
	82 25	1725-218-109-00	49 4	1725-434-013-00	49 50
1716-105-001-00	9 7	1725-219-121-00	49 6	1725-434-047-00	49 34
1716-501-006-10	16 9		49 39	1725-434-101-00	49 20
	16 13		49 43	1725-434-106-00	49 47
1716-601-009-00	3 21	1725-219-122-00	49 46	1725-434-107-00	49 48
	4 21	1725-219-215-00	87 6	1725-434-108-00	49 53
1716-680-222-00	66 29	1725-219-216-00	87 7	1725-434-111-00	49 24
	66 33	1725-219-232-00	87 5	1725-434-113-00	49 45
	66 39	1725-219-720-20	27 6	1725-434-114-00	49 21
	66 47		28 6		49 25

Numerical Index

1832-097-100-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
1725-434-115-00	49	22	1729-509-001-00	55	34	1770-621-530-00	65	19
	49	26	1729-601-280-10	58	9	1770-902-004-00	75	2
1725-434-116-00	49	29	1729-602-006-00	3	43	1770-902-051-00	75	1
	49	52		4	43	1771-105-001-00	9	5
1725-434-121-00	49	42	1729-604-003-00	3	28	1771-215-001-00	22	6
1725-434-122-00	49	40		4	28	1771-215-210-00	22	2
	49	44	1729-702-003-00	57	12	1771-244-011-10	26	24
1725-434-123-00	49	49	1729-705-009-00	65	24	1771-246-052-00	29	3
1725-434-124-00	49	54	1729-741-007-00	60	2	1771-307-051-20	33	1
1725-436-320-00	50	2	1739-401-001-00	40	5	1771-407-001-10	40	2
1725-436-600-00	50	1	1739-401-700-00	38	1	1771-407-200-00	40	1
1725-436-601-00	50	6	1739-407-074-00	40	3	1771-503-003-00	52	7
1725-436-610-00	50	3	1739-530-270-00	56	24	1771-510-250-00	56	3
1725-436-611-00	50	4	1739-681-220-20	66	15	1771-510-251-00	56	4
1725-436-612-00	50	5	1739-904-001-00	76	4	1771-923-200-10	79	1
1725-509-260-00	55	7		77	4	1771-923-210-00	79	6
1725-611-087-00	63	3	1739-904-004-00	76	3	1772-652-001-00	65	27
	64	3		77	3	1772-652-220-10	65	26
1725-680-220-10	66	43	1740-313-300-10	36	1	1772-654-001-00	63	21
1725-690-071-00	67	14	1740-313-301-00	36	5		64	21
1728-102-220-00	3	12	1740-407-530-00	55	52	1772-654-002-10	63	22
	4	12	1740-517-600-00	56	15		64	22
1728-204-002-00	22	1	1740-517-610-00	56	22	1772-654-210-00	63	20
1728-204-073-30	22	5	1740-680-530-20	66	17		64	20
1728-307-024-00	33	9	1741-604-012-00	44	5	1772-654-212-00	86	1
1728-307-025-00	33	12		45	5	1772-654-213-00	86	2
1728-307-026-10	33	14	1742-504-004-00	35	33	1772-654-214-00	86	3
1728-310-052-00	34	2	1742-606-001-10	70	5	1772-654-215-00	86	4
1728-317-251-00	37	2	1742-662-001-00	69	8	1772-654-216-00	63	7
1728-407-076-10	40	6	1746-902-004-00	65	18		63	12
1728-408-001-00	41	15	1747-640-067-00	31	2		64	7
1728-441-701-10	51	2	1752-102-005-00	3	20		64	12
1728-508-280-10	55	1		4	20		86	8
1729-111-006-10	10	7	1752-508-005-00	54	6	1772-654-217-00	86	9
1729-111-283-00	10	9	1752-606-004-00	58	8	1772-654-250-10	66	23
1729-111-284-00	10	10	1754-407-001-00	56	7	1772-654-251-00	66	24
1729-202-002-00	27	5	1755-111-300-00	10	4	1772-654-280-10	66	25
	27	10	1757-901-011-00	75	3	1772-654-281-00	66	26
	28	5	1763-601-003-00	44	3	1772-654-282-00	66	27
	28	10		45	3	1773-267-002-00	47	7
1729-202-003-00	18	7	1764-603-002-00	46	2	1773-401-202-10	38	2
1729-202-005-00	33	11		46	5	1773-434-012-00	49	2
1729-202-007-00	27	15	1770-102-004-00	3	3	1773-702-001-00	71	3
	28	15		4	3	1773-702-002-00	71	11
1729-202-014-00	26	27	1770-111-004-00	10	12	1774-111-310-10	10	8

Numerical Index

1832-097-100-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
1774-111-311-00	10	11	1809-553-240-20	57	3	1832-102-051-00	4	8
1774-272-071-00	31	16	1809-553-280-00	53	8	1832-102-052-00	4	9
1774-650-212-00	63	6		57	5	1832-102-210-20	3	16
	63	11	1809-603-001-00	59	1		4	16
	64	6	1809-603-002-00	59	2	1832-102-220-00	3	2
	64	11	1809-606-002-00	60	6		4	2
1774-680-250-00	66	13	1809-650-006-00	63	4	1832-102-230-10	3	26
1774-904-031-10	77	13		64	4		4	26
1774-904-032-00	76	13	1809-650-012-00	63	30	1832-102-240-00	3	38
1776-432-003-00	49	7	1809-650-230-00	63	5		4	38
1782-103-051-00	5	8		64	5	1832-102-310-00	3	6
	6	8	1809-650-232-00	63	8	1832-102-320-00	4	6
1796-604-073-00	3	44		63	13	1832-102-330-00	3	1
	4	44		64	8		4	1
1800-652-400-00	66	5		64	13	1832-103-003-00	5	2
	66	6	1809-650-233-00	63	9		6	2
	66	7		63	14	1832-103-210-10	5	5
	66	8		64	9	1832-103-300-00	5	1
	66	9		64	14	1832-103-500-00	6	1
	66	10	1809-650-240-00	63	10	1832-103-510-10	6	5
1801-509-530-00	56	11		64	10	1832-104-001-00	7	7
1805-202-025-00	21	12	1809-670-220-00	65	9	1832-104-002-00	7	9
1805-508-260-00	54	1	1809-690-204-00	67	12		8	10
1806-102-008-00	44	10	1809-690-205-00	67	15	1832-104-051-00	8	7
	45	10	1809-801-002-10	72	8	1832-105-001-00	9	15
1809-102-027-00	3	4	1809-801-004-00	72	16	1832-111-001-00	10	1
	4	4	1809-801-007-00	72	17	1832-112-001-10	11	3
1809-102-330-00	3	14	1809-801-280-00	66	40		12	5
	4	14	1817-904-004-00	76	12	1832-112-051-00	12	2
1809-111-002-00	10	3		77	12	1832-112-210-00	11	8
1809-112-210-00	11	6	1825-127-300-00	26	6	1832-112-510-00	12	10
1809-117-002-00	13	2	1825-127-302-00	87	1	1832-112-520-00	12	8
1809-405-003-00	39	4	1825-127-303-00	87	2	1832-117-210-00	13	1
1809-405-004-20	39	10	1825-127-304-00	87	3	1832-117-220-00	13	3
1809-405-008-00	39	13	1825-127-305-00	87	9	1832-117-230-00	13	8
1809-408-260-10	41	16	1825-127-306-00	87	14	1832-118-210-10	14	1
1809-410-001-00	58	7	1825-127-307-00	87	12	1832-120-210-00	15	1
1809-503-003-00	52	15	1832-101-210-00	1	1	1832-201-001-00	16	1
	52	26	1832-101-220-00	1	2	1832-201-002-00	16	2
	52	37	1832-101-510-00	2	1	1832-201-210-00	16	11
1809-503-220-10	52	11	1832-101-520-00	2	2	1832-203-001-00	17	1
1809-509-006-00	55	47	1832-102-001-00	3	42	1832-204-001-00	18	1
1809-509-450-00	55	54		4	42	1832-204-002-00	18	4
1809-553-210-20	57	1	1832-102-004-00	3	8		26	1
1809-553-230-00	57	7	1832-102-005-00	3	9	1832-204-003-00	18	6

Numerical Index

1832-097-100-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
1832-213-001-00	20	6	1832-306-002-00	32	3	1832-411-002-10	44	13
1832-213-002-00	20	3	1832-306-210-00	32	12		45	13
1832-213-210-00	20	9	1832-307-001-00	33	5	1832-411-003-00	44	16
1832-213-900-00	20	1	1832-307-002-00	33	13		45	16
1832-214-001-00	21	1	1832-307-210-00	33	19	1832-411-004-00	44	18
1832-214-002-00	21	13	1832-310-001-00	34	1		45	18
1832-216-210-10	23	1	1832-310-210-00	34	4	1832-411-005-00	44	20
1832-216-220-00	23	6	1832-310-220-00	34	8	1832-411-006-00	45	20
1832-241-001-00	24	1	1832-312-002-00	35	18	1832-411-007-00	44	7
	25	1	1832-312-003-00	35	30		45	7
1832-244-001-00	26	3	1832-312-210-00	35	7	1832-411-240-20	44	1
1832-244-002-00	26	11	1832-312-220-00	35	1		45	1
1832-244-003-00	26	21	1832-312-230-00	35	13	1832-411-250-20	44	8
1832-244-004-00	26	18	1832-312-240-10	35	21		45	8
1832-244-005-00	26	13	1832-312-260-00	35	28	1832-411-260-10	44	2
1832-244-006-00	26	26		36	11		45	2
1832-244-007-00	26	28	1832-312-270-00	35	24	1832-412-001-00	46	7
1832-244-200-00	26	7	1832-312-280-00	35	10	1832-412-002-00	46	8
1832-244-230-00	26	23	1832-313-001-10	36	16	1832-412-210-10	46	1
1832-245-001-00	27	4	1832-313-210-00	36	7	1832-412-230-10	46	4
	28	4	1832-313-220-00	36	10	1832-430-001-00	47	6
1832-245-200-00	27	1	1832-313-230-00	36	13	1832-430-210-00	47	1
	28	1	1832-317-200-00	37	1	1832-430-220-00	47	3
1832-245-210-00	27	7	1832-317-230-00	37	3	1832-430-230-00	47	11
1832-245-220-00	27	13	1832-405-001-00	39	12	1832-431-001-00	48	15
1832-245-500-00	28	7	1832-405-210-00	39	1	1832-431-002-00	48	19
1832-245-510-00	28	13	1832-405-230-00	39	3	1832-431-003-00	48	3
1832-246-210-00	29	1	1832-405-240-00	39	5	1832-431-004-00	48	8
1832-271-001-00	30	29	1832-405-250-00	39	11	1832-431-005-00	48	9
1832-271-002-00	30	16	1832-405-260-00	39	7	1832-431-006-00	48	12
1832-271-210-00	30	1	1832-408-001-00	41	12	1832-431-007-00	48	25
1832-271-230-00	30	9	1832-410-001-00	42	19	1832-431-210-00	48	1
1832-271-240-00	30	7	1832-410-002-00	42	20	1832-431-220-00	48	23
1832-271-250-00	30	25	1832-410-210-10	42	6	1832-431-230-10	48	30
1832-271-260-00	30	11		43	6	1832-433-200-00	49	18
1832-272-001-10	31	7	1832-410-250-10	42	13	1832-433-250-00	49	60
	31	23		43	13	1832-434-001-00	49	28
1832-272-003-00	31	12	1832-410-310-10	42	1	1832-434-002-00	49	31
	31	28		43	1	1832-434-003-00	49	56
1832-272-210-00	31	4	1832-410-410-10	42	9	1832-434-004-00	49	55
1832-272-220-10	31	18		43	9	1832-434-101-00	49	41
1832-272-250-00	31	31	1832-410-450-10	42	17	1832-434-102-00	49	38
1832-272-260-10	31	10		43	17	1832-441-001-00	51	6
1832-272-270-10	31	26	1832-411-001-10	44	11	1832-441-200-00	51	1
1832-306-001-00	32	1		45	11	1832-441-230-00	51	3

Numerical Index

1832-097-100-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
1832-503-001-00	52 18	1832-670-201-00	65 22	2500-901-027-00	78 1
1832-503-002-00	52 29	1832-670-202-00	65 23	2504-135-008-10	30 12
	52 40	1832-670-210-10	65 1		30 26
1832-503-003-00	52 4	1832-670-310-00	65 11	2508-350-007-10	3 39
1832-503-004-00	52 43	1832-670-320-00	65 12		4 39
1832-503-210-00	52 3	1832-670-330-00	65 13	2514-102-008-00	3 40
1832-503-220-00	52 10	1832-670-340-00	65 14		4 40
1832-503-230-00	52 21	1832-680-230-00	66 31	2514-201-011-00	15 2
1832-503-240-00	52 32	1832-690-200-10	67 1	2515-665-210-00	66 21
1832-503-250-00	52 1	1832-690-202-00	67 2	2521-730-025-00	44 4
1832-503-270-10	52 22	1832-690-203-00	67 3		45 4
	52 33	1832-690-210-00	68 1	3104-210-004-10	35 37
1832-503-280-00	52 46	1832-695-001-00	69 10	3504-418-007-10	30 30
1832-504-210-00	53 10	1832-695-200-00	69 5	3533-901-012-00	73 5
1832-508-210-00	54 3	1832-695-210-20	69 1		74 5
1832-508-220-00	53 11	1832-695-250-00	69 7	3621-702-003-00	72 18
	54 17	1832-701-210-10	70 1		79 5
1832-509-002-00	55 33	1832-701-230-10	70 8	3623-150-003-10	1 4
1832-509-003-00	55 16	1832-702-002-00	71 2		2 4
1832-509-230-00	55 30	1832-702-210-00	71 1	3623-263-001-00	1 8
1832-509-240-00	55 51	1832-702-250-00	71 5		2 8
1832-509-270-00	55 27	1832-702-251-00	71 6	3626-370-005-00	54 9
1832-509-280-00	55 6	1832-801-210-00	72 1	3640-547-007-00	82 27
1832-509-290-00	55 15	1832-801-220-10	72 3	3642-496-007-10	66 45
1832-509-310-00	55 50	1832-801-230-00	72 7	3650-261-001-00	41 17
1832-509-320-00	55 14	1832-801-250-00	72 14	3650-262-202-00	67 13
1832-509-330-00	55 11	1832-901-001-00	73 1	3650-270-214-00	65 20
	56 2		74 1	3656-202-006-10	3 45
	56 8	1832-901-002-00	73 2		4 45
1832-510-001-00	56 25		74 2	3666-202-005-10	9 16
1832-510-220-00	56 21	1832-901-003-00	73 3		69 2
1832-601-001-00	58 5	1832-901-013-00	74 3	3670-236-003-00	58 3
1832-601-002-00	58 6	1832-902-001-10	75 4	3676-356-001-00	16 16
1832-601-210-00	58 1	1832-902-002-00	75 5	3768-185-022-10	53 7
1832-603-001-00	59 4	1836-432-204-00	49 35	3814-354-015-10	54 14
1832-606-001-00	60 1	2144-419-022-00	30 13	3814-371-004-00	56 5
1832-606-002-00	60 8		30 27	3817-116-005-00	20 7
1832-611-210-10	61 1	2144-519-009-10	35 38	3821-262-202-00	67 7
1832-630-001-00	62 1	2145-586-002-00	52 12	3821-262-203-00	67 8
1832-630-002-00	62 3		52 23	3821-262-204-00	67 9
1832-650-001-00	63 32		52 34	3821-262-209-00	67 10
1832-650-210-00	63 1	2186-536-212-00	65 17	3824-232-021-00	59 3
	64 1	2213-312-013-00	15 3	3824-247-202-00	67 6
1832-650-310-00	63 18		48 2	3824-247-204-00	67 11
	64 18	2500-210-016-00	30 15	3829-248-003-00	70 6

Numerical Index

1832-097-100-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
3829-260-303-00	67 4	J061-116-025-00	54 7	K500-007-039-00	82 41
3829-282-610-00	66 36	J061-230-038-00	3 11	K500-008-000-00	19 1
3829-311-200-10	9 9		4 11	K500-008-001-00	82 1
3829-387-410-00	55 9	J061-236-044-00	3 10	K500-008-004-00	82 2
	55 48		4 10	K500-008-012-00	82 7
3843-261-200-20	65 15	J061-247-055-00	8 9	K500-008-013-00	82 8
3843-261-201-00	65 16	J061-252-063-00	7 8	K500-008-023-00	82 18
	65 25		7 10	K500-008-026-00	82 19
3864-351-200-00	54 10		8 8	K500-008-034-00	82 29
4101-102-038-00	3 25		8 11	K500-008-035-00	82 30
	4 25	J062-087-093-00	9 14	K500-008-100-00	82 34
4335-512-004-00	63 29	J062-111-120-00	9 12	K510-001-010-00	82 5
	64 28	J062-119-126-00	9 6	K510-001-011-00	82 6
6901-911-020-00	2 3		9 8	K510-001-016-00	82 11
6901-931-225-00	1 3	J062-138-148-00	16 10	K510-001-020-00	82 13
	42 3		16 14	K510-001-029-00	82 20
	42 7	J062-147-159-00	3 13	K510-001-036-00	82 32
	42 16		4 13	K510-001-039-00	82 28
	43 3	K167-005-000-20	41 1	K510-003-021-00	82 14
	43 7	K167-005-001-10	41 3	K510-003-022-00	82 15
	43 16	K167-005-200-10	41 2	K510-003-037-00	82 16
6901-931-235-00	42 8	K167-005-300-10	41 4	K510-003-301-00	82 35
	42 10	K167-005-310-10	41 7	K510-003-303-00	82 37
	43 8	K182-007-002-00	53 3	K510-003-304-00	82 38
	43 10	K182-012-001-10	53 2	K510-005-023-00	82 17
7827-205-010-00	33 18	K182-013-000-30	53 1	K510-018-302-00	82 36
8650-203-001-10	57 2	K182-034-002-00	41 5	P103-521-006-10	55 42
	57 4		41 8		56 9
8654-501-043-00	72 11	K182-034-003-00	41 6		56 13
8663-201-004-00	20 11		41 9	P113-201-007-00	63 24
8663-201-005-00	20 8	K200-152-110-20	55 18		64 23
	20 12	K200-282-000-00	55 17	V111-165-001-20	66 4
8664-555-003-00	53 12	K220-002-000-00	56 17	V111-176-002-00	63 31
	56 1	K250-090-002-00	55 28	V120-265-001-60	70 7
8664-905-003-00	76 9	K250-090-003-00	55 29	V120-366-001-20	3 27
	77 9	K275-001-003-00	55 2		4 27
8664-955-002-00	76 10		82 21	V120-366-002-00	58 4
	77 10	K290-001-001-00	55 23	V195-164-008-30	65 10
8669-865-003-00	72 15	K290-001-002-00	55 24	V200-260-605-00	72 12
8680-201-009-00	18 2	K290-001-003-00	55 25	V201-260-803-50	3 23
	18 5	K290-003-000-30	55 21		4 23
	26 2	K500-006-006-10	82 4	V201-260-806-50	9 2
	26 12	K500-006-015-00	82 10	V201-260-807-50	55 38
	33 2	K500-006-017-00	82 12	V201-260-808-00	55 39
	33 6	K500-006-300-10	82 3	V201-260-810-50	32 9

Numerical Index

1832-097-100-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V201-261-004-00	39 8	V211-360-801-60	45 6	V230-360-601-00	52 16
V201-360-803-00	31 33		45 9		52 27
V201-360-804-00	48 29		45 17		52 38
V201-360-805-50	31 34		45 19	V230-360-601-20	29 2
V201-360-812-00	17 5		45 21		29 4
V201-361-203-00	64 19		46 3	V230-360-601-60	63 17
V201-361-203-50	79 7		46 6		64 17
	80 2		60 10		67 17
V201-361-206-00	79 3	V211-360-802-00	3 17	V231-360-801-20	12 3
V201-461-003-50	49 67		4 17		63 33
V201-461-203-50	70 2		7 6	V231-360-801-60	3 15
	70 9		8 6		4 15
V203-361-003-00	5 3		67 18		22 7
	6 3	V211-361-002-50	42 21		36 6
V210-360-601-60	3 5		54 2		39 6
	3 7		54 5		48 26
	4 5	V211-361-003-00	10 2		48 31
	4 7	V211-370-801-60	44 12		52 47
	66 22		44 14		58 2
	66 30		45 12		62 2
	66 34		45 14	V231-360-802-50	16 4
	66 37	V211-560-801-60	53 9		24 3
	66 41		57 6		25 3
	66 48		57 8		26 20
V210-360-602-00	55 5	V211-560-802-00	30 8		35 32
V210-360-603-50	55 3		31 32		48 22
V211-260-801-60	13 12		42 18	V231-360-804-00	17 3
	16 15		43 18		32 6
	56 6	V211-561-002-00	32 13	V231-361-002-00	35 9
V211-260-802-00	32 7		35 27		39 2
	60 4	V211-561-002-50	36 15	V231-361-007-00	63 2
V211-261-002-50	52 2	V211-561-003-00	32 11		64 2
V211-360-801-60	3 41		41 13	V231-361-202-00	72 2
	4 41	V211-561-004-00	41 14	V231-361-202-50	63 19
	9 17	V211-660-801-60	41 18	V251-341-002-00	33 22
	11 7	V211-660-802-50	5 6		42 5
	12 9		6 6		43 5
	29 6		61 2	V251-341-203-20	42 4
	31 3	V211-660-803-50	40 4		43 4
	31 17	V211-661-002-50	37 7	V301-260-006-00	11 4
	44 6		42 2		12 6
	44 9		43 2		55 4
	44 17		49 62		72 13
	44 19	V211-661-003-00	26 25	V304-260-008-00	30 17
	44 21	V220-541-003-50	82 33		30 19

Numerical Index

1832-097-100-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V304-260-008-00	30 24	V362-260-008-00	56 12	V411-260-006-00	47 13
	35 34		58 10		52 13
	48 28		66 42		52 24
	54 11		69 3		52 35
	57 13		69 6		72 9
	71 13		69 11	V411-260-008-00	9 4
	72 6		72 4		14 2
	86 7	V363-260-010-00	30 10		23 7
V304-260-010-00	13 7		47 2		30 35
	39 9	V401-160-008-00	9 3		31 8
V304-260-012-00	1 5		17 4		31 13
	2 5		21 4		31 24
V304-260-016-00	57 11		30 23		31 29
V304-460-008-00	31 35		32 8		35 11
V304-460-010-00	37 6		54 12		35 19
	42 15		55 40		35 39
	43 15		86 6		36 8
	49 66	V401-160-010-00	5 4		36 17
V304-460-012-00	30 32		6 4		47 9
	42 12		37 5		47 12
	43 12		42 14		52 19
V305-260-012-00	30 6		43 14		52 30
	81 3		48 11		52 41
V327-261-216-00	49 64		50 8		55 41
V327-262-110-00	50 7	V401-160-012-00	1 6		86 5
V360-260-004-00	10 6		2 6	V411-260-010-00	13 6
	66 2		30 5		37 4
V360-260-005-00	66 12		30 31		47 4
	9 10		42 11		48 10
V360-260-006-00	11 5		43 11		52 5
	12 7		79 4		52 44
	66 14		79 8	V411-260-012-00	1 7
	66 16		80 3		2 7
	66 18	V401-160-014-00	51 5		63 25
	66 20		57 10		64 24
	66 35	V401-160-016-00	70 3		80 4
	67 16		70 10	V411-260-014-00	51 4
	69 9		52 8		49 63
	3 18		13 9	V411-260-016-00	57 9
V362-260-008-00	3 46		23 2		71 4
	4 18		31 5	V411-260-022-00	23 4
	4 46		31 19		31 21
	11 9		35 2		35 4
	12 11		35 14		35 16
	30 34		35 25		35 22

Numerical Index

1832-097-100-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V500-162-002-00	52 14	V600-110-620-40	27 2	V720-103-502-40	48 24
	52 25		27 14	V720-103-502-60	16 12
	52 36		28 2	V720-103-504-40	83 6
V500-162-501-50	13 10		28 14	V720-111-900-70	55 36
V500-162-502-00	14 3		48 16	V720-111-901-00	82 39
	23 8	V600-110-620-60	26 4	V720-112-401-10	54 16
	30 36		33 15		55 8
	31 9	V600-110-630-50	20 10		55 10
	31 14		82 9		55 13
	31 25	V600-111-600-40	27 11		55 45
	31 30		28 11		55 49
	35 12	V600-150-620-10	30 4		55 53
	35 20	V704-140-016-00	34 3		55 56
	35 40	V704-140-017-00	26 10		82 23
	36 9	V704-140-018-00	30 14	V720-112-401-20	55 35
	36 18		30 28	V720-112-401-40	55 31
	47 5	V704-140-020-00	27 3		55 32
	47 10		27 12		55 43
	47 14		28 3		56 10
	50 9		28 12		56 14
V500-162-502-50	52 6	V704-140-022-00	23 5		56 16
	52 45		31 22		56 18
V500-164-003-00	35 23		34 10		56 20
	49 65		35 5		56 23
V523-100-801-60	19 3		35 17		82 22
	21 3	V704-140-025-00	33 10	V720-112-401-50	19 6
V523-101-002-20	16 3		82 24	V720-112-401-60	55 20
	17 2	V704-140-030-00	20 5	V720-112-402-00	55 22
	24 2		33 21	V720-112-402-20	55 19
	25 2		87 10	V721-103-103-50	54 8
	26 19	V705-140-032-00	82 26	V721-103-104-50	54 4
	32 5	V705-140-034-00	26 15	V721-103-105-00	19 4
	32 10	V705-140-045-00	48 5	V721-103-106-00	82 31
	48 21	V705-140-047-00	48 18	V721-103-106-50	48 7
V530-160-803-20	35 29	V705-140-052-00	26 29	V721-103-107-00	19 5
	36 12		33 3	V723-102-003-40	26 17
V560-160-005-00	52 9		33 7	V723-102-004-20	41 11
V560-160-008-00	52 20	V707-140-062-00	20 14	V723-102-005-00	65 21
	52 31	V707-140-072-00	25 4	V723-112-003-80	41 10
	52 42		27 16	V724-124-304-20	53 5
V580-140-301-80	47 8		28 16	V730-104-804-20	53 6
V600-110-620-30	26 9	V720-102-401-00	83 2	V744-120-350-70	48 17
V600-110-620-40	26 5	V720-102-401-80	34 9	V744-120-400-80	33 17
	26 8	V720-102-402-00	71 10	V744-120-420-80	18 3
	26 14	V720-103-502-40	22 4	V744-125-450-80	48 6

Numerical Index

1832-097-100-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V744-130-450-80	33 4				
	33 8				
V760-150-000-00	23 3				
	31 6				
	31 20				
	35 3				
	35 15				
	35 26				
	49 61				
V780-140-000-1T	55 26				
	82 40				
V780-140-000-20	55 37				
V782-160-000-2B	48 20				
V782-160-000-4B	48 4				
	49 59				
V782-160-000-6B	32 2				
V782-160-000-8B	16 7				
	32 4				
V793-142-480-60	53 4				
W201-261-206-00	81 2				

Alphabetical Index

6004-097-690-00

Description	Fig.	Key	Description	Fig.	Key	Description	Fig.	Key
ADAPTER/255X065 ASSY	23	1	BOLT/M8X20/7T	21	8	FLANGEBOLT/M6X12	6	27
ARM/CONTROL	21	28	BOLT/WASHERHEAD	29	8	FLANGEBOLT/M6X16	25	8
ARM/FLOATING COMP	21	20	BOLT/WS	17	4	FLANGEBOLT/M8X16	10	11
ARM/TENSION	23	2		19	5		17	9
BALL, STEEL	2	5	BRACKET ROCKER SHAFT	12	12	FLANGEBOLT/M8X20	4	3
BEARING, RB/6203	21	13	BRACKET, ROCKER SHAFT	12	13		18	11
BEARING/BALL	10	44	BRG/CONROD/UN050 SET	7	5		18	17
	21	14	BRG/CONROD/UN100 SET	7	6		24	3
	30	6	BRG/CRANK/UN050 SET	7	1	FLANGEBOLT/M8X25	18	22
	30	11	BRG/CRANK/UN100 SET	7	3	FLANGEBOLT/M8X30	10	15
BEARING/CONNECTING R	14	7	BRUSH	30	17	FLANGEBOLT/M8X45	10	12
BEARING/CRANK/LOWER	6	12	BUSH	30	15		18	6
BEARING/CRANK/UPPER	6	11	CAMSHAFT/INJECTION P	21	10	FLANGEBOLT/M8X50	12	19
BEARING/CRANKSET	6	10	CAP, BLANK/30	10	35	FLANGEBOLT/M8X55	10	9
BEARING/THRUST/CRANK	6	13	CAP, OIL FILLER	3	2	FLANGEBOLT/M8X75	10	13
	7	2	CAP, SEALING	2	2		18	18
	7	4	CARTRIDGE/OILFILTER	17	13	FLANGEBOLT/M8X85	10	8
BELT/VNR5A36.5	19	6	CLAMP, STRAINER	17	8	FLYWHEEL	21	17
BODY/NOZZLE HOLDER	28	2	CLAMP/WIRE/10-15	18	14	FLYWHEEL ASSY	16	5
BODY/OILPUMP	17	2	CLIP/HOSE/7.6-8.2	22	5	FRAME/DRIVEEND ASSY	30	7
BOLT	2	7	COLLOR	30	3	FRAME/END/REAR	30	12
	6	2	CONNECTINGROD ASSY	14	5	GASKET	3	5
	10	38	CONNECTOR, OIL FILTER	6	24		18	2
	12	18	CONNECTOR/FUEL	22	1		25	7
	30	9	CONNECTOR/GLOWPLUG	25	5		27	5
	30	10	CORRUGATEDTUBE	22	6		27	22
	30	19	COVER, BEARING	30	5	GASKET, EXH. MANIFOLD	5	2
	30	20	COVER/CYLINDER HEAD	3	1		27	7
	30	21	COVER/END/REAR	30	13	GASKET, INLET MANIFOL	4	2
	30	22	COVER/HYDRAULIC	10	47		27	6
	30	24	COVER/INJECTIONPUMP	6	25	GASKET, NOZZLE	20	3
BOLT, JOINT	17	11	CRANKSHAFT ASSY	16	1	GASKET/COVER	6	26
BOLT, S/M6X12/7T	13	5	CUP/SEALING/12	6	7		10	48
	21	16	CUP/SEALING/16	10	3		27	11
BOLT, S/M6X25/7T	17	5	CUP/SEALING/28	6	3	GASKET/CYLINDERHEAD	2	6
BOLT, S/M8X20/7T	10	51	CUP/SEALING/36	6	4		27	3
BOLT, S/M8X25/7T	5	3	CUTTER, VALVE	12	5	GASKET/DELIVERYVALVE	29	4
BOLT, SEMS/M10X20, 7T	9	3	CYLINDERBLOCK ASSY	6	1	GASKET/GEARCASE	10	27
BOLT, SEMS/M10X25, 7T	24	8	CYLINDERHEAD ASSY	2	1		27	14
BOLT/CONNECTINGROD	14	6	DOWEL	6	21	GASKET/HOUSING	18	16
BOLT/CRANK	16	9	ELEMENT ASSY	29	7		27	20
BOLT/FLANGE	16	7	FAN/COOLING	19	1	GASKET/PLATE	10	37
BOLT/M6	10	32	FLANGEBOLT/M10X20	11	2		27	15
	10	33	FLANGEBOLT/M10X70	24	5	GASKET/SPACER	18	9
BOLT/M6X10	21	18	FLANGEBOLT/M6X10	8	4		27	19

Alphabetical Index

6004-097-690-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
GASKET/WATERPUMP	18 5	NUT/M08	21 9	PISTON(0V/050)	15 1
	27 18	NUT/M6	10 34	PISTON(0V/100)	15 3
GEAR/CAMSHAFT	13 2		21 29	PISTON/VALVE/RELIEF	10 29
GEAR/CRANK	16 3	NUT/M8	10 18	PLATE	29 11
GEAR/IDLE ASSY	13 6		10 45		30 8
GEAR/INJECTIONPUMP	21 11		10 49	PLATE/ADJUST	24 2
GEARCASE ASSY	10 1	NUT/NOZZLERETAINING	28 5	PLATE/ADJUSTING	29 9
GENERATOR ASSY	24 1	OILPAN COMP	8 1	PLATE/FRONT	10 36
GLOWPLUG	25 3	OILPUMP ASSY	17 1	PLATE/REAR COMP	9 1
GUIDE/LEVELGAGE COMP	6 30	ORING	29 3	PLATE/TAPPET/AD 0.2	29 23
HANGER	11 1	O-RING/1A,P15	17 7	PLATE/TAPPET/AD 0.25	29 27
HOLDER/BRUSH ASSY	30 16		27 17	PLATE/TAPPET/AD 0.3	29 24
HOLDER/DELIVERYVALVE	29 2	O-RING/1A,P18	8 3	PLATE/TAPPET/AD 0.35	29 28
HOLDER/JE/9-9	10 14	O-RING/1A,P8	21 26	PLATE/TAPPET/AD 0.4	29 25
HOLDER/NOZZLE ASSY	28 1	O-RING/1A,S50	10 40	PLATE/TAPPET/AD 0.45	29 29
HOLDER/RECTIFIE ASSY	30 14		27 16	PLATE/TAPPET/AD 0.5	29 26
HOSE/RUBBER	3 6	O-RING/1A,S55	18 21	PLATE/TAPPET/AD 0.55	29 30
	18 13		27 21	PLATE/TAPPET/AD 0.6	29 18
	22 3	PACKING	10 20	PLATE/TAPPET/AD 0.65	29 31
HOUSING ASSY	29 6		17 12	PLATE/TAPPET/AD 0.7	29 19
HOUSING/THERMOSTAT	18 15		27 13	PLATE/TAPPET/AD 0.8	29 20
INJECTIONNOZZLE ASSY	20 1	PIECE, DISTANCE	28 6	PLATE/TAPPET/AD 0.9	29 21
INJECTIONPUMP ASSY	21 1	PIN	6 17	PLATE/TAPPET/AD 1.0	29 22
KEY/07X05X09	13 3		6 28	PLATE/THRUST	13 4
	21 12		10 23	PLATE/THRUST/INJECTI	21 15
KEY/07X05X20	16 4	PIN, CONTROL	21 22	PLATE/WATER PUMP	18 3
LEVELGAGE	6 29	PIN, GROOVE	10 26	PLUG	12 11
LEVER/CONTROL COMP	21 25	PIN, NOZZLE HOLDER	28 3	PLUG/M14X1.5	8 2
MANIFOLD(INLET) ASSY	4 1	PIN, PISTON	14 3	PLUG/PT1/2	2 3
MANIFOLD, EXH	5 1	PIN, ST, B/10X18	16 2	PLUG/PT1/8	6 5
NIPPLE	6 22	PIN/ARM	10 21		10 2
NOZZLE ASSY	28 51	PIN/IDLEGEAR	6 6	PLUG/SCREW	10 24
NUT	12 17	PIN/INJECTIONPUMP	29 10	PLUG/SCREW/SEAL	6 23
	28 50	PIN/SNAP	10 22	POINTER	9 2
	30 2	PIN/STRAIGHT	6 16	PULLEY	30 1
	30 23		17 3	PULLEY/CRANK	16 8
	30 25	PIN/TUBE	6 15	PULLEY/WATERPUMP	19 2
NUT, CAP/M8	10 19		10 41	RACK/CONTROL ASSY	29 13
NUT/CAP	3 4	PIPE, OIL	17 10	REGULATOR ASSY	26 1
NUT/FLANGE	25 4	PIPE/FUEL	22 2		30 26
NUT/FLANGE/M10	24 6	PIPE/INJECTION ASSY	20 4	REPAIR/ENGINE SET	27 1
NUT/M08	10 10		20 5	RESISTANCE/1.0	22 4
	12 20		20 6	RING, SNAP	14 4
	18 7	PIPE/WATEROUTLET	18 20	RING, SNAP/12 C	10 31
	18 12	PISTON	14 1	RING, SNAP/16 C	12 15

Alphabetical Index

6004-097-690-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
RING, SNAP/4 E	21 23	SPRING, STARTING	21 32	WASHER/1.1	28 15
RING/PISTON SET	14 2	SPRING/DELIVERYVALVE	29 1	WASHER/1.125	28 16
RINGGEAR	16 6	SPRING/NOZZLEHOLDER	28 4	WASHER/1.15	28 17
RINGPISTON/OV050 SET	15 2	SPRING/PUMPPLUNGER	29 16	WASHER/1.175	28 18
RINGPISTON/OV100 SET	15 4	SPRING/RELIEF VALVE	10 30	WASHER/1.2	28 19
RINK/CONTROL	21 21	SPRING/VALVE	12 3	WASHER/1.225	28 20
ROCKERARM	12 9	SPRINGGOVERNOR	21 24	WASHER/1.25	28 21
ROCKERSHAFT ASSY	12 8	STARTER ASSY	24 7	WASHER/1.275	28 22
ROD, PUSH	12 7	STOPPER/FULLLOAD	10 17	WASHER/1.3	28 23
ROTOR ASSY	30 4	STRAINER	17 6	WASHER/1.325	28 24
SCREW ADJUST	12 16	STUD	2 8	WASHER/1.35	28 25
SCREW/HOLLOW	21 3		6 19	WASHER/1.375	28 26
SCREW/WATER PUMP	18 4		6 20	WASHER/1.4	28 27
SEAL, BEARING CAP	6 8		10 4	WASHER/1.425	28 28
	27 8		10 5	WASHER/1.45	28 29
SEAL, BEARING CAP/7	6 9		10 6	WASHER/1.475	28 30
	27 9		10 42	WASHER/1.5	28 31
SEAL, CYL.HEAD COVER	3 3	STUD/M8X40	6 18	WASHER/1.525	28 32
	27 4		18 10	WASHER/1.55	28 33
SEAL, OIL	2 4	SWITCH/OILPRESSURE	25 1	WASHER/1.575	28 34
	6 14	TAPPET	12 6	WASHER/1.6	28 35
	10 7	TAPPET/INJECTION ASSY	29 12	WASHER/1.625	28 36
	27 2	THERMOMETER	25 2	WASHER/1.65	28 37
	27 10	THERMOSTAT	18 19	WASHER/1.675	28 38
	27 12	THRUSTPIECE	21 19	WASHER/1.7	28 39
SEAT/SPRING/LOWER	29 17	VALVE ASSY	29 5	WASHER/1.725	28 40
SEAT/SPRING/UPPER	29 15	VALVE/EXHAUST	12 2	WASHER/1.75	28 41
SEAT/VALVESPRING	12 4	VALVE/INTAKE	12 1	WASHER/1.775	28 42
SHAFT, CAM	13 1	VALVE/RELIEF ASSY	10 28	WASHER/1.8	28 43
SHAFT/HYDRAULIC ASSY	10 43	WASHER	20 2	WASHER/1.825	28 44
SHAFT/ROCKERARM ASSY	12 10	WASHER, PL/M6	21 30	WASHER/1.85	28 45
SHIM/INJECTIONPUMP	21 4	WASHER, SP/M6	21 31	WASHER/1.875	28 46
	21 5	WASHER, SP/M8	10 46	WASHER/1.9	28 47
	21 6		10 50	WASHER/1.925	28 48
	21 7	WASHER/0.9	28 7	WASHER/1.95	28 49
SHORTBLOCKENGINE ASSY	1 1	WASHER/0.925	28 8	WASHER/9X22X2	24 4
SLEEVE/PLUNGER	29 14	WASHER/0.95	28 9	WASHER/AIR BLEEDER	21 2
SOLENOID	25 6	WASHER/0.975	28 10	WATERPUMP ASSY	18 1
SPACER	10 39	WASHER/08X14X01	10 16		
SPACER, PUMP. WATER	18 8		10 25		
SPACER/FAN	19 3		27 23		
SPACER/FAN/48	19 4	WASHER/1.0	28 11		
SPRING	12 14	WASHER/1.025	28 12		
	30 18	WASHER/1.05	28 13		
SPRING, RETURN	21 27	WASHER/1.075	28 14		

Alphabetical Index

6005-097-245-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
ADAPTER/240X100 ASSY	23 1	BOLT/M6	10 35	CUP/SEALING/28	6 4
ARM/CONTROL	21 27	BOLT/M6X10	21 16	CUP/SEALING/36	6 5
ARM/FLOATING COMP	21 18	BOLT/THROUGH	29 16	CUP/SEALING/50	2 2
ARM/TENSION	23 2	BOLT/WS	9 3		6 6
ARMATURE/STARTE ASSY	29 2		17 3	CUTTER, VALVE	12 5
BALL	29 17		19 4	CYLINDERBLOCK ASSY	6 1
BALL, STEEL	2 5		29 15	CYLINDERHEAD ASSY	2 1
BEARING	29 3	BRACKET/ROCKERSHAFT	12 12	DOWEL	6 22
	29 4		12 13	EYEBOLT	28 49
BEARING, RB/6203	21 11	BRG/CONROD/UN025 SET	7 5	EYEBOLT/OILJET ASSY	6 34
BEARING/BALL	10 45	BRG/CONROD/UN050 SET	7 6	FAN/COOLING	19 1
	21 12	BRG/CRANK/UN025 SET	7 1	FLANGE BOLT/M10X20	11 3
	30 6	BRG/CRANK/UN050 SET	7 3	FLANGE BOLT/M10X70	24 5
	30 11	BRUSH	30 17	FLANGE BOLT/M6X10	8 4
BEARING/CONNECTING R	14 7	BUSH	30 15	FLANGE BOLT/M6X12	6 27
BEARING/CRANK SET	6 11	BUSH/CONNECTINGROD	26 22	FLANGE BOLT/M6X16	25 8
BEARING/CRANK/LOWER	6 13	BUSHING/DRAIN	29 20	FLANGE BOLT/M8X16	10 12
BEARING/CRANK/UPPER	6 12	CAMSHAFT	13 1		17 8
BEARING/THRUST/CRANK	6 14	CAMSHAFT/INJPUMP	21 8	FLANGE BOLT/M8X20	18 8
	7 2	CAP, OIL FILLER	3 5		18 14
	7 4	CAP/OILFILLER	6 31		21 6
BELT/VNR5A40.0	19 5	CARTRIDGE/OILFILTER	17 9		24 3
BOLT	2 7	CLAMP/STRAINER	17 7	FLANGE BOLT/M8X25	4 3
	6 2	CLAMP/WIRE/10-15	18 11		18 19
	10 39	CLAMP/WIRE/16-20	17 15	FLANGE BOLT/M8X30	10 16
	12 18	CLIP/HOSE/7.6-8.2	22 5	FLANGE BOLT/M8X45	18 7
	28 9	CLUTCH/STARTER ASSY	29 5	FLANGE BOLT/M8X50	10 13
	28 51	COLLOR	30 3	FLANGE BOLT/M8X55	12 19
	30 9	CONNECTINGROD ASSY	14 5	FLANGE BOLT/M8X60	10 14
	30 10	CONNECTOR/FUEL	22 1	FLANGE BOLT/M8X70	10 10
	30 19	CONNECTOR/GLOWPLUG	25 5	FLANGE BOLT/M8X75	10 9
	30 20	CONNECTOR/OILCOOLER	17 11		18 15
	30 21	CONTROL RACK	28 47	FLANGE BOLT/M8X85	10 8
	30 22	CONTROLSLEEVE	28 48	FLYWEIGHT ASSY	21 15
	30 24	CORRUGATED TUBE	22 6	FLYWHEEL ASSY	16 5
BOLT, S/M6X12/7T	13 5	COVER	29 23	FRAME/DRIVEEND ASSY	30 7
	21 14	COVER, BEARING	30 5	FRAME/END/REAR	30 12
BOLT, S/M8X20/7T	10 52	COVER/BLOWBY	3 3	FRAME/STARTEREND	29 10
BOLT, S/M8X25/7T	5 3	COVER/CYLINDER HEAD	3 1	GASKET	3 8
BOLT, SEMS/M10X20, 7T	11 2	COVER/END/REAR	30 13		20 5
BOLT, SEMS/M12X40/7T	24 8	COVER/HYDRAULIC	10 48		25 7
BOLT/CONNECTINGROD	14 6	COVER/INJECTIONPUMP	6 25		26 5
BOLT/CRANK	16 9	CRANKSHAFT ASSY	16 1		26 21
BOLT/FLANGE	16 7	CUP/SEALING/16	6 3		27 17
BOLT/M6	10 34	CUP/SEALING/20	10 3		28 4

Alphabetical Index

6005-097-245-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
GASKET	28 50	INJECTIONNOZZLE ASSY	20 1	O-RING/1A, P22A	26 17
	28 52	INJECTIONPUMP ASSY	21 1	O-RING/1A, P25	6 32
GASKET, NOZZLE	20 2	KEY/07X05X09	13 3	O-RING/1A, P8	21 25
GASKET, WATER PUMP	26 18		21 10	O-RING/1A, S50	10 41
GASKET/COVER	6 26	KEY/07X05X20	16 4		26 16
	10 49	LEVELGAGE	6 29	O-RING/1A, S55	18 18
	26 11	LEVER/CONTROL COMP	21 24		26 20
GASKET/CYLINDERHEAD	2 6	MANIFOLD/EXHAUST	5 1	PACKING	10 21
	26 3	MANIFOLD/INLET ASSY	4 1	PIN	6 18
GASKET/EXH MANIFOLD	5 2	NOZZLE	27 16		6 28
	26 7	NUT	12 17		10 24
GASKET/GEARCASE	10 28		27 18		28 11
	26 14		29 21	PIN, CONTROL	21 20
GASKET/HOUSING	18 13		29 22	PIN, ST, B/10X18	16 2
	26 19		30 2	PIN/ARM	10 22
GASKET/INLETMANIFOLD	4 2		30 23	PIN/GROOVE	10 27
	26 6		30 25	PIN/IDLEGEAR	6 8
GASKET/PLATE	10 38	NUT, CAP/M8	10 20	PIN/PISTON	14 3
	26 15	NUT/CAP	3 7	PIN/SNAP	10 23
GASKET/SPACER	18 5	NUT/FLANGE	25 4	PIN/SPRING	6 35
GASKET/WATERPUMP	18 2	NUT/FLANGE/M10	24 6	PIN/STRAIGHT	6 17
GEAR/CAMSHAFT	13 2	NUT/M08	10 11		17 2
GEAR/CRANK	16 3		12 20	PIN/TUBE	6 16
GEAR/IDLE ASSY	13 6		18 3		10 42
GEAR/INJECTIONPUMP	21 9		18 9	PINION/STARTER	29 8
GEARCASE ASSY	10 1		21 7	PIPE/FUEL	22 2
GENERATOR ASSY	24 1	NUT/M12	24 9	PIPE/INJECTION ASSY	20 6
GLOWPLUG	25 3	NUT/M6	10 36		20 7
GUIDE/LEVELGAGE COMP	6 30		21 28		20 8
HANGER	11 1	NUT/M8	10 19	PIPE/OILJET	6 33
HEATSHILD/NOZZLE	20 3		10 46	PIPE/WATER/HOUSING	6 24
HOLDER/BRUSH ASSY	30 16		10 50	PIPE/WATEROUTLET	18 17
HOLDER/DELIVERYVALVE	28 5	NUT/NOZZLERETAINING	27 15	PISTON	14 1
HOLDER/JE/9-9	10 15	OILCOOLERASSY	17 10	PISTON(OV/050)	15 1
	17 16	OILPAN COMP	8 1	PISTON(OV/100)	15 3
HOLDER/NOZZLEASSY	27 1	OILPUMP ASSY	17 1	PISTON/VALVE/RELIEF	10 30
HOLDER/RECTIFIE ASSY	30 14	OILSEAL	6 15	PLATE	30 8
HOLDER/STARTER ASSY	29 11		26 10	PLATE/ADJUST	24 2
HOSE/OILCOOLER/IN	17 13	ORIFICE	3 10	PLATE/FRONT	10 37
HOSE/OILCOOLER/OUT	17 14	O-RING	29 19	PLATE/REAR	9 1
HOSE/RUBBER	3 9	ORING	28 6	PLATE/T=2.60	28 16
	18 10		28 8	PLATE/T=2.65	28 17
	22 3	O-RING/1A, P18	8 3	PLATE/T=2.70	28 18
HOUSING/STARTER ASSY	29 9		10 33	PLATE/T=2.75	28 19
HOUSING/THERMOSTAT	18 12	O-RING/1A, P22A	17 6	PLATE/T=2.80	28 20

Alphabetical Index

6005-097-245-00

Description	Fig. Key		Description	Fig. Key		Description	Fig. Key	
PLATE/T=2.85	28	21	RESISTANCE/1.0	22	4	SHIM/INJECTIONPUMP	21	4
PLATE/T=2.90	28	22	RETAINER	29	7		21	5
PLATE/T=2.95	28	23	RING SNAP	14	4	SHORTBLOCKENGIN ASSY	1	1
PLATE/T=3.00	28	24	RING,SNAP/12 C	10	32	SLEEVEFLANGE	28	7
PLATE/T=3.05	28	25	RING,SNAP/4 E	21	21	SNAPRING	28	12
PLATE/T=3.10	28	26	RING/PISTONSET	14	2	SOLENOID	25	6
PLATE/T=3.15	28	27	RING/SNAP	12	15	SPACER	10	40
PLATE/T=3.20	28	28	RINGGEAR	16	6		27	14
PLATE/T=3.25	28	29	RINGPISTON/OV050 SET	15	2	SPACER/FAN/48	19	3
PLATE/T=3.30	28	30	RINGPISTON/OV100 SET	15	4	SPACER/WATERPUMP	18	4
PLATE/T=3.35	28	31	RINK/CONTROL	21	19	SPRING	12	14
PLATE/T=3.40	28	32	ROCKERARM	12	9		30	18
PLATE/T=3.45	28	33	ROCKERSHAFT ASSY	12	8	SPRING, BRUSH	29	12
PLATE/T=3.50	28	34	RORA	29	6	SPRING, RETURN	21	26
PLATE/T=3.55	28	35	ROTOR ASSY	30	4	SPRING/DELIVERYVALVE	28	3
PLATE/T=3.60	28	36	RUBBERFLANGE	3	2	SPRING/GOVERNOR	21	23
PLATE/T=3.65	28	37	SCREW	29	14	SPRING/IDLE	21	32
PLATE/T=3.70	28	38	SCREW, SOCKET/M6X20	17	4	SPRING/PLUNGER	28	13
PLATE/T=3.75	28	39	SCREW/ADJUST	12	16	SPRING/RELIEF VALVE	10	31
PLATE/T=3.80	28	40	SCREW/TAPPING	3	4	SPRING/RETURN	29	18
PLATE/T=3.85	28	41	SEAL, BEARING CAP	6	9	SPRING/SETTING	21	22
PLATE/T=3.90	28	42		26	8	SPRING/STARTING	21	31
PLATE/T=3.95	28	43	SEAL, BEARING CAP/7	6	10	SPRING/VALVE	12	3
PLATE/T=4.00	28	44		26	9	SPRINGNOZZLE	27	12
PLATE/T=4.05	28	45	SEAL, OIL	2	4	SPRINGSEAT	27	13
PLATE/T=4.10	28	46		10	7		28	14
PLATE/THRUST	13	4		26	2		28	15
PLATE/THRUST/INJPUMP	21	13		26	12	STARTER ASSY	24	7
PLUG	12	11	SEAL/CYL HEAD/UNDER	3	6	STOPPER/FULLLOAD	10	18
PLUG/CYLINDERBLOCK	6	37		26	4	STRAINER	17	5
PLUG/M14X1.5	8	2	SEAT/VALVESPRING	12	4	STUD	2	8
PLUG/PT1/2	2	3	SHAFT/HYDRAULIC ASSY	10	44		6	20
PLUG/PT1/4	10	2	SHAFT/ROCKERARM ASSY	12	10		10	4
PLUG/PT1/8	6	7	SHIM/0.10	27	2		10	5
	6	36	SHIM/0.20	27	3		10	6
PLUG/SCREW	10	25	SHIM/0.30	27	4		10	43
PLUG/SCREW/SEAL	6	23	SHIM/0.40	27	5	STUD/M8X40	6	19
PLUNGER ASSY	28	1	SHIM/0.50	27	6		18	6
POINTER	9	2	SHIM/0.52	27	7	STUD/M8X60/7T	6	21
PULLEY	30	1	SHIM/0.54	27	8	SWITCH/MAGNETIC ASSY	29	13
PULLEY/CRANK	16	8	SHIM/0.56	27	9	SWITCH/OILPRESSURE	25	1
PULLEY/WATERPUMP	19	2	SHIM/0.58	27	10	TAPPET	12	6
PUSHROD	12	7	SHIM/0.80	27	11		28	10
REGULATOR ASSY	30	26	SHIM/INJECTIONPUMP	21	2	THERMOMETER	25	2
REPAIR/ENGINESET	26	1		21	3	THERMOSTAT	18	16

Alphabetical Index

6005-097-245-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
THRUSTPIECE	21 17				
VALVE, DELIVERY	28 2				
VALVE/EXHAUST	12 2				
VALVE/INTAKE	12 1				
VALVE/RELIEF ASSY	10 29				
WASHER, PL/M6	21 29				
WASHER, SP/M6	21 30				
WASHER, SP/M8	10 47				
	10 51				
WASHER/Ø8X14X01	10 17				
	10 26				
	26 13				
WASHER/9X22X2	24 4				
WASHER/CORRUGATE	20 4				
WASHER/OILCOOLER	17 12				
WATERPUMP ASSY	18 1				
YOKE/STARTER ASSY	29 1				

Alphabetical Index

1832-097-100-00

Description	Fig. Key		Description	Fig. Key		Description	Fig. Key	
ADAPTER(3/8X1/4)	56	5	ARM/MIRROR ASSY	64	16	BEARING/BALL	49	2
ADAPTER/90DEG/3/8	54	9	ARM/NEUTRAL ASSY	30	11	BEARING/BALL/6010C	21	12
ADAPTER/90DEG/PUMP	53	7	ARM/PARKING COMP	36	10	BEARING/BALL/6909	49	34
ADAPTER/G1/4	55	16	ARM/SPOOL COMP	52	3	BEARING/BALL/HPS	18	2
ADAPTER/G1/4 ASSY	55	7	ARM/TRUNNION COMP	30	1		18	5
ADAPTER/G1/4-M1 ASSY	55	52	BAND	63	23		21	13
ADAPTER/G1/4XG3/8	55	30		67	14		26	2
ADAPTER/G3/8ASSY	56	15		71	8		26	12
	56	22	BAND,WIRE/140	67	20		26	28
ADAPTER/L/G1/4 ASSY	54	15	BAND,WIRE/250	67	19		33	2
	55	12	BAR/ROCK COMP	39	7		33	6
	55	55	BATTERY/55B24R ASSY	12	1	BLOCK/CYLINDER/HMP1	82	3
ADAPTER/L/G1/4XR1/4	41	15	BATTERY/80D26R ASSY	11	1	BLOCK/PORT/HMP1/008	82	2
ADAPTER/L/PF3/8 ASSY	56	19	BEARING,RB/16004	27	11	BODY/VALVE/PT0	55	33
ADAPTER/L/PT1/8	55	46		28	11	BOLT,S/M10X20/7T	32	13
ADAPTER/PF1/4 ASSY	55	44	BEARING,RB/6201SS	30	4		35	27
ADAPTER/PT1/8	55	47	BEARING,RB/6203	26	9	BOLT,S/M10X25	52	2
ADAPTER/R3/8-G1/4	56	7	BEARING,RB/6204	26	5	BOLT,S/M10X25/7T	36	15
ADAPTER/T	53	12		26	8	BOLT,S/M10X30/7T	32	11
	56	1		26	14		41	13
ADAPTOR(G3/8) ASSY	54	14		27	2	BOLT,S/M10X40/7T	41	14
ADPTE/G1/4.1/4	55	9		27	14	BOLT,S/M8X16	13	12
	55	48		28	2		16	15
ARM	66	29		28	14		56	6
	66	33		48	16	BOLT,S/M8X16/7T	53	9
	66	39	BEARING,RB/6206	26	4		57	6
	66	47		33	15		57	8
ARM/4WD COMP	47	3	BEARING,RB/6305	20	10	BOLT,S/M8X20	32	7
	48	23		82	9		60	4
ARM/BRAKE COMP	35	1	BEARING/6010/KBC	49	14	BOLT,S/M8X20/7T	30	8
ARM/BRAKE/SHAFT COMP	35	28	BEARING/6205/KBC	49	32		31	32
	36	11		49	51		42	18
ARM/COUNTER/BRAKE	35	13	BEARING/6206/KBC	49	29		43	18
ARM/COUNTER/FRONT	31	10		49	52	BOLT,SEMS/M10X20,7T	2	3
ARM/COUNTER/REA ASSY	31	26	BEARING/6304/KBC	49	46	BOLT,SEMS/M12X25/7T	1	3
ARM/DIFF COMP	22	2	BEARING/BALL	18	7		42	3
ARM/DUMP/COLLECTOR	52	32		20	2		42	7
ARM/HST ASSY	30	25		26	27		42	16
ARM/HST/F COMP	31	4		27	5		43	3
ARM/HST/R COMP	31	18		27	10		43	7
ARM/LIFT/COLLECTOR	52	21		27	15		43	16
ARM/LIFT/LH ASSY	57	1		28	5	BOLT,SEMS/M12X35/7T	42	8
ARM/LIFT/MOWER COMP	52	10		28	10		42	10
ARM/LIFT/RH ASSY	57	3		28	15		43	8
ARM/MIRROR ASSY	63	16		33	11		43	10

Alphabetical Index

1832-097-100-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
BOLT, SP/M10X25	42 21	BOLT, SP/M8X16	60 10	BOLT/SEAL/M8X30X9T	48 2
	54 2	BOLT, SP/M8X16/7T	41 18	BOLT/SM/M10X23	30 2
	54 5	BOLT, SP/M8X20	3 17	BOLT/SP/M10X30	49 54
BOLT, SP/M10X25/7T	37 7		4 17	B00T	66 27
	42 2		7 6	B00T/COVER/COLUMN	59 4
	43 2		8 6	BRACKET/COVER COMP	39 5
	49 62		67 18	BRACKET/LEVER/4WD	47 1
BOLT, SP/M10X30	10 2	BOLT, SP/M8X25/7T	5 6	BRACKET/LEVER/ACCELE	13 3
BOLT, SP/M10X30/7T	26 25		6 6	BRACKET/MOUNT/L COMP	1 1
BOLT, SP/M6X16	3 5		61 2		2 1
	3 7	BOLT, SP/M8X35/7T	40 4	BRACKET/MOUNT/R COMP	1 2
	4 5	BOLT/BATTERY	11 2		2 2
	4 7		12 4	BRACKET/MUFFLER/224	6 5
	66 22	BOLT/LH/M12X1.25X25	72 16	BRACKET/MUFFLER/235	5 5
	66 30	BOLT/M06X08/APSET	83 8	BRACKET/NEUTRAL COMP	30 7
	66 34	BOLT/M10X190	48 12	BRACKET/VALVE COMP	52 1
	66 37	BOLT/M10X21	39 4	BRACKET/WEIGHT COMP	79 6
	66 41	BOLT/M10X30/7T, P1.25	5 3	BRAKE/114 ASSY	34 4
	66 48		6 3	BRAKE/SHOE ASSY	34 5
BOLT, SP/M6X20	55 5	BOLT/M10X35/9T	49 67	BULB/12V/5W	63 27
BOLT, SP/M6X35	55 3	BOLT/M10X40	39 8		64 26
BOLT, SP/M8X16	3 41	BOLT/M12X30/7T	64 19	BULB/12V21/5W	86 9
	4 41	BOLT/M12X35/7T	79 7	BULB/12V21W	63 7
	9 17		80 2		63 12
	11 7	BOLT/M12X35/9T	70 2		64 7
	12 9		70 9		64 12
	29 6	BOLT/M12X60	81 2		86 8
	31 3	BOLT/M12X60/7T	79 3	BULB/12V3.4W	65 20
	31 17	BOLT/M14X1.5X30	51 6	BULB/12V4W	63 8
	44 6	BOLT/M16X120	71 2		63 13
	44 9	BOLT/M6X50	72 12		64 8
	44 12	BOLT/M8X105	32 9		64 13
	44 14	BOLT/M8X120/7T	17 5	BULB/H4/60/55W	63 6
	44 17	BOLT/M8X25	21 5		63 11
	44 19	BOLT/M8X30/7T	31 33		64 6
	44 21	BOLT/M8X35	3 23		64 11
	45 6		4 23	BUMPER/REAR COMP	63 18
	45 9	BOLT/M8X40/7T	48 29		64 18
	45 12	BOLT/M8X55/7T	31 34	BUSH	84 7
	45 14	BOLT/M8X65	9 2	BUSH, LEVER	3 19
	45 17	BOLT/M8X75	55 38		4 19
	45 19	BOLT/M8X80	55 39	BUSH/10X12X15	19 2
	45 21	BOLT/S/M12X30	49 22	BUSH/18X20X20	30 12
	46 3		49 26		30 26
	46 6	BOLT/SEAL/M8X30X9T	15 3	BUSH/20X23X20	57 2

Alphabetical Index

1832-097-100-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
BUSH/20X23X20	57 4	CHAIN/ROLLER60X060	33 13	CONTROLLER/PTO ASSY	69 7
BUSH/22X25X25	31 11	CHUTE/BLOWER COMP	72 3	CONTROLLER/STEERING	40 1
	31 27	CHUTE/GUIDE COMP	72 7	COOLER/OIL ASSY	56 11
	35 31	CLAMP/28X55	41 17	COUPLING/PTO	27 4
	36 14	CLAMP/WIRE/30-38	3 11		28 4
	49 19		4 11	COUPRING/16X27X55	26 22
BUSH/40X44X15	82 12	CLAMP/WIRE/36-44	3 10	COVER ASSY	7 2
BUTTON	36 4		4 10		8 2
BUZZER	66 21	CLAMP/WIRE/47-55	8 9	COVER, BRAKE	34 7
CABLE/4WD/LOCK ASSY	47 11	CLAMP/WIRE/52-63	7 8	COVER/4WD COMP	48 30
CABLE/ACCELERATOR	13 8		7 10	COVER/BATTERY	11 3
CABLE/ACCELERATOR/AU	14 1		8 8		12 5
CABLE/BATTERY ASSY	11 8		8 11	COVER/BUSH/HMP1/008	82 29
	12 10	CLAMP/WORM/16-25	54 7	COVER/CHUTE/SIDE	44 20
CABLE/DIFF ASSY	23 6	CLEANER/AIR ASSY	7 1	COVER/CHUTE/SIDE/W	45 20
CABLE/EARTH ASSY	11 6		8 1	COVER/COLUMN/F	59 1
	12 8	CLIP	7 3	COVER/COLUMN/R	59 2
CAM/CENTER	84 10		8 3	COVER/CONTROLLER	69 10
CAM/DRAIVE	84 13	CLIP/BAND/4.5	67 15	COVER/DUST	50 4
CAM/DRIVEN	84 8	CLIP/HOSE/11.1-12.0	9 12	COVER/ENGINE COMP	58 1
CAP	3 32	CLIP/HOSE/11.9-12.6	9 6	COVER/FRONT	60 6
	4 32		9 8	COVER/FUSE	67 11
	83 4	CLIP/HOSE/13.8-14.8	16 10	COVER/RADIATOR COMP	3 26
CAP, BLANK/72	25 5		16 14		4 26
CAP, OIL	49 57	CLIP/HOSE/14.7-15.9	3 13	COVER/RADIATOR/UPPER	3 42
CAP, PTO SHAFT	29 5		4 13		4 42
CAP/NONLEAK ASSY	10 8	CLIP/HOSE/8.7-9.3	9 14	COVER/REAR/UNDER	44 13
CAP/OIL (30)	16 16	CLUMP	3 36		45 13
CAP/PIPE	63 4		4 36	COVER/REAR/UPPER	44 11
	64 4	CLUTCH ASSY	48 13		45 11
CAP/WHEEL	38 2	CLUTCH/DIFFLOCK	22 1	COVER/REARLIGHT	63 32
CASE, DIFF	21 6	CLUTCH/PTO ASSY	26 6	COVER/ROD/A SET	41 4
CASE/4WD	48 3		27 6	COVER/ROD/B SET	41 7
CASE/BLOWER COMP	72 1		28 6	COVER/SIDE/LH/F COMP	44 2
CASE/CHAIN/A	32 1	COLLAR, PINION THRUST	21 9		45 2
CASE/CHAIN/B	32 3	COLLAR, THRUST	21 11	COVER/SIDE/LH/R COMP	44 1
CASE/CONTROLLER COMP	69 1	COLLAR/08X12X15	40 3		45 1
CASE/DIFFERENTIAL/FR	49 8	COLLAR/12X22X80	39 12	COVER/SIDE/RH COMP	44 8
CASE/FINAL/LOWER/LH	49 38	COLLAR/48X52X17	49 5		45 8
CASE/FINAL/LOWER/RH	49 41	COLLAR/50X62X08	20 6	COVER/SIDEPTO	29 3
CASE/FINAL/UPPER/LH	49 20	COLLAR/53X61X06	20 3	COVER/TANK	10 12
CASE/FINAL/UPPER/RH	49 24	COLUMN/STEERING/LOWE	39 1	COVER/TRUNNION/HMP1/	82 30
CASE/HMP1/008	82 1	COLUMN/STEERING/UPPE	39 3	COVER/WHEEL	49 53
CASE/TRANSMISSION/LH	16 1	CONNECTOR/SUCTION	54 3	CUSHION, B/ RUBBER	72 5
CASE/TRANSMISSION/RH	16 2	CONTROLLER ASSY	69 5	CUSHION/RUBBER/10X25	3 22

Alphabetical Index

1832-097-100-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
CUSHION/RUBBER/10X25	4 22	FLANGEBOLT/M8X16	4 15	GEAR/BEVEL/09	49 45
CYLINDER ASSY	41 1		22 7	GEAR/BEVEL/11	49 28
CYLINDER/013 ASSY	53 1		36 6	GEAR/BEVEL/14	21 10
DAMPER/OIL ASSY	30 33		39 6	GEAR/BEVEL/15	49 10
DIODE/3.0A	67 13		48 26	GEAR/BEVEL/17	49 31
DISC/BRAKE	85 7		48 31	GEAR/BEVEL/21	49 16
DISK/BRAKE	87 11		52 47	GEAR/BEVEL/35	49 48
DRUM/BRAKE	34 1		58 2	GEAR/HELICAL/28	18 1
DUMPER/HOOD ASSY	58 9		62 2		18 6
DUST SEAL	41 6	FLANGEBOLT/M8X25	16 4		26 3
	41 9		24 3	GEAR/HELICAL/31	18 4
DUST SEAL SER42	53 4		25 3		26 1
ELBOW/90DEG ASSY	55 42		26 20	GEAR/HELICAL/31 COMP	27 1
	56 9		35 32		28 1
	56 13		48 22	GEAR/INPUT SET	20 1
ELEMENT	83 7	FLANGEBOLT/M8X40	17 3	GEAR/SPUR/24 COMP	20 9
ELEMENT ASSY	7 4		32 6	GEAR/SPUR/26 COMP	26 7
	8 4	FLOOR	62 1	GEAR/SPUR/33	26 11
FAN COMP	72 14	FRAME/FLOOR COMP	42 9	GEAR/SPUR/34	26 13
FAN/RADIATOR/22 ASSY	4 6		43 9	GEAR/SPUR/40 COMP	27 13
FAN/RADIATOR/23 ASSY	3 6	FRAME/LH COMP	70 1		28 7
FENDER/SF2	60 1	FRAME/LOWER COMP	42 6	GEAR/SPUR/42	21 1
FILTER/FUEL	10 7		43 6	GEAR/SPUR/45 COMP	27 7
FILTER/FUEL ASSY	9 1	FRAME/MAIN COMP	42 1		28 13
FILTER/OIL ASSY	56 3		43 1	GRIP	52 17
	56 4	FRAME/RADIATOR COMP	3 16		52 28
FILTER/PORT/09	55 34		4 16		52 39
FILTER/SUCTION/400	54 1	FRAME/RH COMP	70 8		58 3
FLANGEBOLT/M10X20	35 9	FRAME/UPPER COMP	42 13	GRIP/4WD	47 7
	39 2		43 13	GRIP/ORANGE	36 5
FLANGEBOLT/M10X70	63 2		71 1	GRIP/THROTTLE	13 2
	64 2	FUSE(BLADE/32V15A)	67 8	GROMMET/13X17X05	60 5
FLANGEBOLT/M12X20	72 2	FUSE/BLADE/32V05A	67 6	GROMMET/17X21X05	60 2
FLANGEBOLT/M12X25	63 19	FUSE/BLADE/32V10A	67 7	GROMMET/17X21X3	70 4
FLANGEBOLT/M6X10	52 16	FUSE/BLADE/32V20A	67 9	GROMMET/9	63 29
	52 27	FUSE/SLOW BLOW/40A	67 5		64 28
	52 38	FUSE/SLOW BLOW/60A	67 4	GUARD/HOSE	9 15
FLANGEBOLT/M6X12	29 2	FUSE/SLOWBLOW/50A	67 3	GUARD/RUBBER	46 7
	29 4	GASKET	5 2	GUARD/UNDER/FRONT	44 16
FLANGEBOLT/M6X16	63 17		6 2		45 16
	64 17		86 1	GUARD/UNDER/REAR	44 18
	67 17	GASKET/HMP1/008	82 19		45 18
FLANGEBOLT/M8X12	12 3	GAUGE,OIL LEVEL	16 6	GUIDE/CHAIN	33 14
	63 33	GAUGE/FUEL ASSY	10 4	GUIDE/LEVER COMP	52 46
FLANGEBOLT/M8X16	3 15	GAUGE/LEBEL	16 5	HARNESS/JOINT ASSY	68 1

Alphabetical Index

1832-097-100-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
HARNESS/LAMP	63 28	HOUSING/AXLE ASSY	49 18	JOINT BALL M08RH	30 18
	64 27	HST/SFH/23 ASSY	19 1	KEY	65 16
HARNESS/LAMP ASSY	65 19	HUB/12X22X30	48 8		65 25
HARNESS/MAIN ASSY	67 1	HUB/12X22X97	48 9	KN0B/SET/M06X15	60 7
HARNESS/OILPRESSURE	67 21	HUB/BRAKE/SHAFT COMP	35 24	LABEL/4WD	75 5
HOLDER	13 11	HUB/PARKING ASSY	36 13	LABEL/BATTERY	76 2
	65 4	INSULATOR	3 4		76 12
HORN ASSY	66 17		4 4		77 2
	66 19		57 12		77 12
HOSE ASSY	56 24		65 5	LABEL/BATTERY/55B24R	77 13
HOSE/07X12X1250 ASSY	9 11		71 11	LABEL/BATTERY/80D26R	76 13
HOSE/08X13X300	9 7		71 12	LABEL/CAUTION	76 1
HOSE/08X13X600	9 5	INSULATOR/10X10X450	3 3		76 9
HOSE/290 ASSY	3 12		4 3		77 1
	4 12	INSULATOR/1100	58 5		77 9
HOSE/BREATHER	16 9	INSULATOR/15	40 5	LABEL/CAUTION/L	76 10
	16 13	INSULATOR/15X15X280	3 20		77 10
HOSE/CLEANER/INLET	7 9		4 20	LABEL/CE	78 1
	8 10	INSULATOR/15X55X03	58 8	LABEL/CONTROL	75 4
HOSE/CLEANER/OUTLET/	7 7	INSULATOR/16X300	58 7	LABEL/CONTROL/SHROTT	75 3
	8 7	INSULATOR/210	44 5	LABEL/CONTROL/START/	65 18
HOSE/DRAIN/MOTER	54 6		45 5	LABEL/DIFF	75 2
HOSE/FUEL/2450 ASSY	9 13	INSULATOR/220	3 45	LABEL/FUEL	76 3
HOSE/FV-M ASSY	55 54		4 45		77 3
HOSE/HYDRO/1000 ASSY	55 14	INSULATOR/240	46 2	LABEL/FUSE	67 2
HOSE/HYDRO/1200 ASSY	53 11		46 5	LABEL/METER	65 22
	54 17	INSULATOR/30X35X150	3 43	LABEL/NOISE/LWA/105	77 14
HOSE/HYDRO/1550 ASSY	55 15		4 43	LABEL/PANEL	65 23
HOSE/HYDRO/1700 ASSY	55 50	INSULATOR/550	44 4	LABEL/PARKING	75 1
HOSE/HYDRO/1800 ASSY	55 6		45 4	LABEL/ROPS	76 11
HOSE/HYDRO/3200 ASSY	41 16	INSULATOR/595	58 6		77 11
HOSE/HYDRO/600 ASSY	55 11	INSULATOR/791	3 39	LABEL/W/FAN	76 6
	56 2		4 39		77 6
	56 8	INSULATOR/90	3 30	LABEL/W/RADIATOR	76 7
HOSE/HYDRO/750 ASSY	53 10		4 30		77 7
HOSE/RADIATOR/IN/224	4 8		44 15	LABEL/W/STARTER	76 8
HOSE/RADIATOR/IN/235	3 8		45 15		77 8
HOSE/RADIATOR/OUT/22	4 9	INSULATOR/CHUTE	72 8	LABEL/WARNING/BELT	76 5
HOSE/RADIATOR/OUT/23	3 9	INSULATOR/LAMP	63 21		77 5
HOSE/RUBBER	3 34		64 21	LABEL/WARNING/HOT	76 4
	3 35	INSULATOR/MOUNT/LH	1 4		77 4
	3 37		2 4	LAMP/COMBINATION/REA	63 20
	4 34	INSULRATOR/45X45X90	3 44		64 20
	4 35		4 44	LAMP/HEAD/LH ASSY	63 5
	4 37	JOINT BALL M08LH	30 22		64 5

Alphabetical Index

1832-097-100-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
LAMP/HEAD/RH ASSY	63 10	NUT, CASTLE/M16 P=1.5	49 64	NUT/WASHER/M6	66 16
	64 10	NUT, RING	83 5		66 18
LAMP/MONITOR ASSY	65 9	NUT/LH/M08	30 21		66 20
LAMP/NUMBERPLAT SET	63 26		35 36		66 35
	64 25	NUT/M10	13 7		67 16
LEVER/ACCELERATOR	13 1		39 9		69 9
LEVER/COLLECTOR COMP	52 22	NUT/M10/7T	37 6	NUT/WASHER/M8	3 18
	52 33		42 15		3 46
LEVER/LIFT COMP	52 11		43 15		4 18
LEVER/PARKING ASSY	36 1		49 66		4 46
LEVER/TILT	39 13	NUT/M12	1 5		11 9
LINING/13X50X03	13 4		2 5		12 11
LINKPIN	71 7		30 6		30 34
MAT/STEP	62 3		81 3		56 12
METAL/4WD	48 19	NUT/M12/7T	30 32		58 10
METAL/HST	17 1		42 12		66 42
METAL/PTO/B	26 24		43 12		69 3
METAL/PTO/BLOWER	24 1	NUT/M12X1.25	50 6		69 6
	25 1	NUT/M16	57 11		69 11
METAL/PTO/MOWER	26 18		71 3		72 4
METER/FUEL ASSY	65 3	NUT/M6	11 4	OIL SEAL	82 28
METER/HOUR ASSY	65 2		12 6	O-RING	82 38
MIRROR ASSY	63 15		55 4	O-RING/1A, G35	54 8
	64 15		72 13	O-RING/1A, G45	54 4
MOLDING/FENDER/LH	73 1	NUT/M8	30 17	O-RING/1A, G50	19 4
	74 1		30 19	O-RING/1A, G60	82 31
MOLDING/FENDER/RH	73 2		30 24	O-RING/1A, G65	48 7
	74 2		35 34	O-RING/1A, G70	19 5
MUDGUARD/LH COMP	46 1		48 28	O-RING/1A, P10A	83 2
MUDGUARD/RH COMP	46 4		54 11	O-RING/1A, P18	34 9
MUFFLER COMP	5 1		57 13	O-RING/1A, P20	71 10
	6 1		71 13	O-RING/1A, P24	22 4
NEEDLE	82 11		72 6		48 24
NET/COOLER/OIL	56 25		86 7	O-RING/1A, P26	16 12
NIPPLE, GREASE	23 3	NUT/M8/7T	31 35	O-RING/1A, P44	83 6
	31 6	NUT/RING	65 17	O-RING/1A, S34	26 17
	31 20	NUT/WASHER/M10	30 10	O-RING/1A, S42	41 11
	35 3		47 2	O-RING/1A, S50	65 21
	35 15	NUT/WASHER/M4	10 6	O-RING/1B, P10	82 39
	35 26	NUT/WASHER/M5	66 2	O-RING/1B, P11	54 16
	49 61		66 12		55 8
NUT	65 7	NUT/WASHER/M6	9 10		55 10
	66 24		11 5		55 13
	66 26		12 7		55 45
NUT, CASTLE/M10 P1.25	50 7		66 14		55 49

Alphabetical Index

1832-097-100-00

Description	Fig. Key		Description	Fig. Key		Description	Fig. Key	
0-RING/1B, P11	55	53	PAD/HST/R	31	16	PIN/10X101	52	4
	55	56	PAD/PS	40	2	PIN/10X141	52	43
	82	23	PANEL/SWITCH COMP	65	1	PIN/10X21	22	3
0-RING/1B, P12	55	35	PEDAL/BRAKE COMP	35	7	PIN/12X75	49	11
0-RING/1B, P14	55	31	PEDAL/DIFF COMP	23	1	PIN/14X63 COMP	53	8
	55	32	PEDAL/HST/F COMP	31	1		57	5
	55	43	PEDAL/HST/RH COMP	31	15	PIN/19X124	71	6
	56	10	PIN ASSY	71	5	PIN/6X42	52	12
	56	14	PIN, SPLIT/2.5X15	13	10		52	23
	56	16	PIN, SPLIT/2.5X20	14	3		52	34
	56	18		23	8	PIN/B	49	23
	56	20		30	36		49	27
	56	23		31	9	PIN/CAM/BRAKE COMP	34	8
	82	22		31	14	PIN/COUNTER/HST	30	29
0-RING/1B, P15	19	6		31	25	PIN/COUNTER/HST COMP	31	31
0-RING/1B, P16	55	20		31	30	PIN/GROOVE	35	29
0-RING/1B, P20	55	22		35	12		36	12
0-RING/1B, P22	55	19		35	20	PIN/M16X112 COMP	57	7
0-RING/1B, P7	55	36		35	40	PIN/PARALLEL/08X32	21	2
0-RING/1B, S38	41	10		36	9	PIN/PIVOT COMP	49	60
0-RING/AS568/013	55	23		36	18	PIN/SNAP	52	9
0-RING/AS568/014	55	24		47	5		52	20
0-RING/AS568/015	55	25		47	10		52	31
ORNAMENT/224	74	3		47	14		52	42
ORNAMENT/235	73	3		50	9	PIN/SPRING	49	12
ORNAMENT/ISEKI	73	4	PIN, SPLIT/2.5X25	52	6	PIN/STRAIGHT	84	11
	73	5		52	45	PINION/BEVEL/09	49	1
	74	4	PIN, SPLIT/2X20	52	14	PINION/BEVEL/11	49	9
	74	5		52	25	PINION/BEVEL/12	21	8
ORNAMENT/STEERING	73	6		52	36	PIPE, BREATHER	16	8
	74	6	PIN, SPLIT/4X30	35	23	PIPE/COOLER COMP	56	21
PACKING	3	33		49	65	PIPE/FILLER/OIL	16	11
	4	33	PIN, SPRING/3X18 W	47	8	PIPE/PTO/MOWER COMP	55	51
	10	10	PIN, ST	82	32	PISTON	85	1
	49	58	PIN, ST, B/10X22	16	3		87	1
	83	9		17	2	PISTON STOPPER	53	3
PACKING PS-42	53	5		24	2	PISTON/012	53	2
PACKING, OIL PUMP	54	13		25	2	PLATE	10	9
PACKING/PISTON	41	3		26	19		48	25
PACKING/RUBBER	10	5		32	5	PLATE, SWITCH	66	45
PACKINGA	10	11		32	10	PLATE/ADJUST COMP	30	9
PAD	35	8		48	21	PLATE/BACK	85	4
PAD/50	9	16	PIN, ST, B/8X16	19	3		87	7
	69	2		21	3	PLATE/BRAKE	85	8
PAD/HST	31	2	PIN/05X17	52	7	PLATE/BRAKE COMP	35	10

Alphabetical Index

1832-097-100-00

Description	Fig. Key		Description	Fig. Key		Description	Fig. Key	
PLATE/BUMPER	80	1	PLUG/SCREW/SEAL	48	20	RING, SNAP/25 C	82	24
PLATE/CONTROLLER	40	6		49	59	RING, SNAP/30 C	20	5
PLATE/COVER	44	7		55	26		33	21
	45	7		82	40		87	10
PLATE/DISC	85	2	POPPET/1.3	55	29	RING, SNAP/32 C	82	26
PLATE/DISK	87	6	POPPET/CHECK/0.5	82	17	RING, SNAP/34 C	26	15
PLATE/GUARD/RADIATOR	3	38	POPPET/CHECK/0.9X2	82	18	RING, SNAP/45 C	48	5
	4	38	POPPET/RELIEF	82	15	RING, SNAP/47 C	48	18
PLATE/I/16X1105	31	12	PRESSURE/BRAKE	87	12	RING, SNAP/52 C	26	29
	31	28	PUMP/FUEL ASSY	9	9		33	3
PLATE/I/16X217	31	7	PUNP/GEAR/5.2/L ASSY	54	10		33	7
	31	23	R.B.B/6908/KOYO	49	35	RING, SNAP/R62	20	14
PLATE/I/19X115	46	8	RACKEND ASSY	50	3	RING, SNAP/R72	25	4
PLATE/I/19X140	52	29	RADIATOR ASSY	3	1		27	16
	52	40		4	1		28	16
PLATE/I/19X254	52	18	RBB/FLANGE	35	30	RING/22	27	9
PLATE/I/19X517	36	16	RELAY ASSY	66	1		28	9
PLATE/I/19X927	35	18		66	3	RING/25	27	8
PLATE/I/22X130	10	3		66	11		28	8
PLATE/L/220X30	12	2	RELAY/5P ASSY	66	5	RING/36	50	5
PLATE/PARKING COMP	36	7		66	6	RING/BACK UP	53	6
PLATE/SEPARATER	85	3		66	7	RING/BRAKE	84	4
	87	5		66	8	RING/0	85	12
PLATE/SPRING	82	16		66	9		87	2
PLATE/SWASH/HMP1/006	82	4		66	10		87	3
PLATE/SWITCH COMP	66	40	RELAY/FLASHER/EEC	66	15	RING/0/1A/G90	49	21
PLATE/THRUST/HMP1/00	82	10	RELIEFVALVE/090 ASSY	55	27		49	25
PLATE/U/70X85	63	22	RESERVETANK ASSY	3	31	RING/SEAL	85	6
	64	22		4	31	RING/SNAP	85	5
PLATE/VALVE/MOTOR	82	6	RESISTER/8	67	12		85	9
PLATE/VALVE/PUMP	82	5	RING	71	9	RING/SNAP/A	84	2
PLUG	65	8	RING, SNAP/16 C	34	3	RING/SNAP/B	84	12
PLUG(G3/8)	82	20	RING, SNAP/17 C	26	10	RING/SNAP/CR52	49	6
PLUG(PF1/4)	55	2	RING, SNAP/18 C	30	14		49	39
	82	21		30	28		49	43
PLUG, CAP/62X6	82	27	RING, SNAP/20 C	27	3	RING/SNAP/CR62	49	30
PLUG/52X10	49	40		27	12		49	37
	49	44		28	3	RING/SNAP/CS25	49	4
PLUG/M12X1.25	82	36		28	12	RING/SNAP/CS40	49	17
PLUG/SCREW	55	37	RING, SNAP/22 C	23	5		49	36
PLUG/SCREW/R1/4	49	42		31	22	RING/SNAP/CS50	49	15
PLUG/SCREW/SEAL	16	7		34	10	RING/SNAP/R62	33	16
	32	2		35	5		82	25
	32	4		35	17	RIVET/SCREW ASSY	62	4
	48	4	RING, SNAP/25 C	33	10	ROD	36	2

Alphabetical Index

1832-097-100-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
ROD PACKING	41 5	SHAFT,DIFF. PINION	21 7	SPRING/HE060	35 38
	41 8	SHAFT/100	49 56	SPRING/HE068	48 27
ROD/127 COMP	39 11	SHAFT/450	49 55	SPRING/HE073	22 5
ROD/4WD	47 6	SHAFT/465	26 21	SPRING/HE095	35 6
ROD/M08X110 COMP	30 20	SHAFT/4WD ASSY	48 1	SPRING/HE108	30 15
ROD/M08X120	35 33	SHAFT/BRAKE COMP	35 21	SPRING/PLATE	52 15
ROD/M08X47	30 16	SHAFT/DIFF/LH	33 1		52 26
ROD/M08X72/LH	35 37	SHAFT/DIFF/RH	33 5		52 37
ROD/PISTON	41 2	SHAFT/INPUT SET	15 1	SPROCKET/11	33 9
RODEND/137 ASSY	50 1	SHAFT/MOTOR/HMP1/008	82 8	SPROCKET/29	33 12
RODEND/B ASSY	50 2	SHAFT/OUTPUT	48 15	STAY/CASE COMP	32 12
RUBBER, CUSHION	60 9	SHAFT/PTO	26 26	STAY/COLLECTOR/LH	42 19
S.W/LH/M12	72 17	SHAFT/PUMP/HMP1/008	82 7	STAY/COLLECTOR/RH	42 20
SCREW	86 3	SHAFT/WHEEL	49 47	STAY/CONTROLLER	69 8
SCREW, SEMS/M5X16	70 7	SHAFT/WHEEL COMP	33 19	STAY/COVER/SIDE/P	29 1
SCREW, SOCKET/M10X35	82 33	SHIM	20 7	STAY/CYLINDER	41 12
SCREW, SP/M6X12	3 27	SHIM/0.1	20 11	STAY/DEFFCABLE	22 6
	4 27	SHIM/0.2	20 8	STAY/FENDER	60 8
SCREW, SP/M6X20	58 4		20 12	STAY/GUARD/CONTAINER	42 17
SCREW/M03X20	66 44	SHIM/0.3	5 8		43 17
SCREW/M5X12	66 4		6 8	STAY/LAMP/FRONT COMP	63 1
SCREW/M6X20	63 31	SHIM/0.6/B	5 7		64 1
SCREW/SOCKET	15 2		6 7	STAY/PLUG	3 14
SCREW/SOCKET/M8X16	82 41	SHOE/BRAKE	84 5		4 14
SCREW/TAPPING	65 10	SHROUD COMP	3 2	STAY/ROCK	39 10
SCREW/TAPPING/3.5X13	65 27		4 2	STAY/SWITCH/HST COMP	66 31
SCREW/TRUSS/M06X16	65 24	SLEEVE ASSY	48 14	STOPPER/B	63 30
SCREW/TRUSS/M08X20	59 3	SNAPRING	87 8	STUD/M10X20/7T	33 22
SEAL(62)	20 15	SNAPRING/85	87 13		42 5
SEAL, OIL	27 17	SPOOL	82 35		43 5
	28 17	SPRING	3 28	STUD/M12X32/7T	42 4
SEAL, OIL/TC20357	48 17		4 28		43 4
SEAL, OIL/TC20408	33 17		36 3	SWITCH/BEACON ASSY	65 13
SEAL, OIL/TC20428	18 3		84 6	SWITCH/COMBINATION	65 26
SEAL, OIL/TC25458	48 6		85 10	SWITCH/HAZARD ASSY	65 14
SEAL, OIL/TC30458	33 4		87 4	SWITCH/LEVER ASSY	66 28
	33 8	SPRING, DISK	13 5		66 32
SEAL/OIL	26 16	SPRING, TENSION	34 6		66 38
	33 18	SPRING, VALVE	83 1		66 46
	49 7	SPRING/A	84 9	SWITCH/LIMIT ASSY	66 43
SEAL/OIL ASSY	49 33	SPRING/HC021	82 14	SWITCH/MAIN ASSY	65 15
	49 50	SPRING/HC023	82 37	SWITCH/PTO ASSY	65 11
SEAL/RING/45X03	87 14	SPRING/HC030	82 13		65 12
SEAT ASSY	61 1	SPRING/HC045	55 28	SWITCH/PUSH ASSY	66 23
SENSOR/STRAW/L/165	66 36	SPRING/HC058	72 11		66 25

Alphabetical Index

1832-097-100-00

Description	Fig.	Key	Description	Fig.	Key	Description	Fig.	Key
TANK/FUEL	10	1	WASHER	86	4	WASHER, PL/M8	35	39
TIRE/23X10.5-12 ASSY	37	1		87	9		36	8
TIRE/F/18X8.50- ASSY	51	1	WASHER, PL/M10	13	6		36	17
TIRE/TURF/18X8.50-8	51	2		37	4		47	9
TOOL/FUSE	67	10		47	4		47	12
TRAY/BOTTLE	70	5		48	10		52	19
TRIM/140	69	4		52	5		52	30
TRIM/188	3	29		52	44		52	41
	4	29	WASHER, PL/M12	1	7		55	41
TRIM/198	3	40		2	7		86	5
	4	40		63	25	WASHER, PULLEY	72	18
TRIM/230	44	3		64	24		79	5
	44	10		80	4	WASHER, SP/M10	5	4
	45	3	WASHER, PL/M14	51	4		6	4
	45	10	WASHER, PL/M16	49	63		37	5
TRIM/70	63	24		57	9		42	14
	64	23		71	4		43	14
TUBE/07X09X30	3	21	WASHER, PL/M22	23	4		48	11
	4	21		31	21		50	8
TUBE/540 COMP	26	23		35	4	WASHER, SP/M12	1	6
TURNBUCKLE/M8	35	35		35	16		2	6
TYRE/TURF/23-12	37	2		35	22		30	5
UNIT/TIMER ASSY	66	13	WASHER, PL/M5	52	8		30	31
U-NUT	3	24	WASHER, PL/M6	13	9		42	11
	4	24		23	2		43	11
	46	9		31	5		79	4
	72	10		31	19		79	8
UNUT (M8)	63	9		35	2		80	3
	63	14		35	14	WASHER, SP/M14	51	5
	64	9		35	25	WASHER, SP/M16	57	10
	64	14		47	13		70	3
U-NUT/M10X1.5	63	3		52	13		70	10
	64	3		52	24	WASHER, SP/M8	9	3
VALVE	7	5		52	35		17	4
	8	5		72	9		21	4
VALVE/1S-2D ASSY	55	1	WASHER, PL/M8	9	4		30	23
VALVE/282 ASSY	55	17		14	2		32	8
VALVE/CHECK ASSY	56	17		23	7		54	12
VALVE/PRV/B ASSY	55	21		30	35		55	40
VALVE/REDUCE/21 SET	55	18		31	8		86	6
VALVE/RELIEF/00 SET	82	34		31	13	WASHER, SUPPORT	30	30
VIS	83	3		31	24	WASHER/05X20X01	70	6
WASHER	65	6		31	29	WASHER/17X22X03	34	2
	84	1		35	11	WASHER/18X26X02	30	13
	85	11		35	19		30	27

Alphabetical Index

1832-097-100-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
WASHER/24X9X3.2	3 25				
	4 25				
WASHER/25X42X02	49 3				
WASHER/27X36X03	49 49				
WASHER/27X79X02	72 15				
WASHER/30X46X03	20 4				
WASHER/31X42X1	33 20				
WASHER/38X12X2	30 3				
WASHER/50X62X02	20 13				
WASHER/9X32X2	60 3				
WASHER/A	84 3				
WASHER/RUBBER	86 2				
WEIGHT/15 SET	81 1				
WEIGHT/40	79 2				
WEIGHT/REAR SET	79 1				
WHEEL/12XW7 COMP	37 3				
WHEEL/8X7 COMP	51 3				
WHEEL/STEERING ASSY	38 1				
WIRE, LEAD	1 8				
	2 8				