



Spare Parts Catalogue

LX14-45-TRIPLEX+D.C.S.

Handling systems | Stackers


Valid for machine code: HDB14000100

Revision: 0 (10/2006)

<https://truckmanualshub.com/>

Copyright 2017 Pramac Group, All Rights Reserved.

IMPORTANT NOTICE: Before using this information please check if updated releases have been published on Pramac Service & Parts Online Center - <http://www.pramacparts.com>




Position	Part Number	Description	Notes
101	V0301190007-PRAMAC	Telaio Lx 14/45 Vern.verde Pramac	-
102	S0307190033	Fork Lx 14/45 Painted	-
103	G019304	Adjustable Nylon Pad For G019104	-
104	G019305	Adjustable Pad Disc For G019104	-
105	G019301	Cyl. Roller Bearing D77.7 Xg019104	-
106	S0302015025	Glevis Pin Tx/gx/lx "burnished"	-
107	S0302020117	Polyurethane Roller D82x70 + Bearing	-
109	S0302015026	Tandem Pin Te/tm/l10 (burnished)	-
110	S0302010006	Complete Roller Tandem Polyurethane L16 - L/vt	-
111	G040010	Lever Hinge Zinc Plated White	-
112	V09349-PRAMAC	Battery Compartment Side Panel Lx12-16	-
113	S0300177021	Right Side Protection Lx 12-16 Painted	-
114	S0300177020	Left Side Protection Lx 12-16 Painted	-
115	G034903	Cage Nut M8 Zn	-
116	G018001	Complete Castor Wheel Lx + Protection	-
117	G053345	Polyurethane/cast Iron Wheel Z125x50/50(s501183)	-
118	G053335	Polyurethane/cast Iron Wheel Z125x50/50 C/c Bomb.	-
119	G09353	Second Speed Microswitch Support Lx12-16	-
120	G075006	Limit Switch With Roller Pizzato MkV11d15	-
121	S0300179013	Motor Wheel Protection Lx 12-16 Painted	-
122	G071099	Connector 160a	-
123	G071203	Handle Ab 995 G3 (anderson)	-
124	G052002	Rubber Bellows (for Stackers)(0-rab/010)	-
125	S0300178046	Hood Lx	-
126	V09348-PRAMAC	Closing Carter Cofano Lx12-16 Green Pramac	-
127	G076000	Controller 1243-4224 (24v-200a) '08	-
128	G075110	Horn 24v Dc	-
129	G079019	Contacto Albright Sw80-65 24v Co	-
130	G070625	Fuse Holder Screw Cap + Fuse 6.3a	-
131	G077540	Fuse 160a (rfm Reghel)	-
132	G070603	Fuse Holder X Fuse 160amp	-
134	S0300178047	Battery Hood Lx	-
135	G040401	Quarter Turn Lock Complete	-
136	S0300178050	Plexiglass Guard H=2900 Lx	-
137	G035001	Blind Nut Nylon Black M8	-
138	S0300199017	Cylinder U-bolt Lx14/45 Painted	-
139	S0300187336	Cylinder Screw Protection Lx16 Painted	-

<https://truckmanualshub.com/>


Position	Part Number	Description	Notes
140	▲ P0CD00020	Kit Wiring '05 Fx - Lx	Valid for products manu
	▲ S0309170253	Electric Wiring Lx	Valid for products manu
	▲ P0CD00006	Kit Cavi Completo Lx12/16 Timone 03	Valid for products manu

<https://truckmanualshub.com/>




Position	Part Number	Description	Notes
201	V0305190027-9005	Second Stage Lx 14/45 Painted	-
202	G010407	Bearing 6007 2rs (35-62-14)	-
203	S0305194041	Pulley Lx14/45 Burnished	-
204	S0300185013	Chain Holder Lx 12-14-16 Zinc Plated	-
205	S0300155003	Chain Holder Stacker 12q Single Chain	-
206	G062102	Flayer Chain Pin BI546 D6x33	-
207	G019301	Cyl. Roller Bearing D77.7 Xg019104	-
208	G019305	Adjustable Pad Disc For G019104	-
209	G019304	Adjustable Nylon Pad For G019104	-
210	G062104	Flayer Chain Pin BI544 D6x29	-
211	G062028	Flayer Chain Stub BI544-119p	-
212	G010403	Bearing 6005 2rs (25-47-12)	-
213	S0300176057	Pulley Machined Lx12-16/29-35 Burnished	-
214	G087007	Male Cap 3/8 Tme30/8 Gas	-
215	G085005	Valvola Vuba 3/8" Foro 0.8 Cilindro Lx Vuba0600f08	-
216	S0306194042	Piston Lx14/45	-
217	S0306176061	Cylinder Spacer L.241 Lx12/25-29-35	-
218	S0306194043	Cylinder Nut Ring Lx14/45	-
219	S0306195063	Piston Rod Lx14/45	-
220	S0306190020	Complete Cylinder Lx14/45 Painted	-
221	GP90033	Seal Kit Cylinder Lx14/45	-
222	G062029	Flayer Chain Stub BI534-113p	-
223	V0305190024-9005	Third Stage Lx14/45 Painted	-

<https://truckmanualshub.com/>



Position	Part Number	Description	Notes
701	G084001	Screw Perforate (4 Holes) 3/8" L 29-0,5/0 Ch22	-
702	G083013	Tube R1at 3/8"	-
703	G083002	Tubo En853 2sn 3/8" L=880 Occhio 3/8" - Occhio 3/8" - H Occhio 17,5+/-0,2 Foro 3/8	-
704	G083012	Tube R1at 3/8"	-
705	G084112	Adapter Male 1/4 Female 3/8	-
706	S0300177019	Distributor Connection Lx 12-16 Painted	-
707	G084002	Screw Perforate Double (8 Holes) 3/8" L 49 -0,5/0 Ch22	-
708	G081022	Hydraulic Unit 224253001 Up100 (lx12 - Lx16)	Valid for products with s
	G081034	Hydraulic Unit 24v 3kw Iskra 4.3cc Tank 12l. X Lx 14/45 Free Lift	Valid for products with s
	G081026	Centr. Hidroirma 24 V 3 Kw 4.3 Cc	Valid for products with s
	G081033	Hydraulic Unit 24v 3kw Iskra 4.3cc Tank 8l. X Lx 14/45	Valid for products with s
709	G085004	Lever Stick A001 Hdm10 M08x125	-
710	G075004	Microswitch For Tow Bar L10	-
711	G085008	Distributor Hdm140K02 151/mod.1/429z3+valvola	-
712	G087007	Male Cap 3/8 Tme30/8 Gas	-
713	G096109	Rubber-metal Washer Rgm 3/8"	-

<https://truckmanualshub.com/>




Position	Part Number	Description	Notes
300	G082240	Cap Tp Sf. 1/2" (200527060502)	-
301	G082239	Tank Up100 P08 (200973450160)	-
302	G082227	Tank Clamping Set Pl. Up100 6-14l.	-
303	G082241	Suction Set (200759900940)	-
304	G082090	Filter Conv.150 Micron (757500070)	-
305	G082168	Pump Ap100/3,5 S.409+cop.748240010	Valid for products with s
	PC1748250015	Pompa Centr. Lx14/45/al	Valid for products with s
306	G082165	Body Gasket Set Up100	-
307	G082190	Valve Cap T817/0(hidr.778800040)	-
308	G082237	Cap Toei 1/4 (200527360201)	-
309	G082235	Body Up100k35+oil Seal (200740420141)	-
310	G082242	Joint Complete (200659600290)	-
311	G082182	New Code Plh000004	Valid for products with s
	PC1543924602	Motore Completo Centralina Lx14/45 A.I. Lx14/45 Triplex	Valid for products with s
312	G082147	New Code Plh000004	Valid for products with s
	G082162	Brushes Engine Kit Hydraulic 20054413	Valid for products with s
313	G082127	Complete Relay 24v C.c. P.c-e-f-g (ef.)	Valid for products with s
	PC1544134210	Contacto 24v. For Lx14/45 A.I.	Valid for products with s
996	G081022	Hydraulic Unit 224253001 Up100 (lx12 - Lx16)	Valid for products with s
	G081026	Centr. Hidroirna 24 V 3 Kw 4.3 Cc	Valid for products with s
997	G082239	Tank Up100 P08 (200973450160)	-

<https://truckmanualshub.com/>




Position	Part Number	Description	Notes
300	G082240	Cap Tp Sf. 1/2" (200527060502)	-
301	G082239	Tank Up100 P08 (200973450160)	-
302	G082227	Tank Clamping Set Pl. Up100 6-14l.	-
303	G082241	Suction Set (200759900940)	-
304	G082090	Filter Conv.150 Micron (757500070)	-
305	PC1748250010	Pompa Centralina LX14/45 A.I. LX14/45 Triplex	-
306	G082165	Body Gasket Set Up100	-
307	G082190	Valve Cap T817/0(hidr.778800040)	-
308	G082237	Cap Toei 1/4 (200527360201)	-
309	G082235	Body Up100k35-oil Seal (200740420141)	-
310	G082242	Joint Complete (200659600290)	-
311	PC1543924602	Motore Completo Centralina LX14/45 A.I. LX14/45 Triplex	-
312	PC116770229	Brushes LX14/45 A.I. LX14/45 Triplex	-
313	PC1544134212	Contactore Power Station Hydraulic LX14/45 A.I. LX14/45 Triplex	-
314	G081033	Hydraulic Unit 24v 3kw Iskra 4.3cc Tank 8l. X Lx 14/45	-

<https://truckmanualshub.com/>




Position	Part Number	Description	Notes
300	G082240	Cap Tp Sf. 1/2" (200527060502)	-
301	PCI773450160	Serbatoio In Lamiera Lx14/45 A.I. Codice Bucher 20072490620	-
302	PCI771900220	Kit Fissaggio Serbatoio Centr. 14/45 Al	-
303	PCI759900890	Tubo Aspirazione Centr. Lx14/45al	-
304	G082090	Filter Conv.150 Micron (757500070)	-
305	PCI748250010	Pompa Centralina Lx14/45 A.I. Lx14/45 Triplex	-
306	G082165	Body Gasket Set Up100	-
307	G082190	Valve Cap T817/0(hidr.778800040)	-
308	G082237	Cap Toei 1/4 (200527360201)	-
309	G082235	Body Up100k35+oil Seal (200740420141)	-
310	G082242	Joint Complete (200659600290)	-
311	PCI543924602	Motore Completo Centralina Lx14/45 A.I. Lx14/45 Triplex	-
312	PCI16770229	Brushes Lx14/45 A.I. Lx14/45 Triplex	-
313	PCI544134212	Contactore Power Station Hydraulic Lx14/45 A.I. Lx14/45 Triplex	-
314	G081034	Hydraulic Unit 24v 3kw Iskra 4.3cc Tank 12l. X Lx 14/45 Free Lift	-



Position	Part Number	Description	Notes
501	S0304178033	Handle Emergency '00	-
502	S0304178032	Handle Horn Rocker Switch '00	-
503	S0304178031	Handle Butterfly '00	-
504	S0304178035	Handle Cover '00 X Lx	-
505	G079005	Battery Level Gauge Curtis	-
506	G079018	Hour Meter Curtis	-
507	G078058	Key Block Rch (rch Reghel)	-
508	G077002	Electronic Throttle Et160	-
509	S0304178034	Handle Potentiometer Support '00	-
510	G075017	Microswitch Xg52-j21	-
511	G075016	Microswitch 5a 250v	-
512	G07330	Handle Emergency Support Plate '00	-
513	S0304178044	Coated Handle '00 (poly)	-
514	G001132	Spring De11 Wire 1 - 4 Turns L10 Mol/zn	-
515	G001134	Spring De12,3 F1 - 9 Turns - L=24 Zinc Plated	-
516	G001131	Spring De5,6 F0,5 - 10 Turns L20 Zinc Plated	-
517	S0304190101	Handle '00 Complete Stacker Lx	-
518	S0319012001	Cable Tiller L/g (curtis)	-


<https://truckmanualshub.com/>



<https://truckmanualshub.com/>

Position	Part Number	Description	Notes
601	G073242	Screw Wheel	-
602	G073301	Rubber Ring For Motorwheel L16 New /lx16/lx14-45/lx14-45 A.I.	-
	G073311	Motor Wheel Adiprene Ring L16 New	-
	G073329	Motor Wheel Ecologic Rubber Ring L16 New	-
603	G073006	Motor Wheel Ring	-
604	G073302	Protection Ring	-
605	G073303	New Code G073302	-
606	G073009	Bearing	-
607	G073304	Return Pinion + Ring Gear 8 Holes	-
608	G073305	O-ring For Crown Wheel	-
609	G073306	Motor Wheel Gasket	-
610	G073307	Motor Wheel Casting	-
611	G073011	Motor Wheel Gasket	-
612	G073247	Bearing	-
613	G073026	Bearing 16006	-
614	G073029	Pinion + Driver Wheel	-
615	G073030	Compensation Ring	-
619	G073089	Brake Holder Plate	-
622	G073308	Brake Lining + Hub	-
623	G073091	Electric Brake 24v D100 B3139/15p 5 Hole 11mm.	-
625	G073013	Gasket	-
626	G073014	Cover	-
629	G073067	Tension Rod+tube	-
632	G073032	Paddled Clamp	-
633	G073019	Slip Support	-
634	G073068	Brushes Kit Motor 24v	-
635	G073249	Slip Bearing 6201 2src3	-
648	G073339	Complete Motor Lx16	-


<https://truckmanualshub.com/>



<https://truckmanualshub.com/>

Position	Part Number	Description	Notes
401	S0303010153	Motor Wheel Wiring Bracket L10-H16	-
402	S0303180337	Motor Wheel Support Lx 16 Painted	-
403	G010214	Bearing 6010 2rs(50-80-16)	-
404	G042280	Inner Seeger 7436 I 80	-
405	S0303016030	Motor Wheel Shaft Washer L10	-
406	S0313080057	Complete Motor Bearing Stackler	-
407	G001141	Spring De78 F.11x185 P.22 X L10-H16-l/vt	-
408	S0303010139	Spring Loader Lx-gx Zinc Plated	-
409	G042150	Outer Seeger 7435 E 50	-
410	V000044101-90050	Supporto Timone Gx-lx '03 Vern	-
411	S000044034	Protection Plate Tiller Microswitch Gx-lx Dark Zinc Coated	-
412	G075004	Microswitch For Tow Bar L10	-
413	S000025501	Tiller Pin Gx-lx '03 Burnished	-
414	G016307	Boccola Flangiata Du 18-20	-
415	S000025503	Tiller Spacer Gx-lx '03	-
416	G001728	Gas Spring Gx Ama R20 Z10 Lta 255 Mm 170 N	-
417	S000025502	Burnished Tiller Screw-nut Spacer Gx-lx '03	-
418	V000044102-90050	Tiller Bracket Gx-lx '03 Painted	-
419	V09415-9005	Tiller Box Gx-lx '03 Painted	-
420	S000025901	Coperchio Timone Gx-lx '03	-


<https://truckmanualshub.com/>



<https://truckmanualshub.com/>

Position	Part Number	Description	Notes
401	G074428	Motor Wheel Separated Excitation 1.2kw Lx16	-
402	S0303180337	Motor Wheel Support Lx 16 Painted	-
403	G010214	Bearing 6010 2rs(50-80-16)	-
404	▲ S0303018002	Motor Wheel Sliding Bushing L10	Valid for products with s
405	G042280	Inner Seeger 7436 I 80	-
406	S0303016030	Motor Wheel Shaft Washer L10	-
408	S0313080057	Complete Motor Bearing Stackler	-
409	G001141	Spring De78 F.11x185 P.22 X L10-H16-l/vt	-
411	P0KI00006	Tiller Kit L/k20	-
412	S0304013027	Handle Pin Gx-lx-k20 "burnished"	-
413	G016353	Self-lubricating Bushing 20x28x35 L=20	-
414	G001728	Gas Spring Gx Ama R20 Z10 Lta 255 Mm 170 N	-
415	S0304010142	Handle Support Painted "I" - "k20"	-
418	S0303010139	Spring Loader Lx-gx Zinc Plated	-
419	S0303010153	Motor Wheel Wiring Bracket L10-H16	-
420	G075004	Microswitch For Tow Bar L10	-
421	G042150	Outer Seeger 7435 E 50	-

<https://truckmanualshub.com/>



<https://truckmanualshub.com/>

Position	Part Number	Description	Notes
901	G085023	Distributor Hds11/hds07 Double Command Lift Fx-lx	-
902	G096109	Rubber-metal Washer Rgm 3/8"	-
903	G084001	Screw Perforate (4 Holes) 3/8" L 29-0,5/0 Ch22	-
904	G082000	Pole Lever Distributor And Double Command Lift Fx - Lx	-
905	V09451-9005	Plate Distributor Double Command Lift Fx-lx Paint. * Black	-
906	S000060201	Connector Hidraulics Tubes Double Command Lift Fx-lx	-
907	G084002	Screw Perforate Double (8 Holes) 3/8" L 49 -0,5/0 Ch22	-
908	G083013	Tube R1at 3/8"	-
909	G075104	Unipolar Button 16(6)a/250v Lift/lowering "timoniera '00"	-
910	G075119	Green Cap For Single Pole Pushbutton Switch 16a	-
	G075120	Black Cap For Single Pole Pushbutton Switch 16a	-
911	G075118	Rubber Protection Cap	-
912	G075168	Bipolar Button 16(6)a/250v Lift Timoniera '00 Double Command Lift Fx-lx	-
913	S0114288025	Handle Cover Cx14 Plus	-
914	S000060011	Complete Wheelhouse Double Command Lift Fx-lx	-
916	S000060013	Wiring Rudder Double Command Lift Fx-lx	-
917	PC100002	Elettrovalvola Discesa Fx/lx D.c.s.	-
918	PC100003	Valvola Salita Fx/lx D.c.s.	-

<https://truckmanualshub.com/>