

Chapter VI Appendix

1. Wiring diagram of the electrical system




Fig.6-1 Wiring diagram of the electrical system

- 1.Battery 6-Q(A)-80 2.Electrical horn DL38-12 3.Front head lamp 4.Double plug socket 5.Silicon rectifying alternator 6.Starter 7.Fuse box BX 505 8.One-position switch 9.Turning signal light 10.One plug socket 11.Rear work light 12.Ammeter 307A 13.Starting switch JK424/JK290 14.Horn relay 15.Horn button 16.Two-position switch 17.Direction indicating light switch 18.Oil pressure gauge 19.Regulator 20.Thermal flasher 21.Counting timer 22.Water temperature gauge 23.Fuel gauge 24.Oil pressure plug 25.Water temperature gauge 26.Fuel sensor 27.Preheater 28.Switch 29.Brake switch

2. Accessories for customers to order

Customers may order and purchase the following accessories of the tractors from our factory according to requirements: