

부품 매뉴얼 PARTS MANUAL


C20/25/30/32 CL

TRUCK MODEL : C20-32 CL

SERIAL NUMBER : C232L - XXXX - 9855 CNF (HMC,Tier4)

부품 청구시 항상 장비의 SERIAL NO. 도
함께 알려 주십시오.

ALWAYS GIVE TRUCK SERIAL NUMBER
WHEN ORDERING PARTS.



Publication Date : Jan. 2013



(본사) 경기도 부천시 오정구 오정동 202-1
(Head office) 202-1 Ojung-Dong, Ojung-Gu, Bucheon-city, Kyunggi-do, Korea
(공장) 경남 창원시 웅남동 40-1
(Factory) 40-1 Ungnam-dong, Changwon-city, Kyungnam, Korea




00-687	ENGINE MOUNTING 엔진 어셈블리	12-257	ALTERNATOR 알터네이터
00-688	ENGINE GASKET KIT 엔진 가스킷 키트	13-033	KEY & DIRECTIONAL SWITCH INSTALLATION 키 & 다이렉트스위치 조립그룹
00-690	CYLINDER HEAD & COVERS 실린더 헤드 & 커버	13-034	HEAD LAMP INSTALLATION 헤드램프 조립그룹
00-691	CRANKCASE 크랭크케이스	13-128	LAMP INSTALLATION 램프 조립그룹
01-340	COOLING SYSTEM 냉각 장치	13-150	LED LIGHTS INSTALLATION LED 라이트 조립그룹
01-349	WATER COOLING SYSTEM 쿨링 워터 시스템	13-162	STROBE LIGHT MOUNTING 경광등 어셈블리
02-154	NON PRE-CLEANER GP 논-프리크리너 그룹	13-182	STROBE LIGHT 경광등
02-156	ACCELERATOR SYSTEM 악셀레이터 장치	13-183	STROBE LIGHT MOUNTING 경광등 어셈블리
02-194	ACCELERATOR LINKAGE 악셀레이터 링케이지	13-228	BACK-UP ALARM INSTALLATION 백-업 알람 조립그룹
02-474	AIR CLEANER ASSEMBLY 에어 크리너 어셈블리	13-230	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드 & 턴시그널라이트 조립그룹
02-478	INDICATOR LIGHT INSTALLATION 지시등 조립그룹	13-327	REAR ACCESSORY MOUNTING 리어 액세서리 마운팅
03-268	FUEL SYSTEM 연료 시스템	13-332	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드 & 턴시그널라이트 조립그룹
03-349	LPG TANK MOUNTING LPG 탱크 마운팅	13-338	HEAD & T/SIGNAL LIGHT INSTALLATION 헤드 & 턴시그널라이트 조립그룹
03-559	SWING DOWN BRACKET ASSEMBLY *	13-344	KEY & DIRECTIONAL SWITCH INSTALLATION 키 & 다이렉트스위치 조립그룹
03-581	SWITCH INSTALLATION 스위치 조립그룹	14-133	ELECTRICAL WIRING (INSTRUMENT) *
03-599	INTAKE & EXHAUST MANIFOLD 흡기 & 배기 매니폴드	14-247	ELECTRICAL WIRING (MAIN) *
03-605	FUEL LINE 연료 라인	14-438	STATIC STRAP 스태틱 스트랩
03-606	FUEL SYSTEM 연료 시스템	14-579	LPS CONSTRUCTION LPS 구성품
03-607	EXHAUST SYSTEM 배기 장치	20-086	DRIVE AXLE 드라이브 액슬
03-640	SWING DOWN LPG TANK MTG 스윙 다운 LPG 탱크 조립그룹	22-011	BRAKE ASSEMBLY 브레이크 어셈블리
03-683	INTAKE & EXHAUST MANIFOLD 흡기 & 배기 매니폴드	22-013	DRIVE WHEEL & TIRE MOUNTING 드라이브휠 & 타이어 마운팅
03-684	FUEL LINES 연료 라인	22-035	DRIVE WHEEL & TIRE (CUSHION TYPE) *
03-698	INTAKE SYSTEM 흡기 시스템 (듀얼)	22-036	STEER WHEEL & TIRE (CUSHION TYPE) *
05-035	TRANSMISSION PUMP & HYDRAULICS 트랜스미션 펌프 & 유압	22-037	STEER WHEEL & TIRE MOUNTING 스티어링휠 & 타이어 마운팅
05-036	CONVERTOR HOUSING AND PUMP DRIVE 컨버터 하우징 & 펌프 드라이브	23-411	BRAKE & INCHING LINES 브레이크 및 인칭라인
05-165	CONVERTER HOUSING & CLUTCH ASSY 컨버터 하우징 & 클러치	23-460	BRAKE LINES 브레이크 라인
06-143	SPEED LIMIT INSTALLATION 속도 제한장치 조립그룹	23-545	PARKING BRAKE LINKAGE 주차 브레이크 링케이지
06-144	TRANSAXLE ASSEMBLY 트랜스엑슬 어셈블리	25-050	STEER COLUMN & GEAR MOUNTING *
06-619	TRANSMISSION CASE AND DIFFERENTIAL ASSEMBLY 트랜스미션 케이스 & 차동장치 어셈블리	25-076	STEERING UNIT 스티어링 유니트
06-750	E TRANSMISSION CLUTCH PACK 트랜스미션 클러치 팩	25-144	STEERING COLUMN 스티어링 칼럼
06-801	CONTROL COVER 컨트롤 커버	25-250	STEERING WHEEL MOUNTING *
07-075	TRANSAXLE MOUNTING 트랜스엑슬 마운팅	25-267	STEERING GEAR MOUNTING 스티어링 기어 어셈블리
10-131	TRANSMISSION COOLING LINES 트랜스미션 쿨링 라인	26-209	STEER AXLE ASSEMBLY 스티어링 액슬 어셈블리
11-110	ELECTRICAL CONTROL 전기장치 컨트롤	26-225	HYDRAULIC RETURN LINES 유압 라인 - 리턴
12-193	ALTERNATOR ASSEMBLY 알터네이터 어셈블리	26-266	STEER CYLINDER 스티어링 실린더
12-213	BATTERY MOUNTING 배터리 어셈블리	26-306	STEER LINES 스티어링 라인



26-307	STEER AXLE MOUNTING 스티어링 액슬 마운팅	39-235	ELECTRICAL COMPONENTS (CAB) *
29-192	HYDRAULIC PUMP 유압 펌프	39-512	FLOOR PLATE MOUNTING 플로어 플레이트 마운팅
29-237	HYDRAULIC TANK & COMPONENTS MOUNTING 유압탱크 & 구성품 마운팅	39-519	LOAD BACK REST 로드 백 레스트
30-209	HYDRAULIC VALVE MOUNTING (2SPOOL) 유압밸브 마운팅 (2스풀)	39-559	NOISE REDUCTION INSTALLATION 소음저감 조립그룹
30-210	HYDRAULIC VALVE MOUNTING (3SPOOL) 유압밸브 마운팅 (3스풀)	39-593	ELECTRICAL COMPONENTS (CAB) *
30-211	HYDRAULIC VALVE MOUNTING (4SPOOL) 유압밸브 마운팅 (4스풀)	39-626	ENCLOSED CAB 캡 (박스형)
30-510	MAIN CONTROL VALVE 3-SPOOL(PUSH BUTTON) 메인 컨트롤 밸브 - 3 스푼 (푸시버튼)	39-661	SEAT ASSEMBLY 시트 어셈블리
30-511	MAIN CONTROL VALVE 4-SPOOL(PUSH BUTTON) 메인 컨트롤 밸브 - 4 스푼 (푸시버튼)	39-674	FLOOR PLATE MOUNTING 플로어 플레이트 마운팅
30-512	HYDRAULIC CONTROL VALVE-2 SPOOL 유압 컨트롤 밸브 - 2 스푼	39-829	SEAT MOUNTING 시트 어셈블리
30-513	HYDRAULIC CONTROL VALVE-3 SPOOL 유압 컨트롤 밸브 - 3 스푼	39-834	SEAT ASSEMBLY (SUSPENSION) 시트 어셈블리
30-514	HYDRAULIC CONTROL VALVE-4 SPOOL 유압 컨트롤 밸브 - 4 스푼	39-963	COWL MOUNTING 카울 마운팅
31-139	HYDRAULIC LIFT & TILT LINES 유압 리프트 & 틸트 라인	39-969	POD INSTALLATION 파드 조립그룹
31-307	HYDRAULIC SUPPLY LINES 유압 공급 라인	39-976	CAB MOUNTING 캐빈 마운팅
32-129	TILT CYLINDER 틸트 실린더	39-977	OVERHEAD GUARD MOUNTING 오버헤드가드 마운팅
32-155	TILT CYLINDER MOUNTING 틸트 실린더 어셈블리	40-243	MODEL & SPECIFICATION DECALS *
32-167	TILT AMOUNT GROUP 틸트 어마운트 그룹	40-254	DECALS 데칼
32-169	TILT AMOUNT GROUP 틸트 어마운트 그룹	40-260	TRUCK FLUIDS 트럭 유체
32-171	ACCUMULATOR INSTALLATION *	41-008	STORAGE CONSOLE 저장 콘솔
33-069	RELIEF VALVE ASSEMBLY 릴리프 밸브 어셈블리	41-038	HEATER INSTALLATION 히터 조립그룹
33-130	SELECTOR SOLENOID VALVE 셀렉터 솔레노이드 밸브	47-000	SEAT WING KIT 시트윙 키트
34-044	LOAD BACK REST 로드 백 레스트	47-005	REAR HAND GRIP MOUNTING *
34-103	CARRIAGE ASSEMBLY 캐리지 어셈블리	50-109	E DEVICE HOSE REEL 디바이스 호스릴
34-209	CARRIAGE ASSEMBLY 캐리지 어셈블리	50-157	SOLENOID VALVE 솔레노이드 밸브
34-734	UPRIGHT MOUNTING 업라이트 마운팅	50-171	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 작업장치 호스 적응 (캐리지)
37-003	OVERHEAD GUARD COVER 오버헤드가드 커버	50-172	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION *
37-050	REAR WIPER INSTALLATION 리어 와이퍼 조립그룹	50-175	HIGH TERMINATION FOR DEVICE HOSE ADAPTATION *
37-054	CAB DOOR SASH ASSEMBLY *	50-232	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 작업장치 호스 적응 (업라이트)
37-056	ENCLOSED CAB 캡 (박스형)	50-243	QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION 퀵 차단 (호스 어댑션 장치용)
37-076	BACK MIRROR 백미러	50-269	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 작업장치 호스 적응 (업라이트)
37-083	OVERHEAD GUARD MOUNTING 오버헤드가드 마운팅	50-270	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) *
37-114	HOOD MOUNTING 후드 마운팅	50-284	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 작업장치 호스 적응 (캐리지)
37-117	SHEET METAL & TRIM 시트 메탈 & 트림	50-289	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) *
37-124	SEAT ARMREST ASSEMBLY 아암레스트 어셈블리	50-290	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) *
38-225	FRAME & COUNTERWEIGHT 프레임 & 카운터웨이트	50-291	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) *
38-270	FRAME TANK BOTTOM PLUG 프레임 탱크 하단 플러그	50-292	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) *
39-012	LEAD WIRE GROUND 접지선	50-293	ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) *



50-407	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 작업장치 호스 적용 (업라이트)
50-410	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 작업장치 호스 적용 (업라이트)
50-432	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 작업장치 호스 적용 (업라이트)
50-439	ATTACHMENT HOSE ADAPTATION (UPRIGHT) 작업장치 호스 적용 (업라이트)
50-590	AUXILIARY VALVE LINES 보조 밸브 라인
50-716	E HOSE ADAPTATION 호스 어댑션
50-765	HIGH TERMINATION PLUMBING 하이 터미네이션 배관
50-791	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 작업장치 호스 적용 (캐리지)
50-793	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 작업장치 호스 적용 (캐리지)
50-794	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 작업장치 호스 적용 (캐리지)
50-796	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 작업장치 호스 적용 (캐리지)
50-797	ATTACHMENT HOSE ADAPTATION (CARRIAGE) 작업장치 호스 적용 (캐리지)
50-798	QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION 퀵 차단 (호스 어댑션 장치용)
50-820	SOLENOID VALVE FOR DEVICE HOSE ADAPTATION *
53-187	SIDE SHIFT ASSEMBLY *
53-198	SIDESHIFT CYLINDER 사이드 쉬프트 실린더
54-015	FORK POSITIONER (BASIC) 포크 포지셔너 (기본)
66-058	FORK 포크
66-159	LIFT CYLINDER ASSEMBLY 리프트 실린더 어셈블리
66-160	SECONDARY CYLINDER ASSEMBLY 2차 실린더 어셈블리
66-179	STANDARD UPRIGHT 표준 업라이트
66-232	TRIPLE STAGE UPRIGHT 3단 업라이트
66-235	PRIMARY CYLINDER ASSEMBLY *
66-999	EXTENTION FORK 익스텐션 포크
75-(17)000	UNITROL PEDAL MOUNTING 유니트롤 페달 마운팅
75-(17)005	UNITROL PEDAL MOUNTING 유니트롤 페달 마운팅
75-(33)014	VARIABLE RELIEF VALVE INSTALLATION 가변 릴리프 밸브 어셈블리
75-(33)045	DEVICE HYDRAULIC PRESSURE GAUGE INSTALLATION 디바이스 유압 압력게이지 조립그림
75-001	SEAT OPERATED BRAKE SWITCH 시트 조작 브레이크 스위치
75-004	SEAT OPERATED BRAKE 시트 조작 브레이크
75-005	SEAT OPERATED BRAKE 시트 조작 브레이크
75-012	SEAT OPERATED BRAKE SWITCH 시트 조작 브레이크 스위치



00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.047	DAMPENER, ENGINE FRONT VIBRATION 댐퍼너
00.055	FASTENER, ENGINE FRONT VIBRATION DAMPENER 패스너
00.056	MOUNT, ENGINE RH 마운트
00.071	MOUNT, ENGINE LH 마운트
00.352	ADAPTOR, FLYWHEEL MOUNTING 어댑터
00.871	FASTENER, FLYWHEEL HOUSING 패스너
01.195	BELT, FAN 벨트
40.331	DECAL, CLARK LOGO (ENGINE) *




ENGINE MOUNTING

94.705	FASTENER, ENGINE MOUNTING BRACKET 패스너
95.471	FASTENER, ENGINE MOUNT 패스너
95.472	FASTENER, ENGINE MOUNT 패스너



ENGINE GASKET KIT




00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓킷
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓
00.427	SEAL, CRANKCASE REAR OIL 시일
00.547	SEAL, ENGINE FRONT GEAR COVER 시일
00.604	GASKET, CRANKCASE HEAD 가스켓
00.664	GASKET, ROCKER ARM COVER 가스켓
00.703	SEAT, INTAKE VALVE SPRING 시트
00.705	SEAT, EXHAUST VALVE SPRING 시트



01.018	SEAL, OIL LEVEL DIPSTICK ADAPTOR 시일
01.100	GASKET, CRANKCASE OIL PAN DRAIN PLUG 가스켓
01.286	GASKET, OIL FILLER CAP 가스켓
01.322	GASKET, ENGINE OIL FILTER ADAPTOR 가스켓
01.441	GASKET, ENGINE WATER PUMP ATTACHING 가스켓
01.481	GASKET, ENGINE WATER PUMP BODY 가스켓
01.751	SEAL, OIL PAN DIPSTICK HOLE PLUG 시일
02.928	GASKET, EXHAUST MANIFOLD 가스켓
02.929	GASKET, INTAKE MANIFOLD 가스켓
62.201	GASKET, ENGINE WATER TEMPERATURE CONTROL 가스켓



CYLINDER HEAD & COVERS




00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.063	PLUG, CRANKCASE HEAD 플러그
00.064	SEAL, CAMSHAFT OIL 시일
00.069	FASTENER, ENGINE LIFTING BRACKET 패스너
00.070	FASTENER, ENGINE LIFTING BRACKET 패스너
00.072	COVER, CRANKCASE HEAD END 커버
00.074	FASTENER, CRANKCASE HEAD END COVER 패스너
00.075	FASTENER, CRANKCASE HEAD END COVER 패스너
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓킷
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓
00.151	PLUG, CRANKCASE HEAD REAR 플러그
00.247	TENSIONER, CAMSHAFT TIMING BELT 텐서너
00.248	GUIDE, CAMSHAFT TIMING BELT TENSIONER 가이드
00.256	FASTENER, CAMSHAFT TIMING GEAR 패스너
00.345	BUSHING, CRANKCASE HEAD 부싱

00.464	BRACKET, ENGINE LIFTING 브라켓
00.466	BRACKET, ENGINE LIFTING 브라켓
00.600	HEAD ASSEMBLY, CRANKCASE 헤드
00.604	GASKET, CRANKCASE HEAD 가스켓
00.606	FASTENER, CRANKCASE HEAD 패스너
00.607	FASTENER, CRANKCASE HEAD 패스너
00.608	FASTENER, CRANKCASE HEAD 패스너
00.609	FASTENER, CRANKCASE HEAD 패스너
00.610	HEAD, CRANKCASE 헤드
00.611	FASTENER, CRANKCASE HEAD 패스너
00.646	FASTENER, ENGINE ROCKER ARM PIVOT SUPPORT 패스너
00.650	CAMSHAFT 캠샤프트
00.663	COVER, ROCKER ARM 커버
00.664	GASKET, ROCKER ARM COVER 가스켓
00.665	FASTENER, ROCKER ARM COVER 패스너



CYLINDER HEAD & COVERS

00.677	GEAR, CAMSHAFT TIMING 기어
00.683	SEAT, EXHAUST VALVE INSERT 시트
00.684	SEAT, INTAKE VALVE INSERT 시트
00.685	VALVE, EXHAUST 밸브
00.688	VALVE, INTAKE 밸브
00.689	RETAINER, ENGINE VALVE SEAL 리테이너
00.691	SPRING, ENGINE INTAKE VALVE 스프링
00.692	SPRING, ENGINE EXHAUST VALVE 스프링
00.693	GUIDE, INTAKE VALVE 가이드
00.694	GUIDE, EXHAUST VALVE 가이드
00.698	LOCK, EXHAUST VALVE SPRING SEAT 로크
00.700	LOCK, INTAKE VALVE SPRING SEAT 로크
00.703	SEAT, INTAKE VALVE SPRING 시트
00.705	SEAT, EXHAUST VALVE SPRING 시트
00.707	LIFTER, ENGINE VALVE 리프터
00.728	CHAIN, CAMSHAFT TIMING 체인
00.752	RETAINER, CRANKCASE HEAD COMBUSTION CHAMBER INSE 리테이너
00.769	TENSIONER, CAMSHAFT TIMING CHAIN 텐셔너
00.793	BUSHING, ENGINE LOCKER ARM PIVOT SUPPORT 부싱
00.809	SLEEVE, CRANKCASE VENT TUBE VALVE 슬리브
01.283	CAP, CRANKCASE OIL FILLER 캡
01.286	GASKET, OIL FILLER CAP 가스켓
01.791	CHAIN, OIL PUMP DRIVE 체인
02.381	VALVE, PCV 밸브
62.177	CAMSHAFT, EXHAUST 캠샤프트
62.178	GUIDE, ENGINE OIL PUMP CHAIN 가이드
62.179	FASTENER, ENGINE OIL PUMP CHAIN TENSION 패스너
62.180	TENSIONER, ENGINE OIL PUMP CHAIN 텐셔너
62.200	GEAR, CAMSHAFT TIMING 기어
91.073	LOCKWASHER, CRANKCASE HEAD FASTENER 로크와셔
94.071	FASTENER, ROCKER ARM PIVOT SUPPORT 패스너
94.978	FASTENER, CAMSHAFT TIMING BELT TENSIONER 패스너
95.478	FASTENER, ENGINE BALANCER WEIGHT DRIVE CHAIN GUI 패스너
95.481	FASTENER, ENGINE BALANCER WEIGHT DRIVE CHAIN GUI 패스너




00.000	PRODUCTION ENGINE ASSEMBLY 엔진	00.350	CRANKSHAFT 크랭크샤프트
00.010	SHORT ENGINE ASSEMBLY 숏엔진	00.351	PLATE, FLYWHEEL REINFORCING 플레이트
00.011	CRANKCASE 크랭크케이스	00.353	PLATE, CRANKSHAFT THRUST 플레이트
00.020	COVER, CRANKCASE ACCESS HOLE 커버	00.360	BEARING, NO. 1 MAIN JOURNAL 베어링
00.043	BUSHING, ENGINE REAR SUPPORT BRACKET 부싱	00.361	BEARING, NO. 2 MAIN JOURNAL 베어링
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓킷	00.362	BEARING, NO. 3 MAIN JOURNAL 베어링
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓	00.363	BEARING, NO. 4 MAIN JOURNAL 베어링
00.149	PLUG - EXPANSION, CRANKCASE SIDE 플러그	00.364	BEARING, NO. 5 MAIN JOURNAL 베어링
00.189	SEAL, CRANKCASE OIL GALLEY PLUG 시일	00.380	PULLEY, CRANKSHAFT 풀리
00.200	FASTENER, CRANKSHAFT BEARING NO. 1 CAP 패스너	00.390	WASHER, CRANKSHAFT PULLEY 와셔
00.237	GUIDE, CRANKSHAFT TIMING SPROCKET 가이드	00.395	FASTENER, CRANKSHAFT PULLEY 패스너
00.260	BEARING, CONNECTING ROD (CYL. #1) 베어링	00.405	KEY, CRANKSHAFT TIMING GEAR 키
00.261	BEARING, CONNECTING ROD (CYL. #2) 베어링	00.427	SEAL, CRANKCASE REAR OIL 시일
00.262	BEARING, CONNECTING ROD (CYL. #3) 베어링	00.450	FLYWHEEL 플라이휠
00.263	BEARING, CONNECTING ROD (CYL. #4) 베어링	00.453	GEAR, FLYWHEEL RING 기어



CRANKCASE


00.456	FASTENER, CRANKSHAFT TO FLYWHEEL 패스너	01.700	OIL PUMP ASSEMBLY 오일펌프
00.461	DOWEL, CRANKCASE HEAD 다웰	01.702	FASTENER, OIL PUMP 패스너
00.463	DOWEL, CRANKSHAFT 다웰	01.751	SEAL, OIL PAN DIPSTICK HOLE PLUG 시알
00.482	PLATE, GEAR COVER BACKING 플레이트	01.851	STUD, OIL PAN 스터드
00.501	SPACER, FLYWHEEL RING GEAR 스페이서	01.868	FASTENER, CRANKSHAFT PULLEY 패스너
00.530	COVER, ENGINE FRONT GEAR 커버	62.174	OIL JET, ENGINE OIL PUMP CHAIN 오일젯
00.547	SEAL, ENGINE FRONT GEAR COVER 시알	62.175	FASTENER, ENGINE OIL JET 패스너
00.564	FASTENER, ENGINE FRONT GEAR COVER 패스너	62.181	BUSHING, ENGINE KNOCK 부싱
00.566	FASTENER, ENGINE FRONT GEAR COVER 패스너	62.184	PULLEY, ENGINE CRANKSHAFT DAMPER 풀리
00.567	FASTENER, ENGINE FRONT GEAR COVER 패스너	62.260	PLUG, ENGINE FRONT GEAR COVER NIPPLE *
00.579	PLUG, ENGINE FRONT GEAR COVER 플러그	95.969	FASTENER, ENGINE OIL LEVEL CONTROL 패스너
00.628	PLUG, CRANKCASE HEAD 플러그		
00.668	PLUG, CRANKCASE WATER 플러그		
00.760	ROD ASSEMBLY, CONNECTING 로드		
00.767	FASTENER, CONNECTING ROD BEARING CAP 패스너		
00.803	PISTON (ONE CYLINDER) 피스톤과핀		
00.805	PIN, PISTON 핀		
00.820	PISTON RING 피스톤링		
00.845	HOUSING, FLYWHEEL 하우징		
00.861	FASTENER, FLYWHEEL HOUSING TO CRANKCASE 패스너		
00.862	FASTENER, FLYWHEEL HOUSING TO CRANKCASE 패스너		
00.863	FASTENER, FLYWHEEL HOUSING TO CRANKCASE 패스너		
01.018	SEAL, OIL LEVEL DIPSTICK ADAPTOR 시알		
01.075	PAN, CRANKCASE OIL 팬		
01.079	FASTENER, CRANKCASE OIL PAN 패스너		
01.099	PLUG, CRANKCASE OIL PAN DRAIN 플러그		
01.100	GASKET, CRANKCASE OIL PAN DRAIN PLUG 가스켓		
01.125	DIPSTICK, CRANKCASE OIL LEVEL 딤스틱		
01.188	PAN, CRANKCASE OIL UPPER 팬		
01.191	PIN, ENGINE OIL PAN 핀		
01.295	FASTENER, ENGINE OIL FILTER ATTACHING 패스너		
01.307	CARTRIDGE & GASKET, ENGINE OIL FILTER 카트리지와가스켓		
01.322	GASKET, ENGINE OIL FILTER ADAPTOR 가스켓		
01.353	FITTING, BLOCK TO OIL FILTER 피팅		
01.494	TUBE, OIL LEVEL DIPSTICK ADAPTOR 튜브		
01.511	ADAPTOR, ENGINE OIL FILTER 어댑터		



01.151	GUARD, RADIATOR FAN 가드	01.563	FASTENER, RADIATOR MOUNTING BRACKET 패스너
01.381	BLADE, FAN 블레이드	01.565	SPACER, RADIATOR MOUNTING 스페이서
01.416	SPACER, FAN BLADE 스페이서	01.570	CAP, RADIATOR 캡
01.465	FASTENER, FAN BLADE SPACER 패스너	01.577	HOSE, RADIATOR UPPER 호스
01.520	COMPENSATION TANK, COOLING SYSTEM 보상기	01.579	CLAMP, RADIATOR UPPER HOSE 클램프
01.521	COVER, COMPENSATION TANK 커버	01.600	HOSE, RADIATOR LOWER 호스
01.523	LINE, COOLING SYSTEM COMPENSATION TANK 라인	01.601	CLAMP, RADIATOR LOWER HOSE 클램프
01.526	BRACKET, RADIATOR FILLER MOUNTING 브라켓	01.640	FASTENER, RADIATOR SHROUD EXTENTION 패스너
01.528	CLIP, RADIATOR OVERFLOW LINE 클립	01.660	SHROUD, RADIATOR 슈라우드
01.529	CLAMP, RADIATOR OVERFLOW LINE 클램프	01.693	DAMPENER, RADIATOR VIBRATION 댐프너
01.530	LINE, RADIATOR FILLER 라인	01.697	SCREEN, RADIATOR DUST PROTECTION 스크린
01.547	DRAIN COCK, RADIATOR 드레인콕	01.699	CLAMP, RADIATOR HOSE FASTENER 클램프
01.550	RADIATOR 라디에터	95.403	FASTENER, RADIATOR SHROUD BRACKET 패스너
01.555	LINE, RADIATOR OVERFLOW 라인	96.296	FASTENER, RADIATOR OVERFLOW LINE CLIP 패스너
01.559	FASTENER, RADIATOR UPPER SUPPORT (RADIATOR END) 패스너		



WATER COOLING SYSTEM




00.000	PRODUCTION ENGINE ASSEMBLY 엔진	01.481	GASKET, ENGINE WATER PUMP BODY 가스켓
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓킷	01.504	PIPE, ENGINE WATER PUMP INLET 파이프
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓	01.532	FASTENER, ENG THERMOSTAT BY-PASS FITTING 패스너
01.187	ENGINE WATER PUMP SET 엔진워터펌프	01.543	LINE, ENGINE THERMO BY PASS 라인
01.219	FITTING, WATER PUMP INLET 피팅	01.585	FASTENER, WATER OUTLET ELBOW-REAR 패스너
01.399	BRACKET, FAN MOUNTING 브라켓	01.587	FASTENER, WATER INLET COVER 패스너
01.410	FASTENER, IDLER ADJUSTMENT 패스너	01.588	FASTENER, WATER OUTLET ELBOW 패스너
01.417	PULLEY, FAN 풀리	01.589	GASKET, WATER OUTLET ELBOW 가스켓
01.418	BELT, WATER PUMP 벨트	01.594	GASKET, ENGINE THERMOSTAT HOUSING ATT 가스켓
01.430	PUMP ASSEMBLY, ENGINE WATER 펌프	01.596	THERMOSTAT, ENGINE 써머스태트
01.432	PULLEY, WATER PUMP 풀리	01.666	FASTENER, WATER PUMP PULLEY 패스너
01.434	COVER, WATER PUMP 커버	01.860	FASTENER, FAN DRIVE HUB MOUNTING SHAFT 패스너
01.438	FASTENER, WATER PUMP 패스너	01.872	IDLER, V-BELT 아이들러
01.439	FASTENER, WATER PUMP 패스너	12.100	BRACKET, ALTERNATOR MOUNTING 브라켓
01.441	GASKET, ENGINE WATER PUMP ATTACHING 가스켓	12.103	FASTENER, ALTERNATOR TO BRACKET 패스너



WATER COOLING SYSTEM


12.182	PULLEY, ALTERNATOR TENSIONER 풀리
62.167	BRACKET, ENGINE TENTION PULLEY 브라켓
62.168	CONTROL ASSEMBLY, ENGINE WATER TEMPERATURE 컨트롤
62.201	GASKET, ENGINE WATER TEMPERATURE CONTROL 가스켓
62.202	FASTENER, ENGINE WATER TEMPERATURE CONTROL 패스너
62.203	FASTENER, ENGINE WATER TEMPERATURE CONTROL 패스너
62.243	SENSOR, ENGINE COOLANT TEMPERTURE (ECU) *
94.100	FASTENER, WATER PUMP DISCHARGE FLANGE 패스너
96.577	FASTENER, FAN MOUNTING BRACKET 패스너



NON PRE-CLEANER GP

02-154

- | | |
|--------|---|
| 02.422 | SCREEN, ENGINE INTAKE AIR
스크린 |
| 03.567 | PLUG, AIR INTAKE DRIVER OVERHEAD GUARD
플러그 |
| 93.761 | FASTENER, DRIVERS OVERHEAD GUARD TOP SECTION COVER
패스너 |
| 95.735 | FASTENER, ENGINE AIR INTAKE SCREEN
패스너 |



ACCELERATOR SYSTEM


02-156

- | | |
|--------|--|
| 02.280 | PEDAL, ACCELERATOR
페달 |
| 02.283 | PIN, ACCELERATOR PEDAL TO BRACKET PIVOT
핀 |
| 02.288 | BRACKET, ACCELERATOR PEDAL ATTACHING
브라켓 |
| 02.289 | FASTENER, ACCELERATOR PEDAL BRACKET ATTACHING
패스너 |
| 02.329 | FASTENER, ACCELERATOR PEDAL
패스너 |
| 02.337 | BRACKET, ACCELERATOR LEVER MOUNTING
브라켓 |
| 02.338 | FASTENER, ACCELERATOR LEVER MOUNTING BRACKET
패스너 |
| 03.086 | FASTENER, ACCELERATOR PEDAL STOP
패스너 |
| 03.419 | WEAR PLATE, ACCELERATOR PEDAL ROLLER
웨어플레이트 |



ACCELERATOR SYSTEM

62.050	PEDAL ASSEMBLY, ACCELERATOR 페달
93.726	WASHER, ACCELERATOR PEDAL PIVOT RETAINER 와셔



ACCELERATOR LINKAGE

02-194

02.258	STOP, ACCELERATOR PEDAL 스톱
02.260	BRACKET, ACCELERATOR LINKAGE MOUNTING 브라켓
02.280	PEDAL, ACCELERATOR 페달
02.282	ROD, ACCELERATOR PUSH 로드
02.283	PIN, ACCELERATOR PEDAL TO BRACKET PIVOT 핀
02.284	FASTENER, PEDAL TO BRACKET PIVOT PIN 패스너
02.288	BRACKET, ACCELERATOR PEDAL ATTACHING 브라켓
02.289	FASTENER, ACCELERATOR PEDAL BRACKET ATTACHING 패스너
02.290	BUSHING, ACCELERATOR BELLCRANK 부싱




02.319	BUSHING, ACCELERATOR LINKAGE LEVER 부싱
02.326	BEARING, ACCELERATOR LEVER 베어링
02.338	FASTENER, ACCELERATOR LEVER MOUNTING BRACKET 패스너
02.775	CABLE, ACCELERATOR CONTROL 케이블
02.776	BRACKET, ACCELERATOR CONTROL CABLE 브라켓
03.086	FASTENER, ACCELERATOR PEDAL STOP 패스너
03.163	FASTENER, ACCELERATOR CONTROL ROD END 패스너
03.348	WASHER, ACCELERATOR LINKAGE RETURN LEVER FAST 와셔
03.419	WEAR PLATE, ACCELERATOR PEDAL ROLLER 웨어플레이트
03.461	PIN, ACCELERATOR CONTROL ROD END 핀
03.462	SPRING, ACCELERATOR PEDAL RETURN 스프링
03.645	CLIP, ACCELERATOR CONTROL CABLE 클립
03.687	FASTENER, ACC CONTROL CABLE BRACKET MTG 패스너
03.688	BRACKET, ACCELERATOR LEVER ATTACHING 브라켓
90.957	RETAINER, ACCELERATOR LINKAGE LEVER PIN 리테이너
92.298	NUT, ACCELERATOR LEVER ATTACHING BRACKET FASTENER 너트
93.726	WASHER, ACCELERATOR PEDAL PIVOT RETAINER 와셔
96.445	FASTENER, ACCELERATOR CONTROL CABLE CLIP 패스너



AIR CLEANER ASSEMBLY

ASSEMBLY
COMPLETE — 02.225




AIR CLEANER ASSEMBLY

02-474

- | | |
|--------|---|
| 02.225 | CLEANER ASSEMBLY, ENGINE INTAKE AIR
에어클리너 |
| 02.232 | CLAMP, INTAKE AIR CLEANER
클램프 |
| 02.242 | ELEMENT & GASKET, ENGINE INTAKE AIR CLEANER
엘리먼트와가스켓 |
| 02.380 | CAP, FILTER
캡 |
| 02.790 | VALVE, ENGINE INTAKE AIR CLEANER DUST UNLDR
밸브 |




INDICATOR LIGHT INSTALLATION



INDICATOR LIGHT INSTALLATION

02-478

02.252	FITTING, MAIN AIR CLEANER OUTLET TUBE 피팅
02.257	INDICATOR, ENGINE INTAKE AIR CLEANER AIR RES 인디케이터
62.067	HOSE, AIR CLEANER INTAKE 호스
62.068	HOSE, AIR CLEANER INTAKE 호스
62.069	TUBE, AIR CLEANER INTAKE 튜브




FUEL SYSTEM

03-268

- | | |
|--------|--|
| 02.045 | ADAPTOR, THREE WAY THRU HOOD
어댑터 |
| 02.046 | FASTENER, ADAPTOR
패스너 |
| 03.018 | FITTING, THREE WAY VALVE OUTLET LINE
피팅 |

SWING DOWN
SYSTEM KIT

62.056




LPG TANK MOUNTING

03-349

02.002	CLAMP ARM, LPG TANK GUARD 클램프암
02.010	BRACKET, LPG TANK REAR MOUNTING 브라켓
02.011	FASTENER, TANK REAR MOUNTING BRACKET 패스너
02.020	TANK, FUEL 탱크
03.299	SPACER, LPG TANK GUARD MOUNTING FASTENER 스페이서
39.486	FASTENER, GAS TANK SHIELD 패스너
62.056	KIT, SWING DOWN SYSTEM 킷



SWING DOWN BRACKET ASSEMBLY



SWING DOWN BRACKET ASSEMBLY


03-559

02.009	FASTENER, LPG TANK GUARD MOUNTING 패스너
02.015	STRAP, LPG TANK CLAMP 스트랩
02.097	FASTENER, TANK GUARD PIVOT ROD 패스너
02.388	PIN, TANK LOCATING 핀
03.358	CAP, FUEL TANK 캡
03.458	BRACKET, LPG TANK LOCATING PIN 브라켓
03.468	HANDLE, LPG TANK MOUNTING BRACKET 핸들
03.634	SUPPORT, LPG TANK BRACKET 서포트
03.636	SUPPORT, LPG TANK MOUNTING BRACKET 서포트



SWING DOWN BRACKET ASSEMBLY


03.676	STOP, LPG TANK PIVOT 스톱
03.677	BUSHING, LPG TANK PIVOT 부싱
37.253	WASHER, GAS TANK SHIELD FASTENER 와셔
62.053	PROP, SWING DOWN LPG TANK MTG 프롭
62.055	BRACKET, SWING DOWN LPG TANK MTG 브라켓
62.241	FITTING-LUB, LPG TANK BRACKET PIVOT *
91.422	NUT, LPG TANK SUPPORT 너트
96.420	FASTENER, LPG TANK MOUNTING BRACKET 패스너
96.422	WASHER, LPG TANK BRACKET PIVOT 와셔



SWITCH INSTALLATION

03-581

03.733 SWITCH,LPG PRESSURE
스위치




00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.100	GASKET KIT, ENGINE OVERHAUL 가스켓킷
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스켓
02.548	MANIFOLD, INTAKE 매니폴드
02.549	MANIFOLD, EXHAUST 매니폴드
02.589	SHIELD, HEAT (AT MANIFOLD) 쉴드
02.631	FASTENER, HEAT SHIELD 패스너
02.928	GASKET, EXHAUST MANIFOLD 가스켓
02.929	GASKET, INTAKE MANIFOLD 가스켓



INTAKE & EXHAUST MANIFOLD


03.457	SHIELD, MANIFOLD HEAT 쉴드
03.726	FASTENER, INTAKE MANIFOLD 패스너
11.275	CONDENSER, IGNITION 콘덴서
11.276	FASTENER, IGNITION CONDENSER 패스너
60.830	SENSOR, ENG CONTROL OXYGEN 센서
62.142	SENSOR, ENGINE MAP 센서
62.176	FASTENER, ENGINE MAP SENSOR 패스너
62.204	LINE, PCV 라인
90.253	NUT, MANIFOLD FASTENER 너트
90.738	NUT, MANIFOLD FASTENER 너트
95.877	FASTENER, HEAD SHIELD 패스너



00.000	PRODUCTION ENGINE ASSEMBLY 엔진	02.633	LINE, VAPORIZER OUTLET 라인
01.627	LINE, VAPORIZER WATER OUTLET 라인	02.647	CLIP, FUEL FILTER OUTLET LINE CLIP 클립
01.630	LINE, VAPORIZER WATER INLET 라인	02.802	FITTING, LPG VAPORIZER INLET 피팅
01.638	CLAMP, VAPORIZER WATER OUTLET LINE 클램프	02.940	LINE, INJECTOR LEAK OFF 라인
01.644	CLAMP, VAPORIZER WATER INLET LINE 클램프	02.944	NOZZLE, FUEL INJECTOR 노즐
01.645	LINE, VAPORIZER WATER OUTLET 라인	02.949	LINE, INJECTOR (NO 1 CYLINDER) 라인
01.646	CLAMP, VAPORIZER WATER OUTLET LINE 클램프	02.950	LINE, INJECTOR (NO 2 CYLINDER) 라인
02.043	FILTER, FUEL 필터	02.951	LINE, INJECTOR (NO 3 CYLINDER) 라인
02.050	VALVE, LPG LOCK OFF 밸브	02.952	LINE, INJECTOR (NO 4 CYLINDER) 라인
02.052	CLAMP, REGULATOR OUTLET HOSE 클램프	03.030	INJECTOR ASSEMBLY, FUEL 인젝터
02.053	LINE, REGULATOR OUTLET 라인	03.033	FASTENER, FUEL INJECTOR 패스너
02.371	CONTROL UNIT, ELECTRONIC (ECU) 컨트롤유닛	03.310	FITTING, FUEL LOCK-OFF VALVE OUTLET 피팅
02.373	FASTENER, ECU TO FUEL MODULE 패스너	03.322	BRACKET, LPG REGULATOR MOUNTING 브라켓
02.426	FASTENER, FUEL FILTER BRACKET 패스너	03.338	DAMPENER, FUEL INJECTOR LINE VIBRATION 댐프너
02.601	REGULATOR, VAPORIZER ASSY 레귤레이터	03.375	REPAIR KIT, LP GAS VAPOR REGULATOR 리페어킷



03.396	REPAIR KIT, FUEL VALVE AND FILTER 리페어킷
03.437	CLAMP, FUEL INJECTOR LINE 클램프
03.479	NOZZLE, TIP FUEL INJECTOR 노즐
03.564	NOZZLE, VACUUM REDUCTION 노즐
03.577	LINE, ENGINE FUEL FILTER 라인
03.638	CLAMP, VACUUM LINE 클램프
03.761	FASTENER, THROTTLE POSITIONER BRACKET 패스너
03.762	HOSE, VACUUM 호스
03.826	GASKET, THROTTLE BODY 가스켓
03.829	THROTTLE BODY AND SHAFT 트로틀
11.213	FASTENER, TRANSISTOR IGNITION RESISTOR 패스너
11.274	TRANSISTOR, ENGINE IGNITION 트랜지스터
11.277	COVER, ENGINE IGNITION TRANSISTOR 커버
15.641	WIRING HARNESS, ENGINE 와이어하네스
62.045	BRACKET, ELECTRONIC CONTROL UNIT 브라켓
62.205	BRACKET, FUEL INJECTOR 브라켓
62.209	CLAMP, FUEL FILTER 클램프
62.240	SOLENOID, FUEL LOCK-OFF VALVE *
62.256	REPAIR KIT, FUEL INJECTOR *
92.935	FASTENER, LOCK-OFF VALVE AND FILTER 패스너
93.405	NUT, FUEL INJECTOR FASTENER 너트
94.884	FASTENER, LPG VAPORIZER MOUNTING 패스너



02.040	COUPLER, LPG QUICK DISCONNECT 커플러
02.041	LINE, LP GAS TANK OUTLET 라인
02.044	VALVE, HYDROSTATIC RELIEF 밸브
02.045	ADAPTOR, THREE WAY THRU HOOD 어댑터
02.046	FASTENER, ADAPTOR 패스너
02.047	FITTING, LPG ADAPTOR OUTLET 피팅
02.049	LINE, ADAPTOR OUTLET 라인
02.059	FITTING, LPG VAPORIZER INLET 피팅
02.086	FASTENER, LPG LINE CLIP 패스너




02.090	BRACKET, LPG THREE WAY ADAPTOR MOUNTING 브라켓
02.091	FASTENER, LPG ADAPTOR MOUNTING BRACKET 패스너
02.095	FITTING, LPG THREE WAY ADAPTOR 피팅
02.869	CLIP, LPG LINE 클립
03.018	FITTING, THREE WAY VALVE OUTLET LINE 피팅
03.143	COUPLER, LPG QUICK DISCONNECT 커플러
03.144	COUPLER, LPG QUICK DISCONNECT 커플러
03.733	SWITCH,LPG PRESSURE 스위치
97.080	FASTENER, ECU MOUNTING 패스너

- 03-607 (1)



EXHAUST SYSTEM

47.121	PLUG, OVERHEAD GUARD 플러그
95.249	FASTENER, TAIL PIPE CONNECTION FLANGE 패스너




02.011	FASTENER, TANK REAR MOUNTING BRACKET 패스너
02.041	LINE, LP GAS TANK OUTLET 라인
02.047	FITTING, LPG ADAPTOR OUTLET 피팅
02.095	FITTING, LPG THREE WAY ADAPTOR 피팅
02.426	FASTENER, FUEL FILTER BRACKET 패스너
03.299	SPACER, LPG TANK GUARD MOUNTING FASTENER 스페이서
39.823	BRACKET, FUEL FILTER 브라켓
62.003	CLAMP, LPG TANK 클램프
62.004	PLATE, LICENSE 플레이트



62.044	FASTENER, LICENSE PLATE MOUNTING 패스너
62.055	BRACKET, SWING DOWN LPG TANK MTG 브라켓



INTAKE & EXHAUST MANIFOLD




00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.100	GASKET KIT, ENGINE OVERHAUL 가스킷
00.101	VALVE GRIND GASKET KIT (TOP SET) 밸브가스킷
00.106	FITTING, CRANKCASE VENT TUBE 피팅
01.114	PLUG, WATER OUTLET ELBOW 플러그
01.625	CLAMP, WATER OUTLET HOUSING HOSE 클램프
02.548	MANIFOLD, INTAKE 매니폴드
02.549	MANIFOLD, EXHAUST 매니폴드
02.589	SHIELD, HEAT (AT MANIFOLD) 쉴드



INTAKE & EXHAUST MANIFOLD

02.631	FASTENER, HEAT SHIELD 패스너
02.928	GASKET, EXHAUST MANIFOLD 가스켓
02.929	GASKET, INTAKE MANIFOLD 가스켓
03.457	SHIELD, MANIFOLD HEAT 쉴드
03.726	FASTENER, INTAKE MANIFOLD 패스너
11.275	CONDENSER, IGNITION 콘덴서
11.276	FASTENER, IGNITION CONDENSER 패스너
60.830	SENSOR, ENG CONTROL OXYGEN 센서
62.142	SENSOR, ENGINE MAP 센서
62.176	FASTENER, ENGINE MAP SENSOR 패스너
62.204	LINE, PCV 라인
90.253	NUT, MANIFOLD FASTENER 너트
90.738	NUT, MANIFOLD FASTENER 너트
95.877	FASTENER, HEAD SHIELD 패스너




00.000	PRODUCTION ENGINE ASSEMBLY 엔진
01.627	LINE, VAPORIZER WATER OUTLET 라인
01.630	LINE, VAPORIZER WATER INLET 라인
01.644	CLAMP, VAPORIZER WATER INLET LINE 클램프
01.646	CLAMP, VAPORIZER WATER OUTLET LINE 클램프
02.043	FILTER, FUEL 필터
02.050	VALVE, LPG LOCK OFF 밸브
02.052	CLAMP, REGULATOR OUTLET HOSE 클램프
02.053	LINE, REGULATOR OUTLET 라인
02.371	CONTROL UNIT, ELECTRONIC (ECU) 컨트롤유닛
02.373	FASTENER, ECU TO FUEL MODULE 패스너
02.426	FASTENER, FUEL FILTER BRACKET 패스너
02.601	REGULATOR, VAPORIZER ASSY 레귤레이터
02.647	CLIP, FUEL FILTER OUTLET LINE CLIP 클립
02.802	FITTING, LPG VAPORIZER INLET 피팅

02.940	LINE, INJECTOR LEAK OFF 라인
02.944	NOZZLE, FUEL INJECTOR 노즐
02.949	LINE, INJECTOR (NO 1 CYLINDER) 라인
02.950	LINE, INJECTOR (NO 2 CYLINDER) 라인
02.951	LINE, INJECTOR (NO 3 CYLINDER) 라인
02.952	LINE, INJECTOR (NO 4 CYLINDER) 라인
03.030	INJECTOR ASSEMBLY, FUEL 인젝터
03.033	FASTENER, FUEL INJECTOR 패스너
03.307	FITTING, FUEL LOCK-OFF VALVE INLET 피팅
03.310	FITTING, FUEL LOCK-OFF VALVE OUTLET 피팅
03.322	BRACKET, LPG REGULATOR MOUNTING 브라켓
03.338	DAMPENER, FUEL INJECTOR LINE VIBRATION 댐퍼
03.375	REPAIR KIT, LP GAS VAPOR REGULATOR 리페어킷
03.396	REPAIR KIT, FUEL VALVE AND FILTER 리페어킷
03.400	LINE, FUEL LOCK-OFF VALVE OUTLET 라인



03.401	BRACKET, LPG LOCK-OFF VALVE MOUNTING 브라켓
03.437	CLAMP, FUEL INJECTOR LINE 클램프
03.479	NOZZLE, TIP FUEL INJECTOR 노즐
03.564	NOZZLE, VACUUM REDUCTION 노즐
03.577	LINE, ENGINE FUEL FILTER 라인
03.638	CLAMP, VACUUM LINE 클램프
03.761	FASTENER, THROTTLE POSITIONER BRACKET 패스너
03.762	HOSE, VACUUM 호스
03.826	GASKET, THROTTLE BODY 가스켓
03.829	THROTTLE BODY AND SHAFT 트로틀
11.213	FASTENER, TRANSISTOR IGNITION RESISTOR 패스너
11.274	TRANSISTOR, ENGINE IGNITION 트랜지스터
11.277	COVER, ENGINE IGNITION TRANSISTOR 커버
15.641	WIRING HARNESS, ENGINE 와이어하네스
62.045	BRACKET, ELECTRONIC CONTROL UNIT 브라켓
62.205	BRACKET, FUEL INJECTOR 브라켓
62.209	CLAMP, FUEL FILTER 클램프
62.249	GUARD, ENGINE VAPORIZER WATER INLET *
62.250	U-BOLT CLAMP, FUEL LPG LOCK-OFF *
62.256	REPAIR KIT, FUEL INJECTOR *
93.405	NUT, FUEL INJECTOR FASTENER 너트
94.884	FASTENER, LPG VAPORIZER MOUNTING 패스너
95.928	FASTENER, LPG LOCK OFF VAVLE BRACKET 패스너

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



INTAKE SYSTEM


03-698

- 02.225 CLEANER ASSEMBLY, ENGINE INTAKE AIR
에어클리너
- 02.236 CLAMP, MAIN AIR CLEANER INLET HOSE
클램프
- 02.246 FASTENER, ENGINE INTAKE AIR CLEANER ATTACHING
패스너
- 02.257 INDICATOR, ENGINE INTAKE AIR CLEANER AIR RES
인디케이터
- 02.262 HOSE, MAIN AIR CLEANER OUTLET
호스
- 02.266 HOSE, MAIN AIR CLEANER OUTLET
호스
- 02.267 CLAMP, MAIN AIR CLEANER OUTLET HOSE
클램프
- 02.269 CLAMP, MAIN AIR CLEANER OUTLET HOSE
클램프
- 02.386 FASTENER, ENGINE INTAKE AIR CLEANER SUPPORT
패스너




INTAKE SYSTEM

02.457	FITTING, MAIN AIR CLEANER OUTLET TUBE 피팅
02.969	HOSE, MAIN AIR CLEANER INLET 호스
03.202	CLAMP, ENGINE AIR INTAKE ADAPTOR 클램프
03.383	LINE, MAIN AIR CLEANER INLET LINE 라인
03.517	BRACKET, AIR CLEANER MOUNTING 브라켓



05.057	GEAR, PUMP DRIVE 기어	10.167	FITTING, TRANSMISSION CONTROL COVER OUTLET 피팅
05.148	PLUG, CONVERTER HOUSING 플러그	10.168	FITTING, TRANSMISSION CONTROL COVER OUTLET 피팅
05.261	TUBE FITTING, TRANSMISSION LUB LINE 튜브피팅	20.100	TRANSAXLE ASSEMBLY 트랜스액슬
05.525	PLUG, TRANSMISSION CASE 플러그	20.510	EXPANSION PLUG, INTERNAL GEAR HUB 플러그
06.202	STRAINER, TRANSMISSION SUMP 스트레이너	29.100	PUMP ASSEMBLY, HYDRAULIC 펌프
06.377	PLUG, TRANSMISSION SUMP OIL LEVEL 플러그	29.106	FASTENER, PUMP TO PLATE 패스너
06.447	PLUG, TRANSMISSION CASE 플러그	29.150	GASKET, HYDRAULIC PUMP MOUNTING 가스켓
06.610	TUBE, TRANSMISSION "HIGH" OIL 튜브	29.349	SEAL, PUMP COVER SEAL LOCATOR 시일
06.647	LINE, TRANSMISSION LUBRICATION 라인	31.640	FITTING, HYD PUMP OUTLET (COVER END) 피팅
06.660	SOLENOID ASSEMBLY, TRANSMISSION 솔레노이드	44.055	FITTING, TRANSMISSION CONTROL COVER RETURN LINE 피팅
08.260	TUBE, TRAN OIL LEVEL DIPSTICK SUPPORT 튜브	44.170	COIL, TRANSMISSION CONTROL COVER SOLENOID 코일
08.373	DIPSTICK, TRANSMISSION 딥스틱	44.212	CARTRIDGE, CONTROL VALVE SHIFT SOLENOID 카트리지
08.398	SEAL, TRANSMISSION DIPSTICK SUPPORT 시일	44.301	SEAL KIT, SOLENOID VALVE 시일킷
09.007	PLUG - EXPANSION, GEAR CASE 플러그	95.082	FASTENER, CONTROL SELECTOR SOLENOID RELAY 패스너
10.105	ELEMENT & GASKET, OIL FILTER 엘리먼트와가스켓		




- | | |
|--------|---|
| 05.021 | BEARING, IMPELLER HUB
베어링 |
| 05.023 | SEAL, CONVERTER IMPELLER HUB
시일 |
| 05.030 | GEAR, IMPELLER HUB
기어 |
| 05.033 | STATOR SUPPORT ASSEMBLY, CONVERTER
스테이터 |
| 05.034 | FASTENER, STATOR SUPPORT
패스너 |
| 05.130 | SHAFT, CONVERTER PUMP IDLER GEAR
샤프트 |
| 05.133 | GEAR, CONVERTOR PUMP IDLER
기어 |
| 05.136 | BEARING, CONVERTER STATOR SUPPORT
베어링 |
| 05.137 | LOCATOR, CONVERTER STATOR SUPPORT (OUTER)
로케이터 |



CONVERTOR HOUSING AND PUMP DRIVE

05.233	PLUG, CONVERTOR HOUSING EXPANDER 플러그
05.533	PLUG, CONVERTER HOUSING 플러그
06.400	CONTROL COVER & VALVE ASSEMBLY 컨트롤커버와밸브
06.408	GASKET, CONTROL COVER ATTACHING 가스켓
06.423	FASTENER, CONTROL VALVE HOUSING 패스너
06.471	HOUSING, CONVERTER 하우징
06.522	SEAL AND GASKET KIT, TRANSMISSION 시일과가스켓킷
06.716	FASTENER, CONTROL COVER 패스너
06.954	DOWEL, TRANSMISSION CASE TO CONVERTER 다월
06.977	BEARING, REVERSE CLUTCH HUB (ENGINE END) 베어링
20.100	TRANSAXLE ASSEMBLY 트랜스액슬




- | | |
|--------|---|
| 05.114 | FASTENER, CONVERTER TO CASE
패스너 |
| 05.115 | FASTENER, CONVERTER TO CASE
패스너 |
| 06.220 | GEAR, REVERSE IDLER
기어 |
| 06.506 | SEAL, CONVERTER HOUSING TO CASE-INNER
시일 |
| 06.521 | BALL, INCHING RELIEF VALVE
볼 |
| 06.522 | SEAL AND GASKET KIT, TRANSMISSION
시일과가스켓킷 |
| 06.556 | DISTRIBUTOR, TRANSMISSION DIRECTION SEL OIL
디스트리뷰터 |
| 06.557 | SEAL, TRANSMISSION DIRECTION SELECTOR OIL DIST
시일 |
| 06.574 | GEAR & BEARING FORWARD
기어와베어링 |



CONVERTER HOUSING & CLUTCH ASSY

06.580	THRUST WASHER, REVERSE CLUTCH HUB & DRUM 트러스트와셔
06.581	BEARING, REVERSE GEAR 베어링
06.582	GEAR & BEARING, REVERSE 기어옥뿔어링
06.583	BEARING, REVERSE GEAR 베어링
06.598	BEARING, TRANSMISSION INTERMEDIATE SHAFT OUTER 베어링
06.599	SPACER, TRANSMISSION INTERMEDIATE SHAFT 스페이서
06.671	BEARING, DIRECTION SEL CL HUB 베어링
06.949	RETAINER, CLUTCH OIL DISTRIBUTION SLEEVE 리테이너
06.975	BEARING, REVERSE CLUTCH HUB (AXLE END) 베어링
20.100	TRANSAXLE ASSEMBLY 트랜스액슬
44.181	BEARING, CLUTCH SHAFT THRUST 베어링
44.360	TURBINE SHAFT, DRUM & CLUTCH ASSY 터빈샤프트




SPEED LIMIT INSTALLATION

06-143

08.521 SENSOR, TRANSMISSION SPEED TURBINE
센서

ASSEMBLY
COMPLETE 20.100



TRANSAXLE ASSEMBLY

06-144

05.000	CONVERTER ASSEMBLY, TORQUE 컨버터
05.001	GEAR, CONVERTER RING 기어
05.004	FASTENER, CONVERTER DRIVE & REINFORCING PLATE 패스너
05.141	ADAPTOR, CONVERTER DRIVE 어댑터
05.262	FASTENER, AXLE HOUSING TO CASE 패스너
05.263	FASTENER, CASE TO AXLE HOUSING 패스너
20.100	TRANSAXLE ASSEMBLY 트랜스액슬
20.403	GASKET, DIFFERENTIAL & CARRIER HOUSING 가스켓
20.544	SEAL, DRIVE AXLE SHAFT 시일



TRANSAXLE ASSEMBLY

20.554	FASTENER, DRIVE AXLE HUB CAP 패스너
20.586	SHAFT, DRIVE AXLE 샤프트
44.144	COVER, CONVERTER HOUSING 커버
95.426	FASTENER, CONVERTER DRIVE ADAPTOR 패스너
95.704	FASTENER, CONVERTER HOUSING PLATE 패스너




TRANSMISSION CASE AND DIFFERENTIAL ASSEM

ASSEMBLY COMPLETE 20.100

SEAL & GASKET KIT INCLUDES ITEMS MARKED "K" 06.522

DIFFERENTIAL ASSY INCLUDES ITEMS MARKED "D" 20.287



TRANSMISSION CASE AND DIFFERENTIAL


06-619

05.167	FASTENER, CONVERTER PUMP INLET LINE 패스너	20.240	SPACER, DIFFERENTIAL PINION BEARING 스페이서
05.168	LINE, CONVERTER PUMP INLET 라인	20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
06.279	BEARING, TRANSMISSION OUTPUT SHAFT 베어링	20.252	BEARING, DIFFERENTIAL PINION INNER 베어링
06.522	SEAL AND GASKET KIT, TRANSMISSION 시일과가스켓킷	20.264	CONE, DIFFERENTIAL BEARING 콘
06.657	SEAL, TRANS VALVE PRESS PUMP INLET LINE 시일	20.265	CUP, DIFFERENTIAL BEARING 컵
06.954	DOWEL, TRANSMISSION CASE TO CONVERTER 다웰	20.267	NUT, DIFFERENTIAL BEARING ADJUSTING 너트
06.964	RING, OUTPUT SHAFT GEAR LOCATING 링	20.269	FASTENER, DIFF BEARING ADJUSTING NUT LOCK 패스너
08.037	CASE, TRANSMISSION 케이스	20.279	FASTENER, DIFFERENTIAL CASE TO RING GEAR 패스너
09.005	GEAR, OUTPUT 기어	20.281	FASTENER, DIFF SIDE PINION PIN 패스너
13.010	CONTROL, CONVERTOR TEMPERATURE INDICATOR 컨트롤	20.282	SPIDER, DIFFERENTIAL PINION 스파이더
20.100	TRANSAXLE ASSEMBLY 트랜스액슬	20.283	GEAR, DIFFERENTIAL SIDE PINION 기어
20.203	NUT, DIFFERENTIAL PINION COMPANION FLANGE 너트	20.284	WASHER, DIFF SIDE PINION GEAR THRUST 와셔
20.232	CONE, DIFFERENTIAL PINION OUTER BEARING 콘	20.285	GEAR, DIFFERENTIAL SIDE 기어
20.233	CUP, DIFFERENTIAL PINION OUTER BEARING 컵	20.286	WASHER, DIFFERENTIAL SIDE GEAR THRUST 와셔
20.238	SHIM KIT, DIFFERENTIAL PINION BEARING CAGE 삼	20.287	CASE & GEAR ASSEMBLY, DIFFERENTIAL 케이스와기어



TRANSMISSION CASE AND DIFFERENTIAL ASSEM

44.352 SEAL, CONVERTOR TEMP INDICATOR CONTROL
시알




- | | |
|--------|---|
| 06.310 | SEAL, FORWARD CLUCH PISTON INNER
시일 |
| 06.311 | SEAL, FORWARD CLUTCH PISTON OUTER
시일 |
| 06.312 | PISTON, FORWARD CLUTCH
피스톤 |
| 06.314 | DISC, FORWARD CLUTCH INNER
디스크 |
| 06.315 | DISC, FORWARD CLUTCH OUTER
디스크 |
| 06.317 | PLATE, FORWARD CLUTCH DISC END
플레이트 |
| 06.430 | SPRING, FORWARD CLUTCH PISTON RETURN
스프링 |
| 06.434 | SHAFT & GEAR, CLUTCH DRIVE
샤프트와기어 |
| 06.577 | RETAINER, FORWARD CLUTCH SPRING
리테이너 |



TRANSMISSION CLUTCH PACK

06.579	FASTENER, REVERSE CLUTCH SPRING RETAINER 패스너
44.080	SEAL, FORWARD CLUTCH LUBRICATION PRESSURE PORT PLU 시일
44.101	THRUST WASHER, CLUTCH SHAFT PILOT BEARING 트러스트와셔
44.354	RING, CLUTCH PACK RETAINING 링
44.360	TURBINE SHAFT, DRUM & CLUTCH ASSY 터빈샤프트



05.076 PLUG, COOLER PORT (SMALL)
플러그

05.515 SPOOL, INCHING
스풀

06.400 CONTROL COVER & VALVE ASSEMBLY
컨트롤커버와밸브

06.420 GUIDE & STOP, SHUT-OFF VALVE SPRING
가이드와스톱

06.425 PLUG, CONTROL COVER OIL PASSAGE
플러그

06.426 PLUG, CONTROL COVER
플러그

06.472 PLUG, CONTROL VALVE HOUSING OIL PASSAGE
플러그

06.478 SPRING, INCHING PISTON RETURN
스프링

06.479 PISTON, INCHING
피스톤

06.480 SEAL, INCHING PISTON
시일

06.512 STOP, INCHING SPOOL
스톱

06.513 SPRING, INCHING VALVE
스프링

06.514 ROD, INCHING VALVE
로드

06.517 SEAL, INCHING VALVE PISTON PORT FITTING
시일

06.522 SEAL AND GASKET KIT, TRANSMISSION
시일과가스켓

06.540 SEAL, INCHING PISTON HOUSING
시일

06.830 STOP, PRESSURE REGULATING VALVE
스톱

06.832 SPRING, CLUTCH PRESSURE REGULATING VALVE
스프링

06.837 FASTENER, PRESSURE REGULATING VALVE STOP
패스너

06.838 STOP, INCHING VALVE
스톱

06.839 SEAL, INCHING VALVE STOP
시일

06.843 STOP, ACCUMULATOR PISTON
스톱

06.846 SPRING, ACCUMULATOR PISTON (INNER)
스프링

06.852 SPRING, ACCUMULATOR PISTON (OUTER)
스프링

09.494 SPRING, INCHING SPOOL RETURN
스프링

10.105 ELEMENT & GASKET, OIL FILTER
엘리먼트와가스켓

10.117 FITTING, OIL FILTER TO BASE
피팅

44.072 PLUG, MODULATION VALVE BODY
플러그


44.145 SPOOL, MODULATOR
스풀

44.146 SPRING, MODULATOR SPOOL
스프링




CONTROL COVER

44.148	SPOOL, ACCUMULATOR 스풀
44.345	SPOOL, CLUTCH PRESSURE REGULATOR 스풀
44.346	SPOOL, TRANS COOLER/LUBE OIL FILTER BY-PASS 스풀
44.347	SPRING, TRANS COOLER/LUBE OIL FILTER BY-PASS SPO 스프링
44.348	STOP, TRANS LUBE BY-PASS SPOOL SPRING 스톱
44.349	PIN, TRANS LUBE BY-PASS AND COOLER SEPARATOR 핀
44.350	SPOOL, TRANS LUBE BY-PASS RELIEF 스풀
44.351	SPRING, TRANS LUBE BY-PASS RELIEF SPOOL 스프링




07.007	FASTENER, TRANSMISSION MOUNTING BRACKET LH 패스너
07.012	FASTENER, TRANSMISSION TO ENGINE 패스너
07.013	FASTENER, TRANSMISSION TO ENGINE 패스너
20.100	TRANSAXLE ASSEMBLY 트랜스액슬



TRANSMISSION COOLING LINES

10-131


- | | |
|--------|---|
| 10.021 | FASTENER, COOLER OUTLET LINE CLAMP
패스너 |
| 10.056 | FITTING, COOLER OUTLET
피팅 |
| 10.084 | FITTING, COOLER INLET LINE
피팅 |
| 10.140 | CLAMP, COOLER LINE
클램프 |
| 10.225 | LINE, OIL COOLING
라인 |
| 10.226 | LINE, OIL COOLING
라인 |
| 10.231 | FITTING, OIL COOLING LINES
피팅 |



00.000	PRODUCTION ENGINE ASSEMBLY 엔진
01.854	SENSOR, ENGINE COOLANT TEMPERATURE 센서
01.886	SEAL, ENGINE COOLANT TEMPERATURE SENSOR 실
11.020	MOTOR ASSEMBLY, STARTING 모터
11.034	FASTENER, STARTING MOTOR 패스너
11.201	COIL, IGNITION 코일
11.203	FASTENER, COIL 패스너
11.250	SPARK PLUG 스파크
11.256	HARNESS, IGNITION COIL WIRING 하네스



62.138	SENSOR, ENGINE CRANKSHAFT POSITION 센서
62.140	FASTENER, ENGINE CRANKSHAFT POSITION SENSOR 패스너
62.169	SENSOR, ENGINE CAMSHAFT POSITION 센서
62.170	FASTENER, ENGINE CAMSHAFT POSITION SENSOR 패스너
62.171	SENSOR, ENGINE KNOCK 센서
62.172	FASTENER, ENGINE KNOCK SENSOR 패스너
62.173	SWITCH, ENGINE OIL PRESSURE 스위치



00.000	PRODUCTION ENGINE ASSEMBLY 엔진
12.016	FASTENER, GENERATOR THRU 패스너
12.019	BEARING, GENERATOR DRIVE END 베어링
12.029	SPACER, GENERATOR DRIVE END 스페이서
12.053	SUPPORT, GENERATOR MOUNTING BRACKET 서포트
12.107	FASTENER, ADJUSTING STRAP TO ALTERNATOR 패스너
12.152	BRACKET, ALTERNATOR ADJUSTING STRAP 브라켓
12.154	FASTENER, ALTERNATOR MOUNTING 패스너
12.171	HOUSING, ALTERNATOR RECTIFIER 하우징



ALTERNATOR ASSEMBLY

12.200	ALTERNATOR ASSEMBLY 알터네이터
12.201	FASTENER, ALTERNATOR PULLEY TO SHAFT 패스너
12.202	PULLEY, ALTERNATOR 폴리
12.212	FASTENER, ALTERNATOR DRIVE END BEARING RETAINER PL 패스너
12.214	ROTOR ASSEMBLY, ALTERNATOR 로터
12.216	STATOR ASSEMBLY, ALTERNATOR 스테이터
12.228	BEARING, ALTERNATOR SLIP RING FRAME END 베어링
12.313	COVER, ALTERNATOR BRUSH ACCESS 커버
12.316	REGULATOR, ALTERNATOR VOLTAGE OUTPUT 레귤레이터
12.317	RECTIFIER ASSEMBLY, ALTERNATOR 정류기
12.423	FASTENER, ADJUSTING STRAP TO ALTERNATOR 패스너
93.555	FASTENER, ALTERNATOR RECTIFIER HOUSING COVER 패스너




BATTERY MOUNTING

1	ALTERNATOR ASSEMBLY	12.200	16	TERMINAL, AL
2	FASTENER, ALTERNATOR PULLEY TO SHAFT	12.201	17	RECTIFIER ANI
3	KEY, ALTERNATOR PULLEY	12.203	18	DIODE, ALTERI
4	FAN, ALTERNATOR	12.243	19	MOUNT ASSEMBI
5	SPACER, ALTERNATOR FAN	12.245	20	RECTIFIER AS!
6	PULLEY, ALTERNATOR	12.202	21	BRUSH HOLDER,
7	FRAME, ALTERNATOR DRIVE END	12.205	22	BRUSH KIT, AI
8	BEARING, ALTERNATOR DRIVE END	12.209	23	FRAME, ALTERI
9	PLATE, ALTERNATOR DRIVE END BRG RET	12.211	24	FASTENER, THI
10	FASTENER, ALTERNATOR DR END RET PLATE	12.212	25	FASTENER, BRI
11	SPACER, ALTERNATOR DRIVE END	12.213	26	TERMINAL, AL
12	ROTOR ASSEMBLY, ALTERNATOR	12.214	27	BEARING, ALT
13	RING-SLIP, ALTERNATOR ROTOR	12.215	28	DIODE, ALTERI
14	STATOR ASSEMBLY, ALTERNATOR	12.216	29	CAPACITOR, A
15	TERMINAL PACKAGE, BATTERY	12.218		

12.009	SUPPORT, BATTERY 서포트
12.010	BATTERY 배터리
12.011	CLAMP, BATTERY HOLD DOWN 클램프
12.013	FASTENER, BATTERY HOLD DOWN (AT CLAMP) 패스너
12.049	FASTENER, BATTERY SUPPORT 패스너
14.025	CABLE, BATTERY TO STARTER 케이블
14.026	CABLE, BATTERY GROUND 케이블
14.042	FASTENER, BATTERY GROUND CABLE 패스너
14.147	CABLE, BATTERY NEGATIVE 케이블



97.272 FASTENER, CABLE & WIRE TO STARTER
*



ALTERNATOR ASSEMBLY

12-257

- 12.196 DIODE REC NEGATIVE
다이오드
- 12.197 DIODE REC POSITIVE
다이오드
- 12.200 ALTERNATOR ASSEMBLY
알터네이터
- 12.201 FASTENER, ALTERNATOR PULLEY TO SHAFT
패스너
- 12.202 PULLEY, ALTERNATOR
풀리
- 12.203 KEY, ALTERNATOR PULLEY
키
- 12.204 COLLAR, ALTERNATOR DRIVE END
칼라
- 12.205 FRAME, ALTERNATOR DRIVE END
프레임
- 12.209 BEARING, ALTERNATOR DRIVE END
베어링




ALTERNATOR

12.211	RETAINER, ALTERNATOR DRIVE END BEARING 리테이너
12.214	ROTOR ASSEMBLY, ALTERNATOR 로터
12.216	STATOR ASSEMBLY, ALTERNATOR 스테이터
12.225	INSULATOR, ALTERNATOR HEAT SINK 절연체
12.228	BEARING, ALTERNATOR SLIP RING FRAME END 베어링
12.230	FRAME, ALTERNATOR SLIP RING END 프레임
12.234	BRUSH HOLDER, ALTERNATOR 브러쉬홀더
12.243	FAN, ALTERNATOR 팬
12.276	RETAINER, SLIP RING FRAME END BEARING 리테이너
12.304	SEAL, ALTERNATOR HOUSING 시일
12.305	INSULATOR, ALTERNATOR BRUSH LEAD 절연체
12.313	COVER, ALTERNATOR BRUSH ACCESS 커버
12.316	REGULATOR, ALTERNATOR VOLTAGE OUTPUT 레귤레이터
12.368	INSULATOR, TERMINAL 절연체
12.373	SEAL, ALTERNATOR DRIVE END BEARING 시일
12.731	SEAL, ALTERNATOR DRIVE END BEARING 시일
92.322	LOCKWASHER, ALTERNATOR PULLEY FASTENER 로크와셔




KEY & DIRECTIONAL SWITCH INSTALLATION




- | | |
|--------|---|
| 13.047 | SWITCH, CIRCUIT LOCKING
스위치 |
| 14.238 | HARNESS, DIRECTION CONTROL SWITCH WIRING
하네스 |
| 14.502 | WIRE, IGNITION SWITCH TO ENGINE HARNESS
와이어 |
| 60.260 | KEY, CIRCUIT LOCKING SWITCH
키 |



HEAD LAMP INSTALLATION




- | | |
|--------|---------------------------------|
| 13.270 | HEADLAMP, ADJUSTABLE
헤드램프 |
| 14.018 | WIRE, HEADLIGHT
와이어 |
| 15.437 | HARNESS, HEADLAMP WIRING
하네스 |
| 18.100 | CLIP, HEAD LIGHT WIRE
클립 |
| 60.324 | BULB, HEADLAMP
전구 |



- | | |
|--------|--|
| 13.142 | SWITCH, BRAKE INTERLOCK
스위치 |
| 13.241 | BRACKET, HEAD LAMP
브라켓 |
| 13.243 | FASTENER, HEAD LAMP BRACKET
패스너 |
| 13.247 | FASTENER, TAIL LAMP ASSEMBLY
패스너 |
| 13.270 | HEADLAMP, ADJUSTABLE
헤드램프 |
| 13.299 | GUARD, HEADLIGHT
가드 |
| 13.330 | BRACKET, WARNING LIGHT
브라켓 |
| 13.331 | FASTENER, WARNING LIGHT BRACKET
패스너 |
| 13.332 | ASSEMBLY, WARNING LIGHT
경고등 |



13.335	FASTENER, WARNING LIGHT 패스너
13.660	LIGHT, TURN SIGNAL 라이트
13.673	BRACKET, TURN LIGHT 브라켓
14.182	WIRE, WARNING LIGHT 와이어
14.622	HARNESS, TOWING LIGHTS 하네스
15.437	HARNESS, HEADLAMP WIRING 하네스
15.714	FLASHER, UNIT 플래셔
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
18.007	FASTENER, HARNESS CLIP 패스너
39.689	MIRROR, REAR VIEW 미러
60.664	HARNESS, WARNING DEVICE 하네스
60.795	LIGHT, REAR WORK 라이트
94.082	NUT, HEADLAMP MOUNTING BRACKET FASTENER 너트
95.299	FASTENER, HEADLAMP GUARD 패스너
95.958	NUT, HEADLAMP GUARD FASTENER 너트



LED LIGHTS INSTALLATION


13-150

- | | |
|--------|------------------------------------|
| 13.241 | BRACKET, HEAD LAMP
브라켓 |
| 13.243 | FASTENER, HEAD LAMP BRACKET
패스너 |
| 13.270 | HEADLAMP, ADJUSTABLE
헤드램프 |
| 13.299 | GUARD, HEADLIGHT
가드 |
| 13.660 | LIGHT, TURN SIGNAL
라이트 |
| 13.673 | BRACKET, TURN LIGHT
브라켓 |
| 14.018 | WIRE, HEADLIGHT
와이어 |
| 15.437 | HARNESS, HEADLAMP WIRING
하네스 |
| 15.714 | FLASHER, UNIT
플래셔 |



LED LIGHTS INSTALLATION


18.007	FASTENER, HARNESS CLIP 패스너
60.664	HARNESS, WARNING DEVICE 하네스
60.795	LIGHT, REAR WORK 라이트
95.299	FASTENER, HEADLAMP GUARD 패스너
95.958	NUT, HEADLAMP GUARD FASTENER 너트



- | | |
|--------|--|
| 13.330 | BRACKET, WARNING LIGHT
브라켓 |
| 13.331 | FASTENER, WARNING LIGHT BRACKET
패스너 |
| 13.332 | ASSEMBLY, WARNING LIGHT
경고등 |



STROBE LIGHT




STROBE LIGHT

13-182

- | | |
|--------|--------------------------------|
| 13.332 | ASSEMBLY, WARNING LIGHT
경고등 |
| 13.333 | BULB, WARNING LIGHT
전구 |
| 60.821 | GLOBE, STROBE LIGHT
글로브 |
| 60.822 | BASE, STROBE LIGHT
베이스 |

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




STROBE LIGHT MOUNTING

13-183

- | | |
|--------|--|
| 13.330 | BRACKET, WARNING LIGHT
브라켓 |
| 13.331 | FASTENER, WARNING LIGHT BRACKET
패스너 |
| 13.332 | ASSEMBLY, WARNING LIGHT
경고등 |
| 60.664 | HARNESS, WARNING DEVICE
하네스 |



BACK-UP ALARM INSTALLATION




BACK-UP ALARM INSTALLATION

13-228

- | | |
|--------|--|
| 13.681 | FASTENER, WARNING DEVICE
패스너 |
| 42.001 | WARNING DEVICE, AUDIBLE (AIR OPER)
경보장치 |
| 42.011 | CLIP, AUDIBLE WARNING DEVICE CABLE
클립 |



HEAD & T/SIGNAL LIGHT INSTALLATION



HEAD & T/SIGNAL LIGHT INSTALLATION


13-230

13.270	HEADLAMP, ADJUSTABLE 헤드 램프
13.299	GUARD, HEADLIGHT 가드
13.660	LIGHT, TURN SIGNAL 라이트
13.661	BULB, TURN SIGNAL LIGHT 전구
13.673	BRACKET, TURN LIGHT 브라켓
15.436	HARNESS, RH HEADLAMP WIRING 하네스
15.437	HARNESS, HEADLAMP WIRING 하네스
15.714	FLASHER, UNIT 플래셔
60.324	BULB, HEADLAMP 전구



HEAD & T/SIGNAL LIGHT INSTALLATION

60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
95.299	FASTENER, HEADLAMP GUARD 패스너



13.206	BULB, BACK-UP LAMP 전구
13.217	FASTENER, COM STOP & TAIL LAMP ASSY MTG 패스너
13.218	BULB, STOP & TAIL LAMP 전구
13.330	BRACKET, WARNING LIGHT 브라켓
13.331	FASTENER, WARNING LIGHT BRACKET 패스너
13.332	ASSEMBLY, WARNING LIGHT 경고등
13.675	BULB, TURN LIGHT 전구
15.744	LAMP ASSEMBLY, COMBINATION STOP & TAIL 램프
60.795	LIGHT, REAR WORK 라이트




REAR ACCESSORY MOUNTING

60.797	GROMMET, REAR ACCESSORY WIRE 그롬멧
60.899	WIRING HARNESS, REAR ACCESSORY 옥J潔紵電謬
60.904	SWITCH, STROBE LIGHT 스J穎
60.922	BULB, REAR WORK LAMP 전구
60.923	BRACKET, REAR WORK LAMP MOUNTING 브라켓
60.960	HARNESS, REAR WORK LAMP EXTENSION *
60.962	SPACER, REAR WORK LAMP MOUNTING *
60.964	RELAY, FOOT BRAKE *



HEAD & T/SIGNAL LIGHT INSTALLATION



HEAD & T/SIGNAL LIGHT INSTALLATION

13-332


13.270	HEADLAMP, ADJUSTABLE 헤드 램프
13.299	GUARD, HEADLIGHT 가드
13.660	LIGHT, TURN SIGNAL 라이트
13.673	BRACKET, TURN LIGHT 브라켓
14.018	WIRE, HEADLIGHT 와이어
15.436	HARNESS, RH HEADLAMP WIRING 하네스
15.437	HARNESS, HEADLAMP WIRING 하네스
15.714	FLASHER, UNIT 플래셔
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서



95.299 FASTENER, HEADLAMP GUARD
패스너



HEAD & T/SIGNAL LIGHT INSTALLATION



HEAD & T/SIGNAL LIGHT INSTALLATION

13-338

- | | |
|--------|--|
| 13.270 | HEADLAMP, ADJUSTABLE
헤드 램프 |
| 13.284 | BRACKET, ADJUSTABLE HEADLAMP
브라켓 |
| 13.285 | FASTENER, ADJUSTABLE HEADLAMP BRACKET
패스너 |
| 13.299 | GUARD, HEADLIGHT
가드 |
| 13.660 | LIGHT, TURN SIGNAL
라이트 |
| 13.661 | BULB, TURN SIGNAL LIGHT
전구 |
| 13.673 | BRACKET, TURN LIGHT
브라켓 |
| 15.436 | HARNESS, RH HEADLAMP WIRING
하네스 |
| 15.437 | HARNESS, HEADLAMP WIRING
하네스 |




HEAD & T/SIGNAL LIGHT INSTALLATION

15.714	FLASHER, UNIT 플래셔
60.324	BULB, HEADLAMP 전구
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
60.773	HARNESS, TURN SIGNAL 하네스
95.299	FASTENER, HEADLAMP GUARD 패스너



KEY & DIRECTIONAL SWITCH INSTALLATION



KEY & DIRECTIONAL SWITCH INSTALLATION

13-344

- | | |
|--------|---|
| 11.008 | SWITCH, IGNITION CIRCUIT DELAY CONTROL
스위치 |
| 13.047 | SWITCH, CIRCUIT LOCKING
스위치 |
| 14.238 | HARNESS, DIRECTION CONTROL SWITCH WIRING
하네스 |
| 14.502 | WIRE, IGNITION SWITCH TO ENGINE HARNESS
와이어 |



ELECTRICAL WIRING (INSTRUMENT)

2	HARNESS, CONTROL CIRCUIT WIRING	14.050	16	CABLE, DRIVE
3	CLIP, CONTROL CIRCUIT WIRING HARNESS	18.025	17	CABLE, DRIVE
4	STRAP, HARNESS	18.027	18	CABLE, DRIVE
5	RECEPTACLE & CABLE, BATTERY	14.039	19	CABLE, DRIVE
6	RECEPTACLE, BATTERY CABLE	14.040	20	WIRE ASSEMBLY
7	WIRE ASSEMBLY, PUMP SOLENOID TO VALVE	14.163	21	FASTENER, BAT
8	WIRE ASSEMBLY, PUMP SOLENOID JUMPER	14.164	22	PLATE, RECEP1
9	WIRE ASSEMBLY, PUMP SOL TO PUMP MOTOR	14.047	23	FASTENER, REC
0	CABLE, BATTERY NEGATIVE	14.147	24	WIRE, DRIVE M
1	CABLE, RESISTOR TO B7	14.148	25	WIRE, PLUGGIN
2	WIRE ASSEMBLY, RESISTOR TO H/SPD CONT	14.221	26	WIRE, DIODE 1
3	WIRE ASSEMBLY, RESISTOR TO H/SPD CONT	14.257	27	WIRE, DIODE 1
4	CABLE, DRIVE MOTOR (A2)	14.087	28	CONNECTOR, AL
5	CABLE, DRIVE MOTOR (A1)	14.086		

13.000	PANEL, INSTRUMENT CLUSTER 판넬
13.003	HORN 혼
13.004	FASTENER, HORN MOUNTING BRACKET 패스너
13.079	FASTENER, INSTRUMENT CLUSTER TO INST PANEL 패스너
14.352	FUSE, CONTROL CIRCUIT 퓨즈
15.433	GROMMET, CONTROL CIRCUIT WIRING HARNESS 그로멧
15.447	DIODE, HARNESS 다이오드
15.640	WIRING HARNESS, MACHINE COWL 와이어하네스
15.710	RELAY, ELECTRICAL 릴레이



ELECTRICAL WIRING (INSTRUMENT)

18.009	FASTENER, HARNESS CLIP 패스너
18.010	CLIP, HARNESS 클립
18.011	FASTENER, HARNESS CLIP 패스너
18.012	CLIP, WIRE HARNESS 클립
18.014	CLIP, HARNESS 클립
18.020	CLIP, HARNESS 클립
60.383	GROMMET, CONTROL CIRCUIT WIRING HARNESS 그로멧
65.289	BODY, FUSE BOX *
65.832	COVER, FUSE BOX 커버
95.009	FASTENER, FUSE BOX MOUNTING 패스너




ELECTRICAL WIRING (MAIN)

201	COIL, IGNITION	14.002	WIRE, HOUR ME
250	SPARK PLUG	14.003	FUSE, HORN
301	REGULATOR, VOLTAGE	14.004	FUSE, MAIN
301	RELAY, HORN	14.025	CABLE, BATTER
303	HORN	14.026	CABLE, BATTER
304	FASTENER, HORN	14.031	KIT, HIGH TEN
311	CONTROL, ENGINE TEMPERATURE INDICATOR	14.114	HARNESS, MACH
313	CONTROL, ENGINE OIL PRESSURE INDICATOR	14.572	RESISTOR, ALT
315	CONTROL, ENGINE HOUR METER	14.787	FUSE, ACCESS

01.854	SENSOR, ENGINE COOLANT TEMPERATURE 센서
11.001	RELAY, STARTER 릴레이
11.002	FASTENER, STARTER RELAY 패스너
13.688	RELAY, ENGINE CONDITION SIGNAL 릴레이
14.114	HARNESS, MACHINE WIRING 하네스
15.447	DIODE, HARNESS 다이오드
18.000	CLIP, WIRING HARNESS 클립
18.001	FASTENER, WIRING HARNESS CLIP 패스너
18.002	CLIP, WIRING HARNESS 클립




18.008	CLIP, WIRING HARNESS 클립
97.271	FASTENER, CABLE & WIRE TO ALTERNATOR *



STATIC STRAP

14-438


- 39.417 GROUND STRAP, ELECTRIC TRUCK
접지케이블
- 39.418 FASTENER, ELECTRIC TRUCK GROUND STRAP
패스너



12.100	BRACKET, ALTERNATOR MOUNTING 브라켓	15.646	HARNESS, ENGINE DISCONNECT 하네스
12.101	FASTENER, ALTERNATOR BRACKET 패스너	15.647	CABLE, DISCONNECT SWITCH TO STARTER 케이블
12.103	FASTENER, ALTERNATOR TO BRACKET 패스너	15.648	FASTENER, DISCONNECT SWITCH MOUNTING BRACKET 패스너
12.107	FASTENER, ADJUSTING STRAP TO ALTERNATOR 패스너	15.650	CABLE, DISCONNECT SWITCH TO KNOB 케이블
12.148	SPACER, ALTERNATOR MOUNTING 스페이서	15.651	BRACKET, DISCONNECT SWITCH MOUNTING 브라켓
12.152	BRACKET, ALTERNATOR ADJUSTING STRAP 브라켓	15.652	FASTENER, DISCONNECT SWITCH CLAMP ?스너
12.154	FASTENER, ALTERNATOR MOUNTING 패스너	15.653	CLAMP, DISCONNECT SWITCH CABLE 클램프
12.200	ALTERNATOR ASSEMBLY 알터네이터	15.654	FASTENER, DISCONNECT SWITCH BRACKET TO LEVER 패스너
13.470	SWITCH, DISCONNECT 스위치	15.656	PIN, DISCONNECT SWITCH CABLE LEVER 핀
14.336	HARNESS, ALTERNATOR 하네스	15.657	LEVER, DISCONNECT SWITCH ACTUATING 레버
14.352	FUSE, CONTROL CIRCUIT 퓨즈	15.823	BRACKET, CIRCUIT SWITCH RELAY PROTECTION *
14.431	CABLE, BATTERY TO DISCONNECT SWITCH 케이블	15.824	COVER, CIRCUIT SWITCH RELAY PROTECTION *
15.447	DIODE, HARNESS 다이오드	15.825	COVER, ENGINE CONDITION RELAY PROTECTION *
15.640	WIRING HARNESS, MACHINE COWL 와이어 하네스	15.826	COVER, ENGINE CONDITION RELAY PROTECTION *
15.645	KNOB, DISCONNECT SWITCH ACTUATING 노브	18.019	FASTENER, BATTERY CABLE CLIP 패스너



18.088	CLAMP, BATTERY CABLE 클램프
40.024	PLATE, UNDERWRITERS LABEL 플레이트
40.025	FASTENER, UNDERWRITERS LABEL PLATE 패스너
40.180	DECAL, BATTERY DISCONNECT SWITCH 데칼
40.243	DECAL, LPS 데칼
65.289	BODY, FUSE BOX *
65.832	COVER, FUSE BOX 커버
97.174	FASTENER, CIRCUIT SWITCH RELAY PROTECTION *
97.175	FASTENER, CIRCUIT SWITCH RELAY PROTECTION *
97.176	FASTENER, ENGINE CONDITION RELAY PROTECTION *




20.100	TRANSAXLE ASSEMBLY 트랜스액슬
20.386	WASHER, DRIVE AXLE HUB SEAL 와셔
20.513	RETAINER, DRIVE AXLE HUB BEARING 리테이너
20.514	LOCKPLATE, DRIVE AXLE HUB BEARING RETAINER 로크플레이트
20.539	SUPPORT, DRIVE AXLE SPINDLE (RH) 서포트
20.540	SUPPORT, DRIVE AXLE SPINDLE (LH) 서포트
20.571	CONE, DRIVE AXLE HUB OUTER BEARING 콘
20.575	CUP, DRIVE AXLE HUB OUTER BEARING 컵
20.581	HUB ASSEMBLY, DRIVE AXLE 히브



DRIVE AXLE

20.582	HUB, DRIVE WHEEL 허브
20.602	SEAL, DRIVE AXLE HUB INNER OIL 시일
20.608	CONE, DRIVE AXLE HUB INNER BEARING 콘
20.612	CUP, DRIVE AXLE HUB INNER BEARING 컵
20.627	VENT, DIFFERENTIAL & AXLE 벤트
20.859	HOUSING, DRIVE AXLE 하우징
23.244	BRAKE ASSEMBLY, RH DRIVE WHEEL 브레이크
23.245	BRAKE ASSEMBLY, LH DRIVE WHEEL 브레이크
23.246	FASTENER, BRAKE ASSEMBLY 패스너
23.730	FASTENER, BRAKE ASSEMBLY 패스너



22.088 RETAINER, PARKING BRAKE LINKAGE LEVER FULCRUM
리테이너

22.195 CUP, BRAKE SHOE GUIDE
컵

22.202 PIN, BRAKE CABLE CLEVIS
핀

22.280 SPRING, BRAKE SHOE GUIDE PIN
스프링

22.898 CABLE, PARKING BRAKE DRAW - LH
케이블

22.900 CABLE, PARKING BRAKE DRAW - RH
케이블

23.048 SPRING, PARKING BRAKE OPERATING ARM ANTI-RATTLE
스프링

23.214 CYLINDER ASSEMBLY, LH BRAKE
실린더

23.223 BLEEDER, BRAKE WHEEL CYLINDER
블리더

23.237 COVER, RH BRAKE ADJUSTOR
커버

23.242 PLATE, LH BRAKE BACKING
플레이트

23.243 PLATE, RH BRAKE BACKING
플레이트

23.244 BRAKE ASSEMBLY, RH DRIVE WHEEL
브레이크

23.245 BRAKE ASSEMBLY, LH DRIVE WHEEL
브레이크

23.247 SHOE SET, BRAKE LINING
슈

23.249 SPRING, LH BRAKE RETURN
스프링

23.258 FASTENER, LH WHEEL CYLINDER
패스너

23.292 ANCHOR, BRAKE SHOE
앵커

23.342 FASTENER, BRAKE SPRING ANCHOR
패스너

23.346 ARM, PARKING BRAKE
암

23.389 RETAINER, PARKING BRAKE CABLE
리테이너

23.475 ADJUSTOR, BRAKE SHOE
어드저스터

23.546 CABLE, BRAKE ADJUSTOR (RH)
케이블

23.550 LEVER, BRAKE ADJUSTOR (LH)
레버

23.551 LEVER, BRAKE ADJUSTOR (RH)
레버

23.552 SPRING, BRAKE ADJUSTOR (LH)
스프링

23.553 SPRING, BRAKE ADJUSTOR (RH)
스프링

23.698 LEVER, PARKING BRAKE OPERATING LH
레버

23.699 ARM, BRAKE ADJUSTOR REACTION LH
암


23.735 SHOE & LINING SET, BRAKE
슈와라이닝



BRAKE ASSEMBLY

23.738	SPRING, BRAKE SHOE RETURN (RH) 스프링
23.747	SPRING, BRAKE SHOE RETURN (LH) 스프링
23.762	ARM, PARKING BRAKE OPERATING 암
23.776	SHEAVE, PARKING BRAKE CABLE 쉬브
24.336	ADJUSTOR, BRAKE SHOE LH 어드저스터

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



DRIVE WHEEL & TIRE MOUNTING


22-013

- | | |
|--------|---|
| 23.030 | DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠타이어 |
| 23.335 | FASTENER, DRIVE WHEEL
패스너 |



DRIVE WHEEL & TIRE (CUSHION TYPE)

ASSEMBLY
COMPLETE — 23.030



DRIVE WHEEL & TIRE (CUSHION)


22-035

- | | |
|--------|---|
| 22.989 | TIRE ASSEMBLY, DRIVE
* |
| 23.009 | RIM ASSEMBLY, DRIVE WHEEL
립 |
| 23.030 | DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠타이어 |



STEER WHEEL & TIRE (CUSHION TYPE)

ASSEMBLY
COMPLETE — 23.031




STEER WHEEL & TIRE (CUSHION)

22-036

22.990	TIRE ASSEMBLY, STEER *
23.000	RIM ASSEMBLY, STEER WHEEL 립
23.031	STEER WHEEL AND TIRE ASSEMBLY 휠


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



STEER WHEEL & TIRE MOUNTING

22-037


22.658	SEAL, STEER WHEEL 시일
23.031	STEER WHEEL AND TIRE ASSEMBLY 휠
26.139	CONE, STEER WHEEL HUB BEARING (OUTER) 콘
26.140	WASHER, STEER WHEEL HUB BEARING THRUST 와셔
26.141	FASTENER, STEER WHEEL HUB 패스너
26.143	CAP, STEER WHEEL HUB 캡
92.505	COTTER, STEER WHEEL HUB FASTENER 커터



- | | |
|--------|---|
| 22.082 | BRACKET, BRAKE CABLE (BRAKE END)
브라켓 |
| 22.083 | FASTENER, BRAKE CABLE BRACKET (BRAKE END)
패스너 |
| 22.122 | FASTENER, BRAKE PEDAL PIVOT RETAINER
패스너 |
| 22.201 | CABLE, INCHING
케이블 |
| 23.051 | FASTENER, MASTER CYLINDER MOUNTING BRACKET
패스너 |
| 23.100 | PEDAL, BRAKE
페달 |
| 23.101 | SHAFT, BRAKE PEDAL
샤프트 |
| 23.105 | BEARING, BRAKE PEDAL
베어링 |
| 23.114 | PAD & FASTENER, BRAKE PEDAL
패드와패스너 |



23.136	SPRING, BRAKE PEDAL RETURN 스프링
23.145	FASTENER, BRAKE PEDAL SHAFT 패스너
23.150	CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE 실린더
23.156	FASTENER, CYLINDER & TANK ATTACHING 패스너
23.434	BRACKET, BRAKE PEDAL PIVOT 브라켓
23.439	PEDAL, INCHING 페달
23.440	PAD & FASTENER, INCHING PEDAL 패드와패스너
23.533	FASTENER, BRAKE LINK CLEVIS 패스너
23.538	ARM, BRAKE LINKAGE PIVOT 암
23.540	FASTENER, BRAKE LINKAGE PIVOT ARM 패스너
23.658	BEARING, BRAKE PEDAL LINK 베어링
23.665	SPRING, INCHING PEDAL RETURN 스프링
23.786	FASTENER, INCHING BRAKE PEDAL 패스너
23.924	LINK, BRAKE ADJUSTOR 링크
23.926	LINK, BRAKE ADJUSTOR 링크
24.379	LINK, INCHING 링크



UNITROL PEDAL MOUNTING

23-460


- | | |
|--------|---|
| 13.142 | SWITCH, BRAKE INTERLOCK
스위치 |
| 22.011 | COVER, BRAKE LINE REEL HOUSING
커버 |
| 22.023 | FASTENER, BRAKE LINE REEL
패스너 |
| 22.338 | CLAMP, BRAKE FLUID RESERVOIR
클램프 |
| 22.357 | CAP, BRAKE FLUID RESERVOIR
캡 |
| 22.452 | CLAMP, BRAKE MASTER CYLINDER FILLER LINE
클램프 |
| 22.528 | BLEEDER, BRAKE LINES ADAPTOR
블리더 |
| 22.627 | TEE, BRAKE LINE
티 |
| 22.951 | FASTENER, BRAKE LINE CLAMP
패스너 |



23.173	FITTING, BRAKE MASTER CYLINDER OUTLET 피팅
23.176	GASKET, BRAKE MASTER CYLINDER OUTLET FTG BOLT 가스켓
23.186	LINE, BRAKE MASTER CYLINDER OUTLET 라인
23.207	LINE, LH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
23.208	LINE, RH DRIVE WHEEL BRAKE CYLINDER TO TEE 라인
23.792	RESERVOIR, BRAKE FLUID 리저버
23.793	FASTENER, BRAKE FLUID RESERVOIR 패스너
23.794	LINE, BRAKE MASTER CYLINDER INLET 라인
23.906	CLAMP, BRAKE MASTER CYLINDER LINE 클램프

PARKING BRAKE SYSTEM

23-545




- 23-545 (1)



PARKING BRAKE LINKAGE

22.860	PEDAL, PARKING BRAKE 페달
22.895	FASTENER, PARKING BRAKE PEDAL PIVOT RETAINER 패스너
23.264	BRAKE ASSEMBLY, PARKING 브레이크
23.269	FASTENER, PARKING BRAKE LEVER 패스너
23.284	FASTENER, PARKING BRAKE CABLE BRACKET 패스너
23.410	BEARING, PARKING BRAKE CAM ROLLER 베어링
23.481	LEVER, PARKING BRAKE RELEASE 레버
23.482	SPRING, PARKING BRAKE RELEASE LEVER 스프링
23.483	PIVOT, PARKING BRAKE RELEASE LEVER 피봇
23.489	PIVOT, PARKING BRAKE RELEASE LEVER 피봇
23.571	BUMPER, PARKING BRAKE LEVER 범퍼
23.638	ANCHOR, PARKING BRAKE CABLE 앵커
23.639	FASTENER, PARKING BRAKE CABLE ANCHOR 패스너
23.767	SPRING, PARKING BRAKE DRAW 스프링
23.851	LINK, PARKING BRAKE 링크
23.918	FASTENER, PARKING BRAKE PEDAL PIVOT BRACKET 패스너
23.959	FASTENER, PARKING BRAKE RELEASE VALVE 패스너
92.855	NUT, PARKING BRAKE FASTENER 너트

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



STEER COLUMN & GEAR MOUNTING

25-050

- | | |
|--------|--|
| 05.185 | BASE, DIRECTIONAL SELECTOR LEVER
베이스 |
| 06.101 | LEVER ASSEMBLY, FORWARD & REVERSE
레버 |
| 13.110 | SWITCH, DIRECTIONAL CONTROL (FORWARD)
스위치 |
| 13.111 | FASTENER, DIRECTIONAL CONTROL SWITCH
패스너 |
| 13.130 | FASTENER, DIRECTION CONTROL LEVER
패스너 |
| 13.655 | SWITCH, TURN INDICATOR
스위치 |
| 13.656 | BRACKET, TURN INDICATOR SWITCH
브라켓 |
| 25.034 | FASTENER, STEERING GEAR ATTACHING
패스너 |
| 25.150 | GEAR BOX ASSEMBLY, STEERING
기어박스 |



STEER COLUMN & GEAR MOUNTING

25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트와컬럼
25.785	FASTENER, TILT STEERING SHAFT & COLUMN ASSEMBLY 패스너
40.002	LEGEND, SHIFT PATTERN 범례
40.069	DECAL, FORWARD-BACKWARD 드칼
44.250	DIRECTIONAL CONTROL ASSEMBLY 방향컨트롤
44.251	HOUSING, DIRECTIONAL CONTROL ASSEMBLY 하우징
44.252	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING 커버
44.254	FASTENER, DIRECTIONAL CONTROL ASSY HOUSING COVER 패스너
44.255	SEAL, DIRECTIONAL CONTROL ASSY LEVER 시일
44.356	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING REAR 커버
60.483	RETAINER, DIRECTIONAL CONTROL LEVER 리테이너
60.686	RING, HORN CONTACT 링
60.773	HARNESS, TURN SIGNAL 하네스
60.951	GROMMET, TURN INDICATOR SWITCH 그로멧
67.017	FASTENER, DIRECTIONAL CONTROL DETENT SUPPORT 패스너
67.018	SPRING, DIRECTIONAL CONTROL DETENT 스프링
96.000	FASTENER, TURN INDICATOR SWITCH 패스너




STEERING UNIT

ASSEMBLY COMPLETE — 25.150

SEAL KIT INCLUDES ITEMS MARKED "K" — 25.109

NEEDLE BEARING KIT INCLUDES ITEMS MARKED "R" — 25.972




STEERING UNIT

25-076

- | | |
|--------|-------------------------------------|
| 25.109 | KIT, STEER GEAR SEAL
킷 |
| 25.150 | GEAR BOX ASSEMBLY, STEERING
기어박스 |
| 25.972 | BEARING KIT, STEERING GEAR
* |

ASSEMBLY
COMPLETE 25.770



STEERING COLUMN


25-144

25.010	JACKET, STEERING COLUMN 자켓
25.030	SHAFT ASSEMBLY, STEERING COLUMN 샤프트
25.130	FASTENER, DIRECTIONAL ASSEMBLY 패스너
25.137	KEY, DIRECTIONAL ASSEMBLY 키
25.141	SHAFT, STEERING GEAR 샤프트
25.332	YOKE, STEER UNIVERSAL JOINT CLAMP 요크
25.769	SPRING, STEERING COLUMN TILTING (LOWER) 스프링
25.770	SHAFT & COLUMN ASSY, POWER STEERING (TILT) 샤프트와컬럼
25.771	SHAFT, STEERING COLUMN (TILT) 샤프트



STEERING COLUMN

25.772	RETAINER, STEERING COLUMN SHAFT 리테이너
25.841	BUSHING, STEERING GEAR SHAFT 부싱
25.933	FASTENER, STEERING COLUMN 패스너
37.344	SPRING, STEERING COLUMN TILTING 스프링
37.348	PYLON, STEERING COLUMN 파일런




14.060	WIRE, HORN BUTTON TERM TO CONNECTOR 와이어
25.002	HORN BUTTON KIT 혼버튼킷
25.003	NUT, HANDWHEEL 너트
25.004	HAND WHEEL, STEERING GEAR 핸드휠
25.190	FASTENER, HORN BUTTON 패스너
25.219	KNOB, STEERING HAND WHEEL SPINNER 노브
25.221	FASTENER, STEERING SPINNER KNOB 패스너
25.222	CAP, STEERING SPINNER KNOB 캡
25.778	WIRE, CONTACT HORN 와이어



STEERING WHEEL MOUNTING


25.779	CONTACT, HORN 컨택트
25.780	HORN BUTTON 혼버튼
90.453	WASHER, STEERING SPINNER KNOB FASTENER 와셔
96.358	WASHER, STEERING HANDWHEEL SPINNER KNOB FASTENER 와셔
96.695	FASTENER, WIRE MOUNTING 패스너
96.756	WASHER, WIRE MOUNTING FASTENER 와셔



- | | |
|--------|--|
| 05.185 | BASE, DIRECTIONAL SELECTOR LEVER
베이스 |
| 13.130 | FASTENER, DIRECTION CONTROL LEVER
패스너 |
| 13.656 | BRACKET, TURN INDICATOR SWITCH
브라켓 |
| 14.184 | WIRE, WARNING LIGHT SWITCH FEED
와이어 |
| 17.905 | GASKET, DIRECTION SWITCH MOUNTING
가스켓 |
| 19.302 | ACTUATOR, DIRECTION SWITCH
액츄에이터 |
| 25.770 | SHAFT & COLUMN ASSY, POWER STEERING (TILT)
샤프트와컬럼 |
| 38.255 | CAP, STEERING GEAR MOUNTING
캡 |
| 40.002 | LEGEND, SHIFT PATTERN
범례 |



44.251	HOUSING, DIRECTIONAL CONTROL ASSEMBLY 하우징
44.252	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING 커버
44.254	FASTENER, DIRECTIONAL CONTROL ASSY HOUSING COVER 패스너
44.356	COVER, DIRECTIONAL CONTROL ASSEMBLY HOUSING REAR 커버
60.483	RETAINER, DIRECTIONAL CONTROL LEVER 리테이너
94.341	FASTENER, HORN CONTACT 패스너
96.126	NUT, DIRECTION SWITCH FASTENER 너트




26.000	CYLINDER ASSEMBLY, STEERING 실린더
26.086	FASTENER, STEERING CYLINDER ANCHOR END 패스너
26.100	AXLE ASSEMBLY, STEERING 스티어액슬
26.119	AXLE, STEER 액슬
26.124	SHIM, STEER AXLE KNUCKLE 심
26.125	PIN, STEER AXLE KNUCKLE 핀
26.129	FITTING - LUB, STEER AXLE KNUCKLE 피팅
26.130	BEARING, STEER AXLE KNUCKLE PIN 베어링
26.131	BEARING, STEER AXLE KNUCKLE PIN LOWER 베어링



STEER AXLE ASSEMBLY

26.132	KNUCKLE, STEER AXLE (RH) 너트
26.148	KNUCKLE, STEER AXLE (LH) 너트
26.190	SEAL, STEER AXLE KNUCKLE OIL 시일
26.239	SEAL, STEER AXLE FORK COVER 시일
26.290	RETAINER, STEER AXLE KNUCKLE PIN LOWER BEARING 리테이너
26.337	LOCATOR, STEER AXLE KNUCKLE PIN 로케이터
26.338	PIN, STEERING ARM 핀
26.339	LUB-FITTING, STEERING ARM 윤활피팅
26.340	BEARING, STEERING ARM PIN 베어링
26.348	LOCATOR, STEER CYLINDER 로케이터
26.351	WASHER, STEERING ARM PIN 와셔
26.417	ARM, STEERING 암
92.507	WASHER, STEERING ARM FASTENER 와셔
94.853	FASTENER, STEER AXLE KNUCKLE PIN 패스너
94.854	COTTER, STEER AXLE KNUCKLE PIN FASTENER 커터
94.855	RETAINER, STEERING ARM PIN 리테이너




HYDRAULIC RETURN LINES

26-225


28.033	FITTING, SUMP RETURN 피팅
28.259	FITTING, SUMP RETURN LINE 피팅
28.506	LINE, SUMP RETURN 라인
31.387	CLAMP, MAIN VALVE TO SUMP LINE 클램프
31.445	FITTING, MAIN VALVE TO FILTER LINE 피팅
31.595	CLAMP, SUMP RETURN LINE FITTING 클램프
31.827	LINE, FILTER INLET 라인



STEER CYLINDER



26.000	CYLINDER ASSEMBLY, STEERING 실린더
26.003	SEAL KIT, PISTON ROD 시일킷
26.089	BARREL, STEERING CYLINDER 배럴
26.090	STEER CYLINDER PISTON 피스톤
26.093	GLAND, STEERING CYLINDER 그랜드
26.099	BUSHING, STEERING CYLINDER GLAND 부싱



STEERING LINES


26-306

28.052	FITTING, STEERING GEAR 피팅
28.055	FITTING, STEERING GEAR 피팅
28.272	LINE, STEER CYLINDER INLET 라인
28.279	LINE, STEER CYLINDER INLET 라인
31.479	CLAMP, STEERING LINES 클램프
31.664	LINE, STEERING CYLINDER ANCHOR PORT 라인
31.668	LINE, STEERING CYLINDER ROD PORT 라인
31.669	FITTING, STEERING CYLINDER ROD PORT 피팅
31.793	CLAMP, POWER STEERING LINES 클램프



94.662	FASTENER, POWER STEERING LINES CLAMP 패스너
94.665	FASTENER, POWER STEERING LINES CLAMP 패스너


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



STEER AXLE MOUNTING

26-307

- | | |
|--------|---|
| 26.100 | AXLE ASSEMBLY, STEERING
스티어액슬 |
| 26.174 | SILENT BLOCK, AXLE MOUNTING (REAR)
사일런트블록 |
| 26.175 | FASTENER, SILENT BLOCK TO FRAME (REAR)
패스너 |
| 38.047 | BRACKET, STEER AXLE MOUNTING
브라켓 |



- | | |
|--------|---|
| 05.061 | RING-RETAINING, BEARING LOCATING
링 |
| 05.062 | RING-RETAINING, PUMP SHAFT BEARING
링 |
| 05.173 | FASTENER, CONVERTER PUMP COVER
패스너 |
| 29.028 | SEAL KIT, HYDRAULIC UNIT PUMP
시일킷 |
| 29.100 | PUMP ASSEMBLY, HYDRAULIC
펌프 |
| 29.102 | SEAL, PUMP SHAFT
시일 |
| 29.173 | KEY, PUMP GEAR
키 |
| 29.186 | SEAL, PUMP SHAFT
시일 |
| 29.198 | FASTENER, PUMP HOUSING
패스너 |



29.205	SEAL, PUMP SHAFT 시일
--------	------------------------

Exploded view diagram of a mechanical assembly. The diagram shows the following components and their part numbers:

- 29.605: A small cylindrical component shown in a dashed circle at the top left.
- 29.786: A small cylindrical component at the top left, below 29.605.
- 29.788: A small cylindrical component below 29.786.
- 31.163: A small cylindrical component below 29.788.
- 29.386: A long, curved hose or pipe extending from the top left towards the center.
- 29.768: A group of several small pins or screws located in the center of the assembly.
- 29.728: A small cylindrical component on the right side.
- 29.893: A small cylindrical component below 29.728.
- 29.766: A bracket grouping 29.728 and 29.893.
- 29.809: A long, thin rod or pin on the right side.
- 29.738: A large cylindrical component in the middle left area.
- 29.767: A circular component with multiple holes, located in the center.
- 29.798: A cylindrical component on the bottom right.

29-237


29.386	LINE, SUMP BREATHER 라인
29.605	FILTER, AIR BREATHER 필터
29.728	CAP, HYDRAULIC SUMP FILLER 캡
29.738	FILTER ASSEMBLY, HYDRAULIC SUMP 필터
29.766	COVER, SUMP TANK 커버
29.767	SEAL, SUMP TANK COVER 시일
29.768	FASTENER, SUMP TANK COVER 패스너
29.786	FASTENER, SUMP BREATHER 패스너
29.788	BREATHER, SUMP 브리더



HYDRAULIC TANK & COMPONENTS MOUNTING

29.798	SCREEN, HYDRAULIC SUMP PRE FILTER 스크린
29.809	DIPSTICK, SUMP LEVEL 딤스틱
29.893	PLATE, HYDRAULIC SUMP 플레이트
31.163	CLAMP, SUMP RETURN LINE 클램프

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



HYDRAULIC VALVE MOUNTING (2 SPOOL)

30-209


30.000	VALVE ASSEMBLY, HYDRAULIC 벨브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.362	FASTENER, VALVE MOUNTING PLATE 패스너
30.442	SPACER, CONTROL LEVERS 스페이서



HYDRAULIC VALVE MOUNTING (2SPOOL)

30.787	BOOT, VALVE CONTROL LEVER 부트
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드

HYDRAULIC VALVE MOUNTING (3SPOOL)



30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.362	FASTENER, VALVE MOUNTING PLATE 패스너
30.442	SPACER, CONTROL LEVERS 스페이서




HYDRAULIC VALVE MOUNTING (3SPOOL)

30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.083	CAP, VALVE CONTROL LEVER DECAL 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드



HYDRAULIC VALVE MOUNTING (4SPOOL)



30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀
30.089	LEVER, LIFT CONTROL 레버
30.090	LEVER, TILT CONTROL 레버
30.094	KNOB, LIFT CONTROL LEVER 노브
30.097	KNOB, TILT CONTROL LEVER 노브
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.362	FASTENER, VALVE MOUNTING PLATE 패스너




HYDRAULIC VALVE MOUNTING (4SPOOL)

30.642	CAP, AUXILIARY VALVE SPOOL 캡
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.083	CAP, VALVE CONTROL LEVER DECAL 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드



MAIN CONTROL VALVE 3-SPOOL(PUSH BUTTON)



- 13.034 CLIP, VALVE SWITCH WIRING HARNESS
*
- 13.035 RELAY, VALVE SWITCH WIRING HARNESS
*
- 15.339 HARNESS, AUXILIARY VALVE SWITCH WIRING
하네스
- 30.000 VALVE ASSEMBLY, HYDRAULIC
벨브
- 30.033 FASTENER, HYDRAULIC VALVE MOUNTING
패스너
- 30.087 PIN, VALVE CONTROL LEVER PIVOT
핀
- 30.089 LEVER, LIFT CONTROL
레버
- 30.090 LEVER, TILT CONTROL
레버
- 30.094 KNOB, LIFT CONTROL LEVER
노브




MAIN CONTROL VALVE 3-SPOOL(PUSH BUTTON)

30.097	KNOB, TILT CONTROL LEVER 노브
30.362	FASTENER, VALVE MOUNTING PLATE 패스너
30.442	SPACER, CONTROL LEVERS 스페이서
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
32.137	BRACKET, INSTRUMENT MOUNTING 브라켓
32.138	SWITCH, PUSH BUTTON 스위치
39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.083	CAP, VALVE CONTROL LEVER DECAL 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터



MAIN CONTROL VALVE 4-SPOOL(PUSH BUTTON)



- 13.034 CLIP, VALVE SWITCH WIRING HARNESS
*
- 13.035 RELAY, VALVE SWITCH WIRING HARNESS
*
- 15.339 HARNESS, AUXILIARY VALVE SWITCH WIRING
하네스
- 30.000 VALVE ASSEMBLY, HYDRAULIC
밸브
- 30.033 FASTENER, HYDRAULIC VALVE MOUNTING
패스너
- 30.087 PIN, VALVE CONTROL LEVER PIVOT
핀
- 30.089 LEVER, LIFT CONTROL
레버
- 30.090 LEVER, TILT CONTROL
레버
- 30.094 KNOB, LIFT CONTROL LEVER
노브




MAIN CONTROL VALVE 4-SPOOL(PUSH BUTTON)

30.097	KNOB, TILT CONTROL LEVER 노브
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.362	FASTENER, VALVE MOUNTING PLATE 패스너
30.642	CAP, AUXILIARY VALVE SPOOL 캡
30.787	BOOT, VALVE CONTROL LEVER 부트
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버
32.138	SWITCH, PUSH BUTTON 스위치
49.042	CAP, TILT CONTROL LEVER 캡
49.081	CAP, LIFT CONTROL LEVER 캡
49.082	CAP, LIFT CONTROL LEVER 캡
49.102	FASTENER, VALVE CONTROL LEVER PIVOT RETAINER 패스너
49.103	RETAINER, VALVE CONTROL LEVER PIVOT PIN 리테이너
49.104	PIN, VALVE CONTROL LEVER CLEVIS ROD 핀
49.105	RETAINER, VALVE CONTROL LEVER CLEVIS ROD PIN 리테이너
49.109	ROD, VALVE CONTROL CLEVIS 로드
52.162	CONNECTOR, AUXILIARY VALVE LEVER WIRE 커넥터



HYDRAULIC CONTROL VALVE-2 SPOOL



30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
30.067	RELIEF VALVE KIT, VALVE INLET SECTION 릴리프밸브
30.107	FASTENER, VALVE THRU 패스너
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 시일킷
30.507	SEAL KIT, HYDRAULIC VALVE (TILT) 시일킷
30.530	FASTENER, VALVE THRU 패스너
30.715	FASTENER, VALVE THRU 패스너
30.762	END COVER, HYDRAULIC VALVE 엔드커버
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션




HYDRAULIC CONTROL VALVE-2 SPOOL

49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀실킷
49.197	SPOOL SEAL KIT, TILT SECTION 스풀실킷



HYDRAULIC CONTROL VALVE-3 SPOOL



- | | |
|--------|--|
| 30.000 | VALVE ASSEMBLY, HYDRAULIC
밸브 |
| 30.067 | RELIEF VALVE KIT, VALVE INLET SECTION
릴리프밸브 |
| 30.107 | FASTENER, VALVE THRU
패스너 |
| 30.406 | SEAL KIT, HYDRAULIC VALVE (LIFT)
시일킷 |
| 30.507 | SEAL KIT, HYDRAULIC VALVE (TILT)
시일킷 |
| 30.530 | FASTENER, VALVE THRU
패스너 |
| 30.714 | SEAL KIT, HYDRAULIC VALVE SECTION (AUX)
시일킷 |
| 30.715 | FASTENER, VALVE THRU
패스너 |
| 30.762 | END COVER, HYDRAULIC VALVE
엔드커버 |




HYDRAULIC CONTROL VALVE-3 SPOOL

49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀실킷
49.197	SPOOL SEAL KIT, TILT SECTION 스풀실킷
49.198	SPOOL SEAL KIT, AUX SECTION 스풀실킷



HYDRAULIC CONTROL VALVE-4 SPOOL




- | | |
|--------|--|
| 30.000 | VALVE ASSEMBLY, HYDRAULIC
밸브 |
| 30.067 | RELIEF VALVE KIT, VALVE INLET SECTION
릴리프밸브 |
| 30.107 | FASTENER, VALVE THRU
패스너 |
| 30.250 | SEAL KIT, HYDRAULIC VALVE SECTION (AUX)
시일킷 |
| 30.406 | SEAL KIT, HYDRAULIC VALVE (LIFT)
시일킷 |
| 30.507 | SEAL KIT, HYDRAULIC VALVE (TILT)
시일킷 |
| 30.530 | FASTENER, VALVE THRU
패스너 |
| 30.714 | SEAL KIT, HYDRAULIC VALVE SECTION (AUX)
시일킷 |
| 30.715 | FASTENER, VALVE THRU
패스너 |



HYDRAULIC CONTROL VALVE-4 SPOOL

30.762	END COVER, HYDRAULIC VALVE 엔드커버
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션
49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.115	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.179	AUX SECTION, HYDRAULIC VALVE 보조섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀실킷
49.197	SPOOL SEAL KIT, TILT SECTION 스풀실킷
49.198	SPOOL SEAL KIT, AUX SECTION 스풀실킷
49.199	SPOOL SEAL KIT, AUX SECTION 스풀실킷




HYDRAULIC LIFT & TILT LINES

31-139

- | | |
|--------|--|
| 31.030 | LINE, VALVE TO LIFT CYLINDER
라인 |
| 31.061 | FITTING, VALVE TILT PORT "A"
피팅 |
| 31.072 | LINE, RH TILT CYLINDER ROD PORT
라인 |
| 31.073 | LINE, LH TILT CYLINDER ROD PORT
라인 |
| 31.075 | FITTING, RH TILT CYLINDER ROD PORT
피팅 |
| 31.077 | FITTING, LH TILT CYLINDER ROD PORT
피팅 |
| 31.083 | LINE, RH TILT CYLINDER ANCHOR PORT
라인 |
| 31.158 | LINE, LH TILT CYLINDER ANCHOR PORT
라인 |
| 31.168 | FASTENER, TILT LINE CLAMP
패스너 |



31.169	CLAMP, TILT LINE 클램프
31.200	FITTING, MAIN VALVE LIFT PORT 피팅



HYDRAULIC SUPPLY LINES

31-307

28.291	FITTING, PUMP OUTLET 피팅
28.397	FITTING, STEERING GEAR LINE 피팅
28.800	SEAL, MAIN VALVE INLET PORT FITTING 시일
28.806	SEAL, MAIN VALVE INLET LINE FITTING 시일
28.847	LINE, MAIN VALVE INLET 라인
30.952	DUST CAP, PRESSURE GAUGE PORT FITTING 더스트캡
31.006	LINE, PUMP INLET 라인
31.007	CLAMP, PUMP INLET LINE 클램프
31.036	FITTING, MAIN VALVE INLET PORT 피팅




HYDRAULIC SUPPLY LINES

31.115	LINE, STEERING PUMP OUTLET 라인
31.150	FITTING, STEER VALVE DISCHARGE PORT 피팅
31.422	LINE, PUMP OUTLET (COVER END) 라인
31.448	FITTING, PUMP OUTLET LINE 피팅
31.480	PLUG, PRESSURE GAUGE PORT 플러그
31.865	BRACKET, VALVE INLET LINE CLAMP 브라켓
95.236	FASTENER, HYDRAULIC LINE CLAMP 패스너



TILT CYLINDER




TILT CYLINDER

32-129

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.002	CYLINDER ASSEMBLY, WELDED 실린더
32.017	GLAND, TILT CYLINDER 그랜드
32.018	BUSHING, TILT CYLINDER GLAND 부싱
32.036	ROD & PISTON ASSEMBLY, TILT CYLINDER 로드와피스톤
32.072	PACKING KIT, TILT CYLINDER 패킹킷

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



TILT CYLINDER MOUNTING

32-155


32.000	CYLINDER ASSEMBLY, TILT 실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.029	FASTENER, TILT CYLINDER ROD END 패스너
32.030	PIN, TILT CYLINDER TO UPRIGHT 핀
32.032	FITTING, TILT CYLINDER TO UPRIGHT PIN LUB 피팅
32.033	PIN, TILT CYLINDER REAR MOUNTING RH 핀
32.034	RETAINER, TILT CYLINDER ANCHOR PIN 리테이너
32.035	FITTING, TILT CYLINDER TO FRAME PIN LUB 피팅
32.043	BEARING, TILT CYLINDER FRAME MOUNTING 베어링



TILT CYLINDER MOUNTING

32.053	BEARING, TILT CYLINDER ROD END 베어링
32.056	SPACER, TILT CYLINDER ROD END 스페이서
32.084	CAPSCREW, TILT CYLINDER ROD END PIN RETAINER 캡스크류
32.102	SHIM, TILT CYLINDER STROKE ADJUSTING 심
90.438	NUT, TILT CYLINDER ROD END FASTENER 너트
90.439	BOLT, TILT CYLINDER TO FRAME PIN LOCK 볼트
94.796	WASHER, TILT CYLINDER ROD END PIN RETAINER FASTENER 와셔

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE




TILT AMOUNT GP

32-167

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.056	SPACER, TILT CYLINDER ROD END 스페이서
32.102	SHIM, TILT CYLINDER STROKE ADJUSTING 심


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



TILT AMOUNT GP

32-169

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.056	SPACER, TILT CYLINDER ROD END 스페이서
32.102	SHIM, TILT CYLINDER STROKE ADJUSTING 심
32.132	SPACER, TILT CYLINDER ROD END 스페이서
32.133	SHIM, TILT CYLINDER STROKE ADJUSTING 심




ACCUMULATOR INSTALLATION

32-171


30.000	VALVE ASSEMBLY, HYDRAULIC 밸브
32.800	ACCUMULATOR, HYDRAULIC 어큐뮬레이터
32.801	CLAMP, HYDRAULIC ACCUMULATOR MOUNTING 클램프
32.802	BRACKET, HYDRAULIC ACCUMULATOR 브라켓
32.805	SEAL, HYDRAULIC ACCUMULATOR CONNECTOR 시일
32.806	CONNECTOR, HYDRAULIC ACCUMULATOR 커넥터
32.810	LINE, HYDRAULIC ACCUMULATOR 라인
32.814	FITTING, HYDRAULIC ACCUMULATOR LINE 피팅
32.841	NUT, HYDRAULIC ACCUMULATOR FITTING 너트




32.842	SEAL, HYDRAULC ACCUMULATOR FITTING 시일
--------	--



- | | |
|--------|--|
| 33.600 | RELIEF VALVE, DEVICE VARIABLE PRESSURE
릴리프밸브 |
| 33.601 | LEVER, DEVICE VARIABLE RELIEF VALVE
레버 |
| 33.610 | SEAL, DEVICE PRESS RELIEF VAL CHECK PORT PLUG
시일 |
| 33.613 | SEAL, DEVICE RELIEF VALVE PISTON ADJ END
시일 |
| 33.618 | CARTRIDGE KIT, DEVICE VARIABLE RELIEF VALVE
카트리지킷 |
| 33.631 | FASTENER, DEVICE RELIEF VALVE
패스너 |



- 33.380 VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID
벨브
- 33.384 FASTENER, DEV SELECTOR VALVE SOLENOID COIL
패스너
- 33.385 COIL, DEVICE SELECTOR VALVE SOLENOID
코일
- 33.387 SEAL KIT, DEVICE SELECTOR VALVE
시일킷
- 33.388 REPAIR KIT, DEVICE SELECTOR VALVE
리페어킷




LOAD BACK REST

34-044


34.998 FASTENER, LOAD SAFETY BACK REST
패스너

66.431 RETAINER, LBR CAPSCREW
리테이너


ASSEMBLY COMPLETE 34.300




TYPE - 1



TYPE - 2



TYPE - 3



TYPE - 4

CARRIAGE ASSEMBLY

34-103

34.300	ASSEMBLY, FORK BARS & CARRIAGE 캐리지
34.301	ROLLER, CARRIAGE OUTER THRUST 롤러
34.307	ROLLER, CARRIAGE INNER THRUST 롤러
34.320	SHAFT, CARRIAGE OUTER THRUST ROLLER 샤프트
34.321	FASTENER, CARRIAGE ROLLER SHAFT 패스너
34.328	ROLLER, CARRIAGE CAPTIVE 롤러
34.329	RETAINER, CARRIAGE CAPTIVE ROLLER 리테이너
34.330	FASTENER, CARRIAGE CAPTIVE ROLLER RETAINER 패스너
34.332	SHIM, CARRIAGE CAPTIVE ROLLER 심



34.340 CARRIAGE WELDED ASSEMBLY
캐리지용 접물



CARRIAGE ASSEMBLY

This Carriage assembly was manufactured by the CASCADE CORPORATION and is not serviced by CLARK Material Handling Company.

CASCADE parts manuals, technical specifications and lists of worldwide distributors are available on-line at:


<http://www.cascorp.com>.

When ordering service parts, it will be necessary to provide CASCADE with the CASCADE model and serial numbers of the carriage. CASCADE will not recognize the CLARK carriage part number listed on the PIC or in PartsPRO.

34.300	CARRIAGE ASSEMBLY COMPLETE
34.340	CARRIAGE WELDED ASSEMBLY



UPRIGHT MOUNTING




UPRIGHT MOUNTING

34-734

34.036	BUSHING, UPRIGHT TRUNNION 부싱
34.037	CAP, UPRIGHT TRUNNION 캡
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너
34.039	FITTING-LUB, UPRIGHT TRUNNION 피팅
66.167	SHIM, LIFT CYLINDER UPPER 심
66.442	KEEPER, UPRIGHT TRUNNION CAP 키퍼



OVERHEAD GUARD COVER



OVERHEAD GUARD COVER


37-003

38.243 COVER ASSEMBLY, OVERHEAD GUARD TOP
커버



REAR WIPER INSTALLATION

ASSEMBLY
COMPLETE 37.300



REAR WIPER INSTALLATION

37-050


37.300	CAB ASSEMBLY 캐빈
37.454	NOZZLE, REAR WINDOW GLASS WASHER 노즐
37.481	LINE, WINDOW GLASS WASHER 라인
39.230	MOTOR, REAR WINDOW WIPER 모터
39.233	ARM, REAR WINDOW WIPER 암
39.234	BLADE, REAR WINDOW WIPER 블레이드



CAB DOOR SASH ASSEMBLY

ASSEMBLY COMPLETE — 39.248LH
39.977RH

NOTE :
ITEMS TO BE NOT SOLD
SEPARATELY MARKED "NSS"



CAB DOOR SASH ASSEMBLY

37-054


37.799	LATCH, CAB DOOR WINDOW ASSEMBLY 래치
39.248	WINDOW ASSEMBLY, CAB DOOR (LH) 윈도우
39.298	CHANNEL, FRONT DOOR GLASS - FRONT 채널
39.347	FASTENER, CAB REAR WINDOW LATCH 패스너
39.977	WINDOW ASSEMBLY, CAB DOOR (RH) 윈도우
47.303	GLASS, CAB DOOR (FRONT) 글래스
47.304	GLASS, CAB DOOR (REAR) 글래스
47.307	CHANNEL, CAB SIDE DOOR WINDOW 채널

**ASSEMBLY
COMPLETE** — 37.300

**SIDE DOOR
ASSEMBLY COMPLETE** — 39.152LH
39.131RH

NOTE :
**ITEMS TO BE NOT SOLD
SEPARATELY MARKED "NSS"**

■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



ENCLOSED CAB

37-056

37.300	CAB ASSEMBLY 캐빈	39.144	HANDLE, RH DOOR OUTSIDE 핸들
37.551	HANGER, CAB REAR GLASS 행거	39.145	FASTENER, RH DOOR HANDLE 패스너
37.559	PIN, CABIN REAR GLASS HANGER 핀	39.147	FASTENER, RIGHT HAND DOOR LATCH 패스너
37.560	RETAINER, CAB REAR GLASS HANGER PIN 리테이너	39.152	DOOR ASSEMBLY, LEFT HAND 도어
37.679	HANDLE, RH DOOR INSIDE 핸들	39.192	GLASS, RIGHT HAND DOOR (LOWER) 글래스
37.689	SEAL, DOOR OUTSIDE HANDLE 시일	39.193	WEATHERSEAL, RH DOOR GLASS (LOWER) 웨더시일
37.691	SEAL, DOOR OUTSIDE HANDLE 시일	39.228	WEATHERSEAL, WINDSHIELD SETTING 웨더시일
39.101	GLASS, WINDSHIELD 글래스	39.248	WINDOW ASSEMBLY, CAB DOOR (LH) 윈도우
39.102	WEATHERSEAL, WINDSHIELD SETTING 웨더시일	39.280	GLASS, REAR WINDOW - MOVEABLE 글래스
39.109	GLASS, REAR 글래스	39.318	PANEL, REAR LOWER 판넬
39.110	WEATHERSEAL, REAR GLASS SETTING 웨더시일	39.319	FASTENER, LOWER REAR PANEL 패스너
39.117	ROOF SCREEN 루프스크린	39.339	FASTENER, RH DOOR INSIDE HANDLE 패스너
39.119	SEAL STRIP, ROOF WINDOW 시일스트립	39.344	WEATHERSEAL, RH DOOR WINDOW ASSEMBLY 웨더시일
39.131	DOOR ASSEMBLY, RIGHT HAND 도어	39.349	WEATHERSEAL, CAB REAR WINDOW 웨더시일
39.138	WEATHERSEAL, RIGHT HAND DOOR 웨더시일	39.977	WINDOW ASSEMBLY, CAB DOOR (RH) 윈도우





ENCLOSED CAB

47.144	LATCH, RH DOOR INSIDE 래치
47.145	LATCH, LH DOOR INSIDE 래치
47.269	BRACKET, CAB REAR GLASS GAS SPRING SUPPORT 브라켓
47.270	RUBBER, CAB REAR GLASS GAS SPRING MOUNTING 러버
47.271	RUBBER, CAB REAR GLASS GAS SPRING MOUNTING 러버
47.272	BRACKET, CAB REAR GLASS GAS SPRING MOUNTING 브라켓
47.274	HANDLE, CAB REAR GLASS 핸들
47.371	CAP, CAB REAR GLASS GAS SPRING MOUNTING FASTENER *
47.373	SHOCK ABSORBER, CAB REAR GLASS *
47.375	BRACKET, CAB REAR GLASS HANGER *
47.378	SUPPORT, CAB DOOR INSIDE LATCH *
95.358	FASTENER, REAR GLASS HANGER 패스너
96.877	FASTENER, DOOR INSIDE LATCH STRIKER 패스너
97.063	FASTENER, REAR DOOR HANDLE MOUNTING 패스너
97.171	FASTENER, CAB REAR GLASS GAS SPRING MOUNTING *



BACK MIRROR


ASSEMBLY
COMPLETE 39.689



BACK MIRROR

37-076


- 39.184 FASTENER, REAR VIEW MIRROR
패스너
- 39.689 MIRROR, REAR VIEW
미러



OVERHEAD GUARD MOUNTING

37-083

37.048	FASTENER, OVERHEAD GUARD BUMPER 패스너
37.214	PLUG-BUTTON 플러그
37.290	DAMPENER, OVERHEAD GUARD VIBRATION 댐프너
37.746	PLUG, DRIVER OVERHEAD GUARD 플러그
39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
47.401	WEATHERSTRIP, OVERHEAD GUARD REAR SUPPORT *




HOOD MOUNTING

37-114

- | | |
|--------|--|
| 37.352 | BRACKET, TOP HOOD SPRING (RH)
브라켓 |
| 37.362 | BRACKET, TOP HOOD SPRING (LH)
브라켓 |
| 37.897 | BUMPER, TOP HOOD
범퍼 |
| 37.934 | SEAL, HOOD ACCESS COVER
시일 |
| 38.001 | BRACKET, HOOD SUPPORT
브라켓 |
| 39.423 | FASTENER, TOP HOOD
패스너 |
| 39.535 | BRACKET, TOP HOOD MOUNTING
브라켓 |
| 39.536 | BRACKET, TOP HOOD MOUNTING
브라켓 |
| 39.537 | FASTENER, TOP HOOD MOUNTING BRACKET
패스너 |



39.594	HOOD, TOP 후드
39.595	FASTENER, TOP HOOD 패스너
39.641	PLATE, TOP HOOD LATCH MOUNTING 플레이트
39.643	CATCH, TOP HOOD LATCH 캐치
39.644	LATCH, TOP HOOD 래치
39.648	FASTENER, TOP HOOD LATCH CATCH 패스너
39.662	FASTENER, TOP HOOD LATCH BRACKET 패스너
39.702	PROP, HOOD 프롭
39.705	FASTENER, HOOD PROP 패스너
41.104	SOUND SEAL, RH SIDE HOOD 사운드시일
41.105	SOUND SEAL, LH SIDE HOOD 사운드시일
41.251	SOUND SEAL, TOP HOOD 사운드시일
41.602	SOUND SEAL, ENGINE HOOD 사운드시일
41.603	SOUND SEAL, ENGINE HOOD 사운드시일
47.074	FASTENER, TOP HOOD SPRING BRACKET 패스너
94.763	FASTENER, HOOD SUPPORT 패스너




SHEET METAL & TRIM

37-117

02.422	SCREEN, ENGINE INTAKE AIR 스크린
03.567	PLUG, AIR INTAKE DRIVER OVERHEAD GUARD 플러그
37.200	PANEL, FRONT 판넬
37.201	PANEL, LH SIDE 판넬
37.202	PANEL, RH SIDE 판넬
38.049	STEP ASSEMBLY, RH 스텝
38.050	STEP ASSEMBLY, LH 스텝
38.052	FASTENER, STEP FRONT 패스너
39.363	FASTENER, RH SIDE PANEL 패스너




39.570	COVER ASSEMBLY, DASH 커버
39.571	FASTENER, DASH COVER 패스너
39.757	COVER, FRAME END 커버
39.860	BRACKET, RADIATOR BAFFLE MOUNTING 브라켓
47.003	COVER, RADIATOR 커버
47.004	SEAL, RADIATOR COVER 시일
47.416	COVER, RADIATOR *
93.761	FASTENER, DRIVERS OVERHEAD GUARD TOP SECTION COVER 패스너
94.743	FASTENER, RADIATOR COVER TRIM 패스너
95.735	FASTENER, ENGINE AIR INTAKE SCREEN 패스너
97.288	FASTENER, FRAME END COVER *



SEAT ARMREST ASSEMBLY

37-124

- | | |
|--------|---------------------------------------|
| 37.919 | ARMREST LH, SEAT
암레스트 |
| 37.920 | ARMREST RH, SEAT
암레스트 |
| 96.403 | FASTENER, SEAT ARMREST BRACKET
패스너 |





FRAME & COUNTERWEIGHT

38-225

- | | |
|--------|--|
| 38.869 | COUNTERWEIGHT
카운터웨이트 |
| 38.870 | FASTENER, COUNTERWEIGHT (LOWER)
패스너 |
| 38.920 | PIN, COUPLER
핀 |
| 38.921 | PIN, COUPLER PIN CROSS
핀 |



FRAME TANK BOTTOM PLUG




DETAIL - A

FRAME TANK BOTTOM PLUG

38-270

- | | |
|--------|---------------------------------------|
| 38.246 | PLUG, FRAME BOTTOM MAGNETIC
플러그 |
| 38.280 | SEAL, FRAME BOTTOM MAGNETIC PLUG
실 |




LEAD WIRE GROUND

39-012

60.908 WIRE, LEAD GROUND
와이어



ELECTRICAL COMPONENTS (CAB)




13.228	LAMP ASSEMBLY, DOME 램프
13.229	BULB, DOME LAMP 전구
13.233	FASTENER, DOME LAMP 패스너
15.430	GROMMET, CABIN WIRING HARNESS 그로멧
37.300	CAB ASSEMBLY 캐빈
37.437	PUMP & TANK, WINDSHIELD WASHER 펌프와탱크
37.461	NOZZLE, WINDSHIELD GLASS WASHER 노즐
37.481	LINE, WINDOW GLASS WASHER 라인
37.624	SPEAKER, CABIN 스피커



ELECTRICAL COMPONENTS (CAB)


37.636	COVERING, CAB INSIDE ROOF 커버링
37.759	GROMMET, COVER WINDSHIELD WIPER MOTOR 그로멧
37.818	BRACKET, WINDSHIELD WASHER TANK 브라켓
39.178	SWITCH, WINDSHIELD WIPER 스위치
39.200	MOTOR, WINDSHIELD WIPER 모터
39.203	ARM, WINDSHIELD WIPER 암
39.204	BLADE, WINDSHIELD WIPER 블레이드
41.404	ANTENNA, AUDIO 안테나
47.260	SWITCH ASSY, CABIN 스위치
60.292	COVER, CAB SWITCH PANEL 커버
60.297	SWITCH, WINDSHIELD WASHER 스위치
60.299	SWITCH, HEATER ON/OFF 스위치
60.330	WIRING HARNESS, CAB 와이어하네스
60.746	PROTECTION,HARNESS 보호장치
94.497	FASTENER, WINDSHIELD WASHER TANK 패스너
94.570	FASTENER, CAB SWITCH PANEL COVER 패스너
95.302	FASTENER, LOUDSPEAKER 패스너
96.965	FASTENER, REAR WINDOW WIPER BRACKET 패스너




FLOOR PLATE MOUNTING

39-512

- | | |
|--------|----------------------------|
| 37.902 | MAT, FLOORPLATE
매트 |
| 39.475 | PLATE, FRONT FLOOR
플레이트 |



- | | |
|--------|---|
| 34.977 | RETAINER, LOAD BACK REST TRUNNION PIN
리테이너 |
| 34.991 | FASTENER, LOAD SAFETY BACK REST EXT
패스너 |
| 34.995 | FASTENER, LOAD SAFETY BACK REST
패스너 |
| 92.226 | NUT, LOAD SAFETY BACK REST FASTENER
너트 |




NOISE REDUCTION INSTALLATION

39-559

- | | |
|--------|--|
| 37.146 | SOUND ABSORBER, OVERHEAD GUARD
흡음재 |
| 41.252 | SOUND SEAL, FLOOR PLATE FRONT
사운드시일 |
| 41.321 | SOUND SEAL, FLOOR PLATE REAR
사운드시일 |
| 41.397 | SOUND ABSORBER, RADIATOR COVER
흡음재 |



ELECTRICAL COMPONENTS (CAB)




13.228	LAMP ASSEMBLY, DOME 램프
13.229	BULB, DOME LAMP 전구
13.233	FASTENER, DOME LAMP 패스너
15.430	GROMMET, CABIN WIRING HARNESS 그로멧
37.300	CAB ASSEMBLY 캐빈
37.437	PUMP & TANK, WINDSHIELD WASHER 펌프와탱크
37.461	NOZZLE, WINDSHIELD GLASS WASHER 노즐
37.481	LINE, WINDOW GLASS WASHER 라인
37.624	SPEAKER, CABIN 스피커




ELECTRICAL COMPONENTS (CAB)

37.636	COVERING, CAB INSIDE ROOF 커버링
37.759	GROMMET, COVER WINDSHIELD WIPER MOTOR 그로멧
39.178	SWITCH, WINDSHIELD WIPER 스위치
39.200	MOTOR, WINDSHIELD WIPER 모터
39.203	ARM, WINDSHIELD WIPER 암
39.204	BLADE, WINDSHIELD WIPER 블레이드
41.404	ANTENNA, AUDIO 안테나
47.260	SWITCH ASSY, CABIN 스위치
60.292	COVER, CAB SWITCH PANEL 커버
60.297	SWITCH, WINDSHIELD WASHER 스위치
60.299	SWITCH, HEATER ON/OFF 스위치
60.330	WIRING HARNESS, CAB 와이어하네스
60.746	PROTECTION,HARNESS 보호장치
94.497	FASTENER, WINDSHIELD WASHER TANK 패스너
94.570	FASTENER, CAB SWITCH PANEL COVER 패스너
95.302	FASTENER, LOUDSPEAKER 패스너
96.965	FASTENER, REAR WINDOW WIPER BRACKET 패스너



37.300	CAB ASSEMBLY 캐빈
41.402	COVER, AUDIO AND TRANSCEIVER MOUNTING BOX 커버
41.407	AUDIO 라디오
41.411	BRACKET, AUDIO AND TRANSCEIVER BOX MOUNTING 브라켓
47.245	MANUAL, CASSETTE 매뉴얼
95.305	FASTENER, AUDIO AND TRANSCEIVER BOX TO MOUNTING BR 패스너



- 37.406 BRACKET, SEAT BACK REST COVER LH
브라켓
- 37.407 BRACKET, SEAT BACK REST COVER RH
브라켓
- 37.439 SAFETY BELT, SEAT
세이프티벨트
- 37.531 BRACKET, SEAT SAFETY BELT MOUNTING
브라켓
- 37.720 COVER, OPERATOR SEAT LATERAL RESTRAINT
커버
- 37.743 COVER, SEAT SUPPORT LATCH
커버
- 38.163 BRACKET, SEAT SUPPORT RH
브라켓
- 39.719 SEAT ASSEMBLY
시트
- 39.720 CUSHION, SEAT
쿠션




SEAT ASSEMBLY


39.721	CUSHION, SEAT BACK REST 쿠션
39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.732	SPACER, SEAT FRAME TO ADJUSTOR 스페이서
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
95.429	FASTENER, SEAT LATERAL RESTRAINT COVER 패스너



FLOOR PLATE MOUNTING



FOR CAB




FOR OVERHEAD GUARD

FLOOR PLATE MOUNTING

39-674

37.902	MAT, FLOORPLATE 매트
39.475	PLATE, FRONT FLOOR 플레이트


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



SEAT MOUNTING

39-829

39.719	SEAT ASSEMBLY 시트
48.347	FASTENER, SEAT ASSEMBLY 패스너
96.736	WASHER, SEAT ASSEMBLY FASTENER 와셔




- | | |
|--------|---|
| 37.406 | BRACKET, SEAT BACK REST COVER LH
브라켓 |
| 37.407 | BRACKET, SEAT BACK REST COVER RH
브라켓 |
| 37.439 | SAFETY BELT, SEAT
세이프티벨트 |
| 37.915 | SUSPENSION COVER, SEAT SUSPENSION
서스펜션 |
| 37.918 | SUSPENSION ASSEMBLY, SEAT
서스펜션 |
| 38.163 | BRACKET, SEAT SUPPORT RH
브라켓 |
| 39.719 | SEAT ASSEMBLY
시트 |
| 39.720 | CUSHION, SEAT
쿠션 |
| 39.721 | CUSHION, SEAT BACK REST
쿠션 |



SEAT ASSEMBLY (SUSPENSION)

39.726	ADJUSTOR, SEAT 어드저스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드저스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 킷
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
94.880	FASTENER, SEAT SUPPORT CATCH BRACKET 패스너
95.274	FASTENER, SEAT CUSHION SUSPENSION SUPPORT 패스너
96.412	FASTENER, SEAT SUSPENSION BACK SIDE COVER 패스너



COWL MOUNTING


39-963

- | | |
|--------|---|
| 37.748 | DAMPENER, COWL VIBRATION
댐프너 |
| 39.546 | COWL ASSEMBLY
카울 |
| 39.547 | FASTENER, COWL ASSEMBLY
패스너 |
| 96.307 | FASTENER, COWL PLATE
패스너 |
| 97.154 | FASTENER, COWL DAMPENER MOUNTING
패스너 |



POD INSTALLATION

ASSEMBLY
COMPLETE 39.500




POD INSTALLATION

39-969

- | | |
|--------|----------------------------------|
| 13.000 | PANEL, INSTRUMENT CLUSTER
판넬 |
| 37.250 | HOUSING, INSTRUMENT PANEL
하우징 |
| 39.510 | HOUSING, INSTRUMENT PANEL
하우징 |


■ INDICATES AN ASSEMBLY
HAVING SERVICEABLE
COMPONENTS ILLUSTRATED
ELSEWHERE



CAB MOUNTING

39-976

37.048	FASTENER, OVERHEAD GUARD BUMPER 패스너
37.214	PLUG-BUTTON 플러그
37.290	DAMPENER, OVERHEAD GUARD VIBRATION 댐프너
37.300	CAB ASSEMBLY 캐빈
37.746	PLUG, DRIVER OVERHEAD GUARD 플러그
39.933	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
47.003	COVER, RADIATOR 커버





OVERHEAD GUARD MOUNTING

39-977

37.048	FASTENER, OVERHEAD GUARD BUMPER 패스너
37.214	PLUG-BUTTON 플러그
37.290	DAMPENER, OVERHEAD GUARD VIBRATION 댐프너
37.746	PLUG, DRIVER OVERHEAD GUARD 플러그
39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너




MODEL & SPECIFICATION DECALS



MODEL & SPECIFICATION DECALS

40-243


40.014	DECAL, MODEL NAME 데칼
40.268	DECAL, SPEC 데칼
40.296	DECAL, TIRE PRESSURE 데칼
40.311	DECAL, SOUND POWER LEVEL 데칼



40.000	PLATE, CAPACITY & SERIAL NUMBER 플레이트	40.158	DECAL, WARNING INDICATOR 데칼
40.001	FASTENER, CAPACITY & SERIAL PLATE 패스너	40.206	DECAL, SLING EYE 데칼
40.010	DECAL, CLARK 데칼	40.236	DECAL, FUEL 데칼
40.012	DECAL, CLARK LOGO-SMALL 데칼	40.240	DECAL, FUEL WARNING 데칼
40.024	PLATE, UNDERWRITERS LABEL 플레이트	40.241	DECAL, BRAKE OIL SPEC 데칼
40.025	FASTENER, UNDERWRITERS LABEL PLATE 패스너	40.247	DECAL, LPG FUEL CYL REPLACEMENT PROCEDURE 데칼
40.030	DECAL, CLARK VERTICAL 데칼	40.248	DECAL, SERVICE CHART 데칼
40.062	DECAL, DRIVERS CAUTION 플래그	40.260	DECAL, HOT SURFACE WARNING 데칼
40.068	DECAL, HYD-SYSTEM OIL 데칼	40.271	DECAL, LP GAS 데칼
40.089	PLATE, SAFETY INSTRUCTION 플레이트	40.279	DECAL, STARTING PROCEDURE 데칼
40.130	LEGEND, SAFETY 범례	40.310	DECAL, EXHAUST GAS 데칼
40.131	LEGEND, SAFETY 범례	40.327	DECAL, FAN WARNING 데칼
40.134	DECAL, OPERATORS MANUAL LOCATION 데칼	40.328	DECAL, WHEEL NUT WARNING 데칼
40.138	DECAL, SAFETY 데칼	40.333	REFLECTOR, COUNTERWEIGHT *
40.143	DECAL, OPERATORS INSTRUCTIONS 데칼	40.346	DECAL, OVERHEAD GUARD DROP TEST *




40.349	PLATE, LESS LP TANK *
40.350	FASTENER, PLATE LESS LP TANK *



NOTE: All Trucks Do Not Use All Fluid Key Numbers


99.901	ENGINE OIL 엔진오일
99.902	TRANSMISSION FLUID 트랜스미션오일
99.903	DRIVE AXLE FLUID 드라이브액슬
99.904	HYDRAULIC SUMP OIL 유압섬프오일
99.905	BRAKE FLUID 브레이크오일
99.906	AXLE END FLUID 액슬엔드오일
99.907	ENGINE ANTIFREEZE 부동액



STORAGE CONSOLE MOUNTING

41-008

- | | |
|--------|---|
| 41.028 | CONSOLE, OPERATOR STORAGE CONSOLE
콘솔 |
| 41.030 | FASTENER, STORAGE CONSOLE
패스너 |



HEATER INSTALLATION

41-038


41.039	GROMMET, HEATER LINE 그로멧
41.050	HEATER ASSEMBLY 히터
41.057	LINE, HEATER INLET 라인
41.058	CLAMP, HEATER INLET LINE 클램프
41.061	LINE, HEATER OUTLET 라인
41.062	CLAMP, HEATER OUTLET LINE 클램프
41.464	BRACKET, HEATER 브라켓
41.606	SLEEVE, HEATER HOSE *
41.607	GUARD, HEATER HOSE *



96.055	FASTENER, HEATER MOUNTING BRACKET 패스너
--------	--

SEAT SAFETY
WING KIT

37.970




SEAT WING KIT

47-000

- | | |
|--------|--|
| 37.447 | RESTRAINT, OPERATOR SEAT LATERAL
레스트레인트 |
| 37.970 | KIT, SEAT SAFETY
킷 |
| 94.537 | FASTENER, OPERATOR SEAT LATERAL RESTRAINT
패스너 |



REAR HAND GRIP MOUNTING




REAR HAND GRIP MOUNTING

47-005

- | | |
|--------|---|
| 37.421 | GROMMET, OVERHEAD GUARD REAR SUPPORT PIVOT
그로멧 |
| 47.385 | GRIP, OVERHEAD GUARD REAR HAND
* |
| 60.968 | WIRE, OVERHEAD GUARD REAR HAND GRIP SWITCH
* |
| 97.216 | FASTENER, OVERHEAD GUARD REAR HAND GRIP
* |



DEVICE HOSE REEL




- 50.130 REEL ASSEMBLY, DEVICE RH HOSE
릴
- 50.141 FLANGE, DEVICE RH HOSE REEL OUTBOARD
플랜지
- 50.142 FLANGE, DEVICE RH HOSE REEL CENTER
플랜지
- 50.147 HUB, DEVICE RH HOSE REEL
허브
- 50.148 SEAL, DEVICE RH HOSE REEL AXLE
시일
- 50.150 AXLE, DEVICE RH HOSE REEL
액슬
- 50.244 HOUSING ASSEMBLY, DEVICE RH HOSE REEL SPRING
하우징
- 50.270 BASE, DEVICE RH HOSE REEL
베이스
- 50.271 FASTENER, DEVICE RH HOSE REEL AXLE
패스너



DEVICE HOSE REEL

50.372	DOG, DEVICE RH HOSE REEL SPRING 도그
50.683	LOCK, DEVICE HOSE REEL DOG 로크
50.685	FASTENER, DEVICE HOSE REEL BASE 패스너
50.795	SPACER, DEVICE HOSE REEL SPRING HOUSING 스페이서
59.018	GUIDE, DEVICE HOSE REEL FASTENER 가이드
59.020	CAP, DEVICE HOSE REEL AXLE 캡
95.514	FASTENER, DEVICE HOSE REEL AXLE CAP 패스너



SOLENOID VALVE

50-157

- | | |
|--------|--|
| 13.575 | WIRE, DEV SELECTOR VALVE SWITCH FEED
와이어 |
| 18.090 | CLIP, REEL WIRE HARNESS
클립 |
| 33.380 | VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID
밸브 |
| 33.381 | FASTENER, DEVICE SELECTOR VALVE
패스너 |
| 33.382 | BRACKET, DEVICE SELECTOR VALVE
브라켓 |
| 33.392 | FASTENER, SECONDARY SELECTOR VALVE
패스너 |
| 33.588 | CLIP, BY-PASS CLAMP LOCK VALVE
클립 |
| 33.589 | FASTENER, BY-PASS CLAMP LOCK VALVE CLIP
패스너 |
| 33.761 | FITTING, DEVICE SELECTOR VALVE C4 PORT
피팅 |




SOLENOID VALVE


33.763	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.765	LINE, DEVICE SELECTOR VALVE C4 PORT HYDRAULIC 라인
33.767	HOSE COUPLING, DEV SEL VALVE C1 PORT 호스커플링
33.778	HOSE COUPLING, DEV SEL VALVE C3 PORT 호스커플링
33.780	LINE, DEVICE SELECTOR VALVE C2 PORT HYDRAULIC 라인
33.788	BRACKET, DEVICE SEL VALVE HYDRAULIC LINE 브라켓
33.882	PLUG, DEVICE SEL VALVE "P" PORT 플러그
51.347	FITTING, SELECTOR VALVE P PORT 피팅
52.035	FITTING, SEC SEL VALVE C4 PORT LINE 피팅




ATTACHMENT HOSE ADAPTATION (CARRIAGE)



HINGED BUCKET (HB) / FORK (HF) - BASIC



ROTATING FORK (RF) - BASIC



LOAD STABILIZER (LS) - BASIC


ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-171

50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.405	COUPLING, DEVICE HOSE 커플링
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅



HIGH TERMINATION FOR DEVICE HOSE ADAPTA



HIGH TERMINATION FOR DEVICE HOSE ADAPTION

50-172

- 59.134 LINE, DEVICE LH LINE FOR HIGH TERMINATION *
- 59.135 LINE, DEVICE LH LINE FOR HIGH TERMINATION *
- 59.136 LINE, DEVICE RH LINE FOR HIGH TERMINATION *
- 59.137 LINE, DEVICE RH LINE FOR HIGH TERMINATION *
- 59.142 FITTING, DEVICE LINE FOR HIGH TERMINATION *
- 59.143 CAP, DEVICE LINE FITTING FOR HIGH TERMINATION *
- 59.144 BRACKET, DEVICE LINE FOR HIGH TERMINATION *
- 59.145 SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION *
- 59.146 SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION *




HIGH TERMINATION FOR DEVICE HOSE ADAPTA

- | | |
|--------|---|
| 97.235 | FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION
* |
| 97.238 | FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION
* |



HIGH TERMINATION FOR DEVICE HOSE ADAPTA



HIGH TERMINATION FOR DEVICE HOSE ADAPTATION

50-175

- 59.134 LINE, DEVICE LH LINE FOR HIGH TERMINATION
*
- 59.135 LINE, DEVICE LH LINE FOR HIGH TERMINATION
*
- 59.136 LINE, DEVICE RH LINE FOR HIGH TERMINATION
*
- 59.137 LINE, DEVICE RH LINE FOR HIGH TERMINATION
*
- 59.142 FITTING, DEVICE LINE FOR HIGH TERMINATION
*
- 59.143 CAP, DEVICE LINE FITTING FOR HIGH TERMINATION
*
- 59.144 BRACKET, DEVICE LINE FOR HIGH TERMINATION
*
- 59.145 SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION
*
- 59.146 SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION
*




HIGH TERMINATION FOR DEVICE HOSE ADAPTA

- | | |
|--------|---|
| 97.235 | FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION
* |
| 97.238 | FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION
* |



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

ATTACHMENT HOSE REFERENCE



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-232

50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일	50.610	FASTENER, DEVICE HOSE GUARD 패스너
50.132	BRACKET, DEVICE HOSE REEL 브라켓	50.811	NUT, DEVICE HOSE FITTING 너트
50.155	FASTENER, DEVICE HOSE CLIP 패스너	59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
50.156	CLIP, DEVICE HOSE 클립	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.200	COUPLING, DEVICE HOSE 커플링	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.316	GUARD, DEVICE RH HOSE 가드	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.119	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING *
50.571	BRACKET, DEVICE HOSE 브라켓	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING *
50.572	FASTENER, DEVICE HOSE BRACKET 패스너	75.015	MODULE, ATTACHMENT HOSE LINES *




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

93.316	DOWEL, STEERING INTERLOCK SWITCH FASTENER 다웰
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET *



QUICK DISCONNECT FOR DEVICE HOSE ADAPTA




- 50.017 TERMINAL BRACKET, DEVICE HOSE
터미널브라켓
- 50.018 DISCONNECT, DEVICE HOSE NIPPLE HALF
디스커넥트
- 50.020 DISCONNECT, DEVICE HOSE SOCKET HALF
디스커넥트
- 50.080 SEAL, DEVICE HOSE DISCONNECT NIPPLE RH
시일
- 50.086 FITTING, DEVICE RH HYDRAULIC HOSE
피팅
- 50.091 FITTING, DEVICE RH HYDRAULIC HOSE
피팅
- 50.203 LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인
- 50.253 LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인
- 50.629 SEAL, DEVICE HOSE DISCONNECT SOCKET RH
시일



QUICK DISCONNECT FOR DEVICE HOSE ADAPTA

50.640	FASTENER, DEVICE RH HYD HOSE FITTING 패스너
50.652	SPACER, DEVICE RH HYDRAULIC HOSE FITTING 스페이서
75.035	KIT, QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION 킷

ATTACHMENT HOSE
REFERENCE



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-269

50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일	50.811	NUT, DEVICE HOSE FITTING 너트
50.132	BRACKET, DEVICE HOSE REEL 브라켓	59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
50.155	FASTENER, DEVICE HOSE CLIP 패스너	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.156	CLIP, DEVICE HOSE 클립	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.200	COUPLING, DEVICE HOSE 커플링	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.316	GUARD, DEVICE RH HOSE 가드	59.101	TIE STRAP, AUXILIARY FUNCTION LINES 타이스트랩
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라인
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING *
50.571	BRACKET, DEVICE HOSE 브라켓	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING *
50.572	FASTENER, DEVICE HOSE BRACKET 패스너	75.015	MODULE, ATTACHMENT HOSE LINES *
50.610	FASTENER, DEVICE HOSE GUARD 패스너	93.316	DOWEL, STEERING INTERLOCK SWITCH FASTENER 다웰




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
95.538	FASTENER, DEVICE HOSE REEL BRACKET 패스너
96.316	FASTENER, DEVICE HOSE REEL 패스너
97.181	FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET *



ATTACHMENT HOSE & CABLE ADAPTATION (UPR



50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.686	WIRE, DEVICE 와이어




ATTACHMENT HOSE & CABLE ADAPTATION (UPR


50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR *
50.731	PLUG, DEVICE CABLE CONNECTOR *
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라J
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너



ATTACHMENT HOSE ADAPTATION (CARRIAGE)



**FORK POSITIONER (FP) - SHIFT
TYPE - 1**



**FORK POSITIONER (FP) - SHIFT
TYPE - 2**

ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-284


50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.405	COUPLING, DEVICE HOSE 커플링
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅
59.085	COUPLING, DEVICE HOSE 커플링



ATTACHMENT HOSE & CABLE ADAPTATION (UPR

ATTACHMENT HOSE
REFERENCE

75.015



ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)

50-289

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브	50.588	BRACKET, DEVICE CABLE CLAMP 브라켓
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너	50.590	CLAMP, DEVICE CABLE LOWER 클램프
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.591	FASTENER, DEVICE CABLE CLAMP LOWER 패스너
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일	50.623	BRACKET, DEVICE CABLE LOWER SHEAVE 브라켓
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피봇	50.624	SHEAVE, DEVICE CABLE 쉬브
50.156	CLIP, DEVICE HOSE 클립	50.625	RETAINER, DEVICE CABLE LOWER SHEAVE 리테이너
50.200	COUPLING, DEVICE HOSE 커플링	50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	50.686	WIRE, DEVICE 와이어
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	50.714	LOCK, DEVICE CABLE CONNECTOR *
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	50.731	PLUG, DEVICE CABLE CONNECTOR *
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	50.732	SPACER, DEVICE CABLE SHEAVE *
50.586	CLIP, DEVICE CABLE 클립	50.733	SPACER, DEVICE CABLE CLAMP BRACKET *
50.587	FASTENER, DEVICE CABLE CLIP 패스너	50.734	BRACKET, DEVICE CABLE TERMINAL CLAMP *




ATTACHMENT HOSE & CABLE ADAPTATION (UPR

50.745	BRACKET, DEVICE CABLE TERMINAL CLAMP MOUNTING *
50.746	FASTENER, DEVICE HOSE TERMINAL BLOCK *
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
97.182	FASTENER, DEVICE CABLE LOWER SHEAVE BRACKET *



ATTACHMENT HOSE & CABLE ADAPTATION (UPR



50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.686	WIRE, DEVICE 와이어




ATTACHMENT HOSE & CABLE ADAPTATION (UPR

50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR *
50.731	PLUG, DEVICE CABLE CONNECTOR *
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너



ATTACHMENT HOSE & CABLE ADAPTATION (UPR



50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록



ATTACHMENT HOSE & CABLE ADAPTATION (UPR


50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.686	WIRE, DEVICE 와이어
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR *
50.731	PLUG, DEVICE CABLE CONNECTOR *
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너



ATTACHMENT HOSE & CABLE ADAPTATION (UPR

ATTACHMENT HOSE
REFERENCE

75.015



ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)

50-292

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브	50.588	BRACKET, DEVICE CABLE CLAMP 브라켓
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너	50.590	CLAMP, DEVICE CABLE LOWER 클램프
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.591	FASTENER, DEVICE CABLE CLAMP LOWER 패스너
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일	50.623	BRACKET, DEVICE CABLE LOWER SHEAVE 브라켓
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피봇	50.624	SHEAVE, DEVICE CABLE 쉬브
50.156	CLIP, DEVICE HOSE 클립	50.625	RETAINER, DEVICE CABLE LOWER SHEAVE 리테이너
50.200	COUPLING, DEVICE HOSE 커플링	50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	50.686	WIRE, DEVICE 와이어
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	50.714	LOCK, DEVICE CABLE CONNECTOR *
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	50.732	SPACER, DEVICE CABLE SHEAVE *
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	50.733	SPACER, DEVICE CABLE CLAMP BRACKET *
50.586	CLIP, DEVICE CABLE 클립	50.734	BRACKET, DEVICE CABLE TERMINAL CLAMP *
50.587	FASTENER, DEVICE CABLE CLIP 패스너	50.745	BRACKET, DEVICE CABLE TERMINAL CLAMP MOUNTING *




ATTACHMENT HOSE & CABLE ADAPTATION (UPR

50.746	FASTENER, DEVICE HOSE TERMINAL BLOCK *
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라인
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라인
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너
97.182	FASTENER, DEVICE CABLE LOWER SHEAVE BRACKET *



ATTACHMENT HOSE & CABLE ADAPTATION (UPR



50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록




ATTACHMENT HOSE & CABLE ADAPTATION (UPR

50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.686	WIRE, DEVICE 와이어
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR *
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라일
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라일
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

ATTACHMENT HOSE
REFERENCE 75.015



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-407

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록



ATTACHMENT HOSE ADAPTATION (UPRIGHT)


50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라J
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라J
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

ATTACHMENT HOSE
REFERENCE

75.015



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-410

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅




ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

ATTACHMENT HOSE
REFERENCE 75.015



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50-432

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피벗
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록



ATTACHMENT HOSE ADAPTATION (UPRIGHT)


50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피벗
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

ATTACHMENT HOSE
REFERENCE

75.015



ATTACHMENT HOSE ADAPTATION (UPRIGHT)


50-439

50.006	SHEAVE, DEVICE HOSE UPPER 쉬브
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일
50.156	CLIP, DEVICE HOSE 클립
50.200	COUPLING, DEVICE HOSE 커플링
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅



ATTACHMENT HOSE ADAPTATION (UPRIGHT)

50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라일
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너




AUXILIARY VALVE LINES

50-590

- | | |
|--------|---|
| 50.072 | FITTING, 1ST AUXILIARY VALVE "B" PORT
피팅 |
| 50.073 | FITTING, 2ND AUXILIARY VALVE "B" PORT
피팅 |
| 50.425 | LINE, 1ST AUXILIARY VALVE "A" PORT
라인 |
| 50.426 | LINE, 1ST AUXILIARY VALVE "B" PORT
라인 |
| 50.427 | LINE, 2ND AUXILIARY VALVE "A" PORT
라인 |
| 50.428 | LINE, 2ND AUXILIARY VALVE "B" PORT
라인 |
| 50.430 | CLAMP, AUXILIARY VALVE LINES
클램프 |
| 50.431 | FASTENER, AUX VALVE LINES CLAMP
패스너 |
| 50.440 | FITTING, 1ST AUXILIARY VALVE "A" PORT
피팅 |




50.441	FITTING, 2ND AUXILIARY VALVE "A" PORT 피팅
--------	---



50.014	FASTENER, DEVICE HOSE CLIP TO BRACKET RH 패스너
50.015	CLIP, DEVICE LINE TO UPRIGHT 클립
50.016	FASTENER, DEVICE LINE TO UPRIGHT CLIP 패스너
50.023	LINE, DEVICE HYDRAULIC 라인
50.024	COUPLING, DEVICE RH HOSE (VALVE END) 커플링
50.054	COUPLING, DEVICE LH HOSE (VALVE END) 커플링
50.067	CLAMP, DEVICE HOSE TO BRACKET 클램프
50.076	COUPLING, DEVICE RH HOSE (REEL INLET) 커플링
50.077	LINE, DEVICE RH HYDRAULIC (VALVE TO REEL) 라인



50.087	FITTING, DEVICE LH HYDRAULIC HOSE 피팅
50.092	FASTENER, DEVICE HOSE TO BRACKET RH CLAMP 패스너
50.130	REEL ASSEMBLY, DEVICE RH HOSE 릴
50.131	FASTENER, DEVICE RH HOSE REEL 패스너
50.132	BRACKET, DEVICE HOSE REEL 브라켓
50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.205	BRACKET, DEVICE LINE CLAMP 브라켓
50.253	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.312	FITTING, DEVICE RH HOSE REEL INLET 피팅
50.501	FITTING, DEVICE HOSE REEL OUTLET 피팅
50.861	FITTING, AUXILIARY VALVE A PORT 피팅
51.438	CLIP, DEVICE HOSE 클립
59.003	RETAINER, DEVICE HOSE 리테이너
90.795	NUT, DEVICE HOSE CLAMP FASTENER 너트




- | | |
|--------|--|
| 50.019 | FASTENER, DEVICE HOSE DISCONNECT
패스너 |
| 50.105 | SEAL, DEVICE HOSE SWIVEL COUPLING PLUG
시일 |
| 50.108 | SEAL, DEVICE HOSE SWIVEL COUPLING INLET PORT
시일 |
| 50.203 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.253 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.292 | FITTING, DEVICE RH HYDRAULIC HOSE
피팅 |
| 50.298 | BRACKET, DEVICE HOSE TERMINAL
브라켓 |
| 50.643 | LINE, DEVICE UPPER (AT CARRIAGE)
라인 |
| 50.646 | LINE, DEVICE
라인 |




50.786	SEAL, DEVICE RH HOSE TERMINAL BLOCK PORT 시일
50.830	CAP, DEVICE HOSE REEL FITTING 캡
53.033	FASTENER, HOSE TERMINAL BRACKET 패스너
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
75.033	KIT, CARRIAGE TERMINATION PIPING - RH 킷
75.034	KIT, CARRIAGE TERMINATION PIPING - LH 킷




ATTACHMENT HOSE ADAPTATION (CARRIAGE)




**MODEL: GTX162
GEX162**
UPRIGHT: STANDARD




**MODEL: GTX162, GEX162
EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: TRIPLE STAGE & HI-LO




**MODEL: GTX162, GEX162
EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: TRIPLE STAGE




**MODEL: EPX162, CMP158
P152, TMX250, ESX250**
UPRIGHT: STANDARD



**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: STANDARD



**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: TRIPLE STAGE



**MODEL: EPX360, ECX360
GEX230, P232
GTS232, CQ230**
UPRIGHT: HI-LO


ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-791

- | | |
|--------|--|
| 50.203 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.253 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.301 | CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립 |



ATTACHMENT HOSE ADAPTATION (CARRIAGE)




ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-793

- | | |
|--------|--|
| 50.203 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.253 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |



ATTACHMENT HOSE ADAPTATION (CARRIAGE)




ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-794

50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.253	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.301	CLIP, DEVICE RH HOSE (AT CARRIAGE) 클립
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅



ATTACHMENT HOSE ADAPTATION (CARRIAGE)




ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-796

- | | |
|--------|--|
| 50.203 | LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인 |
| 50.301 | CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립 |
| 50.408 | COUPLING, DEVICE HOSE
커플링 |
| 50.410 | COUPLING, DEVICE HOSE
커플링 |



ATTACHMENT HOSE ADAPTATION (CARRIAGE)




ATTACHMENT HOSE ADAPTATION (CARRIAGE)

50-797

50.203	LINE, DEVICE HYDRAULIC (AT CARRIAGE) 라인
50.343	FITTING, DEVICE LH LINE 피팅
50.344	FITTING, DEVICE LH LINE 피팅
50.408	COUPLING, DEVICE HOSE 커플링
50.410	COUPLING, DEVICE HOSE 커플링
50.803	FITTING, DEVICE HYDRAULIC LINE 피팅
59.091	FITTING, DEVICE HYDRAULIC LINE 피팅



QUICK DISCONNECT FOR DEVICE HOSE ADAPTA




QUICK DISCONNECT FOR DEVICE HOSE ADAPTATION

50-798

- 59.092 QUICK DISCONNECT, DEVICE HOSE
퀵디스커넥트
- 59.131 FITTING, DEVICE LINE QUICK DISCONNECT
*
- 59.132 FITTING, DEVICE LINE QUICK DISCONNECT
*



SOLENOID VALVE FOR DEVICE HOSE ADAPTATI



14.567	WIRE, DEVICE SELECTOR VALVE SWITCH FEED 와이어
18.060	CLAMP, DEVICE SELECTOR VALVE CABLE 클램프
18.195	TERMINAL, DEVICE SELECTOR VALVE SWITCH FEED WIRE *
27.024	PLUG, DEVICE SELECTOR VALVE OPTIONAL OUTLET PORT 플러그
33.380	VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID 밸브
33.381	FASTENER, DEVICE SELECTOR VALVE 패스너
33.533	LINE, DEVICE SELECTOR VALVE "P" PORT HYDRAULIC *
33.535	LINE, DEVICE SELECTOR VALVE "R" PORT HYDRAULIC *
33.750	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅




SOLENOID VALVE FOR DEVICE HOSE ADAPTATI

33.751	FITTING, DEVICE SELECTOR VALVE C1 PORT 피팅
33.752	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.753	FITTING, DEVICE SELECTOR VALVE C2 PORT 피팅
33.754	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.755	FITTING, DEVICE SELECTOR VALVE "P" PORT 피팅
33.756	FITTING, DEVICE SELECTOR VALVE "R" PORT 피팅
33.761	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.763	FITTING, DEVICE SELECTOR VALVE C4 PORT 피팅
33.765	LINE, DEVICE SELECTOR VALVE C4 PORT HYDRAULIC 라인
33.768	LINE, DEVICE SELECTOR VALVE C1 PORT HYDRAULIC 라인
59.092	QUICK DISCONNECT, DEVICE HOSE 퀵디스커넥트
59.131	FITTING, DEVICE LINE QUICK DISCONNECT *
59.132	FITTING, DEVICE LINE QUICK DISCONNECT *



SIDE SHIFT ASSEMBLY




40.343	DECAL, ATTACHMENT SAFETY *
53.016	FITTING-LUB, SIDE SHIFTER MOVABLE FRAME SUPPORT SH 피팅
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.099	SIDE SHIFTER, DEVICE 사이드쉬프트
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
54.128	SPACER, SIDE SHIFTER MOVEABLE FRAME BEARING 스페이서
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링



54.218	HOOK, SIDE SHIFTER HANGER 후크
54.219	SPACER, SIDE SHIFTING BASE PLATE HANGER 스페이서
54.314	SPACER, SIDE SHIFTER CYLINDER REAR 스페이서

ASSEMBLY
COMPLETE — 53.020

PACKING KIT
INCLUDES ITEMS
MARKED "K" — 54.222




SIDESHIFT CYLINDER

53-198

53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.109	GLAND, SIDE SHIFTER CYLINDER 그랜드
53.110	RETAINER, SIDE SHIFTER CYLINDER GLAND 리테이너
53.117	BUSHING, SIDE SHIFTER CYLINDER GLAND 부싱
53.215	FITTING, SIDE SHIFTER CYLINDER ROD PORT 피팅
53.676	ROD, SIDE SHIFTER CYLINDER PISTON 로드
54.222	PACKING KIT, SIDE SHIFTER CYLINDER 패킹킷
54.416	BARREL, SIDE SHIFT CYLINDER 배럴
54.556	BALL, SIDE SHIFTER CYLINDER ROD PORT *



97.241	SET SCREW, SIDE SHIFTER CYLINDER ROD PORT *
--------	--




- | | |
|--------|---|
| 52.149 | NUT, SIDE SHIFTER CYLINDER ANCHOR PORT LINE FITTING
너트 |
| 53.023 | ANCHOR, SIDE SHIFTER CYLINDER ROD END
앵커 |
| 53.182 | FASTENER, SIDE SHIFTER HANGER
패스너 |
| 53.207 | LINE, SIDE SHIFTER CYLINDER ANCHOR PORT
라인 |
| 53.218 | LINE, SIDE SHIFTER CYLINDER ROD PORT
라인 |
| 53.600 | CYLINDER ASSEMBLY, INBOARD RH FORK
실린더 |
| 53.603 | CYLINDER ASSEMBLY, INBOARD LH FORK
실린더 |
| 54.080 | LINE, SIDE SHIFT CYLINDER ANCHOR PORT
라인 |
| 54.116 | LINE, SIDE SHIFT CYLINDER ROD PORT
라인 |




54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트

FORK STOP
PIN KIT — 34.359



KNOB TYPE - CASCADE




LEVER TYPE - HEBEI

FORK

66-058


- | | |
|--------|-----------------------------------|
| 34.350 | FORK ASSEMBLY
포크 |
| 34.359 | KIT, FORK STOP PIN (CAPTIVE)
킷 |




34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 시일과팩킹킷
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너
96.274	WASHER, LIFT CYLINDER CHECK VALVE 워셔



SECONDARY CYLINDER ASSEMBLY



- 66.395 CHECK VALVE, FINAL LIFT CYLINDER
체크밸브
- 66.397 WASHER, FINAL LIFT CYLINDER CHECK VALVE
와셔
- 66.398 SNAP RING, FINAL LIFT CYLINDER CHECK VALVE
스냅링
- 66.400 CYLINDER ASSEMBLY, FINAL LIFT
실린더
- 66.401 BARREL, FINAL LIFT CYLINDER
배럴
- 66.402 PACKING KIT, FINAL LIFT CYLINDER
패킹킷
- 66.403 PISTON ROD, FINAL LIFT CYLINDER
피스톤로드
- 66.413 SPACER, FINAL LIFT CYLINDER PISTON ROD
스페이서
- 66.444 GLAND, FINAL LIFT CYLINDER
그랜드



28.746	FITTING, LIFT CYLINDER LINE 피팅	34.107	ANCHOR, LIFT CHAIN 앵커
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
31.545	FITTING, LIFT CYL FLOW CONTROL VALVE INLET 피팅	34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너
31.546	FITTING, LIFT CYL FLOW CONTROL VALVE OUTLET 피팅	34.186	ROLLER, UPRIGHT 롤러
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.000	UPRIGHT & LIFT CYL ASSEMBLY 엄라이트와실린더	34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아웃레일	66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
34.013	ROLLER, UPRIGHT 롤러	66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
34.014	SHIM, UPRIGHT ROLLER 심	66.167	SHIM, LIFT CYLINDER UPPER 심
34.037	CAP, UPRIGHT TRUNNION 캡	66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너	66.505	CARTRIDGE, LIFT CYLINDER FLOW CONTROL VALVE *
34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너	66.507	TEE, LIFT CYLINDER LINE *
34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일	66.508	SPACER, LIFT CHAIN ANCHOR FASTENER *
34.084	SHEAVE, LIFT CHAIN 쉬브	91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
34.101	CHAIN, LIFT 체인	91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너




STANDARD UPRIGHT

93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너
94.655	FASTENER, LIFT CYLINDER LINE JUNCTION BLOCK 패스너



TRIPLE STAGE UPRIGHT



28.726	SHEAVE, LIFT CYLINDER HOSE 쉬브	34.042	FASTENER, LIFT CYLINDER (UPPER) 패스너
28.727	PIVOT, LIFT CYLINDER HOSE SHEAVE 피봇	34.050	INNER RAIL WELDED ASSEMBLY, UPRIGHT 인너레일
28.729	LINE, LIFT CYLINDER 라인	34.081	SPACER, LIFT CHAIN SHEAVE CARRIER 스페이서
28.744	FITTING, LIFT CYLINDER LINE 피팅	34.084	SHEAVE, LIFT CHAIN 쉬브
28.746	FITTING, LIFT CYLINDER LINE 피팅	34.100	CARRIER, LIFT CYLINDER CHAIN SHEAVE 캐리어
31.217	LINE, LIFT CYLINDER INLET FITTING 라인	34.101	CHAIN, LIFT 체인
31.545	FITTING, LIFT CYL FLOW CONTROL VALVE INLET 피팅	34.102	FASTENER, SHEAVE CARRIER 패스너
31.546	FITTING, LIFT CYL FLOW CONTROL VALVE OUTLET 피팅	34.107	ANCHOR, LIFT CHAIN 앵커
31.549	LINE, LIFT CYL FLOW CONTROL VALVE INLET 라인	34.108	FASTENER, LIFT CHAIN TO ANCHOR 패스너
34.000	UPRIGHT & LIFT CYL ASSEMBLY 업라이트와실린더	34.111	FASTENER, CHAIN SHEAVE SHAFT (CARRIER) 패스너
34.001	OUTER RAIL WELDER ASSEMBLY, UPRIGHT 아웃레일	34.113	SHAFT, LIFT CHAIN SHEAVE (CARRIER) 샤프트
34.013	ROLLER, UPRIGHT 롤러	34.150	CHAIN, UPRIGHT RAIL LIFT 체인
34.014	SHIM, UPRIGHT ROLLER 심	34.186	ROLLER, UPRIGHT 롤러
34.037	CAP, UPRIGHT TRUNNION 캡	34.200	INTERMEDIATE RAIL WELDED ASSEMBLY, UPRIGHT 인터레일
34.038	FASTENER, UPRIGHT TRUNNION CAP 패스너	34.271	FASTENER, LIFT CYLINDER LOWER 패스너




TRIPLE STAGE UPRIGHT

34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.444	VALVE ASSEMBLY, LIFT CYLINDER FLOW CONTROL 밸브
66.116	SPACER, LIFT CHAIN ANCHOR 스페이서
66.147	VALVE, FINAL LIFT CYLINDER PORT FLOW CONTROL 밸브
66.167	SHIM, LIFT CYLINDER UPPER 심
66.212	SPACER, LIFT CYLINDER FASTENER 스페이서
66.215	VALVE, LIFT CYLINDER PORT FLOW CONTROL 밸브
66.400	CYLINDER ASSEMBLY, FINAL LIFT 실린더
66.438	SHEAVE, HOSE 쉬브
66.505	CARTRIDGE, LIFT CYLINDER FLOW CONTROL VALVE *
66.506	CLAMP, LIFT CYLINDER *
66.507	TEE, LIFT CYLINDER LINE *
66.508	SPACER, LIFT CHAIN ANCHOR FASTENER *
91.411	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
91.414	RETAINER, LIFT CHAIN TO ANCHOR FASTENER 리테이너
93.984	FASTENER, LIFT CHAIN ANCHOR 패스너
94.054	FASTENER, LIFT CYLINDER (UPPER) 패스너
94.655	FASTENER, LIFT CYLINDER LINE JUNCTION BLOCK 패스너
97.179	FASTENER, LIFT CYLINDER CLAMP *



PRIMARY CYLINDER ASSEMBLY



34.400	CYLINDER ASSEMBLY, LIFT 실린더
34.401	BARREL, LIFT CYLINDER 배럴
34.402	SEAL & PACKING KIT, LIFT CYLINDER 시일과팩킹킷
34.466	SPACER, LIFT CYLINDER FEED TUBE 스페이서
34.475	ROD, LIFT CYLINDER 로드
34.476	BEARING, LIFT CYLINDER ROD 베어링
34.478	GLAND, LIFT CYLINDER 그랜드
34.864	CHECK VALVE, LIFT CYLINDER 체크밸브
34.867	RETAINER, LIFT CYLINDER CHECK VALVE 리테이너




PRIMARY CYLINDER ASSEMBLY

66.502	CUSHION, LIFT CYLINDER 쿠션
96.274	WASHER, LIFT CYLINDER CHECK VALVE 옥셔




EXTENTION FORK



EXTENTION FORK

66-999

- | | |
|--------|---|
| 34.704 | EXTENSION, FORK ASSEMBLY COMPLETE
익스텐션 |
| 66.465 | PIN, EXTENTION FORK
핀 |
| 66.466 | PIN, EXTENTION FORK
핀 |



UNITROL PEDAL INSTALLATION

75-(17)000

- | | |
|--------|---|
| 03.903 | BRACKET, ACCELERATOR PEDAL ROLLER
브라켓 |
| 03.904 | FASTENER, ACCELERATOR PEDAL ROLLER BRACKET
패스너 |
| 22.754 | PAD, UNITROL PEDAL
패드 |
| 22.755 | SHAFT, UNITROL PEDAL PAD PIVOT
샤프트 |
| 22.756 | FASTENER, UNITROL PEDAL PAD PIVOT
패스너 |
| 22.757 | PLATE, UNITROL PEDAL PAD STOP
플레이트 |
| 22.758 | SEAL, UNITROL PEDAL PAD STOP PLATE
시일 |
| 22.759 | FASTENER, UNITROL PEDAL PAD STOP PLATE
패스너 |
| 22.760 | HARNESS, UNITROL PEDAL SWITCH WIRING
하네스 |




UNITROL PEDAL MOUNTING

22.761	NUT, UNITROL PEDAL PAD TENSION SPRING RETAINER 너트
22.763	RETAINER, UNITROL PEDAL PAD TENSION SPRING 리테이너
22.764	GUIDE, UNITROL PEDAL PAD TENSION SPRING 가이드
22.765	SPRING, UNITROL PEDAL PAD TENSION 스프링
22.769	BEARING, UNITROL PEDAL BRACKET 베어링
22.770	BRACKET, UNITROL PEDAL 브라켓
22.880	RETAINER, UNITROL SWITCH WIRE 리테이너
22.881	WASHER, UNITROL PEDAL PAD STOP PLATE FASTENER 와셔
22.882	FASTENER, UNITROL PEDAL SWITCH 패스너
22.883	CONNECTOR, UNITROL PEDAL SWITCH WIRING HARNESS 커넥터
22.884	LOCK, UNITROL PEDAL SWITCH WIRING HARNESS CONNECTO 로크
22.885	GROMMET, UNITROL PEDAL WIRING HARNESS 그로멧
22.889	BUMPER, UNITROL PEDAL PAD 범퍼
22.916	FASTENER, UNITROL SWITCH WIRE RETAINER 패스너
22.917	NUT, UNITROL SWITCH WIRE RETAINER FASTENER 너트



UNITROL PEDAL MOUNTING




UNITROL INSTALLATION

75-(17)005

- | | |
|--------|---|
| 22.768 | PIVOT, UNITROL PEDAL
피벗 |
| 22.771 | SPRING, UNITROL PEDAL RETURN
스프링 |
| 22.772 | BRACKET, UNITROL PEDAL MOUNTING
브라켓 |
| 22.773 | WASHER, UNITROL PEDAL PIVOT FASTENER
와셔 |
| 22.774 | FASTENER, UNITROL PEDAL PIVOT
패스너 |
| 22.886 | RETAINER, UNITROL PEDAL RETURN SPRING
리테이너 |
| 22.888 | FASTENER, UNITROL PEDAL MOUNTING BRACKET
패스너 |




VARIABLE RELIEF VALVE INSTALLATION



30.956	SEAL, RELIEF VALVE PLUG 시일	33.712	COUPLING, DEVICE RELIEF VALVE DISCHARGE HOSE 커플링
33.054	PLUG, RELIEF VALVE PORT 플러그	33.713	LINE, DEVICE RELIEF VALVE DISCHARGE 라인
33.055	SEAL, RELIEF VALVE PORT PLUG 시일	33.714	COUPLING, DEVICE RELIEF VALVE DISCHARGE LINE 커플링
33.600	RELIEF VALVE, DEVICE VARIABLE PRESSURE 릴리프밸브	33.732	FITTING, DEVICE RELIEF VALVE INLET 피팅
33.603	BRACKET, DEVICE CARIABLE RELIEF VALVE 브라켓	33.733	FITTING, DEVICE RELIEF VALVE INLET 피팅
33.604	FASTENER, DEVICE VARIABLE RELIEF VALVE 패스너	33.900	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.617	SPACER, DEV VARIABLE RELIEF VAL BRKT 스페이서	33.934	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.661	FITTING, DEVICE RELIEF VALVE OUTLET PORT 피팅	33.934	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.701	COUPLING, DEVICE RELIEF VALVE INLET LINE 커플링	33.935	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.702	LINE, DEVICE RELIEF VALVE INLET 라인	75.311	KIT, RELIEF VALVE INSTALLATION 킷
33.703	COUPLING, DEVICE RELIEF VALVE INLET LINE 커플링	90.854	BOLT, DEVICE MOUNTING BRACKET FASTENER 볼트
33.706	FITTING, DEVICE RELIEF VALVE INLET PORT 피팅	90.855	LOCKWASHER, DEVICE MOUNTING BRACKET FASTENER 로크와셔
33.707	SEAL, DEVICE RELIEF VALVE INLET PORT FITTING 시일	91.221	NUT, DEV VARIABLE RELIEF VALVE FASTENER 너트
33.710	FITTING, DEVICE RELIEF VALVE DISCHARGE PORT 피팅	91.712	LOCKWASHER, DEVICE RELIEF VALVE FASTENER 로크와셔
33.711	SEAL, DEVICE RELIEF VALVE DISCHARGE PORT FTG 시일		



DEVICE HYDRAULIC PRESSURE GAUGE INSTALL





- | | |
|--------|--|
| 33.720 | GAUGE, DEVICE HYDRAULIC PRESSURE
게이지 |
| 33.724 | FITTING, DEVICE HYD PRESSURE GAUGE
피팅 |
| 75.301 | DEVICE, HYDRAULIC PRESSURE GAUGE
디바이스 |



SEAT OPERATED BRAKE SWITCH

ENGINE
SHUTDOWN KIT — 75.046




SEAT OPERATED BRAKE SWITCH

75-001


- | | |
|--------|--|
| 13.135 | SWITCH, SEAT SAFETY
스위치 |
| 15.483 | CLAMP, SEAT SWITCH INSTALLATION CABLE
클램프 |
| 15.646 | HARNESS, ENGINE DISCONNECT
하네스 |
| 75.046 | KIT, SEAT ACTUATED ENGINE SHUTDOWN
킷 |
| 95.916 | FASTENER, SEAT SWITCH
패스너 |
| 95.917 | NUT, SEAT SWITCH FASTENER
너트 |



SEAT OPERATED BRAKE



STANDARD SEAT




DETAIL C

- | | |
|--------|--|
| 15.490 | HARNESS, SEAT ACTUATED ENGINE SHUTDOWN WIRING
하네스 |
| 18.087 | CLIP, SEAT SAFETY SWITCH WIRE
클립 |



SEAT OPERATED BRAKE




15.490 HARNESS, SEAT ACTUATED ENGINE SHUTDOWN WIRING
하네스


18.087 CLIP, SEAT SAFETY SWITCH WIRE
클립



SEAT OPERATED BRAKE SWITCH



39.706




DETAIL A

39.719

**ASSEMBLY
COMPLETE**

75.046

**ENGINE
SHUTDOWN KIT
INCLUDES ITEMS
MARKED "K"**



VIEW A

SEAT OPERATED BRAKE SWITCH

75-012

- | | |
|--------|---|
| 39.706 | SUPPORT, SEAT
서포트 |
| 39.719 | SEAT ASSEMBLY
시트 |
| 75.046 | KIT, SEAT ACTUATED ENGINE SHUTDOWN
킷 |