


N.V. ISEKI EUROPE S.A.
Sterrebeekstraat 179 D4
B-1930 Zaventem - Belgium



PARTS CATALOGUE

ISEKI TRACTOR

TS 3110



1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

HOW TO USE THIS PARTS CATALOGUE

CATALOGUE CONSTRUCTION

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
A	B	C							E

- A. Ref. No. : It is a reference number to find parts in the drawings.
- B. Parts No. : Every part has its own 12-digit code number with which it is computer-controlled.
Parts which have "V" at their code numbers' head are purchasable in the market.
- C. Description: Names, sizes, functions and other meanings of parts are found in this column.
"JH" and "RH" of parts are given by facing to the tractor-moving-forward direction or looking at them mounted on the tractor.
Components of an assembled part (ASS'Y or SET) are listed set in from ASS'Y or SET name and headed with " . " as in the following example:

(Example)

JOINT (A) ASS'Y

. YOKE (A), SPLINE

. JOINT, CROSS

. YOKE (B), SPLINE

. RING, SNAP/C TYPE 20

Components of
JOINT (A) ASS'Y

Abbreviations which are used in this column are explained in Table page 2

- D. Q'ty: This column specifies the quantity of a part required for one tractor. "AR" is the abbreviation of "AS REQUIRED".

- E. Remarks: Additional notices are said here if any.

Explanation of symbols:

		Page
Fig. 19	FEED PUMP; INJECTION PUMP Pompe a main	39
Fig. 20	STARTER Demarreur	41
Fig. 21	GENERATOR (12V-10A) Dynaño	43
Fig. 21A	GENERATOR (12V-20A) Dynamo	44
CHASSIS		
Fig. 22	RADIATOR Radiateur	47
Fig. 23	INTAKE SYSTEM Filtre a air	49
Fig. 24	EXHAUST AND INTAKE SYSTEM Silencieux et tuyau d'echappement	51
Fig. 25	BONNET Carenage	53
Fig. 26	FRAME AND FAN COVER Chassis	57
Fig. 27	AXLE BRACKET AND BALANCE WEIGHT (S, D TYPE) Support d'essieu	61
Fig. 28	AXLE BRACKET AND BALANCE WEIGHT (F-U, F-DU, LF-DU TYPE) Support d'essieu	63
Fig. 29	FRONT AXLE (S, D TYPE) Essieu avant	65
Fig. 30	FRONT WHEEL (S, D TYPE) Jante avant	69
Fig. 31	AXLE HOUSING AND BEVEL CASE (F-U, F-DU TYPE) Carter de pont avant	71
Fig. 32	FINAL CASE AND KNUCKLE ARM SYSTEM (F-U, F-DU TYPE) Reducteur de roue avant	73
Fig. 33	DIFFERENTIAL CASE SYSTEM (F-U, F-DU TYPE) Commande et blocage du differentiel	77
Fig. 34	FRONT WHEEL DRIVING SYSTEM (F-U, F-DY TYPE) .. Jante avant	79

		Page
Fig. 35	STEERING WHEEL (S, D TYPE) Direction	83
Fig. 36	STEERING WHEEL (F-U, F-DU, LF-DU TYPE) Direction	85
Fig. 37	METER PANEL Tableau de board	87
Fig. 38	CLUTCH HOUSING (S TYPE) Embrayage	89
Fig. 39	CLUTCH HOUSING (F-U TYPE) Embrayage	91
Fig. 40	CLUTCH HOUSING (D TYPE) Embrayage	95
Fig. 41	CLUTCH HOUSING (F-DU TYPE) Embrayage	99
Fig. 41A	CLUTCH HOUSING (LF-DU TYPE) Embrayage	103
Fig. 41B	CLUTCH HOUSING (LF-DU TYPE) Embrayage	107
Fig. 42	CHANGE GEAR SYSTEM (F-U, F-DU, LF-DU TYPE) .. Lever de vitesses avant	111
Fig. 43	DRIVE SHAFT SYSTEM (F-U, F-DU, LF-DU TYPE) ... Demi arbre avant	113
Fig. 44	CLUTCH PEDAL Pedale d'embrayage	115
Fig. 45	FUEL TANK Reservoir	119
Fig. 46	THROTTLE SYSTEM Accelerateur	121
Fig. 47	TRANSMISSION CASE Voite de vitesses	123
Fig. 48	TRANSMISSION GEAR (S, F-U TYPE) Arbres et demultiplicateur	127
Fig. 48A	TRANSMISSION GEAR (S, F-U TYPE) Arbres et demultiplicateur	131
Fig. 49	TRANSMISSION GEAR (D, F-DU, LF-DU TYPE) Arbres et demultiplicateur (D. ~ #101288, F. ~ #004182)	135
Fig. 49A	TRANSMISSION GEAR (D, F-DU, LF-DU TYPE) Arbres et demultiplicateur (D. #101289~, F. #004183~)	139
Fig. 50	POWER TAKE OFF Arbre de prise de force	143

		Page
Fig. 51	GEAR SHIFT Mechanisme de changement	147
Fig. 52	REAR AXLE HOUSING Carter de pont arriere	151
Fig. 53	DIFFERENTIAL GEAR..... Commande et blocage du differentiel	153
Fig. 54	STEP AND BRAKE SYSTEM (S, D TYPE) Pedales de freins	155
Fig. 55	STEP AND BRAKE SYSTEM (F-U, F-DU, LF-DU TYPE) Pedales de freins	159
Fig. 56	BRAKE (E41, E43) Frein	163
Fig. 56A	BRAKE (E21, E23) Frein	165
Fig. 57	HYDRAULIC SYSTEM (S, D TYPE) Mecanisme de relevage hydraulique	169
Fig. 58	HYDRAULIC SYSTEM (F-U, F-DU, F-DU TYPE)..... Mecanisme de relevage hydraulique	171
Fig. 59	HYDRAULIC LIFT ARM Relevage bras (S. ~ #002730, D. ~ #101407, F. ~ #005703)	173
Fig. 59A	HYDRAULIC LIFT ARM Relevage bras (S. #002731~, D. #101408~, F. #005704~)	177
Fig. 60	HYDRAULIC PIPING (S, D TYPE) Hydraulique tuyautage	181
Fig. 61	HYDRAULIC PIPING (F-U, F-DU, LF-DU TYPE) Hydraulique tuyautage	185
Fig. 62	FENDER Aile	189
Fig. 63	REAR WHEEL Jante arriere	193
Fig. 64	ELECTRICAL SYSTEM (1) Equipement electrique	195
Fig. 65	ELECTRICAL SYSTEM (2) Equipement electrique	197
Fig. 66	ELECTRICAL SYSTEM (3) Equipement electrique	201
Fig. 67	WIRING DIAGRAM Cablage dagramme	205
Fig. 68	BATTERY SYSTEM Batterie	207

		Page
Fig. 69	THREE POINT SYSTEM Attelage trois point	209
Fig. 70	ACCESSORIES AND TOOLS Outils	213
Fig. 71	WEIGHT Contrepoids	215
Fig. 72	STEERING GEAR BOX (MECHANICAL) Boîtier de direction	217
Fig. 73	STEERING GEAR BOX (POWER) Boîtier de direction	219
Fig. 74	CONTROL VALVE Soupape de contrôle	223
Fig. 75	HYDRAULIC SYSTEM (G-type) Mécanisme de relevage hydraulique	227
Fig. 76	LIFT ARM AND CYLINDER (G-type) Relevage bras	229
Fig. 77	DRAFT AND POSITION LEVER SYSTEM (G-type) Lévier de commande	231
Fig. 78	SPRING CASE SYSTEM (G-type) Carter de ressort	233
Fig. 79	SUB CONTROL LEVER SYSTEM (G-type) Lévier de sous-commande	237
Fig. 80	CONTROL VALVE (G-type) Soupape de contrôle	239
Fig. 81	SUB CONTROL VALVE (G-type) Soupape de sous-contrôle	241
Fig. 82	RETURN CHECK VALVE (G-type) Robinet de trop-plein retenue	243

ENGINE
Moteur


3ADIA-01

1
2
3
4
5

6

7



Fig.1 CYLINDER HEAD AND OTHER PARTS
Culasse



Ref.No. Réf.Nº	Parts No. Pièces Nº	Description Désignation	Q'ty Quant	Remarks Remarques
1- 1	5681-111-0096-0	HEAD, CYL ASSY Cylindre	1	511110-0960
1- 3	5691-112-9006-0	CAP, SEALING/44.5 Pastille	1	911129-0060
1- 3-1	5691-112-9081-0	CAP, SEALING/16 Pastille	3	911129-0810
1- 3-2	5691-112-9082-0	CAP, SEALING/18 Pastille	3	911129-0820
1- 3-3	5691-112-9083-0	CAP, SEALING/12 Pastille	3	911129-0830
1- 4	5690-986-0522-0	PLUG, PLATE Boucheau	3	909860-5220
1- 5	5690-920-2308-0	PLUG, SCREW Poinçon	1	909202-3080
1- 6	5690-992-0843-0	PACKING, PLUG Joint	1	909920-8430
1- 7	5691-171-5054-0	INSERT, VALVE SEAT INLET Insertion	3	911715-0540
1- 8	5690-171-1066-0	INSERT, VALVE SEAT EXH Insertion	3	911711-0660
1- 9	5691-172-1113-0	GUIDE, INLET VALVE Guide soupape	3	911721-1130
1- 9-1	5691-172-1159-0	GUIDE, EXH VALVE Guide soupape	3	911721-1590
1-10	5690-966-4034-0	PLUG Boucheau	2	909664-0340
1-11	5681-256-9004-0	SEAL, VALVE Joint	6	512569-0040
1-14	5691-115-0801-0	PLUG, HOT ASSY Bougie à incandescence	3	911150-8010
1-21	5691-114-5624-0	GASKET, CYL HEAD Joint de culasse	1	911145-6240
1-22	5690-980-2514-0	BOLT Vis	15	909802-5140
1-22a	5680-900-9036-0	BOLT Vis	15	Ⓐ 509009-0360 F. #543789 ~
1-29	5681-117-0142-1	COVER, CYL HEAD ASSY Cache culbuteurs	1	511170-1421
1-30	5691-175-0043-0	CAP, OIL FILLER ASSY Bouchon	1	911750-0430
1-31	5691-117-9105-0	WASHER Rondelle	2	911179-1050
1-32	5691-117-9030-0	PACKING, HEAD COVER NUT Joint	2	911179-0300
1-34	5690-983-0212-0	STUD, HEAD COVER Goujon	2	909830-2120
1-35	5691-117-5011-0	NUT, HEAD COVER Erou	2	911175-0110
1-49	5691-117-3137-0	PACKING, HEAD COVER Joint	1	911173-1370 new; 63M-173-1170
1-50	5688-688-5375-0	MARK, CAUTION Etiquette	1	585885-3750

Fig.2 CYLINDER BODY AND OTHER PARTS

Bloc-cylinders



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
2- 1	5691-121-0058-1	BODY, CYL ASSY Carter	1	511210-0581
2- 2	5690-980-2591-0	BOLT, BEARING CAP Vis	8	909802-2910
2- 6	5691-121-9195-0	CAP, SEALING/38 Pastille	1	911219-1950
2- 6-1	5691-121-9005-0	CAP, SEALING/38.1 Pastille	1	911219-0050
2- 6-2	5691-121-9006-0	CAP, SEALING/31.75 Pastille	3	911219-0060
2- 6-3	5691-112-9006-0	CAP, SEALING/46 Pastille	2	911129-0060
2- 8	5690-966-4034-0	PLUG, TAPPET CHAMBER Boussieu	3	909664-0340
2- 9	5690-920-1318-0	PLUG, OIL GALLERY Boussieu	2	909201-3180
2-10	5690-920-1328-0	PLUG, TAPPET CHAMBER Boussieu	2	909201-3280
2-10-1	5690-920-1345-0	PLUG, TAPPET CHAMBER Boussieu	3	909201-3450
2-11	5690-986-4015-0	PLUG, OIL GALLERY Boussieu	2	909864-0150
2-12	5690-920-1056-0	PLUG, CAM BEARING Boussieu	1	909201-0560
2-26	5690-922-0605-0	NIPPLE Raccord	1	909220-6050
2-28	5691-131-1806-0	PLATE, F CYL BODY Plaque ar.	1	911311-8060
2-29	5681-131-2011-0	PACKING, PLATE TO CYL BODY Joint	1	511312-0110
2-31	5690-815-1030-0	PIN, STRAIGHT Goupille	2	908151-0300
2-32	5690-190-0822-0	BOLT, SEMS Vis	3	901900-8220
2-33	5690-411-0822-0	STUD, INJ PUMP Goupion	1	904110-8220
2-36	5690-990-2299-0	NIPPLE, ROCKER OIL FEED Raccord	1	909902-2990
2-37	5690-816-1032-0	PIN, STRAIGHT Goupille	1	908161-0320
2-54	5690-960-6535-0	BOLT, REAMER/L = 43 Vis	1	909606-5350
X2-78	~~5690-992-4449-0~~ ~~5680-962-3036-0~~	SEAL, CRANK R. Joint	1	909924-4490
2-81	5691-134-1809-0	PLATE, R. Plaque ar.	1	911341-8090
2-84	5690-980-0684-0	BOLT/L = 25 Vis	3	909800-6840
2-84-1	5690-191-1030-0	BOLT, SEMS Vis	3	901911-0300
2-84-2	5690-193-1235-0	BOLT, SEMS Vis	2	901931-2350
2-86	5690-915-0510-0	WASHER, SP Rondelle frein	3	90915-05100
2-87	5690-911-0510-0	NUT, REAMER BOLT Ecran	1	909110-5100
2-88	5690-915-0510-0	WASHER, SP/M10 Rondelle frein	1	909150-5100
2-93	5681-372-1028-0	PIPE, WATER DRAIN Conduit	1	513721-0280
2-99	5691-125-8108-0	PACKING Joint	2	911258-1080


* Applicable parts with specified chassis numbers : 2 WD # 002431-
4 WD # 005715-

Order 82-07 (2/4)
March 31, '82. *

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
3- 1	5681-131-1024-0	CASE, TIMING GEAR Carter de distribution	1	511311-0240
3- 2	5691-132-1137-0	COVER, GEAR CASE Couvercle	1	911321-1370
3- 3	5691-132-2066-0	PACKING Joint	1	911322-0660
3- 4	5690-190-0612-0	BOLT, SEMS Vis	2	901900-6120
3- 5	5690-411-0840-0	STUD, TACHOMETER/M8 x 40 Goujon	1	904110-8400
	5690-411-0820-0	STUD, TACHOMETER/M8 x 20 Goujon	1	904110-8200
3- 5-1	5690-411-0820-0	STUD, OIL PUMP/M8 x 20 Goujon	3	904110-8200
3- 8	5691-131-2046-0	PACKING Joint	1	911312-0460
X 3- 9	~~5690-992-4448-0~~ ~~5680-462-5074-0~~	SEAL, OIL Bague d'étanchéité	1	909924-4480
3-12	5691-132-7045-0	POINTER, TIMING GEAR Pointe	1	911327-0450
3-14	5691-131-2803-0	PACKING Joint	1	911312-8030
3-17	5680-903-0015-0	BOLT, SEMS Vis	7	509030-0150
3-17-2	5690-105-5855-0	BOLT Vis	2	901055-8550
3-19	5690-915-0508-0	WASHER, SP/M8 Rondelle frein	2	909150-5080
3-22	5691-132-2083-0	PACKING Joint	1	911322-0830
3-23	5690-911-0508-0	NUT Ecran	3	909110-5080
3-24	5690-105-5875-0	BOLT/M8 x 75 Vis	4	901055-8750
3-25	5690-915-0508-0	WASHER, SP Rondelle frein	4	909150-5080
3-61	5691-252-5801-0	GEAR, OIL PUMP Pignon de pompe	1	912525-8010
3-62	5691-253-3801-0	SHAFT, GEAR Axe	1	912533-8010
3-63	5690-009-0667-0	BEARING, BALL Roulement radial	2	900090-6670
* Applicable parts with specified chassis numbers : 2 WD # 002731 - 4 WD # 005715 -				

Fig.4 OIL PAN, CRANK CASE AND OTHER PARTS


Carter d'huile & Carter moteur



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
4- 1	5681-136-0312-0	PAN, OIL ASSY Pompe à huile	1	511360-3120
4- 3	5690-966-2012-0	• PLUG, OIL DRAIN Purgeur	2	909662-0120
4- 4	5690-992-0651-0	• PACKING, OIL DRAIN Joint	2	909920-6510
4- 5	5690-815-1222-0	PIN, STRAIGHT Goupille	2	908151-2220
4- 6	5681-121-5031-1	CASE, CRANK Carter	1	511215-0311
4-17	5691-136-7603-0	PACKING, OIL PAN Joint	1	911367-6030
4-29	5690-205-0616-0	BOLT, OIL PAN Vis	27	902050-6160
4-30	5690-915-0506-0	WASHER, SP Rondelle frein	27	909150-5060
4-36	5681-176-0053-1	GAUGE, OIL LEVEL ASSY Jauge	1	511760-0531
4-37	5690-992-0609-0	PACKING, LEVEL GAUGE Joint	1	909920-6090
4-42	5690-106-5845-0	BOLT/M8 X 45 Vis	10	901065-8450
	5690-106-5880-0	BOLT/M8 X 80 Vis	4	901065-8800
	5690-960-2070-0	BOLT/M8 X 138 Vis	3	909602-0700
	5690-960-0082-0	BOLT/M8 X 129 Vis	1	909600-0820
4-43	5690-915-0508-0	WASHER, SP Rondelle frein	18	909150-5080
4-44	5688-588-5357-0	MARK, OIL PAN Étiquette	1	585885-3750

Fig.5 OIL PUMP AND FIXING PARTS


Pompe a huile



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
5- 1	5691-310-0637-0	PUMP, OIL ASSY Pompe à huile	1	913100-6370
5- 6	5691-312-0601-0	ROTOR SET Rotor	1	913120-6010
5- 7	5691-312-8079-0	PINION, OIL PUMP DRIVE Pignon	1	913128-0790
5- 8	5690-987-8084-0	PIN Clouville	1	909878-0840
5-10	5691-311-9609-0	SPACER, OIL PUMP Entrâtoise	1	913119-6090
5-13	5691-311-3086-0	COVER, OIL PUMP Couvercle	1	913113-0860
5-14	5690-104-5875-0	BOLT/M8 x 75 Vis	2	901045-8750
5-14-1	5690-105-5850-0	BOLT/M8 x 50 Vis	2	901055-8500
5-15	5690-915-0508-0	WASHER, SP/M8 Rondelle train	4	909150-5080
5-16	5690-916-4508-0	WASHER/M8 Rondelle	2	909164-5080
5-22	5691-314-3603-0	GAUZE, OIL STRAINER Passoire	1	913143-6030
5-23	5691-314-1604-1	CASE, OIL STRAINER Carter	1	913141-6041
5-26	5690-205-0812-0	BOLT Vis	1	902050-8120
5-27	5690-915-0508-0	WASHER, SP Rondelle train	1	909150-5080
5-41	5690-205-0825-0	BOLT, SEMS Vis	2	902050-8250

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
6- 1	5681-151-0010-0	BEARING KIT, CRANK/STD Cousinnet	1	511510-0100
	5681-154-0010-0	BEARING KIT, CRANK/0.50 US Cousinnet	1	511540-0100
	5681-156-0010-0	BEARING KIT, CRANK/1.00 US Cousinnet d'appui	1	511560-0100
6- 2	5691-158-1057-0	BEARING, THRUST Rondelle	2	911581-0570
6- 3	5681-211-1119-0	PISTON/STD Piston	3	512111-1190
	5681-211-1119-0	PISTON/0.5 OS Piston	3	512114-1190
	5681-211-1119-0	PISTON/1.0 OS Piston	3	512116-1190
6- 4	5681-212-1010-0	RING, PISTON SET/STD Segmentation	3	512121-0100
	~~5681-212-4010-0~~	~~RING, PISTON SET/0.5 OS Segmentation~~	~~3~~	~~512124-0100~~
	5681-212-6010-0	RING, PISTON SET/1.0 OS Segmentation	3	512126-0100
6- 6	5681-221-1009-0	PIN, PISTON Axe de piston	3	512211-0090
6- 7	5680-958-7001-0	RING, SNAP Collat d'axe	6	509587-0010
X 6- 8	~~5681-222-0020-0~~ ~~5681-222-0023-0~~ ~~5681-223-0035-0~~ ~~5691-225-1062-0~~ ~~5681-225-1005-0~~	ROD, CONN ASSY Bielle	3	512230-0250 info n° 82-07 (1/4)
X 6- 9	~~5681-223-0035-0~~	BUSH, SMALL END Cousinnet	3	912251-0620 (E) info n° 82-07 (3/4) March 31, '82 *
X 6-10	~~5681-223-5006-0~~ ~~5681-223-5009-0~~	BOLT Vis	6	512235-0060 " " " " *
6-13	5681-227-1005-0	BEARING, CONN ROD SET Cousinnet de bielle	3	512271-0050
6-14	5681-231-0080-0	CRANKSHAFT ASSY Vilebrequin	1	512310-0080
6-17	5690-815-1222-0	PIN Goupille	1	908151-2220
6-19	5680-980-1001-0	BEARING, BALL Roulement, radial	1	509801-0010
6-25	5691-233-0809-0	FLYWHEEL ASSY Volant d'inertie ensemble	1	912330-8090
6-27	5691-233-3036-1	GEAR, RING Couronne	1	912333-0361
6-33	5680-900-0018-1	BOLT, FLYWHEEL Vis	6	509000-0181
6-34	5681-233-6002-0	WASHER Rondelle	1	512336-0020
6-36	5690-803-0743-0	KEY, FEATHER Clavette	1	908030-7430
6-37	5691-252-1042-0	GEAR, CRANK Pignon	1	912521-0420
6-38	5691-236-2019-0	THROWER, OIL Bague d'étanchéité	1	912362-0390
6-60	5691-237-0807-0	PULLEY, CRANK Poulie	1	912370-8070
6-64	5690-980-2606-0	BOLT, PULLEY Vis	1	909802-6060
* Applicable parts with specified chassis numbers: 2WD # 002431 - see attached sheet 4WD # 006030 -				
6-10	5681-223-0035-0	NUT	6	(E) info n° 82-07 (3/4) March 31, '82 *


Fig.7 VALVE MECHANISM
Distribution



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
7-1	5681-251-1022-0	CAMSHAFT Arbre à cames	1	512511-0220
7-6	5690-252-2801-0	GEAR, CAM Engrenage d'ac	1	912522-8010
7-7	5690-800-0718-0	KEY, FEATHER Clevette	1	908000-7180
7-8	5680-900-0069-0	BOLT Vis	1	509000-0690
7-9	5681-251-9002-1	WASHER, TIMING WHEEL Rondelle	1	512519-0021
7-11	5691-168-1010-0	PLATE, THRUST Plaque	1	911681-0100
7-12	5690-191-0816-0	BOLT, SEMS Vis	2	901910-8160
7-21	5691-253-1024-0	SHAFT, IDLE GEAR Arbre	1	912531-0240
7-22	5691-252-3080-0	GEAR Pignon	1	912523-0800
7-24	5681-253-5005-0	COLLAR, THRUST Collier	1	512535-0050
7-26	5680-900-0084-0	BOLT, SEMS Vis	2	509000-0840
7-31	5691-255-1802-0	VALVE, INLET Soupape d'admission	3	912551-8020
7-32	5691-255-2801-0	VALVE, EXH Soupape d'échapp	3	912552-8010
7-33	5681-256-1011-0	SPRING, VALVE Ressort	6	512561-0110
7-36	5681-256-3017-0	SEAT, SPRING ASSY Cuvette	6	512563-0170
7-37	5691-255-9008-0	RING, SEALING Joint	6	912559-0080
7-38	5681-256-5004-0	COLLAR, SPLIT Arrêteur	12	512565-0040
7-43	5691-257-1801-0	TAPPET Poussoir	6	912571-8010
7-44	5681-257-5015-0	ROD, PUSH Tige de culbuteur	6	512575-0150
7-51	5691-261-1347-0	ARM, ROCKER ASSY Culbuteur	3	912611-3470
7-51-1	5691-261-1349-0	ARM(D), ROCKER ASSY Culbuteur	3	912611-3490
7-53	5691-261-6023-0	SCREW, ADJ Vis	6	912616-0230
7-54	5690-911-1508-0	NUT Ecrou	6	909111-5080
7-56	5691-262-1127-0	SHAFT, ROCKER ARM Axe de culbuteurs	1	912621-1270
7-57	5691-262-6005-0	PLUG Bouchon	2	912626-0050
7-58	5691-262-8093-0	BRACKET, ROCKER SHAFT Appui	3	912628-0930
7-59	5690-994-0607-0	SPRING Ressort	2	909940-6070
7-61	5690-918-0019-0	RING, SNAP/C Collet d'axe	2	909180-0190
7-64	5690-105-0850-0	BOLT Vis	4	901050-8500
7-66	5690-916-4508-0	WASHER Rondelle	4	909164-5080
7-67	5690-911-0508-0	NUT, ROCKER BRACKET Ecrou	2	909110-5080
7-68	5690-916-4508-0	WASHER Rondelle	2	909164-5080

Fig.8 OIL FILTER, FUEL FILTER AND FIXING PARTS


Filtre a huile & filtre a combustible



Ref.No. Réf.Nº.	Parts No. Pièces N°.	Description Désignation	Q'ty Quant	Remarks Remarques
8- 1	5691-320-1812-1	FILTER, OIL ASSY Filtre à huile	1	913201-8121
8- 2	5691-324-0804-0	CARTRIDGE Cartouche	1	913240-8040
8- 6	5691-316-0081-0	COVER ASSY Couvercle	1	913160-0810
8- 24	5690-992-0841-0	PACKING, O-RING Joint	1	909920-8410
8- 28	5691-316-0068-0	VALVE, RELIEF ASSY Soupape de surpression	1	913160-0680
8- 29	5690-992-0525-0	PACKING, O-RING Joint	1	909920-5250
8- 32	5690-009-7011-0	BALL , SAFETY VALVE Bille	1	900097-0110
8- 33	5690-994-0582-0	SPRING, COIL Ressort	1	909940-5820
8- 34	5691-326-3011-0	CAP, VALVE SP Bouchon	1	913263-0110
8- 70	5681-320-0016-0	FILTER, FUEL ASSY Filtre à combustible	1	513200-0160
8- 72	5688-781-0037-0	ELEMENT KIT, FUEL FILTER Element filtrant	1	587810-0370
8- 73	5690-972-0542-0	PACKING, ELEMENT Joint	2	909720-5420
8- 74	5691-321-3601-0	PACKING Joint	1	913213-6010
8- 75	5690-972-0541-0	O-RING, CENTER BOLT Joint torique	1	909720-5410
8- 76	5690-992-0255-0	PACKING, DRAIN PLUG Joint	1	909920-2550
8- 77	5690-957-2014-0	PACKING, EYE JOINT Joint	2	909572-0140
8- 80	5691-321-2804-0	COVER, UP FUEL FILTER Couvercle	1	913212-8040
8- 81	5681-323-1001-0	BOLT, CENTER Vis	1	513231-0010
8- 82	5690-965-1068-0	SEAT, SPRING Coussin inférieur	1	909651-0680
8- 83	5690-974-2109-0	COIL, ELEMENT SPRING Ressort	1	909742-1090
8- 84	5690-920-2724-0	PLUG, FUEL DRAIN Bouchon	1	909202-7240
8- 86	5691-326-0604-0	VALVE, FUEL OVERFLOW Bouchon	1	913260-6040
8- 91	5691-975-5018-0	BRACKET, FUEL FILTER Support	1	519755-0180
8- 92	5670-980-1103-0	BOLT Vis	2	909801-1030
8- 93	5690-915-0608-0	WASHER, SP Rondelle frein	2	909150-6080
8- 94	5690-916-4508-0	WASHER Rondelle	2	909164-5080
8- 96	5690-197-1035-0	BOLT, SEMS Vis	2	901971-0350
8-100	5691-321-9077-0	PACKING Joint	1	913219-0770
8-101	5690-190-0835-0	BOLT, SEMS Vis	3	901900-9350
8-101-1	5690-190-0845-0	BOLT/M8 x 45 Vis	1	901900-8450
8-102	5688-588-5355-0	MARK, OIL FILTER CAUTION Etiquette	1	585885-3550
8-103	5688-588-5359-0	MARK, FUEL FILTER Etiquette	1	585885-3590

Fig.9 OIL PIPE AND OTHER PARTS


Pipe



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
9- 1	5691-331-2325-0	PIPE, OIL ASSY Pipe	1	913312-3250
9- 2	5691-331-2335-0	PIPE, OIL ASSY Pipe	1	913312-3350
9- 3	5690-990-6105-1	BOLT, JOINT Vis	1	909906-1051
9- 4	5690-992-0900-0	PACKING Joint	2	909920-9000
9- 6	5690-205-0814-0	BOLT Vis	1	902050-8140
9- 7	5690-915-0508-0	WASHER, SP Rondelle Frein	1	909150-5080

Fig.10 COOLING SYSTEM


Pompe a eau



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
10- 1	5681-361-0076-1	PUMP, WATER ASSY Pompe à eau	1	513610-0761
10- 6	5681-363-1005-0	BEARING UNIT Rondelle	1	513631-0050
10- 7	5690-981-4014-0	SCREW, SET Vis	1	909814-0141
10- 8	5690-915-0508-0	WASHER, SP Rondelle frein	1	909150-5080
10- 9	5691-363-9001-0	THROWER, BEARING UNIT Rondelle	1	913639-0010
10-11	5681-362-0005-0	SEAL UNIT ASSY Joint	1	513620-0050
10-12	5691-362-1076-0	IMPELLER Rotor	1	913621-0760
10-13	5681-364-2016-0	FAN, CENTER Moyeu	1	513642-0160
10-16	5691-361-2053-0	COVER, WATER PUMP BODY Couvercle	1	913612-0530
10-17	5691-361-3607-0	PACKING Joint	1	913613-6070
10-18	5690-309-0816-0	SCREW, THROTTLE Vis	1	903090-8160
10-31	5691-361-4743-0	PACKING Joint	1	913614-0430
10-33-2	5680-900-0088-0	BOLT Vis	4	50900-0880
10-33-3	5680-900-0089-0	BOLT Vis	1	509000-0890
10-33-4	5690-105-6055-0	BOLT/M10 x 55 Vis	1	901056-0550
10-34	5690-915-0510-0	WASHER, SP/M10 Rondelle frein	1	909150-5100
10-41	5691-367-5804-0	PLATE, FAN BELT ADJ Etrier	1	913675-8040
10-50	5691-364-1624-0	PULLEY, FAN Poulie	1	913641-6240
10-51	5691-364-2078-0	SPACER, FAN Poulie	1	913642-0780
10-54	5681-366-0234-0	BLADE, UP Ventilateur	1	513660-2340
10-59	5690-105-5650-0	BOLT/M6 x 50 Vis	4	901055-6500
10-61	5690-915-0506-0	WASHER, SP Rondelle frein	4	909150-5060
10-64	5681-367-1040-0	BELT, COOLING FAN/973 Courroie	1	513671-0400
10-71	5691-371-3064-1	PIPE, WATER OUTLET Pipe	1	913713-0641
10-72	5681-377-0022-1	THERMOSTAT Thermostat	1	513770-0221
10-76	5680-963-7013-0	PACKING Joint	1	509637-0130
10-77	5690-191-0828-0	BOLT, SEMS Vis	2	901910-8280
10-79	5690-966-1005-0	PLUG Bouchon	2	909661-0050
10-81	5690-957-1316-0	PACKING Joint	2	909571-3160
10-90	5681-371-6028-0	HOUSING, THERMOSTAT Carcasse	1	513716-0280
10-91	5681-374-3021-0	PACKING Joint	1	513743-0210
10-92	5690-190-0820-0	BOLT, SEMS/M8 x 20 Vis	2	901900-8200
10-92-1	5690-190-0822-0	BOLT, SEMS/M8 x 22 Vis	2	901900-8220
10-93	5691-372-1134-1	HOSE, BY-PASS/RUBBER Durit	1	913721-1341
10-94	5690-991-5644-1	CLIP, HOSE Collier	2	909915-6441

Fig.11 AIR INTAKE AND EXHAUST SYSTEM

Pipe d'admission & echappement




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
11- 1	5681-411-1003-2	MANIFOLD, INLET Manifold	1	514111-0032
11- 3	5690-410-0848-0	STUD Goujon	2	904100-8480
11-20	5681-414-1006-0	MANIFOLD, EXH Manifold	1	514141-0060
11-21	5690-411-0830-0	STUD, EXH MANIFOLD Goujon	4	904110-8300
11-46	5691-414-6090-0	GASKET, MANIFOLD Joint	1	914146-0900
11-48	5690-916-4508-0	WASHER Rondelle	1	909164-5080
11-49	5690-915-0508-0	WASHER, SP Rondelle frein	1	909150-5080
11-52	5690-196-0835-0	BOLT/MB x 35 Vis	6	901960-8350
11-52-1	5690-104-5895-0	BOLT/MB x 95 Vis	1	901045-8950
11-66	5691-432-0652-1	SHUTTER, INTAKE ASSY Volant	1	914320-6521
11-76	5680-963-7015-0	PACKING Joint	2	509637-0150
11-77	5690-911-0508-0	NUT Erou	2	909110-5080
11-78	5690-915-0508-0	WASHER, SP Rondelle frein	2	909150-5080
11-79	5690-994-2600-0	SPRING, SHUTTER RETURN Ressort	1	909942-6000
11-81	5690-916-4508-0	WASHER Rondelle	2	909164-5080
11-84	5691-433-4640-0	EYE, SPRING Crochet	1	914334-6400
11-87	5690-915-0506-0	WASHER, SP Rondelle frein	1	909150-5060
11-88	5690-204-0610-0	BOLT, SPRING EYE Vis	1	902050-6100
11-91	5699-344-0612-0	SCREW Vis	1	993440-6120
11-92	5681-431-9100-0	CLIP, SHUTTER CABLE Attache	1	514319-1000



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
12- 2	5681-531-1006-0	NOZZLE Injecteur	3	515311-0060
12- 3	5681-533-0003-0	HOLDER, NOZZLE Porte Injecteur	3	515330-0030
12- 6	5691-531-5027-0	SHIELD, HEAT Couvercle	3	915315-0270
12- 7	5691-531-5026-0	WASHER, NOZZLE HOLDER Rondelle	3	915315-0260
12- 8	5691-531-5028-0	WASHER, HEAT SHIELD Rondelle	3	915315-0280
12- 9	5691-531-5074-0	WASHER, CORRUGATED Rondelle	3	915315-0740
12-15	5691-542-1612-0	PIPE, INJ ASSY/NO.1 Conduit	1	915421-6120
12-16	5691-542-1613-0	PIPE, INJ ASSY/NO.2 Conduit	1	915421-6130
12-17	5691-542-1614-0	PIPE, INJ ASSY/NO.3 Conduit	1	915421-6140
12-19	5691-541-9072-0	CLIP ASSY Serre tube	2	915419-0720
	5690-980-2539-0	• SCREW Vis	2	909802-5390
	5690-915-0505-0	• WASHER, SP Rondelle frein	2	909150-5050
12-21	5681-541-1058-0	PIPE, FUEL ASSY Conduit	1	515411-0580
12-22	5681-541-1059-0	PIPE, FUEL ASSY Conduit	1	515411-0590
12-23	5690-990-6325-1	BOLT, JOINT Vis	2	909906-3251
12-24	5690-957-2014-0	PACKING, BOLT Joint	4	909572-0140
12-27	5690-991-3846-0	PIPE, VINYL Conduit	1	909913-8460
12-31	5681-541-1257-0	PIPE, LEAK OFF FUEL Conduit	1	515411-2570
12-32	5690-990-6314-1	BOLT, JOINT Vis	1	909906-3141
12-33	5690-957-1408-0	PACKING, PIPE JOINT Joint	2	909571-4080
12-36	5681-541-1223-0	JOINT, FUEL INLET EYE ASSY Conduit	2	515411-2230
12-100	5690-970-7130-0	JOINT, EYE Bollseau	1	909707-1300


Fig.13 ENGINE FOOT, HANGER AND FIXING PARTS
Support & crochet



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
13-11	5691-971-1601-0	BRACKET, GENERATOR Support	1	919711-6010
13-13	5690-191-1020-0	BOLT Vite	4	901911-0200
13-30	5690-915-0512-0	WASHER, SP Rondelle frein	2	909150-5120
13-31	5690-912-0412-0	NUT Ecrou	2	909120-4120
13-33	5690-916-0512-0	WASHER Rondelle	2	909160-5120
13-34	5690-165-6245-0	BOLT Vite	2	901656-2450
13-36	5690-191-0830-0	BOLT Vite	2	901910-8300
13-37	5690-191-0820-0	BOLT Vite	1	901910-8200
13-38	5690-916-4708-0	WASHER Rondelle	1	909164-7080
13-40	5690-911-0508-0	NUT/M8 Ecrou	2	909110-5080
13-41	5681-177-7004-0	HANGER, ENGINE F. Crochet	1	511777-0040
13-41-1	5691-177-7152-1	HANGER, ENGINE R. Crochet	1	911777-1521
13-42	5690-205-0818-0	BOLT Vite	2	902050-8180
13-43	5690-915-0508-0	WASHER, SP/M8 Rondelle frein	2	909150-5080
13-51	5681-131-9056-0	PACKING Joint	1	511319-0560
13-52	5690-105-5870-0	BOLT Vite	1	901055-8700
13-52-1	5690-105-5855-0	BOLT/M8 x 55 Vite	1	901055-8550
13-52-4	5680-903-0015-0	BOLT Vite	3	509030-0150
13-53	5690-911-0508-0	NUT Ecrou	1	909110-5080
13-55	5690-915-0508-0	WASHER, SP/M8 Rondelle frein	3	909150-5080

Fig.14 INJECTION PUMP AND OTHER PARTS


Pompe d'injection



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
14- 5	5681-560-0645-1	PUMP, INJECTION ASSY Pompe d'injection	1	515600-6451 See Fig. 17
14-15	5681-572-0110-1	GOVERNOR Régulateur	1	515720-1101 See Fig. 18
14-20	5681-575-0004-0	PUMP, FEED Pompe à main	1	515750-0040 See Fig. 19
14-38	5681-975-1003-0	BRACKET, INJ PUMP Support	1	519751-0030
14-40	5690-992-0576-0	PACKING, INJ PUMP Joint	1	909920-5760
14-42	5681-252-4037-0	GEAR, INJ PUMP Pignon	1	512524-0370
14-49	5681-253-9001-0	ADAPTER, TACHOMETER Arbre d'indicateur	1	512539-0010
14-50	5685-588-5362-0	MARK, INJ PUMP CAUTION Etiquette	1	585685-3620

Fig.15 ELECTRICAL PARTS


Equipment électrique



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
15- 1	5698-210-0608-1	STARTER ASSY/12V <i>Démarrreur</i>	1	982100-6081 See Fig. 20
15- 2	5688-120-0273-0	GENERATOR ASSY /12V-10A <i>Dynamo</i>	1	581200-2730 See Fig. 21
15-2a	5688-120-0272-0	GENERATOR ASSY/12V-20A <i>Dynamo</i>	1	581200-2720 See Fig. 21A
15- 4	5698-225-0113-0	REGULATOR/12V <i>Régulateur de tension</i>	1	982253-1130
15- 7	5688-241-0012-1	SWITCH, OIL PRESS WARNING <i>Interrupteur</i>	1	582410-0121
15-12	5698-251-1978-0	PLUG, GLOW/SHEATHED TYPE <i>Bougie à incandescence</i>	3	982511-9780
15-14	5698-253-0101-0	CONTROL, RESISTANCE <i>Contrôle</i>	1	982530-1010
15-23	5691-973-2075-0	CONNECTOR <i>Jonction</i>	1	919732-0750

Fig.16 ENGINE ACCESSORY PARTS


Indicateur de vitesse



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
16-50	5681-931-0002-0	DRIVE, TACHOMETER ASSY Indicateur de vitesse	1	519310-0020
16-55	5680-962-3003-0	PACKING, TACHOMETER DRIVE Joint	1	509623-0030
16-68	5690-911-0408-0	NUT Ecrou	2	909110-4080
16-69	5690-915-0508-0	WASHER, SP Rondelle frein	2	909150-5080

Fig.17 INJECTION PUMP; PROPER

Pompe d'injection




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
17- 0-1	5681-560-0645-0	PUMP, INJ ASSY Pompe d'injection	1	515600-6451
17- 5	5681-561-1032-0	HOUSING, PUMP ASSY Corps de pompe	1	515611-0320
17-15	5698-121-5115-0	STUD, HOUSING Goujon	3	981215-1150
17-16	5698-123-5017-0	ADAPTER, HOUSING Vis d'alimentation	1	981235-0170
17-18	5641-561-9024-0	BOLT, HOUSING Vis	1	115619-0240
17-19	5641-561-9024-0	BOLT, HOUSING Vis	1	115619-0240
17-20	5641-563-9008-0	GASKET, HOUSING BOLT Joint	1	115639-0080
17-21	5641-563-9008-0	GASKET, HOUSING BOLT Joint	1	115639-0080
17-22	5698-121-3206-0	COVER, HOUSING SIDE Couvercle	1	981213-2060
17-23	5698-121-5330-0	SCREW Vis	2	981215-3300
17-24	5698-121-5180-0	GASKET, SCREW Joint	2	981215-1380
17-25	5698-121-1532-0	GAUGE, LEVEL Jauge	1	981211-5320
17-27	5641-561-9004-0	WASHER, SP Rondelle frein	3	115619-0040
17-28	5641-572-9006-0	NUT Eccou	3	115729-0060
17-29	5640-962-3013-0	O-RING Joint torique	1	109623-0130
17-31	5698-123-3104-0	PLUNGER ASSY Corps de clapet	3	981233-1040
17-32	5698-124-3101-0	VALVE, DEL Clapet de refoulement	3	981243-1010
17-34	5698-124-1303-0	SPRING, DEL VALVE Ressort	3	981241-3030
17-35	5698-124-5014-0	GASKET, DEL VALVE Joint	3	981245-0140
17-36	5698-124-1406-0	HOLDER, DEL VALVE Reccord d'injection	3	981241-4060
17-43	5641-562-2001-0	TAPPET ASSY Poussoir	3	115622-0010
17-44	5698-841-0265-0	NUT, TAPPET Eccou	3	988410-2650
17-45	5698-122-1220-0	PIN, TAPPET Goupille	3	981221-2200
17-46	5698-122-1209-0	BOLT, TAPPET Vis	3	981221-2090
17-47	5641-562-2003-0	ROLLER, TAPPET Rouleau	3	115622-0030
17-48	5641-562-9001-0	BUSH, TAPPET Cousinnet	3	115629-0010
17-49	5698-122-1225-0	GUIDE, TAPPET Oeillette de poussoir	3	981221-2250
17-57	5698-123-1404-0	SPRING, PLUNGER Ressort	3	981231-4040
17-58	5698-123-5015-0	SEAT, PLUNGER SP Coupelle supérieure	3	981235-0150
17-59	5698-123-5016-0	SEAT, PLUNGER SP Coupelle inférieure	3	981235-0160
17-60	5698-122-5058-0	SLEEVE, PLUNGER CONTROL Manchon	3	981225-0580
17-61	5698-122-5057-0	PINION, CONTROL SLEEVE Pignon de débit	3	981225-0570
17-62	5698-123-5003-0	SCREW, PINION Vis	3	981235-0030
17-66	5698-121-5336-0	RACK, CONTROL Crémillère	1	981215-3360
16-67	5641-563-9003-0	SCREW, CONTROL RACK Vis	1	115639-0030
17-75	5698-122-3106-0	SHAFT, CAM Arbre à cames	1	981223-1060
17-76	5690-009-0233-0	BEARING, BALL Roulement radial	1	900090-2330
17-77	5690-009-0066-0	BEARING, BALL Roulement radial	1	900090-0660

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
17- 82	5698-122-5059-0	RING, CAMSHAFT Anneau	1	981225-0590
17- 83	5698-122-5045-0	RING, SIDE Anneau	1	981225-0450
17- 90	5698-122-5041-0	SEAL, OIL Bague d'étanchéité	1	981225-0410
17- 93	5698-121-3207-0	HOUSING, COVER Couvercle	1	981213-2070
17- 95	5681-561-9053-0	BOLT Vis	4	515619-0530
17-108	5698-132-5301-0	KEY, WOODRUFF Clavette	1	981325-3010
17-111	5698-132-5301-0	BOLT, JOINT Vis	1	909906-3250
17-113	5641-575-9001-0	PACKING Joint	2	115759-0010
17-119	5698-121-5061-0	BREATHER, AIR Clapet à air	1	981215-0610
17-121	5641-563-9008-0	GASKET Joint	1	115639-0080
17-145	5698-121-5146-0	BOLT, JOINT Vis	1	981215-1460
17-146	5698-139-1507-0	EYE, OVER FLOW Treu	1	981391-5070
17-147	5698-139-1703-0	GASKET Joint	1	981391-7030
17-150	5681-572-9002-0	PLUG, TAPPET Bouchon	1	515729-0020
17-151	5698-121-5078-0	PLUG, TAPPET Bouchon	2	981215-0780
17-152	5698-121-5004-0	PLUG, TAPPET Bouchon	2	981215-0040
17-153	5641-563-9009-0	GASKET, PLUG Joint	2	115639-0090
17-162	5690-916-0610-0	WASHER Rondelle	4	909160-6100
17-163	5698-841-0222-0	WASHER, SP Rondelle	4	988410-2220
17-164	5681-563-9002-0	NUT Eccrou	4	515639-0020

[illegible]

Fig.18 GOVERNOR (MECHANICAL); INJECTION

Regulateur




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
18- 0-1	5681-572-0110-1	GOVERNOR ASSY Regulateur	1	515720-1101
18- 5	5681-572-1007-0	HOUSING, GOVERNOR Carrosse	1	515721-0070
18- 7	5698-139-1608-0	PLUG, HOUSING Bouchon	1	981391-6080
18- 8	5698-131-5062-0	GASKET, PLUG Joint	1	981315-0620
18- 9	5698-131-5214-0	BREATHER, AIR Clapet a air	1	981315-2140
18-10	5641-563-9008-0	GASKET, AIR BREATHER Joint	1	115639-0080
18-11	5698-132-6124-0	PLUG, HOUSING Bouchon	1	981326-1240
18-13	5698-131-5065-0	ADAPTER, HOUSING Reccord	1	981315-0650
18-14	5690-190-0818-0	BOLT Vis	1	901900-8180
18-15	5698-132-5397-0	PLATE, HOUSING Plaque	1	981325-3970
18-18	5698-132-5200-0	SCREW Vis	1	981325-2000
18-19	5698-132-5437-0	NUT, LOCK Erou	2	981325-2370
18-26	5698-132-5182-0	SCREW Vis	1	981325-1820
18-27	5698-132-6112-0	NUT Erou	1	981326-1120
18-30	5681-572-1008-0	COVER, GOVERNOR Couvercle	1	515721-0080
18-36	5698-139-1108-0	SCREW Vis	1	981391-1080
18-40	5698-132-1189-0	COVER Couvercle	1	981321-1890
18-41	5681-572-9113-0	GAUGE, LEVEL Jauge	1	515729-1130
18-42	5698-139-1907-0	O-RING Joint torique	1	981391-9070
18-47	5698-123-5034-0	CAP Bouchon	1	981235-0340
18-50	5698-132-1310-0	FLYWEIGHT ASSY Masse/orte	1	981321-3100
18-52	5698-132-5301-0	KEY, WOODRUFF Cloveite	1	981325-3010
18-54	5698-841-0200-0	NUT, FLYWEIGHT Erou	1	988410-2000
18-58	5670-009-0229-0	BEARING, FLYWEIGHT Roulement radial	1	900900-2290
18-63	5698-132-2282-0	SPRING, GOVERNOR Ressort	1	981322-2820
18-64	5698-132-1660-0	SPRING, LINK Ressort	1	981321-6600
18-67	5641-572-3020-0	CAPSULE, SPRING Capsule	1	115723-0200
18-68	5698-139-3204-0	NUT Erou	1	981393-2040
18-69	5641-563-9008-0	GASKET, SP CAPSULE Joint	1	115639-0080
18-70	5698-132-5112-0	NUT, CAP Erou	1	981325-1120
18-73	5681-572-3614-0	CAPSULE, SPRING Capsule	1	515723-6140
18-74	5690-081-3023-0	NUT, SP CAPSULE Erou	1	900813-0230
18-77	5698-132-1721-0	LEVER, SWIVEL Levier	1	981321-7210
18-81	5698-132-1205-0	O-RING Joint torique	2	981321-2050
18-83	5698-132-1220-0	SEAL, OIL Bague d'etanchéité	1	981321-2200
18-84	5698-132-5173-0	SHIM Cale	1	981325-1730
18-85	5698-132-5097-0	SHIM Cale	AR	981325-0970
18-86	5698-132-5318-0	PLUG Bouchon	1	981325-3180

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
18- 88	5698-132-5030-0	KEY, WOODRUFF Clavette	1	981325-0300
18- 89	5698-139-1307-0	COLLAR, SWIVEL LEVER Collier	1	981391-3070
18- 90	5698-132-5488-0	WASHER, SWIVEL LEVER Rondelle	AR	981325-4880
18- 94	5698-132-1705-0	LEVER, FLOATING Lever	1	981321-7050
18- 95	5698-132-5181-0	SHIM Cale	2	981325-1810
18- 96	5698-131-5191-0	PIN, SPLIT Goupille fendue	1	981315-1910
18-100	5698-132-1713-0	LINK Chânon	1	981321-7130
18-103	5698-132-5062-0	PIN Goupille	1	981325-0620
18-104	5641-572-5021-0	LEVER, SWIVEL Lever	1	115725-0210
18-115	5698-122-5019-0	SEAL, OIL Bagua d'etanchéité	1	981225-0190
18-116	5691-572-9001-0	GASKET Joint	1	915729-0010
18-117	5691-572-9002-0	GASKET Joint	1	915729-0020

SERVICE MEMO


Fig.19 FEED PUMP; INJECTION PUMP
Pompe a main



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
19- 0-1	5681-575-0004-0	PUMP, FEED ASSY Pompe alimentaire	1	515750-0040
19- 5	5681-575-1002-0	HOUSING, FEED PUMP Carasse	1	515751-0020
19- 9	5698-135-1205-0	PISTON Piston	1	981351-2050
19-10	5698-135-1303-0	SPRING, PISTON Ressort	1	981351-3030
19-11	5698-135-5023-0	PLUG, SP PISTON Bouchon	1	981355-0230
19-12	5698-135-5035-0	GASKET, PLUG Joint	1	981355-0350
19-14	5681-575-4001-0	TAPPET ASSY Poussoir	1	515754-0010
19-16	5698-135-1403-0	ROLLER, TAPPET Rouleau	1	981351-4030
19-17	5698-135-1310-0	PIN, TAPPET Goupille	1	981351-4100
19-18	5641-575-9002-0	GUIDE, TAPPET Dolgie de poussoir	2	115759-0020
19-26	5698-135-1602-0	VALVE, CHECK Valve	2	981351-6020
19-27	5698-135-5031-0	GASKET, CHECK VALVE Joint	1	981355-0310
19-28	5698-135-1702-0	SPRING, CHECK VALVE Ressort	2	981351-7020
19-31	5698-135-5076-0	BOLT, JOINT Vis	1	981355-0760
19-32	5690-990-6325-0	BOLT, JOINT Vis	1	909906-3250
19-33	5641-575-9001-0	PACKING, JOINT BOLT Joint	4	115759-0010
19-35	5641-575-9003-0	ADAPTER, CHECK VALVE Raccord	1	115759-0030
19-40	5640-962-3016-0	O-RING Joint torique	1	109623-0160
19-42	5698-135-5025-0	RING, SNAP Collet d'axe	1	981355-0250
19-44	5698-135-2104-0	PUMP, PRIMING Pompe	1	981352-1040

Fig.20 STARTER


Demarreur



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
20- 0-1	5698-210-0608-0	STARTER/12V-1.8KW Démarreur	1	982100-6080
20- 0-1 a	5698-210-0608-1	STARTER/12V-1.8KW Démarreur	1	982100-6081 ⑤ ENO. 536659~
20- 6	5698-212-3104-0	ARMATURE Induit	1	982123-1040
20- 8	5688-112-8026-0	STOPPER, PINION Butée	1	581128-0260
20- 18	5688-112-8028-0	WASHER, ADJ Rondelle	2	581128-0280
20- 23	5698-211-1298-0	COIL, FIELD Inducteur	1	982111-2980
20- 24	5688-112-9024-0	SCREW, SET Vis	4	581129-0240
20- 30	5698-211-6149-0	COVER, R. ASSY Cape du collecteur	1	982116-1490
20- 31	5698-211-3901-0	COVER, R Capot de l'armature	1	982113-9010
20- 32	5698-211-5433-0	METAL, R Collar	1	982115-4330
20- 35	5698-211-1731-0	SPRING, BRUSH Ressort	4	982111-7310
20- 37	5698-211-1654-0	BRUSH Brosse	4	982111-6540
20- 50	5698-212-6107-0	BRACKET, CENTER ASSY Cape du bendix	1	982126-1070
20- 52	5698-212-6108-0	METAL, CENTER Collar	1	982126-1080
20- 55	5698-212-3204-0	CLUTCH, PINION ASSY Roue libre à rouleaux	1	982123-2040
20- 65	5698-211-1384-0	CASE, GEAR ASSY Carter	1	982111-3840
20- 66	5698-211-5433-0	METAL, F Collar	1	982115-4330
20- 77	5688-112-9021-0	PIN, SHIFT LEVER Vis	1	581129-0210
20- 80	5698-215-0503-0	SWITCH, MAGNETIC ASSY Contacteur	1	982150-5030
20- 80 a	5698-215-0503-1	SWITCH, MAGNETIC ASSY Contacteur	1	982150-5031 ⑤ ENO. 536659~
20- 85	5698-211-6120-0	BOLT, THROUGH Vis	2	982116-1200
20-104	5698-215-5307-0	PACKING Joint	1	982155-3070
20-105	5698-211-5362-0	O-RING Joint torique	1	982115-3620
20-107	5688-112-9022-0	PACKING Joint	4	581129-0220
20-111	5688-112-9023-0	O-RING Joint torique	1	581129-0230

Fig.21 GENERATOR (12V-10A)

Dynamo




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
21-0-1	5688-120-0273-0	GENERATOR/12V-10A Dynamo	1	581200-2730
21- 5	5698-222-3109-0	ROTOR ASSY Rotor	1	982223-1090
21-20	5698-223-1109-0	STATOR ASSY Stator	1	982231-1090
21-25	5688-111-5012-0	COVER, R. ASSY Plaque av.	1	581115-0120
21-27	5688-121-9005-0	RECTIFIER ASSY Plaque a diodes	1	581219-0050
21-31	5698-221-5926-0	HOLDER, BRUSH Porte brosses	1	982215-9260
21-33	5648-121-5005-0	BRUSH Brosse	2	181215-0050
21-41	5688-121-9006-0	TERMINAL ASSY Faisceau	1	581219-0060
21-51	5698-223-1307-0	COVER, F. Plaque ar.	1	982231-3070
21-75	5698-223-3208-0	PULLEY ASSY Poulie	1	982233-2080
21-90	5698-223-5060-0	BOLT, THROUGH Vis	2	982235-0600



Fig.21A GENERATOR (12V-20A)


Dynamo



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Q'ty Quant	Remarks Remarques
21A-0-1	5688-120-0272-0	GENERATOR/12A - 20A Dynamo	1	581200-2720
21A-5	5688-122-1030-0	ROTOR ASSY Rotor	1	581221-0300
21A-20	5688-121-1024-0	STATOR ASSY Stator	1	581211-0240
21A-25	5688-121-4033-0	COVER, R. ASSY Flaque ar.	1	581214-0330
21A-27	5698-223-1619-0	RECTIFIER ASSY Plaque a diodes	1	982231-6190
21A-30	5688-121-5008-0	BRUSH & HOLDER ASSY Brelol	1	581215-0080
21A-39	5688-121-8009-0	COVER, RECTIFIER Support de pallier	1	581218-0090
21A-50	5698-223-1308-0	COVER, F. ASSY Flaque ar.	1	982231-3080
21A-75	5688-122-2032-0	PULLEY ASSY Poulie	1	581222-0320
21A-80	5698-223-5074-0	NUT, PULLEY ASSY Erou	1	982235-0740
21A-90	5698-223-5072-0	BOLT, THROUGH Vis	2	982235-0720
21A-90-1	5688-122-9042-0	BOLT, THROUGH Vis	1	581229-0420

CHASSIS

Fig.22 RADIATOR
Radiateur




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	F-LDU	
22- 1	1431-151-2101-0	RADIATOR ASSY Radiateur complet	1	1	1	1	1	Ⓡ { S #002541 ~ D #101309 ~ F #004499 ~
22- 2	1431-151-2120-0	• CAP Bouchon de radiateur	1	1	1	1	1	
22- 3	1424-101-2030-0	• PLUG Robinet de vidange	1	1	1	1	1	
22- 4	1424-101-2040-0	• PACKING Joint de vidange	1	1	1	1	1	
22- 5	1431-151-2130-0	• NET Filet	1	1	1	1	1	
22- 6	1422-151-2120-0	• PLATE CAUTION Etiquette	1	1	1	1	1	
22- 7	1424-101-0020-0	HOSE, RADIATOR LW Durite d'eau	1	1	1	1	1	
22- 8	1424-101-0030-0	HOSE, RADIATOR UP Durite d'eau	1	1	1	1	1	
22- 9	1424-101-0040-0	CLIP/45 Collier	1	1	1	1	1	
22-10	1424-101-0050-0	CLIP/42 Collier	3	3	3	3	3	
22-11	1423-101-0060-0	THERMOMETER Thermomètre	1	1	1	1	1	
22-11a	1431-152-2500-0	THERMOMETER Thermomètre	1	1	1	1	1	



Fig.23 INTAKE SYSTEM


Filtre a air



Ref.No. Réf.Nº	Parts No. Pièces Nº	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-FDU	
23- 1	1431-151-2300-0	CLEANER, AIR ASSY Filtre à air	1	1	1	1	1	
23- 2	1431-151-2500-0	• ELEMENT ASSY/PAPER Cartouche	1	1	1	1	1	
23- 3	1416-101-0110-0	• PACKING ASSY Joint	1	1	1	1	1	
23- 4	1423-101-0040-0	• BOLT, WING/M10 Vis à oreilles	1	1	1	1	1	
23- 5	1416-101-0070-0	• BAND ASSY Bande	1	1	1	1	1	
23- 6	1416-101-0140-0	• O-RING Joint torique	1	1	1	1	1	
23- 7	1416-101-0120-0	• PAN, DUST ASSY Casseroles	1	1	1	1	1	
23- 8	1416-101-0130-0	• DIVIDER ASSY Diviseur	1	1	1	1	1	
23- 9	1422-152-2310-0	• PAPER, CAUTION (A) Étiquette A	1	1	1	1	1	
23-10	1422-152-2210-0	• PAPER, CAUTION (B) Étiquette B	1	1	1	1	1	
23-11	1422-152-2320-0	• PAPER, CAUTION (C) Étiquette C	1	1	1	1	1	
23-12	1421-101-0130-0	BOLT, WING Vis à oreilles	1	1	1	1	1	
23-13	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	1	1	1	1	1	
23-14	1423-602-4001-0	BRACKET Support	1	1	1	1	1	
23-15	V201-260-8020-0	BOLT/MB X 20 Vis	2	2	2	2	2	
23-16	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
23-17	V201-260-8020-0	BOLT/MB X 20 Vis	4	4	4	4	4	
23-18	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
23-19	1421-602-0080-0	CUSHION, C/RUBBER Silencibloc	2	2	2	2	2	
23-20	1431-151-2600-0	CLEANER, AIR ASSY	1	1	1	1	1	
23-21	1422-152-2210-0	• PAPER, CAUTION B	1	1	1	1	1	
23-22	1431-151-2800-0	• ELEMENT ASSY/PAPER	1	1	1	1	1	
23-23	1422-152-2310-0	• PAPER, CAUTION A	1	1	1	1	1	
23-24	1422-152-2320-0	• PAPER, CAUTION C	1	1	1	1	1	(D #002731~ (F #005655~
23-25	1431-151-2900-0	• PAN, DUST ASSY	1	1	1	1	1	
23-26	1431-151-3000-0	• DIVIDER ASSY	1	1	1	1	1	
23-27	1423-101-0040-0	• BOLT, WING ASSY	1	1	1	1	1	
23-28	1416-101-0110-0	• PACKING ASSY	1	1	1	1	1	

Fig.24 EXHAUST AND INTAKE SYSTEM

Silencieux et tuyau d'échappement




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-FDU	
24- 1	1425-101-0010-0	PIPE, EXH. Pipo d'échappement	1	1	1	1	1	
24- 2	1415-101-0180-0	GASKET Joint	1	1	1	1	1	
24- 3	V303-260-0080-0	NUT/M8 Erou	4	4	4	4	4	
24- 4	V305-260-0080-0	NUT/M8 Erou	4	4	4	4	4	
24- 5	1431-151-2200-0	MUFFLER Silencieux	1	1	1	1	1	
24- 6	1421-101-0030-0	PIPE, TAILL Tube d'échappement	1	1	1	1	1	
24- 7	1431-101-0020-0	CLAMP, MUFFLER Attache	2	2	2	2	2	
24- 8	V201-261-0070-0	BOLT/M10 X 70 Vis	2	2	2	2	2	
24- 9	V413-160-0100-0	WASHER/M10 Rondelle	4	4	4	4	4	
24-10	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	2	2	2	2	2	
24-11	V300-260-0100-0	NUT/M10 Erou	2	2	2	2	2	
24-12	1423-101-0030-0	PIPE/RUBBER Durit	1	1	1	1	1	
24-13	1415-101-0400-0	CLIP, C Collier	2	2	2	2	2	
24-14	1425-101-1000-0	PIPE, INLET Pipa d'admission	1	1	1	1	1	
24-15	1415-101-0100-0	CUSHION, RADIATOR Silentbloc	4	4	4	4	4	
24-16	1421-101-0010-0	BOLT/M10 X 42 Vis	2	2	2	2	2	
24-17	V413-160-0120-0	WASHER/M12 Rondelle	2	2	2	2	2	
24-18	1305-241-0010-0	PIN, HAIR Attache bois	2	2	2	2	2	
24-19	1425-101-0020-0	HOSE, DRAIN Conduit expansion	1	1	1	1	1	
24-20	1417-102-0050-0	BAND, HOSE Collier	2	2	2	2	2	
24-21	1427-932-0030-0	TAG, CAUTION Etiquette	1	1	1	1	1	



Fig.25 BONNET

Carenage




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F	U	F	
25- 1	1425-601-1000-1	BONNET Capôt du moteur	1	1	1	1	1	
25- 2	1431-938-0011-0	MARK, OIL Etiquette	1	1	1	1	1	English
25- 2a	1431-938-0012-0	MARK, OIL Etiquette	1	1	1	1	1	ⓑ English
25- 2-1	1431-935-0010-0	MARK, OIL Etiquette	1	1	1	1	1	★ French
25- 2-1a	1431-935-0011-0	MARK, OIL Etiquette	1	1	1	1	1	ⓑ★ French
25- 3	1427-937-0130-0	MARK, FUEL Etiquette	1	1	1	1	1	English
25- 3a	1427-941-0160-0	MARK, FUEL Etiquette	1	1	1	1	1	ⓑ English
25- 3-1	1427-934-0130-0	MARK, FUEL Etiquette	1	1	1	1	1	★ French
25- 4	1431-938-0020-0	MARK, WIRING Etiquette	1	1	1	1	1	English
25- 4a	1431-938-0021-0	MARK, WIRING Etiquette	1	1	1	1	1	English
25- 4b	1431-938-0022-0	MARK, WIRING Etiquette	1	1	1	1	1	ⓑ English {D #001177~ F #003470~
25- 4-1	1431-935-0020-0	MARK, WIRING Etiquette	1	1	1	1	1	★ French
25- 4-1a	1431-935-0021-0	MARK, WIRING Etiquette	1	1	1	1	1	★ French
25- 4-1b	1431-935-0022-0	MARK, WIRING Etiquette	1	1	1	1	1	ⓑ★ French {D #001177~ F #003470~
25- 5	1425-601-0010-0	SIDE, BONNET LH Plaque	1	1	1	1	1	
25- 6	1431-903-0031-0	MARK, SIDE LH Plaque laterale G	1	1	1	1	1	
25- 6-1	1431-938-0070-0	MARK, SIDE LH Plaque laterale G.	1	1	1	1	1	for E61
25- 7	1425-601-0020-0	SIDE, BONNET RH Plaque	1	1	1	1	1	
25- 8	1431-903-0041-0	MARK, SIDE RH Plaque laterale D.	1	1	1	1	1	
25- 8-1	1431-938-0080-0	MARK, SIDE RH Plaque laterale D.	1	1	1	1	1	for E61
25- 9	1421-601-0030-0	BOLT, SET Vis	8	8	8	8	8	
X 25-10	~~V411-150-0080-0~~ 1411-601-0130-0	WASHER/M8 9 x 1 1/2 x 1.2 Rondelle	8	8	8	8	8	ⓐ info n° 62 - 07 (4/4) March 31, '82
25-11	1423-601-2000-0	PLATE, SIDE LH Joue G.	1	1	1	1	1	
25-12	1423-601-3000-0	PLATE, SIDE RH Joue D.	1	1	1	1	1	
25-13	V300-260-0080-0	NUT/M8 Eccou	4	4	4	4	4	
25-14	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
25-15	1326-616-0010-0	WASHER Rondelle	1	1	1	1	1	
25-16	1423-601-0030-0	MASK, F. Traverse av.	1	1	1	1	1	
25-17	1423-901-0030-0	MARK, F. Etiquette	1	1	1	1	1	
25-18	V200-260-6016-0	BOLT/M8 x 16 Vis	4	4	4	4	4	
25-19	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	4	4	4	4	4	
25-20	V300-260-0060-0	NUT/M6 Eccou	4	4	4	4	4	
25-21	1431-651-2001-0	GRILLE Cetandre	1	1	1	1	1	
25-22	1423-601-0050-0	BOLT, GRILLE SET Vis	4	4	4	4	4	
25-23	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
25-24	1423-601-0040-0	NET Filet	1	1	1	1	1	
25-25	V201-260-8016-0	BOLT/M8 x 16 Vis	5	5	5	5	5	
25-26	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	5	5	5	5	5	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DC	L.FDU	
25-27	V413-160-0080-0	WASHER/M8 Rondelle	4	4	4	4	4	B
25-28	1421-601-0110-0	STAY, LIGHT LH Appui G.	1	1	1	1	1	
25-28a	1421-601-0111-0	STAY, LIGHT LH Appui G.	1	1	1	1	1	
25-29	1421-601-0120-0	STAY, LIGHT RH Appui D.	1	1	1	1	1	
25-29a	1421-601-0121-0	STAY, LIGHT RH Appui D.	1	1	1	1	1	B
25-30	V201-260-8020-0	BOLT/M8 X 20 Bolt	4	4	4	4	4	
25-31	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
25-32	V413-160-0080-0	WASHER/M8 Rondelle	4	4	4	4	4	
25-33	1421-601-0080-0	MARKER, SIDE LH Etiquette	1	1	1	1	1	
25-34	1421-601-0090-0	MARKER, SIDE RH Etiquette	1	1	1	1	1	
25-35	V200-260-6012-0	BOLT/M6 X 12 Vis	4	4	4	4	4	
25-36	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	4	4	4	4	4	
25-37	1423-601-0060-0	SEAL Joint	1	1	1	1	1	
25-38	1423-601-0080-0	RUBBER, TENSION B Joint	3	3	3	3	3	
25-39	1421-621-2100-0	MIRROR, R. VIEW ASSY Retroviseur	1	1	1	1	1	
25-40	1421-621-2200-0	STAY, MIRROR Appui	1	1	1	1	1	
25-41	1421-621-0390-0	BRACKET, MIRROR Support	1	1	1	1	1	
25-42	1421-621-0410-0	PACKING Joint	1	1	1	1	1	
25-43	V201-261-0050-0	BOLT/M10 X 60 Vis	1	1	1	1	1	
25-44	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	1	1	1	1	1	
25-45	V300-260-0100-0	NUT/M10 Eccrou	1	1	1	1	1	
25-46	V111-166-0016-0	SCREW/M6 X 16 Vis	4	4	4	4	4	
25-47	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	4	4	4	4	4	
25-48	V300-260-0060-0	NUT/M6 Eccrou	4	4	4	4	4	

Q

Fig.26 FRAME AND FAN COVER

Chassis



Ref.No. Réf.Nº	Parts No. Pièces Nº.	Description Désignation	Model & Qty Modél & Quant					Remarks Remarques
			S	D	F-U	FDU	LFPU	
26- 1	1431-656-2001-0	FRAME, F. Chassis av.	1	1	1	1	1	
26- 2	1421-602-0010-0	BUSH Cousinnet	2	2	2	2	2	
26- 3	V201-260-8016-0	BOLT/M8 X 16 Vis	6	6	6	6	6	
26- 4	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	6	6	6	6	6	
26- 5	1431-656-2100-0	FRAME, R. Chassis ar.	1	1	1	1	1	
26- 6	3746-261-2050-0	CUSHION, B/RUBBER Tampon	6	6	6	6	6	
26- 7	V201-160-8016-0	BOLT/M8 X 16 Vis	4	4	4	4	4	
26- 8	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
26- 9	V413-160-0080-0	WASHER/M8 Rondelle	4	4	4	4	4	
26-10	1426-602-1000-0	STAY, CATCHER Appui	1	1	1	1	1	
26-11	1421-602-4001-0	HOOK Crochet	1	1	1	1	1	
26-12	1421-602-0110-0	SUPPORT, SPRING Support	1	1	1	1	1	
26-13	1421-602-0030-0	SPRING, TENSION/65 Ressort	1	1	1	1	1	
26-14	1421-602-0040-0	SPRING, PRESS/85 Ressort	1	1	1	1	1	
26-15	V500-152-5015-0	PIN, SPLIT/2.5 X 15 Goupille fendue	2	2	2	2	2	
26-16	V201-260-8030-0	BOLT/M8 X 30 Vis	1	1	1	1	1	
26-17	V201-260-8035-0	BOLT/M8 X 35 Vis	1	1	1	1	1	
26-18	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
26-19	V413-160-0080-0	WASHER/M8 Rondelle	2	2	2	2	2	
26-20	1421-602-0050-0	CUSHION, B/RUBBER Cale B	2	2	2	2	2	
26-20a	1421-602-0051-0	CUSHION, B/RUBBER Cale B	2	2	2	2	2	ⓑ
26-21	V302-260-0080-0	NUT/M8 Eccrou	2	2	2	2	2	
26-22	1423-602-0010-0	PLATE SEAL Plaque	1	1	1	1	1	
26-23	V201-260-8016-0	BOLT/M8 X 16 Vis	2	2	2	2	2	
26-24	V300-260-0080-0	NUT/M8 Eccrou	2	2	2	2	2	
26-25	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
26-26	1421-602-8000-0	STOPPER, BONNET Arrêt	1	1	1	1	1	
26-27	1421-602-0070-0	SPRING, ROD Ressort	1	1	1	1	1	
26-28	V201-260-6012-0	BOLT/M8 X 12 Vis	1	1	1	1	1	
26-29	V300-260-0060-0	NUT/M8 Eccrou	1	1	1	1	1	
26-30	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	1	1	1	1	1	
26-31	V500-152-0018-0	PIN, SPLIT/2 X 18 Goupille fendue	1	1	1	1	1	
26-32	1431-604-2000-0	COVER, FAN Couvercle	1	1	1	1	1	
26-32a	1431-604-2001-0	COVER, FAN Couvercle	1	1	1	1	1	ⓑ
26-33	1431-604-2200-0	STAY, COVER Bride	1	1	1	1	1	
26-34	V201-260-8016-0	BOLT/M8 X 16 Vis	4	4	4	4	4	
26-35	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
26-36	V413-160-0080-0	WASHER/M8 Rondelle	2	2	2	2	2	

Ref.No. Réf.Nº	Parts No. Pièces Nº	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-FDU	
26-37	1425-604-2001-0	COVER, FAN B Couvercle B	1	1	1	1	1	
26-38	1424-604-4001-0	COVER, FAN D Couvercle D	1	1	1	1	1	
26-39	V201-260-8016-0	BOLT/M8 X 16 Vis	2	2	2	2	2	
26-40	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
26-41	V500-152-5015-0	PIN, SPLIT/2.5 X 15 Goupille fendue	1	1	1	1	1	
26-42	V413-160-0080-0	WASHER/M8 Rondelle	2	2	2	2	2	
26-43	1424-111-1000-0	BASE, TANK LH Assiette de réservoir G.	1	1	1	1		
26-43a	1424-111-1001-0	BASE, TANK LH Assiette de réservoir G.	1	1	1	1	1	Ⓔ { D #101098 F #003180
26-44	1424-111-2000-0	BASE, TANK RH Assiette de réservoir D.	1	1	1	1		
26-44a	1424-111-2001-0	BASE, TANK RH Assiette de réservoir D.	1	1	1	1	1	Ⓔ { D #101098 F #003180
26-45	V201-260-8016-0	BOLT/M8 X 16 Vis	3	3	3	3	3	
26-46	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
26-47	V413-160-0080-0	WASHER/M8 Rondelle	2	2	2	2	2	
26-48	V201-260-8020-0	BOLT/M8 X 20 Vis	1	1	1	1	1	
26-49	1421-602-7000-0	STAY, BRACKET Appui	2	2	2	2	2	
26-50	1424-604-0010-0	COLLAR/9 X 14 X 8 Collar	1	1	1	1	1	
26-51	1425-604-2100-0	STAY, COVER Bride	1	1	1	1	1	
26-52	1421-602-0090-0	CUSHION, TANK/RUBBER Cafe	2	2	2	2	2	For adjust
26-53	1425-602-2020-0	COLLAR/9 X 14 X 12 Collar	1	1	1	1	1	
26-54	1425-602-2030-0	COLLAR/9 X 14 X 16 Collar	1	1	1	1	1	
26-55	V201-260-8016-0	BOLT/M8 X 16 Vis	2	2	2	2	2	
26-56	V201-260-8025-0	BOLT/M8 X 25 Vis	1	1	1	1	1	
26-57	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	3	3	3	3	3	
26-58	V413-160-0080-0	WASHER/M8 Rondelle	3	3	3	3	3	
26-59	V413-160-0100-0	WASHER/M10	1	1	1	1	1	

SERVICE MEMO

1. The first step in the process of creating a new product is to identify a market need. This involves conducting market research to understand what consumers are looking for and what gaps exist in the current market.

2. Once a market need is identified, the next step is to develop a concept. This involves brainstorming ideas and creating a rough sketch of the product.

3. The third step is to create a prototype. This is a physical model of the product that can be used to test the design and make any necessary adjustments.


4. After the prototype is created, the next step is to conduct a feasibility study. This involves evaluating the product's potential for success in the market, taking into account factors such as cost, production time, and competition.

5. Once the feasibility study is complete, the next step is to develop a business plan. This document outlines the company's goals, strategies, and financial projections, and is used to secure funding from investors or lenders.

6. The final step in the process is to launch the product. This involves marketing the product to the target audience, distributing it, and providing customer support.

Fig.27 AXLE BRACKET AND BALANCE WEIGHT (S, D TYPE)


Support d'essieu



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	DU	
27- 1	1431-451-2000-0	BRACKET, AXLE Chassis av.	1	1					
27- 2	V201-461-4040-0	BOLT/M14 X 40 Vis	4	4					
27- 3	V201-461-4045-0	BOLT/M14 X 45 Vis	2	2					
27- 4	V401-160-0140-0	WASHER, SP/M14 Rondelle frein	6	6					
27- 5	1431-451-2200-0	HITCH, F. Support av.	1	1					
27- 6	V201-261-2025-0	BOLT/M12 X 25 Vis	5	5					
27- 7	V401-160-0120-0	WASHER, SP/M12 Rondelle frein	5	5					
27- 8	1417-401-0010-0	WEIGHT, BALANCE Contrepoids	1	1					★
27- 9	V201-261-0020-0	BOLT/M10 X 20 Vis	4	4					★ > Option for S-type
27-10	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	4	4					★
27-11	1415-401-0050-0	WEIGHT, BALANCE B Contrepoids B.	1	1					
27-12	V201-261-0020-0	BOLT/M10 X 20 Vis	4	4					
27-13	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	4	4					
27-14	1431-947-0030-0	MARK, MODEL Etiquette	1	1					
27-15	1427-932-0140-0	MARK, TYPE/E41 Etiquette	1	1					E41
27-15-1	1427-932-0160-0	MARK, TYPE/E43 Etiquette	1	1					E43
27-15-2	1431-948-0010-0	MARK, TYPE/E61	1	1					E61

Fig.28 AXLE BRACKET AND BALANCE WEIGHT (F-U, F-DU, LF-DU TYPE)

Support d'essieu




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-FDU	
28- 1	1431-455-2000-0	BRACKET, AXLE Chassis av.			1	1	1	
28- 2	V201-461-4040-0	BOLT/M14 x 40 Vis			4	4	4	
28- 3	V201-461-4045-0	BOLT/M14 x 45 Vis			2	2	2	
28- 4	V401-160-0140-0	WASHER, SP/M14 Rondelle frein			6	6	6	
28- 5	1425-436-2300-0	METAL, PIVOT F SET Pivot ar.			1	1	1	
28- 5a	1425-436-2301-0	METAL, PIVOT F SET Pivot ar.			1	1	1	Ⓔ #005643~
28- 6	1425-436-0020-0	BUSH/50 x 55 x 40 Cousinet			1	1	1	
28- 6a	1425-436-0021-0	BUSH/50 x 55 x 40 Cousinet			1	1	1	Ⓔ #00564, 3~
28- 7	V201-261-6045-0	BOLT/M16 x 45 Vis			4	4	4	
28- 8	V401-160-0160-0	WASHER, SP/M16 Rondelle frein			4	4	4	
28- 9	V761-400-0000-0	NIPPLE, GREASE Graisseur			2	2	2	
28-10	1425-436-2200-0	METAL, PIVOT R ASSY Pivot ar, complete			1	1	1	
28-10a	1425-436-2201-0	METAL, PIVOT R ASSY Pivot ar, complete			1	1	1	Ⓔ #005643~
28-11		• METAL, PIVOT R. Pivot ar			1	1	1	△
28-12	1425-436-2220-0	• BUSH/80 x 85 x 36 Cousinet			1	1	1	
28-12a	1425-436-2221-0	• BUSH/80 x 85 x 36 Cousinet			1	1	1	Ⓔ #005643~
28-13	V720-105-7080-0	• O-RING/P80 Joint torçue			2	2	2	
28-14	V401-561-6050-0	BOLT/M16 x 50 9T Vis			2	2	2	
28-15	V401-160-0160-0	WASHER, SP/M10 Rondelle frein			2	2	2	
28-16	V520-101-0022-0	PIN, A/10 x 22 Goupille			2	2	2	
28-17	1431-451-2200-0	HITCH, F. Accroch ar.			1	1	1	
28-18	V201-261-2025-0	BOLT/M12 x 25 Vis			5	5	5	
28-19	V401-160-0120-0	WASHER, SP/M12 Rondelle frein			5	5	5	
28-20	1431-947-0010-0	MARK, MODEL F Etiquette			1	1		
28-20-1	1431-947-0020-0	MARK, MODEL F Etiquette					1	
28-21	1427-932-0140-0	MARK, TYPE/E41 Etiquette			1	1		E41
28-21-1	1427-932-0160-0	MARK, TYPE/E43 Etiquette			1	1		E43
28-21-2	1431-948-0010-0	MARK, TYPE/E61 Etiquette			1	1		E61



Fig.29 FRONT AXLE (S, D TYPE)

Essieu avant



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	E	D	
29- 1	1431-045-2000-0	AXLE, F. SET Axe av.	1	1					
29- 2	1407-402-0010-0	BUSH/30 x 34 x 30 Cousinet	2	2					
29- 3	V763-400-0000-0	NIPPLE, GREASE Graisseur	1	1					
29- 4	1415-401-0020-0	PIVOT, CENTER Pivot d'essieu	1	1					
29- 5	V720-103-5030-0	O-RING/P30 Joint torique	2	2					
29- 6	1415-401-0040-0	COLLAR, PIVOT Collier	1	1					
29- 7	1415-401-0030-0	WASHER/21 x 42 x 6 Rondelle	1	1					
29- 8	V320-260-0200-0	NUT, SLOTTED/M20 Ecrou à crans	1	1					
29- 9	V500-154-0040-0	PIN, SPLIT/4 x 40 goupille fendue	1	1					
29-10	1425-422-2201-0	END, AXLE LH SET Extrémité d'axe G	1	1					
29-10a	1425-422-2202-0	END, AXLE LH SET Extrémité d'axe G	1	1					© D #101171~ inc. 29-17
29-11	1425-422-2301-0	END, AXLE RH SET Extrémité d'axe D	1	1					
29-11a	1425-422-2302-0	END, AXLE RH SET Extrémité d'axe D	1	1					
29-12	1426-402-0010-0	BOLT/M16 x 85 Vis	4	4					
29-12a	1426-402-0011-0	BOLT/M16 x 87 Vis	4	4					© #101171~
29-13	1404-401-0170-0	WASHER, B/M16 Rondelle	4	4					
29-14	V401-160-0160-0	WASHER, SP/M16 Rondelle frein	4	4					
29-15	V300-460-0160-0	NUT/M16 Ecran	4	4					
29-16	V761-400-0000-0	NIPPLE, GREASE Graisseur	2	2					
29-17	1414-501-0100-0	BUSH/35 x 40 x 35 Cousinet	4	4					
29-18	1426-423-0020-0	BEARING, TB Butée à billes	2	2					
29-19	V744-148-6809-0	SEAL, OIL/TC50689 Bague d'étanchéité	2	2					
29-20	V720-103-5035-0	O-RING/P35 Joint torique	4	4					
29-20a	V720-103-5035-0	O-RING/P35 Joint torique	2	2					© D #101171~
29-21	1426-423-2500-0	SPINDLE, KNUCKLE RH Broche D.	1	1					
29-22	1426-423-2300-0	BOSS, KNUCKLE SPINDLE Moyeu	1	1					
29-22a	1426-423-2301-0	BOSS, KNUCKLE SPINDLE Moyeu	1	1					© D #101171~
29-23	V580-140-8056-0	PIN, SPRING W/8 x 56 Goupille élastique	1	1					
29-24	1426-423-2400-0	SPINDLE, KNUCKLE LH Broche G.	1	1					
29-25	1326-708-0050-0	KEY Clevette	1	1					
29-26	1425-403-2200-0	ARM, DRAG Bras d'attelage	1	1					
27-26a	1425-403-2201-0	ARM, DRAG Bras d'attelage	1	1					© D #101171~
27-27	1404-401-0170-0	WASHER, B/M16 Rondelle	1	1					
29-28	1405-401-0060-0	WASHER/M16 Rondelle	1	1					
29-29	V330-260-0160-0	NUT/M16 Ecran	1	1					
29-30	1426-423-0010-0	COLLAR, OIL SEAL Collier	2	2					
29-31	V762-148-6507-0	SEAL, OIL/VC48657 Bague d'étanchéité	2	2					
29-32	V744-148-6509-0	SEAL, OIL/TC48659 Bague d'étanchéité	2	2					

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	LFDU	
29-34	V630-113-2007-0	BEARING, TR/32007 Roulement	2	2				
29-35	V630-113-0204-0	BEARING, TR/30204 Roulement	2	2				
29-36	V321-260-0200-0	NUT, SLOTTED/M20 Erou à creneaux	2	2				
29-37	V500-154-0030-0	PIN, SPLIT/4 X 30 Goupille fendue	2	2				
29-38	1431-461-0010-0	TUBE, TIE ROD Barre d'accouplement	1	1				
29-38a	1431-461-0011-0	TUBE, TIE ROD Barre d'accouplement	1	1				
29-39	1431-461-2000-0	ROD, TIE Barre d'accouplement	1	1				
29-40	1426-403-0020-0	METAL, TIE ROD SET Coquille	1	1				
29-41	1432-403-0071-0	WASHER Rondelle	2	2				
29-42	V201-461-0065-0	BOLT/M10 X 65 9T Vis	1	1				
29-43	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	1	1				
29-44	V300-460-0100-0	NUT/M10 Erou	1	1				
29-45	1426-426-0020-0	NUT, LH THREAD/M20 Erou	1	1				
29-46	V333-260-0200-0	NUT/M20 Erou	1	1				
29-47	1426-426-2100-0	END, ROD RH RH ASSY Rotule D.	1	1				
29-48	1425-433-2000-0	END, ROD LH LH ASSY Rotule G.	1	1				
29-49	V767-400-0000-0	* NIPPLE, GREASE Craisseur	2	2				
29-50	1426-426-2120-0	* COVER, DUST Cape	2	2				
29-51	V321-260-0140-0	* NUT, SLOTTED/M14 Erou à creneaux	2	2				
29-52	V500-153-0030-0	* PIN, SPLT/3 X 30 Goupille fendue	2	2				
29-53	1425-433-0310-0	SEAL, OIL/ES3E434 Bague d'étanchéité	2	2				© D#10171~
29-54	1424-951-0010-0	COLLAR, THRUST/4.5 Collier	1	1				★
29-55	1424-951-0020-0	COLLAR, THRUST/5 Collier	1	1				★
29-56	1424-951-0030-0	COLLAR, THRUST/6.5 Collier	1	1				★
29-57	1424-951-0040-0	COLLAR, THRUST/8 Collier	1	1				★
29-58	1424-951-0090-0	SHIM, A/0.5 Cale	2	2				★
29-59	1424-951-0110-0	SHIM, A/1.0 Cale	2	2				★
29-60	1424-953-0010-0	SEAL, OIL. Bague d'étanchéité	2	2				★ For axle end


© D#10171~

★ }
★ } For center pivot
★ }
★ }
★ } For knuckle spindle
★ }
★ For axle end

SERVICE MEMO


[illegible]

Fig.30 FRONT WHEEL (S, D TYPE)
Jante avant



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F-U	F-DU	L-FDU		
30- 1	1411-411-0020-0	CAP, WHEEL Chapeau	2	2					
30- 2	1411-411-0030-0	PACKING Joint	2	2					
30- 3	V200-260-6012-0	BOLT/M6 X 12 Vis	6	6					
30- 4	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	6	6					
30- 5	1426-428-0010-0	BOSS, F. WHEEL Moyeux av.	2	2					
30- 0-1	1431-478-2000-0	TIRE, F. ASSY Pneu av. ensemble	2	2				E21, E41	
30- 6	1425-428-2000-1	• RIM, F. WHEEL Trembois de roue	2	2				Option for E23, E43	
30- 7	1431-478-2010-0	• TIRE /5.00-15 4PR Pneu	2	2				E21, E41	
30- 8	V889-005-0015-0	• TUBE /5.00-15 Chambre a air	2	2					
30- 9	V999-300-0010-0	• CAP, TIRE VALVE Bouchon de valve	2	2					
30-10	V201-461-2025-0	BOLT/M12 X 25 9T Vis	12	12					
30-11	V401-160-0120-0	WASHER, SP/M12 Rondelle train	12	12					

Fig.31 AXLE HOUSING AND BEVEL CASE (F-U, F-DU TYPE)
Carter de pont avant




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-D	F-EU	
31- 1	1425-431-0031-0	CASE, BEVEL Carter de différentiel av.			1	1	1	
31- 2	1425-431-0110-0	METAL, DIFF Pallier			2	2	2	
31- 3	1425-431-0120-0	SHIM, B Cale			AR	AR	AR	
31- 4	1425-431-0130-0	SHIM, C Cale			AR	AR	AR	
31- 5	V201-260-8020-0	BOLT/MBX 22 Vis			8	8	8	
31- 6	V401-160-0080-0	WASHER, SP/M8 Rondelle train			8	8	8	
31- 7	1425-432-2002-0	HOUSING, AXLE Tube pont			1	1	1	
31- 8	1425-432-0020-0	PACKING, HOUSING Joint			1	1	1	
31- 9	7963-201-0030-0	PIN, KNOCK/10 X 22 Goupille			2	2	2	
31- 9a	1425-432-0030-0	PIN, KNOCK/10 X 22 Goupille			2	2	2	(A)
31-10	V251-441-0022-0	BOLT, STUD/M10 X 22 Goujon			10	10	10	
31-11	V401-160-0100-0	WASHER, SP/M10 Rondelle train			10	10	10	
31-12	V300-460-0100-0	NUT/M10 7T Ecrou			10	10	10	
31-13	V781-100-0008-0	PLUG Bouchon			1	1	1	
31-14	1425-432-0010-0	PIPE, BREATHER Tubulure			1	1	1	
31-15	V720-103-5050-0	O-RING/P50 Joint torique			1	1	1	
31-16	1425-431-0040-0	COLLAR, THRUST Collier			1	1	1	
31-17	V720-103-5040-0	O-RING/P40 Joint torique			1	1	1	
31-18	1424-951-0050-0	COLLAR, THRUST F/5.5 Collier			AR	AR	AR	★
31-19	1424-951-0060-0	COLLAR, THRUST F/6 Collier			AR	AR	AR	★
31-20	1424-951-0070-0	COLLAR, THRUST F/6.5 Collier			AR	AR	AR	★
31-21	1424-951-0080-0	COLLAR, THRUST F/7 Collier			AR	AR	AR	★
31-22	1424-951-0140-0	SHIM, C/0.5 Cale			2	2	2	★
31-23	1424-951-0150-0	SHIM, C/1.0 Cale			2	2	2	★
31-24	1424-953-0010-0	SEAL, OIL Bague d'étanchéité			AR	AR	AR	★ For axle end

For center pivot

For Bearing Cover

Fig.32 FINAL CASE AND KNUCKLE ARM SYSTEM(F-U, F-DU TYPE)
Reducteur de roue avant



Ref.No. Réf.No.	Parts No. Pièces No.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-FDU	
32- 1	1425-433-0011-0	CASE, FINAL A Carter de reducteur A.			2	2	2	
32- 2	1425-433-0041-0	PACKING, CASE Joint			2	2	2	
32- 3	7963-201-0030-0	PIN, KNOCK Goupille			4	4	4	
32- 4	V201-461-2030-0	BOLT/M12 x 30 Vis			12	12	12	
32- 5	V401-160-0120-0	WASHER, SP/M12 Rondelle frein			12	12	12	
32- 6	1425-433-0080-0	COVER, BEARING Couvercle			2	2	2	
32- 6a	1425-433-0081-0	COVER, BEARING Couvercle			2	2	2	Ⓒ #005420~
32- 7	1425-433-0090-0	PACKING, COVER A Joint			2	2	2	
32- 8	1425-433-0150-0	BUSH/35 x 39 x 26 Cousinnet			2	2	2	
32- 8a	1425-433-0151-0	BUSH/35 x 39 x 26 Cousinnet			2	2	2	Ⓒ #005420~
32- 9	1425-433-0310-0	SEAL, OIL/OS35424 Bague d'étanchéité			2	2	2	
32-10	V201-560-8020-0	BOLT/M8 x 20 Vis			12	12	12	
32-11	V401-160-0080-0	WASHER, SP/M8 Rondelle frein			12	12	12	
32-12	1425-433-2200-0	CASE, FINAL B LH SET Carter de reducteur B G.			1	1	1	
32-12a	1425-433-2201-0	CASE, FINAL B LH SET Carter de reducteur B G.			1	1	1	Ⓓ #005643~
32-13	1425-433-2300-0	CASE, FINAL B RH SET Carter de reducteur B G.			1	1	1	
32-13a	1425-433-2301-0	CASE, FINAL B RH SET Carter de reducteur B G.			1	1	1	Ⓒ #001226~
32-13b	1425-433-2302-0	CASE, FINAL B RH SET Carter de reducteur B G.			1	1	1	Ⓓ #005643~
32-14	1425-433-0240-0	COVER, WHEEL SHAFT LH Couvercle de reducteur			1	1	1	
32-14a	1425-433-0240-0	COVER, WHEEL SHAFT LH Couvercle de reducteur			2	2	2	#001226~
32-15	1425-433-0250-0	COVER, WHEEL SHAFT RH Couvercle de reducteur			1	1	1	Ⓓ ~#001225
32-16	1425-433-0260-0	PACKING, COVER B Joint			2	2	2	
32-17	V781-100-0008-0	PLUG Bouchon			4	4	4	
32-18	V520-101-0022-0	PIN, A/10 x 22 Goupille			4	4	4	
32-19	V201-461-0025-0	BOLT/M10 x 25 Vis			28	28	28	
32-20	V401-160-0100-0	WASHER, SP/M10 Rondelle frein			24	24	24	
32-21	1425-433-2401-0	ARM, DRAG SET Bras d'attelage			1	1	1	
32-21a	1425-433-2402-0	ARM, DRAG SET Bras d'attelage			1	1	1	Ⓒ #005420~
32-22	1425-433-2501-0	METAL, KING PIN SET Coquille			1	1	1	
32-22a	1425-433-2502-0	METAL, KING PIN SET Coquille			1	1	1	Ⓒ #005420~
32-23	V761-400-0000-0	NIPPLE, GREASE Graisseur			2	2	2	
32-24	V520-101-0022-0	PIN, A/10 x 22 Goupille			2	2	2	
32-25	V251-441-0025-0	STUD/M10 x 25 9T Goujon			4	4	4	
32-26	V401-160-0100-0	WASHER, SP/M10 Rondelle frein			8	8	8	
32-27	V300-160-0100-0	NUT/M10 Ecrou			4	4	4	
32-28	1425-433-0271-0	ARM, KNUCKLE LH Lavier de fusée G.			1	1	1	
32-29	1425-433-0281-0	ARM, KNUCKLE RH Lavier de fusée D.			1	1	1	
32-30	V201-461-0025-0	BOLT/M10 x 25 Vis			8	8	8	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	E	D	
32-31	V401-160-0100-0	WASHER, SP/M10 Rondelle train			8	8	8		
32-32	1425-433-0291-0	ROD, TIE Barre d'accouplement			1	1	1		
32-33	V333-260-0200-0	NUT/M20 Eccrou			1	1	1		
32-34	1426-426-0020-0	NUT, LH THREAD/M20 Eccrou			1	1	1		
32-35	1426-426-2100-0	END, ROD RH RH ASSY Ratelle G.			1	1	1		
32-36	1425-433-2000-0	END, ROD LH LH ASSY Ratelle D.			1	1	1		
32-37	V767-400-0000-0	* NIPPLE, GREASE Graisseur			2	2	2		
32-38	1426-426-2120-0	* COVER, DUST Calthe			2	2	2		
32-39	V321-260-0140-0	NUT, SLOTTED/M14 Eccrou à créneaux			2	2	2		
32-40	V500-153-0030-0	PIN, SPLIT/3 X 30 Goupille fendue			2	2	2		

Blank page.


Commande et blocage du différentiel



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques	
			S	D	F.U	F.DU	L.FDU		
33- 1	1425-431-2000-0	PINION, DRIVE F SET Pignon d'attache				1	1	1	
33- 1a	1425-431-2001-0	PINION, DRIVE F SET Pignon d'attache				1	1	1	© #003462~
33- 2	V705-140-0620-0	RING, SNAP/C 62 Collet d'axe				1	1	1	
X33- 3	~~1425-421-0090-0~~ ~~1425-431-0090-0~~	COLLAR, B Collier				1	1	1	info n° 82-03 (1/4) March 31, '82
33- 4	1425-431-0080-0	SHIM, A/0.2 Cale				AR	AR	AR	
33- 5	1415-205-0160-0	SHIM, B/0.1 Cale				AR	AR	AR	
33- 6	V631-113-2206-0	BEARING, TR/32206 Roulement				1	1	1	
X33- 7	~~1425-421-0050-0~~ ~~1425-431-0050-0~~	COLLAR, A Collier				1	1	1	info n° 82-03 (1/4) March 31, '82
33- 8	V630-113-0206-0	BEARING, TR/30206 Roulement				1	1	1	
33- 9	1425-431-0070-0	WASHER, LOCK Rondelle frein				1	1	1	
33-10	1425-431-0060-0	NUT/M30 Erou				2	2	2	
33-11	V744-125-4511-0	SEAL, OIL/TC254511 Bague d'étanchéité				1	1	1	
33-12	1425-431-0140-0	CASE, DIFF Boîtier de differential				1	1	1	
33-12a	1425-431-0141-0	CASE, DIFF Boîtier de differential				1	1	1	© #003462~
33-13	1425-431-0160-0	GEAR, BEVEL/20T Planétaire				2	2	2	
33-14	1425-431-0210-0	HOLDER, DIFF PINION Carter				1	1	1	
33-15	1425-431-0150-0	PINION, DIFF/11T Satellites				4	4	4	
33-16	1427-301-0050-0	COLLAR, PINION THRUST Coupelle de jeu				4	4	4	
X33-17 a	~~1488-411-0060-0~~ ~~1425-431-0160-0~~	SHAFT, DIFF PINION A Axes des satellites A.				1	1	1	Ⓐ info n° 83-18(2/2) Jan 11, '83
X33-18 a	~~1488-411-0070-0~~ ~~1425-431-0190-0~~	SHAFT, DIFF PINION B Axes des satellites B.				2	2	2	Ⓐ " " "
33-19	V520-100-8020-0	PIN, A/8 x 20 Bouillo				3	3	3	
33-20	1425-431-0170-0	COLLAR, THRUST/43 x 58 x 1 Collier				1	1	1	
33-20a	1421-301-0120-0	COLLAR, THRUST/43 x 58 x 1 Collier				1	1	1	Ⓐ
33-21		GEAR, BEVEL/35T Pignon conique				1	1	1	△
33-21a		GEAR, BEVEL/35T Pignon conique				1	1	1	△ #003462~
33-22	V251-440-8042-0	STUD/M8 x 42 Goujon				4	4	4	
33-23	V401-160-0080-0	WASHER, SP/M8 Rondelle frein				4	4	4	
33-24	V300-460-0080-0	NUT/M8 7T Erou				4	4	4	
33-25	V600-110-6011-0	BEARING, RB/6011 Roulement radial				2	2	2	

Fig.34 FRONT WHEEL DRIVING SYSTEM(F-U, F-DY TYPE)

Jante avant




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-D	LEDE	
34- 0-1	1431-476-2000-0	TIRE, F. LH ASSY Roue av. G. ensemble			1	1	1	E21, E41
34- 1	1425-438-2001-1	• RIME, F. WHEEL Jante			1	1	1	Option for E23, E43
34- 2	1431-476-2010-0	• TIRE/6.00-16 4PR Pneu			1	1	1	Info no. 82-03 (1/4) March 31, '82 E21, E41
*34- 3	~~V338-006-0016-0~~ ~~V889-006-0016-0~~	• TUBE/6.00-16 Chambre à air			1	1	1	
34- 4	V999-300-0010-0	• CAP, TIRE VALVE Bouchon de valve			1	1	1	
34- 0-2	1431-476-2100-0	TIRE, F. RH ASSY Roue av. D. ensemble			1	1	1	
34- 5	1425-438-2001-1	• RIM, F. WHEEL Jante			1	1	1	Option for E43
34- 6	1431-476-2010-0	• TIRE/6.00-16 4PR Pneu			1	1	1	E21, E41
34- 7	V889-006-0016-0	• TUBE/6.00-16 Chambre à air			1	1	1	
34- 8	V999-300-0010-0	• CAP, TIRE VALVE Bouchon de valve			1	1	1	
34- 9	1425-433-0190-0	SHAFT, WHEEL Fusée			2	2	2	
34-10	V744-155-7812-0	SEAL, OIL/TC557812 Bague d'étanchéité			2	2	2	
34-11	V742-155-7809-0	SEAL, OIL/VC55789 Bague d'étanchéité			2	2	2	
34-12	1425-433-0230-0	COLLAR, THRUST Collier			2	2	2	
34-13	V201-461-2025-0	BOLT/M12 X 25 9T Vis			12	12	12	
34-14	V401-160-0120-0	WASHER, SP/M12 Rondelle frein			12	12	12	
34-15	V600-110-6309-0	BEARING, RB/6309 Roulement radial			2	2	2	
34-16	1425-433-0220-0	RING, SNAP Collet d'axe			2	2	2	
34-16a	1425-433-0221-0	RING, SNAP Collet d'axe			4	4	4	
34-17	1425-433-0210-0	GEAR, BEVEL/40T Pignon conique			2	2	2	
34-18	V600-110-6208-0	BEARING, RB/6208 Roulement radial			2	2	2	
34-19	V600-110-6306-0	BEARING, RB/6306 Roulement radial			2	2	2	
34-20	V705-140-0720-0	RING, SNAP/C72 Collet d'axe			2	2	2	
34-21	1425-433-0180-0	CAP, BLANK/72 Pare-set			2	2	2	
34-22	1425-433-0130-0	BUSH/55 x 60 x 30 Cousinnet			2	2	2	
34-22a	1425-433-0131-0	BUSH/55 x 60 x 30 Cousinnet			2	2	2	① #005643~
34-23	V744-155-7209-0	SEAL, OIL/TC55729 Bague d'étanchéité			2	2	2	
34-24	1425-433-0060-0	SHAFT, COUNTER Arbre intermédiaire			2	2	2	
34-25	1425-433-0170-0	GEAR, BEVEL/16T Pignon conique			2	2	2	
34-26	V610-115-1107-0	BEARING, TB/51107 Butée à billes			2	2	2	
34-27	V704-140-0300-0	RING, SNAP/C 30 Collet d'axe			2	2	2	
34-28	1425-433-0050-0	GEAR, BEVEL/17T Pignon conique			2	2	2	
34-29	1425-433-0070-0	WASHER/13 X 42 X 9 Rondelle			2	2	2	
34-30	V201-461-2030-0	BOLT/M12 X 30 Vis			2	2	2	
34-31	V401-160-0120-0	WASHER, SP/M12 X 30 9T Rondelle frein			2	2	2	
34-32	V600-110-6013-0	BEARING, RB/6013 Roulement radial			2	2	2	
34-33	1425-433-0030-0	SHAFT, FINAL DRIVE Arbre			2	2	2	
*34-34	V704-140-0350-0	RING, SNAP/C 35 Collet d'axe			2	2	2	① Info no. 83-18 (1/2) Jan 14, '83

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F	U	F	
34-35	V600-110-6307-0	BEARING, R8/6307 Roulement radial			2	2	2	
34-36	1425-433-0020-0	GEAR, BEVEL/13T Pignon conique			2	2	2	
34-37	V704-140-0250-0	RING, SNAP/C-26 Carter d'axe			2	2	2	(D) imp no. 83 - 18 (1/2) Jan 17, '83

Blank lined paper for writing.


Fig.35 STEERING WHEEL (S, D TYPE)

Direction



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	EDU	LFDU	
35- 1	1426-406-2003-0	BOX, STEERING GEAR ASSY Boîtier de direction	1	1				See Fig. 72
35- 2	V413-160-0100-0	WASHER/M10 Rondelle	1	1				
35- 3	V321-260-0100-0	NUT, SLOTTED/M10 P = 1.25 Eccrou à créneaux	1	1				
35- 4	V500-152-0025-0	PIN, SPLIT/2 X 25 Goupille fendue	1	1				
35- 5	1421-400-0520-0	WHEEL, STEERING ASSY Voient	1	1				
35- 6	1407-406-0020-0	• CAP, STEERING Cape	1	1				
35- 7	1407-406-0040-0	• PACKING, CAP Anneau	1	1				
35- 8	1421-903-0160-0	MARK, CAP Étiquette	1	1				
35- 9	V520-101-0022-0	PIN, A/10 X 22 Goupille	2	2				
35-10	V201-461-2030-0	BOLT/M12 X 30 9T Vis	4	4				
35-11	V401-160-0120-0	WASHER, SP/M12 Rondelle frein	4	4				
35-12	1425-406-0010-0	ROD, DRAG Tige de direction	1	1				
35-13	1421-403-0020-0	NUT, LG THREAD/M17 Eccrou	1	1				
35-14	1421-403-0010-0	NUT/M17 Eccrou	1	1				
35-16	1423-400-0520-0	END, ROD RH ASSY Rotule G	1	1				
35-17	1421-400-0540-0	END, ROD LH ASSY Rotule D	1	1				
35-18	1404-402-0010-0	• COVER, DUST Cape	2	2				
35-19	1421-403-0030-0	• NUT, SLOTTED/M12 Eccrou à créneaux	2	2				
35-20	V500-152-5025-0	• PIN, SPLIT/2.5 X 25 Goupille	2	2				
35-21	1404-402-0050-0	• NIPPLE, GREASE Graisseur	2	2				



Fig.36 STEERING WHEEL(F-U, F-DU LF-DU TYPE)
Direction



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F.U	F.DU	LE	DU	
36- 1	1426-426-2001-0	BOX, STEERING GEAR Boîtier de direction			1	1	1		See Fig. 73 © { D #101326~ F #004696~
36- 1a	1426-426-2002-0	BOX, STEERING GEAR Boîtier de direction			1	1	1		
36- 2	V413-160-0100-0	WASHER/M10 Rondelle			1	1	1		
36- 3	V321-260-0100-0	NUT, SLOTTED/M10 Eccrou à créneaux			1	1	1		
36- 4	V500-152-0025-0	PIN, SPLIT/2 x 25 Goupille fendue			1	1	1		
36- 5	1421-400-0520-0	WHEEL, STEERING ASSY Volant			1	1	1		
36- 6	1407-406-0020-0	* CAP, STEERING Calotte			1	1	1		
36- 7	1407-406-0040-0	* PACKING, CAP Anneau			1	1	1		
36- 8	1421-903-0160-0	MARK, CAP Étiquette			1	1	1		
36- 9	V520-101-0022-0	PIN, A/10 x 22 Goupille			2	2	2		
36-10	V251-441-2030-0	STUD/M12 x 30 9T Goujon			2	2	2		
36-11	V401-160-0120-0	WASHER, SP/M12 Rondelle frein			2	2	2		
36-12	V300-460-0120-0	NUT/M12 7T Eccrou			2	2	2		
36-13	V201-461-2035-0	BOLT/M12 x 35 9T Vis			2	2	2		
36-14	V401-160-0120-0	WASHER, SP/M12 Rondelle frein			2	2	2		
36-15	1425-437-0010-0	ROD, DRAG Tige de direction			1	1	1		
36-16	1426-426-0020-0	NUT, LH THREAD/M20 Eccrou			1	1	1		
36-17	V333-260-0200-0	NUT/M20 Eccrou			1	1	1		
36-18	1426-426-2100-0	END, ROD RH RH ASSY Rotule G			1	1	1		
36-19	1426-426-2200-0	END, ROD LH RH ASSY Rotule D			1	1	1		
36-20	1426-426-2120-0	* COVER, DUST Caienne			2	2	2		
36-21	V321-260-0140-0	* NUT, SLOTTED/M14 Eccrou			2	2	2		
36-22	V500-153-0030-0	* PIN, SPLIT/3 x 30 Goupille			2	2	2		
36-23	V767-400-0000-0	* NIPPLE, GREASE Graisseur			2	2	2		
36-24	1431-952-0010-0	DAMPER, STEERING Amortisseur			1	1	1		
36-25	1431-952-2000-0	BRACKET, A Support			1	1	1		
36-26	1431-952-2100-0	BRACKET, B Support			1	1	1		
36-27	1431-952-0021-0	PIN/60 Goupille			2	2	2		
36-28	V201-461-2045-0	BOLT/M12 x 45 9T Vis			2	2	2		
36-29	V413-160-0120-0	WASHER/M12 Rondelle			2	2	2		
36-30	V500-153-0025-0	PIN, SPLIT/3 x 25 Goupille fendue			2	2	2		


Fig.37 METER PANEL

Tableau de board



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	F.DU	
37- 1	1431-661-2000-1	PANEL, METER Tableau de bord	1	1	1	1	1	
37- 1a	1431-661-2001-1	PANEL, METER Tableau de bord	1	1	1	1	1	Ⓑ { D #001177~ F #003470~
37- 2	1421-903-0190-0	MARK, KEY SWITCH Etiquette	1	1	1	1	1	
37- 2a	1422-940-0080-0	MARK, KEY SWITCH Etiquette	1	1	1	1	1	Ⓐ
37- 3	1421-904-0030-0	MARK, STARTER A Etiquette	1	1	1	1	1	
37- 3a	1427-941-0190-0	MARK, STARTER A Etiquette	1	1	1	1	1	Ⓑ
37- 4	1427-937-0040-0	MARK, DRIVE Etiquette	1	1	1	1	1	English
37- 4-1	1427-934-0040-0	MARK, DRIVE Etiquette	1	1	1	1	1	★ French
37- 5	1421-903-0060-0	MARK, BLINKER Etiquette	1	1	1	1	1	
37- 5a	1431-940-0170-0	MARK, BLINKER/W Etiquette	1	1	1	1	1	Ⓑ
37- 6	1427-903-0040-0	MARK, HORN Etiquette	1	1	1	1	1	
37- 7	V201-260-8020-0	BOLT/M8 X 20 Vis	2	2	2	2	2	
37- 8	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
37- 9	3740-314-0170-0	WASHER Rondelle	2	2	2	2	2	
37- 9a	3560-201-0150-0	WASHER Rondelle	2	2	2	2	2	Ⓒ
37-10	1421-603-0010-0	BUSH, STEERING Cousinnet	1	1	1	1	1	
37-11	1421-603-0040-0	BUSH, LEVER Cousinnet	1	1	1	1	1	
37-12	1423-603-0010-0	STAY, METER Appui	1	1	1	1	1	
37-13	1423-603-0020-0	SHIELD, END Joint	1	1	1	1	1	
37-14	V200-260-6016-0	BOLT/M6 X 16 Vis	2	2	2	2	2	
37-15	V300-260-0060-0	NUT/M6 Eccrou	2	2	2	2	2	
37-16	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	2	2	2	2	2	
37-17	V413-160-0060-0	WASHER/M6 Rondelle	2	2	2	2	2	
37-18	1421-904-0040-0	MARK, STARTER B Etiquette	1	1	1	1	1	
37-18a	1427-941-0210-0	MARK, STARTER BU Etiquette	1	1	1	1	1	Ⓑ
37-19	1423-904-0030-0	MARK, FUEL LAMP Etiquette	1	1	1	1	1	Ⓓ English
37-19-1	1431-935-0050-0	MARK, FUEL LAMP Etiquette	1	1	1	1	1	★Ⓓ French
37-20	1421-903-0220-0	MARK, THROTTLE Etiquette	1	1	1	1	1	
37-20a	1422-940-0090-0	MARK, THROTTLE Etiquette	1	1	1	1	1	Ⓐ
37-21	1421-904-0050-0	MARK, GLOW Etiquette	1	1	1	1	1	Ⓓ English
37-21-1	1431-935-0060-0	MARK, GLOW Etiquette	1	1	1	1	1	Ⓓ French
37-22	1431-938-0050-0	MARK, WARNING SWITCH Etiquette	1	1	1	1	1	Ⓓ
37-23	1431-938-0060-0	MARK, PANEL Etiquette	1	1	1	1	1	Ⓒ English { D #100943~ F #002578~
37-23-1	1431-935-0090-0	MARK, PANEL Etiquette	1	1	1	1	1	★Ⓒ French


Fig.38 CLUTCH HOUSING(S TYPE)
Embrayage



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
38- 1	1424-120-0012-0	HOUSING, CLUTCH Cartier d'embrayage	1						
38- 2	V303-460-0140-0	NUT/M14 Eccrou	2						
38- 3	V401-160-0140-0	WASHER, SP/M14 Rondelle frein	2						
38- 4	V251-341-2032-0	STUD/M12 X 32 9T Goujon	3						
38- 5	V201-461-2035-0	BOLT/M12 X35 Vis	5						
38- 6	V401-260-0120-0	WASHER, SP/M12 Rondelle frein	10						
38- 7	V300-460-0120-0	NUT/M12 Eccrou	3						
38- 8	V303-460-0120-0	NUT/M12 Eccrou	4						
38- 9	1404-120-0090-0	WASHER/M12 Rondelle	3						
38-10	1427-317-0040-0	CAP, BLANK/M14 Fusset	20						
38-11	1326-706-0020-0	PLUG, DRAIN Bouchon	2						
38-12	V763-400-0000-0	NIPPLE, GREASE Graisseur	2						
38-13	V520-201-0022-0	PIN, A/10 X 22 Goupille	1						
38-14	1416-120-0020-0	COVER, INSPECTION Couvercle	1						
38-15	1416-120-0030-0	PACKING Joint	1						
38-16	V201-260-8016-0	BOLT/M8 X 16 Vis	4						
38-17	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4						
38-18	1415-121-0010-0	GUIDE, SLEEVE Manchon	1						
38-19	1401-211-0100-0	BOLT/M8 X 25 Vis	3						
38-20	V401-260-0080-0	WASHER, SP/M8 Rondelle frein	3						
38-21		WIRE/0.9 X 200 Fil	1						
38-22	1417-121-0021-0	SLEEVE Manchon	1						
38-23	1416-120-0040-0	BEARING, RELEASE/40TMK 20B1 Roulement	1						
38-24	1415-120-0060-0	SPRING, TENSION/86 Ressort	2						
38-25	1415-121-0040-0	SHAFT, INPUT Arbre d'entrée	1						
38-26	1415-121-0050-0	COUPLING, SPLINE Couplage	1						
38-27	1415-121-0060-0	WASHER, LOCK Rondelle frein	1						
38-28	V201-461-0040-0	BOLT/M10 X 40 Vis	2						
38- 0-1	1417-100-0521-0	CLUTCH ASSY/225 Embrayage ensemble	1						
38-29	1417-121-1001-0	* PLATE, PRESS ASSY Plaque	1						
38-30	1415-121-2000-0	* DISC, CLUTCH ASSY Disque d'embrayage	1						
38-31	V401-260-0080-0	WASHER, SP/M8 Rondelle frein	6						
38-32	1415-121-0090-0	BOLT/M8 X 25 Vis	2						
38-33	V201-260-8025-0	BOLT/M8 X 25 Vis	4						

Fig.39 CLUTCH HOUSING(F-U TYPE)

Embrayage




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-EDU	
39- 1	1425-132-0013-0	HOUSING, CLUTCH Carter d'embrayage			1			
39- 2	V401-160-0140-0	WASHER, SP/M14 Rondelle frein			2			
39- 3	V303-460-0140-0	NUT/M14 7T Erou			2			
39- 4	V251-441-2032-0	STUD/M12 X 32 9T Gaunjon			3			
39- 5	V201-461-2035-0	BOLT/M12 X 35 9T Vis			5			
39- 6	V401-160-0120-0	WASHER, SP/M12 Rondelle frein			10			
39- 7	V300-460-0120-0	NUT/M12 7T Erou			3			
39- 8	V303-460-0120-0	NUT/M12 7T Erou			4			
39- 9	1404-120-0090-0	WASHER, LOCK/M12 Rondelle frein			3			
39-10	1427-317-0040-0	CAP, BLANK/M14 Fausset			14			
39-11	V781-100-0008-0	PLUG Bouchon			1			
39-12	V763-400-0000-0	NIPPLE, GREASE Graisseur			2			
39-13	V520-101-0022-0	PIN, A/10 X 22 Goupille			1			
39-14	1416-120-0020-0	COVER, INSPECTION Couvercle			1			
39-15	1416-120-0030-0	PACKING Joint			1			
39-16	V201-260-8016-0	BOLT/M8 X 16 Vis			4			
39-17	V401-160-0080-0	WASHER, SP/M8 Rondelle frein			4			
39-18	1415-121-0010-0	GUIDE, SLEEVE Manchon			1			
39-19	1401-211-0100-0	BOLT/M8 X 25 Vis			3			
39-20	V401-160-0080-0	WASHER, SP/M8 Rondelle frein			3			
39-21		WIRE/0.9 X 200 Fil			1			
39-22	1417-121-0021-0	SLEEVE Manchon			1			
39-23	1416-120-0040-0	BEARING, RELEASE/40TM 20B1 Roulement			1			
39-24	1415-120-0060-0	SPRING, TENSION/85 Resort			2			
39-25	1415-121-0040-0	SHAFT, INPUT Arbre d'entrée			1			
39-26	1415-121-0050-0	COUPLING, SPLINE Couple			1			
39-27	1415-121-0060-0	WASHER, LOCK Rondelle frein			1			
39-28	V201-461-0040-0	BOLT/M10 X 40 9T Vis			2			
39- 0-1	1417-100-0521-0	CLUTCH ASSY/225 Embrayage ensemble			1			
39-29	1417-121-1001-0	• PLATE, PRESS ASSY Plaque			1			
39-30	1415-121-2000-0	• DISK, CLUTCH ASSY/225 Disque d'embrayage			1			
39-31	V401-160-0080-0	WASHER, SP/M8 Rondelle frein			6			
39-32	1415-121-0090-0	BOLT/M8 X 25 Vis			2			
39-33	V201-260-8025-0	BOLT/M8 X 25 Vis			4			
39-34	1425-139-0040-0	METAL, SHIFT Carter			1			
39-35	1425-139-0050-0	PACKING Joint			1			
39-36	V520-101-0022-0	PIN, A/10 X 22 Goupille			2			
39-37	V201-461-0105-0	BOLT/M10 X 105 9T Vis			4			

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F-U	F-D	L-F	D-U	
39-38	V201-461-0095-0	BOLT/M10 X 95 9T Vis			2				
39-39	V401-160-0100-0	WASHER, SP/M10 Rondelle frein			6				
39-40	V781-100-0006-0	PLUG Bouchon			1				
39-41	1326-706-0020-0	PLUG, DRAIN Bouchon			2				
39-42	V705-140-0170-0	RING, SNAP/C 17 Collet d'axe			1				
39-43	1425-132-0021-0	GEAR, DRIVE/17T Pignon d'attache			1				
39-44	V600-110-6206-0	BEARING, RB/6206 Roulement radial			1				
39-45	V740-142-6512-0	SEAL, OIL/SC426512 Bague d'étanchéité			1				

100

Fig.40 CLUTCH HOUSING(D TYPE)
Embrayage




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	FDU	LFDE	
40- 1	1424-120-0012-0	HOUSING, CLUTCH Carter d'embrayage		1				
40- 2	V303-460-0140-0	NUT/M14 7T Erou		2				
40- 3	V401-160-0140-0	WASHER, SP/M14 Rondelle frein		2				
40- 4	V251-441-2032-0	STUD/M12 X 32 9T Goujon		3				
40- 5	V201-461-2035-0	BOLT/M12 X 35 9T Vis		5				
40- 6	V401-160-0120-0	WASHER, SP/M12 Rondelle frein		10				
40- 7	V300-460-0120-0	NUT/M12 7T Erou		3				
40- 8	V303-460-0120-0	NUT/M12 7T Erou		4				
40- 9	1404-120-0090-0	WASHER, LOCK/M12 Rondelle frein		3				
40-10	1427-317-0040-0	CAP, BLANK/M14 Fausset		20				
40-11	1326-706-0020-0	PLUG, DRAIN Bouchon		2				
40-12	V763-400-0000-0	NIPPLE, GREASE Graisseur		2				
40-13	V320-101-0022-0	PIN, A/10 X 22 Goupille		1				
40-14	1416-120-0020-0	COVER, INSPECTION Couvercle		1				
40-15	1416-120-0030-0	PACKING Joint		1				
40-16	V201-260-8016-0	BOLT/M8 X 16 Vis		4				
40-17	V401-160-0080-0	WASHER, SP/M8 Rondelle frein		4				
40-18	1415-120-0030-0	GUIDE, SLEEVE Manchon		1				
40-19	1401-211-0100-0	BOLT/M8 X 25 Vis		3				
40-20	V401-160-0080-0	WASHER, SP/M8 Rondelle frein		3				
40-21		WIRE/0.9 X 200 Fil		1				
40-22	V600-150-6207-0	BEARING, RB/62072NS Roulement radial		1				
40-23	1415-120-0050-0	SLEEVE Manchon		1				
40-24	1415-120-0040-0	BEARING, RELEASE Roulement		1				
40-25	1415-120-0060-0	SPRING, TENSION/86 Ressort		2				
40-26	1417-120-0021-0	SHAFT, INPUT A Arbre d'entrée A.		1				
40-27	V705-140-0170-0	RING, SNAP/C 17 Collet d'axe		1				
40-28	1415-120-0080-0	COUPLING, SPLINE/20 X 75 Couplage		1				
40-29	1417-120-1002-0	SHAFT, INPUT B Arbre d'entrée B.		1				
40- 0-1	1426-120-2001-0	CLUTCH, DUAL ASSY/225 Embrayage ensemble		1				
40- 0-1a	1426-120-2002-0	CLUTCH, DUAL ASSY/225 Embrayage ensemble		1				①
40-30	1415-120-0090-0	• COVER, CLUTCH A Couvercle A.		1				△
40-31	1426-120-2100-0	• DISC, CLUTCH F/225 Disque d'embrayage		1				
40-32	1415-120-0110-0	• PLATE, PRESS A Plaque A		1				△
40-33	1415-120-0160-0	• BOLT Vis		3				
40-34	1415-120-0170-0	• NUT Erou		3				
40-35	1415-120-0130-0	• SPRING, DIAPHRAGM Ressort		2				△
40-36	1426-120-2201-0	• DISC, P/225 Disque d'embrayage		1				

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.FDU	
40-36a	1426-120-2202-0	• DISC, P/225 Disque d'embrayage		1				ⓑ
40-37	1415-120-0120-0	• PLATE, PRESS B Plaque B.		1				^
40-38	1415-120-0100-0	• COVER, CLUTCH B Couverture B.		1				
40-39	1415-120-0230-0	• PIPE, KNOCK Goupille		4				
40-40	1415-120-0220-0	• BOLT Vis		6				
40-41	1415-120-0240-0	• WASHER, SP/M8 Rondelle frein		6				
40-42	1415-120-0250-0	• WASHER/M8 Rondelle		2				
40-43	1415-120-3000-0	• ROD, RELEASE Barre		3				
40-44	1415-120-2000-0	• LEVER, RELEASE Lavier		3				
40-45	1415-120-0020-0	• PIN, RELEASE ROD Goupille		3				
40-46	1415-120-0180-0	• PIN, LEVER A Goupille		3				
40-47	1415-120-0210-0	• WASHER Rondelle		3				
40-48	V500-151-2015-0	• PIN, SPLIT/12 X 15 Goupille fendue		3				
40-49	1415-120-0190-0	• PIN, LEVER B Goupille		3				
40-50	1415-120-0140-0	• SCREW, LEVER ADJ Vis		3				
40-51	1415-120-0150-0	• NUT Ecrou		3				
40-52	1415-120-0260-0	• WASHER, LOCK Rondelle frein		3				

[illegible]

Fig.41 CLUTCH HOUSING(F-DU TYPE)

Embrayage



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
41- 1	1425-132-0013-0	HOUSING, CLUTCH Carter d'embrayage						1	
41- 2	V401-160-0140-0	WASHER, SP/M8 Rondelle frein						2	
41- 3	V303-460-0140-0	NUT/M14 7T Eccrou						2	
41- 4	V251-441-2032-0	STUD/M12 X 32 9T Goujon						3	
41- 5	V201-461-2035-0	BOLT/M12 X 35 9T Vis						5	
41- 6	V401-160-0120-0	WASHER, SP/M12 Rondelle frein						10	
41- 7	V300-460-0120-0	NUT/M12 7T Eccrou						3	
41- 8	V303-460-0120-0	NUT/M12 7T Eccrou						4	
41- 9	1404-120-0090-0	WASHER, LOCK/M12 Rondelle frein						3	
41-10	1427-317-0040-0	CAP, BLANK/M14 Fausset						14	
41-11	V781-100-0008-0	PLUG Bouchon						1	
41-12	V763-400-0000-0	NIPPLE, GREASE Graisseur						2	
41-13	V520-101-0022-0	PIN, A/10 X 22 Goupille						1	
41-14	1416-120-0020-0	COVER, INSPECTION Couvercle						1	
41-15	1416-120-0030-0	PACKING Joint						1	
41-16	V201-260-8016-0	BOLT/M8 X 16 Vis						4	
41-17	V401-160-0080-0	WASHER, SP/M8 Rondelle frein						4	
41-18	1415-120-0030-0	GUIDE, SLEEVE Manchon						1	
41-19	1401-211-0100-0	BOLT/M8 X 25 Vis						3	
41-20	V401-160-0080-0	WASHER, SP/MB Rondelle frein						3	
41-21		WIRE/0.9 X 200 Fil						1	
41-22	V600-150-6207-0	BEARING, RB/62072NS Roulement radial						1	
41-23	1415-120-0050-0	SLEEVE Manchon						1	
41-24	1415-120-0040-0	BEARING, RELEASE/CT55 8L1 Roulement						1	
41-25	1415-120-0060-0	SPRING, TENSION/86 Ressort						2	
41-26	1417-120-0021-0	SHAFT, INPUT A Arbre d'entrée A.						1	
41-27	V705-140-0170-0	RING, SNAP/C 17 Collet d'axe						1	
41-28	1415-120-0080-0	COUPLING, SPLINE/20 X 75 Couplage						1	
41-29	1417-120-1002-0	SHAFT, INPUT B Arbre d'entrée B.						1	
41- 0-1	1426-120-2001-0	CLUTCH, DUAL ASSY/225 Embrayage ensemble						1	
41- 0-1a	1426-120-2002-0	CLUTCH, DUAL ASSY/225 Embrayage ensemble						1	Ⓢ
41-30	1415-120-0090-0	* COVER, CLUTCH A Couvercle						1	
41-31	1426-120-2100-0	* DISC, F/225 Disque d'embrayage						1	
41-32	1415-120-0110-0	* PLATE, PRESS A Plaque A.						1	
41-33	1415-120-0160-0	* BOLT Vis						3	
41-34	1415-120-0170-0	* NUT Eccrou						3	
41-35	1415-120-0130-0	* SPRING, DIAPHRAGM Ressort						2	
41-36	1426-120-2201-0	* DISC, P/225 Disque d'embrayage						1	


Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	LFDD	
41-36a	1426-120-2202-0	• DISC, P/225 Disque d'embrayage				1		ⓑ
41-37	1415-120-0120-0	• PLATE, PRESS B Plaque B.				1		
41-38	1415-120-0100-0	• COVER, CLUTCH B Couvercle				1		
41-39	1415-120-0230-0	• PIPE, KNOCK Goupille				4		
41-40	1415-120-0220-0	• BOLT Vis				6		
41-41	1415-120-0240-0	• WASHER, SP/MB Rondelle frein				6		
41-42	1415-120-0250-0	• WASHER/M8 Rondelle				2		
41-43	1415-120-3000-0	• ROD, RELEASE Bero				3		
41-44	1415-120-2000-0	• LEVER, RELEASE Lever				3		
41-45	1415-120-0020-0	• PIN, RELEASE ROD Goupille				3		
41-46	1415-120-0180-0	• PIN, LEVER A Goupille				3		
41-47	1415-120-0210-0	• WASHER Rondelle				3		
41-48	V500-151-2015-0	• PIN, SPLIT/1.2 X 15 Goupille fendue				3		
41-49	1415-120-0190-0	• PIN, LEVER B Goupille				3		
41-50	1415-120-0140-0	• SCREW, LEVER ADJ Vis				3		
41-51	1415-120-0150-0	• NUT Eccrou				3		
41-52	1415-120-0260-0	• WASHER, LOCK Rondelle frein				3		
41-53	1425-139-0040-0	METAL, SHIFT Carter				1		
41-54	1425-139-0050-0	PACKING Joint				1		
41-55	V520-101-0022-0	PIN, A/10 X 22 Goupille				2		
41-56	V201-461-0105-0	BOLT/M10 X 105 9T Vis				4		
41-57	V201-461-0095-0	BOLT/M10 X 95 9T Vis				2		
41-58	V401-160-0100-0	WASHER, SP/M10 Rondelle frein				6		
41-59	V740-142-6512-0	SEAL, OIL/SC426512 Bague d'étanchéité				1		
41-60	V705-140-0170-0	RING, SNAP/C 17 Collet d'axe				1		
41-61	1425-132-0021-0	GEAR, DRIVE/17T Pignon d'entraîche				1		
41-62	V600-110-6206-0	BEARING, RB/6206 Roulement radial				1		
41-63	1326-706-0020-0	PLUG, DRAIN Bouchon				2		
41-64	V781-100-0006-0	PLUG/PT 3/8 Bouchon				1		

V



Fig.41A CLUTCH HOUSING(LF-DU TYPE)

Embrayage




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
41A-1	1425-134-0010-0	HOUSING, CLUTCH Carter d'embrayage						1	
41A-2	V251-441-2032-0	STUD/M12 x 32 9T Goujon						3	
41A-3	V201-461-2035-0	BOLT/M12 x 35 9T Vis						5	
41A-4	V401-160-0120-0	WASHER, SP/M12 Rondelle frein						10	
41A-5	V300-460-0120-0	NUT/M12 Erou						3	
41A-6	V303-460-0120-0	NUT/M12 Erou						4	
41A-7	1404-120-0090-0	WASHER, LOCK/M12 Rondelle frein						3	
41A-8	V303-460-0140-0	NUT/M14 Erou						2	
41A-9	V401-160-0140-0	WASHER, SP/M14 Rondelle frein						2	
41A-10	1427-317-0040-0	CAP, BLANK/M14 Fausset						14	
41A-11	V781-100-0008-0	PLUG Bouchon						1	
41A-12	V763-400-0000-0	NIPPLE, GREASE Graisseur						2	
41A-13	V520-101-0022-0	PIN/10 x 22 Goupille						1	
41A-14	1416-120-0020-0	COVER, INSPECTION Couvercle						1	
41A-15	1416-120-0030-0	PACKING Joint						1	
41A-16	V201-260-8016-0	BOLT/M8 x 16 Vis						4	
41A-17	V401-160-0080-0	WASHER, SP/M8 Rondelle frein						4	
41A-18	1427-252-0020-0	CAP, BLANK Fausset						1	
41A-19	1326-706-0020-0	PLUG, DRAIN Bouchon						2	
41A-20	1425-135-0010-0	METAL, SLEEVE Palier						1	
41A-21	1425-134-0030-0	PACKING, SLEEVE METAL Joint						1	
41A-22	V520-200-6016-0	PIN/6 x 16 Goupille						1	
41A-23	1401-211-0100-0	BOLT/M8 x 25 Vis						4	
41A-24	1415-125-0240-0	BOLT/M8 x 45 Vis						4	
41A-25	V401-160-0080-0	WASHER, SP/M8 Rondelle frein						8	
41A-26		WIRE/0.9 x 700 Fil						1	
41A-27	V740-235-5007-0	SEAL, OIL/SG35507 Bague d'étanchéité						1	
41A-28	1415-120-0050-0	SLEEVE Manchon						1	
41A-29	1415-120-0040-0	BEARING, RELEASE Roulement						1	
41A-30	1415-125-0250-0	SPRING, TENSION/41 Ressort						2	
41A-31	1415-125-0320-0	COUPLING/20 x 95 Couplage						1	
41A-0-1	1426-120-2001-0	CLUTCH, DUAL ASSY/225 Embrayage ensemble						1	
41A-0-1a	1426-120-2002-0	CLUTCH, DUAL ASSY/225 Embrayage ensemble						1	②
41A-32	1415-120-0090-0	• COVER, CLUTCH A Couvercle						1	
41A-33	1426-120-2100-0	• DISC, F/225 Disque d'embrayage						1	
41A-34	1415-120-0110-0	• PLATE, PRESS A Plaque A						1	
41A-35	1415-120-0160-0	• BOLT Vis						3	
41A-36	1415-120-0170-0	• NUT Erou						3	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F.U	F.DU	LE	EDU	
41A-37	1415-120-0130-0	• SPRING, DIAPHRAGM Ressort						2	
41A-38	1426-120-2201-0	• DISC, P/225 Disque d'embrayage						1	
41A-38a	1426-120-2202-0	• DISC, P/225 Disque d'embrayage						1	③
41A-39	1415-120-0120-0	• PLATE, PRESS B Plaque B						1	
41A-40	1415-120-0100-0	• COVER, CLUTCH B Couvercle						1	
41A-41	1415-120-0230-0	• PIPE, KNOCK Goupille						4	
41A-42	1415-120-0220-0	• BOLT Vis						6	
41A-43	1415-120-0240-0	• WASHER, SP/M8 Rondelle frein						6	
41A-44	1415-120-0250-0	• WASHER/M8 Rondelle						2	
41A-45	1415-120-3000-0	• ROD, RELEASE Barre						3	
41A-46	1415-120-2000-0	• LEVER, RELEASE Lever						3	
41A-47	1415-120-0200-0	• PIN, RELEASE ROD Goupille						3	
41A-48	1415-120-0180-0	• PIN, LEVER A Goupille						3	
41A-49	1415-120-0210-0	• WASHER Rondelle						3	
41A-50	V500-151-2015-0	• PIN, SPLT/1.2 x 15 Goupille fendue						3	
41A-51	1415-120-0190-0	• PIN, LEVER B Goupille						3	
41A-52	1415-120-0140-0	• SCREW, LEVER ADJ Vis						3	
41A-53	1415-120-0150-0	• NUT Eccrou						3	
41A-54	1415-120-0260-0	• WASHER Rondelle						3	
41A-55	1425-134-0070-0	COVER, BOTTOM Couvercle						1	
41A-56	1425-134-0080-0	PACKING, COVER Joint						1	
41A-57	V201-260-8020-0	BOLT/M8 x 20 Vis						4	
41A-58	V401-160-0080-0	WASHER, SP/M8 Rondelle frein						4	
41A-59	1425-139-0040-0	METAL, SHIFT Carter						1	
41A-60	1425-139-0050-0	PACKING Joint						1	
41A-61	V520-101-0022-0	PIN, A/10 x 22 Goupille						2	
41A-62	V201-461-0105-0	BOLT/M10 x 105.9 T Vis						4	
41A-63	V201-461-0095-0	BOLT/M10 x 95.9 T Vis						2	
41A-64	V401-160-0100-0	WASHER, SP/M10 Rondelle frein						6	
41A-65	V740-142-6512-0	SEAL, OIL/SC426512 Bague d'étanchéité						1	
41A-66	V705-140-0170-0	RING, SNAP/C17 Collet d'axe						1	
41A-67	1425-132-0021-0	GEAR, DRIVE/17T Pignon d'attaque						1	
41A-68	V600-110-6206-0	BEARING, RB/6206 Roulement radial						1	
41A-69	V781-100-0006-0	PLUG/PT 3/8 Bouchon						1	



Fig.41B CLUTCH HOUSING(LF-DU TYPE)

Embrayage




Ref.No. Réf.Nº	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	F-DU	
41B- 1	1415-125-0051-0	GEAR, INPUT/13T Pignon d'entrée					1	
41B- 2	1415-125-0061-0	GEAR, INPUT/24T Pignon d'entrée					1	
41B- 3	1415-125-0260-0	PIPE, INPUT Doutille de pignon					1	
41B- 4	1425-134-0060-0	METAL, BEARING Arrière de roulement					1	
41B- 5	V520-100-6016-0	PIN/6 x 16 Goupille					1	
41B- 6	V740-230-5007-0	SEAL, OIL/SC30507 Bague d'étanchéité					1	
41B- 7	V740-235-5007-0	SEAL, OIL/SC35507 Bague d'étanchéité					1	
41B- 8	V600-110-6007-0	BEARING, RB/6007 Roulement radial					2	
41B- 9	V705-140-0620-0	RING, SNAP/62 Collet d'axe					1	
41B-10	V251-440-6012-0	STUD/M8 x 12 9T Goujon					2	
41B-11	V200-460-6050-0	BOLT/M6 x 50 9T Vis					4	
41B-12	V401-160-0060-0	WASHER, SP/M6 Rondelle frein					4	
41B-13	V300-460-0060-0	NUT/M6 7T Eccou					2	
41B-14	1415-125-0350-0	WASHER, LOCK/M6 Rondelle frein					2	
41B-15	V600-110-6206-0	BEARING, RB/6206 Roulement radial					1	
41B-16	V704-140-0300-0	RING, SNAP/30 Collet d'axe					1	
41B-17	V653-420-2620-0	BEARING, NR/TLA2020 Roulement à aiguilles					1	
41B-18	1415-125-0310-0	SHAFT, OUTPUT Arbre récepteur					1	
41B-19	1426-125-0030-0	GEAR, SHIFT/35T Baladeur étage					1	
41B-20	V600-110-6205-0	BEARING, RB/6205 Roulement radial					1	
41B-21	V704-140-0250-0	RING, SNAP/25 Collet d'axe					1	
41B-22	1417-125-0020-0	GEAR, OUTPUT/24T Pignon					1	
41B-23	V740-225-4409-0	SEAL, OIL/SC25449 Bague d'étanchéité					1	
41B-24	V704-140-0520-0	RING, SNAP/52 Collet d'axe					1	
41B-25	V600-110-6012-0	BEARING, RB/6012 Roulement radial					1	
41B-26	V705-140-0950-0	RING, SNAP/95 Collet d'axe					2	
41B-27	V704-140-0600-0	RING, SNAP/60 Collet d'axe					1	
41B-28	1415-125-0130-0	SEAL, OIL/SC609512 Bague d'étanchéité					1	
41B-29	1415-125-0271-0	SHAFT, COUNTER Arbre de renvoi					1	
41B-30	1426-125-0021-0	GEAR, COUNTER/39-17T Pignon étage					1	
41B-31	1415-125-0360-0	BEARING, NR/KT283313 Roulement à aiguilles					1	
41B-32	1415-125-0080-0	GEAR, COUNTER/39-17T Pignon étage					1	
41B-33	V600-110-63040	BEARING, RB/6304 Roulement radial					2	
41B-34	1426-125-0050-0	STAY, CREEP SHIFTER Appui					1	
41B-35	V720-102-4011-0	O-RING/P11 Joint torique					2	
41B-36	1426-125-0040-0	SHIFTER, CREEP Fourchette					1	
41B-37	1415-216-0060-0	BOLT/M8 x 16 Vis					1	
41B-38		WIRE/0.9 x 100 Fil					1	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L.FDU	
41B-39	V680-200-0013-0	BALL, STEEL Bille					1	
41B-40	1415-210-0020-0	SPRING, SHIFTER Resort					1	
41B-41	1415-125-0160-0	WASHER/13 x 25 x 2 Rondelle					1	
41B-42	1424-125-0030-0	BOLT/M12 x 12 Vis					1	
41B-43	1415-125-0171-0	BOSS, SHIFT Bossage					1	
41B-44	1415-216-0060-0	BOLT/M8 x 18 Vis					1	
41B-45		WIRE/0.9 x 100 Fil					1	
41B-46	1415-125-2001-0	ARM, SHIFT Lever de selecteur					1	
41B-47	V720-102-4012-0	O-RING/P12 Joint torique					1	
41B-48	1426-125-2000-0	LEVER, SHIFT Lever de changement					1	
X 41B-49	~~4106-105-5030-0~~ ~~2101-235-0210-0~~	GRIP KNOB Pommasse					1	(A) LF du info n° 82 - 07 (4/4)
41B-50	V580-140-6028-0	PIN, SPRING/6 x 28 Goupille elastique					1	
41B-51	1426-125-0060-0	COVER, HOUSING Couvercle					1	
41B-52	1415-125-0190-0	PACKING, COVER Joint					1	
41B-53	V201-260-8020-0	BOLT/M8 x 20 Vis					6	
41B-54	V401-160-0800-0	WASHER, SP/M8 Rondelle train					6	
41B-55	7954-205-1000-0	CAP, OIL/30 Bouchon					1	
41B-56	V744-240-5508-0	SEAL, OIL/TC40558 Bague d'étanchéité					1	
41B-57	1415-125-0290-0	GEAR, COUNTER/28T Pignon etage					1	
41B-58	V600-110-6008-0	BEARING, RB/6008 Roulement radial					1	
41B-59		WIRE/0.9 x 150 Fil					1	
41B-60	1425-134-0090-0	STOPPER, OIL Pastille					1	
41B-61	V200-260-6012-0	BOLT/M6 x 12 Vis					2	
41B-62	V401-160-0060-0	WASHER, SP/M6 Rondelle train					2	

[illegible]

Fig.42 CHANGE GEAR SYSTEM(F-U, F-DU LF-DU TYPE)


Levier de vitesses avant



Ref.No. Réf.Nº	Parts No. Pièces Nº	Description Désignation	Model & Q'ty Modél & Quant							Remarks Remarques
			S	D	F	U	F	D	U	
42- 1	V600-110-6205-0	BEARING, RB/6205 Roulement radial			2		2		2	
42- 2	1425-132-0080-0	GEAR, SHIFT/24T Pignon			1		1		1	
42- 3	1425-132-0070-0	SHAFT, SHIFT Arbre			1		1		1	
42- 4	V705-140-0520-0	RING, SNAP/C52 Collet d'axe			1		1		1	
42- 5	V740-225-5208-0	SEAL, OIL/SC25528 Bague d'étanchéité			1		1		1	
42- 6	1425-132-0091-0	SHIFTER Fourchette			1		1		1	
42- 7	V680-200-0010-0	BALL, STEEL/5/16" Bille			1		1		1	
42- 8	1302-225-0030-0	SPRING, SHIFTER Ressort de fourchette			1		1		1	
42- 9	V500-153-0025-0	PIN, SPLIT/3 X 25 Goupille			1		1		1	
42-10	1425-132-0110-0	STAY, SHIFTER Appui			1		1		1	
42-11	V720-101-9010-0	O-RING/P10 Joint torique			1		1		1	
42-12	1416-216-0040-0	STOPPER, SHIFTER STAY Arrêt			1		1		1	
42-13	V401-160-0080-0	WASHER, SP/M8 Rondelle frein			1		1		1	
42-14	V201-260-8012-0	BOLT/M8 X 12 Vis			1		1		1	
42-15	1425-132-2000-0	ARM, SHIFT Bras			1		1		1	
42-16	V740-116-2607-0	SEAL, OIL/SC16167 Bague d'étanchéité			1		1		1	
42-17	1425-132-2100-0	BOSS, SHIFT Moyeau			1		1		1	
42-18	V580-140-6032-0	PIN, SPRING/W6 X 32 Goupille élastique			1		1		1	
42-19	V590-130-9150-0	WIRE/0.9 X 150 Fil			1		1		1	
42-20	1425-132-0130-0	ROD/235 Goupille			1		1		1	
42-21	V500-152-0018-0	PIN, SPLIT/2 X 18 Goupille fendue			2		2		2	
42-22	1425-132-2200-0	LEVER, SHIFT Lévier			1		1		1	
42-23	1425-132-0120-0	PIN, COUNTER SHIFT Goupille			1		1		1	
42-24	V401-160-0140-0	WASHER, SP/M14 Rondelle frein			1		1		1	
42-25	V704-140-0160-0	RING, SNAP/C 18 Collet d'axe			1		1		1	
X42-26	~~4106-105-3030-0~~ ~~2101-230-0040-0~~	GRIP, KNOB Pommes			1		1		1	(A) F-U, F-DU, L-F DU info n° 82-01/64 March 31, '82. English ★ French
42-27	1427-943-0041-0	MARK, F-SHIFT Étiquette			1		1		1	
42-27-1	1431-935-0070-0	MARK, F-SHIFT Étiquette			1		1		1	
42-28	V607-110-6204-0	BEARING, RB/6204 NR Roulement radial			2		2		2	
42-29	1425-139-0020-0	PIN, COUNTER Goupille			1		1		1	
42-30	1425-139-0010-0	GEAR, COUNTER/27T Pignon			1		1		1	
42-31	1425-139-0030-0	COLLAR Collier			1		1		1	
42-32	V704-140-0200-0	RING, SNAP/C 20 Collet d'axe			1		1		1	

Fig.43 DRIVE SHAFT SYSTEM(F-U, F-DU LF-DU TYPE)


Demi arbre avant



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
43- 1	1425-132-0160-0	COVER, METAL Couvercle			1	1	1		
43- 2	1425-132-0170-0	PACKING, COVER Joint			1	1	1		
43- 3	V201-260-8020-0	BOLT/M8 X 20 Vis			4	4	4		
43- 4	V401-160-0080-0	WASHER, SP/M8 Rondelle tre'n			4	4	4		
43- 5	V721-103-1040-0	O-RING/G40 Joint torique			1	1	1		
43- 6	1425-132-0150-0	COUPLING Couplage			2	2	2		
43- 7	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe			1	1	1		Used #002281~
43- 8	1425-132-2300-0	COVER, SHAFT Couvercle			1	1	1		
43- 9	1425-132-0140-0	SHAFT, DRIVE Demi arbre avant			1	1	1		
43- 9a	1425-132-0141-0	SHAFT, DRIVE Demi arbre avant			1	1	1		② #002281~
43-10	V580-140-4026-0	PIN, SPRING/W 4 X 28 Goupille elastique			1	1	1		
43-11		WIRE/O.9 X 150 Fil			1	1	1		①

Fig.44 CLUTCH PEDAL

Pedale d'embrayage




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F-U	F-U	F-U	F-U	
44- 1	1424-122-1000-0	PEDAL, CLUTCH Pedale d'embrayage	1		1				
44- 1-1	1426-128-2000-0	PEDAL, CLUTCH Pedale d'embrayage		1		1	1		
44- 2	V763-400-0000-0	NIPPLE, GREASE Ecroû à graissage	1	1	1	1	1		
44- 3	1424-122-2000-0	ROD, CLUTCH Tige d'embrayage	1	1	1	1	1		
44- 4	1415-312-5000-0	YOKE, LH THREAD Chape	1	1	1	1	1		
44- 5	1401-122-0050-0	NUT, LH THREAD/M8 Ecroû	1	1	1	1	1		
44- 6	1415-312-6000-0	YOKE, RH THREAD Chape	1	1	1	1	1		
44- 7	V302-260-0080-0	NUT/M8 Ecroû	1	1	1	1	1		
44- 8	1404-312-0060-0	PIN, YOKE A Goupille	2	2	2	2	2		
44- 9	V413-160-0080-0	WASHER/M8 Rondelle	2	2	2	2	2		
44-10	V500-152-0015-0	PIN, SPLIT/2 X 15 Goupille fendue	2	2	2	2	2		
44-11	1403-312-0030-0	SPRING, PARKING BRAKE Ressort	1	1	1	1	1		
44- 0-1	1417-012-2000-0	CLUTCH SHAFT & ARM SET Axe & bras	1	1	1	1			
44- 0-2	1426-012-3000-0	CLUTCH SHAFT & ARM SET Axe & bras					1		
44-12		• SHAFT, CLUTCH Axe	1	1	1	1			△
44-12-1		• SHAFT, CLUTCH Axe					1		△
44-13		• ARM, CLUTCH A Bras	1	1	1	1			△
44-13-1		• ARM, CLUTCH A Bras					1		△
44-14	W201-260-8040-0	BOLT/M8 X 40 S-40 Vis	1	1	1	1	1		
44-15	V302-260-0080-0	NUT/M8 Ecroû	1	1	1	1	1		
44-16	1415-122-0010-0	O-RING Joint torique	1	1	1	1	1		
44-17	V767-400-0000-0	NIPPLE, GREASE Graisseur	1	1	1	1	1		
44-18	1404-101-0010-0	PIN, TAPER Goupille	1	1	1	1			
44-18-1	V580-140-8028-0	PIN, SPRING/W B x 28 Goupille elastique					1		
44-19		WIRE/1.2 X 200 Fil	1	1	1	1	1		
44-20	1415-122-0020-0	CAP, SEAL Fausset	2	2	2	2	2		
44- 0-3	1417-012-2100-0	SHAFT, THROUGHOUT SET Axe ensemble	1	1	1	1			
44- 0-4	1426-012-3100-0	SHAFT, THROUGHOUT SET Axe ensemble					1		
44-21		• SHAFT, THROUGHOUT Axe	1	1	1	1	1		△
44-22		• ARM, CLUTCH B Bras	1	1	1	1			△
44-22-1		• ARM, CLUTCH B Bras					1		△
44-23		• YOKE Chape	1	1	1	1	1		△
44-24	1404-101-0010-0	PIN, TAPER Goupille	1	1	1	1	1		
44-25		WIRE/1.2 X 200 Fil	1	1	1	1	1		
44-26	1415-122-6000-0	ROD, CLUTCH B Tige de debayage	1	1	1	1			
44-26a	1424-122-2100-0	STAY, CLUTCH Appui	1	1	1	1			Ⓡ
44-26-1	1426-128-2400-0	STAY, CLUTCH Appui					1		
44-27	1404-312-0060-0	PIN, YOKE A Goupille	2	2	2	2	2		

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.FDU	
44-27-1	3737-235-0080-0	PIN					2	
44-28	V413-160-0080-0	WASHER/M8 Rondelle	2	2	2	2	2	
44-29	V500-152-0015-0	PIN, SPLIT/2 X 15 Goupille fendue	2	2	2	2	2	
44-30	1415-122-0010-0	O RING Joint torique	1	1	1	1	1	
44-31	1404-101-0010-0	PIN, TAPER Goupille	1	1	1	1	1	
44-32	(V590-131-2200-0)	WIRE/1.2 X 200 Fil	1	1	1	1	1	
44-33	V767-400-0000-0	NIPPLE, GREASE Graisseur	1	1	1	1	1	
44-34	1424-122-0011-0	ARM, CUT OFF Craçhes	1	1	1	1	1	
44-35	V201-260-8020-0	BOLT/M8 X 20 Vis	1	1	1	1	1	
44-36	V300-260-0080-0	NUT/M8 Ecran	1	1	1	1	1	
44-37	1414-312-0020-0	SPRING, TENSION/53 Ressort	1	1	1	1	1	

[illegible]

Fig.45 FUEL TANK


Reservoir



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
45- 1	1424-111-3000-0	TANK, FUEL Réservoir de combustible	1	1	1	1	1	1	FILTER-TANK
45- 2	1407-111-0010-0	WASHER/8 X 12 X 2 Rondelle	1	1	1	1	1	1	
45- 3	V200-260-8012-0	BOLT/M8 X 12 Vis	1	1	1	1	1	1	
45- 4	1425-102-0010-0	PIPE, FUEL Conduit	2	2	2	2	2	2	
45- 4a	1425-102-0010-0	PIPE, FUEL Conduit	1	1	1	1	1	1	
45- 5	1421-111-2100-0	CAP, ASSY Bouchon	1	1	1	1	1	1	(B) 2 wds # 002731 - info n° 82-03 (4/4) 4 wds # 006030 - March 31, '82.
X 45- 0-1	~~1417-102-0510-0~~ 1417-102-0510-0	FILTER, FUEL ASSY Filtre à combustible	1	1	1	1	1	1	
45- 6		• JOINT/L-TYPE Joint	1	1	1	1	1	1	
45- 7		• JOINT, FUEL Joint	1	1	1	1	1	1	
45- 8	1417-102-0090-0	• ELEMENT Element	1	1	1	1	1	1	
45- 9		• BODY Corps du filtre	1	1	1	1	1	1	
45-10		• LEVER Lever	1	1	1	1	1	1	
45-11		• VALVE Soupape	1	1	1	1	1	1	
45-12		• SPRING, VALVE Ressort	1	1	1	1	1	1	
45-13	V720-102-4010-0	• O-RING Joint torique	1	1	1	1	1	1	
45-14		• VIS Vis	1	1	1	1	1	1	
X 45-15	~~1415-102-0090-0~~ 1415-102-0090-0	• CUP Cuvette	1	1	1	1	1	1	
45-16	1415-102-0100-0	• NUT, RING Ecrou de cuve	1	1	1	1	1	1	
45-17	V720-103-5044-0	• O-RING Joint torique	1	1	1	1	1	1	
45-18	1415-102-0120-0	• PLUG, BREATHING Bouchon	2	2	2	2	2	2	(B) 2 wds # 002731 - info n° 82-03 (4/4) 4 wds # 006030 - March 31, '82.
45-19	1415-102-0130-0	• PACKING Joint	2	2	2	2	2	2	
45-20	V201-260-8020-0	BOLT/M8 X 20 Vis	2	2	2	2	2	2	
45-21	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	2	
45-22	1417-102-0030-0	PIPE, FUEL A Conduit	1	1	1	1	1	1	
45-22a	1424-102-0030-0	PIPE, FUEL B Conduit	1	1	1	1	1	1	
45-23	1417-102-0050-0	BAND, HOSE Sangle	6	6	6	6	6	6	
45-24	1404-621-0270-0	CLAMP, HARNESS B Attache faisceau	1	1	1	1	1	1	
45-25	1415-111-2000-0	BAND, TANK A Sangle	1	1	1	1	1	1	
45-26	1417-111-2000-0	BAND, TANK Sangle	1	1	1	1	1	1	
45-27	1415-111-0010-0	STOPPER, BAND Attache	1	1	1	1	1	1	
45-28	1415-111-0020-0	COLLAR/9 X 14 X 30 Collier	1	1	1	1	1	1	
45-29	V300-260-0080-0	NUT/M8 Ecrou	1	1	1	1	1	1	(B) TANK-FILTER
45-30	V302-260-0080-0	NUT/M8 Ecrou	1	1	1	1	1	1	
45-31	1416-600-0550-0	SWITCH, FUEL ASSY Interrupteur	1	1	1	1	1	1	
45-32	1416-621-0370-0	• PACKING/RUBBER Joint	1	1	1	1	1	1	
45-33	V200-260-5010-0	BOLT/M5 X 10 P=0.8 Vis	5	5	5	5	5	5	
45-34	1416-621-0270-0	WASHER SEAL/M5 Rondelle	5	5	5	5	5	5	
45-35	1424-102-0020-0	PIPE, FUEL A Conduit	1	1	1	1	1	1	

Fig.46 THROTTLE SYSTEM

Accélérateur



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	E	D	
46- 1	1424-116-1000-0	PEDAL, ACCEL Pedale	1	1	1	1	1	1	interchangeable
46- 2	1416-120-0060-0	SPRING, TENTION/65 Ressort	1	1	1	1	1	1	
46- 3	V500-152-5018-0	PIN, SPLIT/2.5 X 18 Goupille fendue	1	1	1	1	1	1	
46- 4	1415-116-0071-0	CONNECTOR, ACCEL A Jonction A.	1	1	1	1	1	1	
46- 5	1421-116-0010-0	CONNECTOR, ACCEL Jonction A.	1	1	1	1	1	1	
46- 6	1421-116-0020-0	TURNBUCKLE/M6 Tendeur	1	1	1	1	1	1	
46- 7	V300-260-0060-0	NUT/M6 Ecrou	1	1	1	1	1	1	
46- 8	V500-152-0018-0	PIN, SPLIT/2 X 18 Goupille fendue	2	2	2	2	2	2	
46- 9	1421-116-0030-0	ARM, ACCEL Bras	1	1	1	1	1	1	
46- 9-1	1421-116-2000-0	ARM, ACCEL Bras	1	1	1	1	1	1	
46-10	1416-116-0040-0	PIN, ARM Goupille	1	1	1	1	1	1	
46-11	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	1	1	1	1	1	1	
46-12	V413-160-0100-0	WASHER/M10 Rondelle	1	1	1	1	1	1	
46-13	V500-152-0018-0	PIN, SPLIT/2 X 18 Goupille fendue	1	1	1	1	1	1	
46-14	1425-116-0010-0	ROD, ACCEL Tige	1	1	1	1	1	1	
46-15	V500-152-0018-0	PIN, SPLIT/2 X 18 Goupille fendue	2	2	2	2	2	2	
46-16	1424-117-1000-0	LEVER, THROTTLE Manette de gaz	1	1	1	1	1	1	
46-17	1414-117-0040-0	KNOB, LEVER/30 Poignée	1	1	1	1	1	1	
46-18	1414-117-0050-0	LINING/13 X 50 X 3 Garniture de friction	1	1	1	1	1	1	
46-19	1407-117-0070-0	WASHER/13 X 32 X 1 Rondelle	1	1	1	1	1	1	
46-20	1404-117-0080-0	SPRING, PRESS/22 Ressort	1	1	1	1	1	1	
46-21	V413-160-0120-0	WASHER/M12 Rondelle	1	1	1	1	1	1	
46-22	V320-160-0120-0	NUT, SLOTTED/M12 Ecrou à crénelures	1	1	1	1	1	1	
46-23	V500-153-0025-0	PIN, SPLIT/3 X 25 Goupille fendue	1	1	1	1	1	1	
46-24	1423-117-0010-0	HOLDER, THROTTLE Support	1	1	1	1	1	1	
46-25	V201-260-8016-0	BOLT/M8 X 16 Vis	2	2	2	2	2	2	
46-26	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	2	
46-27	V300-260-0080-0	NUT/M8 Ecrou	2	2	2	2	2	2	
46-28	1421-904-0190-0	TAG, BATTERY Etiquette	1	1	1	1	1	1	English
46-28-1	1427-934-0190-0	TAG, BATTERY Etiquette	1	1	1	1	1	1	★ French
46-29	1427-932-0040-0	TAG, CAUTION Etiquette	1	1	1	1	1	1	




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	LFDU	
47- 1	1431-254-0010-0	CASE, T-MISSION Boîte de vitesses	1	1	1	1	1	③ { D #101238 ~ F #003991 ~
47- 1a	1431-254-0011-0	CASE, T-MISSION Boîte de vitesses	1	1	1	1	1	
47- 2	V251-441-4028-0	STUD/M14 X 28 9T Goujon	6	6	6	6	6	
47- 3	V251-441-0028-0	STUD/M10 X 28 9T Goujon	5	5	5	5	5	
47- 4	V251-441-2032-0	STUD/M12 X 32 9T Goujon	3	3	3	3	3	
47- 5	V251-260-8025-0	STUD/M8 X 25 Goujon	4	4	4	4	4	
47- 6	V251-441-2040-0	STUD/M12 X 40 9T Goujon	7	7	7	7	7	
47- 7	V251-441-0035-0	STUD/M10 X 35 9T Goujon	10	10	10	10	10	
47- 8	V251-440-8025-0	STUD/M8 X 25 9T Goujon	4	4	4	4	4	
47- 9	V520-101-0028-0	PIN, A/10 X 25 Goupille	2	2	2	2	2	
47-10	V781-100-0006-0	PLUG Bouchon	2	2	2	2	2	
47-11	1427-317-0040-0	CAP, BLANK/M14 Fausset	8	8	8	8	8	
47-12	1424-202-0010-0	METAL, INPUT GEAR Pallier	1		1			
47-13	1424-201-0020-0	METAL, INPUT GEAR Pallier		1		1	1	
47-14	1415-201-0030-0	PACKING, INPUT GEAR Joint	1	1	1	1	1	
47-15	V201-260-8020-0	BOLT/M8 X 20 Vis	4		4			
47-15-1	V201-260-8025-0	BOLT/M8 X 25 Vis		4		4	4	
47-16	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
47-17	1417-201-0020-0	METAL, DRIVE PINION Pallier	1	1	1	1	1	
47-18	1415-201-0050-0	SHIM, A/0.198 Cale A.	AR	AR	AR	AR	AR	
47-19	1415-201-0060-0	SHIM, B/0.1 Cale B.	AR	AR	AR	AR	AR	
47-20	1415-201-0070-0	SHIM, C/0.05 Cale C.	AR	AR	AR	AR	AR	
47-21	1403-201-0060-0	O-RING Joint torique	1	1	1	1	1	
47-22	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
47-23	V303-460-0080-0	NUT/M8 7T Ecrou	4	4	4	4	4	
47-24	1415-201-0080-0	COVER, PINION METAL Couvercle	1	1				
47-24-1	1425-231-0010-0	COVER, PINION METAL Couvercle			1	1	1	
47-25	1415-201-0090-0	PACKING, METAL COVER Joint	1	1	1	1	1	
47-26	V200-460-6016-0	BOLT/M6 X 16 Vis	4	4	4	4	4	
47-27	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	4	4	4	4	4	
47-28	1424-201-0010-0	METAL, DRIVE SHAFT Pallier	1	1	1	1	1	
47-29	1417-201-0050-0	PACKING, METAL Joint	1	1	1	1	1	
47-30	V200-260-6020-0	BOLT/M6 X 20 Vis	4	4	4	4	4	
47-31	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	4	4	4	4	4	
47-32	1417-201-0080-2	METAL, PTO SHAFT Pallier	1	1	1	1	1	
47-33	1415-201-0190-0	PACKING Joint	1	1	1	1	1	
47-34	V303-260-0080-0	NUT/M8 Ecrou	4	4	4	4	4	
47-35	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	6	6	6	6	6	

Ref.No. Réf.Nº.	Parts No. Pièces N°.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F.U	F.DU	L.FDU		
47-36	1411-716-0040-0	SEAL/42 Bouchon	1	1	1	1	1		
47-37	1426-207-0011-0	METAL, BACK GEAR Palier	1	1	1	1	1		
47-38	1415-207-0061-0	PACKING, BACK METAL A Joint A.	1	1	1	1	1		
47-39	1415-207-0071-0	PACKING, BACK METAL B Joint B.	2	2	2	2	2		
47-40	V510-100-4016-0	PIN, TAPER/4 X 16 Goupille	1	1	1	1	1		
47-41	V201-260-8020-0	BOLT/M8 X20 Vis	4	4	4	4	4		
47-42	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4		
47-43	V520-101-0022-0	PIN, A/10 X 22 Goupille	2	2	2	2	2		
47-44	V201-260-8025-0	BOLT/M8 X 25 Vis	2	2	2	2	2		
47-45	V251-441-4035-0	STUD/M14 X35 9T Goujon	2	2	2	2	2		

[illegible]

Fig.48 TRANSMISSION GEAR(S, F-U TYPE)
Arbres et demultiplicateur




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.RDU	
48- 1	1415-204-0010-0	GEAR, INPUT/15T Pignon d'entrée	1		1			
48- 2	V708-140-0620-0	RING, SNAP/C62 Collet d'axe	1		1			
48- 3	1426-204-0050-0	BEARING, RB/6205 Roulement radial	1		1			
48- 4	1417-204-0010-0	GEAR, INPUT/16T Pignon d'entrée	1		1			
48- 5	V600-110-6305-0	BEARING, RB/6305 Roulement radial	1		1			
48- 6	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe	1		1			
48- 7	V740-125-4508-0	SEAL, OIL/SC2545B Bague d'étanchéité	1		1			
48- 8	1426-204-0080-0	BEARING, NR/BM2220 Roulement à aiguilles	1		1			
48- 9	1426-204-0040-0	SHAFT, SHIFT Arbre primaire	1		1			
48-10	1426-204-0011-0	GEAR, SHIFT/19-15T Baladeur étage	1		1			
48-11	1426-204-0031-0	GEAR, SHIFT/35T Baladeur étage	1		1			
48-12	1426-204-0022-0	GEAR, SHIFT/29-24T Baladeur étage	1		1			
48-13	V600-110-6305-0	BEARING, RB/6305 Roulement radial	1		1			
48-14	V705-140-0620-0	RING, SNAP/C 62 Collet d'axe	2		2			
48-15	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe	1		1			
48-16	1415-205-0170-0	BEARING, CR/NH2207 Roulement	1		1			
48-17	1415-205-0020-0	GEAR, COUNTER/36T Pignon étage	1		1			
48-18	1415-205-0030-0	COLLAR/36 X 45 X 37 Collier	1		1			
48-19	1426-205-0020-0	GEAR, COUNTER/33T Pignon étage	1		1			
48-20	1426-205-0031-0	GEAR, COUNTER/27T Pignon étage	1		1			
48-21	1415-205-0180-0	WASHER, ADAPTER/AW07 Rondelle	1		1			
48-22	V670-200-0070-0	NUT, ADAPTER/AN07 Eccrou	1		1			
48-23	1415-205-0060-0	COLLAR, COUNTER Collier	1		1			
48-24	1426-205-0060-0	GEAR, COUNTER/37-17T Pignon étage	1		1			
48-25	1426-205-0040-0	COLLAR/28 X 33 X 42 Collier	1		1			
48-26	1415-205-0080-0	BEARING, NR/KT283327 Roulement à aiguilles	2		2			
48-27	1417-205-0040-0	GEAR, PTO COUNTER/36T Pignon	1		1			
48-28	1415-205-0110-0	BEARING, NR/KT283313 Roulement à aiguilles	1		1			
48-29	1415-205-0120-0	COLLAR/28 X 33 X 5 Collier	1		1			
48-30	1415-205-0080-0	BEARING, NR/KT283327 Roulement à aiguilles	1		1			
48-31	1415-205-0130-0	COLLAR/25 X 42 X 4 Collier	1		1			
48-32	1417-205-0050-0	BEARING, TR/32305 Roulement	1		1			
48-33	1415-205-0150-0	SHIM, A/0.05 Cale A.	AR		AR			
48-34	1415-205-0160-0	SHIM, B/0.10 Cale B.	AR		AR			
48-35	V671-400-0050-0	WASHER, ADAPTER/AW05 Rondelle	1		1			
48-36	V670-200-0050-0	NUT, ADAPTER/AN05 Eccrou	1		1			
48-37	1417-211-0010-0	GEAR, PTO DRIVE/21T Pignon	1		1			
48-38	V607-110-6305-0	BEARING, RB/6305NR Roulement radial	1		1			

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.FDU	
48-39	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe	1		1			
48-40	1424-211-1000-0	SHAFT, PTO DRIVE Demi arbre av.	1		1			
48-41	1415-207-0043-0	PIN, BACK GEAR Arbre de marche ar.	1		1			
48-42	1426-207-0021-0	GEAR, BACK/20T Pignon	1		1			
48-43	1415-207-0090-0	BEARING, NR/NAG4901 Roulement à aiguilles	2		2			
48-44	V704-140-0120-0	RING, SNAP/C 12 Collet d'axe	1		1			
48-45	1412-204-0030-0	RING, SNAP/AR24 Collet d'axe	2		2			
48-46	1426-205-0051-0	GEAR, COUNTER/23T Pignon étage	1		1			

[illegible]

Fig.48A TRANSMISSION GEAR(S, F-U TYPE)

Arbres et demultiplicateur



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F	U	F	
48A-1	1415-204-0010-0	GEAR, INPUT/16T Pignon d'entrée	1		1			
48A-2	V708-140-0620-0	RING, SNAP/C62 Collet d'axe	1		1			
48A-3	1426-204-0050-0	BEARING, RB/6206 Roulement radial	1		1			
48A-4	1417-204-0010-0	GEAR, INPUT/16T Pignon d'entrée	1		1			
48A-5	V600-110-6305-0	BEARING, RB/6305 Roulement radial	1		1			
48A-6	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe	1		1			
48A-7	V740-125-4508-0	SEAL, OIL/SC26458 Bague d'étanchéité	1		1			
48A-8	1426-204-0080-0	BEARING, NR/BM2220 Roulement à aiguilles	1		1			
48A-9	1426-204-0040-0	SHAFT, SHIFT Arbre primaire	1		1			
48A-10	1426-204-0011-0	GEAR, SHIFT/19-15T Baladeur étage	1		1			
48A-11	1426-204-0031-0	GEAR, SHIFT/35T Baladeur étage	1		1			
48A-12	1426-204-0022-0	GEAR, SHIFT/29-24T Baladeur étage	1		1			
48A-13	V600-110-6305-0	BEARING, RB/6305 Roulement radial	1		1			
48A-14	V705-140-0620-0	RING, SNAP/C 62 Collet d'axe	2		2			
48A-15	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe	1		1			
48A-16	1424-205-0010-0	BEARING, CR/NH2207R Roulement	1		1			
48A-17	1426-261-0020-0	GEAR, COUNTER/33 36T Pignon étage	1		1			
48A-18	1426-205-0060-0	GEAR, COUNTER/37-17T Pignon étage	1		1			
48A-19	1415-205-0080-0	BEARING, NR/KT283327 Roulement à aiguilles	2		2			
48A-20	1426-261-0040-0	GEAR, PTO COUNTER/36T Pignon	1		1			
48A-21	1415-205-0110-0	BEARING, NR/KT283313 Roulement à aiguilles	1		1			
48A-22	1415-205-0120-0	COLLAR/28 X 33 X 5 Collier	1		1			
48A-23	1415-205-0080-0	BEARING, NR/KT283327 Roulement à aiguilles	1		1			
48A-24	1415-205-0130-0	COLLAR/25 X 42 X 4 Collier	1		1			
48A-25	1426-261-0050-0	BEARING, TR Roulement à rouleaux coniques	1		1			
48A-26	1415-205-0150-0	SHIM, A/0.05 Cale A.	AR		AR			
48A-27	1415-205-0160-0	SHIM, B/0.10 Cale B.	AR		AR			
48A-28	V671-400-0050-0	WASHER, ADAPTER/AW05 Rondelle	1		1			
48A-29	V670-200-0050-0	NUT, ADAPTER/AN05 Eccrou	1		1			
48A-30	1417-211-0010-0	GEAR, PTO DRIVE/21T Pignon	1		1			
48A-31	V607-110-6305-0	BEARING, RB/6305NR Roulement radial	1		1			
48A-32	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe	1		1			
48A-33	1424-211-1000-0	SHAFT, PTO DRIVE Demi arbre av.	1		1			
48A-34	1415-207-0043-0	PIN, BACK GEAR Arbre de marche ar.	1		1			
48A-35	1426-207-0021-0	GEAR, BACK/20T Pignon	1		1			
48A-36	1415-207-0090-0	BEARING, NR/NAG4901 Roulement à aiguilles	2		2			
48A-37	V704-140-0120-0	RING, SNAP/C 12 Collet d'axe	2		2			
48A-38	1412-204-0030-0	RING, SNAP/AR24 Collet d'axe	2		2			


Ref.No. Réf.Nº	Parts No. Pièces Nº	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	F.DU	
48A-39	1426-261-0030-0	GEAR, COUNTER 23T-27T Pignon etage	1		1			
48A-40	1424-952-0040-0	SHIM, COUNTER GEAR Bague d'oscurement	AR		AR			

[illegible]

Fig.49 TRANSMISSION GEAR(D, F-DU, LF-DU TYPE)

Arbres et demultiplicateur

(D. ~ #101288, F. ~ #004182)



Ref.No. Réf.No.	Parts No. Pièces No.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	P-U	F-DU	L-FDU	
49- 1	1417-203-0010-0	GEAR, INPUT/16T Pignon d'entrée		1		1		
49- 1-1	1417-223-0010-0	GEAR, INPUT/16T Pignon d'entrée					1	
49- 2	1415-203-0020-0	BEARING, NR/NA4904 7 Roulement à aiguilles		1		1	1	
49- 3	V705-140-0550-0	RING, SNAP/C 55 Collet d'axe		1		1	1	
49- 4	1415-203-0030-0	COLLAR/36 X 43 X 27 Collier		1		1	1	
49- 5	V600-110-6007-0	BEARING, RB/6007 Roulement radial		1		1	1	
49- 6	V704-140-0350-0	RING, SNAP/C 35 Collet d'axe		1		1	1	
49- 7	V705-140-0620-0	RING, SNAP/C 62 Collet d'axe		3		3	3	
49- 8	V744-135-6210-0	SEAL, OIL/TC356120 Bague d'étanchéité		1		1	1	
49- 9	1415-203-0040-0	SEAL, OIL/VC22287 Bague d'étanchéité		1		1	1	
49-10	V653-422-2820-0	BEARING, NR/TLA2220 Roulement à aiguilles		1		1	1	
49-11	V704-140-0300-0	RING, SNAP/C 30 Collet d'axe		1		1	1	
49-12	V705-140-0620-0	RING, SNAP/C 62 Collet d'axe		1		1	1	
49-13	1426-204-0050-0	BEARING, RB/6206 Roulement radial		1		1	1	
49-14	1417-203-0020-0	GEAR, INPUT/15T Pignon d'entrée		1		1		
49-14-1	1417-223-0020-0	GEAR, INPUT/15T Pignon d'entrée					1	
49-15	1426-204-0080-0	BEARING, NR/BM2220 Roulement à aiguilles		1		1	1	
49-16	1426-204-0040-0	SHAFT, SHIFT Arbre primaire		1		1	1	
49-17	1426-204-0011-0	GEAR, SHIFT/19-15T Pignon		1		1	1	
49-18	1426-204-0031-0	GEAR, SHIFT/35T Pignon		1		1	1	
49-19	1426-204-0022-0	GEAR, SHIFT/29-24T Pignon		1		1	1	
49-20	V600-110-6305-0	BEARING, RB/6305 Roulement radial		1		1	1	
49-21	1426-205-0051-0	GEAR, COUNTER/23T Pignon étage		1		1	1	
49-22	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe		1		1	1	
49-23	1415-205-0170-0	BEARING, CR/NH2207 Roulement		1		1	1	
49-24	1415-205-0020-0	GEAR, COUNTER/36T Pignon étage		1		1	1	
49-25	1415-205-0030-0	COLLAR/36 X 45 X 37 Collier		1		1	1	
49-26	1426-205-0020-0	GEAR, COUNTER/33T Pignon étage		1		1	1	
49-27	1426-205-0031-0	GEAR, COUNTER/29T Pignon étage		1		1	1	
49-28	1415-205-0180-0	WASHER, ADAPTER/AW07 Rondelle		1		1	1	
49-29	V670-200-0070-0	NUT, ADAPTER/AN07 Eccou		1		1	1	
49-30	1415-205-0060-0	COLLAR, COUNTER Collier		1		1	1	
49-31	1426-205-0060-0	GEAR, COUNTER/37-17T Pignon étage		1		1	1	
49-32	1426-205-0040-0	COLLAR/36 X 45 X 34 Collier		1		1	1	
49-33	1415-205-0080-0	BEARING, NR/KT283327 Roulement à aiguilles		2		2	2	
49-34	1417-205-0040-0	GEAR, PTO COUNTER/36T Pignon étage		1		1	1	
49-35	1415-205-0110-0	BEARING, NR/KT283313 Roulement à aiguilles		1		1	1	
49-36	1415-205-0120-0	COLLAR/28 X 33 X 5 Collier		1		1	1	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-FD	
49-37	1415-205-0080-0	BEARING, NR/KT283327 Roulement à aiguilles		1		1	1	
49-38	1415-205-0130-0	COLLAR/26 X 42 X 4 Collier		1		1	1	
49-39	1417-205-0050-0	BEARING, TR/32305 Roulement		1		1	1	
49-40	1415-205-0150-0	SHIM, A/0.05 Cale		AR		AR	AR	
49-41	1415-205-0160-0	SHIM, B/0.10 Cale		AR		AR	AR	
49-42	V671-400-0050-0	WASHER, ADAPTER/AW05 Rondelle		1		1	1	
49-43	V670-200-0050-0	NUT, ADAPTER/AN05 Ecran		1		1	1	
49-44	V607-110-6305-0	BEARING, RB/6305NR Roulement radial		1		1	1	
49-45	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe		1		1	1	
49-46	1424-212-1000-0	SHAFT, PTO DRIVE Arbre		1		1	1	
49-47	1417-212-2000-0	RING, OIL Collet		1		1	1	
49-48	V742-130-6205-0	SEAL, OIL/VC30852 Bague d'étanchéité		1		1	1	
49-49	1415-207-0043-0	PIN, BACK, GEAR Arbre de marche ar.		1		1	1	
49-50	1426-207-0021-0	GEAR, BACK/25T Pignon		1		1	1	
49-51	1415-207-0090-0	BEARING, NR/NAG4901 Roulement à aiguilles		2		2	2	
49-52	V704-140-0120-0	RING, SNAP/C 12 Collet d'axe		1		1	1	
49-53	1412-204-0030-0	RING, SNAP/24 Collet d'axe		2		2	2	
49-54	1417-211-0010-0	GEAR, PTO DRIVE/21T Pignon		1		1	1	
49-55	V740-145-6209-0	SEAL, OIL/SC45829 Bague d'étanchéité		1		1	1	
49-56	V708-140-0620-0	RING, SNAP/C 62 Collet d'axe		1		1	1	

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99


100



Fig.49A TRANSMISSION GEAR(D, F-DU, LF-DU TYPE)

Arbres et demultiplicateur

(D. #101289~, F. #004183~)



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
49A- 1	1417-203-0010-0	GEAR, INPUT/16T Pignon d'entrée		1			1		⊙ { D #101238 ~ F #003991 ~
49A- 1a	1417-203-0011-0	GEAR, INPUT/16T Pignon d'entrée		1			1		
49A-1-1	1417-223-0010-0	GEAR, INPUT/16T Pignon d'entrée						1	
49A-1-1a	1417-223-0011-0	GEAR, INPUT/16T Pignon d'entrée						1	⊙ { D #101238 ~ F #003991 ~
49A- 2	1415-203-0020-0	BEARING, NR/NA4904 7 Roulement à aiguilles		1			1	1	
49A- 3	V705-140-0550-0	RING, SNAP/C55 Collet d'axe		1			1	1	
49A- 4	1415-203-0030-0	COLLAR/36 X 43 X 27 Collier		1			1	1	
49A- 5	V600-110-6007-0	BEARING, RB/6007 Roulement radial		1			1	1	
49A- 6	V704-140-0350-0	RING, SNAP/C 35 Collet d'axe		1			1	1	
49A- 7	V705-140-0620-0	RING, SNAP/C 62 Collet d'axe		3			3	3	
49A- 8	V744-135-6210-0	SEAL, OIL/TC356120 Bague d'étanchéité		1			1	1	
49A- 9	1415-203-0040-0	SEAL, OIL/VC22287 Bague d'étanchéité		1			1	1	
49A-10	V653-422-2820-0	BEARING, NR/TLA2220 Roulement à aiguilles		1			1	1	
49A-11	V704-140-0300-0	RING, SNAP/C 30 Collet d'axe		1			1	1	
49A-12	V705-140-0620-0	RING, SNAP/C 62 Collet d'axe		1			1	1	
49A-13	1426-204-0050-0	BEARING, RB/6206 Roulement radial		1			1	1	
49A-14	1417-203-0020-0	GEAR, INPUT/16T Pignon d'entrée		1			1	1	
49A-15	1426-204-0080-0	BEARING, NR/BM2220 Roulement à aiguilles		1			1	1	
49A-16	1426-204-0040-0	SHAFT, SHIFT Arbre primaire		1			1	1	
49A-17	1426-204-0011-0	GEAR, SHIFT/19-15T Pignon		1			1	1	
49A-18	1426-204-0031-0	GEAR, SHIFT/35T Pignon		1			1	1	
49A-19	1426-204-0022-0	GEAR, SHIFT/29-24T Pignon		1			1	1	
49A-20	V600-110-6305-0	BEARING, RB/6305 Roulement radial		1			1	1	
49A-21	1426-261-0030-0	GEAR, COUNTER/23-27T Pignon étage		1			1	1	
49A-22	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe		1			1	1	
49A-23	1424-205-0010-0	BEARING, CR/NH2207R Roulement		1			1	1	
49A-24	1426-261-0020-0	GEAR, COUNTER/33-36T Pignon étage		1			1	1	
49A-25	1426-205-0060-0	GEAR, COUNTER/37-17T Pignon étage		1			1	1	
49A-26	1415-205-0080-0	BEARING, NR/KT283327 Roulement à aiguilles		2			2	2	
49A-27	1426-261-0040-0	GEAR, PTO COUNTER/36T Pignon étage		1			1	1	
49A-28	1415-205-0110-0	BEARING, NR/KT283313 Roulement à aiguilles		1			1	1	
49A-29	1415-205-0120-0	COLLAR/28 X 33 X 5 Collier		1			1	1	
49A-30	1415-205-0080-0	BEARING, NR/KT283327 Roulement à aiguilles		1			1	1	
49A-31	1415-205-0130-0	COLLAR/25 X 42 X 4 Collier		1			1	1	
49A-32	1426-261-0050-0	BEARING, TR/32305 Roulement		1			1	1	
49A-33	1415-205-0150-0	SHIM, A/0.05 Cale		AR			AR	AR	
49A-34	1415-205-0160-0	SHIM, B/0.10 Cale		AR			AR	AR	
49A-35	V671-400-0050-0	WASHER, ADAPTER/AW05 Rondelle		1			1	1	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.FDU	
49A-36	V670-200-0050-0	NUT, ADAPTER/AN05 Eccrou		1		1	1	
49A-37	V607-110-6305-0	BEARING, RB/6305NR Roulement radial		1		1	1	
49A-38	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe		1		1	1	
49A-39	1424-212-1000-0	SHAFT, PTO DRIVE Arbre		1		1	1	
49A-40	1417-212-2000-0	RING, OIL Collet		1		1	1	
49A-41	V742-130-6205-0	SEAL, OIL/VC30652 Bague d'étanchéité		1		1	1	
49A-42	1415-207-0043-0	PIN, BACK GEAR Arbre de marche ar.		1		1	1	
49A-43	1426-207-0021-0	GEAR, BACK/25T Pignon		1		1	1	
49A-44	1415-207-0090-0	BEARING, NR/NAG4901 Roulement à aiguilles		2		2	2	
49A-45	V704-140-0120-0	RING, SNAP/C 12 Collet d'axe		2		1	1	
49A-46	1412-204-0030-0	RING, SNAP/24 Collet d'axe		2		2	2	
49A-47	1417-211-0010-0	GEAR, PTO DRIVE/21T Pignon		1		1	1	
49A-48	V740-145-6209-0	SEAL, OIL/SC45629 Bague d'étanchéité		1		1	1	
49A-49	V708-140-0620-0	RING, SNAP/C 62 Collet d'axe		1		1	1	
49A-50	1424-952-0040-0	SHIM, COUNTER GEAR Bague d'écartement		AR		AR	AR	

[illegible]

Fig.50 POWER TAKE OFF

Arbre de changement




Fig. 47-1


Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	U	
50- 1	1431-280-0010-0	GEAR, PTO COUNTER/14-21T Pignon	1	1	1	1	1	1	
50- 2	V607-110-6305-0	BEARING, RB/6305NR Roulement radial	1	1	1	1	1	1	
50- 3	V600-110-6207-0	BEARING, RB/6207 Roulement radial	1	1	1	1	1	1	
50- 4	1415-213-0010-0	SHAFT, PTO Arbre	1	1	1	1	1	1	
50- 5	1431-283-0010-0	GEAR, PTO COUNTER/36-43T Pignon	1	1	1	1	1	1	
50- 6	1426-213-0010-0	BEARING, RB/6205NR Roulement radial	1	1	1	1	1	1	
50- 7	V600-110-6207-0	BEARING, RB/6207 Roulement radial	1	1	1	1	1	1	
50- 8	V744-135-5508-0	SEAL, OIL/TC35558 Jugite d'huile	1	1	1	1	1	1	
50- 9	~~1421-212-0040-0~~ 1444-314-0040-0	CAP, PTO SHAFT Chapeau d'arbre	1	1	1	1	1	1	(A) inf 83-16 + 83-18(e/e)
50-10	1417-216-2000-0	ARM, LOW SHIFT Bras	1	1	1	1	1	1	
50-11	1415-216-0060-0	BOLT/M8 X 16 Vis	1	1	1	1	1	1	
50-12		WIRE/0.9 X 150 Fil	1	1	1	1	1	1	
50-13	V720-102-4021-0	O-RING/P21 Joint torique	1	1	1	1	1	1	
50-14	1431-286-2000-0	LEVER, PTO SHIFT Sélecteur de PDF	1	1	1	1	1	1	
50-15	4106-105-3030-0	KNOB, LEVER Poignée	1	1	1	1	1	1	
50-15a	2101-230-0010-0	KNOB, LEVER Poignée	1	1	1	1	1	1	(A)
50-16	1431-286-0020-0	GUIDE, PTO SHIFT LEVER Guide de PDF	1	1	1	1	1	1	(B) { S #002721~ D #101383~ F #005160~
50-16a	1431-286-0021-0	GUIDE, PTO SHIFT LEVER Guide de PDF	1	1	1	1	1	1	
50-17	1431-938-0040-0	MARK, PTO Étiquette	1	1	1	1	1	1	
50-17a	1431-940-0110-0	MARK, PTO Étiquette	1	1	1	1	1	1	(A)
50-17b	1425-940-0060-0	MARK, PTO Étiquette	1	1	1	1	1	1	(B)
50-18	V201-260-8016-0	BOLT/M8 X 16 Vis	2	2	2	2	2	2	
50-19	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	2	
50-20	1417-216-0040-0	BAR, PTO LOW SHIFT Barre	1	1	1	1	1	1	
50-21	V500-152-5018-0	PIN, SPLIT/2.5 X 18 Goupille fendue	2	2	2	2	2	2	
50-22	1431-286-0010-0	STAY, PTO SHIFTER Appui	1	1	1	1	1	1	
50-23	V720-101-9010-0	O-RING/P10 Joint torique	1	1	1	1	1	1	
50-24	1417-216-0010-0	SHIFTER, PTO LOW Fourchette	1	1	1	1	1	1	
50-24a	1424-216-0010-0	SHIFTER, PTO LOW Fourchette	1	1	1	1	1	1	(B) D { #100993~ F { #002748~
50-25	V680-100-0010-0	BALL, STEEL Bille	1	1	1	1	1	1	
50-26	1102-225-0030-0	SPRING, SHIFTER Resort	1	1	1	1	1	1	
50-27	V500-153-0025-0	PIN, SPLIT/3 X 25 Goupille fendue	1	1	1	1	1	1	
50-28	1416-216-0040-0	STOPPER, SHIFTER STAY Bouchon	1	1	1	1	1	1	
50-29	V201-260-8016-0	BOLT/M8 X 16 Vis	1	1	1	1	1	1	
50-30	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	1	1	1	1	1	1	
50-31	1424-303-2000-0	SHAFT, DIFF-LOCK Arbre	1	1	1	1	1	1	
50-32	V720-102-4016-0	O-RING/P16 Joint torique	1	1	1	1	1	1	
50-33	1407-303-0020-0	CAM, DIFF-LOCK Came	1	1	1	1	1	1	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	E	D	
50-34	1407-303-0030-0	BOLT/M10 X 20 Vis	1	1	1	1	1	1	
50-35		WIRE/1.2 X 220 Fil	1	1	1	1	1	1	
50-36	1407-303-0010-0	SHIFTER, DIFF-LOCK Fourchette de creboisage	1	1	1	1	1	1	
50-37	1407-303-0040-0	SPRING, PRESS/40 Ressort	1	1	1	1	1	1	
50-38	V413-160-0180-0	WASHER/M18 Rondelle	1	1	1	1	1	1	
50-39	V500-154-0030-0	PIN, SPLIT/4 X 30 Goupille fendue	1	1	1	1	1	1	
50-40	V200-260-6012-0	BOLT/M8 X 12 Vis	2	2	2	2	2	2	
50-41	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	2	2	2	2	2	2	
50-42	1424-303-0010-0	WASHER/21 X 40 X 3 Rondelle	1	1	1	1	1	1	
50-43	V704-140-0120-0	RING, SNAP/C 12 Collet d'axe	1	1	1	1	1	1	

SERVICE MEMO

Fig.51 GEAR SHIFT

Mechanisme de changement



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F-U	F-D	U-F	D-F	
51- 1	1431-273-0010-0	COVER, SHIFT Couvercle	1	1	1	1	1	1	
51- 2	1415-208-0020-0	PACKING, SHIFTER COVER Joint	1	1	1	1	1	1	
51- 3	V520-100-6016-0	PIN, A/6 x 16 Goupille	1	1	1	1	1	1	
51- 3a	1421-207-0050-0	PIN, A/6 x 16 Goupille	1	1	1	1	1	1	①
X 51- 4	V201-260-8045-0	BOLT/M8 x 45 Vis	5	5	5	5	5	5	Correct for E 21, 23 info x 82-0) (4/4) March 31, '82.
51- 5	V201-260-8060-0	BOLT/M8 x 60 Vis	2	2	2	2	2	2	
51- 6	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	8	8	8	8	8	8	
51- 7	7956-205-0160-0	CAP, OIL/30 Bouchon	1	1	1	1	1	1	
51- 8	1426-208-0020-0	LEVER, SHIFT Lever de changement	1	1	1	1	1	1	
51- 8a	1426-208-0021-0	LEVER, SHIFT Lever de changement	1	1	1	1	1	1	② { S #002721 ~
51- 8b	1426-208-0022-0	LEVER, SHIFT Lever de changement	1	1	1	1	1	1	② { D #101383 ~
51- 9	1416-207-0040-0	SPRING, CONICAL/83 Ressort	1	1	1	1	1	1	② { F #005160 ~
51-10	1407-207-0040-0	SEAT, SPRING Cuvette de ressort	1	1	1	1	1	1	
51-10a	1421-207-0040-0	SEAT, SPRING Cuvette de ressort	1	1	1	1	1	1	③
51-11	1407-207-0050-0	RING, SNAP Collet d'axe	1	1	1	1	1	1	
51-12	1426-208-0032-0	GUIDE, SHIFT LEVER Garde de vitesses	1	1	1	1	1	1	
51-13	1402-501-0170-0	BOLT/M6 x 12 Vis	4	4	4	4	4	4	
51-14	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	4	4	4	4	4	4	
51-15		WIRE/O.9 x 350 Fil	1	1	1	1	1	1	
51-16	1403-207-0010-0	BOOT, SHIFT LEVER Cupule de rotule	1	1	1	1	1	1	
51-17	1414-207-0050-0	KNOB, LEVER/48 Pommette	1	1	1	1	1	1	
51-17a	2132-211-0040-0	KNOB, LEVER/48-14 Pommette	1	1	1	1	1	1	④ { S #002721 ~
51-18	1415-209-1000-0	ARM, SUB SHIFT Doigt de subdivision	1	1	1	1	1	1	④ { D #101383 ~
51-19	V720-102-4012-0	O-RING/P12 Joint torique	1	1	1	1	1	1	④ { F #005160 ~
51-20	1421-208-1000-0	LEVER, SUB SHIFT Lever de transfert	1	1					
51-20a	1421-208-1001-0	LEVER, SUB SHIFT Lever de transfert	1	1					⑤
51-20-1	1426-214-2000-0	LEVER, SUB SHIFT Lever de transfert			1	1	1	1	
51-20-1a	1426-214-2001-0	LEVER, SUB SHIFT Lever de transfert			1	1	1	1	⑥
51-21	V580-140-6028-0	PIN, SPRING/W6 x 28 Goupille élastique	1	1	1	1	1	1	
51-22	4106-105-3030-0	GRIP Poignée	1	1	1	1	1	1	
51-22a	2101-230-0010-0	GRIP Poignée	1	1	1	1	1	1	⑦
51-23	1415-210-0030-0	STAY, LOW SHIFTER Appui	1	1	1	1	1	1	
51-24	1401-201-0160-0	BOLT/M6 x 16 9T Vis	2	2	2	2	2	2	
51-25	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	2	2	2	2	2	2	
51-26	V590-130-9400-0	WIRE/O.9 x 400 Fil	2	2	2	2	2	2	
51-27	1415-210-0010-0	SHIFTER, LOW Fourchette	1	1	1	1	1	1	
51-27a	1426-210-0060-0	SHIFTER, LOW Fourchette	1	1	1	1	1	1	⑧ { S #002721 ~
51-28	1415-210-0020-0	SPRING, SHIFTER Ressort	1	1	1	1	1	1	⑧ { D #101383 ~
									⑧ { F #005160 ~


1424-209

1426-210-214 1431-273-935-938

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F.U	F.D	U.L	F.D.U	
51-29	V680-100-0013-0	BALL, STEEL Bille	1	1	1	1	1	1	
51-30	1426-210-0031-0	STAY, THIRD SHIFTER Appui	1	1	1	1	1	1	
51-31	1401-201-0160-0	BOLT/M6 x 16 9T Vis	2	2	2	2	2	2	
51-32	V401-160-0060-0	WASHER, SP/M6 Rondelle train	2	2	2	2	2	2	
51-33	V704-140-0150-0	RING, SNAP/C 15 Collet d'axe	1	1	1	1	1	1	
51-34	1426-210-0021-0	SHIFTER, SUB Fourchette	1	1	1	1	1	1	
51-34a	1426-210-0022-0	SHIFTER, SUB Fourchette	1	1	1	1	1	1	Ⓔ { D #100993 ~ F #002748 ~
51-35	1426-210-0011-0	SHIFTER, THIRD Fourchette	1	1	1	1	1	1	
51-35a	1426-210-0012-0	SHIFTER, THIRD Fourchette	1	1	1	1	1	1	Ⓔ { D #100993 ~ F #002748 ~
51-36	1415-210-0020-0	SPRING, SHIFTER Ressort	2	2	2	2	2	2	
51-37	V680-100-0013-0	BALL, STEEL Bille	2	2	2	2	2	2	
51-38	1426-210-0050-0	STAY, BACK SHIFTER Appui	1	1	1	1	1	1	
51-39	1401-201-0160-0	BOLT/M6 x 16 9T Vis	2	2	2	2	2	2	
51-40	V401-160-0060-0	WASHER, SP/M6 Rondelle train	2	2	2	2	2	2	
51-41	1426-210-0041-0	SHIFTER, BACK Fourchette	1	1	1	1	1	1	
51-41a	1426-210-0042-0	SHIFTER, BACK Fourchette	1	1	1	1	1	1	Ⓔ { D #100993 ~ F #002748 ~
51-42	1415-210-0020-0	SPRING, SHIFTER Ressort	1	1	1	1	1	1	
51-43	V680-100-0013-0	BALL, STEEL Bille	1	1	1	1	1	1	
51-44		WIRE/0.9 x 90 Fil	1	1	1	1	1	1	
x51-45	V201-260-8050-0	BOLT/M8 x 50 Vis	1	1	1	1	1	1	no use for E 21, 23 infon 88.02 (4/1) March 31, '82.
51-46	1427-932-0020-0	TAG, CAUTION	1	1	1	1	1	1	

[illegible]


Fig.52 REAR AXLE HOUSING
Carter de pont arriere



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.FDU	
52- 1	1417-306-0010-0	HOUSING, R. AXLE LH Carter du réducteur G.	1	1	1	1	1	
52- 2	1417-306-0020-0	HOUSING, R. AXLE RH Carter de réducteur D.	1	1	1	1	1	
52- 3	V251-261-2032-0	STUD/M12 X 32 Goujon	6	6	6	6	6	
52- 4	1415-306-0070-0	PACKING, RAXLE HOUSING Joint	2	2	2	2	2	
52- 5	1417-306-0030-0	O-RING Joint torique	2	2	2	2	2	
52- 6	V201-461-0030-0	BOLT/M10 X 30 BT Vis	8	8	8	8	8	
52- 7	V300-460-0100-0	NUT/M10 7T Eccrou	10	10	10	10	10	
52- 8	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	18	18	18	18	18	
52- 9	V580-140-8025-0	PIN, SPRING/8 X 25 Goupille élastique	2	2	2	2	2	
52-10	V300-460-0120-0	NUT/M12 7T Eccrou	6	6	6	6	6	
52-11	V401-160-0120-0	WASHER, SP/M12 Rondelle frein	6	6	6	6	6	
52-12	1326-706-0020-0	PLUG, DRAIN Bouchon	2	2	2	2	2	
52-13	V607-110-6311-0	BEARING, RB/6311NR Roulement radial	2	2	2	2	2	
52-14	1415-307-0020-0	COLLAR/55 X 70 X 4 Collier	2	2	2	2	2	
52-15	V600-110-6212-0	BEARING, RB/6212 Roulement radial	2	2	2	2	2	
52-16	1415-306-0030-2	METAL, OIL SEAL Palier	2	2	2	2	2	
52-17	1415-306-0040-0	PACKING, METAL Joint	2	2	2	2	2	
52-18	1415-306-0060-0	SEAL/A03250E Bague d'étanchéité	2	2	2	2	2	
52-19	V201-260-8020-0	BOLT/MB X 20 Vis	8	8	8	8	8	
52-20	V401-160-0080-0	WASHER, SP/MB Rondelle frein	8	8	8	8	8	
52-21	1431-355-0010-0	SHAFT, WHEEL Fusée	2	2	2	2	2	
52-22	V671-400-0100-0	WASHER, ADAPTER/AW10 Rondelle	2	2	2	2	2	
52-23	V670-200-0100-0	NUT, ADAPTER/AN10 Eccrou	2	2	2	2	2	

Fig.53 DIFFERENTIAL GEAR


Commande et blocage du differenciel



Ref.No. Réf.No.	Parts No. Pièces No.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-FDU	
53- 1	1431-026-3000-0	GEAR, DRIVE 8 SET Pignon d'attache	1	1				
53- 1a	1431-009-2010-0	GEAR, DRIVE 8 SET Pignon d'attache	1	1				⊙ #101289~
53- 2	1431-026-2000-0	GEAR, DRIVE F SET Pignon d'attache			1	1	1	
53- 2a	1431-009-2100-0	GEAR, DRIVE F SET Pignon d'attache			1	1	1	⊙ #004183~
53- 3	V600-110-6211-0	BEARING, RB/6211 Roulement radial	1	1	1	1	1	
53- 4	1431-301-0050-0	COLLAR, THRUST/45 X 66 X 1 Rondelle d'adul	1	1	1	1	1	
53- 5	1431-301-0060-0	GEAR, DIFF SIDE A/20T Pignon	1	1	1	1	1	
53- 6	1431-301-0090-0	PINION, DIFF/12T Satellite	4	4	4	4	4	
53- 7	1431-301-0020-0	SHAFT, DIFF-PINION A Axe des satellites A.	1	1	1	1	1	
53- 8	1431-301-0030-0	SHAFT, DIFF-PINION B Axe des satellites B.	2	2	2	2	2	
53- 9	1431-301-0040-0	HOLDER, PINION SHAFT Nœs de differential	1	1	1	1	1	
53-10	1431-301-0110-0	GEAR, DIFF-LOCK Pignon	1	1	1	1	1	
53-11	V600-110-6211-0	BEARING, RB/6211 Roulement radial	1	1	1	1	1	
53-12	1404-301-0100-0	BOLT, DIFF Vis	8	8	8	8	8	
53-13	1404-301-0090-0	WASHER, DIFF-BOLT Rondelle	4	4	4	4	4	
53-14	V303-460-0080-0	NUT/M8 7T Eccou	8	8	8	8	8	
53-15	1426-301-0050-0	PINION, WHEEL LH/10T Pignon de roue G.	1	1	1	1	1	
53-16	V600-110-6309-0	BEARING, RB/6309 Roulement radial	1	1	1	1	1	
53-17	1426-202-0010-0	METAL, DIFF-CASE LH Peller G.	1	1	1	1	1	
53-18	V721-103-1115-0	O-RING/G115 Joint torique	1	1	1	1	1	
53-19	1426-301-0070-0	CLUTCH, DIFF-LOCK Crochet directionnel	1	1	1	1	1	
53-20	1426-301-0060-0	PINION, WHEEL RH/10T Pignon de roue D.	1	1	1	1	1	
53-21	1426-202-0021-0	METAL, DIFF-CASE RH Peller D.	1	1	1	1	1	
53-22	1415-201-0140-0	SHIM, A/O.198 Cale, A.	AR	AR	AR	AR	AR	
53-23	1415-201-0150-0	SHIM, B/O.1 Cale, B.	AR	AR	AR	AR	AR	
53-24	1415-201-0160-0	SHIM, C/O.5 Cale, C.	AR	AR	AR	AR	AR	
53-25	V721-103-1115-0	O-RING/G115 Joint torique	1	1	1	1	1	
53-26	V201-260-8025-0	BOLT/M8 X 25 Vis	12	12	12	12	12	
53-27	V401-160-0080-0	WASHER, SP/M8 Rondelle train	12	12	12	12	12	
53-28	V600-110-6309-0	BEARING, RB/6309 Roulement radial	1	1	1	1	1	
53-29	V705-140-1000-0	RING, SNAP/C 100 Collet d'axe	2	2	2	2	2	
53-30	1417-200-0511-0	SEAL Bague d'etancheite	2	2	2	2	2	
53-30a	1417-201-2000-0	SEAL Bague d'etancheite	2	2	2	2	2	⊙
53-31	1417-307-0010-0	GEAR, WHEEL/60T Roue d'entee	2	2	2	2	2	
53-32	1431-301-0010-0	CASE, DIFF LH Boitier de differential	1	1	1	1	1	
53-33	1431-301-0070-0	GEAR, DIFF-SIDE B/20T Pignon	1	1	1	1	1	
53-34	1431-301-0080-0	COLLAR, PINION THRUST Rondelle d'adul	4	4	4	4	4	

Fig.54 STEP AND BRAKE SYSTEM(S, D TYPE)

Pedales de freins




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U.	F.DU	F.DU	
54- 1	1423-031-2000-0	PEDAL BRAKE SET Pedales de freins G.	1	1				
54- 2	1423-312-0010-0	COLLAR/28 x 34 x 15 Collier	1	1				
54- 3	1421-312-0020-0	WASHER/26 x 35 x 1 Rondelle	2	2				
54- 4	V720-103-5025-0	O-RING/P25 Joint torique	2	2				
54- 5	V511-168-0050-0	PIN, TAPER/8 x 50 Goupille	1	1				
54- 6	1415-312-3000-0	PEDAL, BRAKE RH Pedales de freins D.	1	1				
54- 7	V763-400-0000-0	NIPPLE, GREASE Graisseur	1	1				
54- 8	V704-140-0250-0	RING, SNAP/C 25 Collet d'axe	1	1				
54- 9	1415-312-6000-0	YOKE, RH Chape D.	2	2				
54-10	1404-312-0050-0	PIN, YOKE B Axe de chape	2	2				
54-11	V413-160-0080-0	WASHER/M8 Rondelle	2	2				
54-12	V500-152-0018-0	PIN, SPLIT/2 x 18 Goupille fendue	2	2				
54-13	1415-312-4001-0	ROD, BRAKE Boullette	2	2				
54-14	V302-260-0080-0	NUT/M8 Erou	2	2				
54-15	1401-122-0050-0	NUT, LH THREAD/M8 Erou	2	2				
54-16	1415-312-5000-0	YOKE, LH Chape G.	2	2				
54-17	1404-312-0060-0	PIN, YOKE A Axe de chape	2	2				
54-18	V413-160-0080-0	WASHER/M8 Rondelle	2	2				
54-19	V500-152-0018-0	PIN, SPLIT/2 x 18 Goupille fendue	2	2				
54-20	1403-312-0030-0	SPRING, PARKING BRAKE Ressort	2	2				
54-21	1416-303-2000-0	PEDAL, DIFF LOCK Commande de différentiel	1	1				
54-22	1415-303-0010-0	ROD, DIFF LOCK Tige de différentiel	1	1				
54-23	V500-152-0018-0	PIN, SPLIT/2 x 18 Goupille fendue	2	2				
54-24	1401-304-0120-0	SPRING, BRAKE RETURN Ressort	1	1				
54-24a	1427-301-0210-0	SPRING, TENSION/121	1	1				Ⓐ
54-25	V201-261-2035-0	BOLT/M12 x 35 Vis	1	1				
54-26	V300-260-0120-0	NUT/M12 Erou	1	1				
X54-27	1415-312-0021-0	LEVER, PARKING Verrou de parcage	1	1				no use for E 21, 23 info n° 62-07 (4/4) March 31, '81.
X54-28	1415-312-0031-0	HOLDER, LEVER Support de levier	1	1				
X54-29	1424-312-2000-0	STOPPER, PARKING Groshe de parcage	1	1				
X54-30	V201-260-8025-0	BOLT/M8 x 25 Vis	1	1				
X54-31	V300-260-0080-0	NUT/M8 Erou	2	2				
X54-32	1414-312-0020-0	SPRING, TENSION/53 Ressort	1	1				
X54-33	V201-260-8016-0	BOLT/M8 x 16 Vis	1	1				
54-34	1426-616-2000-0	STEP, LH Marchepied G.	1	1				
54-35	1426-616-2102-0	STEP, RH Marchepied D.	1	1				
54-36	1414-616-0010-0	CUSHION/RUBBER Cale	8	8				
54-37	V413-160-0080-0	WASHER/M8 Rondelle	8	8				

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-FDU	
54-38	V500-152-0015-0	PIN, SPLIT/2 x 15 Goupille fendue	8	8				
54-39	1426-616-2200-0	FRAME, STEP LH Chassis G.	1	1				
54-40	1426-616-2302-0	FRAME, STEP RH Chassis D.	1	1				
54-41	V201-261-0020-0	BOLT/M10 x 20 Vis	4	4				
54-42	V413-160-0100-0	WASHER/M10 Rondelle	4	4				①
54-43	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	4	4				

[illegible]

Fig.55 STEP AND BRAKE SYSTEM(F-U, F-DU, LF-DU TYPE)

Pedales de freins



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	F.DG	
55- 1	1423-031-2000-0	PEDAL, BRAKE SET Pedales de freins G.			1	1	1	
55- 2	1423-312-0010-0	COLLAR/28 x 34 x 16 Collier			1	1	1	
55- 3	1421-312-0020-0	WASHER/26 x 35 x 1 Rondelle			2	2	2	
55- 4	V720-103-5025-0	O-RING/P25 Joint torique			2	2	2	
55- 5	V511-160-8050-0	PIN, TAPER/8 x 50 Goupille			1	1	1	
55- 6	1415-312-3000-0	PEDAL, BRAKE RH Pedales de freins D.			1	1	1	
55- 7	V763-400-0000-0	NIPPLE, GREASE Graisseur			1	1	1	
55- 8	V704-140-0250-0	RING, SNAP/C 25 Collat d'axe			1	1	1	
55- 9	1415-312-6000-0	YOKE, RH Chape D.			2	2	2	
55-10	1404-312-0050-0	PIN, YOKE B Axe de chape			2	2	2	
55-11	V413-160-0080-0	WASHER/M8 Rondelle			2	2	2	
55-12	V500-152-0018-0	PIN, SPLIT/2 x 18 Goupille fendue			2	2	2	
55-13	1415-312-4001-0	ROD, BRAKE Biellette			2	2	2	
55-14	V302-260-0080-0	NUT/M8 Ecrou			2	2	2	
55-15	1401-122-0050-0	NUT, LH THREAD/M8 Ecrou			2	2	2	
55-16	1415-312-5000-0	YOKE, LH Chape G.			2	2	2	
55-17	1404-312-0060-0	PIN, YOKE A Axe de chape			2	2	2	
55-18	V413-160-0080-0	WASHER/M8 Rondelle			2	2	2	
55-19	V500-152-0018-0	PIN, SPLIT/2 x 18 Goupille fendue			2	2	2	
55-20	1403-312-0030-0	SPRING, PARKING BRAKE Ressort			2	2	2	
55-21	1416-303-2000-0	PEDAL, DIFF-LOCK Commande de differential			1	1	1	
55-22	1415-303-0010-0	ROD, DIFF-LOCK Tige de differential			1	1	1	
55-23	V500-152-0018-0	PIN, SPLIT/2 x 18 Goupille fendue			2	2	2	
55-24	1401-304-0120-0	SPRING, BRAKE RETURN Ressort			1	1	1	
55-24a	1427-301-0210-0	SPRING, TENSION/121 Ressort			1	1	1	Ⓐ
55-25	V201-261-2035-0	BOLT/M12 x 35 Vis			1	1	1	
55-26	V300-260-0120-0	NUT/M12 Ecrou			1	1	1	
X55-27	1415-312-0021-0	LEVER, PARKING Verrou de parcage			1	1	1	no use for E 21, 23 info n° 82-07 (4/4) March 31, '82.
X55-28	1415-312-0031-0	HOLDER, LEVER Support de levier			1	1	1	
X55-29	1424-312-2000-0	STOPPER, PARKING Crochet de parcage			1	1	1	
X55-30	V201-260-8016-0	BOLT/M8 x 16 Vis			1	1	1	
X55-31	V300-260-0080-0	NUT/M8 Ecrou			1	1	1	
X55-32	1414-312-0020-0	SPRING, TENSION/53 Ressort			1	1	1	
X55-33	V201-260-8020-0	BOLT/M8 x 20 Vis			1	1	1	
55-34	1426-616-2000-0	STEP, LH Marchepied G.			1	1	1	
55-35	1426-616-2102-0	STEP, RH Marchepied D.			1	1	1	
55-36	1414-616-0010-0	CUSHION/RUBBER Cela			8	8	8	
55-37	V413-160-0080-0	WASHER/M8 Rondelle			8	8	8	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-EDU	
55-38	V500-152-0015-0	PIN, SPLIT/2 x 15 Goupille fendue			8	8	8	
55-39	1426-616-2200-0	FRAME, STEP LH Chassis G.			1	1	1	
55-40	1426-616-2302-0	FRAME, STEP RH Chassis D.			1	1	1	
55-41	V201-261-0020-0	BOLT/M10 x 20 Vis			4	4	4	
55-42	V413-160-0100-0	WASHER/M10 Rondelle			4	4	4	①
55-43	V401-160-0100-0	WASHER, SP/M10 Rondelle frein			4	4	4	

1. The first step in the process of creating a new product is to identify a market need. This involves conducting market research to understand what consumers are looking for and what gaps exist in the current market.

2. Once a market need is identified, the next step is to develop a concept. This involves brainstorming ideas and creating a rough sketch of the product.

3. The third step is to create a prototype. This is a physical model of the product that can be used to test the design and make any necessary adjustments.


4. After the prototype is created, the next step is to conduct a feasibility study. This involves evaluating the product's potential for success in the market, taking into account factors such as cost, production time, and competition.

5. Once the feasibility study is complete, the next step is to develop a business plan. This document outlines the company's goals, strategies, and financial projections, and is used to secure funding from investors or lenders.

6. The final step in the process is to launch the product. This involves marketing the product to the target audience, distributing it, and providing customer support.

Fig.56 BRAKE (E41, E43)

Frein




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	LEDU	
56- 1	1417-310-0010-0	DRUM, BRAKE Tambour	2	2	2	2	2	④
56- 2	1415-310-0030-0	WASHER, DRUM Rondelle	2	2	2	2	2	
56- 2a	1419-310-0020-0	WASHER, DRUM Rondelle	2	2	2	2	2	
56- 3	V201-461-2025-0	BOLT/M12 X 25 9T Vis	2	2	2	2	2	
56- 4	V401-160-0120-0	WASHER, SP/M12 Rondelle frein	2	2	2	2	2	
56- 5	1417-310-0040-0	WASHER, LOCK Rondelle frein	2	2	2	2	2	
56- 6	1417-310-1000-0	SHOE, BRAKE Machete	4	4	4	4	4	
56- 7	1417-310-0030-0	SPRING, TENSION/79 Ressort	4	4	4	4	4	
56- 8	1417-310-4000-0	PIN, BRAKE CAM LH Garnet G.	1	1	1	1	1	
56- 9	1417-310-5000-0	PIN, BRAKE CAM RH Garnet D.	1	1	1	1	1	
56-10	V720-102-4021-0	O-RING/P21 Joint torique	2	2	2	2	2	
56-11	1407-310-0060-0	RING, SNAP/WR25 Collet d'axe	2	2	2	2	2	
56-12	1417-310-2000-0	METAL, BRAKE LH Flasque G.	1	1	1	1	1	
56-13	1417-310-3000-0	METAL, BRAKE RH Flasque D.	1	1	1	1	1	
56-14	1417-310-0020-0	O-RING Joint torique	2	2	2	2	2	
56-15	V764-400-0000-0	NIPPLE, GREASE Graisseur	2	2	2	2	2	
56-16	V201-260-8025-0	BOLT/M8 X 25 Vis	10	10	10	10	10	
56-17	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	10	10	10	10	10	
56-18	V580-100-6020-0	PIN, SPRING/G X 20 Goupille elastique	2	2	2	2	2	



Fig.56A BRAKE (E21, E23)

Frein




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	LFDU	
56A- 1	1417-310-0010-0	DRUM, BRAKE Tambour	2	2	2	2	2	
56A- 2	1419-310-0020-0	WASHER, DRUM Rondelle	2	2	2	2	2	
56A- 3	V201-461-2025-0	BOLT/M12 x 25 9T Vis	2	2	2	2	2	
56A- 4	V401-460-0120-0	WASHER, SP/M12 Rondelle frein	2	2	2	2	2	
56A- 5	1417-310-0040-0	WASHER, LOCK Rondelle frein	2	2	2	2	2	
56A- 6	1417-310-1000-0	SHOE, BRAKE Machoire	4	4	4	4	4	
56A- 7	1417-310-0030-0	SPRING, TENSION/79 Ressort	4	4	4	4	4	
56A- 8	1426-354-2100-0	PIN, BRAKE CAM LH Garné G.	1	1	1	1	1	
56A- 9	1426-354-2200-0	PIN, BRAKE CAM RH Garné D.	1	1	1	1	1	
56A-10	V720-102-4021-0	O-RING/P21 Joint torique	2	2	2	2	2	
56A-11	1407-310-0060-0	RING, SNAP/WR25 Coilet d'axe	2	2	2	2	2	
56A-12	1417-310-2000-0	METAL, BRAKE LH Plaque G.	1	1	1	1	1	
56A-13	1417-310-3000-0	METAL, BRAKE RH Plaque D.	1	1	1	1	1	
56A-14	1417-310-0020-0	O-RING Joint torique	2	2	2	2	2	
56A-15	V764-400-0000-0	NIPPLE, GREASE Graisseur	2	2	2	2	2	
56A-16	V201-260-8025-0	BOLT/M8 x 25 Vis	8	8	8	8	8	
56A-17	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	10	10	10	10	10	
56A-18	V580-140-6020-0	PIN, SPRING/6 x 20 Goupille elastique	2	2	2	2	2	
56A-19	1426-354-2000-0	PLATE, LEVER SET Support	1	1	1	1	1	
56A-20	V201-460-8035-0	BOLT/M8 x 35 Vis	2	2	2	2	2	
56A-21	V302-260-0100-0	NUT/M10 Eccrou	2	2	2	2	2	
56A-22	1422-355-2300-0	LEVER, PARKING ASSY Lever de frein	1	1	1	1	1	
56A-23	V201-260-8020-0	BOLT/M8 x 20 Vis	2	2	2	2	2	
56A-24	V300-260-0080-0	NUT/M8 Eccrou	2	2	2	2	2	
56A-25	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
56A-26	1422-355-0020-0	ROD, PARKING Triage de frein	1	1	1	1	1	
56A-27	V413-160-0080-0	WASHER/M8 Rondelle	2	2	2	2	2	
56A-28	V500-153-0018-0	PIN, SPLIT/3 x 18 Goupille fendue	2	2	2	2	2	
56A-29	1426-354-0010-0	ROD, PARKING LH Triage de frein	2	2	2	2	2	
56A-29a	1426-354-0011-0	ROD, PARKING LH Triage de frein	2	2	2	2	2	①
56A-30	1422-355-0030-0	ROD, PARKING RH Triage de frein	2	2	2	2	2	
56A-31	1421-122-0030-0	TURNBUCKLE Ridote	2	2	2	2	2	
56A-32	V302-260-0080-0	NUT/M8 Eccrou	2	2	2	2	2	
56A-33	V413-160-0080-0	WASHER/M8 Rondelle	4	4	4	4	4	
56A-34	V500-153-0018-0	PIN, SPLIT/3 x 18 Goupille fendue	4	4	4	4	4	
56A-35	1422-355-2500-0	ARM, PARKING Lever	1	1	1	1	1	
56A-36	1426-354-2300-0	SHAFT, PARKING Arbre transversal	1	1	1	1	1	
56A-37	V580-140-8028-0	PIN, SPRING/8 x 28 Goupille elastique	1	1	1	1	1	

Ref.No. Réf.Nº.	Parts No. Pièces N°.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.FDC	
56A-38	V580-140-5028-0	PIN, SPRING/5 x 28 Goupille elastique	1	1	1	1	1	
56A-39		WIRE/1.2 x 100 Fil	1	1	1	1	1	

[illegible]

Fig.57 HYDRAULIC SYSTEM(S, D TYPE)


Mecanisme de relevage hydraulique



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	F.DU	
57- 1	1415-501-2001-0	CASE, CYL Verin	1	1				Inc. 59-7, 8
57- 2	1415-501-0020-0	PACKING, CYL CASE Joint	2	2				
57- 3	1426-501-1000-0	PAN, OIL Carter d'huile	1	1				
57- 4	V781-100-0006-0	PLUG Bouchon	1	1				
57- 5	V201-461-0170-0	BOLT/M10 x 170 9T Vis	2	2				
57- 6	V201-461-0030-0	BOLT/M10 x 30 9T Vis	7	7				
57- 7	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	15	15				
57- 8	V300-460-0100-0	NUT/M10 Eccrou	5	5				
57- 9	1404-201-0180-0	PACKING, OIL CAP Joint	1	1				
57-10	1414-501-0080-0	CAP, OIL Bouchon	1	1				
57-11	1421-207-0030-0	NIPPLE, BREATHER/30 Mamelon	2	2				
57-12	1421-501-0060-0	PIPE, BREATHER Conduit	1	1				
57-12a	1426-501-0010-0	PIPE, BREATHER Conduit	1	1				
57-13	1424-505-0060-0	CYLINDER Cylindre	1	1				
57-14	V721-113-1090-0	O-RING/G90 Joint torique	1	1				
57-15	V721-113-1085-0	O RING/G85 Joint torique	1	1				
57-16	1415-505-0030-0	RING, SNAP/WR90 Collet d'exo	1	1				
57-17	1415-505-0050-0	ROD Tige	1	1				
57-18	1415-505-0040-0	PISTON Piston	1	1				
57-19	1415-505-0060-0	RING, BACK-UP Rondelle de recul	1	1				
57-20	V720-105-7065-0	O-RING/P65 Joint torique	1	1				
57-21	V721-113-1070-0	O-RING/G70 Joint torique	1	1				
57-22	1415-505-0020-0	HEAD, CYL Culasse	1	1				
57-23	V201-461-2035-0	BOLT/M12 x 35 9T Vis	6	6				
57-24	V401-160-0120-0	WASHER, SP/M12 Rondelle frein	6	6				
57-25	1404-503-0010-0	FILTER, SUCTION Crapine aspirante	1	1				
57-26	1421-312-0020-0	WASHER/28 x 35 x 1 Rondelle	1	1				
57-27	1407-501-0090-0	SPRING, PRESS/41 Resort	1	1				
57-28	V413-160-0100-0	WASHER/M10 Rondelle	2	2				
57-29	V201-461-0035-0	BOLT/M10 x 35 9T Vis	1	1				
47-30	1427-317-0040-0	CAP, BLANK/M14 Fausset	2	2				

Fig.58 HYDRAULIC SYSTEM(F-U, F-DU, LF-DU TYPE)

Mecanisme de relevage hydraulique




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
58- 1	1426-502-2001-0	CASE, CYL Verin			1	1	1		Inc. 59-7, 8
58- 2	1415-501-0020-0	PACKING, CYL CASE Joint			2	2	2		
58- 3	1426-501-1000-0	PAN, OIL Carter d'huile			1	1	1		
58- 4	V781-100-0006-0	PLUG Bouchon			1	1	1		
58- 5	V201-461-0170-0	BOLT/M10 x 170 9T Vis			2	2	2		
58- 6	V201-461-0030-0	BOLT/M10 x 30 9T Vis			7	7	7		
58- 7	V401-160-0100-0	WASHER/M10 Rondelle			15	15	15		
58- 8	V300-460-0100-0	NUT/M10 Ecrou			5	5	5		
58- 9	1404-201-0180-0	PACKING, OIL CAP Joint			1	1	1		
58-10	1414-501-0080-0	CAP, OIL Bouchon			1	1	1		
58-12	1421-501-0060-0	PIPE, BREATHER Conduit			1	1	1		
58-12a	1426-501-0010-0	PIPE, BREATHER Conduit			1	1	1		
58-13	1424-505-0060-0	CYLINDER Cylindre			1	1	1		
58-14	V721-113-1090-0	O-RING/G90 Joint torique			1	1	1		
58-15	V721-113-1085-0	O-RING/G85 Joint torique			1	1	1		
58-16	1415-505-0030-0	RING, SNAP/WR90 Collet d'axe			1	1	1		
58-17	1415-505-0050-0	ROD Tige			1	1	1		
58-18	1415-505-0040-0	PISTON Piston			1	1	1		
58-19	1415-505-0060-0	RING, BACK-UP Rondelle de recul			1	1	1		
58-20	V720-105-7065-0	O-RING/P85 Joint torique			1	1	1		
58-21	V721-113-1070-0	O-RING/G70 Joint torique			1	1	1		
58-22	1415-505-0020-0	HEAD, CYL Culasse			1	1	1		
58-23	V201-461-2035-0	BOLT/M12 x 35 9T Vis			6	6	6		
58-24	V401-160-0120-0	WASHER, SP/M12 Rondelle frein			6	6	6		
58-25	1404-503-0010-0	FILTER, SUCTION Crepine aspirante			1	1	1		
58-26	1421-312-0020-0	WASHER/28 x 35 x 1 Rondelle			1	1	1		
58-27	1407-501-0090-0	SPRING, PRESS/M41 Ressort			1	1	1		
58-28	V413-160-0100-0	WASHER/M10 x 35 9T Rondelle			2	2	2		
58-29	V201-461-0035-0	BOLT/M10 x 35 Vis			1	1	1		
58-30	1427-317-0040-0	CAP, BLANK/M14 Fausset			2	2	2		

Fig.59 HYDRAULIC LIFT ARM

Relevage bras

(S. ~ #002730, D. ~ #101407, F. ~ #005703)



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	LEDU	
59- 1	1415-503-0040-0	SHAFT, LIFT SET Arbre de relevage	1	1	1	1	1	
59- 2	1424-503-0010-0	CRANK, LIFT Chape	1	1	1	1	1	
59- 3	V580-140-8056-0	PIN, SPRING/W 8 x 56 Goupille élastique	1	1	1	1	1	
59- 4		WIRE/1.2 x 100 Fil	1	1	1	1	1	
59- 5	1403-209-0060-0	BOLT/M8 x 20 Vis	1	1	1	1	1	
59- 6		WIRE/1.2 x 200 Fil	1	1	1	1	1	
59- 7	1404-501-0100-0	BUSH/45 Cousinet	1	1	1	1	1	
59- 8	1404-501-0090-0	BUSH/50 Cousinet	1	1	1	1	1	
59- 9	V745-145-6009-0	SEAL, OIL/TB45609 Bagus d'étanchéité	2	2	2	2	2	
59-10	1415-503-0020-0	ARM, POSITION Bras	1	1	1	1	1	
59-11	V580-140-6010-0	PIN, SPRING/W 8 x 10 Goupille élastique	1	1	1	1	1	
59-12	1431-557-0010-0	ARM, LIFT LH Bres de lavage G.	1	1	1	1	1	
59-13	1417-503-0010-0	ARM, LIFT RH Bres de lavage D.	1	1	1	1	1	
59-14	1404-502-0080-0	BOLT, LIFT ARM SET Vis	2	2	2	2	2	
59-15	V401-160-0120-0	WASHER, SP/M12 Rondelle train	2	2	2	2	2	
59-16	V300-460-0120-0	NUT/M12 7T Eccrou	2	2	2	2	2	
59-17	1404-502-0130-0	BOLT/M8 x 25 S=25 Vis	2	2	2	2	2	
59-18	V302-260-0080-0	NUT/M8 Eccrou	2	2	2	2	2	
59-19	1415-503-2000-0	FORK, LIFT BRACKET Fourch	2	2	2	2	2	
59-20	1415-503-0030-0	PIN, LIFT ARM Goupille	2	2	2	2	2	
59-21	7963-613-0040-0	PIN/19 x 84 Goupille	2	2	2	2	2	
59-22	1402-500-9010-0	PIN, LINK LARGE Goupille	2	2	2	2	2	
59-22a	1421-502-0020-0	PIN, LINK Goupille	2	2	2	2	2	Ⓐ
59-23	1415-503-1000-2	ROD Biellette	1	1	1	1	1	
59-24	1405-502-0050-0	PIN, ARM C-TYPE Goupille	2	2	2	2	2	
59-25	V500-152-5015-0	PIN, SPLIT/2.5 x 15 Goupille élastique	2	2	2	2	2	
59-26	1424-500-0512-0	VALVE, CONTROL ASSY Soupape de contrôle	1	1	1	1	1	
59-26A	1424-505-0010-0	• VALVE, CONTROL SET Soupape de contrôle	1	1	1	1	1	Ⓐ
59-26B	1424-505-0020-0	• GASKET Joint	1	1	1	1	1	21101-02302
59-26C	1424-505-0030-0	• GASKET Joint	1	1	1	1	1	21101-02301
59-26D	V720-102-4022-0	• O-RING/P22 Joint torique	2	2	2	2	2	95111-02200
59-26E	V720-102-4015-0	• O-RING/P15 Joint torique	2	2	2	2	2	95111-01500
59-26F	V720-102-4016-0	• O-RING/P16 Joint torique	2	2	2	2	2	95111-01600
59-26G	V720-101-9009-0	• O-RING/P9 Joint torique	3	3	3	3	3	95111-00900
59-26H	V720-102-4012-0	• O-RING/P12 Joint torique	4	4	4	4	4	95111-01200
59-26I	V720-101-9010-0	• O-RING/P10A Joint torique	1	1	1	1	1	95111-01090
59-26J	1424-505-0040-0	• LEVER Lever	1	1	1	1	1	21102-00211
59-26K	V720-102-4018-0	• O-RING/P18 Joint torique	1	1	1	1	1	95111-01800


Ref.No. Réf.Nº	Parts No. Pièces Nº	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F	U	F	
59-27	V201-260-8085-0	BOLT/M8 x 85 Vis	3	3	3	3	3	
59-28	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	3	3	3	3	3	
59-29	1432-242-0040-0	GRIP, B Poignée	1	1	1	1	1	
59-30	1415-505-1001-0	GUIDE, LEVER Secteur de guidage	1	1	1	1		for Mark with rivet
59-30a	1423-505-2100-0	GUIDE, LEVER Secteur de guidage	1	1	1	1	1	for Mark without rivet
59-31	1431-930-0010-0	MARK, HYD Étiquette	1	1	1	1		
59-31a	1431-935-0080-0	MARK, HYD Étiquette	1	1	1	1	1	
59-32	V291-202-0006-0	RIVET/2 x 6 Rivet	4	4	4	4		①
59-33	1415-505-0080-0	COLLAR/9 x 14 x 56 Collar	2	2	2	2	2	
59-34	V201-260-8065-0	BOLT/M8 x 65 Vis	2	2	2	2	2	
59-35	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
59-36	1415-505-0090-0	LINING Rondelle	1	1	1	1	1	
59-37	1415-505-0100-0	PLATE, LINING Rondelle	2	2	2	2	2	
59-38	1415-505-0110-0	SPRING, CONE Ressort	2	2	2	2	2	
59-39	V320-160-0120-0	NUT, SLOTTED/M12 Eccrou à créneaux	1	1	1	1	1	
59-40	V500-153-0028-0	PIN, SPLIT/3 x 28 Goupille fendue	1	1	1	1	1	
59-41	V332-260-0120-0	NUT/M12 P-1.25 Eccrou	1	1	1	1	1	
59-42	1415-505-0120-0	BOLT, LEVER SET Vis	1	1	1	1	1	
59-43	V413-160-0080-0	WASHER/M8 Rondelle	1	1	1	1	1	
59-44	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	1	1	1	1	1	
59-45	V370-160-0080-0	NUT, WING/M8 Eccrou papillon	1	1	1	1	1	
59-46	1415-505-0130-0	STOPPER Crochet	1	1	1	1	1	
59-47	V201-260-8016-0	BOLT/M8 x 16 Vis	2	2	2	2	1	
59-48	V413-160-0080-0	WASHER/M8 Rondelle	2	2	2	2	2	
59-49	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
59-50	V300-260-0080-0	NUT/M8 Eccrou	2	2	2	2	2	
59-51	1406-926-3020-0	WASHER, YOKE Rondelle	1	1	1	1	1	
59-52	1424-904-0011-0	MARK, LOCK A Étiquette	1	1	1	1	1	English
59-52a	1431-940-0080-0	MARK, LOCK A Étiquette	1	1	1	1	1	② English
59-52-1	1431-935-0030-0	MARK, LOCK A Étiquette	1	1	1	1	1	* French
59-53	1424-505-2300-0	CONTROL VALVE ASSY	1	1	1	1	1	② { U #101171~101407 F #003462~005703 See Fig. 74

[illegible]

Fig.59A HYDRAULIC LIFT ARM

Relevage bras

(S. #002731~, D. #101408~, F. #005704~)




Ref.No. Réf.No.	Parts No. Pièces No.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	F.DG	
59A-1	1415-503-0040-0	SHAFT, LIFT Arbre de relevage	1	1	1	1	1	
59A-2	1424-503-0010-0	CRANK, LIFT Chape	1	1	1	1	1	
59A-3	V580-140-8056-0	PIN, SPRING/W8 x 56 Goupille élastique	1	1	1	1	1	
59A-4		WIRE/1.2 x 100 Fil	1	1	1	1	1	
59A-5	1403-209-0060-0	BOLT/M8 x 20 Vis	1	1	1	1	1	
59A-6		WIRE/1.2 x 200 Fil	1	1	1	1	1	
59A-7	1404-501-0100-0	BUSH/4b Cousinnet	1	1	1	1	1	
59A-8	1404-501-0090-0	BUSH/50 Cousinnet	1	1	1	1	1	
59A-9	V745-145-6009-0	SEAL, OIL/TB45600 Bague d'aranchette	2	2	2	2	2	
59A-10	1415-503-0020-0	ARM, POSITION Bras	1	1	1	1	1	
59A-11	V580-140-6010-0	PIN, SPRING/W8 x 10 Goupille élastique	1	1	1	1	1	
59A-12	1431-557-0010-0	ARM, LIFT LH Bras de relevage G.	1	1	1	1	1	
59A-13	1417-503-0010-0	ARM, LIFT RH Bras de relevage D.	1	1	1	1	1	
59A-14	1404-502-0080-0	BOLT, LIFT ARM SET Vis	2	2	2	2	2	
59A-15	V401-160-0120-0	WASHER, SP/M12 Rondelle frein	2	2	2	2	2	
59A-16	V300-460-0120-0	NUT/M12 7T Ecran	2	2	2	2	2	
59A-17	1404-502-0130-0	BOLT/M8 x 25 S - 25 Vis	2	2	2	2	2	
59A-18	V302-260-0080-0	NUT/M8 Ecran	2	2	2	2	2	
59A-19	1415-503-2000-0	FORK, LIFT BRACKET Fourche	2	2	2	2	2	
59A-20	1415-503-0030-0	PIN, LIFT ARM Goupille	2	2	2	2	2	
59A-21	7963-613-0040-0	PIN/19 x 84 Goupille	2	2	2	2	2	
59A-22	1421-502-0020-0	PIN, LINK Goupille	2	2	2	2	2	
59A-23	1415-503-1000-2	ROD Bielle	1	1	1	1	1	
59A-24	1405-502-0050-0	PIN, ARM C-TYPE Goupille	2	2	2	2	2	
59A-25	V500-152-5015-0	PIN, SPLIT/2.5 x 15 Goupille élastique	2	2	2	2	2	
59A-26	1424-505-2401-0	VALVE, CONTROL ASSY Sous-asse de contrôle	1	1	1	1	1	See Fig. 74
59A-27	V201-260-8085-0	BOLT/M8 x 85 Vis	3	3	3	3	3	
59A-28	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	3	3	3	3	3	
59A-29	1432-242-0040-0	GRIP, B Poignée	1	1	1	1	1	
59A-30	1424-505-0081-0	GUIDE, LEVER Secteur de guidage	1	1	1	1	1	
59A-31	1415-505-0080-0	COLLAR/9 x 14 x 56 Cotlier	2	2	2	2	2	
59A-32	V201-260-8065-0	BOLT/M8 x 65 Vis	2	2	2	2	2	
59A-33	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
59A-34	1421-507-0150-0	LINING Revêtement	2	2	2	2	2	
59A-35	1421-507-0140-0	WASHER/6 x 24 x 2 Rondelle	1	1	1	1	1	
59A-36	1426-574-0290-0	SPRING, PRESS/28 Resort	1	1	1	1	1	
59A-37	V200-260-6045-0	BOLT/M6 x 45 Vis	1	1	1	1	1	
59A-38	V300-260-0060-0	NUT/M6 Ecran	1	1	1	1	1	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant.					Remarks Remarques
			S	D	P-U	P-D	P-D	
59A-39	1421-507-0161-0	BOLT, LEVER SET Vis	2	2	2	2	2	
59A-40	1421-507-0170-0	COLLAR/9 x 14 x 8 Collier	2	2	2	2	2	
59A-41	V370-160-0080-0	NUT, WING/M8 Ecoule a oreilles	1	1	1	1	1	
59A-42	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
59A-43	V300-260-0080-0	NUT/M8 Ecoule	1	1	1	1	1	

[illegible]

Fig.60 HYDRAULIC PIPING (S, D TYPE)

Hydraulique tuyautage



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	E	D	
60- 1	1424-505-2700-0 (1424-505-0050-0)	PUMP, GEAR ASSY Pompe hydraulique	1	1					
60- 2	1421-503-4320-0	• O-RING Joint torique	2	2					
60- 3	1421-503-4330-0	• BUSH, A SET Douille	1	1					
60- 4	1424-505-2710-0	• GEAR SET Pignon	1	1					
60- 5	1421-503-4350-0	• BUSH, C SET Joint torique	1	1					
60- 6	1421-503-4360-0	• RING, SUPPORT Bague	2	2					
60- 7	1421-503-4370-0	• RING, SEALING Anneau d'étanchéité	2	2					
60- 8	1421-503-4380-0	• O-RING Joint torique	1	1					
60- 9	1421-503-4390-0	• COVER Couvercle	1	1					
60-10	1421-503-4410-0	• BOLT Vis	6	6					
60-11	1421-503-4420-0	• SEAL, OIL Bague d'étanchéité	1	1					
60-12	1421-503-4430-0	• KEY, WOODRUFF Clavette	1	1					
60-13	1404-503-0080-0	BOSS, SPLINE/25 Moyeu	1	1					
60-14	1404-503-0090-0	WASHER, LOCK Rondelle frein	1	1					
60-15	V303-260-0080-0	NUT/M8 Eccrou	1	1					
60-16	1425-505-4200-0	PIPE, SUCTION B Tubulure d'aspiration	1	1					
60-17	V720-112-4020-0	O-RING/P20 Joint torique	1	1					
60-18	V200-260-6030-0	BOLT/M6 x 30 Vis	3	3					
60-19	V200-260-6025-0	BOLT/M6 x 25 Vis	1	1					
60-20	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	4	4					
60-21	V413-160-0060-0	WASHER/M8 Rondelle	3	3					
60-22	1415-505-0140-0	BOLT, CONNECTOR Vis	1	1					
60-23	V720-112-4018-0	O-RING/P18 Joint torique	2	2					
60-24	1425-505-4100-0	PIPE, SUCTION A Tubulure d'aspiration A.	1	1					
60-24-1	1426-576-2000-0	PIPE, SUCTION A Tubulure d'aspiration A.	1	1					for G-type
60-25	V721-103-1030-0	O-RING/G30 Joint torique	1	1					
60-26	V200-260-6016-0	BOLT/M6 x 16 Vis	4	4					
60-27	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	4	4					
60-28	V413-160-0060-0	WASHER/M8 Rondelle	1	1					
60-29	V720-112-4020-0	O-RING/P20 Joint torique	1	1					
60-30	V200-260-6030-0	BOLT/M6 x 30 Vis	4	4					
60-31	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	4	4					
60-32	1416-506-0030-0	CLAMP, PIPE A Attache A.	1	1					
60-33	1416-506-0040-0	CLAMP, PIPE B Attache B.	1	1					
60-34	V111-168-0016-0	SCREW/M8 x 16 Vis	4	4					
60-35	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4					
60-36	1424-505-2100-0	COVER, PUMP Couvercle	1	1					

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
60-36a	1424-505-2101-0	COVER, PUMP Couvercle	1	1					Ⓔ { S #002541~ D #101309~ for G-type
60-37	1425-505-3000-0	PIPE, DEL A Tubulure A.	1	1					
60-37-1	1426-576-2100-0	PIPE, DEL A Tubulure A.	1	1					
60-38	1425-505-4000-0	PIPE, DEL B Tubulure B.	1	1					
60-39	1421-503-0050-0	HOSE/RUBBER 14 x 20 x 100 Durix	1	1					
60-40	1421-503-0060-0	CLIP/21 Attache	2	2					
60-41	1404-503-0060-0	PACKING, OIL PUMP Joint	1	1					

[illegible]

Hydraulique tuyautage




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F-U	F-D	L-R	D-U	
61- 1	1426-506-0051-0	PUMP, GEAR Pompe hydraulique			1	1	1		
61- 1a	1426-506-2600-0 (1426-506-0052-0)	PUMP, GEAR Pompe hydraulique			1	1	1		
61- 2	1426-506-2630-0	• BUSH, A SET Douille			1	1	1		
61- 3	1426-506-2640-0	• GEAR SET Pignon de pompe			1	1	1		
61- 4	1426-506-2650-0	• RING, BACK-UP Bague			2	2	2		
61- 5	1426-506-2660-0	• O-RING Joint torique			2	2	2		
61- 6	1421-503-4380-0	• O-RING Joint torique			1	1	1		
61- 7	1426-506-2670-0	• SEAL, OIL Bague d'étanchéité			1	1	1		
61- 8	1426-506-2680-0	• BOLT Vis			6	6	6		
61- 9	V401-160-0080-0	• WASHER, SP/M8 Rondelle frein			6	6	6		
61-10	1426-506-2690-0	• BUSH, B SET Manchon			1	1	1		
61-11	1426-506-2710-0	• RING, SUPPORT Bague			2	2	2		
61-12	1421-503-4370-0	• RING, SEALING Anneau d'étanchéité			2	2	2		
61-13	1426-506-0062-0	BOSS, SPLINE/28 Moyeu			1	1	1		
61-14	1426-506-0070-0	WASHER, LOCK Rondelle frein			1	1	1		
61-15	V303-260-0080-0	NUT/M8 Ecrou			1	1	1		
61-16	1426-506-2101-0	PIPE, SUCTION B Tubulure d'aspiration B.			1	1	1		
61-17	V720-112-4020-0	O-RING/P20 Joint torique			1	1	1		
61-18	V200-260-6030-0	BOLT/M6 x 30 Vis			3	3	3		
61-19	V200-260-6025-0	BOLT/M6 x 25 Vis			1	1	1		
61-20	V401-160-0060-0	WASHER, SP/M6 Rondelle frein			4	4	4		
61-21	V413-160-0060-0	WASHER/M6 Rondelle			3	3	3		
61-22	1415-505-0140-0	BOLT, CONNECTOR Vis			2	2	2		
61-23	V720-112-4018-0	O-RING/P18 Joint torique			6	6	6		
61-24	1426-506-2001-0	PIPE, SUCTION A Tubulure d'aspiration A.			1	1	1		
61-24-1	1426-576-2000-0	PIPE, SUCTION A Tubulure d'aspiration A.			1	1	1		for G-type
61-25	V721-103-1030-0	O-RING/G30 Joint torique			1	1	1		
61-26	V200-260-6016-0	BOLT/M6 x 16 Vis			4	4	4		
61-27	V401-160-0060-0	WASHER, SP/M6 Rondelle frein			4	4	4		
61-28	V413-160-0060-0	WASHER/M6 Rondelle			1	1	1		
61-29	V720-112-4020-0	O-RING/P20 Joint torique			1	1	1		
61-30	V200-260-6035-0	BOLT/M6 x 35 Vis			4	4	4		
61-31	V401-160-0060-0	WASHER, SP/M6 Rondelle frein			4	4	4		
61-32	1426-506-0031-0	CLAMP, PIPE A Attache A.			1	1	1		
61-33	1426-506-0040-0	CLAMP, PIPE B Attache B.			1	1	1		
61-34	V111-168-0016-0	SCREW/M8 x 16 Vis			3	3	3		

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	J-U	F-D	L	EDU	
61-35	V401-160-0080-0	WASHER, SP/M8 Rondelle frein				4	4	4	
61-36	1424-505-2100-0	COVER, PUMP Couvercle				1	1	1	
61-36a	1424-505-2101-0	COVER, PUMP Couvercle				1	1	1	Ⓜ #003462~
61-37	1426-506-2200-0	PIPE, DEL A Tubulure A.				1	1	1	
61-38	1425-505-4000-0	PIPE, DEL B Tubulure B.				1	1	1	
61-39	1426-506-2300-0	PIPE, DEL B Tubulure B.				1	1	1	
61-39-1	1426-578-2000-0	PIPE, DEL B Tubulure B.				1	1	1	for G-type
61-40	1426-506-2400-0	PIPE, E Tubulure E.				1	1	1	
61-40-1	1426-578-2100-0	PIPE, RETURN Tubulure				1	1	1	for G-type
61-41	1426-506-0010-0	ELBOW/90 Coudé				1	1	1	
61-42	1426-506-0020-0	CONNECTOR Junction				1	1	1	
61-43	V111-168-0018-0	SCREW/M8 x 18 Vis				1	1	1	
61-44	1424-604-0010-0	COLLAR/9 x 14 x 8 Collier				1	1	1	
61-45	1426-506-0080-0	HOSE/RUBBER 19 x 25 x 100 Durit				1	1	1	
61-46	1426-506-0110-0	CLIP/28 Attache				2	2	2	
61-47	1404-503-0060-0	PACKING, OIL PUMP Joint				1	1	1	

[illegible]

Fig.62 FENDER

Aile



Ref.No. Réf.N°	Parts No. Pièces N°	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	C	U	F	D	
62- 1	1423-606-2000-0	FENDER, LH Garde-boue G.	1	1	1	1	1	1	{ S #002721 ~ D #101362 ~ F #004901 ~ English
62- 1a	1423-606-2001-1	FENDER, LH Garde-boue G.	1	1	1	1	1	1	
62- 2	1427-937-0030-0	MARK, DRIVE CAUTION Etiquette	1	1	1	1	1	1	
62- 2-1	1427-934-0030-0	MARK, DRIVE CAUTION Etiquette	1	1	1	1	1	1	★ French
62- 3	1423-606-3000-1	FENDER, RH Garde-boue D.	1	1	1	1	1	1	{ S #002721 ~ D #101362 ~ F #004901 ~ English
62- 3a	1423-606-3001-1	FENDER, RH Garde-boue D.	1	1	1	1	1	1	
62- 4	1427-937-0090-0	MARK, DIFF. LOCK Etiquette	1	1	1	1	1	1	
62- 4-1	1427-934-0090-0	MARK, DIFF-LOCK Etiquette	1	1	1	1	1	1	★ French
62- 5	V201-260-8020-0	BOLT/M8 x 20 Vis	12	12	12	12	12	12	
62- 6	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	20	20	20	20	20	20	
62- 7	V413-160-0080-0	WASHER/M8 Rondelle	12	12	12	12	12	12	
62- 8	V300-260-0080-0	NUT/M8 Erou	12	12	12	12	12	12	
62- 9	1424-606-1000-0	PLATE, SET LH Support G.	1	1	1	1	1	1	
62- 9-1	1431-666-2000-0	BASE, FENDER LH Support G.	1	1	1	1	1	1	for E61
62-10	1424-606-2000-0	PLATE, SET RH Support G.	1	1	1	1	1	1	
62-10-1	1431-666-2100-0	BASE, FENDER RH Support G.	1	1	1	1	1	1	for E61
62-11	1405-131-0040-0	WASHER Rondelle	6	6	6	6	6	6	
62-12	1405-131-0050-0	CUSHION/RUBBER Cale	6	6	6	6	6	6	
62-12a	1421-606-0030-0	CUSHION, BASE Cale	6	6	6	6	6	6	ⓑ
62-13	V300-260-0120-0	NUT/M12 Erou	6	6	6	6	6	6	
62-14	V302-260-0120-0	NUT/M12 Erou	6	6	6	6	6	6	
62-15	1426-611-1002-0	BACKET, SEAT Berceau de siege	1	1	1	1	1	1	for E41, E43
62-15-1	1426-673-2000-0	BRACKET, SEAT Berceau de siege	1	1	1	1	1	1	for E21, E23
62-15-2	1431-671-2100-0	BRACKET, SEAT Berceau de siege	1	1	1	1	1	1	for E61
62-15-3	1426-675-2000-0	BRACKET, SEAT Berceau de siege	1	1	1	1	1	1	for G-type E21, 23
62-15-4	1426-672-2000-0	BRACKET, SEAT Berceau de siege	1	1	1	1	1	1	for G-type E41, 43, 61
62-16	1423-606-0010-0	CATCHER, HAND Main courante	2	2	2	2	2	2	
62-17	1326-636-0010-0	WASHER Rondelle	4	4	4	4	4	4	
62-17a	3560-201-0150-0	WASHER Rondelle	4	4	4	4	4	4	ⓑ
62-18	V201-260-8020-0	BOLT/M8 x 20 Vis	4	4	4	4	4	4	
62-19	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	4	
62-20	V413-160-0080-0	WASHER/M8 Rondelle	4	4	4	4	4	4	
62-21	1421-600-0510-0	SEAT ASSY Siege complet	1	1	1	1	1	1	
62-22	1421-611-0010-0	• SEAT A Siege A.	1	1	1	1	1	1	
62-23	1421-611-0020-0	• SEAT B Siege B.	1	1	1	1	1	1	
62-24	1421-611-0030-0	• PLATE A Dossier A.	1	1	1	1	1	1	
62-25	V201-260-6020-0	• BOLT/M6 x 20 Vis	2	2	2	2	2	2	
62-26	V201-260-6030-0	• BOLT/M6 x 30 Vis	2	2	2	2	2	2	


Ref.No. Réf.Nº	Parts No. Pièces Nº	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F	U	F	
62-27	V401-160-0060-0	• WASHER, SP/M6 Rondelle frein	4	4	4	4	4	
62-28	V413-160-0060-0	• WASHER/M6 Rondelle	4	4	4	4	4	
62-29	1414-632-0050-0	CUSHION/RUBBER A Cale A.	2	2	2	2	2	
62-30	1421-611-0040-0	CUSHION/RUBBER Cale	2	2	2	2	2	
62-31	3737-154-0020-0	PIN, SEAT SET Gond de siège	1	1	1	1	1	
62-32	1305-241-0010-0	PIN, HAIR Attache beta	1	1	1	1	1	
62-33	V201-260-8016-0	BOLT/M8 x 16 Vis	4	4	4	4	4	
62-34	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
62-35	1425-606-0010-0	SPACER Entretoise	2	2	2	2	2	
62-35-1	1431-666-0011-0	SPACER, FENDER LH Entretoise	1	1	1	1	1	for E61
62-35-2	1431-666-0021-0	SPACER, FENDER RH Entretoise	1	1	1	1	1	for E61
62-36	1431-938-0030-0	MARK, LOCK B Étiquette	1	1	1	1	1	English
62-36a	1431-938-0031-0	MARK, LOCK BE Étiquette	1	1	1	1	1	Ⓔ English
62-36-1	1431-935-0040-0	MARK, LOCK B Étiquette	1	1	1	1	1	★ French
62-37	V413-160-0008-0	WASHER/M8 Rondelle	4	4	4	4	4	
62-38	1423-606-2041-0	PLATE, C Enjolivure	2	2	2	2	2	
62-39	V111-166-0012-0	SCREW/M6 x 12 Vis	8	8	8	8	8	
62-40	V300-260-0060-0	NUT/M6 Eccrou	8	8	8	8	8	Ⓔ { S #002721~ D #101362~ F #004901~
62-41	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	8	8	8	8	8	
62-42	V413-160-0060-0	WASHER/M6 Rondelle	8	8	8	8	8	

Blank page.

— — — — —

Fig.63 REAR WHEEL

Jante arriere




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	E	D	
63- 0-1	1431-361-2000-0	WHEEL, R. LH SET Roue a disque avec jante G.	1	1	1	1	1	1	E21, E41
63- 0-2	1431-361-2200-0	WHEEL, R. RH SET Roue a disque avec jante D.	1	1	1	1	1	1	
63- 1	1431-361-2100-0	• TIRE LH ASSY Pneu G. ensemble	1	1	1	1	1	1	
63- 2	1431-361-2300-0	• TIRE RH ASSY Pneu D. ensemble	1	1	1	1	1	1	
63- 3	1417-317-1000-2	• RIM, WHEEL/W10-24 Jante	2	2	2	2	2	2	
63- 4	1431-361-2110-0	• TIRE Pneu	2	2	2	2	2	2	
63- 5	V889-001-2424-0	• TUBE/12.4 24 Chambre	2	2	2	2	2	2	
63- 6	V999-300-0010-0	• CAP, TIRE VALVE Bouchon de valve	2	2	2	2	2	2	
63- 7	1404-317-0050-2	• DISC, R. WHEEL Roue a disque	2	2	2	2	2	2	
63- 8	V201-461-6090-0	• BOLT/M16 X 90 9T Vis	8	8	8	8	8	8	
63- 9	V300-460-0160-0	• NUT/M16 7T Eccou	8	8	8	8	8	8	
63-10	V302-460-0160-0	• NUT/M16 7T Eccou	8	8	8	8	8	8	
63-11	V401-160-0160-0	• WASHER, SP/M16 Rondelle frein	8	8	8	8	8	8	
63-12	V201-461-6030-0	BOLT/M16 X 39 9T Vis	12	12	12	12	12	12	
63-13	V401-160-0160-0	WASHER, SP/M16 Rondelle frein	12	12	12	12	12	12	
63- 0-3	1431-362-2000-0	RIM, R. WHEEL SET Jante	2	2	2	2	2	2	
63-14	1417-317-1000-2	• RIM, WHEEL/W10-24 Jante	2	2	2	2	2	2	
63-15	1404-317-0050-2	• DISC, R. WHEEL Roue a disque	2	2	2	2	2	2	
63-16	V201-461-6090-0	• BOLT/M16 X 90 9T Vis	8	8	8	8	8	8	E23, E43
63-17	V300-460-0160-0	• NUT/M16 7T Eccou	8	8	8	8	8	8	
63-18	V302-460-0160-0	• NUT/M16 7T Eccou	8	8	8	8	8	8	
63-19	V401-160-0160-0	• WASHER, SP/M16 Rondelle frein	8	8	8	8	8	8	



Fig.64 ELECTRICAL SYSTEM(1)

Equipement électrique




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	E	D	
64- 1	1431-686-2400-0	HARNESS, WIRE NO.1 ASSY Faisceau ensemble	1	1	1	1	1	1	Ⓟ { D #00117~ F #003470~
64- 1a	1431-686-2401-0	HARNESS, WIRE NO.1 ASSY Faisceau ensemble	1	1	1	1	1	1	
64- 2		• HARNESS, WIRE NO.1 Faisceau	1	1	1	1	1	1	
64- 2a		• HARNESS, WIRE NO.1 Faisceau	1	1	1	1	1	1	△
64- 3	1431-686-2420-0	• FUSE/10A Coupacircuit	1	1	1	1	1	1	Ⓟ
64- 4	1423-621-2010-0	• FUSE/5A Coupacircuit	2	2	2	2	2	2	
64- 5	1431-686-0020-0	HARNESS, WIRE/NO.2 Faisceau	1	1	1	1	1	1	
64- 5a	1431-686-0021-0	HARNESS, WIRE/NO. 2 Faisceau	1	1	1	1	1	1	Ⓟ
64- 6	1431-686-0030-0	HARNESS, WIRE/NO.3 Faisceau	1	1	1	1	1	1	
64- 7	1421-621-0160-0	HARNESS, WIRE/NO.4 Faisceau	1	1	1	1	1	1	
64- 8	1423-621-0150-0	HARNESS, WIRE/NO.5 Faisceau	1	1	1	1	1	1	}
64- 9	1421-621-0190-0	HARNESS, WIRE/NO.7 Faisceau	1	1	1	1	1	1	
64-10	1431-686-0060-0	HARNESS, WIRE/NO.6 Faisceau	1	1	1	1	1	1	
64-11	1431-686-0050-0	HARNESS, WIRE/NO.5 Faisceau	1	1	1	1	1	1	} no use for E61
64-12	1431-686-0040-0	HARNESS, WIRE/NO.4 Faisceau	1	1	1	1	1	1	
64-13	1425-621-0020-0	CABLE, METER Cable	1	1	1	1	1	1	
64-14	1415-621-0160-0	COVER, TERMINAL/L14-7 Couvercle	1	1	1	1	1	1	}
64-15	1425-600-0511-0	WIRE, STOP ASSY Interrupteur	1	1	1	1	1	1	
64-16	1425-621-0030-0	• WIRE, STOP SET Fil	1	1	1	1	1	1	
64-17	1421-621-0081-0	• KNOB Poignée	1	1	1	1	1	1	}
64-18	V300-260-0050-0	• NUT/M5 Eccrou	1	1	1	1	1	1	
64-19	1421-621-0070-0	• NUT/M14 Eccrou	1	1	1	1	1	1	
64-20	V500-151-6010-0	PIN, SPLIT/1.6 X 10 Goupille fendue	1	1	1	1	1	1	}
64-21	V413-160-0050-0	WASHER/M5 Rondelle	1	1	1	1	1	1	
64-22	3737-172-0090-0	CLAMP, LW Attache	3	3	3	3	3	3	
64-23	V111-166-0012-0	SCREW/M6 X 12 Vis	2	2	2	2	2	2	}
64-24	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	2	2	2	2	2	2	
64-25	V300-260-0060-0	NUT/M6 Eccrou	2	2	2	2	2	2	
64-26	1421-621-0380-0	BAND, WIRE/170 Sangle	3	3	3	3	3	3	}
64-27	1317-621-0020-0	CLIP Attache	5	5	5	5	5	5	
64-28	1404-621-0300-0	GROMMET Oeillet	3	3	3	3	3	3	
64-29	1376-402-0030-0	BAND, WIRE/140 Sangle	4	4	4	4	4	4	}
64-30	1421-621-0360-0	CLAMP, HARNESS Attache faisceau	3	3	3	3	3	3	
64-31	1431-681-0011-0	HARNESS, WIRE/NO. 1 Faisceau ensemble	1	1	1	1	1	1	
64-32	1431-681-0021-0	HARNESS, WIRE/NO. 2 Faisceau ensemble	1	1	1	1	1	1	} for E61
64-33	1421-621-2300-0	REFLECTOR ASSY Reflecteur	2	2	2	2	2	2	
64-34	V302-250-0050-0	• NUT/M5 Eccrou	2	2	2	2	2	2	
64-35	V401-150-0050-0	• WASHER, SP/M5 Rondelle frein	2	2	2	2	2	2	}

Q

Fig.65 ELECTRICAL SYSTEM(2)

Equipement electrique




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
65- 1	1416-621-0440-0	HORN Avertisseur	1	1	1	1	1	1	
65- 2	V200-260-6012-0	BOLT/M6 X 12 Vis	1	1	1	1	1	1	
65- 3	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	1	1	1	1	1	1	
65- 4	V300-260-0060-0	NUT/M6 Erou	1	1	1	1	1	1	
65- 5	1431-681-2000-0	HOURLMETER ASSY Indicateur de vitesse	1	1	1	1	1	1	
65- 5a	1431-681-2001-0	HOURLMETER ASSY Indicateur de vitesse	1	1	1	1	1	1	⑬ #005655 ~
65- 6	1431-681-2010-0	• HOURLMETER SET Indicateur de vitesse	1	1	1	1	1	1	
65- 7	1407-621-0050-0	• SOCKET Emboiture	1	1	1	1	1	1	
65- 8	1423-621-0010-0	• SOCKET Emboiture	1	1	1	1	1	1	
65- 9	1407-621-0070-0	• SOCKET Emboiture	1	1	1	1	1	1	
65-10	1403-621-0310-0	• BULB/12V-3.4W Ampoule	2	2	2	2	2	2	
65-11	1415-621-0100-0	• BULB/6V-3W Ampoule	1	1	1	1	1	1	
65-12	1407-621-0040-0	• RUBBER Ca'e	1	1	1	1	1	1	
65-13	1431-686-2100-0	LAMP, PILOT ASSY Témoin optique ensemble	2	2	2	2	2	2	
65-14	1431-686-2110-0	• SOCKET Emboiture	2	2	2	2	2	2	Green
65-15	1431-686-2120-0	• LENS Verre	2	2	2	2	2	2	
65-16	1419-621-0160-0	• WASHER Rondelle	2	2	2	2	2	2	
65-17	1419-621-0170-0	• GASKET Joint	2	2	2	2	2	2	
65-18	1419-621-0180-0	• HOLDER Manche	2	2	2	2	2	2	
65-19	1403-621-0310-0	• BULB Ampoule	2	2	2	2	2	2	
65-20	1426-621-0350-0	FLASHER UNIT Lentille clignotante	1	1	1	1	1	1	
65-21	1426-621-0360-0	BASE, FLASHER UNIT Carter	1	1	1	1	1	1	
65-22	V200-260-6016-0	BOLT/M6 X 16 Vis	1	1	1	1	1	1	
65-23	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	1	1	1	1	1	1	
65-24	V300-260-0060-0	NUT/M6 Erou	1	1	1	1	1	1	
65-25	1421-600-0570-0	LAMP, PILOT G ASSY Témoin optique ensemble	1	1	1	1	1	1	
65-26	1419-621-0150-0	• LENS Verre	1	1	1	1	1	1	Red
65-27	1419-621-0170-0	• GASKET Joint	1	1	1	1	1	1	
65-28	1403-621-0310-0	• BULB/12V-3.4W Ampoule	1	1	1	1	1	1	
65-29	1431-686-2200-0	SWITCH, WARNING ASSY Interrupteur	1	1	1	1	1	1	
65-30	1431-686-2210-0	• BODY, SWITCH Corps d'interrupteur	1	1	1	1	1	1	
65-31	1431-686-2220-0	• NUT/M12 P=1.0 Erou	2	2	2	2	2	2	
65-32	1431-686-2230-0	• WASHER Rondelle	1	1	1	1	1	1	⑭ D ~ #001176 F ~ #003469
65-33	1431-686-2240-0	• WASHER, TOOTHED Rondelle	1	1	1	1	1	1	
65-34	1431-686-2250-0	• VIS, TERMINAL Vis	4	4	4	4	4	4	
65-35	1431-686-2260-0	• CAP, WATERPROOF Chapeau	1	1	1	1	1	1	
65-36	1415-600-0550-0	BOX, FUSE ASSY Boite de fusibles	1	1	1	1	1	1	
65-37	1415-621-0200-0	• FUSIBLE/10A Fusibles	3	3	3	3	3	3	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F.U	F.D	F.DU	L.FDU	
65-38	1415-621-0210-0	• FUSE/5A Fusibles	6	6	6	6	6	6	
65-39	V111-165-0016-0	SCREW/M5 X 16 Vis	2	2	2	2	2	2	
65-40	V401-160-0050-0	WASHER, SP/M5 Rondelle frein	2	2	2	2	2	2	
65-41	V300-260-0050-0	NUT/M5 Erou	2	2	2	2	2	2	
65-42	1407-600-0520-0	SWITCH, KEY ASSY Contacteur	1	1	1	1	1	1	
65-43		• SWITCH, KEY Contacteur	1	1	1	1	1	1	△
65-44	1407-621-0120-0	• KEY Vie de contact	2	2	2	2	2	2	
65-45	1416-621-0020-0	SWITCH, STARTER Commande clignotante	1	1	1	1	1	1	
65-46	1402-621-0130-0	SWITCH, PUSH BUTTON Bouton d'avertisseur	1	1	1	1	1	1	
65-46a	3614-261-2200-0	SWITCH, HORN ASSY Bouton d'avertisseur	1	1	1	1	1	1	④ { D ~ #001176 F ~ #003469
65-47	1403-621-0130-0	SWITCH, LEVER Interrupteur	1	1	1	1	1	1	⑤
65-48	1431-686-0010-0	CAP, BLANK/23 Fausset	1	1	1	1	1	1	
65-49	1423-621-0040-0	LIGHTER, CIGARRET Allume cigare	1	1	1	1	1	1	★
65-50	1431-686-2500-0	SWITCH, FLASHER ASSY Interrupteur	1	1	1	1	1	1	} D #001177 ~ F #003470 ~
65-51		• BODY Corps d'interrupteur	1	1	1	1	1	1	
65-52	1431-686-2520-0	• WASHER Rondelle	2	2	2	2	2	2	
65-53	1431-686-2530-0	• NUT Erou	1	1	1	1	1	1	
65-54	1431-686-2540-0	• LEVER, SWITCH Lévior	1	1	1	1	1	1	

[illegible]

Fig.66 ELECTRICAL SYSTEM(3)

Equipement électrique



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U.	F.DU	L.FDU	
66- 1	1421-621-2000-0	LAMP, HEAD ASSY Phare complet	2	2	2	2	2	
66- 2	1421-621-2010-0	• LENS Verre	2	2	2	2	2	
66- 3	1421-621-2020-0	• SOCKET Emboîture	2	2	2	2	2	
66- 4	1421-621-2030-0	• BULB/12V-25W Ampoule	2	2	2	2	2	
66- 5	V201-261-0020-0	BOLT/M10 X 20 Vis	4	4	4	4	4	
66- 6	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	4	4	4	4	4	
66- 7	1423-600-0520-0	LAMP, WORK ASSY Projecteur de travail	1	1	1	1	1	★
66- 8	1423-621-0050-0	• LENS Verre	1	1	1	1	1	★
66- 9	1423-621-0200-0	• BULB/12-25W Ampoule	1	1	1	1	1	★
66-10	1423-621-0060-0	• STAY Appui	1	1	1	1	1	★
66-11	1423-621-0070-0	• PACKING, LENS Joint	1	1	1	1	1	★
66-12	1423-621-0080-0	• SPRING Resort	1	1	1	1	1	★
66-13	1423-621-0090-0	• LAMP, WORK SET Projecteur de travail	1	1	1	1	1	★
66-14	V413-160-0080-0	WASHER Rondelle	2	2	2	2	2	★
66-15	V202-160-8016-0	BOLT/M8 X 16 Vis	1	1	1	1	1	★
66-16	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	1	1	1	1	1	★
66-17	V300-260-0080-0	NUT/M8 Eccrou	1	1	1	1	1	★
66-18	1431-686-2000-0	LAMP, BLINKER ASSY Clignoteur ensemble	2	2	2	2	2	
66-19	1431-686-2010-0	• LENS Verre	2	2	2	2	2	
66-20	1421-621-0290-0	• GASKET, BASE Joint	2	2	2	2	2	
66-21	V421-160-0050-0	• WASHER, TOOTHED/M5 Rondelle	4	4	4	4	4	
66-22	V300-260-0050-0	• NUT/M5 Eccrou	4	4	4	4	4	
66-23	1421-621-0300-0	• SCREW Vis	4	4	4	4	4	
66-24	1421-621-0310-0	• BULB/12V-20W Ampoule	2	2	2	2	2	
66-25	1421-621-0320-0	• WASHER Rondelle	4	4	4	4	4	
66-26	V413-160-0050-0	• WASHER/M5 Rondelle	4	4	4	4	4	
66-27	1416-621-0050-0	SWITCH, RELAY Interrupteur	1	1	1	1	1	
66-28	V302-260-0080-0	NUT/M8 Eccrou	2	2	2	2	2	
66-29	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
66-30	V200-260-6020-0	BOLT/M6 X 20 Vis	2	2	2	2	2	
66-31	V300-260-0060-0	NUT/M6 Eccrou	2	2	2	2	2	
66-32	V401-160-0060-0	WASHER, SP/M6 Rondelle frein	2	2	2	2	2	
66-33	V413-160-0060-0	WASHER/M6 Rondelle	2	2	2	2	2	
66-34	1416-600-0530-0	SWITCH, SAFETY ASSY Inter de securite	1	1	1	1	1	
66-35	1416-621-0250-0	• BOOT Capote	1	1	1	1	1	
66-36	1416-621-0260-0	NUT/M22 Eccrou	1	1	1	1	1	
66-37	1417-621-0040-0	HOLDER, SWITCH Attache	1	1	1	1	1	
66-38	V201-260-8020-0	BOLT/M6 X 25 Vis	2	2	2	2	2	

Standard for E61

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	F-DU	
66-39	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	
66-40	V413-160-0080-0	WASHER/M8 Rondelle	2	2	2	2	2	
66-41	1423-621-0180-0	CUSHION/RUBBER Cale	4	4	4	4	4	
66-41a	1423-616-0040-0	CUSHION/10 x 25 Cale	4	4	4	4	4	(A)
66-42	2701-101-0520-0	WASHER Rondelle	2	2	2	2	2	
66-43	1423-621-0190-0	BOLT/M6 X 25 Vis	2	2	2	2	2	For regulator setting
66-44	V320-260-0060-0	NUT, SLOTTED/M6 Ecrou à oreilles	2	2	2	2	2	
66-45	V500-151-6015-0	PIN, SPLIT/1.6 X 15 Goupille fendue	2	2	2	2	2	
66-46	V201-260-8016-0	BOLT/M8 X 16 Vis	1	1	1	1	1	For regulator earth
66-47	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	1	1	1	1	1	
66-48	V300-260-0080-0	NUT/M8 Ecrou	1	1	1	1	1	

SERVICE MEMO[illegible]




Fig.67 WIRING DIAGRAM
Cable diagramme






Fig.68 BATTERY SYSTEM


Batterie



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F-U	F-DU	LEBU		
68- 1	1417-621-0010-0	BATTERY/30HR Batterie	1	1	1	1	1	⑤ { S #002633 ~ D #101326 ~ F #004696 ~	
68- 2	1424-112-1003-0	BASE, BATTERY Cuvette de batterie	1	1	1	1	1		
68- 2a	1424-112-1004-0	BASE, BATTERY Cuvette de batterie	1	1	1	1	1		
68- 3	3746-261-2050-0	PLATE Plaque	2	2	2	2	2	⑥	
68- 4	V201-260-8016-0	BOLT/M8 X 16 Vis	4	4	4	4	4		
68- 5	V401-260-0080-0	WASHER, SP/M8 Rondelle frein	6	6	6	6	6		
68- 6	1417-112-0010-0	PLATE, BATTERY SET Étrier de batterie	1	1	1	1	1		
68- 7	1416-112-0020-0	BOLT, BATTERY SET Vis	2	2	2	2	2		
68- 8	V413-160-0060-0	WASHER/M6 Rondelle	2	2	2	2	2		
68- 9	V401-260-0060-0	WASHER, SP/M6 Rondelle frein	2	2	2	2	2		
68-10	V300-260-0060-0	NUT/M6 Ecrou	4	4	4	4	4		
68-11	1423-621-0210-0	STRAP/430 Cable	1	1	1	1	1		
68-12	1417-621-0020-0	CABLE, BATTERY Cable de masse	1	1	1	1	1		
68-13	1402-621-0140-0	COVER, TERMINAL/L50-14 Couvercle	1	1	1	1	1		
68-14	V201-260-8020-0	BOLT/M8 X 20 Vis	2	2	2	2	2		
68-15	V413-160-0080-0	WASHER/M8 Rondelle	3	3	3	3	3		
68-16	1425-621-0010-0	CLAMP, HARNESS Attache faisceau	1	1	1	1	1		

Fig.69 THREE POINT SYSTEM

Attelage trois point




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	L-FDU	
69- 1	1431-566-2000-0	SUPPORT, LW LINK LH Support G.	1	1	1	1	1	
69- 2	1431-566-2100-0	SUPPORT, LW LINK RH Support D.	1	1	1	1	1	
69- 3	V201-461-4035-0	BOLT/M14 X 35 Vis	8	8	8	8	8	
69- 4	V401-160-0140-0	WASHER, SP/M14 Rondelle frein	8	8	8	8	8	
69- 5	1423-511-0010-0	PIN/22 X 90 Goupille	2	2	2	2	2	
69- 6	1421-502-0020-0	PIN, LINK Goupille	2	2	2	2	2	
69- 7	1431-566-2200-0	SUPPORT, LH Support G.	1	1	1	1	1	
69- 8	1431-566-2300-0	SUPPORT, RH Support D.	1	1	1	1	1	
69- 9	V201-461-2030-0	BOLT/M12 X 30 Vis	8	8	8	8	8	
69-10	V401-160-0120-0	WASHER, SP/M12 Rondelle frein	8	8	8	8	8	
69-11	7963-611-0030-0	PIN/12 X 48 Goupille	4	4	4	4	4	
69-12	7957-405-0030-0	PIN, HAIR/12 Attache beta	4	4	4	4	4	
69-13	1417-511-1000-0	LINK, LW Barres inférieures	2	2	2	2	2	
69-14	1404-511-0031-0	BOLT, STABILIZER SET Vis	2	2	2	2	2	
69-14a	7963-611-0010-0	PIN, CHAIN Goupille	2	2	2	2	2	(A)
69-15	V300-260-0160-0	NUT/M16 Erou	2	2	2	2	2	
69-16	V401-160-0160-0	WASHER, SP/M16 Rondelle frein	2	2	2	2	2	
69-17	1417-511-2000-0	LINK, TOP LH THREAD Vis G. de tirant	1	1	1	1	1	
69-17-1	1421-511-3001-0	LINK, TOP LH THREAD Vis G. de tirant	1	1	1	1	1	for G-type
69-18	1404-511-6000-0	LINK, TOP RH THREAD Vis D. de tirant	1	1	1	1	1	
X69-18-1	1444-514-2000-0	LINK, TOP RH THREAD Vis D. de tirant	1	1	1	1	1	for G-type
69-19	1423-511-2000-0	TURNBUCKLE Tendeur de tirant	1	1	1	1	1	
69-19a	1444-514-2900-0	TURNBUCKLE Tendeur de tirant	1	1	1	1	1	(A)
69-20	1402-511-6000-0	NUT, TOP LINK LOCK Frein de tendeur	1	1	1	1	1	
69-21	1402-500-9040-0	PIN, TOP LINK Broche de tirant	1	1	1	1	1	2 used for G-type
69-22	1431-566-0010-0	PIN/19 x 220 Goupille	1	1	1	1	1	
69-23	1421-502-0020-0	PIN, LINK Goupille	4	4	4	4	4	
69-24	1423-511-2100-0	CHAIN, CHECK A Organeau A.	2	2	2	2	2	
69-25	1423-511-2200-0	CHAIN, CHECK B Organeau B.	2	2	2	2	2	
69-26	1423-511-0020-0	TURNBUCKLE, CHAIN Retroir	2	2	2	2	2	
69-27	V300-260-0160-0	NUT/M16 Erou	2	2	2	2	2	
69-28	1416-511-4000-0	CHAIN, LW LINK Chaîne de 3 points	2	2	2	2	2	
69-29	1417-520-1000-0	ROD, LIFT Chape relevage	1	1	1	1	1	
69-30	1404-520-2001-0	FORK, LIFTING RH Cavalier	1	1	1	1	1	
69-31	1404-520-0030-0	SCREW, ADJ RH Vis	1	1	1	1	1	
69-32	1302-726-0050-0	TINE Came	1	1	1	1	1	
69-33	1302-726-0060-0	SPRING, LOCK Resort	1	1	1	1	1	
69-34	1404-520-3000-0	ROD, LIFT Chape de relevage	1	1	1	1	1	

Ref.No. Réf.Nº	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.FDU	
69-35	1404-520-0010-0	WASHER, THRUST Rondelle	1	1	1	1	1	
69-36	1404-520-0020-0	HANDLE, ADJ Poignée	1	1	1	1	1	
69-37	V580-100-6040-0	PIN, SPRING/6 x 40 Goupille élastique	1	1	1	1	1	
69-38	1423-520-0010-0	PIN/16 x 70 Goupille	2	2	2	2	2	
69-38a	1423-520-0011-0	PIN/16 x 63 Goupille	2	2	2	2	2	®
69-39	1305-931-0030-0	PIN, HAIR Attache bote	2	2	2	2	2	
69-40	V761-400-0000-0	NIPPLE, GREASE Graisseur	1	1	1	1	1	
69-41	1431-566-2400-0	SPACER Entretoise	1	1	1	1	1	
69-41-1	1426-580-2300-0	HITCH, TOP LINK	1	1	1	1	1	for G-type
69-42	1402-511-0020-0	PIN, TOP LINK	1	1	1	1	1	for G-type


Fig.70 ACCESSORIES AND TOOLS

Outils



Ref.No. Réf.Nº	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.D	LRDC	
70- 1	1431-570-2000-0	PIN, POINT Goupille	1	1	1	1	1	★
70- 2	V201-461-4032-0	BOLT/M14 X 32 Vis	4	4	4	4	4	★
70- 3	V401-160-0140-0	WASHER, SP/M14 Rondelle frein	4	4	4	4	4	★
70- 4	1431-570-0010-0	DRAWBAR Barre d'attelage	1	1	1	1	1	★
70- 4a	1431-570-0011-0	DRAWBAR Barre d'attelage	1	1	1	1	1	★ ⑤
70- 5	1431-570-2100-0	BRACKET, DRAWBER Support	1	1	1	1	1	★
70- 5a	1431-570-2101-0	BRACKET, DRAWBER Support	1	1	1	1	1	★ ⑤
70- 6	7963-603-0010-0	PIN/19 x 220 Broche	2	2	2	2	2	
70- 6a	1431-566-0010-0	PIN/19 x 220 Broche	2	2	2	2	2	⑤ { D #100511~ E #001571~
70- 7	1402-500-9010-0	PIN, LINK LARGE Goupille	3	3	3	3	3	
70- 7a	1421-502-0020-0	PIN, LINK Goupille	3	3	3	3	3	④
70- 8	1416-509-8000-0	COVER, SHIELD Chapoteau	1	1	1	1	1	
70- 9	V201-261-0016-0	BOLT/M10 x 16 Vis	4	4	4	4	4	
70-10	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	4	4	4	4	4	
70-11	1431-561-2001-0	HITCH, R. LH Support or G.	1	1	1	1	1	
70-11-1	1426-580-2000-0	HITCH, R. LH Support or G.	1	1	1	1	1	for G-type
70-12	1431-561-2101-0	HITCH, R. RH Support or D.	1	1	1	1	1	
70-12-1	1426-580-2100-0	HITCH, R. RH Support or D.	1	1	1	1	1	for G-type
70-13	V201-461-4035-0	BOLT/M14 X 35 Vis	2	2	2	2	2	
70-14	V401-160-0140-0	WASHER, SP/M14 Rondelle frein	8	8	8	8	8	
70-15	V300-460-0140-0	NUT/M14 Eccrou	6	6	6	6	6	
70-16	1422-155-0020-0	COUPLING, CG Couplage	1	1	1	1	1	
70-17	1422-155-0030-0	WASHER, LOCK Rondelle frein	3	3	3	3	3	
70-18	V203-261-2055-0	BOLT/M12 X 55 Vis	3	3	3	3	3	
70-19	1422-155-2300-0	COUPLING, SPLINE Couplage	1	1	1	1	1	
70-20	1422-155-0040-0	BOLT/M12 X 50 Vis	3	3	3	3	3	
70-21	V321-260-0120-0	NUT, SLOTTED/M12 Eccrou à crénelux	3	3	3	3	3	
70-22	V500-153-0030-0	PIN, SPRIT/5 X 45 Goupille fendue	3	3	3	3	3	
70-23	1421-906-0010-0	SPANNER, BOX/22 Cle à pipe	1	1	1	1	1	
70-24	1401-906-0050-0	WRENCH Cle	1	1	1	1	1	
70-25	V920-552-4027-0	SPANNER/24-27 Cle plate	1	1	1	1	1	
70-26	V920-551-9022-0	SPANNER/19-22 Cle plate	1	1	1	1	1	
70-27	V920-551-3017-0	SPANNER/13-17 Cle plate	1	1	1	1	1	
70-28	V920-551-2014-0	SPANNER/12-14 Cle plate	1	1	1	1	1	
70-29	V920-550-8010-0	SPANNER/8-10 Cle plate	1	1	1	1	1	

Fig.71 WEIGHT
Contrepoids




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	D	
71- 1	1423-092-2000-0	WEIGHT, F. WHEEL SET Contrepoids av	1	1					★
71- 2	1404-922-0020-0	•BOLT, F. WEIGHT Vis	8	8					★
71- 3	V300-260-0120-0	•NUT/M12 Eccrou	8	8					★
71- 4	V401-160-0120-0	•WASHER, SP/M12 Rondelle frein	8	8					★
71- 5	1404-922-0030-0	•NUT, F. WEIGHT Eccrou	8	8					★
71- 6	V401-260-0120-0	•WASHER, SP/M12 Rondelle frein	16	16					★
71- 7	V201-261-2055-0	•BOLT/M12 X 55 Vis	8	8					★
71- 8	1325-930-1050-0	•COLLAR Collier	16	16					★
71- 9	1423-092-2100-0	WEIGHT R WHEEL SET Contrepoids ar	1	1	1	1	1		★
71-10	1404-922-0060-0	•COLLAR, R. WEIGHT Collier	16	16	16	16	16		★
71-11	1404-922-1000-0	•BOLT, R. WEIGHT SET Vis	8	8	8	8	8		★
71-12	V401-260-0160-0	•WASHER, SP/M14 Rondelle frein	16	16	16	16	16		★
71-13	V300-260-0160-0	•SP/M16 Eccrou	16	16	16	16	16		★
71-14	1421-922-0010-0	WEIGHT, BALANCE Contrepoids	3	3	3	3	3		★
71-15	W201-261-2055-0	BOLT/M12 X 55 Vis	3	3	3	3	3		★
71-16	V302-260-0120-0	NUT/M12 Eccrou	3	3	3	3	3		★



Fig.72 STEERING GEAR BOX (MECHANICAL)


Boitier de direction



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.FDU	
72- 0-1	1426-406-2003-0	BOX, STEERING ASSY Boîtier de direction	1	1				
72- 1	1426-406-2040-0	• BOX, GEAR ASSY Corps du boîtier	1	1				
72- 2	1426-406-2050-0	• BALL NUT ASSY Axe de direction	1	1				
72- 3	1426-506-2160-0	• BALL BEARING Balle	1	1				
72- 4	1426-406-2170-0	• BEARING, OUT Rondelle	2	2				
72- 5	1426-406-2060-0	• COLUMN Colonne de direction	1	1				
72- 6	1426-406-2080-0	• O-RING Joint torique	1	1				
72- 7	1426-406-2120-0	• SHIM, R. VOER SET Cale	1	1				
72- 8	V401-160-0100-0	• WASHER, SP/M10 Rondelle frein	4	4				
72- 9	V201-461-0028-0	• BOLT/M10 X 28 9T Vis	4	4				
72-10	1426-406-2030-0	• BUSH, COLUMN Bague	1	1				
72-11	V780-100-0004-0	• PLUG/PT ¼ Bouchon	1	1				
72-12	1426-406-2180-0	• SHAFT, SECTOR Axe de balle pendants	1	1				
72-13	1426-406-2140-0	• SHIM, ADJ SCREW SET Cale	1	1				
72-14	1426-406-2130-0	• SCREW, ADJ Vis	1	1				
72-15	1426-406-2070-0	• COVER, SIDE Couvercle	1	1				
72-16	1426-406-2110-0	• PACKING, SIDE COVER Joint	1	1				
72-17	V300-260-0100-0	• NUT/M10 Etrou	1	1				
72-18	1426-406-2150-0	• BOLT, SEMS/M8 X 20 9T Vis	4	4				
72-19	1426-406-2090-0	• SEAL, OIL Bague d'étanchéité	1	1				
72-20	1426-406-2022-0	• ARM, PITMAN Bras pitman	1	1				
72-21	V401-160-0220-0	• WASHER, SP/M22 Rondelle frein	1	1				
72-22	V320-260-0220-0	• NUT, SLOTTED/M22 Etrou à créneaux	1	1				
72-23	V500-155-0045-0	• PIN, SPLIT/5 X 45 Goupille fendue	1	1				

Fig.73 STEERING GEAR BOX(POWER)

Boitier de direction



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	U	
73- 0-1	1426-426-2001-0	BOX, STEERING ASSY Boîtier de direction				1	1	1	Included Ref No. 1~75
73- 0-1a	1426-426-2002-0	BOX, STEERING ASSY Boîtier de direction				1	1	1	⊙ { D #101326~ F #004696~
73- 0-2	1426-426-2300-0	BOX, STEERING SET Boîtier de direction				1	1	1	
73- 0-2a	1426-426-2301-0	BOX, STEERING SET Boîtier de direction				1	1	1	⊙ { D #101326~ F #004696~
73- 1	1426-426-2310-0	• BOX, GEAR Corps du boîtier				1	1	1	
73- 2	1426-426-2320-0	• BEARING, NR Roulement d'étranchéite				1	1	1	
73- 3	1426-426-2330-0	• PACKING, U Joint				1	1	1	
73- 4	1426-426-2340-0	• PLATE, BACK-UP Bague				1	1	1	
73- 5	1426-426-2350-0	• HOLDER, OIL SEAL Griffe				1	1	1	
73- 6	1426-426-2360-0	• SEAL, OIL Bague d'étanchéité				1	1	1	
73- 7	1426-426-2370-0	• COVER, F. Couvercle				1	1	1	
73- 8	1426-426-2380-0	• BEARING, NR Roulement à aiguilles				2	2	2	
73- 9	1426-426-2390-0	• RING Bague				3	3	3	
73-10	1426-426-2810-0	• O-RING/S34 Joint torique				3	3	3	
73-11	V721-103-1045-0	• O-RING/G45 Joint torique				1	1	1	
73-12	V704-140-0500-0	• RING, SNAP/C50 Collier d'axe				1	1	1	
73-13	1426-426-2820-0	• BALL NUT ASSY Vis du boîtier de direction				1	1	1	
73-14	1426-426-2830-0	• RING Bague				1	1	1	
73-15	V721-103-1070-0	• O-RING/G70 Joint torique				1	1	1	
73-16	1426-426-2840-0	• COVER, CYL Couvercle du cylindre				1	1	1	
73-17	V721-103-1075-0	• O-RING/G75 Joint torique				1	1	1	
73-18	1426-426-3090-0	• O-RING/S11.2 Joint torique				4	4	4	
73-19	1426-426-3110-0	• PIPE Tuyau rigide				2	2	2	
73-19a	1426-426-3111-0	• PIPE Tuyau rigide				2	2	2	⊙ { D #101326~ F #004696~
73-20	1426-426-3020-0	• COLLAR, A Bague				1	1	1	
73-21	1426-426-3070-0	• O-RING/S80 Joint torique				2	2	2	
73-22	1426-426-3050-0	• BEARING, THRUST Butée				2	2	2	
73-23	1426-426-2850-0	• VALVE ASSY Soupape				1	1	1	
73-24	1426-426-2860-0	• PISTON, RETURN Piston				8	8	8	
73-25	1426-426-2870-0	• SPRING Ressort				4	4	4	
73-26	1426-426-3040-0	• COLLAR, C Bague				2	2	2	
73-27	1426-426-3030-0	• COLLAR, B Bague				1	1	1	
73-28	1426-426-3060-0	• NUT, LOCK Eccrou				1	1	1	
73-29	V705-140-0370-0	• RING, SNAP/C37 Collet d'axe				1	1	1	
73-30	1426-426-2920-0	• HOLDER Griffe				1	1	1	
73-31	1426-426-2930-0	• SEAL, OIL Bague d'étanchéité				1	1	1	
73-32	1426-426-2910-0	• COVER, R. Couvercle				1	1	1	
73-33	1426-426-3120-0	• BOLT Vis				4	4	4	


Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.FDU	
73-34	V401-160-0120-0	• WASHER, SP/M12 Rondelle frein			8	8	8	
73-35	1426-426-2970-0	• O-RING Joint torique			2	2	2	
73-36	1426-426-3010-0	• SPRING Ressort			1	1	1	
73-37	1426-426-2980-0	• PIN, SPRING Goupille elastique			1	1	1	
73-38	1426-426-2990-0	• RIVET Rivet			1	1	1	
73-39	1426-426-2960-0	• SHAFT, STEERING Axe de direction			1	1	1	
73-40	1426-426-2950-0	• BUSH, COLUMN Bague			1	1	1	
73-41	1426-426-2940-0	• COLUMN Conduite de direction			1	1	1	
73-42	V401-160-0080-0	• WASHER, SP/M8 Rondelle frein			4	4	4	
73-43	1426-426-3140-0	• BOLT/M8 X 20 Vis			4	4	4	
73-44	1426-426-3150-0	• SHAFT, SECTOR Axe de bielle pendante			1	1	1	
73-45	1426-426-3160-0	• SCREW, ADJ Vis			1	1	1	
73-46	1426-426-3170-0	• SHIM, ADJ SCREW Cale			1	1	1	
73-47	1426-426-3080-0	• O-RING/S90 Joint torique			1	1	1	
73-48	1426-426-2890-0	• BEARING, NR Roulement a aiguilles			1	1	1	
73-49	1426-426-2880-0	• COVER, SIDE Couvercle			1	1	1	
73-50	1426-426-3210-0	• PACKING Joint			2	2	2	
73-51	1426-426-3180-0	• NUT Ecrou			1	1	1	
73-52	1426-426-3190-0	• NUT, COVER Ecrou			1	1	1	
73-53	1426-426-3130-0	• BOLT/M12 X 32 Vis			4	4	4	
73-54	1426-426-2011-0	• ARM, PITMAN Bras pitman			1	1	1	
73-55	V401-160-0270-0	• WASHER, SP/M27 Rondelle frein			1	1	1	
73-56	V321-260-0270-0	• NUT, SLOTTED/M27 Ecrou a creneaux			1	1	1	
73-56a	1426-426-3220-0	• NUT, SLOTTED/M27 Ecrou a creneaux			1	1	1	Ⓐ
73-57	V500-155-0050-0	• PIN, SPLIT/5 X 50 Goupille fendue			1	1	1	
73- 0-3	1426-426-2400-0	DIVIDER, FLOW SET Soupape			1	1	1	
73-58	1426-426-2410-0	• BODY Corps			1	1	1	
73-59	1426-426-2420-0	• SPRING Ressort			1	1	1	
73-60	V720-102-4020-0	• O-RING/P20 Joint torique			1	1	1	
73-61	1426-426-2430-0	• PLUG Bouchon			1	1	1	
73-62	1426-426-2440-0	• PIPPET Plaque de robinet			1	1	1	
73-63	1426-426-2450-0	• SPRING Ressort			1	1	1	
73-64	1426-426-2470-0	• SHIM Cale			0	0	0	
73-65	V720-102-4014-0	• O-RING/P14 Joint torique			1	1	1	
73-66	1426-426-2460-0	• PLUG Bouchon			1	1	1	
73-67	1426-426-2700-0	VALVE, CHECK SET Soupape de retenue			1	1	1	
73-68	V401-160-0080-0	WASHER, SP/M8 Rondelle frein			3	3	3	
73-69	1426-426-2050-0	BOLT/M8 X 50 Vis			3	3	3	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F.U	F.D	U	F.D	
73-70	1426-426-2030-0	UNION Raccord de tuyau			1	1	1		
73-71	1426-426-2600-0	PIPE, B SET Tuyau rigide			1	1	1		
73-72	1426-426-2020-0	UNION Raccord de tuyau			2	2	2		
73-73	V720-102-4018-0	O-RING/P18 Joint torique			2	2	2		
73-74	1426-426-2500-0	PIPE, A SET Tuyau rigide			1	1	1		
73-75	1426-426-2040-0	UNION Raccord de tuyau			1	1	1		



Fig.74 CONTROL VALVE

Soupape de controle



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	F.DU	
74- 0-1	1424-505-2300-0	VALVE, CONTROL ASSY Soupape de contrôle	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74- 0-1a	1424-505-2301-0	VALVE, CONTROL ASSY Soupape de contrôle	1	1	1	1	1	
74- 1	1424-505-2310-0	• BODY Corps	1	1	1	1	1	
74- 2	1424-505-2350-0	• VALVE, UNLOAD Robinet de vidange	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74- 3	1424-505-2510-0	• SPRING Ressort	1	1	1	1	1	
74- 4	V720-102-4015-0	• O-RING/P15 HS70 Joint torique	2	2	2	2	2	
74- 5	1424-505-2360-0	• PLUG Bouchon	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74- 6	1424-505-2580-0	• SHAFT Arbre	1	1	1	1	1	
74- 6a	1424-505-2420-0	• SHAFT Arbre	1	1	1	1	1	
74- 7	1424-505-2430-0	• ARM Bras	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74- 8	V580-140-5018-0	• PIN, SPRING/5 x 18 Goupille élastique	2	2	2	2	2	
74- 9	1424-505-2450-0	• LINK Barre	1	1	1	1	1	
74-10	1424-505-2460-0	• RING, SNAP Collet d'axe	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74-11	1424-505-2550-0	• SEAL, OIL Bague d'étanchéité	2	2	2	2	2	
74-12	1424-505-2530-0	• LEVER Lever de commande	1	1	1	1	1	
74-12a	1424-505-2531-0	• LEVER Lever de commande	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74-13	V580-140-5028-0	• PIN, SPRING/5 X 28 Goupille élastique	2	2	2	2	2	
74-14	1424-505-2420-0	• SHAFT Arbre	1	1	1	1	1	
74-15	1424-505-2440-0	• ARM Bras	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74-16	1424-505-0020-0	• GASKET Joint	1	1	1	1	1	
74-17	1424-505-2590-0	• LINK, FEEDBACK Barre	1	1	1	1	1	
74-18	1424-505-2330-0	• CAP Capuchon	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74-19	V401-160-0080-0	• WASHER, SP/M8 Rondelle frein	13	13	13	13	13	
74-20	V201-260-8080-0	• BOLT/M8 X 80 Vis	6	6	6	6	6	
74-21	V720-102-4012-0	• O-RING/P12 HS70 Joint torique	4	4	4	4	4	⊙ { S #002731~ D #101408~ F #005704~
74-22	1424-505-2410-0	• COVER Couvercle	1	1	1	1	1	
74-23	V201-260-8025-0	• BOLT/M8 X 25 Vis	3	3	3	3	3	
74-24	V780-100-0002-0	• PLUG Bouchon	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74-25	1424-505-2380-0	• SEAT Cuvette	1	1	1	1	1	
74-26	V720-102-4010-0	• O-RING/P10A HS70 Joint torique	1	1	1	1	1	
74-27	1424-505-2470-0	• BALL, STEEL Bille	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74-28	1424-505-2490-0	• SPRING Ressort	1	1	1	1	1	
74-29	1424-505-2390-0	• PLUG Bouchon	1	1	1	1	1	
74-30	1424-505-2370-0	• VALVE, RELIEF ASSY Soupape de décharge	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74-31	V720-102-4022-0	• O-RING/P22 HS70 Joint torique	2	2	2	2	2	
74-32	1424-505-2320-0	• LAP ASSY Tige	1	1	1	1	1	
74-33	1424-505-2520-0	• RING SNAP/S Collet d'axe	1	1	1	1	1	⊙ { S #002731~ D #101408~ F #005704~
74-34	1424-505-2480-0	• SPRING, RETURN Ressort	1	1	1	1	1	


Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	L.FDU	
74-35	1424-505-0030-0	• GASKET Joint	1	1	1	1	1	
74-36	1424-505-2340-0	• CAP Capuchon	1	1	1	1	1	
74-37	1424-505-2610-0	• PLATE Plaque	1	1	1	1	1	
74-38	V201-260-8036-0	• BOLT/M8 X 36 Vis	1	1	1	1	1	
74-39	V201-260-8063-0	• BOLT/M8 X 63 Vis	1	1	1	1	1	
74-40	V720-101-9009-0	• O-RING/P9 HS70 Joint torique	1	1	1	1	1	
74-41	1424-505-2540-0	• ADJUSTER ASSY Lever de réglage	1	1	1	1	1	
74-42	1424-505-2560-0	• SCREW Vis	1	1	1	1	1	
74-43	V720-102-4018-0	• O-RING/P18 HS70 Joint torique	1	1	1	1	1	
74-44	1424-505-2570-0	• PLUG Bouchon	1	1	1	1	1	
74-45	V720-102-4016-0	• O-RING/P16 HS70 Joint torique	2	2	2	2	2	

[illegible]




Fig.75 HYDRAULIC SYSTEM (G-type)

Mechanisme de relevage hydraulique



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	LEDU	
75- 1	1426-571-2101-0	CASE, CYL SET Corps de cylindre	1	1	1	1	1	
75- 2	1404-501-0090-0	BUSH/50 Cousinnet	1	1	1	1	1	
75- 3	1404-501-0100-0	BUSH/45 Cousinnet	1	1	1	1	1	
75- 4	1421-207-0030-0	NIPPLE, BREATHER/30 Raccord de tuyau	2	2	2	2	2	
75- 5	1421-501-0060-0	PIPE, BREATHER/7 x 11 x 350 Conduit	1	1	1	1	1	
75- 6	1414-501-0080-0	CAP, OIL Bouchon	1	1	1	1	1	
75- 7	1404-201-0180-0	PACKING, OIL CAP Joint	1	1	1	1	1	
75- 8	V781-100-0006-0	PLUG Bouchon	1	1	1	1	1	
75- 9	V780-100-0002-0	PLUG Bouchon	1	1	1	1	1	
75-10	V300-460-0100-0	NUT/M10 7T Eccrou	5	5	5	5	5	
75-11	V201-461-0030-0	BOLT/M10 x 30 9T Vis	7	7	7	7	7	
75-12	V201-461-0155-0	BOLT/M10 x 155 9T Vis	2	2	2	2	2	
75-13	V201-461-0085-0	BOLT/M10 x 85 9T Vis	1	1	1	1	1	
75-14	V401-160-0100-0	WASHER, SP/M10 Rondelle frein	15	15	15	15	15	
75-15	V251-260-8020-0	STUD/M8 x 20 Goujon	4	4	4	4	4	
75-16	1415-501-0020-0	PACKING, CYL CASE Joint	2	2	2	2	2	
75-17	1426-501-1010-0	PAN, OIL Carter d'huile	1	1	1	1	1	
75-18	1426-571-2001-0	VALVE, RETURN CHECK Robinet de trop-plein retenue	1	1	1	1	1	See Fig. 82
75-19	V201-260-8045-0	BOLT/M8 x 45 Vis	3	3	3	3	3	
75-20	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	3	3	3	3	3	
75-21	V720-112-4014-0	O-RING/P14 Joint torique	3	3	3	3	3	
75-22	1426-571-0020-0	KNOB, SLOW RETURN Bouton	1	1	1	1	1	
75-23	V302-260-0080-0	NUT/M8 Eccrou	1	1	1	1	1	
75-24	1426-571-0030-0	METAL, FILTER Support	1	1	1	1	1	
75-25	V303-260-0080-0	NUT/M8 Eccrou	4	4	4	4	4	
75-26	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
75-27	V720-102-4020-0	O-RING/P20 Joint torique	1	1	1	1	1	
75-28	1426-571-0040-0	FILTER, SUCTION Filtre	1	1	1	1	1	
75-29	1426-571-0050-0	CONNECTOR Raccord	1	1	1	1	1	
75-30	1426-571-0060-0	COVER, SUB CONTROL Couvercle	1	1	1	1	1	
75-31	V201-260-8030-0	BOLT/M8 x 30 Vis	4	4	4	4	4	
75-32	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
75-33	V720-112-4014-0	O-RING/P14 Joint torique	4	4	4	4	4	
75-34	1426-571-0070-0	HOLDER, KNOB Griffe	1	1	1	1	1	
75-35	V201-260-8016-0	BOLT/M8 x 16 Vis	2	2	2	2	2	
75-36	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	3	2	2	2	2	
75-37	V781-100-0006-0	PLUG/PT3/B Bouchon	1	1	1	1	1	

Fig.76 LIFT ARM AND CYLINDER(G-type)
Relevage bras




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U.	F.D.	LED	
76- 1	1426-572-2000-0	CRANK, LIFT Chape	1	1	1	1	1	
76- 2	V580-140-8056-0	PIN, SPRING W/8 x 56 Goupille elastique	1	1	1	1	1	
76- 3		WIRE/1.2 x 100 Fil	1	1	1	1	1	
76- 4	1403-209-0060-0	BOLT/M8 x 20 Vis	1	1	1	1	1	
76- 5		WIRE/1.2 x 200 Fil	1	1	1	1	1	
76- 6	1415-503-0040-0	SHAFT, LIFT Axe de relevage	1	1	1	1	1	
76- 7	V745-145-6009-0	SEAL, OIL/TB 45609 Baguo d'etanchéité	2	2	2	2	2	
76- 8	1431-557-0010-0	ARM, LIFT LH Bras de relevage G.	2	2	2	2	2	
76- 9	1404-502-0080-0	BOLT, LIFT ARM SET Vis	2	2	2	2	2	
76-10	V300-460-0120-0	NUT/M12 Erou	2	2	2	2	2	
76-11	V401-160-0120-0	WASHER, SP/M12 Rondelle frein	2	2	2	2	2	
76-12	1415-503-0030-0	PIN, LIFT ARM Goupille	2	2	2	2	2	
76-13	1404-502-0130-0	BOLT/M8 x 25 Vis	2	2	2	2	2	
76-14	V302-260-0080-0	NUT/M8 Erou	2	2	2	2	2	
76-15	1415-503-2000-0	FORK, LIFT BRACKET Fourch	2	2	2	2	2	
76-16	7963-613-0040-0	PIN/19 x 84 Goupille	2	2	2	2	2	
76-17	1421-502-0020-0	PIN, LINK Goupille	2	2	2	2	2	
76-18	1426-574-0010-0	CYLINDER Cylindre	1	1	1	1	1	
76-19	1426-574-0020-0	PIPE, KNOCK Goupille	2	2	2	2	2	
76-20	V720-112-4014-0	O-RING/P14 HS90 Joint torique	4	4	4	4	4	
76-21	V201-461-2100-0	BOLT/M12 x 100 9T Vis	1	1	1	1	1	
76-22	V201-461-2120-0	BOLT/M12 x 120 9T Vis	1	1	1	1	1	
76-23	V201-461-2130-0	BOLT/M12 x 130 9T Vis	1	1	1	1	1	
76-24	V201-461-2150-0	BOLT/M12 x 150 9T Vis	1	1	1	1	1	
76-25	V401-160-0120-0	WASHER, SP/M12 Rondelle frein	4	4	4	4	4	
76-26	1415-505-0040-0	PISTON Piston	1	1	1	1	1	
76-27	1415-505-0050-0	ROD Tige	1	1	1	1	1	
76-28	1415-505-0060-0	RING, BACK-UP/P65 Rondelle de recul	1	1	1	1	1	
76-29	V720-105-7065-0	O-RING/P65 Joint torique	1	1	1	1	1	
76-30	1426-574-2000-0	VALVE, CONTROL ASSY Soupape de controle	1	1	1	1	1	See Fig. 80
76-31	V201-260-8060-0	BOLT/M8 x 60 Vis	4	4	4	4	4	
76-32	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	4	4	4	4	4	
76-33	V720-112-4012-0	O-RING/P12 HS90 Joint torique	3	3	3	3	3	
76-34	1426-574-2100-0	ARM, UP STOP Lever	1	1	1	1	1	
76-35	1426-574-2200-0	BOSS, UP STOP Bossage	1	1	1	1	1	
76-36	V580-140-5022-0	PIN, SPRING W/5 x 22 Goupille elastique	1	1	1	1	1	
76-37	V580-140-3022-0	PIN, SPRING W/3 x 22 Goupille elastique	1	1	1	1	1	
76-38		WIRE/0.9 x 100 Fil	1	1	1	1	1	
76-39	1426-574-0030-0	SPRING, TORQUE/22 Ressort	1	1	1	1	1	



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	E	D	
77- 1	1426-574-2500-0	CAM, DRAFT Came	1	1	1	1	1	1	
77- 2	1426-574-2600-0	CAM, POSITION Came	1	1	1	1	1	1	
77- 3	V720-101-9010-0	O-RING/P10 Joint torique	1	1	1	1	1	1	
77- 4	V720-102-4018-0	O-RING/P18 Joint torique	1	1	1	1	1	1	
77- 5	1426-574-2700-0	LEVER, DRAFT Lever	1	1	1	1	1	1	
77- 6	V580-140-4030-0	PIN, SPRING W/4 x 30 Goupille elastique	1	1	1	1	1	1	
77- 7		WIRE/0.9 x 100 Fil	1	1	1	1	1	1	
77- 8	1426-574-2800-0	LEVER, POSITION Lever	1	1	1	1	1	1	
77- 9	1432-242-0040-0	GRIP, B Poignée	2	2	2	2	2	2	
77-10	1421-507-0140-0	WASHER/6 x 24 x 2 Rondelle	2	2	2	2	2	2	
77-11	1421-507-0130-0	LINING Rondelle	4	4	4	4	4	4	
77-12	1426-574-0290-0	SPRING, PRESS/28 Resort	2	2	2	2	2	2	
77-13	V200-260-6045-0	BOLT/M6 x 45 Vis	2	2	2	2	2	2	
77-14	V300-260-0060-0	NUT/M6 Ecrou	3	3	3	3	3	3	
77-15	1426-574-2900-0	GUIDE, LEVER Secteur de guidage	1	1	1	1	1	1	
77-16	V201-260-8016-0	BOLT/M8 x 16 Vis	2	2	2	2	2	2	
77-17	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	2	
77-18	1426-574-3001-0	HOLDER, GUIDE Griffe	1	1	1	1	1	1	
77-19	1426-574-0311-0	PACKING, HOLDER Joint	1	1	1	1	1	1	
77-20	V201-260-8016-0	BOLT/M8 x 16 Vis	3	3	3	3	3	3	
77-21	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	3	3	3	3	3	3	
77-22	1421-507-0161-0	BOLT, LEVER SET Vis	2	2	2	2	2	2	
77-23	1421-507-0170-0	COLLAR/9 x 14 x 8 Collier	2	2	2	2	2	2	
77-24	V370-160-0080-0	NUT, WING/M8 Ecrou	1	1	1	1	1	1	
77-25	V401-160-0080-0	WASHER, SP/M8 Rondelle frein	2	2	2	2	2	2	
77-26	V303-260-0080-0	NUT/M8 Ecrou	1	1	1	1	1	1	
77-27	1426-574-2300-0	ARM, SPOOL Bras	1	1	1	1	1	1	
77-28	1426-574-0080-0	ROD, B Belle	1	1	1	1	1	1	
77-29	V302-260-0080-0	NUT/M8 Ecrou	1	1	1	1	1	1	
77-30	V580-140-6016-0	PIN, SPRING/W6 x 16 Goupille elastique	2	2	2	2	2	2	

Fig.78 SPRING CASE SYSTEM (G-type)
Carter de ressort




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	LEDE	
78- 1	1426-574-0090-0	ARM, POSITION Bras	1	1	1	1	1	
78- 2	1426-574-0110-0	ROD, C Bielles	1	1	1	1	1	
78- 3	1432-506-0320-0	WASHER/18 Rondelle	1	1	1	1	1	
78- 4	1426-574-0120-0	SPRING, PRESS/37 Ressort	1	1	1	1	1	
78- 5	V413-160-0060-0	WASHER/M6 Rondelle	1	1	1	1	1	
78- 6	V704-140-0100-0	RING, SNAP/C 10 Collet d'axe	1	1	1	1	1	
78- 7	V500-152-5015-0	PIN, SPLIT Goupille fendue	1	1	1	1	1	
78- 8	1432-506-0030-0	SPRING, TENSION/107 Ressort	1	1	1	1	1	
78- 9	V201-260-8020-0	BOLT/M8 x 20 Vis	1	1	1	1	1	
78-10	1426-574-2400-0	ARM, ROD Bras	1	1	1	1	1	
78-11	V704-140-0100-0	RING, SNAP/C 10 Collet d'axe	1	1	1	1	1	
78-12	1426-574-0130-0	ARM, DRAFT Bras	1	1	1	1	1	
78-13	1426-574-0140-0	ROD Bielles	2	2	2	2	2	
78-14	V302-260-0080-0	NUT/M8 Eccrou	2	2	2	2	2	
78-15	1426-574-0150-0	ROD, DRAFT Bielles	1	1	1	1	1	
78-16	1426-574-0160-0	SPRING, PRESS/112 Ressort	1	1	1	1	1	
78-17	1432-506-0090-0	HOLDER, ROD A Griffe	1	1	1	1	1	
78-18	1432-506-0110-0	HOLDER, ROD B Griffe	1	1	1	1	1	
78-19	V704-140-0100-0	RING, SNAP/C 10 Collet d'axe	3	3	3	3	3	
78-20	V580-140-3016-0	PIN, SPRING W/3 x 18 Goupille élastique	1	1	1	1	1	
78-21		WIRE/0.9 x 50 Fil	1	1	1	1	1	
78-22	1426-574-0170-0	BOSS, DRAFT Bessant	1	1	1	1	1	
78-23	V580-140-5030-0	PIN, SPRING W/5 x 30 Goupille élastique	1	1	1	1	1	
78-24		WIRE/0.9 x 150 Fil	1	1	1	1	1	
78-25	1426-574-0180-0	HOLDER, SPRING A Griffe	1	1	1	1	1	
78-26	1426-574-0190-0	HOLDER, SPRING B Griffe	1	1	1	1	1	
78-27	1432-506-0170-0	STOPPER, SPRING Pastille	1	1	1	1	1	
78-28	1432-506-0180-0	WASHER/27 x 48 x 6 Rondelle	1	1	1	1	1	
78-29	1426-574-0210-0	X-RING Anneau d'étanchéité	1	1	1	1	1	
78-30	1426-574-0220-0	SPRING, PRESS/68 Ressort	1	1	1	1	1	
78-31	1426-574-0230-0	CASE, SPRING A Carter de ressort	1	1	1	1	1	
78-32	1426-574-0240-0	CASE, SPRING B Carter de ressort	1	1	1	1	1	
78-33	1426-574-0250-0	PACKING, CASE A Joint	1	1	1	1	1	
78-34	1426-574-0260-0	PACKING, CASE B Joint	1	1	1	1	1	
78-35	1426-574-0270-0	SEAL, DUST Bague d'étanchéité	1	1	1	1	1	
78-36	V201-461-0030-0	BOLT/M10 x 30 9T Vis	4	4	4	4	4	
78-36	V201-460-8025-0	BOLT/M8 x 25 9T Vis	2	2	2	2	2	
78-38	V401-160-0100-0	WASHER, SP/M10 Rondelle fin	4	4	4	4	4	

Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	U	
78-39	V401-160-0080-0	WASHER, SP/M8 Rondelle train	2	2	2	2	2		
78-40	1426-574-0280-0	STOPPER, HOLDER Parrille	1	1	1	1	1		
78-41	V201-260-8016-0	BOLT/M8 x 16 Vis	2	2	2	2	2		
78-42	V401-160-0080-0	WASHER, SP/M8 Rondelle train	2	2	2	2	2		
78-43	1426-574-0040-0	ARM, SPOOL Bras	1	1	1	1	1		
78-44	1426-574-0050-0	ROD, A Bielle	1	1	1	1	1		
78-45	1426-574-0060-0	SPRING, PRESS/23 ressort	1	1	1	1	1		
78-46	1432-506-0320-0	WASHER/18 Rondelle	1	1	1	1	1		
78-47	V500-152-5015-0	PIN, SPLIT/2.5 x 15 Goupille fendue	1	1	1	1	1		
78-48	V413-160-0060-0	WASHER/M6 Rondelle	1	1	1	1	1		
78-49	1426-574-0070-0	SPRING, TENSION/47 Rondelle	1	1	1	1	1		
78-50	V704-140-0100-0	RING, SNAP/C 10 Collet d'axe	1	1	1	1	1		


[illegible]

Fig.79 SUB CONTROL SYSTEM (G-type) LEVER
Levier de sous-commande



For two sub control valve (G2)

For one sub control valve (G1)




Ref.No. Réf.Nº	Parts No. Pièces Nº	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F.U	F.DU	LEDC	
79- 1	1426-584-2000-0	VLAVE, SUB CONTROL ASSY <i>Sous-contrôle</i>	2	2	2	2	2	★ G1....1 pce.
79- 2	V201-460-8105-0	BOLT/M8 x 105 <i>Vis</i>	4	4	4	4	4	★ For G2
79-2-1	V201-460-8065-0	BOLT/M8 x 65 <i>Vis</i>	4	4	4	4	4	★
79- 3	V401-160-0080-0	WASHER, SP/M8 <i>Rondelle frein</i>	4	4	4	4	4	★
79- 4	V720-112-4014-0	O-RING/P14 HS90 <i>Joint torique</i>	10	10	10	10	10	★ G1....5 pcs.
79- 5	1426-584-0010-0	COVER, C-PORT <i>Couvercle</i>	2	2	2	2	2	★ G1....1 pce.
79- 6	V200-260-6016-0	BOLT/M6 x 16 <i>Vis</i>	8	8	8	8	8	★ G1....4 pcs.
79- 7	V401-160-0060-0	WASHER, SP/M6 <i>Rondelle frein</i>	8	8	8	8	8	★ G1....4 pcs.
79- 8	1426-584-2200-0	BASE <i>Socle</i>	1	1	1	1	1	★
79- 9	V201-260-8020-0	BOLT/M8 x 20 <i>Vis</i>	2	2	2	2	2	★
79-10	V461-160-0080-0	WASHER, SP/M8 <i>Rondelle frein</i>	2	2	2	2	2	★
79-11	1426-584-2300-0	BOSS, SUB CONTROL A <i>Bossage</i>	1	1	1	1	1	★
79-12	1426-584-2400-0	BOSS, SUB CONTROL B <i>Bossage</i>	1	1	1	1	1	★ For G2
79-13	1426-584-2500-0	LEVER, SUB CONTROL A <i>Lever</i>	1	1	1	1	1	★ For G2
79-14	1426-584-2600-0	LEVER, SUB CONTROL B <i>Lever</i>	1	1	1	1	1	★
79-15	V580-140-3022-0	PIN, SPRING/3 x 22 <i>Goupille élastique</i>	1	1	1	1	1	★ For G2
79-16	1403-209-0060-0	BOLT/M8 x 20 <i>Vis</i>	1	1	1	1	1	★
79-17		WIRE/0.9 x 150 <i>Fil</i>	2	2	2	2	2	★
79-18	1432-242-0040-0	GRIP, B <i>Poignée</i>	2	2	2	2	2	★




Fig.80 CONTROL VALVE(G-type)

Soupape de controle




Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant					Remarks Remarques
			S	D	F-U	F-DU	LFDC	
80-0-1	1426-574-2000-0	VALVE, CONTROL ASSY Soupape de contrôle	1	1	1	1	1	
80-1	1432-505-2011-0	• CASE Corps de soupape	1	1	1	1	1	
80-2	1432-501-2470-0	• PLUG/PT 1/8 Bouchon	2	2	2	2	2	
80-3	1432-505-2020-0	• COVER, A Couvercle	1	1	1	1	1	
80-4	1432-505-2030-0	• RUSH Manchon	1	1	1	1	1	
80-5	1432-505-2040-0	• PLUG, A Bouchon	3	3	3	3	3	
80-6	V720-112-4012-0	• O-RING/P12 HS90 Joint toropix	3	3	3	3	3	
80-7	V200-360-8016-0	• BOLT/M8 x 16 7T Vis	5	5	5	5	5	
80-8	1432-505-2050-0	• SPRING, E Ressort	1	1	1	1	1	
80-9	1432-505-2060-0	• SEAT, SPRING B Coupelle de ressort	1	1	1	1	1	
80-10	V710-140-0070-0	• RING, SNAP/F-1 Carter d'axe	2	2	2	2	2	
80-11	1432-505-2070-0	• SPRING, A Ressort	1	1	1	1	1	
80-12	1432-505-2080-0	• SPRING, B Ressort	1	1	1	1	1	
80-13	1432-505-2090-0	• SEAT, SPRING D Coupelle de ressort	1	1	1	1	1	
80-14	1432-505-2110-0	• BALL Bille	1	1	1	1	1	
80-15	1432-505-2120-0	• SPRING, C Ressort	1	1	1	1	1	
80-16	1432-505-2131-0	• SEAT, SPRING A Coupelle de ressort	1	1	1	1	1	
80-17	1432-505-2141-0	• SEAT, SPRING C Coupelle de ressort	1	1	1	1	1	
80-18	1432-505-2151-0	• BODY Corps	1	1	1	1	1	
80-19	1432-505-2160-0	• PLUG, RELIEF Bouchon de clapet de décharge	1	1	1	1	1	
80-20	1432-505-2170-0	• SCREW, ADJ Vis	1	1	1	1	1	
80-21	1432-505-2180-0	• SPRING, D Ressort	1	1	1	1	1	
80-22	V720-440-4008-0	• BOLT/M4 x 8 Vis	1	1	1	1	1	
80-23	1432-505-2190-0	• COVER, B Couvercle	1	1	1	1	1	
80-24	V302-260-0060-0	• NUT/M6 Ecran	1	1	1	1	1	
80-25	1432-505-2210-0	• NUT Ecran	1	1	1	1	1	
80-26	1432-505-2220-0	• SPRING, F Ressort	1	1	1	1	1	
80-27	1432-505-2230-0	• SEAT, SPRING E Coupelle de ressort	1	1	1	1	1	
80-28	1426-574-2010-0	• COLLAR Collier	1	1	1	1	1	
80-29	V200-360-8030-0	• BOLT/M8 x 30 Vis	1	1	1	1	1	
80-30	1432-505-2240-0	• SLEEVE Douille	1	1	1	1	1	

Fig.81 SUB CONTROL VALVE(G-type)
Soupape de sous-contrôle



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F	U	F	U	
81-0-1	1426-584-2000-0	VALVE, SUB CONTROL ASSY Soupape de contrôle	2	2	2	2	2	2	
81- 1	1426-584-2010-0	• CASE Corps de soupape	2	2	2	2	2	2	
81- 2	1426-584-2020-0	• PLUG Bouchon	4	4	4	4	4	4	
81- 3	1426-584-2030-0	• COVER, A Couvercle	2	2	2	2	2	2	
81- 4	1426-584-2040-0	• COVER, B Couvercle	2	2	2	2	2	2	
81- 5	1426-584-2050-0	• PACKING, A Joint	2	2	2	2	2	2	
81- 6	1426-584-2060-0	• PACKING, B Joint	2	2	2	2	2	2	
81- 7	V220-240-6012-0	• BOLT/M6 x 12 Vis	12	12	12	12	12	12	
81- 8	1426-584-2070-0	• SPRING Ressort	2	2	2	2	2	2	
81- 9	1426-584-2080-0	• SEAT, SPRING Coupelle de ressort	4	4	4	4	4	4	
81-10	1426-584-2090-0	• STOPPER Pastille	2	2	2	2	2	2	
81-11	V580-140-5018-0	• PIN, SPRING/W5 x 18 Goupille élastique	2	2	2	2	2	2	

Fig.82 RETURN CHECK VALVE(G-type)
Robinet de trop-plein retenue



Ref.No. Réf.Nº.	Parts No. Pièces Nº.	Description Désignation	Model & Q'ty Modél & Quant						Remarks Remarques
			S	D	F-U	F-DU	L-E	L-E	
82-0-1	1426-571-2001-0	VALVE, RETURN CHECK ASSY Robinet de trop-plein retenue	1	1	1	1	1		
82- 1	1432-501-2310-0	• CASE Corps de robinet	1	1	1	1	1		
82- 2	1432-501-2320-0	• COVER Couvercle	1	1	1	1	1		
82- 3	1432-501-2330-0	• SEAL, OIL Bague d'étanchéité	1	1	1	1	1		
82- 4	V220-440-6012-0	• BOLT/M6 x 12 BT Vis	2	2	2	2	2		
82- 5	1432-501-2340-0	• SCREW, ADJ/MB Vis de butée	1	1	1	1	1		
82- 6	V720-112-4006-0	• O-RING/P6 Joint torique	1	1	1	1	1		
82- 7	1432-501-2350-0	• SPRING A Ressort	1	1	1	1	1		
82- 8	1432-501-2360-0	• PLUG Bouchon	1	1	1	1	1		
82- 9	V720-112-4012-0	• O-RING/P12 Joint torique	1	1	1	1	1		
82-10	1432-501-2370-0	• BALL Bille	1	1	1	1	1		
82-11	1432-501-2380-0	• SPRING B Ressort	1	1	1	1	1		
82-12	1432-501-2390-0	• SEAT, SPRING A Coupelle de ressort	1	1	1	1	1		
82-13	1432-501-2410-0	• SEAT, SPRING B Coupelle de ressort	1	1	1	1	1		
82-14	1432-501-2420-0	• BODY Corps	1	1	1	1	1		
82-15	1432-501-2430-0	• VALVE, RELIEF Clapet de décharge	1	1	1	1	1		
82-16	1432-501-2440-0	• PACKING Joint	1	1	1	1	1		
82-17	1432-501-2450-0	• SCREW ADJ/M6 Vis d'ajustement	1	1	1	1	1		
82-18	V302-260-0060-0	• NUT/M6 Ecrou	1	1	1	1	1		
82-19	1432-501-2460-0	• NUT, CAP Ecrou-raccord	1	1	1	1	1		
82-20	1432-501-2470-0	• PLUG/PT 1/8 Bouchon	1	1	1	1	1		
82-21	1432-501-2480-0	• RING, BACK-UP	1	1	1	1	1		

NUMERICAL INDEX

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
		5681-121-5031-1	4-6	5681-411-1003-2	11-1
		5681-131-1024-0	3-1	5681-414-1006-0	11-20
5614-561-9024-0	17-18	5681-131-2011-0	2-29	5681-431-9100-0	11-92
		5681-131-9056-0	13-51	5681-531-1006-0	12-2
5640-962-3013-0	17-29	5681-136-0132-0	4-1	5681-533-0003-0	12-3
5640-962-3016-0	19-40	5681-151-0010-0	6-1	5681-541-1058-0	12-21
		5681-154-0010-0	6-1	5681-541-1059-0	12-22
5641-561-9004-0	17-27	5681-156-0010-0	6-1	5681-541-1223-0	12-36
5641-561-9024-0	17-18, 17-19	5681-176-0053-1	4-36	5681-541-1257-0	12-31
5641-562-2001-0	17-43	5681-177-7004-0	13-41		
5641-562-2003-0	17-47	5681-211-1119-0	6-3	5681-560-0645-1	14-5, 17-0-1
5641-562-9001-0	17-48	5681-211-4119-0	6-3	5681-561-1032-0	17-5
5641-563-9003-0	16-67	5681-211-6119-0	6-3	5681-561-9053-0	17-95
5641-563-9008-0	17-20, 17-21,	5681-212-1010-0	6-4, 6-4-1	5681-563-9002-0	17-164
	17-121,	5681-212-4010-0	6-4, 6-4-1	5681-572-0110-1	14-15,
	18-10, 18-69	5681-212-6010-0	6-4, 6-4-1		18-0-1
5641-563-9009-0	17-153	5681-221-1009-0	6-6	5681-572-1007-0	18-5
5641-572-3020-0	18-67	5681-223-0028-0	6-8	5681-572-1008-0	18-30
5641-572-5021-0	18-104	5681-223-5006-0	6-11	5681-572-3614-0	18-73
5641-572-9006-0	17-28	5681-227-1005-0	6-13	5681-572-9002-0	17-150
5641-575-9001-0	17-113,	5681-231-0080-0	6-14	5681-572-9113-0	18-41
5641-575-9002-0	19-18 ¹⁹⁻³³	5681-233-6002-0	6-34	5681-575-0004-0	14-20,
5641-575-9003-0	19-35	5681-251-1022-0	7-1		19-0-1
		5681-251-9002-1	7-9	5681-575-1002-0	19-5
5648-121-5005-0	21-33	5681-252-4037-0	14-42	5681-575-4001-0	19-14
		5681-253-5005-0	7-24	5681-931-0002-0	16-50
5670-009-0229-0	18-58	5681-253-9001-0	14-49	5681-975-1003-0	14-38
5670-980-1103-0	8-92	5681-256-1011-0	7-33	5685-588-5362-0	14-50
		5681-256-3017-0	7-36	5688-111-5012-0	21-25
5680-900-0018-1	6-33	5681-256-5004-0	7-38	5688-112-8026-0	20-8
5680-900-0069-0	7-8	5681-256-9004-0	1-11	5688-112-8028-0	20-18
5680-900-0084-0	7-26	5681-257-5015-0	7-44	5688-112-9021-0	20-77
5680-900-0088-0	10-33-2	5681-320-0016-0	8-70	5688-112-9022-0	20-107
5680-900-0089-0	10-33-3	5681-323-1001-0	8-81	5688-112-9023-0	20-111
5680-900-9036-0	1-22a	5681-361-0076-1	10-1	5688-112-9024-0	20-24
5680-903-0015-0	3-17, 13-52-4	5681-362-0005-0	10-11	5688-120-0272-0	15-2a, 21A-0-1
5680-958-7001-0	6-7	5681-363-1005-0	10-6	5688-120-0273-0	15-2
5680-962-3003-0	16-55	5681-364-2016-0	10-13	5688-121-1024-0	21A-20
5680-963-7013-0	10-76	5681-366-0234-0	10-54	5688-121-4033-0	21A-25
5680-963-7015-0	11-76	5681-367-1040-0	10-64	5688-121-5008-0	21A-30
5680-980-1001-0	6-19	5681-371-6028-0	10-90	5688-121-8009-0	21A-39
		5681-372-1028-0	2-93	5688-121-9005-0	21-27
5681-111-0096-0	1-1	5681-374-3021-0	10-91	5688-121-9006-0	21-41
5681-117-0142-1	1-29	5681-377-0022-1	10-72	5688-122-1030-0	21A-5

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
5688-122-2032-0	21A-75	5690-197-1035-0	8-96	5690-916-4508-0	7-68, 8-94,
5688-122-9042-0	21A-90-1	5690-204-0610-0	11-88		11-48, 11-81
5688-241-0012-1	15-7	5690-205-0616-0	4-29	5690-916-4708-0	13-38
5688-588-5355-0	8-102	5690-205-0812-0	5-26	5690-918-0019-0	7-61
5688-588-5357-0	4-44	5690-205-0814-0	9-6	5690-920-1056-0	2-12
5688-588-5359-0	8-103	5690-205-0818-0	13-42	5690-920-1318-0	2-9
5688-688-5375-0	1-50	5690-205-0825-0	5-41	5690-920-1328-0	2-10
5688-781-0037-0	8-72	5690-252-2801-0	7-6	5690-920-1345-0	2-10-1
5690-009-0066-0	17-77	5690-309-0816-0	10-18	5690-920-2308-0	1-5
5690-009-0233-0	17-76	5690-410-0848-0	11-3	5690-920-2721-0	8-84
5690-009-0667-0	3-63	5690-411-0820-0	3-5	5690-922-0605-0	2-26
5690-009-7011-0	8-32	5690-411-0820-0	3-5-1	5690-957-1316-0	10-81
5690-081-3023-0	18-74	5690-411-0822-0	2-33	5690-957-1408-0	12-33
5690-104-5875-0	5-14	5690-411-0830-0	11-21	5690-957-2014-0	8-77, 12-24
5690-104-5895-0	11-52-1	5690-411-0840-0	3-5	5690-960-0082-0	4-42
5690-105-0850-0	5-14-1,	5690-800-0718-0	7-7	5690-960-2070-0	4-42
	7-64	5690-803-0743-0	6-36	5690-960-6535-0	2-54
5690-105-5650-0	10-59	5690-815-1030-0	2-31	5690-965-1068-0	8-82
5690-105-5855-0	3-17-2,	5690-815-1222-0	4-5, 6-17	5690-966-1005-0	10-79
	13-52-1	5690-816-1032-0	2-37	5690-966-2012-0	4-3
5690-105-5870-0	13-52	5690-911-0408-0	16-68	5690-966-4034-0	1-10, 2-8
5690-105-5875-0	3-24	5690-911-0508-0	3-23, 7-67,	5690-970-7130-0	12-100
5690-105-6055-0	10-33-4		11-77, 13-40,	5690-972-0541-0	8-75
5690-106-5845-0	4-42		13-53	5690-972-0542-0	8-73
5690-106-5880-0	4-42	5690-911-0510-0	2-87	5690-974-2109-0	8-83
5690-165-6245-0	13-34	5690-911-1508-0	7-54	5690-980-0684-0	2-84
5690-171-1066-0	1-8	5690-912-0412-0	13-31	5690-980-2514-0	1-22
5690-190-0612-0	3-4	5690-915-0505-0	12-19	5690-980-2539-0	12-19
5690-190-0818-0	18-14	5690-915-0506-0	4-30, 10-61,	5690-980-2591-0	2-2
5690-190-0820-0	10-92		11-87	5690-980-2606-0	6-64
5690-190-0822-0	2-32,	5690-915-0508-0	3-19, 3-25,	5690-981-4014-0	10-7
	10-92-1		4-43, 5-15,	5690-983-0212-0	1-34
5690-190-0835-0	8-101		5-27, 9-7,	5690-986-0522-0	1-4
5690-190-0845-0	8-101-1		10-8, 11-49,	5690-986-4015-0	2-11
5690-191-0816-0	7-12		11-78, 13-43,	5690-987-8084-0	5-8
5690-191-0820-0	13-37		13-55, 16-69	5690-990-2299-0	2-36
5690-191-0828-0	10-77	5690-915-0510-0	2-86, 2-88,	5690-990-6105-1	9-3
5690-191-0830-0	13-36		10-34	5690-990-6314-1	12-32
		5690-915-0512-0	13-30	5690-990-6325-0	19-32
5690-191-1020-0	13-13	5690-915-0608-0	8-93	5690-990-6325-1	12-23
5690-191-1030-0	2-84-1	5690-916-0512-0	13-33	5690-991-3846-0	12-27
5690-193-1235-0	2-84-2	5690-916-0610-0	17-162	5690-991-5644-1	10-94
5690-196-0835-0	11-52	5690-916-4508-0	5-16, 7-66,	5690-992-0255-0	8-76

Parts No. Pièces No.	Ref No. Réf No.	Parts No. Pièces No.	Ref No. Réf No.	Parts No. Pièces No.	Ref No. Réf No.
5690-992-0525-0	8-29	5691-177-7152-1	13-41-1	5691-362-1076-0	10-12
5690-992-0576-0	14-40	5691-225-1062-0	6-9	5691-363-9001-0	10-9
5690-992-0609-0	4-37	5691-233-0809-0	6-25	5691-364-1624-0	
5690-992-0651-0	4-4	5691-233-3036-1	6-27	5691-364-2078-0	10-51
5690-992-0841-0	8-24	5691-236-2019-0	6-38	5691-366-2145-1	10-54-1
5690-992-0843-0	1-6	5691-237-0807-0	6-60	5691-367-5804-0	10-41
5690-992-0900-0	9-4			5691-371-3064-1	10-71
5690-992-4448-0	3-9	5691-252-1042-0	6-37	5691-372-1134-1	10-93
5690-992-4449-0	2-78	5691-252-3080-0	7-22	5691-414-6090-0	11-46
5690-994-0582-0	8-33	5691-252-5801-0	3-61	5691-432-0652-1	11-66
5690-994-0607-0	7-59	5691-253-1024-0	7-21	5691-433-4640-0	11-84
5690-994-2600-0	11-79	5691-253-3801-0	3-62	5691-531-5026-0	12-7
		5691-255-1802-0	7-31	5691-531-5027-0	12-6
5691-112-9006-0	1-3, 2-6-3	5691-255-2801-0	7-32	5691-531-5028-0	12-8
5691-112-9081-0	1-3-1	5691-255-9008-0	7-37	5691-531-5074-0	12-9
5691-112-9082-0	1-3-2	5691-257-1801-0	7-43	5691-541-9072-0	12-19
5691-112-9083-0	1-3-3	5691-261-1347-0	7-51	5691-542-1612-0	12-15
5691-114-5624-0	1-21	5691-261-1349-0	7-51-1	5691-542-1613-0	12-16
5691-115-0801-0	1-14	5691-261-6023-0	7-53	5691-542-1614-0	12-17
5691-117-3137-0	1-49	5691-262-1127-0	7-56	5691-572-9001-0	18-116
5691-117-5011-0	1-35	5691-262-6005-0	7-57	5691-572-9002-0	18-117
5691-117-9030-0	1-32	5691-262-8093-0	7-58	5691-971-1601-0	13-11
5691-117-9105-0	1-31	5691-310-0637-0	5-1	5691-973-2075-0	15-23
5691-121-0058-1	2-1	5691-311-3086-0	5-13	5691-975-5018-0	8-91
5691-121-9005-0	2-6-1	5691-311-9609-0	5-10	5698-121-3207-0	17-93
5691-121-9006-0	2-6-2	5691-312-0601-0	5-6	5698-121-5061-0	17-119
5691-121-9195-0	2-6	5691-312-8079-0	5-7	5698-121-5078-0	17-151
5691-125-8108-0	2-99	5691-314-1604-1	5-23	5698-121-5115-0	17-15
5691-131-1806-0	2-28	5691-314-3603-0	5-22	5698-121-5146-0	17-145
5691-131-2046-0	3-8	5691-316-0068-0	8-28	5698-121-5330-0	17-23
5691-131-2803-0	3-14	5691-316-0081-0	8-6	5698-121-5336-0	17-66
5691-132-1137-0	3-2	5691-320-1812-1	8-1	5698-121-5332-0	17-25
5691-132-2066-0	3-3	5691-321-2804-0	8-80	5698-121-3206-0	17-22
5691-132-2083-0	3-22	5691-321-3601-0	8-74	5698-121-5004-0	17-152
5691-132-7045-0	3-12	5691-321-9077-0	8-100	5698-121-5180-0	17-24
5691-134-1809-0	2-81	5691-324-0804-0	8-2	5698-122-1209-0	17-46
5691-136-7603-0	4-17	5691-326-0604-0	8-86	5698-122-1220-0	17-45
5691-158-1057-0	6-2	5691-326-3011-0	8-34	5698-122-1225-0	17-49
5691-168-1010-0	7-11	5691-331-2325-0	9-1	5698-122-3106-0	17-75
5691-171-5054-0	1-7	5691-331-2335-0	9-2	5698-122-5019-0	18-115
5691-172-1113-0	1-9	5691-361-2053-0	10-16	5698-122-5041-0	17-90
5691-172-1159-0	1-9-1	5691-361-3607-0	10-17	5698-122-5045-0	17-83
5691-175-0043-0	1-30	5691-361-4043-0	10-31	5698-122-5057-0	17-61

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
5698-122-5058-0	17-60	5698-135-1205-0	19-9	5698-223-3208-0	21-75
5698-122-5059-0	17-82	5698-135-1303-0	19-10	5698-223-5060-0	21-90
5698-123-1404-0	17-57	5698-135-1310-0	19-17	5698-223-5072-0	21A-90
5698-123-3104-0	17-31	5698-135-1403-0	19-16	5698-223-5074-0	21A-80
5698-123-5003-0	17-62	5698-135-1602-0	19-26	5698-225-0113-0	15-4
5698-123-5015-0	17-58	5698-135-1702-0	19-28	5698-251-1978-0	15-12
5698-123-5016-0	17-59	5698-135-2104-0	19-44	5698-253-0101-0	15-14
5698-123-5017-0	17-16	5698-135-5023-0	19-11	5698-841-0200-0	18-54
5698-123-5034-0	18-47	5698-135-5025-0	19-42	5698-841-0222-0	17-163
5698-124-1303-0	17-34	5698-135-5031-0	19-27	5698-841-0265-0	17-44
5698-124-1406-0	17-36	5698-135-5035-0	19-12		
5698-124-3101-0	17-32	5698-135-5076-0	19-31	5699-344-0612-0	11-91
5698-124-5014-0	17-35	5698-139-1108-0	18-36		
5698-131-5062-0	18-8	5698-139-1307-0	18-89		
5698-131-5065-0	18-13	5698-139-1507-0	17-146		
5698-131-5191-0	18-96	5698-139-1608-0	18-7		
5698-131-5214-0	18-9	5698-139-1703-0	17-147		
5698-132-1189-0	18-40	5698-139-1907-0	18-42		
5698-132-1205-0	18-81	5698-139-3204-0	18-68		
5698-132-1220-0	18-83	5698-210-0608-0	20-0-1		
5698-132-1310-0	18-50	5698-210-0608-1	15-1, 20-0-1a		
5698-132-1660-0	18-64	5698-211-1384-0	20-65		
5698-132-1705-0	18-94	5698-211-1654-0	20-37		
5698-132-1713-0	18-100	5698-211-1731-0	20-35		
5698-132-1721-0	18-77	5698-211-1298-0	20-23		
5698-132-2282-0	18-63	5698-211-3901-0	20-31		
5698-132-5030-0	18-88	5698-211-5362-0	20-105		
5698-132-5062-0	18-103	5698-211-5433-0	20-32, 20-66		
5698-132-5097-0	18-85	5698-211-6120-0	20-85		
5698-132-5112-0	18-70	5698-211-6149-0	20-30		
5698-132-5173-0	18-84	5698-212-3104-0	20-6		
5698-132-5181-0	18-95	5698-212-3204-0	20-55		
5698-132-5182-0	18-26	5698-212-6107-0	20-50		
5698-132-5200-0	18-18	5698-212-6108-0	20-52		
5698-132-5237-0	18-19	5698-215-0503-0	20-80		
5698-132-5301-0	17-108,	5698-215-0503-1	20-80a		
	17-111,	5698-215-5307-0	20-104		
	18-52	5698-221-5926-0	21-31		
5698-132-5318-0	18-86	5698-222-3109-0	21-5		
5698-132-5397-0	18-15	5698-223-1109-0	21-20		
5698-132-5488-0	18-90	5698-223-1307-0	21-51		
5698-132-6112-0	18-27	5698-233-1308-0	21A-50		
5698-132-6124-0	18-11	5698-223-1619-0	21A-27		

Parts No. Pièces No.	Ref No. Réf No.	Parts No. Pièces No.	Ref No. Réf No.	Parts No. Pièces No.	Ref No. Réf No.
1302-225-0030-0	42-8, 50-26	1403-312-0030-0	55-20	1404-621-0300-0	64-28
1302-726-0050-0	69-32	1403-621-0130-0	65-47	1404-922-0020-0	71-2
1302-726-0060-0	69-33	1403-621-0310-0	65-10, 65-19, 65-28	1404-922-0030-0	71-5
1305-241-0010-0	24-18, 62-32			1404-922-0060-0	71-10
1305-931-0030-0	69-39	1404-101-0010-0	44-18, 44-24, 44-31	1404-922-1000-0	71-11
1317-621-0020-0	64-27	1404-117-0080-0	46-20	1405-131-0040-0	62-11
		1404-120-0090-0	38-9, 39-9, 40-9, 41-9, 41A-7	1405-131-0050-0	62-12
1325-930-1050-0	71-8			1405-401-0060-0	29-28
1326-616-0010-0	25-15, 62-17	1404-201-0180-0	57-9, 58-9, 75-7	1405-502-0050-0	59-24, 59A-24
1326-706-0020-0	38-11, 39-41, 40-11, 41-63, 41A-19, 52-12	1404-301-0100-0	53-12	1406-926-3020-0	59-51
1326-708-0050-0	29-25	1404-301-0090-0	53-13	1407-111-0010-0	45-2
		1404-312-0050-0	54-10, 55-10	1407-117-0070-0	46-19
		1404-312-0060-0	44-8, 44-27, 54-17, 55-17	1407-207-0040-0	51-10
1376-402-0030-0	64-29	1404-317-0050-2	63-7, 63-15	1407-207-0050-0	51-11
		1404-401-0170-0	27-27, 29-13	1407-303-0010-0	50-36
1401-122-0050-0	44-5, 54-15, 55-15	1404-402-0010-0	35-18	1407-303-0020-0	50-33
1401-201-0160-0	51-24, 51-31, 51-39	1404-402-0050-0	35-21	1407-303-0030-0	50-34
1401-211-0100-0	38-19, 39-19, 40-19, 41-19, 41A-23	1404-501-0090-0	59-8, 59A-8, 75-2	1407-303-0040-0	50-37
		1404-501-0100-0	59-7, 59A-7, 75-3	1407-310-0060-0	56-11, 56A-11
1401-304-0120-0	54-24, 55-24	1404-502-0080-0	59-14, 59A-14, 76-9	1407-402-0010-0	29-2
1401-906-0050-0	70-24	1404-502-0130-0	59-17, 59A-17, 76-13	1407-406-0020-0	35-6, 36-6
1402-500-9010-0	59-22, 70-7			1407-406-0040-0	35-7, 36-7
1402-500-9040-0	69-21	1404-503-0010-0	57-25, 58-25	1407-501-0090-0	57-27, 58-27
1402-501-0170-0	51-13	1404-503-0060-0	60-41, 61-47	1407-600-0520-0	65-42
1402-511-0020-0	69-42	1404-503-0080-0	60-13	1407-621-0040-0	65-12
1402-511-6000-0	69-20	1404-503-0090-0	60-14	1407-621-0050-0	65-7
1402-621-0130-0	65-46	1404-511-0031-0	69-14	1407-621-0070-0	65-9
1402-621-0140-0	68-13	1404-511-6000-0	69-18	1407-621-0120-0	65-44
		1404-520-0010-0	69-35		
1403-201-0060-0	47-21	1404-520-0020-0	69-36	1411-411-0020-0	30-1
1403-207-0010-0	51-16	1404-520-0030-0	69-31	1411-411-0030-0	30-2
1403-209-0060-0	59-5, 59A-5, 76-4, 79-16	1404-520-2001-0	69-30	1411-716-0040-0	47-36
1403-312-0030-0	44-11, 54-20,	1404-520-3000-0	69-34		
		1404-621-0270-0	45-24	1412-204-0030-0	48-45, 48A-38, 49-53, 49A-46

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
1414-117-0040-0	46-17	1415-120-0150-0	40-51, 41-51,	1415-125-0190-0	41B-52
1414-117-0050-0	46-18		41A-53	1415-125-0240-0	41A-24
1414-207-0050-0	51-17	1415-120-0160-0	40-33, 41-33,	1415-125-0250-0	41A-30
1414-312-0020-0	44-37, 54-32,		41A-35	1415-125-0260-0	41B-3
	55-32	1415-120-0170-0	40-34, 41-34,	1415-125-0271-0	41B-29
1414-501-0080-0	57-10, 58-10,		41A-36	1415-125-0290-0	41B-57
	75-6	1415-120-0180-0	40-46, 41-46,	1415-125-0310-0	41B-18
1414-501-0100-0	29-17		41A-48	1415-125-0320-0	41A-31
1414-616-0010-0	54-36, 55-36	1415-120-0190-0	40-49, 41-49,	1415-125-0350-0	41B-14
1414-632-0050-0	62-29		41A-51	1415-125-0360-0	41B-31
		1415-120-0200-0	41A-47	1415-125-2001-0	41B-46
1415-101-0100-0	24-15	1415-120-0210-0	40-47, 41-47,	1415-201-0030-0	47-14
1415-101-0180-0	24-2		41A-49	1415-201-0050-0	47-18
1415-101-0400-0	24-13	1415-120-0220-0	40-40, 41-40,	1415-201-0060-0	47-19
1415-102-0090-0	45-15		41A-42	1415-201-0070-0	47-20
1415-102-0100-0	45-16	1415-120-0230-0	40-39, 41-39,	1415-201-0080-0	47-24
1415-102-0120-0	45-18		41A-41	1415-201-0090-0	47-25
1415-102-0130-0	45-19	1415-120-0240-0	40-41, 41-41,	1415-201-0140-0	53-22
1415-111-0010-0	45-27		41A-43	1415-201-0150-0	53-23
1415-111-0020-0	45-28	1415-120-0250-0	40-42, 41-42,	1415-201-0160-0	53-24
1415-111-2000-0	45-25		41A-44	1415-201-0190-0	47-33
1415-116-0071-0	46-4	1415-120-0260-0	40-52,	1415-203-0020-0	49-2, 49A-2
1415-120-0020-0	40-45, 41-45		41A-54,	1415-203-0030-0	49-4, 49A-4
1415-120-0030-0	40-18, 41-18		51-52	1415-203-0040-0	49-7, 49A-9
1415-120-0040-0	40-24, 41-24,	1415-120-2000-0	40-44, 41-44,	1415-204-0010-0	48-1, 48A-1
	41A-29		41A-46	1415-205-0020-0	48-17, 49-24
1415-120-0050-0	40-23, 41-23,	1415-120-3000-0	40-43, 41-43,	1415-205-0030-0	48-18, 49-25
	41A-28		41A-45	1415-205-0060-0	48-23, 49-30
1415-120-0060-0	38-24, 39-24,	1415-121-0010-0	38-18, 39-18	1415-205-0080-0	48A-19,
	40-25, 41-25	1415-121-0040-0	38-25, 39-25		48A-23
1415-120-0080-0	40-28, 41-28	1415-121-0050-0	38-26, 39-26		48-26, 48-30,
1415-120-0090-0	40-30, 41-30,	1415-121-0060-0	38-27, 39-27		49A-26,
	41A-32	1415-121-0090-0	38-32, 39-32		49A-30,
1415-120-0100-0	40-38, 41-38,	1415-121-2000-0	38-30, 39-30		49-33, 49-37
	41A-40	1415-122-0010-0	44-16, 44-30	1415-205-0110-0	48A-21,
1415-120-0110-0	40-32, 41-32,	1415-122-0020-0	44-20		48-28
	41A-34	1415-122-6000-0	44-26		49A-28,
1415-120-0120-0	40-37, 41-37,	1415-125-0051-0	41B-1		49-35
	41A-39	1415-125-0061-0	41B-2	1415-205-0120-0	48A-22,
1415-120-0130-0	40-35, 41-35,	1415-125-0080-0	41B-32		48-29
	41A-37	1415-125-0130-0	41B-28		49A-29,
1415-120-0140-0	40-50, 41-50,	1415-125-0160-0	41B-41		49-36
	41A-52	1415-125-0171-0	41B-43	1415-205-0130-0	48A-24,

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
1415-205-0130-0	48-31, 49A-31, 49-38	1415-312-0031-0	54-28, 55-28	1415-600-0550-0	65-36
		1415-312-3000-0	54-6, 55-6	1415-621-0100-0	65-11
		1415-312-4001-0	54-13, 55-13	1415-621-0160-0	64-14
1415-205-0150-0	48A-26, 48-33, 49A-33, 49-40	1415-312-5000-0	44-4, 54-16, 55-16	1415-621-0200-0	65-37
		1415-312-6000-0	44-6, 54-9, 55-9	1415-621-0210-0	65-38
1415-205-0160-0	33-5, 48A-27, 48-34, 49A-34, 49-41	1415-401-0020-0	29-4	1416-101-0070-0	23-5
		1415-401-0030-0	29-7	1416-101-0110-0	23-3, 23-28
		1415-401-0040-0	29-6	1416-101-0120-0	23-7
		1415-401-0050-0	27-11	1416-101-0130-0	23-8
		1415-501-0020-0	57-2, 58-2, 75-16	1416-101-0140-0	23-6
1415-205-0170-0	48-16, 49-23			1416-112-0020-0	68-7
1415-205-0180-0	48-21, 49-28	1415-501-2001-0	57-1	1416-116-0040-0	46-10
1415-207-0043-0	48A-34, 48-41, 49A-42, 49-49	1415-503-0020-0	59-10, 59A-10	1416-120-0020-0	38-14, 39-14, 40-14, 41-14
		1415-503-0030-0	59-20, 59A-20, 76-12	1416-120-0030-0	38-15, 39-15, 40-15, 41-15, 41A-14
1415-207-0061-0	47-38			1416-120-0040-0	38-23, 39-23
1415-207-0071-0	47-39	1415-503-0040-0	59-1, 59A-1, 76-6	1416-120-0060-0	46-2
1415-207-0090-0	48A-36, 48-43, 49A-44, 49-51	1415-503-1000-2	59-23, 59A-23	1416-207-0040-0	51-9
		1415-503-2000-0	59-19, 59A-19, 76-15	1416-216-0040-0	42-12, 50-28
1415-208-0020-0	51-2			1416-303-2000-0	54-21, 55-21
1415-209-1000-0	51-18			1416-506-0030-0	60-32
1415-210-0010-0	51-27	1415-505-0020-0	57-22, 58-22	1416-506-0040-0	60-33
1415-210-0020-0	41B-40, 51-28, 51-36, 51-42	1415-505-0030-0	57-16, 58-16	1416-509-8000-0	70-8
		1415-505-0040-0	57-18, 58-18, 76-26	1416-511-4000-0	69-28
1415-210-0030-0	51-23	1415-505-0050-0	57-17, 58-17, 76-27	1416-600-0530-0	66-34
1415-213-0010-0	50-4			1416-600-0550-0	45-31
1415-216-0060-0	41B-37, 41B-44, 50-11	1415-505-0060-0	57-19, 58-19, 76-28	1416-621-0020-0	65-45
		1415-505-0080-0	59A-31, 59-33	1416-621-0050-0	66-27
1415-303-0010-0	54-22, 55-22			1416-621-0250-0	66-35
1415-306-0030-2	52-16	1415-505-0090-0	59-36	1416-621-0260-0	66-36
1415-306-0040-0	52-17	1415-505-0100-0	59-37	1416-621-0270-0	45-34
1415-306-0060-0	52-18	1415-505-0110-0	59-38	1416-621-0370-0	45-32
1415-306-0070-0	52-4	1415-505-0120-0	59-42	1416-621-0440-0	65-1
1415-307-0020-0	52-14	1415-505-0130-0	59-46		
1415-310-0030-0	56-2	1415-505-0140-0	60-22, 61-22	1417-012-2000-0	44-0-1
1415-312-0021-0	54-27, 55-27	1415-505-1001-0	59-30	1417-012-2100-0	44-0-3
				1417-100-0510-0	45-0-1
				1417-100-0521-0	38-0-1, 39-0-1
				1417-102-0030-0	45-22

Parts No. Pièces No.	Ref No. Réf No.	Parts No. Pièces No.	Ref No. Réf No.	Parts No. Pièces No.	Ref No. Réf No.
1417-102-0050-0	24-20, 45-23	1417-310-1000-0	56-6, 56A-6	1421-400-0540-0	35-17
1417-102-0090-0	45-8	1417-310-2000-0	56-12,	1421-403-0010-0	35-14
1417-111-2000-0	45-26		56A-12	1421-403-0020-0	35-13
1417-112-0010-0	68-6	1417-310-3000-0	56-13,	1421-403-0030-0	35-19
1417-120-0021-0	40-26, 41-26		56A-13	1421-501-0060-0	57-12, 58-12,
1417-120-1002-0	40-29, 41-29	1417-310-4000-0	56-8		75-5
1417-121-0021-0	38-22, 39-22	1417-310-5000-0	56-9	1421-502-0020-0	59-22a,
1417-121-1001-0	38-29, 39-29	1417-317-1000-2	63-3, 63-14		59A-22, 69-6,
1417-125-0020-0	41B-22	1417-401-0010-0	27-8		69-23, 70-7a,
1417-200-0511-0	53-30	1417-503-0010-0	59-13,		76-17
1417-201-0020-0	47-17		59A-13	1421-503-0050-0	60-39
1417-201-0050-0	47-29	1417-511-1000-0	69-13	1421-503-0060-0	60-40
1417-201-0080-2	47-32	1417-511-2000-0	69-17	1421-503-4320-0	60-2
1417-201-2000-0	53-30a	1417-520-1000-0	69-29	1421-503-4330-0	60-3
1417-203-0010-0	49-1, 49A-1	1417-621-0010-0	68-1	1421-503-4350-0	60-5
1417-203-0011-0	49A-1a	1417-621-0020-0	68-12	1421-503-4360-0	60-6
1417-203-0020-0	49-14,	1417-621-0040-0	66-37	1421-503-4370-0	60-7, 61-12
	49A-14			1421-503-4380-0	60-8, 61-6
1417-204-0010-0	48-4, 48A-4	1419-310-0020-0	56-2a, 56A-2	1421-503-4390-0	60-9
1417-205-0040-0	48-27, 49-34	1419-621-0150-0	65-26	1421-503-4410-0	60-10
1417-205-0050-0	48-32, 49-39	1419-621-0160-0	65-16	1421-503-4420-0	60-11
1417-211-0010-0	48A-30,	1419-621-0170-0	65-17, 65-27	1421-503-4430-0	60-12
	48-37,	1419-621-0180-0	65-18	1421-507-0130-0	59A-34,
	49A-47,				77-11
	49-54	1421-101-0010-0	24-16	1421-507-0140-0	59A-35,
1417-212-2000-0	49A-40	1421-101-0030-0	24-6		77-10
	49-47	1421-101-0130-0	23-12	1421-507-0161-0	77-22,
1417-216-0010-0	50-24	1421-111-2100-0	45-5		59A-39
1417-216-0040-0	50-20	1421-116-0010-0	46-5	1421-507-0170-0	59A-40,
1417-216-2000-0	50-10	1421-116-0020-0	46-6		77-23
1417-223-0010-0	49-1-1	1421-116-0030-0	46-9	1421-511-3001-0	69-17-1
	49A-1-1	1421-116-2000-0	46-9-1	1421-600-0510-0	62-21
1417-223-0011-0	49A-1-1a	1421-122-0030-0	56A-31	1421-600-0570-0	65-25
1417-223-0020-0	49-14-1	1421-207-0030-0	57-11, 75-4	1421-601-0030-0	25-9
1417-306-0010-0	52-1	1421-207-0040-0	51-10a	1421-601-0080-0	25-33
1417-306-0020-0	52-2	1421-207-0050-0	51-3a	1421-601-0090-0	25-34
1417-306-0030-0	52-5	1421-208-1000-0	51-20	1421-601-0110-0	25-28
1417-307-0010-0	53-31	1421-208-1001-0	51-20a	1421-601-0111-0	25-28a
1417-310-0010-0	56-1, 56A-1	1421-212-0040-0	50-9	1421-601-0120-0	25-29
1417-310-0020-0	56-14,	1421-301-0120-0	33-20a	1421-601-0121-0	25-29a
	56A-14	1421-312-0020-0	54-3, 55-3,	1421-602-0010-0	26-2
1417-310-0030-0	56-7, 56A-7		57-26, 58-26	1421-602-0030-0	26-13
1417-310-0040-0	56-5, 56A-5	1421-400-0520-0	35-5, 36-5	1421-602-0040-0	26-14

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
1421-602-0050-0	26-20	1421-906-0010-0	70-23	1423-602-0010-0	26-22
1421-602-0051-0	26-20a	1421-922-0010-0	71-14	1423-602-4001-0	23-14
1421-602-0070-0	26-27			1423-603-0010-0	37-12
1421-602-0080-0	23-19	1422-151-2120-0	22-6	1423-603-0020-0	37-13
1421-602-0090-0	26-52	1422-152-2210-0	23-10, 23-21	1423-606-0010-0	62-16
1421-602-0110-0	26-12	1422-152-2310-0	23-9, 23-23	1423-606-2000-0	62-1
1421-602-4001-0	26-11	1422-152-2320-0	23-11, 23-24	1423-606-2001-1	62-1a
1421-602-7000-0	26-49	1422-155-0020-0	70-16	1423-606-2041-0	62-38
1421-602-8000-0	26-26	1422-155-0030-0	70-17	1423-606-3000-1	62-3
1421-603-0010-0	37-10	1422-155-0040-0	70-20	1423-606-3001-1	62-3a
1421-603-0040-0	37-11	1422-155-2300-0	70-19	1423-616-0040-0	66-41a
1421-606-0030-0	62-12a	1422-355-0020-0	56A-26	1423-621-0010-0	65-8
1421-611-0010-0	62-22	1422-355-0030-0	56A-30	1423-621-0040-0	65-49
1421-611-0020-0	62-23	1422-355-2300-0	56A-22	1423-621-0050-0	66-8
1421-611-0030-0	62-24	1422-355-2500-0	56A-35	1423-621-0060-0	66-10
1421-611-0040-0	62-30	1422-940-0080-0	37-2a	1423-621-0070-0	66-11
1421-621-0070-0	64-19	1422-940-0090-0	37-20a	1423-621-0080-0	66-12
1421-621-0081-0	64-17			1423-621-0090-0	64-13
1421-621-0160-0	64-7	1423-031-2000-0	54-1, 55-1	1423-621-0150-0	64-8
1421-621-0190-0	64-9	1423-092-2000-0	71-1	1423-621-0180-0	66-41
1421-621-0290-0	66-20	1423-092-2100-0	71-9	1423-621-0190-0	66-43
1421-621-0300-0	66-23	1423-101-0030-0	24-12	1423-621-0200-0	66-9
1421-621-0310-0	66-24	1423-101-0040-0	23-4, 23-27	1423-621-0210-0	68-11
1421-621-0320-0	66-25	1423-101-0060-0	22-11	1423-621-2010-0	64-4
1421-621-0360-0	64-30	1423-117-0010-0	46-24	1423-901-0030-0	25-17
1421-621-0380-0	64-26	1423-312-0010-0	54-2, 55-2	1423-904-0030-0	37-19
1421-621-0390-0	25-41	1423-400-0520-0	35-16		
1421-621-0410-0	25-42	1423-505-2100-0	59-30a	1424-101-0020-0	22-7
1421-621-2000-0	66-1	1423-511-0010-0	69-5	1424-101-0030-0	22-8
1421-621-2010-0	66-2	1423-511-0020-0	69-26	1424-101-0040-0	22-9
1421-621-2020-0	66-3	1423-511-2000-0	69-19	1424-101-0050-0	22-10
1421-621-2030-0	66-4	1423-511-2100-0	69-24	1424-101-2030-0	22-3
1421-621-2100-0	25-39	1423-511-2200-0	69-25	1424-101-2040-0	22-4
1421-621-2200-0	25-40	1423-520-0011-0	69-38a	1424-102-0020-0	45-35
1421-621-2300-0	64-33	1423-520-0010-0	69-38	1424-102-0030-0	45-22a
1421-903-0060-0	37-5	1423-600-0520-0	66-7	1424-111-1000-0	26-43
1421-903-0160-0	35-8, 36-8	1423-601-0030-0	25-16	1424-111-1001-0	26-43a
1421-903-0190-0	37-2	1423-601-0040-0	25-24	1424-111-2000-0	26-44
1421-903-0220-0	37-20	1423-601-0050-0	25-22	1424-111-2001-0	26-44a
1421-904-0030-0	37-3	1423-601-0060-0	25-37	1424-111-3000-0	45-1
1421-904-0040-0	37-18	1423-601-0080-0	25-38	1424-112-1003-0	68-2
1421-904-0050-0	37-21	1423-601-2000-0	25-11	1424-112-1004-0	68-2a
1421-904-0190-0	46-28	1423-601-3000-0	25-12	1424-116-1000-0	46-1

Parts No. Pièces No.	Ref No. Réf No.	Parts No. Pièces No.	Ref No. Réf No.	Parts No. Pièces No.	Ref No. Réf No.
1424-117-1000-0	46-16	1424-505-2360-0	74-5	1424-952-0040-0	48A-40,
1424-120-0012-0	38-1, 40-1	1424-505-2370-0	74-30		49A-50
1424-122-0011-0	44-34	1424-505-2380-0	74-25	1424-953-0010-0	29-60, 31-24
1424-122-1000-0	44-1	1424-505-2390-0	74-29		
1424-122-2000-0	44-3	1424-505-2410-0	74-22	1425-101-0010-0	24-1
1424-122-2100-0	44-26a	1424-505-2420-0	74-6a, 74-14	1425-101-0020-0	24-19
1424-125-0030-0	41B-42	1424-505-2430-0	74-7	1425-101-1000-0	24-14
1424-201-0010-0	47-28	1424-505-2440-0	74-15	1425-102-0010-0	45-4, 45-4a
1424-201-0020-0	47-13	1424-505-2450-0	74-9	1425-116-0010-0	46-14
1424-202-0010-0	47-12	1424-505-2460-0	74-10	1425-132-0013-0	39-1, 41-1
1424-205-0010-0	48A-16,	1424-505-2470-0	74-27	1425-132-0021-0	39-43, 41-61,
	49A-23	1424-505-2480-0	74-34		41A-67
1424-211-1000-0	48A-33,	1424-505-2490-0	74-28	1425-132-0070-0	42-3
	48-40	1424-505-2510-0	74-3	1425-132-0080-0	42-2
1424-212-1000-0	49A-39,	1424-505-2520-0	74-33	1425-132-0091-0	42-6
	49-46	1424-505-2530-0	74-12	1425-132-0110-0	42-10
1424-216-0010-0	50-24a	1424-505-2531-0	74-12a	1425-132-0120-0	42-23
1424-303-0010-0	50-42	1424-505-2540-0	74-41	1425-132-0130-0	42-20
1424-303-2000-0	50-31	1424-505-2550-0	74-11	1425-132-0140-0	43-9
1424-312-2000-0	54-29, 55-29	1424-505-2560-0	74-42	1425-132-0141-0	43-9a
1424-500-0512-0	59-26	1424-505-2570-0	74-44	1425-132-0150-0	43-6
1424-503-0010-0	59-2, 59A-2	1424-505-2580-0	74-6	1425-132-0160-0	43-1
1424-505-0010-0	59-26A	1424-505-2590-0	74-17	1425-132-0170-0	43-2
1424-505-0020-0	59-26B,	1424-505-2610-0	74-37	1425-132-2000-0	42-15
	74-16	1424-505-2700-0	60-1	1425-132-2100-0	42-17
1424-505-0030-0	59-26C,	1424-505-2710-0	60-4	1425-132-2200-0	42-22
	74-35	1424-604-0010-0	26-50, 61-44	1425-132-2300-0	43-8
1424-505-0040-0	59-26J	1424-604-4001-0	26-38	1425-134-0010-0	41A-1
(1424-505-0050-0)		1424-606-1000-0	62-9	1425-134-0030-0	41A-21
1424-505-0060-0	57-13, 58-13	1424-606-2000-0	62-10	1425-134-0060-0	41B-4
1424-505-0081-0	59A-30	1424-904-0011-0	59-52	1425-134-0070-0	41A-55
1424-505-2100-0	60-36, 61-36	1424-951-0010-0	29-54	1425-134-0080-0	41A-56
1424-505-2101-0	60-36a,	1424-951-0020-0	29-55	1425-134-0090-0	41B-60
	61-36a	1424-951-0030-0	29-56	1425-135-0010-0	41A-20
1424-505-2300-0	59-53,	1424-951-0040-0	29-57	1425-139-0010-0	42-30
	74-0-1	1424-951-0050-0	31-18	1425-139-0020-0	42-29
1424-505-2301-0	59A-26,	1424-951-0060-0	31-19	1425-139-0030-0	42-31
	74-0-1a	1424-951-0070-0	31-20	1425-139-0040-0	39-34, 41-53,
1424-505-2310-0	74-1	1424-951-0080-0	31-21		41A-59
1424-505-2320-0	74-32	1424-951-0090-0	29-58	1425-139-0050-0	39-35, 41-54,
1424-505-2330-0	74-18	1424-951-0110-0	29-59		41A-60
1424-505-2340-0	74-36	1424-951-0140-0	31-22	1425-231-0010-0	47-24-1
1424-505-2350-0	74-2	1424-951-0150-0	31-23	1425-403-2200-0	29-26

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
1425-403-2201-0	27-26a	1425-433-0151-0	32-8a	1425-601-1000-1	25-1
1425-406-0010-0	35-12	1425-433-0170-0	34-25	1425-602-2020-0	26-53
1425-421-0050-0	33-7	1425-433-0180-0	34-21	1425-602-2030-0	26-54
1425-421-0090-0	33-3	1 25-433-0190-0	34-9	1425-604-2001-0	26-37
1425-422-2201-0	29-10	1425-433-0210-0	34-17	1425-604-2100-0	26-51
1425-422-2202-0	29-10a	1425-433-0220-0	34-16	1425-606-0010-0	62-35
1425-422-2301-0	29-11	1425-433-0221-0	34-16a	1425-621-0020-0	64-13
1425-422-2302-0	29-11a	1425-433-0230-0	34-12	1425-621-0030-0	64-16
1425-428-2000-1	30-6	1425-433-0240-0	32-14,	1425-621-0040-0	68-16
1425-431-0031-0	31-1		32-14a	1425-940-0060-0	50-17b
1425-431-0040-0	31-16	1425-433-0250-0	32-15		
1425-431-0060-0	33-10	1425-433-0260-0	32-16	1426-012-3000-0	44-0-2
1425-431-0070-0	33-9	1425-433-0271-0	32-28	1426-012-3100-0	44-0-4
1425-431-0080-0	33-4	1425-433-0281-0	32-29	1426-120-2001-0	40-0-1,
1425-431-0110-0	31-2	1425-433-0291-0	32-32		41-0-1,
1425-431-0120-0	31-3	1425-433-0310-0	29-53, 32-9		41A-0-1
1425-431-0130-0	31-4	1425-433-2000-0	29-48, 32-36	1426-120-2002-0	40-0-1a,
1425-431-0140-0	33-12	1425-433-2200-0	32-12		41-0-1a,
1425-431-0141-0	33-12a	1425-433-2201-0	32-12a		41A-0-1a
1425-431-0150-0	33-15	1425-433-2300-0	32-13	1426-120-2100-0	40-31, 41-31,
1425-431-0160-0	33-13	1425-433-2301-0	32-13a		41A-33
1425-431-0170-0	33-20	1425-433-2302-0	32-13b	1426-120-2201-0	40-36, 41-36,
1425-431-0180-0	33-17	1425-433-2401-0	32-21		41A-38
1425-431-0190-0	33-18	1425-433-2402-0	32-21a	1426-120-2202-0	40-36a,
1425-431-0210-0	33-14	1425-433-2501-0	32-22		41-36a,
1425-431-2000-0	33-1	1425-433-2502-0	32-22a		41A-38a
1425-431-2001-0	33-1a	1425-436-0020-0	28-6	1426-125-0021-0	41B-30
1425-432-0010-0	31-14	1425-436-0021-0	28-6a	1426-125-0030-0	41B-19
1425-432-0020-0	31-8	1425-436-2200-0	28-10	1426-125-0040-0	41B-36
1425-432-2002-0	31-7	1425-436-2201-0	28-10a	1426-125-0050-0	41B-34
1425-433-0011-0	32-1	1425-436-2220-0	28-12	1426-125-0060-0	41B-51
1425-433-0020-0	34-36	1425-436-2221-0	28-12a	1426-125-2000-0	41B-48
1425-433-0030-0	34-33	1425-436-2300-0	28-5	1426-128-2000-0	44-1-1
1425-433-0041-0	32-2	1425-436-2301-0	28-5a	1426-128-2400-0	44-26-1
1425-433-0050-0	34-28	1425-437-0010-0	36-15	1426-202-0010-0	53-17
1425-433-0060-0	34-24	1425-438-2001-1	34-1, 34-5	1426-202-0021-0	53-21
1425-433-0070-0	34-29	1425-505-3000-0	60-37	1426-204-0011-0	48-10,
1425-433-0080-0	32-6	1425-505-4000-0	60-38, 61-38		48A-10,
1425-433-0081-0	32-6a	1425-505-4100-0	60-24		49-17,
1425-433-0090-0	32-7	1425-505-4200-0	60-16		49A-17
1425-433-0130-0	34-22	1425-600-0511-0	64-15	1426-204-0022-0	48-12,
1425-433-0131-0	34-22a	1425-601-0010-0	25-5		48A-12,
1425-433-0150-0	32-8	1425-601-0020-0	25-7		49-19,

Parts No. Pièces No.	Ref No. Réf No.	Parts No. Pièces No.	Ref No. Réf No.	Parts No. Pièces No.	Ref No. Réf No.
1426-204-0022-0	49A-19	1426-261-0020-0	48A-17,	1426-426-0020-0	29-45, 32-34,
1426-204-0031-0	48-11,		49A-24		36-16
	48A-11,	1426-261-0030-0	48A-39,	1426-426-2001-0	36-1, 73-0-1
	49-18,		49A-21	1426-426-2002-0	36-1a,
	49A-18	1426-261-0040-0	48A-20,		73-0-1a
1426-204-0040-0	48-9, 48A-9,		49A-27	1426-426-2011-0	73-54
	49-16,	1426-261-0050-0	48A-25,	1426-426-2020-0	73-72
	49A-16		49A-32,	1426-426-2030-0	73-70
1426-204-0050-0	48-3, 48A-3,		53-15	1426-426-2040-0	73-75
	49-13,	1426-301-0060-0	53-20	1426-426-2050-0	73-69
	49A-13	1426-301-0070-0	53-19	1426-426-2100-0	29-47, 32-35,
1426-204-0080-0	48-8, 48A-8,	1426-354-0010-0	56A-29		36-18
	49-15,	1426-354-0011-0	56A-29a	1426-426-2120-0	29-50, 32-38,
	49A-15	1426-354-2000-0	56A-19		36-20
1426-205-0020-0	48-19, 49-26	1426-354-2100-0	56A-8	1426-426-2200-0	36-19
1426-205-0031-0	48-20, 49-27	1426-354-2200-0	56A-9	1426-426-2300-0	73-0-2
1426-205-0040-0	48-25, 49-32	1426-354-2300-0	56A-36	1426-426-2301-0	73-0-2a
1426-205-0051-0	48-46, 49-21	1426-402-0010-0	29-12	1426-426-2310-0	73-1
1426-205-0060-0	48A-18,	1426-402-0011-0	29-12a	1426-426-2320-0	73-2
	48-24,	1426-403-0020-0	29-40	1426-426-2330-0	73-3
	49A-25,	1426-406-2003-0	35-1	1426-426-2340-0	73-4
	49-31		72-0-1	1426-426-2350-0	73-5
1426-207-0011-0	47-37	1426-406-2030-0	72-10	1426-426-3260-0	73-6
1426-207-0021-0	48A-35,	1426-406-2040-0	72-1	1426-426-2370-0	73-7
	48-42,	1426-406-2050-0	72-2	1426-426-2380-0	73-8
	49A-43,	1426-406-2060-0	72-5	1426-426-2390-0	73-9
	49-50	1426-406-2070-0	72-15	1426-426-2400-0	73-0-3
1426-208-0020-0	51-8	1426-406-2080-0	72-6	1426-426-2410-0	73-58
1426-208-0021-0	51-8a	1426-406-2090-0	72-19	1426-426-2420-0	73-59
1426-208-0022-0	51-8b	1426-406-2022-0	72-20	1426-426-2430-0	73-61
1426-208-0032-0	51-12	1426-406-2110-0	72-16	1426-426-2440-0	73-62
1426-210-0011-0	51-35	1426-406-2120-0	72-7	1426-426-2450-0	73-63
1426-210-0012-0	51-35a	1426-406-2130-0	72-14	1426-426-2460-0	73-66
1426-210-0021-0	51-34	1426-406-2140-0	72-13	1426-426-2470-0	73-64
1426-210-0022-0	51-34a	1426-406-2150-0	72-18	1426-426-2500-0	73-74
1426-210-0031-0	51-30	1426-406-2170-0	72-4	1426-426-2600-0	73-71
1426-210-0041-0	51-41	1426-406-2180-0	72-12	1426-426-2700-0	73-67
1426-210-0042-0	51-41a	1426-423-0010-0	29-30	1426-426-2810-0	73-10
1426-210-0050-0	51-38	1426-423-0020-0	29-18	1426-426-2820-0	73-13
1426-210-0060-0	51-27a	1426-423-2300-0	29-22	1426-426-2830-0	73-14
1426-213-0010-0	50-6	1426-423-2301-0	29-22a	1426-426-2840-0	73-16
1426-214-2000-0	51-20-1	1426-423-2400-0	29-24	1426-426-2850-0	73-23
1426-214-2001-0	51-20-1a	1426-423-2500-0	29-21	1426-426-2860-0	73-24

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
1426-426-2870-0	73-25	1426-506-0051-0	61-1	1426-574-0140-0	78-13
1426-426-2880-0	73-49	(1426-506-0052-0)		1426-574-0150-0	78-15
1426-426-2890-0	73-48	1426-506-0062-0	61-13	1426-574-0160-0	78-16
1426-426-2910-0	73-32	1426-506-0070-0	61-14	1426-574-0170-0	78-22
1426-426-2920-0	73-30	1426-506-0080-0	61-45	1426-574-0180-0	78-25
1426-426-2930-0	73-31	1426-506-0110-0	61-46	1426-574-0190-0	78-26
1426-426-2950-0	73-40	1426-506-2001-0	61-24	1426-574-0210-0	78-29
1426-426-2960-0	73-39	1426-506-2101-0	61-16	1426-574-0220-0	78-30
1426-426-2970-0	73-35	1426-506-2160-0	72-3	1426-574-0230-0	78-31
1426-426-2980-0	73-37	1426-506-2200-0	61-37	1426-574-0240-0	78-32
1426-426-2990-0	73-38	1426-506-2300-0	61-39	1426-574-0250-0	78-33
1426-426-3010-0	73-36	1426-506-2400-0	61-40	1426-574-0260-0	78-34
1426-426-3020-0	73-20	1426-506-2600-0	61-1a	1426-574-0270-0	78-35
1426-426-3030-0	73-27	1426-506-2630-0	61-2	1426-574-0280-0	78-40
1426-426-3040-0	73-26	1426-506-2640-0	61-3	1426-574-0290-0	59A-36,
1426-426-3050-0	73-22	1426-506-2650-0	61-4		77-12
1426-426-3060-0	73-28	1426-506-2660-0	61-5	1426-574-0311-0	77-19
1426-426-3070-0	73-21	1426-506-2670-0	61-7	1426-574-2000-0	76-30,
1426-426-3080-0	73-47	1426-506-2680-0	61-8		80-0-1
1426-426-3090-0	73-18	1426-506-2690-0	61-10	1426-574-2010-0	80-28
1426-426-3110-0	73-19	1426-506-2710-0	61-11	1426-574-2100-0	76-34
1426-426-3111-0	73-19a	1426-571-0020-0	75-22	1426-574-2200-0	76-35
1426-426-3120-0	73-33	1426-571-0030-0	75-24	1426-574-2300-0	77-27
1426-426-3130-0	73-53	1426-571-0040-0	75-28	1426-574-2400-0	78-10
1426-426-3140-0	73-43	1426-571-0050-0	75-29	1426-574-2500-0	77-1
1426-426-3150-0	73-44	1426-571-0060-0	75-30	1426-574-2600-0	77-2
1426-426-3160-0	73-45	1426-571-0070-0	75-34	1426-574-2700-0	77-5
1426-426-3170-0	73-46	1426-571-2001-0	75-18,	1426-574-2800-0	77-8
1426-426-3180-0	73-51		82-0-1	1426-574-2900-0	77-15
1426-426-3190-0	73-52	1426-571-2101-0	75-1	1426-574-3001-0	77-18
1426-426-3210-0	73-50	1426-572-2000-0	76-1	1426-576-2000-0	60-24-1
1426-426-3220-0	73-56a	1426-574-0010-0	76-18		61-24-1
1426-428-0010-0	30-5	1426-574-0020-0	76-19	1426-576-2100-0	60-37-1
1426-462-2940-0	73-41	1426-574-0030-0	76-39	1426-578-2000-0	61-39-1
1426-501-0010-0	57-12a,	1426-574-0040-0	78-43	1426-578-2100-0	61-40-1
	58-12a,	1426-574-0050-0	78-44	1426-580-2000-0	70-11-1
	57-3, 58-3	1426-574-0060-0	78-45	1426-580-2100-0	70-12-1
1426-501-1010-0	75-17	1426-574-0070-0	78-49	1426-580-2300-0	69-41-1
1426-502-2001-0	58-1	1426-574-0080-0	77-28	1426-584-0010-0	79-5
1426-506-0010-0	61-41	1426-574-0090-0	78-1	1426-584-2000-0	79-1, 81-0-1
1426-506-0020-0	61-42	1426-574-0110-0	78-2	1426-584-2010-0	81-1
1426-506-0031-0	61-32	1426-574-0120-0	78-4	1426-584-2020-0	81-2
1426-506-0040-0	61-33	1426-574-0130-0	78-12	1426-584-2030-0	81-3

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
1426-584-2040-0	81-4	1427-934-0090-0	62-4-1	1431-301-0070-0	53-33
1426-584-2050-0	81-5	1427-934-0130-0	25-3-1	1431-301-0080-0	53-34
1426-584-2060-0	81-6	1427-934-0190-0	46-28-1	1431-301-0090-0	53-6
1426-584-2070-0	81-8	1427-937-0030-0	62-2	1431-301-0110-0	53-10
1426-584-2080-0	81-9	1427-937-0040-0	37-4	1431-355-0010-0	52-21
1426-584-2090-0	81-10	1427-937-0090-0	62-4	1431-361-2000-0	63-0-1
1426-584-2200-0	79-8	1427-937-0130-0	25-3	1431-361-2100-0	63-1
1426-584-2300-0	79-11	1427-941-0160-0	25-3a	1431-361-2110-0	63-4
1426-584-2400-0	79-12	1427-941-0190-0	37-3a	1431-361-2200-0	63-0-2
1426-584-2500-0	79-13	1427-941-0210-0	37-18a	1431-361-2300-0	63-2
1426-584-2600-0	79-14			1431-362-2000-0	63-0-3
1426-602-1000-0	26-10	1431-009-2010-0	53-1a	1431-451-2000-0	27-1
1426-611-1002-0	62-15	1431-009-2100-0	53-2a	1431-451-2200-0	27-5, 28-17
1426-616-2000-0	54-34, 55-34	1431-026-2000-0	53-2	1431-455-2000-0	28-1
1426-616-2102-0	54-35, 55-35	1431-026-3000-0	53-1	1431-461-0010-0	29-38
1426-616-2200-0	54-39, 55-39	1431-045-2000-0	29-1	1431-461-0011-0	29-38a
1426-616-2302-0	54-40	1431-101-0020-0	24-7	1431-461-2000-0	29-39
1426-616-2302-0	55-40	1431-151-2101-0	22-1	1431-476-2000-0	34-0-1
1426-621-0350-0	65-20	1431-151-2120-0	22-2	1431-476-2010-0	34-2, 34-6
1426-621-0360-0	65-21	1431-151-2130-0	22-5	1431-476-2100-0	34-0-2
1426-672-2000-0	62-15-4	1431-151-2200-0	24-5	1431-478-2000-0	30-0-1
1426-673-2000-0	62-15-1	1431-151-2300-0	23-1	1431-478-2010-0	30-7
1426-675-2000-0	62-15-3	1431-151-2500-0	23-2	1431-557-0010-0	59-12,
		1431-151-2600-0	23-20		59A-12, 76-8
1427-252-0020-0	41A-18	1431-151-2800-0	23-22	1431-561-2001-0	70-11
1427-301-0050-0	33-16	1431-151-2900-0	23-25	1431-561-2101-0	70-12
1427-301-0210-0	54-24a,	1431-151-3000-0	23-26	1431-566-0010-0	69-22, 70-6a
	55-24a	1431-152-2500-0	22-11a	1431-566-2000-0	69-1
1427-317-0040-0	38-10, 39-10,	1431-254-0010-0	47-1	1431-566-2100-0	69-2
	40-10, 41-10,	1431-254-0011-0	47-1a	1431-566-2200-0	69-7
	41A-10,	1431-273-0010-0	51-1	1431-566-2300-0	69-8
	47-11, 47-30,	1431-280-0010-0	50-1	1431-566-2400-0	69-41
	58-30	1431-283-0010-0	50-5	1431-570-0010-0	70-4
1427-903-0040-0	37-6	1431-286-0010-0	50-22	1431-570-0011-0	70-4a
1427-932-0020-0	51-46	1431-286-0020-0	50-16	1431-570-2000-0	70-1
1427-932-0030-0	24-21	1431-286-0021-0	50-16a	1431-570-2100-0	70-5
1427-932-0040-0	46-29	1431-286-2000-0	50-14	1431-570-2101-0	70-5a
1427-932-0140-0	27-15, 28-21	1431-301-0010-0	53-32	1431-604-2000-0	26-32
1427-932-0160-0	27-15-1,	1431-301-0020-0	53-7	1431-604-2001-0	26-32a
	28-21-1	1431-301-0030-0	53-8	1431-604-2200-0	26-33
1427-934-0030-0	62-2-1	1431-301-0040-0	53-9	1431-651-2001-0	25-21
1427-934-0040-0	37-4-1	1431-301-0050-0	53-4	1431-656-2001-0	26-1
1427-943-0041-0	42-27	1431-301-0060-0	53-5	1431-656-2100-0	26-5

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
1431-661-2000-1	37-1, 37-1a	1431-935-0021-0	25-4-1a	1432-501-2360-0	82-8
1431-666-0011-0	62-35-1	1431-935-0022-0	25-4-1b	1432-501-2370-0	82-10
1431-666-0021-0	62-35-2	1431-935-0030-0	59-52-1	1432-501-2380-0	82-11
1431-666-2000-0	62-9-1	1431-935-0040-0	62-36-1	1432-501-2390-0	82-12
1431-666-2100-0	62-10-1	1431-935-0050-0	37-19-1	1432-501-2410-0	82-13
1431-671-2100-0	62-15-2	1431-935-0060-0	37-21-1	1432-501-2420-0	82-14
1431-681-0011-0	64-31	1431-935-0070-0	42-27-1	1432-501-2430-0	82-15
1431-681-0021-0	64-32	1431-935-0080-0	59-31a	1432-501-2440-0	82-16
1431-681-2000-0	65-5	1431-935-0090-0	37-23-1	1432-501-2450-0	82-17
1431-681-2001-0	65-5a	1431-938-0011-0	25-2	1432-501-2460-0	82-19
1431-681-2010-0	65-6	1431-938-0012-0	25-2a	1432-501-2470-0	80-2, 82-20
1431-686-0010-0	65-18	1431-938-0020-0	25-4	1432-501-2480-0	82-21
1431-686-0020-0	64-5	1431-938-0021-0	25-4a	1432-505-2011-0	80-1
1431-686-0021-0	64-5a	1431-938-0022-0	25-4b	1432-505-2020-0	80-3
1431-686-0030-0	64-6	1431-938-0030-0	62-36	1432-505-2030-0	80-4
1431-686-0040-0	64-12	1431-938-0031-0	62-36a	1432-505-2040-0	80-5
1431-686-0050-0	64-11	1431-938-0040-0	50-17	1432-505-2050-0	80-8
1431-686-0060-0	64-10	1431-938-0050-0	37-22	1432-505-2060-0	80-9
1431-686-2000-0	66-18	1431-938-0060-0	37-23	1432-505-2070-0	80-11
1431-686-2010-0	66-19	1431-938-0070-0	25-6-1	1432-505-2080-0	80-12
1431-686-2100-0	65-13	1431-938-0080-0	25-8-1	1432-505-2090-0	80-13
1431-686-2110-0	65-14	1431-940-0080-0	59-52a	1432-505-2110-0	80-14
1431-686-2120-0	65-15	1431-940-0110-0	50-17a	1432-505-2120-0	80-15
1431-686-2200-0	65-29	1431-940-0170-0	37-5a	1432-505-2131-0	80-16
1431-686-2210-0	65-30	1431-947-0010-0	28-20	1432-505-2141-0	80-17
1431-686-2220-0	65-31	1431-947-0020-0	28-20-1	1432-505-2151-0	80-18
1431-686-2230-0	65-32	1431-947-0030-0	27-14	1432-505-2160-0	80-19
1431-686-2240-0	65-33	1431-948-0010-0	27-15-2,	1432-505-2170-0	80-20
1431-686-2250-0	65-34		28-21-2	1432-505-2180-0	80-21
1431-686-2260-0	65-35	1431-952-0010-0	36-24	1432-505-2190-0	80-23
1431-686-2400-0	64-1	1431-952-0021-0	36-27	1432-505-2210-0	80-25
1431-686-2401-0	64-1a	1431-952-2000-0	36-25	1432-505-2220-0	80-26
1431-686-2420-0	64-3	1431-952-2100-0	36-26	1432-505-2230-0	80-27
1431-686-2500-0	65-50			1432-505-2240-0	80-30
1431-686-2520-0	65-52	1432-242-0040-0	59-29,	1432-506-0030-0	78-8
1431-686-2530-0	65-53		59A-29,	1432-506-0090-0	78-17
1431-686-2540-0	65-54		77-9, 79-18	1432-506-0110-0	78-18
1431-903-0031-0	25-6	1432-403-0071-0	29-41	1432-506-0170-0	78-27
1431-903-0041-0	25-8	1432-501-2310-0	82-1	1432-506-0180-0	78-28
1431-930-0010-0	59-31	1432-501-2320-0	82-2	1432-506-0320-0	78-3, 78-46
1431-935-0010-0	25-2-1	1432-501-2330-0	82-3		
1431-935-0011-0	25-2-1a	1432-501-2340-0	82-5	1444-514-2900-0	69-19a
1431-935-0020-0	25-4-1	1432-501-2350-0	82-7		

Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.	Parts No. Pièces N°.	Ref No. Réf N°.
2101-230-0010-0	50-15a, 51-22a				
2132-211-0040-0	51-17a				
2701-101-0520-0	66-42				
3560-201-0150-0	37-9a, 62-17a				
3614-261-2200-0	65-46a				
3737-154-0020-0	62-31				
3737-172-0090-0	64-22				
3737-235-0080-0	44-27-1				
3740-314-0170-0	37-9				
3847-261-2050-0	26-6, 68-3				
4106-105-3030-0	41B-49, 42-26, 50-15, 51-22				
7954-205-1000-0	41B-55				
7956-205-0160-0	51-7				
7957-405-0030-0	69-12				
7963-201-0030-0	31-9, 32-3				
7963-603-0010-0	70-6				
7963-611-0010-0	69-14a				
7963-611-0030-0	69-11				
7963-613-0040-0	59-21, 59A-21, 76-16				

)

)

TS

1400-098-0031-0

February 1979

Made in Japan revision October 1981

ISEKI & CO., LTD.

Foreign Affairs Division
3-6, Kioicho, Chiyoda-ku, Tokyo, 102, Japan
Telex: 232-2752, 232-2753
Cable address: ISEKIRIOE TOKYO
Phone: 03-238-5245~5258