



2020 Standard and Crew Models Catalog

- Parts Manual -

Table of Contents

Parts Manual

Intake Manifold.....	Page 1
Oil Pump Cover Assembly, Timing Belt Front and Oil Sump Assembly.....	Page 2
Fuel and Ventilation System	Page 3
Cooling System.....	Page 4
Electrical Equipments	Page 5
Battery.....	Page 6
Engine Assembly	Page 6
Cylinder Head and Cover.....	Page 7
Crankcase	Page 8
Exhaust Manifold.....	Page 8
Harness Assembly, Engine and Accessories	Page 9
Timing System	Page 9
Engine Bracket.....	Page 10
Clutch.....	Page 10
Air Cleaner.....	Page 11
Motor Assembly, Starting and Accessories.....	Page 11
Pipe Assembly, Muffler	Page 12
Transmission Assembly and Accessories.....	Page 12
Clutch Fork	Page 13
Transmission Case	Page 13
Input Shaft.....	Page 14

Table of Contents

Counter Shaft	Page 15
Shaft, Reverse Gear	Page 15
Case Assembly, Gear Shift.....	Page 16
Output Shaft	Page 16
Crankshaft and Connecting Rods System.....	Page 17
Valve System.....	Page 18
Gearshift Lever	Page 19
Extension Case	Page 20
RR Door and Inner Part	Page 21
RR Door Regulator	Page 22
RR Door Lock.....	Page 23
2nd Seat Belt	Page 24
3rd Seat Belt.....	Page 24
Fule Filler System	Page 25
Back Door	Page 26
RR Quarter Trim	Page 27
RR Bumper	Page 27
Roof Lining, Assistant Grip, Sunvisor.....	Page 28
Pillar and Other Inner Trim Panel	Page 28
Wind Guide, Radiator	Page 29
Seat Assembly, 2nd	Page 29
Floor Side Garnish, Wheel Arch	Page 30
Seat Assembly, 3rd.....	Page 30

Table of Contents

Rear Axle	Page 31
Side Body Panel Welding Assembly.....	Page 31
Body Frame Welding Assembly	Page 32
Roof Panel.....	Page 33
Light System	Page 34
Wiring Harness	Page 34
Lock Set	Page 35
A/C System	Page 35
Radio and Antenna	Page 36
Seat Assembly, FR	Page 36
Carpet	Page 37
Leaf Spring Assembly.....	Page 37
Fuel Tank Assembly.....	Page 38
Wheel and Tire	Page 38
Spare Tire Carrier.....	Page 39
Final Drive and Differential Gear Assembly	Page 39
FR Upper Member and Dash Panel	Page 40
Fuel Dideline and Fuel Pump	Page 40
Accelerator Cable.....	Page 41
Clutch Cable Assembly.....	Page 41
Gear Shift Control System	Page 42
Propellor Shaft	Page 42
Accelerator Pedal Assembly	Page 43


Table of Contents

Brake Master Cylinder.....	Page 43
Brake Pipe	Page 44
FR Brake	Page 45
RR Brake.....	Page 46
Parking Brake.....	Page 46
Steering Wheel	Page 47
Steering Shaft.....	Page 47
Steering Gear Assembly.....	Page 48
FR Suspension	Page 48
FR Stabilizer Bar.....	Page 49
Absorber and Strut Assembly, FR Suspension	Page 49
FR Door Lock and Inner Trim	Page 50
Glass and Weatherstrip, FR Door	Page 51
FR Hood and Accessories	Page 52
FR Windshield	Page 52
FR Seat Belt	Page 53
FR Fender	Page 54
FR Bumper.....	Page 55
Console Box.....	Page 55
Rearview Mirror.....	Page 56
Mudguard Flap.....	Page 56
Wind Guide Plate	Page 57
Outer Garnish, FR Triangle	Page 57


Table of Contents


ACK Assembly	Page 57
Instrument Panel	Page 58
Air Pipe	Page 58
Washer Assembly	Page 59
Switch Assembly, Combination and Electrical Control	Page 59
Combination Meter	Page 60
Cooling System	Page 61
Wiper Assembly	Page 61
Rail Cover, RR Door Center	Page 62
Side Window Glass	Page 62


Picture	ITEM	CHANGAN NO.	PART NAME	SC6406A. F2KU1	SC5027XX YA4.E2DU1
	53105-12_A	进气系统			
	53105-12_A	INTAKE MANIFOLD			
	1	EA003-1300	NUT	2	2
	2	EA007-0200	STUD, INTAKE MANIFOLD	2	2
	3	EA007-0400	GASKET, INTAKE MANIFOLD	1	1
	4	EA007-0500	HOSE, WATER RETURN	1	1
	5	EA007-0600	CLIP , THROTTLE	6	6
	6	EA007-0700-AB	MANIFOLD, INTAKE	1	1
	7	CV6009-1600	GASKET, THROTTLE BODY	1	1
	8	YC010-170	SENSOR, THROTTLE	1	1
	9	EA007-1200	THROTTLE BODY ASSY	1	1
	10	YC010-210	STEPPER MOTOR	1	1
	11	EA007-1500	REINFORCE PLATE, INTAKE MANIFOLD	1	1





53103-20_A 机油泵前罩壳总成及机油盘总成				
53103-20_A OIL PUMP COVER ASSY ,TIMING BELT FRONT AND OIL SUMP ASSY				
1	EA008-0101	BOLT, FR TIMING COVER	5	5
2	EA008-0202	OIL PUMP WITH FR COVER	1	1
3	Y006-200	PIN, FLYWHEEL	2	2
4	EA008-0400	"O" RING, OIL-OUT	1	1
5	EA008-0500	GASKET, OIL FILTER	1	1
6	EA008-0600	LOCATING PIN, UPPER OIL PUMP	1	1
7	EA008-0700-AA	OIL PAN, UPPER	1	1
8	EA008-0900	O-RING, OIL PUMP STRAINER	1	1
9	EA008-1000	STRAINER, OIL PUMP	1	1
10	EA008-1256	OIL PAN, LOWER	1	1
11	EA008-1300	STUD, OIL PUMP	2	2
12	EA008-1500	PLUG, OIL DRAIN	1	1
13	EA008-1600	GASKET, OIL DRAIN PLUG	1	1
14	EA008-1900-AA	OIL FILTER ASSY	1	1
15	EA008-2000-AB	CONNECTING PIPE, OIL FILTER	1	1
16	EA008-2200	GASKET	1	1
17	EA008-2300	GUIDE, OIL LEVER GAUGE	1	1
18	EA008-2400	OIL SEAL, CRANKSHAFT, FR	1	1
19	EA006-0500	NUT M10	1	1
20	EA008-2700	GAUGE, OIL LEVER	1	1
21	EA008-2900	STUD, OIL PUMP COVER	1	1


[illegible]


[illegible]




53101-30_A 电器及附件				
53101-30_A ELECTRICAL EQUIPMENTS				
1	EA012-0200	COIL, IGNITION	4	4
2	3600010-Y16	ECU	1	
2	MD201011-1718	ECU		1
3	EA012-0400	SPARK PLUG	4	4
4	EA012-1000	BRACKET, COMPRESSOR	1	1
5	EA012-1101	COMPRESSOR ASSY	1	
5	EA012-1100	COMPRESSOR ASSY		1
6	EA012-1400	GENERATOR ASSY	1	1
7	EA012-1700	BRACKET, GENERATOR	1	1
8	EA012-1900	BRACKET ASSY, GENERATOR	1	1
9	EA15011-0600	BOLT, COMPRESSOR BRACKET	2	2
10	EA012-2200	SENSOR ASSY, CRANKSHAFT POSITION	1	1
11	EA012-2400	BRACKET, CANISTER VALVE	1	1
12	YJ018-272	JACKET, CANISTER CONTROL VALVE	1	1
13	YC018-271	VALVEASSY, CANISTER, CONTROL	1	1
14	EA007-0600	CLIP , THROTTLE	6	6
15	EA012-2800	HOSE, CANISTER VALVE	1	1
16	H15008-0200	SENSOR, INTAKE AIR TEMPERATURE	1	1
17	YC010-180	SENSOR, WATER TEMPERATURE	1	1
18	K010-0401	SENSOR, OXYGEN BACKWARD	1	1
19	EA15013-0400	SENSOR, KNOCKING	1	1
20	EA012-3500-AA	ALARM ASSY, OIL PRESSURE	1	1



	53110-10_A 蓄电池			
	53110-10_A BATTERY			
	1	Y063-240	BOLT, BATTERY HOLDING	2
	2	Y063-230	PLATE, BATTERY HOLDING	1
	2	M201087-1000-AA	PLATE, BATTERY HOLDING	1
	3	Y030-011	BATTERY ASSY	1
	4	Y030-050	BRACKET, BATTERY	1
	5	R111025-1000	HEAT INSULATION MAT, BATTERY	1
	53101-00_A 发动机总成			
	53101-00_A ENGINE ASSY			
	1	JL473Q-C	ENGINE ASSY	1
	1	JL473Q-F	ENGINE ASSY	1

[illegible]





53102-20_A 曲轴箱				
53102-20_A CRANKCASE				
1	EA002-0100	PLUG	2	2
2	EA002-0200	WASHER	2	2
3	EA002-0400	BACK-END COVER, CRANKSHAFT	1	1
4	Y006-200	PIN, FLYWHEEL	2	2
5	EA10003-0600	OIL SEAL, CRANKSHAFT, RR	1	1
6	EA002-0701-BB	CRANKSHAFT CASE	1	1
7	EA002-1700-AB	PLATE, OIL PAN BAFFLE	1	1
8	EA002-2000	STUD M6×49.5	4	4
9	EA002-2100	BOLT	10	10
10	EA002-2510	THRUST WASHER, CRANKSHAFT	2	2
11	YJ060-0903	BEARING GROUP, CRANKSHAFT	1 set	1 set
12	EA002-2600	FUEL NOZZLE, TIMING CHAIN	1	1
53106-10_A 排气系统				
53106-10_A EXHAUST MANIFOLD				
1	EA006-0100	INSULATOR, EXHAUST MANIFOLD,UPPER	1	1
2	EA006-0200	GASKET, EXHAUST MANIFOLD	1	1
3	EA006-0300	MANIFOLD, EXHAUST	1	1
4	EA006-0400	BOLT, EXHAUST MANIFOLD	3	3
5	EA006-0500	NUT M10	1	2
6	EA006-0600	INSULATOR, EXHAUST MANIFOLD, LOWER	1	1






	84315-90_A 发动机电线束总成及附件			
	84315-90_A HARNESS ASSY, ENGINE AND ACCESSORIES			
	1	EA013-0203-BC	WIRE HARNESS ASSY, ENGINE	1
	53102-50_A 正时系统及前端轮系			
	53102-50_A TIMING SYSTEM			
	1	EA011-1200	HYDRAULIC TENSIONER	1
	2	EA15007-0800	TENSION RAIL, CHAIN	1
	3	H16007-1800	BOLT, TIMEING CHAIN GUIDE	1
	4	EA011-0100-AA	CHAIN, TIMING	1
	5	EA15007-0300	GUIDE RAIL, CHAIN	1
	6	EA011-0400-AA	PULLEY, CRANKSHAFT TIMING BELT	1
	7	EA011-0500	BELT, GENERATOR	1
	8	EA011-0600	PULLEY, CRANKSHAFT	1
	9	EA011-0700	1# BOLT, CRANKSHAFT PULLEY	1
	10	EA011-0800	BELT, COMPRESSOR	1
	11	EA011-1000	PULLEY, WATER PUMP	1
	12	EA011-0610	BELT, ELASTIC	1



53101-20_A 发动机悬挂				
53101-20_A ENGINE BRACKET				
1	EA014-0100	BOLT, RR ENGINE SUSPENSION	2	2
2	EA014-0200	BRACKET ASSY, ENGINE MOUNTING, RR	1	1
3	EA006-0500	NUT M10	1	1
4	EA014-0402	BRACKET ASSY, ENGINE MOUNTING, LH	1	1
5	EA15005-0600	BOLT M10×40	5	5
6	EA014-0401	BRACKET ASSY, ENGINE MOUNTING, RH	1	1
7	EA014-1100	BOLT M10×70	2	2
8	EA15005-0001	BOLT M10×50	1	1
9	M201021-0500	BRACKET, ENGINE, RH	1	1
9	M201021-0510	BRACKET, ENGINE, LH	1	1
10	M201022-0000	SUPPORT, ENGINE	1	1
11	M201022-0001	PROTECT SHIELD, OIL PAN	1	1
	</			



	53105-20_A 空气滤清器			
	53105-20_A AIR CLEANER			
	1	M201017-0300	FILTER, AIR	1 1
	2	M201017-0800	INLET PIPE, AIR CLEANER	1 1
	3	M201017-0200	AIR CLEANER ASSY	1 1
	4	M201017-0500	HOSE, AIR CLEANER OUTLET	1 1
	5	M201017-0100	AIR CLEANER ASSY WITH ACCESSORY	1 1
	53109-10_A 起动机及附件			
	53109-10_A MOTOR ASSY, STARTING AND ACCESSORIES			
	1	EA017-0500	MOTOR ASSY, STARTING	1 1
	2	EA017-0501	HEAT INSULATION, STARTING MOTOR	1 1

	53106-20_A 消声器			
	53106-20_A PIPE ASSY,MUFFLER			
	1	M201016-0200	TWC	1
	1	1205000-Y06	TWC	1
	2	M201016-0100	MUFFLER ASSY	1
	2	M201016-0101	MUFFLER ASSY	1
	63401-00_A 变速箱及附件			
	63401-00_A TRANSMISSION ASSY AND ACCESSORIES			
	1	YJ020-009	TRANSMISSION ASSY	1
	2	EA15005-0100	BOLT	4
	3	EA016-0400	PLATE, TRANSMISSION DUSTPROOF	1
	4	EA006-0500	NUT M10	1
	5	EA016-0600	UPPER PLATE, CLUTCH	1
	6	EA014-1100	BOLT M10×70	4


	63402-20_A 变速器离合器拨叉组件				
	63402-20_A CLUTCH FORK				
	1	Y019-050	BRACKET, FORK	1	1
	2	YJ023-0708	CIRCLIP, CLUTCH FORK	1	1
	3	Y019-090-1	RELEASE BEARING	1	1
	4	Y019-070	CIRCLIP	1	1
	5	YJ023-0508	FORK, CLUTCH	1	1
	63403-60_A 前后箱				
	63403-60_A TRANSMISSION CASE				
	1	YJ023-0101	RR CASE, TRANSMISSION	1	1
	2	Y020-510	BOLT, REVERSE SHAFT	1	1
	3	YJ023-0105	FR CASE, TRANSMISSION	1	1
	4	YJ020-617	DOUBLE END STUD, TRANSMISSION NO.2	2	2
	5	YJ023-0707	LOCK BOLT, GEAR SHIFT	4	4


[illegible]


	63403-20_A 变速器中间轴组件				
	63403-20_A COUNTER SHAFT				
	1	YA020-230	CIRCLIP, OUTPUT SHAFT RR BEARING	1	1
	2	YJ020-502	BEARING, FR CASE, RR	1	1
	3	PA025-1016	GASCKET, COUTERSHAFT FR BEARING	1	1
	4	YJ023-0303	GEAR, COUNTERSHAFT, 1ST SPEED	1	1
	5	Y020-300	NEEDLE BEARING, COUNTERSHAFT 1ST	1	1
	6	CV6020-4000	RING, SYNCHRONIZER 1ST SPEED	1	1
	7	CV6020-3500	CIRCLIP, SYNCHRONIZER LOW SPEED	1	1
	8	Y020-330	SYNCHRONIZER ASSY, LOW SPEED	1	1
	9	Y020-370	RING, SYNCHRONIZER 2ND SPEED	1	1
	10	YJ023-0304	GEAR, COUNTERSHAFT, 2ND SPEED	1	1
	11	Y020-300	NEEDLE BEARING, COUNTERSHAFT 1ST	1	1
	12	YJ023-0704	COUNTERSHAFT	1	1
13	YJ020-502	BEARING, FR CASE, RR	1	1	
	63403-90_A 变速器倒档齿轮轴组件				
	63403-90_A SHAFT, REVERSE GEAR				
	1	Y020-500	GEAR, REVERSE IDLE	1	1
	2	PA025-1026	WASHER, REVERSE IDLE GEAR SHAFT	1	1
	3	PA025-1025	SHAFT, REVERSE IDLE GEAR	1	1


[illegible]


63403-80_A 变速器主轴组件				
63403-80_A OUTPUT SHAFT				
1	YJ023-0403	NEEDLE BEARING, INPUT SHAFT	1	1
2	YJ023-0404	SPRING, SYNCHRONIZER, HIGH SPEED	1	1
3	YJ023-0405	RING, SYNCHRONIZER, HIGH SPEED	1	1
4	YJ023-0202	OUTPUT SHAFT	1	1
5	YJ023-407	BEARING, MAINSHAFT, FR	1	1
6	YJ023-0305	GEAR, OUTPUT SHAFT	1	1
7	YJ023-0401	BEARING, INPUT SHAFT	1	1
8	YA020-230	CIRCLIP, OUTPUT SHAFT RR BEARING	1	1
9	YJ023-0502	GEAR, SPEED METER DRIVE	1	1
10	YA020-230	CIRCLIP, OUTPUT SHAFT RR BEARING	1	1

[illegible]


[illegible]


[illegible]



[illegible]





95102-30 滑门及内装饰件				
95102-30 RR DOOR AND INNER PART				
1	M201059-0100	PANEL ASSY, RR DOOR, LH	1	
1	M201059-0200	PANEL ASSY, RR DOOR, RH	1	
2	M201059-0300	ARM, RR DOOR UPPER, LH	1	
2	M201059-0400	ARM, RR DOOR UPPER, RH	1	
3	Y085-100	ABSORBER CUSHION, RR DOOR	2	
4	F202059-0300	STOPPER, RR DOOR CLOSE (DOOR)	4	
5	F202051-0200	STOPPER, RR DOOR CLOSE (BODY)	3	
6	M201059-2101	MIDDLE HINGE, RR DOOR, LH	1	1
6	M201059-2201	MIDDLE HINGE, RR DOOR, RH	1	1
7	M201059-3200	TRIM BOARD, RR DOOR INNER, LH	1	
7	M201059-3300	TRIM BOARD, RR DOOR INNER, RH	1	
8	M201059-5200	RR DOOR HOLD (BODY)	2	2
9	M201059-5000	RR DOOR HOLD (DOOR)	2	2
10	F202094-0200	STOPPER, RR DOOR, LH	2	
11	F202094-0300	STOPPER, CENTER PILLAR, LH	2	
12	Y085-100	ABSORBER CUSHION, RR DOOR	2	
13	M201059-6600	SPRING, RR DOOR OPEN STOP, LH	1	1
13	M201059-6700	SPRING, RR DOOR OPEN STOP, RH	1	1
14	S101128-1900	HERMETIC COVER	8	8
15	M201059-4100	ASSY RAIL REAR DOOR CENTER L	1	1
15	M201059-4200	ASSY RAIL REAR DOOR CENTER L	1	1
16	M201059-8002	WEATHERSTRIP, RR DOOR OPENING, LH	2	2

[illegible]


[illegible]

		95103-50 中排安全带			
		95103-50 2ND SEAT BELT			
		1 M201062-0100	RETRACTOR ASSY, 2ND SEAT, LH	1	
		1 M201062-0101	RETRACTOR ASSY, 2ND SEAT, RH	1	
		2 M201062-0300	DOUBLE BUCKLE, 2ND SEAT	1	
		3 M201062-0700	TONGUE WITH BUCKLE, 2ND SEAT	1	
		95104-20 后排安全带			
		95104-20 3RD SEAT BELT			
		1 M201064-0100	SAFETY BELT, RR SEAT, LH	1	
		2 M201064-0300	SAFETY BELT, RR SEAT, RH	1	


[illegible]







95102-80 背门总成				
95102-80 BACK DOOR				
1	M201070-0100	GLASS ASSY, BACK DOOR	1	
2	M201070-0200	PANEL ASSY, BACK DOOR	1	
3	M201070-0300	HINGE ASSY, BACK DOOR	2	2
4	M201096-0700	LAMP ASSY, HIGH MOUNTING STOP	1	
5	M201070-0900	BALANCER, BACK DOOR, LH	1	1
6	M201070-1100	BALANCER, BACK DOOR, RH	1	1
7	M201070-1200	SEAL FLIM, BACK DOOR	1	
8	M201070-1300	TRIM BOARD ASSY, BACK DOOR	1	1
9	M201070-1400	WEATHERSTRIP, BACK DOOR FRAME	1	1
10	F202063-1501	STOPPER, BACK DOOR (DOOR)	2	
10	F202063-1502	STOPPER, BACK DOOR (DOOR)		2
11	F202063-1700	STOPPER, BACK DOOR (BODY)	2	
11	F202063-1701	STOPPER, BACK DOOR (BODY)		2
12	M201070-1800-AA	LOCK ASSY, BACK DOOR	1	1
13	Y094-050	LATCH, BACK DOOR LOCK	1	1
14	M201070-2200	HANDLE, BACK DOOR OUTER	1	1
15	Y034-090	LAMP ASSY, LICENSE	2	2
16	M201070-2601	COVER, BRAKE DOOR LICENSE LAMP	1	
16	M201621-0100	COVER, BRAKE DOOR LICENSE LAMP		1
17	M201096-1000-AA	LAMP ASSY, RR DECORATIVE, LH	1	1
18	M201096-1100-AA	LAMP ASSY, RR DECORATIVE, RH	1	1






95109-50 后侧围内饰板				
95109-50 RR QUARTER TRIM				
1	M201071-0000	TRIM BOARD, RR QUARTER, LH	1	
1	M201071-0001	TRIM BOARD, RR QUARTER, RH	1	
1	M201EV01-0054	TRIM BOARD, RR QUARTER, LH		1
1	M201071-0705	TRIM BOARD, RR QUARTER, RH		1
3	Y083-020	CLIP	14	14

[illegible]


	95109-21 顶盖内衬、安全拉手及遮阳板				
	95109-21 ROOF LINING,ASSISTANT GRIP,SUNVISOR				
	1	M201078-0100	SUN VISOR ASSY, LH	1	1
	3	5702111-Y06	ROOF LINING	1	
	3	5702111-Y05	ROOF LINING		1
	4	Y083-120	PLASTIC CLIP	28	28
	5	M201078-1100	SAFETY GRIP	3	3
	95109-10 立柱及其他内饰板				
	95109-10 PILLAR AND OTHER INNER TRIM PANEL				
	1	M201081-0100	TRIM, A PILLAR, LH	1	1
	1	M201081-0300	TRIM, A PILLAR, RH	1	1
	2	P081-0500	NUT, PLASTIC	4	4
	3	CM9072-1300	CLIP	4	4

	53104-20 散热器导风板			
	53104-20 WIND GUIDE, RADIATOR			
	1	M201081-0202	CONDENSER GASKET R	1
	2	M201081-0201	CONDENSER GASKET L	1
	95103-42 中排座椅总成			
	95103-42 SEAT ASSY,2ND			
	1	7300100-Y09	SEAT ASSY, 3RD (2+1)	1


	95110-21 全车门槛总成及鼓包罩				
	95110-21 FLOOR SIDE GARNISH,WHEEL ARCH				
	1	M201083-0800	ARCH, FR WHEEL HOUSE, RH	1	1
	2	M201083-0200	THRESHOLD TRIM, FR FLOOR, RH	1	1
	3	Y083-020	CLIP	19	19
	4	M201083-0400	THRESHOLD TRIM, RR FLOOR, RH	1	1
	5	M201083-0500	THRESHOLD TRIM, BACK DOOR	1	
	6	M201083-0300	THRESHOLD TRIM, RR FLOOR, LH	1	1
	7	M201083-0100	THRESHOLD TRIM, FR FLOOR, LH	1	1
	8	M201083-0700	ARCH, FR WHEEL HOUSE, LH	1	1
	9	Y083-080	PIN, PLASTIC	1	1
	95103-30 乘客三人座总成				
	95103-30 SEAT ASSY,3RD				
	1	7300200-Y11	SEAT ASSY, 3RD	1	
	2	M201084-0103	ADJUSTER, 3RD SEAT	1	






22203-20 后驱动桥总成				
22203-20 REAR AXLE				
1	M201027-1400	RR AXLE ASSY	1	1
2	M201027-0100	HOUSING COMP, RR AXLE	1	1
3	M201027-0101	PLUG, AIR	1	1
4	Y047-050	PLUG AND GASKET, OIL FILLER	1	1
5	M201027-0105	PLATE, BEARING	2	2
6	Y047-070	PLUG AND GASKET, OIL DRAIN	1	1
7	CM10030-1600	HOLDER, OIL SEAL	2	2
8	M201027-0109	OIL SEAL, RR AXLE	2	2
9	CM10030-1400	RETAINER RING, RR AXLE	2	2
10	R101027-1100	BEARING, RR AXLE	2	2
11	CM10030-1200	SPACER, RR AXLE	2	2
12	M201027-1300	HALF SHAFT ASSY, RR AXLE	2	2
13	M201027-0114	BOLT, WHEEL	8	8







95202-40 侧围焊接总成				
95102-40 SIDE BODY PANEL WELDING ASSY				
1	M201051-1600	PANEL ASSY, SIDE BODY, LH	1	
1	5401200-Y01	PANEL ASSY, SIDE BODY, RH	1	
1	M201351-1600	PANEL ASSY, SIDE BODY, LH		1
1	M201351-1601	PANEL ASSY, SIDE BODY, RH		1
2	M201059-7800	REINF ASSY, UPPER RAIL, LH	1	1
2	M201059-7900	REINF ASSY, UPPER RAIL, RH	1	1
3	M201059-8003	WEATHERSTRIP, SIDE PANEL, LH	1	1
3	M201059-8004	WEATHERSTRIP, SIDE PANEL, RH	1	1



[illegible]

[illegible]

	84306-00 照明系统				
	84306-00 LIGHT SYSTEM				
	2	MD201096-0003	LAMP ASSY, FR COMBINATION, LH	1	1
	2	MD201096-0004	LAMP ASSY, FR COMBINATION, RH	1	1
	3	B201028-0400	LAMP ASSY, FR ROOF	1	1
	5	M201096-0700	LAMP ASSY, HIGH MOUNTING STOP	1	
	12	M201096-0800-AA	LAMP ASSY, RR COMBINATION, LH	1	1
	6	M201096-0900-AA	LAMP ASSY, RR COMBINATION, RH	1	1
	10	M201096-1000-AA	LAMP ASSY, RR DECORATIVE, LH	1	1
	7	M201096-1100-AA	LAMP ASSY, RR DECORATIVE, RH	1	1
	11	M201096-1200-AB	LAMP ASSY,REAR FOG,LH	1	1
	8	M201096-1300-AB	LAMP ASSY,REAR FOG,RH	1	1
	9	Y034-090	LAMP ASSY, LICENSE	2	2
	84315-20 电线束				
	84315-20 WIRING HARNESS				
	1	M201103-0100	WIRING HARNESS, DASHBOARD	1	1
	2	M201103-0200	WIRING HARNESS, CHASSIS	1	1
	3	M201103-0300	WIRING HARNESS, ROOF	1	1
	6	M201103-0600	WIRING HARNESS, BACK DOOR	1	
	4	M201EV01-0034	WIRING HARNESS, BACK DOOR		1
	7	M201103-0700	WIRING HARNESS, BATTERY GROUND	1	1
	8	M201103-0800	WIRING HARNESS, TRANSMISSION GROUND	1	1
	9	M201103-0900	WIRING HARNESS,FUEL PUMP	1	1


	95108-20 全车锁			
	95108-20 LOCK SET			
	1	M201100-0000	LOCK SET	1
	1	M201700-0087	LOCK SET	1
	74101-10 空调系统			
	74101-10 A/C SYSTEM			
	1	M201093-0100-AA	CONDENSER ASSY, A/C	1
	3	M201093-0600-AA	HOSE, FR EVAPORATOR, OUTLET	1
	4	M201093-1600	HOSE ASSY, DISCHARGE, NO.1(HIGH PRESSURE)	1
	4	MS201093-2100	HOSE ASSY, DISCHARGE, NO.1(HIGH PRESSURE)	1
	5	M201093-2900	HOUSING, ROOF EVAPORATOR, RH	1
	6	M201093-2400	EVAPORATOR ASSY, ROOF	1
	7	Y104-610	OUTLET PIPE, ROOF EVAPORATOR, RH	2
	8	M201093-3000	HOUSING, ROOF EVAPORATOR, LH	1
	9	M201093-2600	INLET PIPE, ROOF EVAPORATOR	1
	10	M201093-2500	HOSE ASSY, SUCTION, NO.3	1
	11	M201093-1900	HOSE ASSY, SUCTION, NO.2	1
	12	M201093-0800	HOSE, FR EVAPORATOR, INLET	1
	12	MD201093-0005-AA	HOSE, FR EVAPORATOR, INLET	1
	13	F202098-0800	FAN, CONDENSER	1
	14	MD201093-0013	CONTROLLER ASSY, A/C	1
	15	EA012-1101	COMPRESSOR ASSY	1
	15	EA012-1100	COMPRESSOR ASSY	1
	16	M201093-1800	HOSE ASSY, SUCTION, NO.1(LOW PRESSURE)	1
	16	MD201093-0017	HOSE ASSY, SUCTION, NO.1(LOW PRESSURE)	1
	17	M201093-1000-AB	HVAC (HEATING, VENTILATING AND A/C)	1

	84305-10 音响系统			
	84305-10 RADIO AND ANTENNA			
	1	M201095-0200	HARNESS, ANTENNA	1
	2	M201095-0100	ANTENNA, AM/FM	1
	3	M201095-0600-AA	HORN ASSY	1
	4	MD201095-0400	SPEAKER ASSY	2
	5	MD201095-0013	RADIO ASSY	1
	95103-40 前排座椅总成			
	95103-40 SEAT ASSY,FR			
	1	M201086-0100	SEAT ASSY, DRIVER	1
	1	M201600-0048	SEAT ASSY, DRIVER	1
	1	M201086-0300	SEAT ASSY, CO-DRIVER	1
	1	M201600-0049	SEAT ASSY, CO-DRIVER	1
	2	BX097-013	LOCK, DRIVER'S SEAT	2


	95109-20 前、后地毯总成			
	95109-20 CARPET			
	1	M201089-0100	CARPET, FR FLOOR	1
	2	Y082-040	CLIP	2
	3	5109600-Y10	CARPET, RR FLOOR	1
	3	M201700-0036	CARPET, RR FLOOR	1
	12103-10 后悬架钢板弹簧总成			
	12103-10 LEAF SPRING ASSY			
	1	M201045-0100	LEAF SPRING ASSY	2
	2	M201045-0200	PLATE, SADDLE, LH	1
	2	M201045-0201	PLATE, SADDLE, RH	1
	3	Y043-150	NUT	1
	4	F202045-0700	JOINT PLATE, INNER	2
	5	F202045-0900	JOINT PLATE, OUTER	2
	6	F202045-0800	BUSH, RR SUSPENSION	4
	7	R101045-0400	U-BOLT, RR LEAF SPRING	4
	8	R101045-0300	CUSHION, RR SPRING	2
	9	M201045-1600	ABSORBER ASSY, RR SHOCK	2



53107-10 燃油箱总成				
53107-10 FUEL TANK ASSY				
1	M201046-0100	FUEL TANK ASSY	1	1
2	Y101-140	HOOP	2	2
3	M201079-0006	HOSE, FUEL EVAPORATION	1	1
4	Y101-150	CLAMP	2	2
5	M201046-0700	PIPE, FUEL EVAPORATION	1	1
6	Y101-080	CLAMP	2	2
7	M201046-0101	HOSE, FUEL FILLER	1	1
8	Y056-160	HOOP	2	2
9	M201046-0102	BREATHER HOSE, FUEL TANK	1	1
10	Y101-100	CLIP, FUEL TANK BREATHER HOSE	1	1
11	Y101-110	CLAMP	2	2
12	M201046-0109	NECK ASSY, FUEL FILLER	1	1
13	Y101-050	GASKET, FUEL FILLER NECK	1	1
14	C201129-1000	CAP, FUEL FILLER	1	
14	MS201177-0234	CAP, FUEL FILLER		1
15	M201046-3701	EVAPORATION HOSE II, FUEL	1	1



12104-10 轮胎及轮盘轮辋				
12104-10 WHEEL AND TIRE				
1	M201048-0300	TIRE, 165/70R14LT	5	5
2	M201048-0102	WHEEL ASSY, STEEL(14X5J)	5	5
3	Y048-040	VALVE, TYRE	5	5
4	M201048-0700	WHEEL COVER	4	4
5	MD201078-1103	NUT, WHEEL	16	16







12104-20 备胎架				
12104-20 SPARE TIRE CARRIER				
1	M201030-0100	CARRIER ASSY, SPARE TIRE	1	1
2	Y073-050	CABLE, SPARE TIRE CARRIER	1	1
3	Y073-060	BOLT	4	4


[illegible]


	95201-50 前上构件、前壁板				
	95201-50 FR UPPER MEMBER AND DASH PANEL				
	1	M201053-0100	UPPER MEMBER, FR	1	1
	2	M201053-1602	DASH PANEL ASSY	1	1
	3	M201083-1009	REINF, DASH PANEL SIDE, LH	1	1
	3	M201083-1008	REINF, DASH PANEL SIDE, RH	1	1
	4	M201083-1012	SIDE PIECE, DASH PANEL, LH	1	1
	4	M201083-1013	SIDE PIECE, DASH PANEL, RH	1	1
	5	M201012-1401	MUDGUARD, ENGINE, RH	1	1
	6	M201012-1402	MUDGUARD, ENGINE, RR	1	1
	7	M201084-0800	MEMBER ASSY, ENGINE ROOM, CENTER	1	1
	53107-20 燃油管路及燃油泵				
	53107-20 FUEL DIDELINE AND FUEL PUMP				
	1	M201015-1201	CANISTER ASSY, WITH HOSE	1	1
	2	M201046-3700	PIPE, FUEL EVAPORATION	1	1
	3	Y013-060	PLATE, FUEL PUMP	1	1
	4	EA025-0100	FUEL PUMP ASSY	1	1
	5	Y101-150	CLAMP	2	2
	6	M201079-0006	HOSE, FUEL EVAPORATION	1	1
	7	M201015-0700-AA	FUEL PIPE, NYLON	1	1
	8	M201015-0800-AA	PIPE, NYLON FUEL, RETURN	1	1
	9	CM5013-0201	FILTER ASSY, FUEL	1	1
	10	C201130-1400	CLIP	2	2
	11	Y101-150	CLAMP	2	2
	12	M201039-0005	HOSE, FUEL	1	1


	53105-30 油门拉索			
	53105-30 ACCELERATOR CABLE			
	1	M201018-0100	CABLE ASSY, ACCELERATE	1
	63401-20 离合器拉索总成			
	63401-20 CLUTCH CABLE ASSY			
	1	M201022-0100-BA	CABLE ASSY, CLUTCH	1

	63404-10 换挡操纵总成			
	63404-10 GEAR SHIFT CONTROL SYSTEM			
	1	M201023-0100	LEVER ASSY, GEAR SHIFT CONTROLLER	1 1
	2	M201023-0300	CABLE ASSY, GEAR SHIFT CONTROL	1 1
	3	M201023-0200	CABLE ASSY, GEAR SELECT CONTROL	1 1
	22204-10 传动轴带万向节总成			
	22204-10 PROPELLER SHAFT			
	1	M201024-0100	SHAFT ASSY, PROPELLER	1 1

	53112-10 踏板总成			
	53112-10 ACCELERATOR PEDAL ASSY			
	1	M201032-0101	PEDAL ASSY, ACCELERATOR	1
	2	M201032-0102-AA	PEDAL ASSY, WITH BRAKE LAMP SWITCH	1
	32305-10 制动总泵			
	32305-10 BRAKE MASTER CYLINDER			
	1	M201600-0004	CYLINDER ASSY, BRAKE MASTER	1

[illegible]


[illegible]



32302-10 后轮制动器

32302-10 RR BRAKE



1	M201037-0100	RR BRAKE ASSY, LH	1	1
1	M201037-0101	RR BRAKE ASSY, RH	1	1
2	M201037-0200	PLATE ASSY, RR WHEEL BRAKE, LH	1	1
2	M201037-0201	PLATE ASSY, RR WHEEL BRAKE, RH	1	1
3	M201037-0300	PIN, SHOE HOLD	4	4
4	CM10039-0700	CYLINDER ASSY, RR BRAKE, LH	1	1
4	CM10039-0701	CYLINDER ASSY, RR BRAKE, RH	1	1
5	M201037-0301	RETURN SPRING, UPPER	2	2
6	M201037-0302	SPRING, SHOE RETURN UPPER, LH	2	2
7	M201037-0303	ANCHOR, ADJUST BRAKE SHOE, LH	1	1
7	M201037-0304	ANCHOR, ADJUST BRAKE SHOE, RH	1	1
8	M201037-0305	BOARD, BRAKE SHOE ADJUST, LH	1	1
8	M201037-0306	BOARD, BRAKE SHOE ADJUST, RH	1	1
9	M201037-1600	SHOE ASSY, RR BRAKE, LH	1	1
9	M201037-1700	SHOE ASSY, RR BRAKE, RH	1	1
10	M201037-1100	SPRING, BRAKE SHOE HOLD	4	4
11	M201037-1200	SEAT, BRAKE SHOE HOLD SPRING	4	4
12	M201037-0307	SPRING, LOWER SHOE RETURN	2	2
13	M201037-1500	DRUM ASSY, RR BRAKE	2	2







32304-10 驻车制动器总成


32304-10 PARKING BRAKE

1	F202038-0100	LEVER ASSY, PARKING BRAKE	1	1
2	M201038-0300	CABLE ASSY, PARKING BRAKE NO.1	1	1
3	M201038-0500	CABLE ASSY, PARKING BRAKE NO.2, RH	1	1
4	M201038-0400	CABLE ASSY, PARKING BRAKE NO.2, LH	1	1


	42404-10 方向盘			
	42404-10 STEERING WHEEL			
	1	M201039-0100	COVER, STEERING WHEEL	1 1
	2	M201039-0200	STEERING WHEEL ASSY	1 1
	3	P050-0800	NUT	1 1
	42404-11 转向柱			
	42404-11 STEERING SHAFT			
	1	R101040-0600	DUSTPROOF COVER, STEERING SHAFT	1 1
	2	M201040-0200	SHAFT ASSY, STEERING, LOWER	1 1
	3	M201040-0100	SHAFT ASSY, STEERING, UPPER	1 1
	4	P050-0800	NUT	1 1



	42402-20 转向器总成			
	42402-20 STEERING GEAR ASSY			
	1	M201041-0100	STEERING GEAR ASSY	1
	2	Y052-270	WASHER, STEERING TIE-ROD LOCK	2
	3	F202041-0200	TIE-ROD ASSY, STEERING, LH	1
	4	F202041-0300	TIE-ROD ASSY, STEERING, RH	1
	5	M201062-0305	BRACKET, STEERING GEAR	1
	12102-10 前悬架总成			
	12102-10 FR SUSPENSION			
	1	M201042-0130	FRAME ASSY, FR SUSPENSION	1
	2	F202043-0401	ARM ASSY, FR SUSPENSION, RH	1
	2	F202043-0400	ARM ASSY, FR SUSPENSION, LH	1
	3	Y043-150	NUT M10	1
	4	Y043-140	BOLT M10×1.25×50	1
	5	F202042-0700	ROD ASSY, FR SUSPENSION, LH	1
	5	F202042-0800	ROD ASSY, FR SUSPENSION, RH	1
	6	M201042-0300-AB	STEERING SUPPORT ASSY	1


	12102-30 前稳定杆			
	12102-30 FR STABILIZER BAR			
	1	M201043-0100	FR STABILIZER BAR	1
	2	M201049-6301	STABILIZER LINK	2
	3	F202043-0600	CUSHION, STABILIZER LINK	4
	4	Y044-090	WASHER	4
	5	Y043-150	NUT M10	1
	6	F202046-0101	BUSHING, FR STABILIZER BAR	2
	12102-20 前支柱总成			
	12102-20 ABSORBER & STRUT ASSY, FR SUSPENSION			
	1	M201044-0100	ABSORBER AND STRUT ASSY, FR SUSPENSION, LH	1
	1	M201044-0101	ABSORBER AND STRUT ASSY, FR SUSPENSION, RH	1






95108-10 前门锁及内装饰件				
95108-10 FR DOOR LOCK AND INNER TRIM				
1	M201057-0100	PANEL ASSY, FR DOOR, LH	1	
1	M201057-0200	PANEL ASSY, FR DOOR, RH	1	
1	M201600-0037	PANEL ASSY, RR DOOR, LH		1
1	M201600-0035	PANEL ASSY, FR DOOR, RH		1
2	M201057-0300	HINGE, FR DOOR	4	2
3	M201057-0500	TIE ROD, FR DOOR	2	2
4	M201057-0901-AA	TRIM PIECE, FR QUARTER, LH	1	1
4	M201057-1001-AA	TRIM PIECE, FR QUARTER, RH	1	1
5	M201057-1101	TRIM BOARD, FR DOOR, LH	1	1
5	M201057-1201	TRIM BOARD, FR DOOR, RH	1	1
6	M201057-0401	HANDLE ASSY, FR DOOR INNER, LH	1	1
6	M201057-1401	HANDLE ASSY, FR DOOR INNER, RH	1	1
7	M201057-2002	HANDLE COVER, FR WINDOW REGULATOR	2	2
8	M201057-1901	HANDLE, FR WINDOW REGULATOR	2	2
9	Y083-020	CLIP	11	11
10	M201057-1701	LOCK ASSY, FR DOOR, LH	1	1
10	M201057-1801	LOCK ASSY, FR DOOR, RH	1	1
11	M201057-2200	LATCH ASSY, FR HOOD	2	2
12	M201057-2403	HANDLE ASSY, FR DOOR OUTER, LH	1	1
12	M201057-2503	HANDLE ASSY, FR DOOR OUTER, RH	1	1
13	M201057-0501	HANDLE ASSY, FR DR OPENING, LH	1	1
13	M201057-1501	HANDLE ASSY, FR DR OPENING, RH	1	1




[illegible]




	95110-10 前罩及附件			
	95110-10 FR HOOD AND ACCESSORIES			
	1	M201060-0100-CA	PANEL ASSY, FR HOOD	1 1
	2	M201060-0200	HINGE, FR HOOD, RH	1 1
	3	Y065-090	SIDE CUSHION, FR HOOD	2 2
	4	Y065-070	SEAT, FR HOOD SUPPORT	1 1
	5	M201060-0500-AA	STAY, FR HOOD	1 1
	6	Y065-060	CLIP, FR HOOD SUPPORT	1 1
	7	M201060-0700	LATCH ASSY, FR HOOD	1 1
	8	M201060-1000	HINGE, FR HOOD, LH	1 1
	9	M201060-1200	CABLE, FR HOOD	1 1
	10	M201060-1201-AA	HANDLE, FR HOOD CABLE	1 1
	11	M201060-1500	COWL GARNISH	1 1
	12	M201060-1501	END COVER, COWL, LH	1 1
	13	M201060-1400	WEATHERSTRIP, FR HOOD	1 1
	14	Y084-200	PLASTIC CLIP	4 4
	15	M201060-1502	END COVER, COWL, RH	1 1
	16	M201060-1700	PANEL ASSY, COWL	1 1
	95101-10 前挡风玻璃			
	95101-10 FR WINDSHIELD			
	1	M201060-1402	GLASS, FR WINDSHIELD	1 1
	2	M201060-1401	WEATHERSTRIP, FR WINDSHIELD	1 1


[illegible]

[illegible]


	95107-10 前保险杠总成				
	95107-10 FR BUMPER				
	1	Y084-200	PLASTIC CLIP	2	2
	2	M201076-0012	GRILL, FR BUMPER, UPPER	1	
	2	M201700-0010	GRILL, FR BUMPER, UPPER		1
	3	CM5104-2000	CHANA EMBLEM, FR	1	1
	4	M201076-0400	BRACKET, FR BUMPER, RH	1	1
	5	M201076-0001	FR BUMPER ASSY	1	
	5	M201076-0022	FR BUMPER ASSY		1
	6	M201076-0300	BRACKET, FR BUMPER, LH	1	1
	7	Y074-070	NUT, LICENSE PLATE	4	4
	8	M201076-0200	GRILL, FR BUMPER, LOWER	1	1
	9	M201076-0301	SIDE SUPPORT, FR BUMPER	2	2
	95106-20 控制箱				
	95106-20 CONSOLE BOX				
	1	M201077-0100	BOX ASSY, CONSOLE	1	1
	2	M201077-0300	CUP, CONSOLE BOX, RR	1	1
	3	M201077-0400	COVER, CONSOLE BOX, RR	1	1

 	95105-10 后视镜			
	95105-10 REARVIEW MIRROR			
	1	M201079-0100	MIRROR ASSY, INSIDE VIEW	1
	2	M201079-0011	MIRROR ASSY, OUTSIDE VIEW, LH	1
	2	M201079-0022	MIRROR ASSY, OUTSIDE VIEW, RH	1
	2	M201079-0001	MIRROR ASSY, OUTSIDE VIEW, LH	1
	2	M201079-0002	MIRROR ASSY, OUTSIDE VIEW, RH	
   	95110-20 前、后挡泥板			
	95110-20 MUDGUARD FLAP			
	1	M201080-0100	FR MUDGUARD, LH	1
	2	M201080-0200	FR MUDGUARD, RH	1
	3	M201080-0300	RR MUDGUARD, LH	1
	4	M201080-0400	RR MUDGUARD, RH	1



	84312-10 导流板			
	84312-10 WIND GUIDE PLATE			
	1	M201081-0101	WIND GUIDING COVER, FR	1
	2	M201081-0102	WIND GUIDING COVER, CENTER	1
	95111-60 三角窗外装饰件总成			
	95111-60 OUTER GARNISH, FR TRIANGLE			
	1	M201142-0002	WIND GUIDE, RADIATOR, RH	1
	2	M201142-0001	WIND GUIDE, RADIATOR, LH	1
	01101-10 千斤顶总成			
	01101-10 ACK ASSY			
	1	MD201087-0200	JACK ASSY	1
	2	M201087-0100	HANDLE, JACK	1
	3	M201087-0102-AA	INSULATOR, ENGINE ROOM, LH	1
	4	M201087-0103	INSULATOR, ENGINE ROOM, MID	1
	5	M201087-0104	INSULATOR, ENGINE ROOM, RH	1
	6	M201087-0105	FR INSULATOR, RR FLOOR	1






95106-10 仪表台板				
95106-10 INSTRUMENT PANEL				
1	M201090-0101	INSTRUMENT PANEL ASSY	1	1
2	M201090-0200	VENT ASSY, SIDE	2	2
3	M201090-1101	BOX ASSY, GLOVE	1	1
4	M201090-1001	ASHTRAY ASSY	1	1
5	M201090-0903	PANEL, CENTER CONTROL	1	1
6	M201090-0204	VENT ASSY, CENTRAL, RH	1	1
7	M201090-0203	VENT ASSY, CENTRAL, LH	1	1
8	M201090-0701	LOWER COVER, INSTRUMENT PANEL, LH	1	1
9	M201090-0500	STEERING COVER, LOWER	1	1
10	M201090-0400	STEERING COVER, UPPER	1	1
12	M201090-0300	COVER, COMBINATION METER	1	1
13	M201090-1400	CAP, INSTRUMENT PANEL	1	1
14	M201090-1500	CAP, INSTRUMENT PANEL	1	1
15	M201090-1600	CAP, INSTRUMENT PANEL	1	1
16	Y036-150	FLASHER ASSY	1	1





95106-30 风道系统				
95106-30 AIR PIPE				
1	M201098-0103	PIPE ASSY, DEFROSTER, CENTER	1	1
2	M201098-0200	PIPE ASSY, DEFROSTER, LH	1	1
3	M201098-0500	AIR PIPE, LH	1	1
4	M201098-0400	AIR PIPE, CENTER	1	1
5	M201098-0600	AIR PIPE, RH	1	1
6	M201098-0202	PIPE ASSY, DEFROSTER, RH	1	1

	84307-20 洗涤器总成			
	84307-20 WASHER ASSY			
	1	Y039-020	NOZZLE ASSY, WASHER, FR	2
	2	M201099-0200	HOSE ASSY, WASHER	1
	3	M201099-0500	WASHER ASSY, FR WINDSHIELD	1
	84301-10 开关及电控设备			
	84301-10 SWITCH ASSY, COMBINATION AND ELECTRICAL CONTROL			
	2	M201100-0301	SWITCH ASSY, COMBINATION	1
	3	M201100-0600	SWITCH ASSY, HAZARD	1
	5	F202100-0100	SWITCH, FR DOOR SIGNAL LAMP	4
	6	B201030-0900	CAP, OPTION SWITCH HOLE	2
	7	M201100-1000	SWITCH, LIGHTING ANGLE CONTROL	1

[illegible]

	53104-10 冷却系统			
	53104-10 COOLING SYSTEM			
	1	M201098-0300	BRACKET, RADIATOR, UPPER	1
	2	M201098-0100-AA	RADIATOR ASSY	1
	3	M201098-0104	HOSE, RADIATOR, INLET	1
	4	M201098-0102	HOSE, RADIATOR, OULET	1
	5	Y016-040	BRACKET, REDIATOR MOUNTING	2
	6	F202098-0900	FAN ASSY, RADIATOR	1
	7	M201098-0800	3 WAY	1
	8	M201098-0900-AA	WATER TANK	1
	9	M201098-1000	HOSE, HEATER INLET	1
	10	M201098-1200	JOINTING WITH TUBE, HEATER	1
	11	1303900-Y02	WATER PIPE ASSY, FLOOR	1
	11	M201098-1305	WATER PIPE ASSY, FLOOR	1
	12	1312012-Y02	HOSE, ENGINE TO HEATER	1
	12	M201098-1600	HOSE, ENGINE TO HEATER	1
	13	1303022-Y02	WATER PIPE, ENGINE, OUTLET	1
	13	M201098-1700	WATER PIPE, ENGINE, OUTLET	1
	14	M201098-1400	WATER PIPE, ENGINE, INLET	1
	15	M201098-0201	BRACKET, WATER TANK	1
	16	M201098-1800	HOSE, RADIATOR AIR OVERFLOW	1
	84307-10 刮水器总成			
	84307-10 WIPER ASSY			
	2	M201099-0112	BLADE ASSY, FR WIPER, SUB	1
	3	M201099-0111	ARM ASSY, FR WIPER SUB	1
	4	Y038-080	CAP, WIPER ARM HOLE	2
	6	M201099-0412	BLADE, FR WIPER, SUB	1
	7	M201099-0411	ARM, FR WIPER, SUB	1
	8	M201099-0600-AA	MOTOR AND ARM, FR WIPER	1
	9	M201099-0661	MOTOR, FR WIPER	1
	10	M201099-0664	LINK, FR WIPER	1

	95102-40 中门中导轨盖板总成			
	95102-40 RAIL COVER,RR DOOR CENTER			
	1	M201059-0102	COVER, RR DOOR CENTER RAIL, LH	1
	1	M201059-0202	COVER, RR DOOR CENTER RAIL, RH	1
	95102-70 后侧围玻璃			
	95102-70 SIDE WINDOW GLASS			
	1	M201059-0800	GLASS, SIDE WINDOW, LH	1
	1	M201059-0801	GLASS, SIDE WINDOW, RH	1
	2	M201059-0815	LOCK ASSY, SIDE WINDOW, LH	1
	2	M201059-0816	LOCK ASSY, SIDE WINDOW, RH	1
	3	M201059-0804	WEATHERSTRIP, RR SIDE WINDOW	2
	4	M201059-0811	HINGE, RR SIDE WINDOW	4