
PARTS LIST

RUBBER CRAWLER CARRIER

MST-600VD

Serial No. 60301 and up

MOROOKA

PARTS LIST

RUBBER CRAWLER CARRIER

MST-600VD

Serial No. 60301 and up

FOREWORD

Thank you for purchasing this Morooka Rubber Crawler Carrier.
When ordering a part, please specify the model serial number, the engine serial number and the reading of the hourmeter.

READING FOR PARTS LIST

For complete understanding, the parts list is written as follows.


Fig. Number	Figure numbers are not continuous.
Description	“▪” is put in front of the name of an assembly component and the item is entered next to the assembly. If part marked with “▪” is an assembly, its component is part marked with “▪▪”.
Quantity	The number of pieces per set used for assembly is specified. For assembly or part group components, the number of pieces per assembly is specified.
Serial number	The engine or machine serial number in which the part is used.
Codes	The codes and part number specified in the “Part No.” and “Part name” columns represent the following: ☐ The part specified in the line above is applicable instead of this part. ☆ Supplied as a set rather than singly.

CONTENTS

Item	FIG. No.	PAGE
FORWARD	—	A – 2
CONTENTS	—	0 – 1
ENGINE RELATED PARTS (ENGINE MOUNTING PARTS AND RADIATOR)	101	1 – 2
ENGINE RELATED PARTS (MAIN PUMP AND MOUNTING PARTS)	105	1 – 6
ENGINE RELATED PARTS (AIR INTAKE SYSTEM)	111	1 – 8
ENGINE RELATED PARTS (EXHAUST SYSTEM)	115	1 –10
FUEL TANK AND FUEL PIPING	121	1 –12
FRAME RELATED PARTS (1/6) (RADIATOR GUAR AND FRONT BUMPER)	201	1 –14
FRAME RELATED PARTS (2/6) (UNDER COVER AND SAFETY BAR)	202	1 –16
FRAME RELATED PARTS (3/6) (ENGINE BONNET)	203	1 –18
FRAME RELATED PARTS (4/6) (ENGINE SIDE COVER AND MONITOR PANEL SUPPORT)	204	1 –20
FRAME RELATED PARTS (5/6) (BATTERY BOX)	205	1 –22
FRAME RELATED PARTS (6/6) (OPERATOR'S SEAT AND FOOT REST)	206	1 –24
CANOPY RELATED PARTS	211	1 –26
UNDER CARRIAGE RELATED PARTS (TRAVEL MOTOR AND IDLER)	301	1 –28
UNDER CARRIAGE RELATED PARTS (CARRIER ROLLER)	311	1 –30
UNDER CARRIAGE RELATED PARTS (TRACK ROLLER)	321	1 –32
STEERING CONTROL SYSTEM (1/2)	401	1 –34
STEERING CONTROL SYSTEM (2/2)	402	1 –36
ENGINE CONTROL SYSTEM	411	1 –38
DUMP CONTROL SYSTEM	421	1 –40
HYDRAULIC PIPING (CONTROL VALVE AND DUMP CYLINDER LINE)	501	1 –42
HYDRAULIC PIPING (MAIN PUMP CHARGE LINE)	502	1 –44
HYDRAULIC PIPING (HST MAIN LINE)	503	1 –46
HYDRAULIC PIPING (PARKING BRAKE AND H-L SPEED SELECTOR VALVE LINE)	504	1 –48
HYDRAULIC PIPING (OIL COOLER AND RETURN LINE)	505	1 –50
HYDRAULIC OIL TANK	551	1 –52
HYDRAULIC OIL FILTER	555	1 –54
DUMP BODY RELATED PARTS	601	1 –56
ELECTRICAL SYSTEM (INSTRUMENT PANEL AND CONTROL BOX)	701	1 –58
ELECTRICAL SYSTEM (WIRING HARNESS AND LAMPS)	711	1 –60
ELECTRICAL SYSTEM (RELAYS AND FUSE BOX)	713	1 –64
ELECTRICAL SYSTEM (BATTERY AND BATTERY RELAY)	715	1 –66
MARKS AND PLATES (JAPANESE)	801	1 –68
MARKS AND PLATES (ENGLISH)	811	1 –70
NUMERICAL INDEX	—	9 – 1

MST-600VD

FIG.101 ENGINE RELATED PARTS
(ENGINE MOUNTING PARTS AND RADIATOR)




PV93300

FIG.101


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	1-50100-2000	ENGINE ASS'Y (ISUZU 1AA-4JG1T)	1	60301 ~
2	1-50110-2110	FRONT BRACKET	2	60301 ~
3	0-1000-31030	BOLT (M10X30)	2	60301 ~
4	0-1120-01020	PLANE WASHER (M10)	2	60301 ~
5	0-1200-01008	NUT (M10)	2	60301 ~
6	0-1100-01025	SPRING WASHER (M10)	2	60301 ~
7	1-50110-2120	REAR BRACKET	2	60301 ~
8	0-1000-31025	BOLT (M10X25)	8	60301 ~
9	0-1100-01025	SPRING WASHER (M10)	8	60301 ~
10	1-11110-1110	CUSHION	4	60301 ~
11	0-1000-31235	BOLT (M12X35)	8	60301 ~
12	0-1200-01210	NUT (M12)	12	60301 ~
13	0-1100-01230	SPRING WASHER (M12)	12	60301 ~
14	0-1120-01223	PLANE WASHER (M12)	12	60301 ~
15	1-50140-0020	RADIATOR ASS'Y	1	60301 ~
16	1-50140-2180	FAN GUARD	1	60301 ~
17	0-1000-00816	BOLT (M8X16)	4	60301 ~
18	0-1100-00820	SPRING WASHER (M8)	4	60301 ~
19	0-1120-00816	PLANE WASHER (M8)	4	60301 ~
20	1-17140-1211	OIL COOLER ASS'Y	1	60301 ~
21	1-50140-2250	LEFT SIDE BRACKET	1	60301 ~
22	1-50140-2260	RIGHT SIDE BRACKET	1	60301 ~
23	0-1000-00820	BOLT (M8X20)	4	60301 ~
24	0-1120-00816	PLANE WASHER (M8)	4	60301 ~
25	0-1200-00806	NUT (M8)	4	60301 ~
26	0-1100-00820	SPRING WASHER (M8)	4	60301 ~
27	1-50140-2270	LEFT SIDE BRACKET	1	60301 ~
28	1-50140-2280	RIGHT SIDE BRACKET	1	60301 ~
29	0-1000-00825	BOLT (M8X25)	4	60301 ~
30	0-1100-00820	SPRING WASHER (M8)	4	60301 ~
31	0-1120-00816	PLANE WASHER (M8)	4	60301 ~
32	1-50140-2310	INLET HOSE	1	60301 ~
33	1-50140-2320	OUTLET HOSE	1	60301 ~
34	0-2710-00056	CLAMP	4	60301 ~
35	1-50140-2330	LEFT SIDE BRACKET	1	60301 ~
36	1-50140-2340	RIGHT SIDE BRACKET	1	60301 ~
37	0-1000-01020	BOLT (M10X20)	4	60301 ~
38	0-1200-01008	NUT (M10)	4	60301 ~
39	0-1100-00820	SPRING WASHER (M8)	4	60301 ~
40	0-1120-00816	PLANE WASHER (M8)	4	60301 ~

FIG.101 ENGINE RELATED PARTS
(ENGINE MOUNTING PARTS AND RADIATOR)




PV93300

FIG.105 ENGINE RELATED PARTS (MAIN PUMP AND MOUNTING PARTS)



PV93301

FIG.111 ENGINE RELATED PARTS (AIR INTAKE SYSTEM)




PV93303

FIG.111

[illegible]

FIG.115 ENGINE RELATED PARTS (EXHAUST SYSTEM)




PV93305

FIG.115


[illegible]

FIG.121 FUEL TANK AND FUEL PIPING



PV93307

FIG.201 FRAME RELATED PARTS (1/6)
(RADIATOR GUAR AND FRONT BUMPER)




PV93309

FIG.201

[illegible]

FIG.202 FRAME RELATED PARTS (2/6)
(UNDER COVER AND SAFETY BAR)




PV93311A

FIG.202

[illegible]

FIG.203 FRAME RELATED PARTS (3/6) (ENGINE BONNET)




PV93313

FIG.203

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
	1-50520-0020	ENGINE COVER ASS'Y	1	60301 ~
1	1-50520-2150	•COVER	1	60301 ~
2	1-29520-1521	•CATCHER	2	60301 ~
3	0-1090-00512	•BOLT WITH WASHER (M5X12)	4	60301 ~
4	0-1260-00505	•FLANGE NUT (M5)	4	60301 ~
5	1-41520-1380	•HANDLE	1	60301 ~
6	0-1090-00612	•BOLT WITH WASHER (M6X12)	2	60301 ~
7	1-41520-1670	•DUMPER	1	60301 ~
8	1-41520-1360	•BRACKET	1	60301 ~
9	0-1090-00612	•BOLT WITH WASHER (M6X12)	2	60301 ~
10	1-41520-1350	•BRACKET	1	60301 ~
11	0-1050-00616	•FLANGE BOLT (M6X16)	2	60301 ~
12	0-1260-00606	•FLANGE NUT (M6)	2	60301 ~
13	1-41520-1370	•BOLT	2	60301 ~
14	0-1200-00806	•NUT (M8)	2	60301 ~
15	0-1100-00820	•SPRING WASHER (M8)	2	60301 ~
16	0-1120-00816	•PLANE WASHER (M8)	2	60301 ~
17	1-29520-1460	•ANGLE	1	60301 ~
18	1-41520-1860	•HINGE (WELDED)	2	60301 ~
19	0-1090-00516	•BOLT WITH WASHER (M5X16)	4	60301 ~
20	0-1260-00505	•FLANGE NUT (M5)	4	60301 ~
21	0-1000-01020	BOLT (M10X20)	1	60301 ~
22	0-1100-01025	SPRING WASHER (M10)	1	60301 ~
23	0-1120-01020	PLANE WASHER (M10)	1	60301 ~
24	0-1000-01225	BOLT (M12X25)	4	60301 ~
25	0-1100-01230	SPRING WASHER (M12)	4	60301 ~
26	0-1120-01223	PLANE WASHER (M12)	4	60301 ~
27	1-50520-2210	AIR CLEANER SUPPORT	1	60301 ~
28	0-1000-01020	BOLT (M10X20)	4	60301 ~
29	0-1100-01025	SPRING WASHER (M10)	4	60301 ~
30	0-1120-01020	PLANE WASHER (M10)	4	60301 ~
31	1-50520-2220	REAR COVER	1	60301 ~
32	0-1000-01020	BOLT (M10X20)	5	60301 ~
33	0-1100-01025	SPRING WASHER (M10)	5	60301 ~
34	0-1120-01020	PLANE WASHER (M10)	5	60301 ~
35	1-50520-2240	REAR COVER	1	60301 ~
36	0-1000-01016	BOLT (M10X16)	2	60301 ~
37	0-1100-01025	SPRING WASHER (M10)	2	60301 ~
38	0-1120-01020	PLANE WASHER (M10)	2	60301 ~

FIG.204 FRAME RELATED PARTS (4/6)
(ENGINE SIDE COVER AND MONITOR PANEL SUPPORT)




PV93315

FIG.204

[illegible]

FIG.205 FRAME RELATED PARTS (5/6) (BATTERY BOX)



PV93316

FIG.206 FRAME RELATED PARTS (6/6)
(OPERATOR'S SEAT AND FOOT REST)





FIG.206

[illegible]

FIG.211 CANOPY RELATED PARTS




PV93318

FIG.211

[illegible]

FIG.301 UNDER CARRIAGE RELATED PARTS
(TRAVEL MOTOR AND IDLER)





PV90952

FIG.301


[illegible]

FIG.311 UNDER CARRIAGE RELATED PARTS (CARRIER ROLLER)




PV90794A

FIG.321 UNDER CARRIAGE RELATED PARTS (TRACK ROLLER)




PV93320

FIG.401 STEERING CONTROL SYSTEM (1/2)



PV92410

FIG.402 STEERING CONTROL SYSTEM (2/2)




PV93322

FIG.402


INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	1-50420-1210	OUTER SHAFT	1	60301 ~
2	1-12420-1250	•OUTER SHAFT LEVER (WELDED)	1	60301 ~
3	1-25420-1270	BUSHING	2	60301 ~
4	1-50420-1220	INNER SHAFT	1	60301 ~
5	1-12420-1270	WASHER	1	60301 ~
6	0-3300-01218	SNAP RING	1	60301 ~
7	1-25420-1290	INNER SHAFT LEVER	1	60301 ~
8	0-3260-00663	TAPER PIN	1	60301 ~
9	0-6102-00204	PILLOW BLOCK	1	60301 ~
10	1-12420-1280	GREASE NIPPLE	1	60301 ~
11	0-1000-01035	BOLT (M10X35)	2	60301 ~
12	0-1100-01025	SPRING WASHER (M10)	2	60301 ~
13	0-1120-01020	PLANE WASHER (M10)	2	60301 ~
14	0-6100-00206	PILLOW BLOCK	1	60301 ~
15	1-25420-1311	GREASE NIPPLE	1	60301 ~
16	0-1000-01255	BOLT (M12X55)	2	60301 ~
17	0-1120-01223	PLANE WASHER (M12)	2	60301 ~
18	0-1200-01210	NUT (M12)	2	60301 ~
19	0-1100-01230	SPRING WASHER (M12)	2	60301 ~
20	0-3000-01014	ROD (M10X140)	1	60301 ~
21	0-3000-01041	ROD (M10X410)	1	60301 ~
22	0-3100-11000	ROD END (M10)	2	60301 ~
23	0-1200-01008	NUT (M10)	4	60301 ~
24	0-1100-01025	SPRING WASHER (M10)	2	60301 ~
25	0-3130-01060	TURN BACKLE (M10X60)	2	60301 ~
26	0-3111-11000	ROD END (M10, LEFT THREAD)	2	60301 ~
27	0-1201-01008	NUT (M10, LEFT THREAD)	2	60301 ~
28	0-1200-01008	NUT (M10)	2	60301 ~
29	0-1100-01025	SPRING WASHER (M10)	2	60301 ~
30	0-3500-01020	COLLAR (Φ 10X20)	1	60301 ~
31	0-3500-01010	COLLAR (Φ 10X10)	1	60301 ~
32	0-1000-01050	BOLT (M10X50)	1	60301 ~
33	0-1000-01040	BOLT (M10X40)	1	60301 ~
34	0-1100-01025	SPRING WASHER (M10)	2	60301 ~
35	0-1220-01006	NUT (M10)	2	60301 ~

FIG.411 ENGINE CONTROL SYSTEM




PV93323

FIG.421 DUMP CONTROL SYSTEM




PV92437

FIG.501 HYDRAULIC PIPING
(CONTROL VALVE AND DUMP CYLINDER LINE)



PV93325


FIG.502 HYDRAULIC PIPING (MAIN PUMP CHARGE LINE)



PV93328


FIG.502

FIG.503 HYDRAULIC PIPING (HST MAIN LINE)




PV93330

FIG.504 HYDRAULIC PIPING
(PARKING BRAKE AND H-L SPEED SELECTOR VALVE LINE)




PV93331

FIG.505 HYDRAULIC PIPING (OIL COOLER AND RETURN LINE)




PV93332

FIG.551 HYDRAULIC OIL TANK



PV92442A

FIG.555 HYDRAULIC OIL FILTER




PV92443

FIG.555


[illegible]

FIG.601 DUMP BODY RELATED PARTS



PV93342


FIG.701 ELECTRICAL SYSTEM (INSTRUMENT PANEL AND CONTROL BOX)



PV93335

1-59

FIG.711 ELECTRICAL SYSTEM (WIRING HARNESS AND LAMPS)




PV93336

FIG.711

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	1-50210-1410	MAIN WIRING HARNESS	1	60301 ~
2	1-50210-1420	GROUND CONNECTION CABLE	1	60301 ~
3	0-1200-01008	NUT (M10)	1	60301 ~
4	0-1100-01025	SPRING WASHER (M10)	1	60301 ~
5	0-1120-01020	PLANE WASHER (M10)	1	60301 ~
6	1-30210-0010	HEAD LAMP ASS'Y	2	60301 ~
	1-29210-1230	•BULB	1	60301 ~
7	0-5120-02400	TURN SIGNAL LAMP ASS'Y	2	60301 ~
8	0-5600-02400	HORN	1	60301 ~
9	0-1200-00806	NUT (M8)	1	60301 ~
10	0-1120-00816	PLANE WASHER (M8)	1	60301 ~
11	0-1260-00808	FLANGE NUT (M8)	1	60301 ~
12	1-29210-1310	SLOPE ALARM UNIT	1	60301 ~
13	1-18210-1521	CUSHION	1	60301 ~
14	0-1260-00606	FLANGE NUT (M6)	4	60301 ~
15	1-28210-1520	BACK-UP BUZZER	1	60301 ~
16	0-1260-00808	FLANGE NUT (M8)	1	60301 ~
17	1-12210-1460	LIMIT SWITCH, FOR BACK-UP BUZZER	1	60301 ~
18	1-12210-1470	BRACKET (WELDED)	1	60301 ~
19	1-12210-1480	PLATE	1	60301 ~
20	0-1000-00430	BOLT (M4X30)	2	60301 ~
21	0-1100-00410	SPRING WASHER (M4)	2	60301 ~
22	0-1130-00408	PLANE WASHER (M4)	2	60301 ~
23	0-1000-00820	BOLT (M8X20)	1	60301 ~
24	0-1100-00820	SPRING WASHER (M8)	1	60301 ~
25	1-12210-1490	WIRING HARNESS	1	60301 ~
26	1-29210-1550	HST OIL PRESSURE SWITCH	1	60301 ~
27	0-5310-02024	ENGINE OIL PRESSURE SWITCH	1	60301 ~
28	0-5320-30024	ENGINE WATER TEMP. SENSOR	1	60301 ~
29	1-29210-1180	FUEL LEVEL SENSOR	1	60301 ~
30	1-29210-1570	HST OIL TEMPERATURE SENSOR	1	60301 ~
31	0-2720-01206	CLIP (SMALL)	AR	60301 ~
	0-2720-02506	CLIP (LARGE)	AR	60301 ~
32	0-1200-00605	NUT (M6)	AR	60301 ~
33	0-1100-00615	SPRING WASHER (M6)	AR	60301 ~
34	0-2750-00000	CLIP	AR	60301 ~
35	0-2830-01520	SPIRAL TUBE	AR	60301 ~
	0-2830-02420	SPIRAL TUBE	AR	60301 ~
	0-2830-02920	SPIRAL TUBE	AR	60301 ~

FIG.711 ELECTRICAL SYSTEM (WIRING HARNESS AND LAMPS)




PV93336

FIG.711


[illegible]

FIG.713 ELECTRICAL SYSTEM (RELAYS AND FUSE BOX)



PV93337

FIG.715 ELECTRICAL SYSTEM (BATTERY AND BATTERY RELAY)




PV93338

FIG.715

[illegible]

FIG.801 MARKS AND PLATES (JAPANESE)




PV93339

FIG.801

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	1-12020-1090	CAUTION PLATE (DIESEL FUEL)	1	60301 ~
2	1-12020-1190	CAUTION PLATE (FUEL)	1	60301 ~
3	1-12020-1030	CAUTION PLATE (HYDRAULIC OIL)	1	60301 ~
4	1-12020-1130	CAUTION PLATE (FAN AND PULLEY)	1	60301 ~
5	1-12020-1120	CAUTION PLATE (RADIATOR)	1	60301 ~
6	0-7120-00602	MARK PLATE (MST-600VD)	2	60301 ~
7	1-12020-1140	CAUTION PLATE (TRACK ADJUSTING VALVE)	2	60301 ~
8	0-7110-00000	MARK PLATE (MOROOKA)	1	60301 ~
9	1-12020-1150	CAUTION PLATE (RUBBER CRAWLER)	1	60301 ~
10	0-7000-00603	NAME PLATE (SERIAL NO.)	1	60301 ~
11	0-7010-00603	NAME PLATE (SPECIFICATIONS)	1	60301 ~
12	1-12020-1180	CAUTION PLATE (PERIODICAL REPLACEMENT PARTS)	1	60301 ~
13	1-12020-1040	CAUTION PLATE (SEAT BELT)	1	60301 ~
14	1-12020-1050	CAUTION PLATE (WARM-UP)	1	60301 ~
15	1-12020-1160	OPERATING PLATE (H-L TRAVEL SPEED SELECT SWITCH)	1	60301 ~
16	0-7220-00000	OPERATING PLATE (ENGINE THROTTLE)	1	60301 ~
17	0-7210-03000	OPERATING PLATE (NEUTRAL)	2	60301 ~
18	0-7210-01000	OPERATING PLATE (FORWARD)	1	60301 ~
19	0-7210-02000	OPERATING PLATE (REVERSE)	1	60301 ~
20	0-7200-00000	OPERATING PLATE (DUMP LEVER)	1	60301 ~
21	1-12020-1160	OPERATING PLATE (DUMP LEVER LOCK)	1	60301 ~
22	1-57010-3180	CAUTION PLATE (ENGINE START)	1	60301 ~
23	1-12020-1060	CAUTION PLATE (OPERATING AND MAINTENANCE)	1	60301 ~
24	1-12020-1070	CAUTION PLATE (STARTING AND TRAVELING)	1	60301 ~
25	1-12020-1081	CAUTION PLATE (SLOPE TRAVELING)	1	60301 ~
26	0-7130-03300	MARK PLATE (3300KG)	1	60301 ~
27	1-12020-1170	CAUTION PLATE (INCLINATION)	1	60301 ~
28	1-12020-1010	TAG (DO NOT OPERATE)	1	60301 ~

FIG.811 MARKS AND PLATES (ENGLISH)



PV93340

FIG.811

INDEX	PART NO.	DESCRIPTION	Q'TY	SERIAL NO.
1	1-41010-1280	CAUTION PLATE (DIESEL FUEL)	1	60301 ~
2	1-12020-1310	CAUTION PLATE (FUEL)	1	60301 ~
3	1-41010-1250	CAUTION PLATE (HYDRAULIC OIL)	1	60301 ~
4	1-41010-1260	CAUTION PLATE (FAN AND PULLEY)	1	60301 ~
5	1-41010-1300	CAUTION PLATE (RADIATOR)	1	60301 ~
6	0-7120-00602	MARK PLATE (MST-600VD)	2	60301 ~
7	1-41010-1270	CAUTION PLATE (TRACK ADJUSTING VALVE)	2	60301 ~
8	0-7110-00000	MARK PLATE (MOROOKA)	1	60301 ~
9	1-41010-1240	CAUTION PLATE (RUBBER CRAWLER)	1	60301 ~
10	0-7000-10603	NAME PLATE (SERIAL NO.)	1	60301 ~
11	1-12020-1210	CAUTION PLATE (PERIODICAL REPLACEMENT PARTS)	1	60301 ~
12	1-41010-1310	CAUTION PLATE (SEAT BELT)	1	60301 ~
13	1-41010-1230	CAUTION PLATE (WARM-UP)	1	60301 ~
14	1-41010-1350	OPERATING PLATE (H-L TRAVEL SPEED SELECT SWITCH)	1	60301 ~
15	0-7220-10000	OPERATING PLATE (ENGINE THROTTLE)	1	60301 ~
16	0-7210-13000	OPERATING PLATE (REVERSE)	2	60301 ~
17	0-7210-11000	OPERATING PLATE (NEUTRAL)	1	60301 ~
18	0-7210-12000	OPERATING PLATE (FORWARD)	1	60301 ~
19	0-7200-10000	OPERATING PLATE (DUMP LEVER)	1	60301 ~
20	1-41010-1350	OPERATING PLATE (DUMP LEVER LOCK)	1	60301 ~
21	1-41010-1330	CAUTION PLATE (OPERATING AND MAINTENANCE)	1	60301 ~
22	1-41010-1320	CAUTION PLATE (STARTING AND TRAVELING)	1	60301 ~
23	1-41010-1290	CAUTION PLATE (SLOPE TRAVELING)	1	60301 ~
24	0-7130-13300	MARK PLATE (3300KG)	1	60301 ~
25	1-41010-1360	CAUTION PLATE (INCLINATION)	1	60301 ~
26	1-41010-1210	TAG (DO NOT OPERATE)	1	60301 ~

品番順索引表

NUMERICAL INDEX

PARTS No.	FIG. No.	INDEX
0-1000-00430	711	20
0-1000-00516	205	04
0-1000-00516	205	07
0-1000-00610	205	10
0-1000-00610	421	07
0-1000-00612	121	12
0-1000-00616	202	19
0-1000-00616	421	28
0-1000-00616	713	16
0-1000-00630	421	10
0-1000-00630	421	14
0-1000-00812	504	02
0-1000-00816	101	17
0-1000-00816	201	18
0-1000-00816	204	02
0-1000-00816	551	06
0-1000-00820	101	23
0-1000-00820	111	18
0-1000-00820	115	15
0-1000-00820	115	22
0-1000-00820	201	23
0-1000-00820	201	29
0-1000-00820	206	03
0-1000-00820	206	10
0-1000-00820	206	17
0-1000-00820	311	13
0-1000-00820	401	27
0-1000-00820	411	08
0-1000-00820	411	16
0-1000-00820	555	03
0-1000-00820	711	23
0-1000-00825	101	29
0-1000-00825	111	04
0-1000-00825	115	14
0-1000-00825	421	17
0-1000-00825	715	15
0-1000-00830	715	19
0-1000-00835	501	15
0-1000-01016	105	23
0-1000-01016	203	36
0-1000-01016	411	20
0-1000-01020	101	37
0-1000-01020	121	14
0-1000-01020	201	03
0-1000-01020	201	07
0-1000-01020	202	07
0-1000-01020	202	11
0-1000-01020	203	21
0-1000-01020	203	28
0-1000-01020	203	32

PARTS No.	FIG. No.	INDEX
0-1000-01020	205	13
0-1000-01020	206	22
0-1000-01020	206	26
0-1000-01025	105	22
0-1000-01025	105	24
0-1000-01025	202	03
0-1000-01025	211	02
0-1000-01025	411	02
0-1000-01025	551	17
0-1000-01030	115	03
0-1000-01030	201	11
0-1000-01035	401	12
0-1000-01035	402	11
0-1000-01040	402	33
0-1000-01050	402	32
0-1000-01220	202	15
0-1000-01225	105	28
0-1000-01225	203	24
0-1000-01235	211	06
0-1000-01235	211	10
0-1000-01250	101	42
0-1000-01255	402	16
0-1000-01290	401	30
0-1000-01460	115	25
0-1000-31025	101	08
0-1000-31030	101	03
0-1000-31030	105	13
0-1000-31050	105	05
0-1000-31060	401	25
0-1000-31220	301	17
0-1000-31225	311	15
0-1000-31235	101	11
0-1000-31240	105	15
0-1000-31290	601	12
0-1000-31435	301	06
0-1000-31645	301	03
0-1002-01010	715	11
0-1020-30825	501	13
0-1020-31025	501	07
0-1050-00616	203	11
0-1050-00620	201	14
0-1090-00512	203	03
0-1090-00516	203	19
0-1090-00612	203	06
0-1090-00612	203	09
0-1090-01020	204	07
0-1100-00410	121	06
0-1100-00410	711	21
0-1100-00410	713	06
0-1100-00513	411	15

PARTS No.	FIG. No.	INDEX
0-1100-00615	121	13
0-1100-00615	202	20
0-1100-00615	204	10
0-1100-00615	205	11
0-1100-00615	421	08
0-1100-00615	421	29
0-1100-00615	711	33
0-1100-00615	713	17
0-1100-00820	101	18
0-1100-00820	101	26
0-1100-00820	101	30
0-1100-00820	101	39
0-1100-00820	111	05
0-1100-00820	111	19
0-1100-00820	115	17
0-1100-00820	115	24
0-1100-00820	201	19
0-1100-00820	201	24
0-1100-00820	201	30
0-1100-00820	203	15
0-1100-00820	204	03
0-1100-00820	206	04
0-1100-00820	206	09
0-1100-00820	206	13
0-1100-00820	206	18
0-1100-00820	311	14
0-1100-00820	401	29
0-1100-00820	411	09
0-1100-00820	411	17
0-1100-00820	421	20
0-1100-00820	501	18
0-1100-00820	504	03
0-1100-00820	551	07
0-1100-00820	555	04
0-1100-00820	711	24
0-1100-00820	713	21
0-1100-00820	715	16
0-1100-00820	715	20
0-1100-01025	101	06
0-1100-01025	101	09
0-1100-01025	105	14
0-1100-01025	105	25
0-1100-01025	115	05
0-1100-01025	115	09
0-1100-01025	121	15
0-1100-01025	201	04
0-1100-01025	201	08
0-1100-01025	201	12
0-1100-01025	202	04
0-1100-01025	202	08

PARTS No.	FIG. No.	INDEX
0-1100-01025	202	12
0-1100-01025	203	22
0-1100-01025	203	29
0-1100-01025	203	33
0-1100-01025	203	37
0-1100-01025	205	14
0-1100-01025	206	23
0-1100-01025	206	27
0-1100-01025	211	03
0-1100-01025	401	14
0-1100-01025	402	12
0-1100-01025	402	24
0-1100-01025	402	29
0-1100-01025	402	34
0-1100-01025	411	03
0-1100-01025	411	21
0-1100-01025	551	18
0-1100-01025	711	04
0-1100-01230	101	13
0-1100-01230	101	45
0-1100-01230	105	29
0-1100-01230	202	16
0-1100-01230	203	25
0-1100-01230	211	07
0-1100-01230	211	11
0-1100-01230	301	18
0-1100-01230	311	16
0-1100-01230	401	18
0-1100-01230	401	21
0-1100-01230	402	19
0-1100-01230	601	14
0-1100-01640	301	04
0-1100-02051	401	09
0-1100-03075	301	20
0-1100-03075	321	13
0-1100-31025	105	07
0-1100-31230	105	16
0-1100-31435	301	07
0-1110-01020	715	07
0-1110-01020	715	13
0-1120-00510	205	05
0-1120-00510	205	08
0-1120-00616	201	15
0-1120-00616	202	21
0-1120-00616	205	12
0-1120-00616	421	09
0-1120-00616	421	16
0-1120-00616	421	30
0-1120-00616	713	18
0-1120-00816	101	19

PARTS No.	FIG. No.	INDEX
0-1120-00816	101	24
0-1120-00816	101	31
0-1120-00816	101	40
0-1120-00816	111	06
0-1120-00816	111	16
0-1120-00816	111	20
0-1120-00816	201	20
0-1120-00816	201	25
0-1120-00816	201	31
0-1120-00816	203	16
0-1120-00816	204	04
0-1120-00816	206	11
0-1120-00816	411	10
0-1120-00816	411	18
0-1120-00816	421	18
0-1120-00816	421	25
0-1120-00816	501	16
0-1120-00816	504	04
0-1120-00816	555	05
0-1120-00816	711	10
0-1120-00816	715	17
0-1120-00816	715	21
0-1120-01020	101	04
0-1120-01020	105	26
0-1120-01020	121	16
0-1120-01020	201	05
0-1120-01020	201	09
0-1120-01020	201	13
0-1120-01020	202	05
0-1120-01020	202	09
0-1120-01020	202	13
0-1120-01020	203	23
0-1120-01020	203	30
0-1120-01020	203	34
0-1120-01020	203	38
0-1120-01020	205	15
0-1120-01020	206	24
0-1120-01020	211	04
0-1120-01020	402	13
0-1120-01020	411	04
0-1120-01020	411	22
0-1120-01020	551	19
0-1120-01020	711	05
0-1120-01223	101	14
0-1120-01223	101	43
0-1120-01223	105	17
0-1120-01223	105	30
0-1120-01223	203	26
0-1120-01223	211	08
0-1120-01223	211	12

PARTS No.	FIG. No.	INDEX
0-1120-01223	401	23
0-1120-01223	402	17
0-1120-01225	202	17
0-1120-01432	115	19
0-1120-01432	115	26
0-1120-01432	202	26
0-1120-01432	601	08
0-1130-00408	711	22
0-1160-00823	206	05
0-1160-00823	206	19
0-1200-00605	421	11
0-1200-00605	421	15
0-1200-00605	711	32
0-1200-00805	713	20
0-1200-00806	101	25
0-1200-00806	111	15
0-1200-00806	115	16
0-1200-00806	115	23
0-1200-00806	203	14
0-1200-00806	206	08
0-1200-00806	206	12
0-1200-00806	401	28
0-1200-00806	421	19
0-1200-00806	501	17
0-1200-00806	711	09
0-1200-01008	101	05
0-1200-01008	101	38
0-1200-01008	105	27
0-1200-01008	115	04
0-1200-01008	401	13
0-1200-01008	401	26
0-1200-01008	402	23
0-1200-01008	402	28
0-1200-01008	711	03
0-1200-01008	715	06
0-1200-01210	101	12
0-1200-01210	101	44
0-1200-01210	401	20
0-1200-01210	401	31
0-1200-01210	402	18
0-1200-01210	601	13
0-1200-01411	115	18
0-1200-31008	105	06
0-1200-31008	115	08
0-1200-33024	301	19
0-1200-33024	321	12
0-1201-01008	402	27
0-1201-01210	401	17
0-1220-00805	421	23
0-1220-01006	401	03

PARTS No.	FIG. No.	INDEX	PARTS No.	FIG. No.	INDEX
0-1220-01006	402	35	0-2172-01000	121	17
0-1220-01006	421	04	0-2172-01010	121	18
0-1220-01006	715	12	0-2210-00375	501	19
0-1220-01408	115	27	0-2210-00470	501	08
0-1220-01408	601	07	0-2221-00460	502	01
0-1242-01200	401	22	0-2230-00295	504	05
0-1242-02000	401	08	0-2230-00347	505	07
0-1260-00404	713	23	0-2230-00383	505	08
0-1260-00505	203	04	0-2230-00427	505	11
0-1260-00505	203	20	0-2230-00463	505	12
0-1260-00606	203	12	0-2230-01027	505	15
0-1260-00606	711	14	0-2230-01095	505	16
0-1260-00606	713	13	0-2231-00200	504	09
0-1260-00606	713	19	0-2231-00205	504	06
0-1260-00606	713	25	0-2231-00245	504	12
0-1260-00808	711	11	0-2401-00625	503	02
0-1260-00808	711	16	0-2401-00630	503	01
0-1260-00808	713	03	0-2420-00460	502	07
0-1300-00410	121	05	0-2420-00690	505	01
0-1300-00416	713	05	0-2430-00235	504	07
0-1300-00512	411	14	0-2430-00253	504	10
0-1300-00612	204	09	0-2430-00270	504	08
0-1300-00616	713	29	0-2431-00200	504	11
0-1305-00420	701	04	0-2700-00012	121	08
0-1305-00420	701	06	0-2700-00012	121	21
0-1310-00870	202	28	0-2700-10038	501	03
0-1320-00616	701	02	0-2700-10056	111	22
0-1350-00830	321	09	0-2700-10075	111	11
0-2000-03130	301	10	0-2700-10095	111	10
0-2000-03130	311	06	0-2710-00056	101	34
0-2000-03130	501	12	0-2720-01206	421	27
0-2000-03135	501	06	0-2720-01206	711	31
0-2000-03145	321	10	0-2720-02506	711	31
0-2000-03170	311	12	0-2750-00000	711	34
0-2010-02411	504	14	0-2800-00202	121	22
0-2010-02411	504	15	0-2800-00202	503	10
0-2010-02411	504	17	0-2800-00202	711	36
0-2010-02414	505	10	0-2800-00383	121	22
0-2010-02418	121	10	0-2800-00383	503	10
0-2010-02418	503	08	0-2800-00383	711	36
0-2010-02418	505	14	0-2810-06015	206	16
0-2040-02217	501	20	0-2820-01200	206	25
0-2040-02217	501	21	0-2820-01200	701	11
0-2040-02520	501	10	0-2830-01520	711	35
0-2040-02520	502	02	0-2830-02420	711	35
0-2040-02520	502	09	0-2830-02920	711	35
0-2040-03024	505	03	0-2840-02013	503	09
0-2040-03030	503	05	0-2840-02020	503	09
0-2100-01070	501	01	0-3000-01014	402	20
0-2150-01035	121	07	0-3000-01041	402	21

PARTS No.	FIG. No.	INDEX
0-3010-01258	401	15
0-3100-11000	402	22
0-3100-11200	401	19
0-3101-11200	401	16
0-3111-11000	402	26
0-3130-01060	402	25
0-3200-00825	421	24
0-3220-00422	202	25
0-3220-02516	421	26
0-3220-05970	601	24
0-3260-00663	402	08
0-3300-01218	402	06
0-3300-01225	401	05
0-3300-01635	301	14
0-3310-02572	311	04
0-3310-02575	321	06
0-3400-00000	321	14
0-3400-00100	601	11
0-3400-00170	601	21
0-3500-01010	402	31
0-3500-01020	402	30
0-4000-00400	551	16
0-4010-00200	311	11
0-4121-01706	505	03
0-4121-02106	503	05
0-4210-00404	502	08
0-4210-00603	505	09
0-4210-00604	505	13
0-4210-00606	505	04
0-4210-00610	505	17
0-4210-01010	505	18
0-4211-00202	504	14
0-4211-00202	504	17
0-4211-00303	505	10
0-4211-00406	503	08
0-4212-00606	505	06
0-4220-01010	501	02
0-4300-00202	504	13
0-4300-00404	501	09
0-4300-00604	502	03
0-4300-00606	503	07
0-4300-00606	505	02
0-4301-00604	502	05
0-4310-00303	501	22
0-4310-00606	503	06
0-4320-00202	504	15
0-4320-00404	505	14
0-4321-01203	501	21
0-4321-01404	502	02
0-4321-01404	502	09

PARTS No.	FIG. No.	INDEX
0-4326-01203	501	20
0-4326-01404	501	10
0-4360-01010	505	19
0-4370-01010	505	21
0-4380-00202	121	19
0-4380-01010	501	04
0-4410-00202	504	16
0-4460-00606	505	05
0-4470-00402	502	06
0-5000-00750	715	01
0-5010-00000	715	02
0-5011-00000	715	03
0-5050-00015	701	07
0-5051-00000	701	07
0-5060-00015	713	27
0-5120-02400	711	07
0-5310-02024	711	27
0-5320-30024	711	28
0-5400-00000	701	09
0-5500-02400	713	10
0-5520-02400	713	11
0-5530-02440	713	08
0-5540-12400	715	14
0-5600-02400	711	08
0-5620-00000	111	03
0-6000-06009	321	05
0-6000-06207	311	03
0-6002-30207	301	11
0-6100-00206	402	14
0-6102-00204	402	09
0-6110-00205	401	06
0-7000-00603	801	10
0-7000-10603	811	10
0-7010-00603	801	11
0-7110-00000	801	08
0-7110-00000	811	08
0-7120-00602	801	06
0-7120-00602	811	06
0-7130-03300	801	26
0-7130-13300	811	24
0-7200-00000	801	20
0-7200-10000	811	19
0-7210-01000	801	18
0-7210-02000	801	19
0-7210-03000	801	17
0-7210-11000	811	17
0-7210-12000	811	18
0-7210-13000	811	16
0-7220-00000	801	16
0-7220-10000	811	15

PARTS No.	FIG. No.	INDEX	PARTS No.	FIG. No.	INDEX
1-10330-1160	301	16	1-12020-1210	811	11
1-11110-1110	101	10	1-12020-1310	811	02
1-11130-1110	115	01	1-12210-1140	701	13
1-11130-1140	115	02	1-12210-1440	715	04
1-11130-1150	115	11	1-12210-1460	711	17
1-11130-1160	115	12	1-12210-1470	711	18
1-11130-1160	115	21	1-12210-1480	711	19
1-11130-1180	115	13	1-12210-1490	711	25
1-11160-1120	105	09	1-12210-1610	713	14
1-11160-1120	105	11	1-12320-2110	301	05
1-11210-1140	701	10	1-12330-0011	301	08
1-11330-0020	301	12	1-12330-1111	301	08
1-11330-0020	311	07	1-12330-1120	301	09
1-11330-1230	301	23	1-12330-1150	301	13
1-11350-0020	321	07	1-12330-1210	301	21
1-11350-1120	321	04	1-12330-1220	301	22
1-11350-1130	321	08	1-12330-1241	301	15
1-11410-1210	411	06	1-12340-0020	311	01
1-11510-1210	202	18	1-12340-1140	311	10
1-11520-1220	205	16	1-12340-2110	311	01
1-11660-0020	551	13	1-12340-2120	311	02
1-11660-1120	551	04	1-12350-0010	321	03
1-11660-1140	551	08	1-12350-1110	321	03
1-11660-1150	551	09	1-12420-1111	401	01
1-11660-1160	551	12	1-12420-1120	401	02
1-11660-1170	551	11	1-12420-1131	401	04
1-11660-1180	551	13	1-12420-1140	401	07
1-11660-1190	551	14	1-12420-1150	401	10
1-11660-1210	551	15	1-12420-1160	401	11
1-11660-1220	551	10	1-12420-1250	402	02
1-11660-1230	551	02	1-12420-1270	402	05
1-11660-1250	551	03	1-12420-1280	402	10
1-11710-1150	601	05	1-12520-1321	206	02
1-12020-1010	801	28	1-12630-0012	301	02
1-12020-1030	801	03	1-12640-0010	601	20
1-12020-1040	801	13	1-12670-1410	501	05
1-12020-1050	801	14	1-12710-1110	601	01
1-12020-1060	801	23	1-12710-1120	601	02
1-12020-1070	801	24	1-12710-1130	601	03
1-12020-1081	801	25	1-12710-1140	601	04
1-12020-1090	801	01	1-12710-1170	601	06
1-12020-1120	801	05	1-12710-1320	601	22
1-12020-1130	801	04	1-12710-1330	601	23
1-12020-1140	801	07	1-12710-1360	601	09
1-12020-1150	801	09	1-12710-1400	601	15
1-12020-1160	801	15	1-12710-1410	601	16
1-12020-1160	801	21	1-12710-1420	601	18
1-12020-1170	801	27	1-12710-1430	601	19
1-12020-1180	801	12	1-12710-1440	601	15
1-12020-1190	801	02	1-12710-1460	601	17

PARTS No.	FIG. No.	INDEX	PARTS No.	FIG. No.	INDEX
1-12710-1500	601	15	1-29530-1110	211	09
1-12710-1560	601	17	1-29530-1120	211	05
1-13150-1120	121	20	1-29540-1510	206	07
1-13210-1311	715	09	1-29540-1610	206	21
1-16110-1130	551	05	1-29540-1620	206	20
1-16210-1600	713	26	1-29660-0011	551	01
1-16210-1690	713	28	1-29660-1111	551	01
1-17140-1211	101	20	1-29670-1110	505	20
1-18210-1521	711	13	1-29710-1310	601	10
1-18540-0010	206	06	1-30120-1170	701	16
1-18620-0013	501	14	1-30160-1110	105	08
1-23420-1310	401	24	1-30210-0010	711	06
1-23670-1420	501	11	1-30210-1150	713	02
1-25340-1130	311	05	1-30210-1520	715	08
1-25420-1270	402	03	1-30210-2120	701	05
1-25420-1290	402	07	1-30350-1210	321	02
1-25420-1311	402	15	1-30410-1191	421	21
1-25540-0020	206	14	1-30510-2210	202	10
1-28210-1520	711	15	1-30510-2250	202	14
1-29120-0010	111	01	1-30530-1130	211	01
1-29120-1120	111	01	1-31150-1150	121	09
1-29120-1220	111	02	1-31210-1110	204	08
1-29150-0012	121	01	1-31620-0030	421	01
1-29150-1112	121	01	1-31620-1510	421	01
1-29210-1150	701	12	1-31620-1520	421	02
1-29210-1180	121	04	1-31620-1530	421	03
1-29210-1180	711	29	1-31620-1540	421	05
1-29210-1230	711	06	1-31620-1550	421	12
1-29210-1310	711	12	1-31620-1590	421	06
1-29210-1341	715	10	1-31620-1610	421	13
1-29210-1420	715	18	1-31650-0010	502	04
1-29210-1520	713	15	1-31650-0010	555	01
1-29210-1530	713	09	1-31650-1110	555	01
1-29210-1550	711	26	1-31650-1120	555	02
1-29210-1570	711	30	1-32210-1510	713	07
1-29410-0050	411	11	1-32710-1650	202	23
1-29510-1311	202	27	1-36420-1170	421	22
1-29520-1420	201	02	1-38710-1630	202	24
1-29520-1430	201	06	1-39210-1350	701	15
1-29520-1440	205	02	1-39210-1360	713	04
1-29520-1460	203	17	1-41010-1210	811	26
1-29520-1470	201	28	1-41010-1230	811	13
1-29520-1480	201	27	1-41010-1240	811	09
1-29520-1490	201	26	1-41010-1250	811	03
1-29520-1520	205	06	1-41010-1260	811	04
1-29520-1521	203	02	1-41010-1270	811	07
1-29520-1540	202	01	1-41010-1280	811	01
1-29520-1550	201	10	1-41010-1290	811	23
1-29520-1580	204	01	1-41010-1300	811	05
1-29520-1670	204	05	1-41010-1310	811	12

PARTS No.	FIG. No.	INDEX	PARTS No.	FIG. No.	INDEX
1-41010-1320	811	22	1-50140-2340	101	36
1-41010-1330	811	21	1-50140-2350	101	41
1-41010-1350	811	14	1-50160-1130	105	10
1-41010-1350	811	20	1-50160-1150	105	12
1-41010-1360	811	25	1-50210-1110	701	01
1-41520-1350	203	10	1-50210-1120	701	03
1-41520-1360	203	08	1-50210-1210	701	08
1-41520-1370	203	13	1-50210-1410	711	01
1-41520-1380	203	05	1-50210-1420	711	02
1-41520-1380	205	09	1-50210-1430	715	05
1-41520-1670	203	07	1-50210-1510	713	12
1-41520-1820	202	02	1-50210-1720	701	14
1-41520-1850	205	18	1-50310-1110	301	01
1-41520-1860	203	18	1-50350-1140	321	11
1-41520-1860	205	03	1-50350-1210	321	01
1-43210-1520	713	24	1-50410-2120	411	05
1-45340-1180	311	08	1-50410-2310	411	07
1-45350-1190	311	09	1-50410-2510	411	12
1-46210-1520	713	22	1-50410-2520	411	13
1-46210-1570	713	01	1-50410-2550	411	19
1-46620-0010	504	01	1-50420-1210	402	01
1-48150-1130	121	11	1-50420-1220	402	04
1-50100-2000	101	01	1-50510-2110	201	01
1-50110-2110	101	02	1-50520-0020	203	01
1-50110-2120	101	07	1-50520-0030	205	01
1-50120-2310	111	07	1-50520-2150	203	01
1-50120-2320	111	08	1-50520-2210	203	27
1-50120-2330	111	09	1-50520-2220	203	31
1-50120-2350	111	12	1-50520-2240	203	35
1-50120-2360	111	21	1-50520-2310	206	01
1-50120-2410	111	13	1-50520-2320	206	15
1-50120-2420	111	14	1-50520-2410	205	01
1-50120-2430	111	17	1-50520-2640	204	06
1-50130-1130	115	10	1-50520-2710	202	06
1-50130-2120	115	06	1-50520-2810	105	18
1-50130-2140	115	07	1-50520-2820	105	19
1-50130-2150	115	20	1-50520-2830	105	20
1-50140-0020	101	15	1-50520-2840	105	21
1-50140-2180	101	16	1-50610-0010	105	01
1-50140-2210	201	16	1-50610-0020	105	03
1-50140-2220	201	17	1-50670-2110	503	03
1-50140-2230	201	21	1-50670-2120	503	04
1-50140-2240	201	22	1-50670-2510	505	22
1-50140-2250	101	21	1-50670-2520	505	23
1-50140-2260	101	22	1-50710-1640	202	22
1-50140-2270	101	27	1-51150-1130	121	02
1-50140-2280	101	28	1-51150-1140	121	03
1-50140-2310	101	32	1-51150-1180	121	03
1-50140-2320	101	33	1-51410-1130	411	01
1-50140-2330	101	35	1-51610-1110	105	02

PARTS No.	FIG. No.	INDEX
1-51610-1120	105	04
1-55210-3920	715	22
1-55520-1480	205	17
1-57010-3180	801	22

PARTS No.	FIG. No.	INDEX
-----------	----------	-------

RUBBER CRAWLER CARRIER MST—600VD PARTS LIST

Document No. PE10600VD2-03

Third edition: June 20, 2012

Issued by Morooka Co., Ltd.
358 Shoubeisindencho, Ryugasaki,
Ibaraki 301-0034,
Japan

No part of this manual can be reproduced in any form without permission