https://truckmanualshub.com/

B30D & B25D 6X6 ADT Mk IV

PARTS MANUAL

872133

FIRST ISSUE: MAY 2006
SECOND ISSUE: SEPTEMBER 2006 (SIB 2006/1076)
THIRD ISSUE: JANUARY 2007 (SIB 2007/1014)
FOURTH ISSUE: JULY 2007 (SIB 2007/1069)
LATEST ISSUE: MARCH 2010 (SIB 2010/1027)

Copyright © 2006

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying or otherwise, without the prior written permission of BELL Equipment Company SA (Pty) Limited as the copyright holder.

https://truckmanualshub.com/

https://truckmanualshub.com/

This manual has been produced to assist you in ordering of parts for the maintenance of your ***BELL EQUIPMENT*** machine.

The information contained in the manual is in a logical sequence. Each illustrated breakdown is supported with a parts list.

The parts manual has been produced by the Technical Documentation Department of ***BELL EQUIPMENT*** Co. Every effort has been made to ensure that the information in this manual was correct at the time of publication. ***BELL EQUIPMENT*** Co. has a policy of continuous product development, improvement and design. ***BELL EQUIPMENT*** Co. reserves the right to change, amend and update the design of its product at any time without prior notice. With this policy, changes may have occurred that are not included in this manual.

Whilst every endeavour has been made to provide accurate and reliable information, ***BELL EQUIPMENT*** Co. specifically disclaims any actual or implied warranty and under no circumstances shall be liable for any loss, damage or injury to person or property suffered, whether direct, or indirect or consequential, arising from the use of this manual. In particular and without detracting from the above, the disclaimer also applies in the event of any specification, warning, or representation contained in this manual being inadequate, inaccurate, or unintentionally misleading.

The user is urged to strictly comply with the instructions and warnings that are given in the interests of general safety. Please do not hesitate to contact your ***BELL EQUIPMENT*** Product Support Representative whenever you have a query on your ***BELL*** product or this manual. The address of your nearest ***BELL EQUIPMENT*** branch or dealer is as follows:-

For the latest Bell operations listing please visit: **www.bellequipment.com**

The following address list was correct as at 23 March 2010.

LOCATION OF OPERATIONS

RICHARDS BAY - HEAD OFFICE:

Bell Equipment Group
Physical Address: Carbonode Cell, Alton,Richards Bay,3900
Tel: +27 (0)35 907 9111
Fax: +27 (0)35 797 4336
E-mail: sales@bellequipment.com

ASIA PACIFIC:

SINGAPORE

Bell Equipment (SEA) PTE Ltd
Physical Address: 10 Anson Road, #22-02A International Plaza, Singapore, 079903
Contact: Mohd Johari Ahmead (Dealer Development Sales Manager)
Mobile: +65 966 36404
Tel : +65 622 08 004 or +65 622 62 362
Fax :+65 622 03 004E-mail: bellequipment@singnet.com.sg (Johari) or wendycmw@singnet.com.sg

https://truckmanualshub.com/

EUROPE :

FRANCE

Bell France SARL
Physical Address: Route d' Argenton-Sur-Creuse, 23800 Dun Le Palestel, France
Contact: Claude Boulet (Director) Vincent Valadas (Technical Director)
Mobile: +33 60719 5407
Tel : +33 55589 2356
Fax :+33 55589 2324
E-mail: claudeb@fr.bellequipment.com

GERMANY

Bell Equipment (Alsfeld) GmbH
Physical Address: Willi-Brandt Strasse 4-6, D-36304, Alsfeld, Germany
Contact: Andre Krings (Managing Director)
Mobile: +49 176 220 024 416
Tel: +49 6631 911 300
Fax: +49 6631 911 313
E-mail: andrek@de.bellequipment.com

German Assembly Plant (Eisenach)
Physical Address: Industriestrasse 8, 99819 Grossenlupnitz/OT, Horselberg, Germany
Contact: Andre Krings (Managing Director)
Mobile: +49 176 220 024 416
Tel: +49 369 207 3101
Fax: +49 369 207 3150
Email: andrek@de.bellequipment.com

SPAIN

Bell Equipment Spain
Physical Address: C/Iplacea Nº 10, Nave 2.2 P.I. Alcala Park, 28803 Alcalá de Henares, Madrid, Spain
Contact: Jesus Vivero
Mobile: +34-64 99 33 089
Tel: +34 91 879 60 19
Fax: +34 91 879 60 49
E-mail: lauriannec@fr.bellequipment.com

SWITZERLAND

Bell Switzerland (Bell Handling Systems and Bellinter Holdings)
Physical Address: Rue de Vevey 178, 1630 Bulle, SWITZERLAND
Contact: Jean-Christophe Cerouter or Pascal Gross
Tel: +41 26 913 00 11/2
Fax: +41 26 913 00 19
E-mail: beqch@bluewin.ch or pascal.beqch@bluewin.ch

UNITED KINGDOM

Bell Equipment U.K. LIMITED
Physical Address: Unit 6C, Graycar Business Park, Barton Turns, Barton-Under-Needwood, Burton-on-Trent, DE13 8EN, UNITED KINGDOM
Contact: Neville Paynter
Tel: +44 1283 714259 (Direct)
Tel: +44 1283 714251 (Parts Direct)
Fax: +44 1283 712687
E-mail: cameronc@bellequipment.co.uk or general@bellequipment.co.uk

MIDDLE EAST :

KINGDOM OF BAHRAIN

Physical Address: Building 1110, Road 4225, Block 342, Juffair, Manama, Kingdom of Bahrain
Contact: Kevin Rock (Business Development Manager)
Mobile: +973 3688 3233
Tel: +973 173 64958
Fax: +973 177 25435
E-mail: kevinrock@bellequipment.me.uk

SOUTHERN AFRICA:

CAPE REGION:

CAPE TOWN

Bell Equipment Sales SA Limited
Physical Address: 28 Aviation Road, Phase 4, Airport City, Cape Town, 7475
Contact: John Collins (General Manager)
Mobile: +27 (0)82 495 9338
Tel: +27 (0)21 380 9000
Fax: +27 (0)21 380 9057
E-mail: maureenb@bell.co.za johnc@bell.co.za

EAST LONDON

Bell Equipment Sales SA Limited
Physical Address: 811 East Coast Resort Road, Meisies Halt, Gonubie, East London, 5200
Contact: Kassie van de Heever
Mobile: +27 (0)82 827 8050
Tel: +27 (0)43 732 1415 (Parts) or +27 (0)43 732 1473 (Admin &Technical Queries)
Fax: +27 (0)43 732 1435
E-mail: kassiev@bell.co.za

GEORGE

Bell Equipment Sales SA Limited
Physical Address: Pioneer Avenua Industria Pacaltsdrop, George, 6534
Contact: Ryan Britain
Mobile: +27 (0)82 334 2170
Tel: +27 (0)44 878 0930/1
Fax: +27 (0)44 878 0932
E-mail: karino@bell.co.za

PORT ELIZABETH

Bell Equipment Sales SA Limited
Physical Address: 349 Kempston Road, Korsten, Port Elizabeth, 6056
Contact: Gert Nelson
Mobile: +27 (0)82 657 1190
Tel: +27 (0)41 451 3202/4/6
Fax: +27 (0)41 451 3208
E-mail: lynneo@bell.co.za

LOCATION OF OPERATIONS

NAMIBIA / WINDHOEK

IA Bell Equipment Sales SA Limited
Physical Address: 37 Lazarett Street, Ausspann Platz, Windhoek, Namibia
Contact: Johan van Wyk
Mobile: 081-250 2949
Tel: 264 61 226 021/2/3
Fax: 264 61 228 330

CENTRAL REGION:

JOHANNESBURG (GAUTENG)

Bell Equipment International Operations (Isando Industrial Park)
Physical Address: Griffiths Road, Jet Park, 1459
Contact: Mike Dutton (Managing Director)
Mobile: +27 (0)82 821 1077
Tel: +27 (0)11 966 4949
Fax: +27 (0)11 966 4980
E-mail: sharona@bell.co.za

Bell Equipment Sales SA Limited (Gauteng)
Physical Address: Griffiths Road, Jet Park, 1459
Contact: Dirk Truter (Sales & Operations Manager)
Mobile: +27 (0)82 806 3889
Tel: +27 (0)11 928 9700
Fax: +27 (0)11 928 9730 or (Sales) +27 (0)11 397 6274
E-mail: susanm@bell.co.za

MIDDELBURG (MPUMALANGA)

Bell Equipment Sales SA Limited
Physical Address: 9 Tswelopele Street, Industrial Area, Middelburg, 1050
Contact: Aubrey Potgieter
Modile: +27 (0)83 629 1931
Tel: +27 (0)13 246 8900
Fax: +27 (0)13 246 1229
E-mail: rinas@bell.co.za

RUSTENBURG (NORTH WEST PROVINCE)

Bell Equipment Sales SA Limited
Physical Address: 16 Vanadium Street, Border Industrial, Rustenburg, 0300
Contact: Nico Thompson (Branch Manager)
Mobile: +27 (0)82 773 5422
Tel: +27 (0)14 538 1003/4
Fax: +27 (0)14 538 1005
E-mail: gitteb@bell.co.za

TZANEEN (LIMPOPO)

Bell Equipment Sales SA Limited
Physical Address: 1 Mangaan Street Tzaneen
Contact: Freddie Barnard (Branch Manager)
Mobile: +27 (0)82 335 9102
Tel: +27 (0)15 307 1129
Fax: +27 (0)15 307 3095
E-mail: freddieb@bell.co.za

https://truckmanualshub.com/

COASTAL REGION:

DURBAN

Bell Equipment Group (Chairman's Office)
Physical Address: 75 Columbine Place, Ring Road Industrial Park, Durban North, 4000, Durban, 4000
Contact: Howard Buttery (Chairman)
Tel: +27 (0)31 569 1100
Fax: +27 (0)31 569 1108
E-mail: howardb@bell.co.za

EMPANGENI

Bell Equipment Sales SA Limited
Physical Address: No.1 Irvine Bell Drive, Old Mill Industrial, Empangeni, 3880
Contact: Mike Campbell (Branch Manager)
Mobile: +27 (0)82 784 1477
Tel: +27 (0)35 707 2500
Fax: +27(0)35 792 6516
E-mail: michaelc@bell.co.za

NELSPRUIT (MPUMALANGA)

Bell Equipment Sales SA Limited
Physical Address: 3 Christie Crescent, Vintonia 2, Nelspruit,1200
Contact: Leon van der Linde (Acting Branch Manager)
Mobile: +27(0)82 413 2469
Tel: +27 (0)13 755 2110/6
Fax: +27 (0)13 755 2117
E-mail: corries@bell.co.za

PIETERMARITZBURG

Bell Equipment Sales SA Limited
Physical Address: 7 Van Eck Place, Mkondeni, Scottsville, 3201, Pietermaritzburg, 3209
Contact: Les Lothain (Regional Manager)
Mobile: +27 (0)82 774 9937
Tel: +27 (0)33 386 9319
Fax: +27 (0)33 386 1837
E-mail: michellet@bell.co.za

PIET RETIEF (MPUMALUNGA)

Bell Equipment Sales SA Limited
Physical Address: 136A Kotze Street, Piet Retief, 2380
Contact: Butcha Balate
Mobile: +27 (0)82 774 0495
Tel: +27 (0)17 826 1523
Fax: +27 (0)17 826 1580
E-mail: eugeniob@bell.co.za

SWAZILAND

Bell Equipment Sales SA Limited
Physical Address: Tambankulu Street, Plot 686, Matsapha, Swaziland
Contact: Charlie Boucher
Mobile: 00 268 7602 3795
Tel: +268 51 874 96/7
Fax: +268 51 874 98
E-mail: nicolienb@bell.co.za

https://truckmanualshub.com/

NORTHERN CAPE REGION:

BLOEMFONTEIN

Bell Equipment Sales SA Limited
Physical Address: 17 Dennis Pooley Street, Bloemfontein, 9300
Contact: Peter Wille (Branch Manager)
Mobile: +27 (0)82 854 2265
Tel: +27 (0)51 4327 855
Fax: +27 (0)51 4323 740
E-mail: yvetteo@bell.co.za or peterw@bell.co.za

KIMBERLEY

Bell Equipment Sales SA Limited
Physical Addess: 12 Hendrick Van Eck Street, Kimdustria, 8300
Contact: Aubrey Potgieter (General Manager)
Mobile: +27 (0)83 629 1931
Tel: +27 (0)53 841 0710/11/12/13
Fax: +27 (0)53 841 1940
E-mail: aubreyp@bell.co.za

KURUMAN (NORTHERN CAPE)

Bell Equipment Sales SA Limited
Physical Address: Mariette Crescent, Industrial Area, Kuruman, 8460
Contact: Bernard Niemand (Branch Manager)
Mobile: +27 (0)82 572 7881
Tel: +27 (0)53 712 3072 / 3134
Fax: +27 (0)53 712 3036
E-mail: lorenzoj@bell.co.za

WOLMARANSSTAD

Bell Equipment Sales SA Limited
Physical Address: 80 Kruger Street, Wolmaransstad, 2630
Contact: Bernard Niemand (Branch Manager)
Mobile: +27 (0)82 572 7881
Tel: +27 (0)18 596 2319
Fax: +27 (0)18 596 2855
E-mail: bernardn@bell.co.za

OTHER AFRICA:

MOZAMBIQUE (Responsible for Southern Mozambique ONLY)

Bell Equipment Ltd (Maputo)
Physical Address: Avenida Samora Machel nr.238, Matola, 00258 21, Maputo, Mozambique
Contact: Mario Ferreira
Mobile: +00258 82 301 8940
Tel: +00258 21 722 022/21
Fax: +00258 21 724 559
E-mail: mariof@mz.bellequipment.com

Bell Equipment Ltd (Beira)
Physical Address: Talhao 297, Estrada nacional nr.6, Zona Indutrial da Manga, Beira, 00258 23, Sofala, Mozambique
Contact: Mario Ferreira or Johnny Fourie
Mobile: +00258 84 502 3921
Tel: +00258 23 302 145/6/7
Fax: +00258 23 302 149
E-mail: johnnyf.bell@tdm.co.mz

https://truckmanualshub.com/

ZAMBIA

Bell Equipment Ltd - (Kitwe)
Physical Address: Kalulushi Business Park, Kalulushi, Kitwe, Zambia
Contact: Shaunn McCann (Sales Manager)
Mobile: +260 97 770 677
Tel : +260 2 731 557/8
Fax : +260 2 731 555
E-mail: shaunnmc@zm.bellequipment.com

Bell Equipment Ltd - (Lusaka)
Physical Address: Plant No. 110/186 Lusanshya Road, Lusaka, Zambia
Contact: Keith Russell
Mobile: +260 (97) 7771 302
Tel : +260 (211) 237 120
Fax : +260 (211) 237 121
E-mail: keithr@zm.bellequipment.com

ZIMBABWE

Bell PTA (PVT) Ltd (Harare)
Physical Address: 16 Erith Road, Willowvale, Harare, Zimbabwe
Contact: Charl du Toit
Mobile: +263-91 260 169
Tel: +263 4 661 061/090/125/181/418
Fax: +263 4 621 026
E-mail: charl@bellzim.co.zw

Bell Equipment (Gweru)
Physical Address: 33 J Tongogara Avenue, Gweru, Zimbabwe
Contact: Jannie Van Wyk
Mobile: +263 91 310 722
Tel: +263 54 223 85 / 91
Fax: +263 54 223 85 (ask for fax)

Bell Equipment (Triangle)
Physical Address: Strand 44, Triangle, Zimbabwe
Contact: Urombo Kaunzonze
Mobile: +263 912 542 708 or +263 912 706 376
Tel: +263 33 6552
Fax: +263 33 6552 (ask for fax)
E-mail: belltriangle@africaonline.co.zw

https://truckmanualshub.com/

DEALER

Keep a record of your dealer information here:

https://truckmanualshub.com/

VIN IDENTIFICATION

The principle means of identifying your Bell Equipment machine is by studying the VIN number. The **V**ehicle **I**dentification **N**umber (VIN) structure for the Bell Equipment machines is as follows: (As an example, the B40D 6X6 manufactured at Richards Bay in 2003 has been used).

VIN:AEB1148403R000009

Table 1: CURRENT SA STRUCTURE BREAKDOWN

AEB	11	4	8	40	3	R	00	0009
i	ii	iii	iv	v	vi	vii	viii	ix

i	**AEB**	Are the unique letters designated to Bell for vehicles manufacture in South Africa.
ii	**11**	Is the machine build number, i.e. B40D 6x6. The 4 in front of the 400 number falls away as this is always a 4.
iii	**4**	This is the new number used for software filtering. This will change for all electrical upgrades.
iv	**8**	This indicates if the vehicle is a Bell (8), John Deere (9) or Hitachi (7) branded machine.
v	**40**	Is the number that indicates the type of machine, e.g. B40D (40), B25D (12).
vi	**3**	Is the year of manufacture, i.e. 3 =2003, 4 = 2004 etc.
vii	**R**	Is the plant of manufacture, i.e. R = Richards Bay.
viii	**00**	Spacer digits that could be used for sequential numbering.
ix	**0009**	Is the sequential serial number.

Table 2: CURRENT GERMAN STRUCTURE BREAKDOWN

WO9	11	4	8	40	3	0	B39	009
i	ii	iii	iv	v	vi	vii	viii	ix

i	**WO9**	Are the unique letters designated to Bell for vehicles assembled in Germany.
ii	**11**	Is the machine build number, i.e. B40D 6x6. The 4 in front of the 400 number falls away as this is always a 4.
iii	**4**	This is the new number used for software filtering. This will change for all electrical upgrades.
iv	**8**	This indicates if the vehicle is a Bell (8), John Deere (9) or Hitachi (7) branded machine.
v	**40**	Is the number that indicates the type of machine, e.g. B40D (40), B25D (12).
vi	**3**	Is the year of manufacture, i.e. 3 =2003, 4 = 2004 etc.
vii	**0**	First digit of the build sequence sequential serial number.
viii	**B39**	Is a unique code designated to the German factory.
ix	**009**	Is part of the sequential serial number.

Table 3: NEW SA STRUCTURE BREAKDOWN

AEB	11	4	8	40	0	R	00	0009
i	ii	iii	iv	v	vi	vii	viii	ix

i	**AEB**	Are the unique letters designated to Bell for vehicles manufacture in South Africa.
ii	**11**	Is the machine build number, i.e. B40D 6x6. The 4 in front of the 400 number falls away as this is always a 4.
iii	**4**	This is the new number used for software filtering. This will change for all electrical upgrades.
iv	**8**	This indicates if the vehicle is a Bell (8), John Deere (9) or Hitachi (7) branded machine.
v	**40**	Is the number that indicates the type of machine, e.g. B40D (40), B25D (12).
vi	**0**	Spacer digit that could be used for sequential numbering.
vii	**R**	Is the plant of manufacture, i.e. R = Richards Bay.
viii	**00**	Spacer digits that could be used for sequential numbering.
ix	**0009**	Is the sequential serial number.


Table 4: NEW GERMAN STRUCTURE BREAKDOWN

WO9	11	4	8	40	0	1	B39	009
i	ii	iii	iv	v	vi	vii	viii	ix

i	**WO9**	Are the unique letters designated to Bell for vehicles assembled in Germany.
ii	**11**	Is the machine build number, i.e. B40D 6x6. The 4 in front of the 400 number falls away as this is always a 4.
iii	**4**	This is the new number used for software filtering. This will change for all electrical upgrades.
iv	**8**	This indicates if the vehicle is a Bell (8), John Deere (9) or Hitachi (7) branded machine.
v	**40**	Is the number that indicates the type of machine, e.g. B40D (40), B25D (12).
vi	**0**	Spacer digit that could be used for sequential numbering.
vii	**1**	First digit of the build sequence sequential serial number.
viii	**B39**	Is a unique code designated to the German factory.
ix	**009**	Is part of the sequential serial number.

https://truckmanualshub.com/

VIN IDENTIFICATION



https://truckmanualshub.com/

IMPORTANT

Due to BELL's policy of continuous product improvement, the information contained in this manual was correct up to the time of printing (Issue date of manual). Any changes after this date will be distributed with associated bulletins.
Illustrations in this manual are pictorial representations of the component and are not drawn to scale.

USERS COMMENT FORM

Should you, as user of this manual, have any suggestion for improving the manual, or you find any errors or omissions, then we would like to know.
Please complete a facsimile of this form and hand it in to your nearest BELL Product Support Representative or post it directly to your nearest BELL Branch. Addresses are given at the beginning of this manual.
Thank you for your cooperation.

YOUR COMMENTS, SUGGESTIONS, OR QUERIES:

MACHINE MODEL:
SERIAL NUMBER:
VIN:
DOCUMENT PART NUMBER AND ISSUE:
PAGE NUMBER:

DOES THE MANUAL MEET YOUR NEEDS ?	YES	NO
DID YOU FIND THE INFORMATION ACCURATE ?	YES	NO
DID YOU FIND THE INFORMATION EASY TO READ AND UNDERSTAND ?	YES	NO
DID YOU FIND THE INFORMATION EASY TO RETRIEVE ?	YES	NO

NAME:
COMPANY:
TITLE:
ADDRESS:
TELEPHONE NUMBER:

https://truckmanualshub.com/

CONTENTS

SECTION 1. GENERAL INFORMATION
SECTION 2. ENGINE
SECTION 3. DRIVETRAIN
SECTION 4. HYDRAULICS
SECTION 5. PNEUMATICS
SECTION 6. ELECTRICAL SYSTEM
SECTION 7. FRAME AND BODY
SECTION 8. SERVICE KITS
SECTION 9. RECOMMENDED LUBRICANTS & PAINTS
SECTION 10. SPECIAL TOOLS
SECTION 11. NUMERICAL INDEX

https://truckmanualshub.com/

https://truckmanualshub.com/

TABLE OF CONTENTS

SECTION 1: GENERAL INFORMATION - 1-1

SECTION 2A: ENGINE - OM906LA - 2A-1

ENGINE, MISC. ITEMS : TIER 2 - OM906LA - 2A-2
ENGINE, MISC. ITEMS : TIER 3 - OM906LA - 2A-4
ENGINE, CRANKCASE - OM906LA - 2A-6
ENGINE, TIMING COVER - OM906LA- 2A-8
ENGINE, OIL PAN AND DIPSTICK - OM906LA - 2A-10
ENGINE, CYL. HEAD AND VALVES : TIER 2 - OM906LA - - - - - - - - - - - - - - - - - - 2A-12
ENGINE, CYL. HEAD AND VALVES : TIER 3 - OM906LA - - - - - - - - - - - - - - - - - - 2A-14
ENGINE, CYL. HEAD COVER - OM906LA- 2A-18
ENGINE, CRANKSHAFT AND FLYWHEEL - OM906LA - 2A-20
ENGINE, CONNECTING ROD AND PISTONS - OM906LA - - - - - - - - - - - - - - - - - - 2A-22
ENGINE, CAMSHAFT AND TIMING PARTS - OM906LA- - - - - - - - - - - - - - - - - - - 2A-24
ENGINE, INJECTION PUMP - OM906LA - 2A-26
ENGINE, FUEL LINES - OM906LA - 2A-28
ENGINE, FUEL FILTER - OM906LA - 2A-30
ENGINE, FLAMESTART SYSTEM - OM906LA - 2A-32
ENGINE, TURBO CHARGER - OM906LA - 2A-34
ENGINE, AIR COMPRESSOR - OM906LA - 2A-36
ENGINE, AIR COMP. ATTACHMENT PARTS - OM906LA - - - - - - - - - - - - - - - - - - 2A-38
ENGINE, INTAKE MANIFOLD - OM906LA- 2A-40
ENGINE, EXHAUST MANIFOLD - OM906LA - 2A-42
ENGINE, ELECT. EQUIPMENT : TIER 2 - OM906LA - 2A-44
ENGINE, ELECT. EQUIPMENT : TIER 3 - OM906LA - 2A-46
ENGINE, STARTING MOTOR - OM906LA- 2A-48
ENGINE, ALTERNATOR AND ATTACHMENT - OM906LA- - - - - - - - - - - - - - - - - - - 2A-50
ENGINE, OIL PUMP - OM906LA - 2A-52
ENGINE, OIL FILTER AND OIL COOLER - OM906LA - - - - - - - - - - - - - - - - - - - 2A-54
ENGINE, OIL LINES - OM906LA - 2A-56
ENGINE, WATER PUMP - OM906LA - 2A-58
ENGINE, FAN - OM906LA- 2A-60
ENGINE MOUNTINGS - OM906LA - 2A-62
ENGINE, AIRCONDITIONER COMPRESSOR - OM906LA- - - - - - - - - - - - - - - - - - - 2A-64
EXHAUST SYSTEM - OM906LA - 2A-66
KIT, BIN HEATING (OPTIONAL) - OM906LA - 2A-68
AIR INTAKE SYSTEM - OM906LA- 2A-70
AIR CLEANER - OM906LA - 2A-72
FUEL SYSTEM - OM906LA - 2A-74
FUEL-WATER FILTER UNIT - OM906LA - 2A-76
HANDLIFT PUMP & PRE-FILTER - OM906LA - 2A-78
ENGINE COOLING SYSTEM - OM906LA - 2A-80
ENGINE COOLING SYSTEM, RADIATOR - OM906LA- 2A-84

SECTION 2B: ENGINE - OM926LA - 2B-1

ENGINE, MISCELLANEOUS ITEMS - OM926LA - 2B-2
ENGINE, CRANKCASE - OM926LA - 2B-4
ENGINE, TIMING COVER - OM926LA- 2B-6
ENGINE, OIL PAN AND DIPSTICK - OM926LA - 2B-8
ENGINE, CYLINDER HEAD AND VALVES - OM926LA - - - - - - - - - - - - - - - - - - - 2B-10
ENGINE, CYLINDER HEAD COVER - OM926LA - 2B-14
ENGINE, CRANKSHAFT AND FLYWHEEL - OM926LA - - - - - - - - - - - - - - - - - - - 2B-16
ENGINE, CONNECTING ROD AND PISTONS - OM926LA - - - - - - - - - - - - - - - - - - 2B-18
ENGINE, CAMSHAFT AND TIMING PARTS - OM926LA- - - - - - - - - - - - - - - - - - - 2B-20
ENGINE, INJECTION PUMP - OM926LA - 2B-22
ENGINE, FUEL LINES - OM926LA - 2B-24
ENGINE, FUEL FILTER - OM926LA - 2B-26

https://truckmanualshub.com/

TABLE OF CONTENTS

ENGINE, FLAMESTART SYSTEM - OM926LA - 2B-28
ENGINE, TURBO CHARGER - OM926LA - 2B-30
ENGINE, AIR COMPRESSOR - OM926LA - 2B-32
ENGINE, AIR COMP. ATTACHMENT PARTS - OM926LA - - - - - - - - - - - - - - - - - - 2B-34
ENGINE, INTAKE MANIFOLD - OM926LA- 2B-36
ENGINE, EXHAUST MANIFOLD - OM926LA - 2B-38
ENGINE, ELECTRICAL EQUIPMENT - OM926LA - 2B-40
ENGINE, STARTING MOTOR - OM926LA- 2B-42
ENGINE, ALTERNATOR AND ATTACHMENT - OM926LA- - - - - - - - - - - - - - - - - - 2B-44
ENGINE, OIL PUMP - OM926LA - 2B-46
ENGINE, OIL FILTER AND OIL COOLER - OM926LA - - - - - - - - - - - - - - - - - - 2B-48
ENGINE, OIL LINES - OM926LA - 2B-50
ENGINE, WATER PUMP - OM926LA - 2B-52
ENGINE, FAN - OM926LA- 2B-54
ENGINE MOUNTINGS - OM926LA - 2B-56
ENGINE, AIRCONDITIONER COMPRESSOR - OM926LA- - - - - - - - - - - - - - - - - - 2B-58
EXHAUST SYSTEM - OM926LA - 2B-60
KIT, BIN HEATING (OPTIONAL) - OM926LA - 2B-62
AIR INTAKE SYSTEM - OM926LA- 2B-64
AIR CLEANER - OM926LA - 2B-66
FUEL SYSTEM - OM926LA - 2B-68
FUEL-WATER FILTER UNIT - OM926LA - 2B-70
HANDLIFT PUMP & PRE-FILTER - OM926LA - 2B-72
ENGINE COOLING SYSTEM : DETAIL A - OM926LA - - - - - - - - - - - - - - - - - - 2B-74
ENGINE COOLING SYSTEM, RADIATOR - OM926LA- - - - - - - - - - - - - - - - - - - 2B-78

SECTION 3: DRIVETRAIN - 3-1
TRANSMISSION MISC. PARTS : DETAIL A - 3-2
TRANSMISSION MISC. PARTS : DETAIL B - 3-4
TRANSMISSION HOUSING : DETAIL A - 3-6
TRANSMISSION HOUSING : DETAIL B - 3-8
OIL SUPPLY, CONTROL INSERT : DETAIL A - 3-10
OIL SUPPLY, COVER PLATE : DETAIL A - 3-14
OIL SUPPLY, CONTROL INSERT : DETAIL B - 3-16
OIL SUPPLY, COVER PLATE : DETAIL B - 3-20
RETARDER VALVE - 3-22
GEARBOX PLANETARY - 3-24
COUPLING - 3-26
OUTPUT - 3-38
SHIFT CONTROL - 3-42
SHIFT CONTROL, VALVE BLOCK A : DETAIL A - 3-46
SHIFT CONTROL, VALVE BLOCK A : DETAIL B - 3-48
SHIFT CONTROL, VALVE BLOCK B : DETAIL A - 3-50
SHIFT CONTROL, VALVE BLOCK B : DETAIL B - 3-52
SHIFT CONTROL, THROTTLE VALVE - 3-54
TRANSMISSION DIPSTICK : DETAIL A - 3-56
TRANSMISSION DIPSTICK : DETAIL B - 3-58
TRANSMISSION OIL SUMP- 3-60
TORQUE CONVERTER : DETAIL A - 3-62
TORQUE CONVERTER : DETAIL B - 3-64
POWER TAKE OFF : DETAIL A - 3-66
POWER TAKE OFF : DETAIL B - 3-68
HEAT EXCHANGER - 3-70
PERIPHERALS : DETAIL A - 3-72
PERIPHERALS : DETAIL B - 3-74
TRANSMISSION COOLING SYSTEM - 3-76
DROPBOX MISCELLANEOUS PARTS - 3-78
DROP BOX MOUNTINGS - 3-80

https://truckmanualshub.com/

TABLE OF CONTENTS

DROP BOX HOUSING - 3-82
DROP BOX INPUT SHAFT - 3-84
DROP BOX IDLER - 3-86
DROP BOX OUTPUT SHAFT - 3-88
PARK BRAKE - 3-90
PARK BRAKE ASSEMBLY - 3-92
ACTUATOR ASSEMBLY - 3-94
PROPSHAFTS: B25D - 3-96
PROPSHAFTS: B30D - 3-98
AXLE, FRONT: B30D - 3-100
AXLE, FRONT: B30D WDB OPTION - 3-102
FRONT DIFFERENTIAL ASSEMBLY: B30D - 3-104
FRONT DIFF, CLUTCH CONFIGURATION: B30D - 3-108
AXLE, FRONT: B25D - 3-110
FRONT DIFFERENTIAL ASSEMBLY: B25D - 3-112
FRONT DIFF, CLUTCH CONFIGURATION: B25D - 3-114
THRU DRIVE AND OSCILLATION JOINT - 3-116
AXLE, MIDDLE: B30D ZF DIFFERENTIAL - 3-118
AXLE, MIDDLE: B30D BELL DIFFERENTIAL - 3-120
AXLE, MIDDLE: B30D WDB OPTION - 3-122
MIDDLE DIFFERENTIAL ASSY: B30D ZF DIFF. - 3-124
MIDDLE DIFF, CLUTCH CONFIG: B30D ZF DIFF. - 3-130
MIDDLE DIFFERENTIAL ASSEMBLY: B30D BELL DIFF. - 3-132
MIDDLE DIFF, CLUTCH CONFIG: B30D BELL DIFF. - 3-136
MIDDLE DIFFERENTIAL ASSY: B30D WDB OPTION - 3-138
MIDDLE DIFF, CLUTCH CONFIG: B30D WDB OPTION - 3-142
AXLE, MIDDLE: B25D - 3-144
MIDDLE DIFFERENTIAL ASSY: B25D - 3-146
MIDDLE DIFF, CLUTCH CONFIGURATION: B25D - 3-152
AXLE, REAR: B30D ZF DIFFERENTIAL - 3-154
AXLE, REAR: B30D BELL DIFFERENTIAL - 3-156
AXLE, REAR: B30D WDB OPTION - 3-158
REAR DIFFERENTIAL ASSEMBLY: B30D ZF DIFF. - 3-160
REAR DIFF, CLUTCH CONFIGURATION: B30D ZF DIFF. - 3-164
REAR DIFFERENTIAL ASSEMBLY: B30D BELL DIFF. - 3-166
REAR DIFF, CLUTCH CONFIG: B30D BELL DIFF. - 3-170
REAR DIFF, CLUTCH CONFIG: B30D WDB OPTION - 3-176
AXLE, REAR: B25D - 3-178
REAR DIFFERENTIAL ASSEMBLY: B25D - 3-180
REAR DIFF, CLUTCH CONFIGURATION: B25D - 3-182
BRAKE ASSEMBLY - 3-184
PLANETARY HUB - 3-186
WHEEL SET - 3-188
WHEEL SET (OPTIONAL): B30D (WIDE) - 3-190

SECTION 4: HYDRAULICS - 4-1
HYDRAULIC SYSTEM, CAB - DETAIL A - 4-2
HYDRAULIC SYSTEM, CAB - DETAIL B - 4-4
BRAKE PEDAL - 4-6
STEERING CONTROL VALVE, EATON - 4-8
EMERGENCY STEERING PUMP CHECK VALVE - 4-10
PUMP, EMERGENCY STEERING - 4-12
HYDRAULIC KIT: CAB TILT SYSTEM - 4-14
CAB TILT CYLINDER BREAKDOWN - 4-16
PUMP, CAB TILT - 4-18
HYDRAULIC SYSTEM, VOAC BLOCK - 4-20
HYDRAULIC, VOAC BLOCK - PRESSURE SWITCH - 4-22
HYDRAULIC, VOAC BLOCK - VALVE POSITIONS - 4-24

https://truckmanualshub.com/

TABLE OF CONTENTS

HYDRAULIC, VOAC BLOCK - VALVES - 4-26
HYDRAULIC, VOAC BLOCK - TIP SECTION - 4-28
HYDRAULIC, STEERING CYLINDER - 4-30
HYDRAULIC SYSTEM, FRONT CHASSIS- 4-32
ACCUMULATOR KIT - SOUTH AFRICA- 4-34
ACCUMULATOR KIT - EUROPE - 4-36
ACCUMULATOR KIT, WDB OPTION - SOUTH AFRICA - 4-38
ACCUMULATOR KIT, WDB OPTION - EUROPE - 4-40
HYD. SYS, FRONT AXLE COOLING, WDB OPTION - 4-42
HYDRAULIC PUMP A10V- 4-44
STEERING CYLINDER ASSEMBLY- 4-46
HYDRAULIC TANK MISC PARTS - 4-48
HYDRAULIC SYSTEM, REAR CHASSIS - 4-50
TIP CYLINDER BREAKDOWN - 4-52

SECTION 5: PNEUMATICS - 5-1
PNEUMATIC KIT, CAB - 5-2
KIT, AIR HORN (OPTIONAL) - 5-4
PNEUMATIC BLOCK ASSEMBLY- 5-6
PNEUMATIC SYSTEM, FRONT CHASSIS - 5-8
PURGE TANK VALVE- 5-10
KIT, AIR DRIER- 5-12
KIT, REPAIR, AIR DRIER - 5-14
KIT, 10L RESERVOIR- 5-16
PNEUMATIC KIT : REAR CHASSIS - 5-18

SECTION 6: ELECTRICAL - 6-1
CAB HARNESS & RELATED COMPONENTS - DETAIL A - - - - - - - - - - - - - - - - - - - 6-2
CAB HARNESS & RELATED COMPONENTS - DETAIL B - - - - - - - - - - - - - - - - - - - 6-4
CAB HARNESS & RELATED COMPONENTS - DETAIL C - - - - - - - - - - - - - - - - - - - 6-6
FUSE AND RELAY PANEL COMPONENTS - 6-8
KIT, WIPER - 6-10
ELECTRICAL SYSTEM, CAB, TRANSMISSION - 6-12
REAR VIEW MIRROR ELECTRICAL KIT (CHOICE) - 6-14
REAR VIEW MIRROR MANUAL KIT (CHOICE) - 6-16
MIRRORS - 6-18
ELEC. SYSTEM, CAB, BEACON (OPTIONAL)- 6-20
ELEC. SYSTEM, CAB, WORKLIGHTS (OPTIONAL) - 6-22
ELEC. SYSTEM, CAB, REVERSE LIGHT (OPTIONAL) - - - - - - - - - - - - - - - - - - - 6-24
ELEC. SYSTEM, CAB, MEMORY MODULE (OPTIONAL) - - - - - - - - - - - - - - - - - - - 6-26
ELEC. SYSTEM, CAB, SATELITE (OPTIONAL) - 6-28
KIT, RADIO (OPTIONAL) - 6-30
ELECTRICAL SYSTEM, ENGINE - 6-32
ELECTRICAL SYSTEM, FUEL HEATER (OPTIONAL) - 6-34
ELECTRICAL SYSTEM, LIGHT BREAKDOWNS- 6-36
GRILL, HEAD LIGHTS - 6-38
ELECTRICAL SYSTEM, ARTIC - 6-40
ELECTRICAL SYSTEM, BATTERY BOX - 6-42
ELEC. SYSTEM, FRONT CHASSIS, TRANSMISSION - 6-44
ELECTRICAL SYSTEM, REAR CHASSIS - 6-46
ELECTRICAL SYSTEM, OBW- 6-48
ELECTRICAL CONNECTORS (SHEETS 1 OF 8) - 6-50
ELECTRICAL CONNECTORS (SHEETS 2 OF 8) - 6-52
ELECTRICAL CONNECTORS (SHEETS 3 OF 8) - 6-54
ELECTRICAL CONNECTORS (SHEETS 4 OF 8) - 6-56
ELECTRICAL CONNECTORS (SHEETS 5 OF 8) - 6-58
ELECTRICAL CONNECTORS (SHEETS 6 OF 8) - 6-60

https://truckmanualshub.com/

TABLE OF CONTENTS

ELECTRICAL CONNECTORS (SHEETS 7 OF 8) - 6-62
ELECTRICAL CONNECTORS (SHEETS 8 OF 8) - 6-64

SECTION 7: FRAME & BODY - 7-1
CAB ASSEMBLY - 7-2
CAB SHELL- 7-4
CAB / BONNET INTERFACE SEAL - 7-6
HVAC SEALING,CAB - 7-8
WINDOW GUARD, HANDRAILS & CAB MOUNTINGS- 7-10
REAR VIEW MIRROR BRACKETS - 7-12
CAB DOOR ASSEMBLY - 7-14
CAB WINDOWS - 7-16
WINDOW CATCHES - 7-18
DOOR, HVAC SYSTEM - 7-20
CAB INTERIOR MISC. PARTS - 7-22
CAB INTERIOR HATCHES AND LIDS- 7-24
CAB FLOOR MAT & INTERIOR PANELS - 7-26
ROOF HEADLINERS - 7-28
OPERATOR AND TRAINER SEAT INSTALLATION - 7-30
TRAINER SEAT MOUNTING - 7-32
SEATS INSTALLATION, SEARS - 7-34
BASE, SEAT ASSEMBLY, SEARS - 7-36
STEERING COLUMN MISCELLANEOUS PARTS - 7-38
STEERING COLUMN - 7-40
CAB AIR DUCTING, HVAC SYSTEM - 7-42
AIRCON DRIER UNIT AND PIPING - 7-44
AIRCONDITIONER UNIT BREAKDOWN - 7-46
AIRCON SYSTEM: FRONT CHASSIS - 7-48
FRONT CHASSIS KIT- 7-50
BONNET KIT: DETAIL A - 7-52
BONNET KIT: DETAIL B - 7-58
BONNET CATCH - 7-60
GRILL- 7-62
BELLY PLATE - 7-64
MUDGUARDS AND MISCELLANEOUS PARTS - 7-66
BATTERY BOX KIT - 7-68
FUEL TANK MISC PARTS - 7-70
CAP, DIESEL FILLER - 7-72
COVER, HEADLIGHT - 7-74
FRONT SUSPENSION - 7-76
LINK ASSEMBLY, FRONT SUSPENSION - 7-78
SPHERICAL BEARING BREAKDOWN - 7-80
CYLINDER, SUSPENSION STRUT - 7-82
HYDRAULIC TANK MISC. PARTS - 7-84
HYDRAULIC TANK FILTER ASSEMBLY - 7-86
ARTIC JOINT BEARING ASSEMBLY - 7-88
REAR CHASSIS KIT - 7-92
REAR SUSPENSION - 7-94
BIN, MISCELLANEOUS PARTS: B30D - 7-96
BIN, MISCELLANEOUS PARTS: B25D - 7-98
BIN PIVOT - 7-100
BIN LINER KIT - 7-102
AUTOGATE- 7-104
DECALS - 7-106

https://truckmanualshub.com/

SECTION 8: SERVICE KITS - 8-1
SERVICE KITS - 8-2
SERVICE KITS (CONTINUED) - 8-4

SECTION 9:
RECOMMENDED LUBRICANTS, ADHESIVES AND PAINTS - - - - - - - - - 9-1
LUBRICANTS - 9-2
ADHESIVES - 9-3
PAINTS AND PROCEDURES - 9-4

SECTION 10: SPECIAL TOOLS - 10-1
ENGINE - OM906LA SERVICE TOOLS, KIT 262126- 10-2
ENGINE - OM906LA REPAIR TOOLS, KIT 262127 - 10-6
ENGINE - OM906LA REPAIR TOOLS, KIT 262128 - 10-10
GEAR RATIO 13100 TRANSFER CASE - 10-12
AXLES, DIFFS & FINAL DRIVES : REPAIR/OVERHAUL- - - - - - - - - - - - - - - - - - - 10-24
ZF HK 3.18 LS DIFFERENTIAL - 10-26
SUSPENSION : REPAIR/OVERHAUL - 10-28
HYDRAULICS : REPAIR/OVERHAUL - 10-30
FRAME & OSCILLATION TOOLS - 10-32
DIAGNOSTIC TOOLS (DRIVELINE) - 10-34
TYRE INFLATION KIT - (OPTIONAL) - 10-36

SECTION 11: NUMERICAL INDEX - 11-1

https://truckmanualshub.com/


SECTION 1: GENERAL INFORMATION

https://truckmanualshub.com/

PAGE LAYOUT

HEADING

DOOR, HVAC SYSTEM



RELEVANT MACHINE

B30D & B25D 6X6 ADT

REV 0

7-12

PAGE NUMBER (CHAPTER - PAGE)


ILLUSTRATION ID

PAGE UPDATE REVISION LEVEL

New pages issued with service bulletins will have a higher revision level eg. ***REV 1***

https://truckmanualshub.com/

PAGE LAYOUT



https://truckmanualshub.com/

LIST OF ABBREVIATIONS

ADE	Atlantic Diesel Engines	**LED**	Light Emitting Diode
ATDC	After Top Dead Centre	**l/min**	Litre Per Minute
AC	Alternating Current	**lube**	Lubrication
API	American Petroleum Institute	**Mar**	March
A	Ampere	**max**	Maximum
Ah	Ampere Hours	**MPa**	Megapascal
approx	Approximately	**m**	Metre
Apr	April	**mA**	Miliampere
A/R	As Required	**mm**	Millimetre
assy	Assembly	**min**	Minimum
Aug	August	**NPT**	National Pipe Thread
BTDC	Before Top Dead Centre	**N**	Newton
BHP	Brake Horse Power	**Nm**	Newton Metre
BSP	British Standard Pipe	**NLA**	No Longer Available
CO2	Carbon Dioxide	**NSI**	Non Stock Item
CGA	Compressed Gas Association Inc	**N/C**	Normally Closed
CTD	Control Traction Differential	**N/O**	Normally Open
in3	Cubic Inch	**Nov**	November
m3	Cubic Metre	**No.**	Number
mm3	Cubic Milimetre	**Oct**	October
Dec	December	**OD**	Outside Diameter
db	Decibels	**P/N**	Part Number
deg or o	Degree	**lb**	Pound
oC	Degree Celsius	**psi**	Pound per Square Inch
dia	Diameter	**PTO**	Power Take Off
DBH	Diameter at Breast Height	**press**	Pressure
diff	Differential	**Qty**	Quantity
DC	Direct Current	**RSG**	Recommended Service Guide
E.G.S.	Electronic Gear Shifting	**REV**	Reverse
ext	Extension	**rev/min**	Revolutions Per Minute
Feb	February	**RH**	Right Hand
ft lb	Foot Pound	**RHS**	Right Hand Side
FWD	Forward	**Sep**	September
FMC	Front Mount Cab	**SIB**	Service Information Bulletin
GAL/ min	Gallon Per Minute	**SMR**	Service Metre Reading
Gr	Grade	**SMC**	Side Mounted cab
g	Gram	**SAE**	Society of Automotive Engineers
hz	Hertz	**SABS**	South African Bureau of Standards
hex	Hexagonal	**std**	Standard
HT	High Tensile	**strt**	Straight
incl.	Including	**S/TK**	SuperTruck
ID	Internal Diameter	**temp**	Temperature
ISO	International Organization of Standards	**thru**	Through to and Including
Jan	January	**TDC**	Top Dead Centre
JIC	Joint Industry Conference Standards	**TBN**	Total Base Number
Jul	July	**UNC**	Unified National Coarse
Jun	June	**USGAL**	United States Gallon (3.7854 litre)
kg	Kilogram	**V**	Volt
km/h	Kilometre Per Hour	**VIN**	Vin Identification Number
kPa	Kilopascal	**W**	Watt
kW	Kilowatt	**W/O**	With out
LH	Left Hand	**ZF**	Zahnradfabrik Passau Gmbh
LHS	Left Hand Side		

https://truckmanualshub.com/

BULLETINS

Record the relevant information from the Technical Documentation Bulletins, Service Bulletins and Parts Bulletins into this manual as follows:-

i. Ensure the manual number (87xxxxx) reflected in the bulletin is the same as the 87xxxxx number on the front page of this manual.

ii. Carry out the instructions as detailed in the bulletin.

iii. Record the required information below.

v. File the bulletins in numerical order in a suitable 3 or 4 ring binder.

TECHNICAL DOCUMENTATION BULLETIN RECORD

BULLETIN NO.	DATE RECEIVED	INSERTED BY	
		NAME	SIGNATURE

BULLETINS

BULLETIN NO.	DATE RECEIVED	INSERTED BY	
		NAME	SIGNATURE

https://truckmanualshub.com/

https://truckmanualshub.com/

ORDERING OF PARTS

To facilitate the ordering of parts, the following information is required to determine the correct part for your BELL product.


1. The model and VIN number of your BELL product.
2. The serial number of the relevant assembly.
3. The part number.
4. The section, page and item number where the part appears in the parts manual.
5. The quantity required.
6. Your order number.
7. The delivery address.
8. The method of delivery.


Any other information which will assist us in getting the parts to you with the least amount of trouble or delay should be given. This information will be noted and filed for future reference.


https://truckmanualshub.com/

https://truckmanualshub.com/

MACHINE DIMENSIONS B30D









30D0001CFM - A


https://truckmanualshub.com/

https://truckmanualshub.com/

MACHINE DIMENSIONS B25D








25D0001CFM - A

https://truckmanualshub.com/

https://truckmanualshub.com/

SERIAL NUMBER PLATES




TD0004327

https://truckmanualshub.com/


https://truckmanualshub.com/

ENGINE IDENTIFICATION - TIER 2 AND TIER 3



Engine LH Side view

Engine Specification Label positioned on ECU



Engine Number Detail

950 Indicates **Tier 2** Engine

906.950 - 00 - 000000 Tier 2

906.991 - 00 - 000000 Tier 3

991 Indicates **Tier 3** Engine

TD0004320

https://truckmanualshub.com/


https://truckmanualshub.com/

SECTION 2A: ENGINE - OM906LA

https://truckmanualshub.com/

ENGINE, MISC. ITEMS : TIER 2 - OM906LA

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE



TD0003216
E14832406 - 0


https://truckmanualshub.com/

ENGINE, MISC. ITEMS : TIER 2 - OM906LA

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	255001	1	RING,CLAMPING,OM906LA	X	X			
2	251115	1	ENGINE,DC OM906LA T2	X	X			REFER TO SIB 2010/1027
3	217857	1	NONSLIP,SUMP	X	X			
4	207967	1	BOOT,RUBBER,DRAIN VALVE	X	X			
5	207646	2	MTG,RUBBER,T/MISSION,SPLT	X	X			
6	183140	2	MTG,ENGINE	X	X			
7	176592	4	SPACER,ENG MTG	X	X			
8	175112	1	PLT,COVER,F/WHEEL,HOUSING	X	X			
9	122136	1	VALVE,DRAIN	X	X			
10	121090	1	CONNECT,SPEC	X	X			
11	101324	2	BOLT,HEXHD	X	X			
12	100827	8	SCREW,HEXHD	X	X			
13	100653	2	NUT,STOVER	X	X			
14	100643	8	SCREW,HEXHD	X	X			
15	100548	2	WASHER,HARDENED	X	X			
16	100536	8	WASHER,HARDENED	X	X			
17	100532	4	WASHER,HARDENED	X	X			
18	100370	12	WASHER,HARDENED	X	X			
19	100238	2	SCREW,HEXHD	X	X			
20	100090	12	SCREW,HEXHD	X	X			

https://truckmanualshub.com/



TD0003229
E14832407 - 0


https://truckmanualshub.com/

ENGINE, MISC. ITEMS : TIER 3 - OM906LA

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	255001	1	RING,CLAMPING,OM906LA	X	X			
2	251111	1	ENGINE,DC OM906LA T3	X	X			REFER TO SIB 2010/1027
3	217857	1	NONSLIP,SUMP	X	X			
4	207967	1	BOOT,RUBBER,DRAIN VALVE	X	X			
5	207646	2	MTG,RUBBER,T/MISSION,SPLT	X	X			
6	183140	2	MTG,ENGINE	X	X			
7	176592	4	SPACER,ENG MTG	X	X			
8	175112	1	PLT,COVER,F/WHEEL,HOUSING	X	X			
9	122136	1	VALVE,DRAIN	X	X			
10	121090	1	CONNECT,SPEC	X	X			
11	101324	2	BOLT,HEXHD	X	X			
12	100827	8	SCREW,HEXHD	X	X			
13	100653	2	NUT,STOVER	X	X			
14	100643	8	SCREW,HEXHD	X	X			
15	100548	2	WASHER,HARDENED	X	X			
16	100536	8	WASHER,HARDENED	X	X			
17	100532	4	WASHER,HARDENED	X	X			
18	100370	12	WASHER,HARDENED	X	X			
19	100238	2	SCREW,HEXHD	X	X			
20	100090	12	SCREW,HEXHD	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221850	1	CRANKCASE,LESS CYLINDER LINERS	X	X		UPTO S/N: 301570	
5	DC222128	1	CRANKCASE,C/W CYLINDER LINERS	X	X		FROM S/N: 301571	REFER SIB 2005/1103
11	DC221799	2	SLEEVE,FLYWHEEL	X	X			
17	DC220737	3	BALL,REAR,OIL BORE	X	X			
23	DC100059	1	PIN,DOWEL,BEARING CAP	X	X			
29	DC100670	14	SCREW,BEARING CAP	X	X		UPTO S/N: 185258	
29	DC100739	14	SCREW,BEARING CAP	X	X		FROM S/N: 185259	
35	DC150174	6	BUSHING,CAMSHAFT BEARING	X	X			
41	DC150175	1	BUSHING,CAMSHAFT BEARING	X	X			
47	DC220543	6	PLUG,WELCH,34MM	X	X			
47	DC220549	A/R	PLUG,WELCH,36.2MM	X	X			
53	DC120195	10	PLUG,EXPANSION 40MM	X	X			
53	DC120196	A/R	PLUG,EXPANSION 42MM	X	X			
56	DC221800	1	THROTTLE,TRANSVERSE FUEL DUCT	X	X			
59	DC221801	6	NOZZLE,OIL	X	X			
65	DC220735	2	BALL,OIL PASSAGE FRONT / REAR	X	X			
65	DC221802	2	BALL,FUEL FEED LOCK	X	X			
65	DC221803	2	BALL,FUEL RETURN LOCK	X	X			
65	DC220737	1	BALL,LOCK TRANSVERSE FUEL DUCT	X	X			
65	DC220737	5	BALL,LOCK OIL SUPPLY UNIT PUMP	X	X			
71	DC221804	1	INTERMEDIATE PIECE,OIL PUMP	X	X			
77	DC221805	2	SLEEVE,OIL PUMP	X	X			
83	DC221806	1	INTERMEDIATE PIECE,TURBO,OIL	X	X			
89	DC221807	1	SLEEVE,PULSE SENDER	X	X			
95	DC120226	1	PLUG,EXPANSION	X	X			
107	DC140181	1	RING,SEAL,INTERMEDIATE FLANGE	X	X			
113	DC120116	1	PLUG,SCREW,CYL/HEAD	X	X			
119	DC140150	1	RING,SEAL,CYL/HEAD	X	X			
125	DC120158	1	PLUG,SCREW,OIL PASSAGE REAR	X	X			
131	DC140182	1	RING,SEAL,OIL PASSAGE REAR	X	X			
137	DC100173	1	PLUG,SCREW,MAIN OIL PASSAGE	X	X			
143	DC140172	1	RING,SEAL,MAIN OIL PASSAGE	X	X			
149	DC120227	1	PLUG,SCREW,WATER DRAIN	X	X			
155	DC221809	2	SLEEVE,CYL/HEAD	X	X			
161	DC120170	1	PLUG,SCREW,OIL PASSAGE OIL PUMP	X	X			
167	DC120114	1	PLUG,SCREW,MAIN OIL PASSAGE	X	X			
173	DC140149	1	RING,SEAL,MAIN OIL PASSAGE	X	X			
224	DC221810	1	VALVE,OVERFLOW,RELIEF 4.5 - 5 BAR	X	X			
230	DC140172	1	RING,SEAL,CYL/BLOCK	X	X			
242	DC221811	1	SENDER,FUEL TEMPERATURE	X	X		UPTO S/N: 104832	
242	DC221743	1	SENDER,FUEL TEMPERATURE	X	X		FROM S/N: 104833	
244	DC221742	1	SENDER,OIL PRESSURE	X	X			
248	DC140149	1	RING,SEAL,SENDER UNIT,FUEL TEMP	X	X			
250	DC140172	1	RING,SEAL,SENDER UNIT,OIL PRESSURE	X	X			
266	DC221812	1	VALVE,SOLENOID	X	X			
278	DC221813	1	VALVE	X	X			
290	DC221814	1	GASKET	X	X			
296	DC100671	2	SCREW,FLANGED	X	X			
314	DC260106	1	KIT,GASKET CYLINDER CRANKCASE	X	X			

https://truckmanualshub.com/




TD0003249

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
15	DC222149	1	COVER,TIMING	X	X			
20	DC140197	1	SEAL,OIL CRANKSHAFT REAR	X	X			
25	DC221254	1	COVER,CAP FOR CRANK MECHANISM	X	X			
27	DC221977	1	GASKET,COVER	X	X			
29	DC100507	2	SCREW	X	X			
40	DC100177	1	PLUG,ALLEN	X	X			
45	DC140151	1	RING,SEAL	X	X			
50	DC220100	1	PLUG,SCREW	X	X			
55	DC140155	1	RING,SEAL	X	X			
95	DC100673	9	SCREW,FLANGED,TIMING CASE	X	X			
95	DC100674	5	SCREW,FLANGED,TIMING CASE	X	X			
95	DC100742	3	SCREW,FLANGED,TIMING CASE	X	X			
97	DC100597	1	SCREW,FLANGED,TIMING CASE	X	X			
120	DC222150	1	COVER,TIMING CASE	X	X			
130	DC222151	1	GASKET	X	X			
140	DC100414	5	SCREW	X	X			
150	DC120114	1	PLUG,SCREW	X	X			
155	DC140149	1	RING,SEAL	X	X			

https://truckmanualshub.com/



https://truckmanualshub.com/


ENGINE, OIL PAN AND DIPSTICK - OM906LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221526	1	PAN,OIL	X	X			
17	DC221818	1	GASKET,OIL PAN	X	X			
20	DC120029	1	PLUG,SCREW,OIL DRAIN	X	X			
25	DC140155	1	RING,SEAL,OIL DRAIN	X	X			
80	DC221819	1	SENDER,OIL LEVEL	X	X			
85	DC120200	3	PLUG,SENDER	X	X			
100	DC100085	22	SCREW,HEX	X	X			
175	DC221820	1	TUBE,GUIDE TOP DIPSTICK	X	X			
185	DC221821	1	TUBE,GUIDE BOTTOM DIPSTICK	X	X			
205	DC221822	1	GROMMET	X	X			
210	DC100597	1	SCREW,GUIDE TUBE	X	X			
218	DC120228	1	FITTING,GUIDE TUBE	X	X			
235	DC100677	1	CLAMP,GUIDE TUBE	X	X			
300	DC221823	1	DIPSTICK,OIL	X	X			
325	DC221152	1	CAP	X	X			
330	DC140145	1	RING,SEAL	X	X			
335	DC221851	1	BRACKET,OIL DIPSTICK	X	X			
340	DC100659	1	SCREW,GUIDE TUBE	X	X			
347	DC220562	1	CAP,RUBBER	X	X			
350	DC220407	1	CLAMP,RUBBER CAP	X	X			

https://truckmanualshub.com/

ENGINE, CYL. HEAD AND VALVES : TIER 2 - OM906LA

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE




https://truckmanualshub.com/

ENGINE, CYL. HEAD AND VALVES : TIER 2 - OM906LA

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222153	1	CYLINDER HEAD,C/W VALVES & C/THROTTLE	X	X			
10	DC220735	6	BALL,FASTENER CONSTANT THROTTLE	X	X			
15	DC220543	2	PLUG,EXPANSION,34MM	X	X			
15	DC220549	A/R	PLUG,EXPANSION,36MM	X	X			
20	DC120256	A/R	PLUG,EXPANSION,WEB COOLING,M12	X	X			
20	DC120257	A/R	PLUG,EXPANSION,WEB COOLING,M13	X	X			
25	DC220545	A/R	PLUG,EXPANSION,25MM	X	X			
25	DC220195	1	PLUG,EXPANSION,40MM	X	X			
30	DC220737	6	BALL,LEAK,OIL HOLE PLUG	X	X			
30	DC220735	2	BALL,LEAK,OIL HOLE PLUG	X	X			
30	DC220735	1	BALL,TO PLUG COOLING WATER BORE	X	X			
33	DC120258	4	PLUG,SCREW BRACING	X	X			
40	DC221825	12	SEAT,VALVE,INTAKE STANDARD	X	X			
40	DC221826	12	SEAT,VALVE,INTAKE REPAIR I,35.37MM	X	X			
40	DC221827	12	SEAT,VALVE INTAKE REPAIR II,35.57MM	X	X			
40	DC221828	6	SEAT,VALVE EXHAUST STANDARD	X	X			
40	DC221829	6	SEAT,VALVE EXHAUST REPAIR I,40.37MM	X	X			
40	DC221830	6	SEAT,VALVE EXHAUST REPAIR II,40.57MM	X	X			
45	DC221831	18	GUIDE,VALVE,INTAKE & EXHAUST,STD	X	X			
45	DC221832	A/R	GUIDE,VALVE,INTAKE & EXHAUST,+0.2MM	X	X			
45	DC221833	A/R	GUIDE,VALVE,INTAKE & EXHAUST,+0.5MM	X	X			
50	DC140160	6	RING,SEAL	X	X			
55	DC221834	6	SLEEVE	X	X			
60	DC221835	12	VALVE,INTAKE	X	X			
60	DC221836	6	VALVE,EXHAUST	X	X			
65	DC100678	18	WASHER,VALVE SPRING	X	X			
70	DC221837	12	SPRING,INTAKE VALVE	X	X			
70	DC221838	6	SPRING,EXHAUST VALVE	X	X			
75	DC221839	18	RETAINER,SPRING	X	X			
80	DC220030	36	COLLET,VALVE	X	X			
85	DC221840	18	HOLDER,SEAL	X	X			
95	DC221841	6	VALVE,CONSTANT THROTTLE	X	X			
100	DC221842	6	GUIDE	X	X			
105	DC221843	6	SPRING	X	X			
110	DC221844	6	RETAINER,SPRING	X	X			
115	DC221845	12	VALVE,COLLET	X	X			
120	DC221846	6	PISTON	X	X			
130	DC221847	6	COVER	X	X			
175	DC221848	6	BRIDGE,VALVE	X	X			
180	DC222155	1	GASKET,CYLINDER HEAD TO CRANKCASE	X	X			
185	DC100679	14	SCREW,CYLINDER HEAD TO CRANKCASE	X	X			
260	DC222114	6	INJECTOR,COMPLETE	X	X			
275	DC140185	6	RING,SEAL,INJECTOR TO CYLINDER HEAD	X	X			
282	DC140186	6	RING,SEAL,INJECTOR TO CYLINDER HEAD	X	X			
285	DC221647	6	SOCKET,PIPE	X	X			
290	DC140166	6	RING,SEAL SOCKET TO CYLINDER HEAD	X	X			
295	DC100636	6	SCREW,FITTING ON INJECTOR	X	X			
300	DC221854	6	BRACKET,CLAMPING,INJECTOR TO CYL HD	X	X			
315	DC100741	6	SCREW,INJECTOR TO CYL HEAD	X	X			
390	DC260125	1	KIT,CYLINDER HEAD GASKET	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222153	1	CYLINDER HEAD,C/W VALVES & C/THROTTLE	X	X			
10	DC220735	6	BALL,FASTENER CONSTANT THROTTLE	X	X			
15	DC220543	2	PLUG,EXPANSION,34MM	X	X			
15	DC220549	A/R	PLUG,EXPANSION,36MM	X	X			
20	DC120256	A/R	PLUG,EXPANSION,WEB COOLING,M12	X	X			
20	DC120257	A/R	PLUG,EXPANSION,WEB COOLING,M13	X	X			
25	DC220545	A/R	PLUG,EXPANSION,25MM	X	X			
25	DC120195	A/R	PLUG,EXPANSION,40MM	X	X			
30	DC220737	6	BALL,LEAK,OIL HOLE PLUG	X	X			
30	DC220735	2	BALL,LEAK,OIL HOLE PLUG	X	X			
30	DC220735	1	BALL,TO PLUG COOLING WATER BORE	X	X			
33	DC120258	4	PLUG,SCREW BRACING	X	X			
40	DC221825	12	SEAT,VALVE,INTAKE STANDARD	X	X			
40	DC221826	12	SEAT,VALVE,INTAKE REPAIR I,35.37MM	X	X			
40	DC221827	12	SEAT,VALVE INTAKE REPAIR II,35.57MM	X	X			
40	DC221828	6	SEAT,VALVE EXHAUST STANDARD	X	X			
40	DC221829	6	SEAT,VALVE EXHAUST REPAIR I,40.37MM	X	X			
40	DC221830	6	SEAT,VALVE EXHAUST REPAIR II,40.57MM	X	X			
45	DC221831	18	GUIDE,VALVE,INTAKE & EXHAUST,STD	X	X			
45	DC221832	A/R	GUIDE,VALVE,INTAKE & EXHAUST,+0.2MM	X	X			
45	DC221833	A/R	GUIDE,VALVE,INTAKE & EXHAUST,+0.5MM	X	X			
50	DC140160	6	RING,SEAL	X	X			
55	DC221834	6	SLEEVE	X	X			
60	DC221835	12	VALVE,INTAKE	X	X			
60	DC221836	6	VALVE,EXHAUST	X	X			
65	DC100678	18	WASHER,VALVE SPRING	X	X			
70	DC221837	12	SPRING,INTAKE VALVE	X	X			
70	DC221838	6	SPRING,EXHAUST VALVE	X	X			
75	DC221839	18	RETAINER,SPRING	X	X			
80	DC220030	36	COLLET,VALVE	X	X			
85	DC221840	18	HOLDER,SEAL	X	X			
95	DC221841	6	VALVE,CONSTANT THROTTLE	X	X			
100	DC221842	6	GUIDE	X	X			
105	DC221843	6	SPRING	X	X			
110	DC221844	6	RETAINER,SPRING	X	X			
115	DC221845	12	VALVE,COLLET	X	X			
120	DC221846	6	PISTON	X	X			
130	DC221847	6	COVER	X	X			
175	DC221848	6	BRIDGE,VALVE	X	X			
180	DC222155	1	GASKET,CYLINDER HEAD TO CRANKCASE	X	X			
185	DC100679	14	SCREW,CYLINDER HEAD TO CRANKCASE	X	X			
260	DC222154	6	INJECTOR,COMPLETE	X	X			
275	DC140185	6	RING,SEAL,INJECTOR TO CYLINDER HEAD	X	X			
282	DC140186	6	RING,SEAL,INJECTOR TO CYLINDER HEAD	X	X			
285	DC221647	6	SOCKET,PIPE	X	X			
290	DC140166	6	RING,SEAL SOCKET TO CYLINDER HEAD	X	X			
295	DC100636	6	SCREW,FITTING ON INJECTOR	X	X			
300	DC221854	6	BRACKET,CLAMPING,INJECTOR TO CYL HD	X	X			
315	DC100741	6	SCREW,INJECTOR TO CYL HEAD	X	X			
390	DC260125	1	KIT,CYLINDER HEAD GASKET	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222153	1	CYLINDER HEAD,C/W VALVES & C/THROTTLE	X	X			
135	DC120231	A/R	HELICOIL,M22X1.5X8.0	X	X			
140	DC120232	A/R	HELICOIL,M14X1X7.0	X	X			
145	DC120233	A/R	HELICOIL,M16X1.5X10.5	X	X			
150	DC120234	A/R	HELICOIL,M14X1.5X14	X	X			
155	DC120061	A/R	HELICOIL,M12X1.5X12	X	X			
160	DC120059	A/R	HELICOIL,M10X15	X	X			
165	DC120057	A/R	HELICOIL,M8X12	X	X			
170	DC120058	A/R	HELICOIL,M8X116	X	X			
190	DC120235	5	UNION,THREADED,CONSTANT THROTTLE	X	X			
195	DC140167	5	RING,SEAL CONSTANT THROTTLE TO HEAD	X	X			
200	DC130233	1	LINE,CONSTANT THROTTLE	X	X			
320	DC221855	1	SPINDLE,ROCKER ARM	X	X			
325	DC120236	2	PLUG,EXPANSION	X	X			
330	DC221856	6	ARM,ROCKER,INTAKE	X	X			
335	DC221857	6	ARM,ROCKER,EXHAUST	X	X			
340	DC150176	12	BUSHING	X	X			
345	DC100682	12	SCREW,ADJUSTING	X	X			
350	DC100683	12	NUT,ADJUSTING SCREW	X	X			
355	DC221858	1	BRACKET,ROCKER ARM,FRONT	X	X			
355	DC221859	5	BRACKET,ROCKER ARM,CENTRAL	X	X			
355	DC221860	1	BRACKET,ROCKER ARM,REAR	X	X			
360	DC221861	6	SPRING	X	X			
365	DC100684	12	WASHER	X	X			
370	DC221862	2	RING,LOCK	X	X			
375	DC221863	7	CLAMPING PIECE,ROCKER SHAFT TO HEAD	X	X			
380	DC100685	7	SCREW,ROCKER SHAFT TO CYLINDER HEAD	X	X			

https://truckmanualshub.com/


ENGINE, CYL. HEAD COVER - OM906LA



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221864	1	COVER,CYLINDER HEAD,PLASTIC	X	X			
17	DC221865	1	DIAPHRAGM	X	X			
18	DC222247	1	SPRING,BREATHER	X	X			REFER TO SIB 2007/1053
20	DC222134	1	GASKET,OIL SEP TO CYL/H/COVER	X	X			
29	DC220031	1	CAP,OIL FILLING	X	X			
32	DC220029	1	GASKET	X	X			
35	DC221866	7	INSERT,COVER TO CYLINDER HEAD	X	X			
41	DC221867	4	LOCK	X	X			
47	DC221529	1	GASKET	X	X			
68	DC221868	1	GASKET	X	X			
74	DC100686	7	SCREW,COVER TO CYLINDER HEAD	X	X			
115	DC130194	1	PIPE,BREATHER	X	X			
120	DC130196	1	HOSE,PIPE TO CYLINDER HEAD COVER	X	X			
125	203588	2	CLAMP,PIPE TO CYLINDER HEAD COVER	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC260151	1	CRANKSHAFT,C/W MAIN/BIG END BEARINGS	X	X			
10	DC100687	1	PIN,DOWEL,GEAR TO CRANKSHAFT	X	X			
15	DC221870	1	GEAR,CRANKSHAFT	X	X			
15	DC221871	1	GEAR,CRANKSHAFT,FITTING SIZE -0.30	X	X			
20	DC150205	7	BEARING,MAIN STANDARD	X	X			
20	DC222157	7	BEARING,MAIN,FITTING SIZE 0.10	X	X			
20	DC222158	7	BEARING,MAIN,FITTING SIZE 0.25	X	X			
20	DC222159	7	BEARING,MAIN,FITTING SIZE 0.50	X	X			
20	DC222160	7	BEARING,MAIN,FITTING SIZE 0.75	X	X			
20	DC222161	7	BEARING,MAIN,FITTING SIZE 1.00	X	X			
25	DC100688	2	WASHER,THRUST,STANDARD	X	X			
25	DC100689	2	WASHER,THRUST REPAIR SIZE I,0.30MM	X	X			
25	DC100690	2	WASHER,THRUST,REPAIR SIZE II,0.50MM	X	X			
30	DC150183	6	BEARING,BIG END,STANDARD	X	X			
30	DC150191	6	BEARING,BIG END,FITTING SIZE 0.10	X	X			
30	DC150192	6	BEARING,BIG END,FITTING SIZE 0.25	X	X			
30	DC150193	6	BEARING,BIG END,FITTING SIZE 0.50	X	X			
30	DC150194	6	BEARING,BIG END,FITTING SIZE 0.75	X	X			
30	DC150195	6	BEARING,BIG END,FITTING SIZE 1.00	X	X			
35	DC221872	1	DAMPER,VIBRATION	X	X			
43	DC100691	6	SCREW,DAMPER/HUB TO CRANKSHAFT	X	X			
55	DC221873	1	FLYWHEEL,WITH RING GEAR	X	X			
60	DC221874	1	GEAR,RING	X	X			
70	DC100691	8	SCREW,FLYWHEEL TO CRANKSHAFT	X	X			
75	DC221875	1	GEAR,CRANKSHAFT	X	X			

https://truckmanualshub.com/




TD0003437

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221876	6	ROD,CONNECTING	X	X		UPTO S/N: 456854	
5	DC222152	6	ROD,CONNECTING	X	X		UPTO S/N: 606225	
5	DC222223	6	ROD,CONNECTING	X	X		FROM S/N: 608732	
10	DC100080	12	SCREW	X	X			
15	DC221877	6	PISTON,KIT,STANDARD,102MM	X	X			MAHLE
15	DC221878	6	PISTON,102MM,HEIGHT -.30	X	X			MAHLE
15	DC221879	6	PISTON,102MM,HEIGHT -.60	X	X			MAHLE
15	DC221880	6	PISTON,102MM,HEIGHT -.90	X	X			MAHLE
15	DC222231	6	PISTON,102.30MM,HEIGHT -.30	X	X			MAHLE
15	DC222232	6	PISTON,102.60MM,HEIGHT -.60	X	X			MAHLE
15	DC222233	6	PISTON,102.90MM,HEIGHT -.90	X	X			MAHLE
20	DC260108	6	PISTON RING SET,102MM STD	X	X			
20	DC260153	6	PISTON RING SET,102.30MM	X	X			
20	DC260154	6	PISTON RING SET,102.60MM	X	X			
20	DC206155	6	PISTON RING SET,102.90MM	X	X			
25	DC221881	6	PIN,PISTON	X	X			
30	DC221882	12	RING,RETAINING	X	X			

https://truckmanualshub.com/




TD0003438

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221883	1	CAMSHAFT	X	X			
15	DC221885	1	PIN,CYLINDRICAL	X	X			
20	DC221886	12	FOLLOWER,CAM,INLET/EXHAUST VALVES	X	X			
25	DC221887	12	ROD,PUSH INLET/EXHAUST VALVES	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221888	6	PUMP,FUEL INJECTION	X	X			
10	DC260109	6	KIT,SEAL RING	X	X			BLACK SEAL - TOP,GREEN SEAL - BOT.
15	DC140187	6	RING,SEAL PUMP TO CRANKCASE	X	X			
17	DC140198	6	KIT,REPAIR,FUEL INJECTION PUMP	X	X			
20	DC100692	12	SCREW,PUMP TO CRANKCASE	X	X			
25	DC221889	1	PUMP,FUEL	X	X			
27	DC100693	1	SCREW,SHEAVE PULLEY	X	X			
30	DC221890	1	GASKET,FUEL PUMP TO CRANKCASE	X	X			
35	DC100112	3	SCREW,FUEL PUMP TO C/CASE	X	X			
55	DC221891	1	COVER,INJECTION PUMP	X	X			
60	DC221892	4	PIN,LOCKING COVER ATTACHMENT	X	X			
65	DC221893	4	RING,RETAINING COVER ATTACHMENT	X	X			
70	DC221894	4	SPRING,COVER ATTACHMENT	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC130197	6	PIPE,FUEL PUMP TO INJECTOR NOZZLE	X	X			
15	DC130198	1	PIPE,FUEL TO CYLINDER HEAD	X	X			
20	DC130199	1	PIPE,FROM FUEL FILTER TO FEED PUMP	X	X			
25	DC120211	3	BOLT,BANJO	X	X			
30	DC140172	6	RING,SEAL	X	X			
35	DC120209	2	CONNECTOR,FUEL LINE	X	X			
40	DC120210	2	NUT,UNION FUEL LINES	X	X			

https://truckmanualshub.com/




TD0003441

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
15	DC221896	1	FILTER,FUEL COMPLETE UNIT	X	X			
20	DC221680	1	HEAD,FUEL FILTER	X	X			
23	DC140174	1	RING,SEAL	X	X			
25	DC221897	1	COVER,PRE-FILTER	X	X			
28	DC140188	1	RING,SEAL	X	X			
35	DC140063	1	RING,SEAL	X	X			
40	DC100173	1	PLUG,SCREW	X	X			
45	DC221898	1	INSERT,FILTER	X	X			
50	DC221899	1	ELEMENT,FUEL FILTER KIT	X	X			INCLUDES ITEM 23
55	DC221900	1	ELEMENT,FUEL PRE-FILTER	X	X			INCLUDES ITEM 28
60	DC221901	1	GASKET,FUEL FILTER TO CYLINDER HEAD	X	X			
65	DC100694	1	SCREW,FILTER TO CYL/HEAD	X	X			
65	DC100352	2	SCREW,FILTER TO CYL/HEAD	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221902	1	VALVE,SOLENOID	X	X			
15	DC221903	1	BRACKET,SOLENOID VALVE	X	X			
20	DC100545	2	SCREW,SOLENOID VALVE TO BRACKET	X	X			
25	DC100597	1	SCREW,BRACKET TO CHARGING AIR PIPE	X	X			
30	DC100604	1	NUT,BRACKET TO CHARGING AIR PIPE	X	X			
40	DC130200	1	PIPE,FROM VALVE TO HEATER PLUGS	X	X			
90	DC100142	1	BOLT,BANJO PIPE TO SOLENOID VALVE	X	X			
95	DC140189	2	RING,SEAL PIPE TO SOLENOID VALVE	X	X			
100	DC130201	1	PIPE,FROM FUEL FILTER TO VALVE	X	X			
105	DC120237	1	BOLT,BANJO,FUEL PIPE TO FILTER	X	X			
110	DC100143	1	BOLT,BANJO,FUEL PIPE TO VALVE	X	X			
115	DC140189	2	RING,SEAL FUEL PIPE TO FUEL FILTER	X	X			
120	DC140190	2	RING,SEAL FUEL PIPE TO VALVE	X	X			
125	DC221904	1	PLUG,HEATER CHARGE AIR PIPE	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221587	1	TURBO CHARGER,WASTEGATE	X	X			
10	DC100296	4	NUT,TURBO TO MANIFOLD	X	X			
20	DC221905	1	SHEILD,HEAT,FLANGED ELBOW	X	X			
30	DC100385	4	SCREW,HEAT SHEILD	X	X			
50	DC221582	1	HOSE,MOLDED	X	X			
55	DC100381	1	CLAMP,MOLDED HOSE TO TURBO	X	X			
60	203588	1	CLAMP,HOSE TO BREATHER PIPE	X	X			
60	203588	1	CLAMP,HOSE COMP SUCTION PIPE	X	X			
65	DC130202	1	PIPE,AIR ON TURBO CHARGER	X	X			
94	DC140191	1	RING,SEAL,AIR PIPE	X	X			
100	DC130203	1	PIPE,CHARGE-AIR	X	X			
152	DC100319	1	CLAMP,CHARGE-AIR PIPE TO TURBO	X	X			
160	DC100390	1	SCREW,CHARGE-AIR PIPE ON MEMBER	X	X			
170	DC100695	1	STUD,CHARGE-AIR PIPE AT WATER PUMP	X	X			
175	DC100604	1	NUT,CHARGE-AIR PIPE AT WATER PUMP	X	X			
200	DC221906	1	BRACKET,AIR PIPE AT WATER PUMP	X	X			
251	DC100390	1	SCREW,BRACKET TO CHARGE-AIR PIPE	X	X			
280	DC100597	2	SCREW,BRACKET TO WATER PUMP	X	X			
330	206353	1	CLAMP,CHARGE-AIR PIPE ON HOUSING	X	X			
335	DC140192	1	RING,SEAL,CHARGE-AIR PIPE	X	X			
340	DC100366	1	SCREW,CHARGE-AIR PIPE TO HOUSING	X	X			
345	DC100383	1	NUT,CHARGE-AIR PIPE TO HOUSING	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222156	1	COMPRESSOR,WABCO 352CCM	X	X			
55	DC100696	1	NUT,GEAR TO COMPRESSOR	X	X			
110	DC100743	4	SCREW,COMPRESSOR TO CRANKCASE	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC130212	1	PIPE, SUCTION	X	X			
20	DC130162	1	PIPE, SUCTION	X	X			
60	DC100385	1	SCREW, INTAKE PIPE TO CRANKCASE	X	X			
66	DC130213	1	HOSE, SUCTION LINE TO COMPRESSOR	X	X			
75	203588	2	CLAMP, SUCTION PIPE TO COMPRESSOR	X	X			
180	DC130205	1	PIPE, AT CYLINDER HEAD	X	X			
184	DC130235	1	PIPE, AT WATER PUMP	X	X			
190	DC120182	2	BOLT, BANJO	X	X			
195	DC140149	4	RING, SEAL	X	X			
240	DC220481	1	CAP, POWER STEERING PUMP	X	X			
245	DC220314	1	GASKET	X	X			
250	DC100597	2	SCREW, FLANGED, COVER TO COMP	X	X			

https://truckmanualshub.com/




TD0003457

https://truckmanualshub.com/

ENGINE, INTAKE MANIFOLD - OM906LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
25	DC221915	1	HOUSING,CHARGING AIR ELBOW	X	X			
50	DC222085	1	UNIT,SENDER C/AIR PRES/TEMP,4 BAR	X	X			
52	DC140199	1	RING,SENDER	X	X			
65	DC100744	2	SCREW,FLANGED	X	X			
75	DC100685	2	SCREW,C/AIR ELBOW TO CYL HEAD	X	X			
78	DC100745	10	SCREW,C/AIR ELBOW TO CYL HEAD	X	X			
85	DC222060	6	GASKET,C/AIR ELBOW TO CYL HEAD	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
12	DC222116	1	MANIFOLD,EXHAUST,MIDDLE PIECE	X	X			
14	DC222115	2	MANIFOLD,EXHAUST,END PIECE	X	X			
20	DC100316	2	STUD	X	X			
25	DC221918	3	GASKET,MANIFOLD TO CYLINDER HEAD	X	X			
30	DC100698	12	SCREW,MANIFOLD TO CYLINDER HEAD	X	X			
32	DC222117	4	RING,SEAL,3 PIECE EXHAUST	X	X			
95	DC260112	1	KIT,EXHAUST BRAKE	X	X			
100	DC220960	1	LEVER	X	X			
105	DC220981	1	PIVOT,BALL	X	X			
110	DC100378	1	SCREW,LEVER TO SHAFT	X	X			
115	DC100699	1	NUT,LEVER TO THROTTLE VALVE	X	X			
120	DC260113	1	KIT,EXHAUST BRAKE VALVE	X	X			
125	DC100296	4	NUT,FLANGED,EXH/BRAKE TO TURBO	X	X			
140	DC221919	1	BRACKET	X	X			
145	DC100385	2	SCREW,BRACKET TO FLANGED ELBOW	X	X			
160	DC221920	1	CYLINDER,EXHAUST BRAKE	X	X			
180	DC100112	1	SCREW,CYLINDER TO BRACKET	X	X			
185	DC221921	1	TUBE,PACER,CYLINDER TO BRACKET	X	X			
205	DC220980	1	SOCKET,BALL,CYLINDER TO LEVER	X	X			
210	DC100359	1	NUT,CYLINDER TO LEVER	X	X			
215	DC220836	1	CLIP,SECURING	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221922	1	UNIT,CONTROL,TIER 2	X	X			
11	DC100366	3	SCREW,FLANGED,CONTROL UNIT	X	X			
17	DC221771	6	RING,RUBBER	X	X			
41	DC222147	1	CABLE,ELECTRIC-ENGINE	X	X			
53	DC120249	1	PLUG SOCKET,ENGINE START	X	X			
53	DC120249	1	PLUG SOCKET,ENGINE STOP	X	X			
53	DC120249	1	PLUG SOCKET,OIL LEVEL SENSOR	X	X			
70	DC120247	1	PLUG,COOLING WATER TEMP	X	X			
70	DC120247	1	PLUG,FUEL TEMP SENDER UNIT	X	X			
70	DC120247	1	PLUG,CAMSHAFT POSITION UNIT	X	X			
70	DC120247	1	PLUG,CRANKSHAFT POSITION UNIT	X	X			
70	DC120247	1	PLUG,OIL TEMP SENSOR	X	X			
85	DC120255	1	COUPLING,THROTTLE VALVE	X	X			
100	DC120248	1	PLUG,OIL PRESSURE SENDER UNIT	X	X			
130	DC120250	1	PLUG,BOOST AIR SENSOR	X	X			
205	DC120222	1	HOUSING,PIN,CONTROL MODULE	X	X			
220	DC120244	1	CAP,CONTROL MODULE	X	X			
235	DC120243	A/R	TERMINAL,PIN,CONTROL MODULE	X	X			
250	DC222098	A/R	GASKET,CONTROL MODULE	X	X			
265	DC120245	A/R	PLUG,ENGINE CONTROL	X	X			
280	DC120246	12	SHOE,CABLE UNIT	X	X			
382	DC221924	2	SWITCH,ENGINE START/STOP	X	X			
388	DC100700	2	NUT,ENGINE START/STOP	X	X			
406	101354	4	SCREW,CAP,BRACKET TO CRANKCASE	X	X			
412	DC221734	1	SENDER,SPEED AT CRANKCASE	X	X			
412	DC221734	1	SENDER,SPEED AT TIMING CASE	X	X			
418	DC150196	1	BUSHING,T.D.C. SENSER TO CRANKCASE	X	X			
418	DC150196	1	BUSHING,CRANKCASE POSITION UNIT	X	X			
424	DC140178	1	O-RING,T.D.C. SENDER TO CRANKCASE	X	X			
478	200871	A/R	CABLE TIE	X	X			
514	DC221726	1	ELECTRONICS,KSA	X	X			
520	DC221727	1	HOUSING,SOCKET FLAME START SYSTEM	X	X			
526	DC120221	2	PIN,SOCKET HOUSING FLAME START	X	X			
532	DC221728	2	GASKET,FLAME START SYSTEM	X	X			
538	DC221729	1	BOOT,FLAME START SYSTEM	X	X			
544	DC120218	1	HOUSING,PLUG FLAME START SYSTEM	X	X			
550	DC100664	1	NUT,FLAME START SYSTEM	X	X			
556	DC221730	2	GASKET,FLAME START	X	X			
562	DC221928	2	PIN,SOCKET HOUSING FLAME START	X	X			
568	DC221731	1	BOOT,FLAME START SYSTEM	X	X			
574	DC120220	1	PIN,BUSHING,HEATER PLUG TO GROUND	X	X			
580	DC100383	1	NUT,HEATER PLUG TO GROUND	X	X			
600	DC222101	1	CABLE,CONTROL UNIT TO SHIFT PANEL	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222162	1	UNIT,CONTROL,TIER 3	X	X			
11	DC100366	3	SCREW,FLANGED,CONTROL UNIT	X	X			
17	DC221771	6	RING,RUBBER	X	X			
41	DC222147	1	CABLE,ELECTRIC-ENGINE	X	X			
53	DC120249	1	PLUG SOCKET,ENGINE START	X	X			
53	DC120249	1	PLUG SOCKET,ENGINE STOP	X	X			
53	DC120249	1	PLUG SOCKET,OIL LEVEL SENSOR	X	X			
70	DC120247	1	PLUG,COOLING WATER TEMP	X	X			
70	DC120247	1	PLUG,FUEL TEMP SENDER UNIT	X	X			
70	DC120247	1	PLUG,CAMSHAFT POSITION UNIT	X	X			
70	DC120247	1	PLUG,CRANKSHAFT POSITION UNIT	X	X			
70	DC120247	1	PLUG,OIL TEMP SENSOR	X	X			
85	DC120255	1	COUPLING,THROTTLE VALVE	X	X			
100	DC120248	1	PLUG,OIL PRESSURE SENDER UNIT	X	X			
130	DC120250	1	PLUG,BOOST AIR SENSOR	X	X			
205	DC120222	1	HOUSING,PIN,CONTROL MODULE	X	X			
220	DC120244	1	CAP,CONTROL MODULE	X	X			
235	DC120243	A/R	TERMINAL,PIN,CONTROL MODULE	X	X			
250	DC222098	A/R	GASKET,CONTROL MODULE	X	X			
265	DC120245	A/R	PLUG,ENGINE CONTROL	X	X			
280	DC120246	12	SHOE,CABLE UNIT	X	X			
382	DC221924	2	SWITCH,ENGINE START/STOP	X	X			
388	DC100700	2	NUT,ENGINE START/STOP	X	X			
406	101354	4	SCREW,CAP,BRACKET TO CRANKCASE	X	X			
412	DC221734	1	SENDER,SPEED AT CRANKCASE	X	X			
412	DC221734	1	SENDER,SPEED AT TIMING CASE	X	X			
418	DC150196	1	BUSHING,T.D.C. SENSER TO CRANKCASE	X	X			
418	DC150196	1	BUSHING,CRANKCASE POSITION UNIT	X	X			
424	DC140178	1	O-RING,T.D.C. SENDER TO CRANKCASE	X	X			
478	200871	A/R	CABLE TIE	X	X			
514	DC221726	1	ELECTRONICS,KSA	X	X			
520	DC221727	1	HOUSING,SOCKET FLAME START SYSTEM	X	X			
526	DC120221	2	PIN,SOCKET HOUSING FLAME START	X	X			
532	DC221728	2	GASKET,FLAME START SYSTEM	X	X			
538	DC221729	1	BOOT,FLAME START SYSTEM	X	X			
544	DC120218	1	HOUSING,PLUG FLAME START SYSTEM	X	X			
550	DC100664	1	NUT,FLAME START SYSTEM	X	X			
556	DC221730	2	GASKET,FLAME START	X	X			
562	DC221928	2	PIN,SOCKET HOUSING FLAME START	X	X			
568	DC221731	1	BOOT,FLAME START SYSTEM	X	X			
574	DC120220	1	PIN,BUSHING,HEATER PLUG TO GROUND	X	X			
580	DC100383	1	NUT,HEATER PLUG TO GROUND	X	X			
600	DC222101	1	CABLE,CONTROL UNIT TO SHIFT PANEL	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ENGINE, STARTING MOTOR - OM906LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221926	1	MOTOR,STARTER 24V/4KW,BOSCH	X	X			
10	DC221555	1	BENDIX	X	X			
15	DC150126	1	BUSHING,DRIVE END	X	X			
20	DC221930	1	HOUSING,FRONT	X	X			
25	DC150156	1	BUSHING,BENDIX	X	X			
30	DC221931	1	SWITCH,SOLENOID	X	X			
35	DC221932	1	LEVER,CONTROL	X	X			
45	DC150158	1	BUSHING,COMMUTATOR END	X	X			
80	DC221934	1	SWITCH,SOLENOID	X	X			
95	DC260114	1	KIT,GEARING	X	X			
100	DC260115	1	KIT,GEARING	X	X			
105	DC260116	1	KIT,ARMATURE	X	X			
110	DC100538	3	SCREW,STARTER TO TIMING CASE	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222227	1	ALTERNATOR, W/O PULLEY 28V/80AMP	X	X			SEE SIB 2006/1082
20	DC100715	4	SCREW, ALTERNATOR	X	X			
50	DC150157	1	BEARING, BALL DRIVE END	X	X			
60	DC150168	1	BEARING, BALL SLIP RING SIDE	X	X			
110	DC222017	1	RECTIFIER, ALTERNATOR	X	X			
130	DC222018	1	CONDENSOR, ALTERNATOR	X	X			
170	DC222021	1	REGULATOR AND CUT-OUT	X	X			
190	DC100346	2	SCREW	X	X			
215	DC260152	1	KIT, REPAIR SCREWS	X	X			
220	DC260073	1	KIT, TERMINAL PARTS	X	X			
259	DC220508	1	FAN, ALTERNATOR PULLEY	X	X			
278	DC222022	1	PULLEY, ALTERNATOR	X	X			
280	DC100764	1	WASHER, ALTERNATOR	X	X			
300	DC221967	1	SUPPORT, ALTERNATOR	X	X			
301	DC100755	1	PIN, SPRING	X	X			
302	DC100708	4	SCREW, BRACKET TO CRANKCASE	X	X			
303	DC100662	1	SCREW, ALTERNATOR TO SUPPORT	X	X			
304	DC100604	1	NUT, ALTERNATOR TO SUPPORT	X	X			
305	DC221968	1	BRACKET	X	X			
306	DC100597	1	SCREW, BRACKET TO OIL FILTER	X	X			
307	100478	1	SCREW, ALTERNATOR TO BRACKET	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221937	1	PUMP,OIL	X	X			
10	DC140194	1	SEAL,OIL FRONT CRANKSHAFT	X	X			
20	DC100413	8	SCREW,OIL PUMP TO CRANKCASE	X	X			
25	DC130207	1	PIPE,SUCTION	X	X			
40	DC221936	1	BRACKET	X	X			
45	DC100621	1	SCREW,PIPE TO DIPSTICK GUIDE TUBE	X	X			
50	100197	8	SCREW,SUCTION PIPE TO OIL PUMP	X	X			
55	DC100597	1	SCREW,SUCTION PIPE TO CRANKCASE	X	X			
55	DC100621	1	SCREW,SUPPORT ON OIL INTAKE PIPE	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222148	1	FILTER,OIL COMPLETE UNIT	X	X			
15	DC221939	1	COVER,OIL FILTER	X	X			
25	DC221578	1	ELEMENT,OIL FILTER	X	X			
30	DC221940	1	NECK,FILTER	X	X			
35	DC140195	1	RING,SEAL	X	X			
46	DC140182	1	RING,SEAL TO PLUG SENDER UNIT PORT	X	X			
50	DC221942	1	GASKET,OIL FILTER TO CRANKCASE	X	X			
70	DC221943	1	VALVE,PRESSURE RELIEF	X	X			
75	DC100366	4	SCREW,OIL FILTER TO CRANKCASE	X	X			
75	DC100671	1	SCREW,OIL FILTER TO CRANKCASE	X	X			
105	DC221944	1	ELEMENT,OIL COOLER	X	X			
110	DC221945	1	COVER,OIL COOLER	X	X			
115	DC221946	1	GASKET,OIL COOLER TO COVER	X	X			
120	DC100385	2	SCREW,OIL COOLER TO COVER	X	X			
125	DC221947	1	GASKET,OIL COOLER TO CRANKCASE	X	X			
130	DC100112	12	SCREW,OIL COOLER TO CRANKCASE	X	X			
132	DC221743	1	SENDER,OIL TEMPERATURE	X	X			
133	DC140149	1	RING,SEAL	X	X			
135	DC221171	A/R	PLUG,SCREW	X	X			
140	DC140059	A/R	WASHER,SEALING	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
8	DC130208	1	PIPE,OIL FEED	X	X			
35	DC130231	1	PIPE,OIL RETURN	X	X			
55	DC120182	1	BOLT,BANJO FEED PIPE TO OIL FILTER HD	X	X			
70	DC140149	2	RING,SEAL FEED PIPE TO OIL FILTER HD	X	X			
90	DC221746	1	GASKET,RETURN PIPE TO TURBO	X	X			
105	DC100414	2	SCREW,RETURN PIPE TO TURBO	X	X			
115	DC130210	1	PIPE,PLASTIC,RETURN TO CRANKCASE	X	X			
125	DC100326	2	CLAMP,RETURN PIPE TO CRANKCASE	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
8	DC221949	1	PUMP,WATER WITH GASKETS	X	X			
15	267546	1	KIT,GASKET WATER PUMP	X	X			
20	DC221948	1	GASKET,WATER PUMP TO CRANKCASE	X	X			
24	DC100198	3	SCREW,WATER PUMP TO CRANKCASE	X	X			
28	DC100702	4	SCREW,WATER PUMP TO CRANKCASE	X	X			
42	DC221743	1	SENDER,TEMPERATURE	X	X			
45	DC140149	1	RING,SEAL SENDER UNIT TO FLANGE	X	X			
57	DC222145	1	CONNECTOR,RETARDER	X	X			
100	DC221950	1	GASKET,PIPE SOCKET TO CYL/HEAD	X	X			
106	DC100408	1	SCREW,PIPE SOCKET TO CYL/HEAD	X	X			
112	DC120238	1	SOCKET,PIPE TO WATER PUMP	X	X			
200	DC221577	2	THERMOSTAT,83 DEGREE	X	X			
205	DC140110	2	RING,SEAL	X	X			
224	DC222008	1	COVER,TWIN THERMOSTAT HOUSING	X	X			
230	DC100366	2	SCREW,FLANGED,40MM LG	X	X			
232	DC100657	1	SCREW,FLANGED,70MM LG	X	X			
235	DC220800	1	SENDER,UNIT COOLING WATER OUTLET	X	X			
245	DC120239	1	UNION,BANJO	X	X			
265	DC120240	1	FITTING,HEAT FEED	X	X			
270	DC140182	2	RING,SEAL TO FITTING	X	X			
275	DC221952	1	CAP,RUBBER TO PLUG PIPE SOCKET	X	X			
280	203588	1	CLAMP,RUBBER CAP 20-32MM	X	X			
285	DC221953	1	PULLEY	X	X			
310	DC100507	4	SCREW,FAN PULLEY TO WATER PUMP	X	X			
315	DC222166	1	BELT-V,1939MM	X	X			
315	DC222204	1	BELT-V,1369MM,W/O AIR CON	X	X			FOR EMERGENCY ONLY
320	DC222167	1	PULLEY,GUIDE FUEL FEED PUMP	X	X			
345	DC222168	1	TIGHTENER,BELT	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221391	1	FAN	X	X			
15	DC221390	1	HUB,VISCOUS	X	X			
20	DC100359	4	NUT,FAN CLUTCH AT ADAPTOR PIECE	X	X			
35	DC222225	1	SPACER,FAN	X	X			
40	DC100703	4	STUD	X	X			
55	DC100704	6	SCREW,SPACER TO VIBRATION DAMPER	X	X			

https://truckmanualshub.com/




TD0003478A

https://truckmanualshub.com/

ITEM	PART No	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
75	DC221958	1	EYE,LIFTING REAR	X	X			
85	DC100597	4	SCREW,LIFTING EYE TO CYLINDER HEAD	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
8	DC221758	1	COMPRESSOR,LESS COUPLING	X	X			
10	DC260118	1	KIT,COUPLING	X	X			
15	DC260098	1	KIT,GASKET	X	X			
20	DC221959	1	CONSOLE	X	X			
25	DC221960	2	SLEEVE	X	X			
30	DC221961	2	SLEEVE	X	X			
80	DC100707	4	SCREW,COMPRESSOR TO SUPPORT	X	X			
85	DC100352	4	SCREW,SUPPORT TO CRANKCASE	X	X			

https://truckmanualshub.com/



TD0003835 - B
E14832403 - D


https://truckmanualshub.com/

EXHAUST SYSTEM - OM906LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218292	1	SHIELD,HEAT,EXH,FRONT	X	X			
2	217754	1	EXHAUST,MID SECTION	X	X			
3	217752	1	EXHAUST,FRONT SECTION	X	X			
4	216350	1	EXHAUST,STACK,POLISHED SS	X	X			
5	216042	1	EXHAUST,MUFFLER	X	X			
6	207496	1	CLAMP,EXHAUST	X	X			
7	216755	1	EXHAUST,H/SHIELD COVER	X	X		From VIN. 3327	REFER SIB 2006/1062
8	216754	1	EXHAUST,H/SHIELD FIXED	X	X		From VIN. 3327	REFER SIB 2006/1062
9	206636	1	EXHAUST,H/SHIELD MID	X	X			
10	204035	3	CLAMP,SEALCLAMP	X	X			
11	201212	4	CLAMP,EXHAUST,100MM	X	X			
12	191074	1	HEATSHIELD,TURBO	X	X		From VIN. 3234	REFER SIB 2006/1049
13	174447	1	MTG,EXHAUST H/SHIELD FRNT	X	X			
14	100652	1	NUT,STOVER	X	X			
15	100548	6	WASHER,HARDENED	X	X			
16	100424	11	WASHER,HARDENED	X	X			
17	100370	10	WASHER,HARDENED	X	X			
18	100211	11	SCREW,HEXHD	X	X			
19	100199	1	BOLT,HEXHD	X	X			
20	100091	10	SCREW,HEXHD	X	X			
21	100083	4	SCREW,HEXHD	X	X			

https://truckmanualshub.com/

KIT, BIN HEATING (OPTIONAL) - OM906LA




https://truckmanualshub.com/

KIT, BIN HEATING (OPTIONAL) - OM906LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	260401	1	KIT,BIN HEATING	X	X			
1	262900	1	ASSY,B/HEAT,HOSE GUARD	X	X			
2	216913	1	ASSY,MID SECTION,B/H	X	X			
3	216354	1	EXHAUST,STACK,BIN HEAT,SS	X	X			
4	207374	1	MTG,PLT,LOWER B/HEATING	X	X			
5	207373	1	MTG,BKT,B/HEATING	X	X			
6	206305	1	ASSY,FLEX SWIVEL B/H	X	X			
7	206303	2	ASSY,MID SECT,B/HEATING	X	X			
8	206301	1	ASSY,TOP SECT,B/HEATING	X	X			
9	204035	3	CLAMP,SEALCLAMP	X	X			
10	201667	3	SPRING,BIN HEAT,SUSP,PLT	X	X			
11	201666	6	SPRING,BIN HEAT,BALL,JOINT	X	X			
12	201212	3	CLAMP,EXHAUST	X	X			
13	176250	3	WASHER,PROFILED	X	X			
14	174760	2	FLANGE,BIN HEATING BALL	X	X			
15	174674	1	BKT,BIN HEATING,HYD MTG	X	X			
16	162456	12	WASHER,SPRING RET,BIN HEAT	X	X			
17	162060	3	PIN,BIN HEAT,SPRING GUIDE	X	X			
18	140622	4	SEAL,RING	X	X			
19	100747	6	BOLT,HEXHD	X	X			
20	100655	7	NUT,STOVER	X	X			
21	100652	6	NUT,STOVER	X	X			
22	100569	3	SCREW,HEXHD	X	X			
23	100548	9	WASHER,HARDENED	X	X			
24	100424	17	WASHER,HARDENED	X	X			
25	100312	3	NUT,NYLOC	X	X			
26	100212	7	SCREW,HEXHD	X	X			
27	100210	7	SCREW,HEXHD	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
2	290131	1	AIR CLEANER,FRG15,RADIAL SEAL	X	X			REFERENCE PAGE 2-72; 2-73
3	217684	2	MTG,BAND,2PC,AIR CLEANER,FRG 15	X	X			
4	208828	2	CLAMP,T-BOLT	X	X			
5	206489	1	PIPE,AIR INTAKE	X	X			
6	204668	1	CLAMP,STACK-AIR INTAKE PIPE	X	X			
7	201819	1	REDUCER,STACK	X	X			
8	200641	1	ELBOW,90 DEG 6" EQUAL RUBBER	X	X			
9	200466	1	INFORMER	X	X			
10	200051	1	CLAMP,HOSE	X	X			
11	100370	8	WASHER,HARDENED	X	X			
12	100314	4	NUT,NYLOC	X	X			
13	100089	4	SCREW,HEXHD	X	X			
14	100083	2	SCREW,HEXHD	X	X			
15	100062	2	WASHER,FLAT	X	X			
16	290230	1	PRE-CLEANER (ADT 240)	X	X			
17	202860	1	BOWL,PRE-CLEANER	X	X			
18	220535	1	COVER,PRE CLEANER	X	X			
19	NSI	1	BODY,PRE CLEANER	X	X			
20	NSI	1	NUT,WING	X	X			

https://truckmanualshub.com/

1




P008531

https://truckmanualshub.com/

AIR CLEANER - OM906LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	290131	1	AIR CLEANER,FRG15,RADIAL SEAL	X	X			REFERENCE PAGE 2-70; 2-71
2	220722	1	COVER,FRG15 AIR CLEANER	X	X			
3	220723	6	LATCH,FRG15 AIR CLEANER	X	X			
4	220725	1	ELEMENT,OUTER,FRG15 A/CLEANER	X	X			
5	220747	1	ELEMENT,INNER,FRG15 A/CLEANER	X	X			
6	220724	1	VACUATOR,VALVE,FRG15 A/CLEANER	X	X			
7	NSI	1	BODY,AIR CLEANER	X	X			
8	200871	2	CABLE TIE	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	DC220461	1	PUMP,HANDLIFT& PREFILTER LATES	X	X			REFERENCE PAGE 2-78; 2-79
2	241225	1	HOSE	X	X			
3	241224	1	HOSE	X	X			
4	241218	1	HOSE	X	X			
5	240980	1	HOSE	X	X			
6	207693	1	ASSY,FUEL FILTER	X	X			REFERENCE PAGE 2-76; 2-77
7	206945	6	MTG,RUBBER	X	X			
9	121451	2	ADAPTOR	X	X			
10	121365	1	ADAPTOR	X	X			
11	120969	2	CONNECTOR	X	X			
12	120804	2	ELBOW	X	X			
13	120781	2	ADAPTOR	X	X			
14	120670	1	CONNECT	X	X			
15	100731	4	SCREW,HEXHD	X	X			
16	100548	12	WASHER,HARDENED	X	X			
17	100312	6	NUT,NYLOC	X	X			
18	100198	2	SCREW,HEXHD	X	X			
19	100080	1	SCREW,HEXHD	X	X			
20	100061	1	WASHER,FLAT	X	X			
26	203764	2	P-CLIP,25MM	X	X			

https://truckmanualshub.com/

FUEL-WATER FILTER UNIT - OM906LA




https://truckmanualshub.com/

FUEL-WATER FILTER UNIT - OM906LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	207693	1	FILTER,UNIT,FUEL-WATER	X	X			REFERENCE PAGE 2-74; 2-75
2	207694	1	ELEMENT,FILTER	X	X			
3	224670	1	BOWL,SEE-THRU	X	X			
4	224667	1	VALVE,DRAIN SELF VENTING	X	X			
5	218508	1	CLAMP,FUEL FILTER	X	X			
6	226385	1	KIT,LID & GASKET	X	X			
7	226386	1	KIT,T-HANDLE & O-RING	X	X			
8	221597	1	KIT,SEAL,SERVICE	X	X			

https://truckmanualshub.com/

1



TD0004783


https://truckmanualshub.com/

HANDLIFT PUMP & PRE-FILTER - OM906LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	DC220461	1	HANDLIFT PUMP & PRE-FILTER	X	X			REFERENCE PAGE 2-74; 2-75
2	DC260058	1	KIT,PRE-FILTER ELEMENT	X	X			
3	DC140123	1	RING,SEAL	X	X			
4	DC221232	1	BOWL,FILTER	X	X			

https://truckmanualshub.com/

ENGINE COOLING SYSTEM: DETAIL A - OM906LA




TD0003122 E
E14832405-J SH1-2

https://truckmanualshub.com/

ENGINE COOLING SYSTEM: DETAIL A - OM906LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	AT310335	1	FILLER CAP	X	X			
2	218686	1	HOSE,RADIATOR	X	X			2810 MM LONG
3	218686	1	HOSE,RADIATOR	X	X			1660 MM LONG
4	217971	1	HOSE,INLET	X	X			
5	217970	1	HOSE,BOTTOM	X	X			
6	217969	1	HOSE,TOP	X	X			
12	216484	1	CLAMP,HOSE	X	X			
14	216097	1	TANK,SURGE	X	X			
17	216016	1	PIPE,MAKE-UP	X	X			
18	216015	1	HOSE,MAKE-UP	X	X			
19	216014	1	HOSE,SURGE TNK OUTLET	X	X			
20	216011	1	PIPE,SUCTION	X	X			
24	208821	6	CLAMP,T-BOLT	X	X			
26	203926	2	GROMMET	X	X			
27	203764	6	P-CLIP,25MM	X	X			
28	203681	1	P-CLIP,50MM	X	X			
30	201439	4	P-CLIP,18MM	X	X			
31	200092	4	CLAMP,HOSE	X	X			
32	200061	4	CLAMP,HOSE	X	X			
33	200033	4	CLAMP,HOSE	X	X			
34	187425	1	BKT,VENT PIPES	X	X			
35	187315	1	BKT,PIPE,MAKE-UP	X	X			
36	176353	1	MTG,HOSE,TEFLON	X	X			
38	130002	1	HOSE,PUSHLOCK	X	X			1610 MM LONG
39	130002	1	HOSE,PUSHLOCK	X	X			1330 MM LONG
40	130002	1	HOSE,PUSHLOCK	X	X			1140 MM LONG
43	120051	1	ADAPTOR,MALE	X	X			
46	100731	8	SCREW,HEXHD	X	X			
47	100548	16	WASHER,HARDENED	X	X			
49	100370	12	WASHER,HARDENED	X	X			
50	100364	2	SCREW,HEXHD	X	X			
51	100314	2	NUT,LOCK	X	X			
52	100312	8	NUT,NYLOC	X	X			
53	100310	6	NUT,NYLOC	X	X			
55	100081	5	SCREW,HEXHD	X	X			
56	100080	2	SCREW,HEXHD	X	X			
57	100061	13	WASHER,FLAT	X	X			

https://truckmanualshub.com/




TD0003123 E
E14832405-J SH2-2

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
7	217965	1	HOSE,STRAIGHT,CAC	X	X			
8	217964	1	HOSE,BOTTOM,CAC	X	X			
9	217963	1	HOSE,TOP,CAC	X	X			
10	217962	1	PIPE,BOTTOM,CAC	X	X			
11	217956	1	COOLING PACKAGE	X	X			
13	216128	3	CLAMP,T-BOLT	X	X			
15	216045	1	COWLING,RAD	X	X			
16	216035	1	CLAMP,RETAINER	X	X			
21	214159	1	GUARD,FAN,RHS	X	X			
22	214158	1	GUARD,FAN,LHS	X	X			
23	208824	3	CLAMP,T-BOLT	X	X			
25	206523	2	MTG,RUBBER	X	X			
29	203538	1	CLAMP,T-BOLT	X	X			
37	173733	2	PLT,SPACER	X	X			
41	121312	1	TAP,COOLANT DRAIN	X	X			
42	121224	2	PLUG,HOLLOW HEX	X	X			
44	101345	6	WASHER,HARDENED	X	X			
45	100733	8	SCREW,HEXHD	X	X			
46	100731	8	SCREW,HEXHD	X	X			
47	100548	16	WASHER,HARDENED	X	X			
48	100494	2	SCREW,HEXHD	X	X			
49	100370	12	WASHER,HARDENED	X	X			
52	100312	8	NUT,NYLOC	X	X			
54	100083	4	SCREW,HEXHD	X	X			
57	100061	13	WASHER,FLAT	X	X			

https://truckmanualshub.com/



TD0003608
217956 SH 2-2 A

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	217960	1	TM OIL COOLER	X	X			
2	217959	1	CAC,300D,TIER,MK3	X	X			
3	217958	1	RADIATOR	X	X			
4	216059	1	BRACE,COOLING PACKAGE	X	X			
5	216049	1	FRAME,COOLING PACKAGE,BOT	X	X			
6	216048	1	FRAME,COOLING PACKAGE,TOP	X	X			
7	216047	1	FRAME,COOLING PACKAGE,RIGHT	X	X			
8	216046	1	FRAME,COOLING PACKAGE,LEFT	X	X			
9	100657	8	NUT,STOVER	X	X			
10	100370	40	WASHER,HARDENED	X	X			
11	100178	2	SCREW,HEXHD	X	X			
12	100086	20	SCREW,HEXHD	X	X			
13	100085	10	SCREW,HEXHD	X	X			

https://truckmanualshub.com/


https://truckmanualshub.com/

SECTION 2B: ENGINE - OM926LA

https://truckmanualshub.com/

ENGINE, MISCELLANEOUS ITEMS - OM926LA

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE



TD0005166
E16832407


https://truckmanualshub.com/

ENGINE, MISCELLANEOUS ITEMS - OM926LA

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	255001	1	RING,CLAMPING,OM906LA	X				
2	251113	1	ENGINE,DC OM926LA	X				REFER TO SIB 2010/1027
3	217857	1	NONSLIP,SUMP	X				
4	207967	1	BOOT,RUBBER	X				
5	207646	2	MTG,RUBBER	X				
6	183140	2	MTG,ENGINE	X				
7	176592	4	SPACER,ENG MTG	X				
8	175112	1	PLT,COVER	X				
9	122136	1	VALVE,DRAIN	X				
10	121090	1	CONNECT	X				
11	101324	2	BOLT,HEXHD	X				
12	100827	8	SCREW,HEXHD	X				
13	100653	2	NUT,STOVER	X				
14	100643	8	SCREW,HEXHD	X				
15	100548	2	WASHER,HARDENED	X				
16	100536	8	WASHER	X				
17	100532	4	WASHER,HARDENED	X				
18	100370	12	WASHER,HARDENED	X				
19	100238	2	SCREW,HEXHD	X				
20	100090	12	SCREW,HEXHD	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ENGINE, CRANKCASE - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222234	1	CRANKCASE, OM926LA	X				
11	DC221799	2	SLEEVE, FLYWHEEL	X				
17	DC220737	3	BALL, REAR, OIL BORE	X				
23	DC100059	1	PIN, DOWEL, BEARING CAP	X				
29	DC100739	14	SCREW, BEARING CAP	X				
35	DC150174	6	BUSHING, CAMSHAFT BEARINGS	X				
41	DC150175	1	BUSHING, CAMSHAFT BEARINGS	X				
47	DC220543	6	PLUG, WELCH, 34MM	X				
47	DC220549	A/R	PLUG, WELCH, 36.2MM	X				
53	DC120195	10	PLUG, EXPANSION 40MM	X				
53	DC120196	A/R	PLUG, EXPANSION 42MM	X				
56	DC221800	1	THROTTLE, TRANSVERSE FUEL DUCT	X				
59	DC221801	6	NOZZLE, OIL	X				
65	DC220735	2	BALL, OIL PASSAGE FRONT / REAR	X				
65	DC221802	2	BALL, FUEL FEED LOCK	X				
65	DC221803	2	BALL, FUEL RETURN LOCK	X				
65	DC220737	1	BALL, LOCK TRANSVERSE FUEL DUCT	X				
65	DC220737	5	BALL, LOCK OIL SUPPLY UNIT PUMP	X				
71	DC221804	1	INTERMEDIATE PIECE, OIL PUMP	X				
77	DC221805	2	SLEEVE, OIL PUMP	X				
83	DC221806	1	INTERMEDIATE PIECE, TURBO, OIL	X				
89	DC221807	1	SLEEVE, PULSE SENDER	X				
95	DC120226	1	PLUG, EXPANSION	X				
107	DC140181	1	RING, SEAL, INTERMEDIATE FLANGE	X				
113	DC120116	1	PLUG, SCREW, CYL/HEAD	X				
119	DC140150	1	RING, SEAL, CYL/HEAD	X				
125	DC120158	1	PLUG, SCREW, OIL PASSAGE REAR	X				
131	DC140182	1	RING, SEAL, OIL PASSAGE REAR	X				
137	DC100173	1	PLUG, SCREW, MAIN OIL PASSAGE	X				
143	DC140172	1	RING, SEAL, MAIN OIL PASSAGE	X				
149	DC120227	1	PLUG, SCREW, WATER DRAIN	X				
155	DC221809	2	SLEEVE, CYL/HEAD	X				
161	DC120170	1	PLUG,SCREW , OIL PASSAGE OIL PUMP	X				
167	DC120114	1	PLUG, SCREW, MAIN OIL PASSAGE	X				
173	DC140149	1	RING, SEAL, MAIN OIL PASSAGE	X				
224	DC221810	1	VALVE, OVERFLOW, RELIEF 4.5 - 5 BAR	X				
230	DC140172	1	RING, SEAL, CYL/BLOCK	X				
242	DC221743	1	SENDER, FUEL TEMPERATURE	X				
244	DC221742	1	SENDER, OIL PRESSURE	X				
248	DC140149	1	RING, SEAL, SENDER UNIT, FUEL TEMP	X				
250	DC140172	1	RING, SEAL, SENDER UNIT, OIL PRESSURE	X				
266	DC221812	1	VALVE, SOLENOID	X				
278	DC221813	1	VALVE	X				
290	DC221814	1	GASKET	X				
296	DC100671	2	SCREW, FLANGED	X				
314	DC260106	1	KIT, GASKET CYLINDER CRANKCASE	X				

https://truckmanualshub.com/




TD0004824

https://truckmanualshub.com/

ENGINE, TIMING COVER - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
15	DC222149	1	COVER, TIMING	X				
20	DC140197	1	SEAL, OIL CRANKSHAFT REAR	X				
25	DC221254	1	COVER, CAP FOR CRANK MECHANISM	X				
27	DC221977	1	GASKET, COVER	X				
29	DC100507	2	SCREW	X				
40	DC100177	1	PLUG, SCREW	X				
45	DC140151	1	RING, SEAL	X				
50	DC120104	1	PLUG, SCREW	X				
55	DC140155	1	RING, SEAL	X				
95	DC100673	9	SCREW, FLANGED, TIMING CASE, 60MM	X				
95	DC100674	5	SCREW, FLANGED, TIMING CASE, 80MM	X				
95	DC100742	3	SCREW, FLANGED, TIMING CASE, 160MM	X				
97	DC100597	1	SCREW, FLANGED, TIMING CASE, 25MM	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ENGINE, OIL PAN AND DIPSTICK - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221526	1	PAN,OIL	X				
17	DC221818	1	GASKET,OIL PAN	X				
20	DC120029	1	PLUG,SCREW,OIL DRAIN	X				
25	DC140155	1	RING,SEAL,OIL DRAIN	X				
80	DC221819	1	SENDER,OIL LEVEL	X				
85	DC120200	3	PLUG,SENDER	X				
100	DC100085	22	SCREW,HEX	X				
175	DC221820	1	TUBE,GUIDE TOP DIPSTICK	X				
185	DC221821	1	TUBE,GUIDE BOTTOM DIPSTICK	X				
205	DC221822	1	GROMMET	X				
210	DC100597	1	SCREW,GUIDE TUBE	X				
218	DC120228	1	FITTING,GUIDE TUBE	X				
235	DC100677	1	CLAMP,GUIDE TUBE	X				
300	DC221823	1	DIPSTICK,OIL	X				
325	DC221152	1	CAP	X				
330	DC140145	1	RING,SEAL	X				
335	DC221851	1	BRACKET,OIL DIPSTICK	X				
340	DC100659	1	SCREW,GUIDE TUBE	X				
347	DC220562	1	CAP,RUBBER	X				
350	DC220407	1	CLAMP,RUBBER CAP	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222228	1	CYLINDER HEAD, C/W VALVES & C/THROTTLE	X				
10	DC220735	6	BALL, PLUG FOR WEB COOLING BORE	X				
10	DC220735	6	BALL, FASTENER CONSTANT THROTTLE	X				
15	DC220543	2	PLUG, EXPANSION, 34MM	X				
15	DC220549	A/R	PLUG, EXPANSION, 36MM	X				
20	DC120256	A/R	PLUG, EXPANSION, WEB COOLING, M12	X				
20	DC120257	A/R	PLUG, EXPANSION, WEB COOLING, M13	X				
25	DC220545	A/R	PLUG, EXPANSION, 25MM	X				
25	DC120195	1	PLUG, EXPANSION, 40MM	X				
30	DC220737	6	BALL, LEAK, OIL HOLE PLUG	X				
30	DC220735	2	BALL, LEAK, OIL HOLE PLUG	X				
30	DC220735	1	BALL, TO PLUG COOLING WATER BORE	X				
33	DC120258	4	PLUG, SCREW BRACING	X				
40	DC221825	12	SEAT, VALVE, INTAKE STANDARD	X				
40	DC221826	12	SEAT, VALVE, INTAKE REPAIR I, 35.37MM	X				
40	DC221827	12	SEAT, VALVE INTAKE REPAIR II, 35.57MM	X				
40	DC221828	6	SEAT, VALVE EXHAUST STANDARD	X				
40	DC221829	6	SEAT, VALVE EXHAUST REPAIR I, 40.37MM	X				
40	DC221830	6	SEAT, VALVE EXHAUST REPAIR II, 40.57MM	X				
45	DC221831	18	GUIDE, VALVE, INTAKE & EXHAUST, STD	X				
45	DC221832	A/R	GUIDE, VALVE, INTAKE & EXHAUST, +0.2MM	X				
45	DC221833	A/R	GUIDE, VALVE, INTAKE & EXHAUST, +0.5MM	X				
50	DC140160	6	RING, SEAL	X				
55	DC221834	6	SLEEVE	X				
60	DC221835	12	VALVE, INTAKE	X				
60	DC221836	6	VALVE, EXHAUST	X				
65	DC100678	18	WASHER, VALVE SPRING	X				
70	DC221837	12	SPRING, INTAKE VALVE	X				
70	DC221838	6	SPRING, EXHAUST VALVE	X				
75	DC221839	18	RETAINER, SPRING	X				
80	DC220030	36	COLLET, VALVE	X				
85	DC221840	18	HOLDER, SEAL	X				
90	DC222126	6	CAP, VALVE	X				
95	DC221841	6	VALVE, CONSTANT THROTTLE	X				
100	DC221842	6	GUIDE	X				
105	DC221843	6	SPRING	X				
110	DC221844	6	RETAINER, SPRING	X				
115	DC221845	12	VALVE, COLLET	X				
120	DC221846	6	PISTON	X				
130	DC221847	6	COVER	X				
175	DC221848	6	BRIDGE, VALVE	X				
180	DC222235	1	GASKET, CYLINDER HEAD TO CRANKCASE	X				
185	DC100679	14	SCREW, CYLINDER HEAD TO CRANKCASE	X				
260	DC222243	6	INJECTOR, COMPLETE	X				
275	DC140179	6	RING, SEAL, INJECTOR TO CYLINDER HEAD	X				
275	DC140185	6	RING, SEAL, INJECTOR TO CYLINDER HEAD	X				
282	DC140186	6	SLEEVE, HEAT INJECTOR	X				
285	DC221647	6	SOCKET, PIPE	X				
290	DC140166	6	RING, SEAL SOCKET TO CYLINDER HEAD	X				
295	DC100636	6	SCREW, FITTING ON INJECTOR	X				
300	DC221854	6	BRACKET, CLAMPING, INJECTOR TO CYL HD	X				
315	DC100741	6	SCREW, INJECTOR TO CYL HEAD	X				
390	DC260131	1	KIT, CYLINDER HEAD GASKET	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222153	1	CYLINDER HEAD,C/W VALVES & C/THROTTLE	X				
135	DC120231	A/R	HELICOIL,M22X1.5X8.0	X				
140	DC120232	A/R	HELICOIL,M14X1X7.0	X				
145	DC120233	A/R	HELICOIL,M16X1.5X10.5	X				
150	DC120234	A/R	HELICOIL,M14X1.5X14	X				
155	DC120061	A/R	HELICOIL,M12X1.5X12	X				
160	DC120059	A/R	HELICOIL,M10X15	X				
165	DC120057	A/R	HELICOIL,M8X12	X				
170	DC120058	A/R	HELICOIL,M8X116	X				
190	DC120235	5	UNION,THREADED,CONSTANT THROTTLE	X				
195	DC140167	5	RING,SEAL CONSTANT THROTTLE TO HEAD	X				
200	DC130233	1	LINE,CONSTANT THROTTLE	X				
320	DC221855	1	SPINDLE,ROCKER ARM	X				
325	DC120236	2	PLUG,EXPANSION	X				
330	DC221856	6	ARM,ROCKER,INTAKE	X				
335	DC221857	6	ARM,ROCKER,EXHAUST	X				
340	DC150176	12	BUSHING	X				
345	DC100682	12	SCREW,ADJUSTING	X				
350	DC100683	12	NUT,ADJUSTING SCREW	X				
355	DC221858	1	BRACKET,ROCKER ARM,FRONT	X				
355	DC221859	5	BRACKET,ROCKER ARM,CENTRAL	X				
355	DC221860	1	BRACKET,ROCKER ARM,REAR	X				
360	DC221861	6	SPRING	X				
365	DC100684	12	WASHER	X				
370	DC221862	2	RING,LOCK	X				
375	DC221863	7	CLAMPING PIECE,ROCKER SHAFT TO HEAD	X				
380	DC100685	7	SCREW,ROCKER SHAFT TO CYLINDER HEAD	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ENGINE, CYLINDER HEAD COVER - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221864	1	COVER,CYLINDER HEAD,PLASTIC	X				
17	DC221865	1	DIAPHRAGM	X				
18	DC222247	1	SPRING,BREATHER	X				
20	DC222134	1	GASKET,OIL SEP TO CYL/H/COVER	X				
29	DC220031	1	CAP,OIL FILLING	X				
32	DC220029	1	GASKET	X				
35	DC221866	7	INSERT,COVER TO CYLINDER HEAD	X				
41	DC221867	4	LOCK	X				
47	DC221529	1	GASKET	X				
68	DC221868	1	GASKET	X				
74	DC100686	7	SCREW,COVER TO CYLINDER HEAD	X				
115	DC130194	1	PIPE,BREATHER	X				
120	DC130196	1	HOSE,PIPE TO CYLINDER HEAD COVER	X				
125	203588	2	CLAMP,PIPE TO CYLINDER HEAD COVER	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC260151	1	CRANKSHAFT,C/W MAIN/BIG END BEARINGS	X				
10	DC100687	1	PIN,DOWEL,GEAR TO CRANKSHAFT	X				
15	DC221870	1	GEAR,CRANKSHAFT	X				
15	DC221871	1	GEAR,CRANKSHAFT,FITTING SIZE -0.30	X				
20	DC150205	7	BEARING,MAIN STANDARD	X				
20	DC222157	7	BEARING,MAIN,FITTING SIZE 0.10	X				
20	DC222158	7	BEARING,MAIN,FITTING SIZE 0.25	X				
20	DC222159	7	BEARING,MAIN,FITTING SIZE 0.50	X				
20	DC222160	7	BEARING,MAIN,FITTING SIZE 0.75	X				
20	DC222161	7	BEARING,MAIN,FITTING SIZE 1.00	X				
25	DC100688	2	WASHER,THRUST,STANDARD	X				
25	DC100689	2	WASHER,THRUST REPAIR SIZE I,0.30MM	X				
25	DC100690	2	WASHER,THRUST,REPAIR SIZE II,0.50MM	X				
30	DC150183	6	BEARING,BIG END,STANDARD	X				
30	DC150191	6	BEARING,BIG END,FITTING SIZE 0.10	X				
30	DC150192	6	BEARING,BIG END,FITTING SIZE 0.25	X				
30	DC150193	6	BEARING,BIG END,FITTING SIZE 0.50	X				
30	DC150194	6	BEARING,BIG END,FITTING SIZE 0.75	X				
30	DC150195	6	BEARING,BIG END,FITTING SIZE 1.00	X				
35	DC221872	1	DAMPER,VIBRATION	X				
43	DC100691	6	SCREW,DAMPER/HUB TO CRANKSHAFT	X				
55	DC221873	1	FLYWHEEL,WITH RING GEAR	X				
60	DC221874	1	GEAR,RING	X				
70	DC100691	8	SCREW,FLYWHEEL TO CRANKSHAFT	X				
75	DC221875	1	GEAR,CRANKSHAFT	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222223	6	ROD,CONNECTING	X				
10	DC100080	12	SCREW	X				
15	DC221877	6	PISTON,KIT,STANDARD,102MM	X				MAHLE
15	DC221878	6	PISTON,102MM,HEIGHT -.30	X				MAHLE
15	DC221879	6	PISTON,102MM,HEIGHT -.60	X				MAHLE
15	DC221880	6	PISTON,102MM,HEIGHT -.90	X				MAHLE
15	DC222231	6	PISTON,102.30MM,HEIGHT -.30	X				MAHLE
15	DC222232	6	PISTON,102.60MM,HEIGHT -.60	X				MAHLE
15	DC222233	6	PISTON,102.90MM,HEIGHT -.90	X				MAHLE
20	DC260108	6	PISTON RING SET,102MM STD	X				
20	DC260153	6	PISTON RING SET,102.30MM	X				
20	DC260154	6	PISTON RING SET,102.60MM	X				
20	DC206155	6	PISTON RING SET,102.90MM	X				
25	DC221881	6	PIN,PISTON	X				
30	DC221882	12	RING,RETAINING	X				

https://truckmanualshub.com/




TD0003438

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221883	1	CAMSHAFT	X				
15	DC221885	1	PIN,CYLINDRICAL	X				
20	DC221886	12	FOLLOWER,CAM,INLET/EXHAUST VALVES	X				
25	DC221887	12	ROD,PUSH INLET/EXHAUST VALVES	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221888	6	PUMP,FUEL INJECTION	X				
10	DC260109	6	KIT,SEAL RING	X				BLACK SEAL - TOP,GREEN SEAL - BOT.
15	DC140187	6	RING,SEAL PUMP TO CRANKCASE	X				
17	DC140198	6	KIT,REPAIR,FUEL INJECTION PUMP	X				
20	DC100692	12	SCREW,PUMP TO CRANKCASE	X				
25	DC221889	1	PUMP,FUEL	X				
27	DC100693	1	SCREW,SHEAVE PULLEY	X				
30	DC221890	1	GASKET,FUEL PUMP TO CRANKCASE	X				
35	DC100112	3	SCREW,FUEL PUMP TO C/CASE	X				
55	DC221891	1	COVER,INJECTION PUMP	X				
60	DC221892	4	PIN,LOCKING COVER ATTACHMENT	X				
65	DC221893	4	RING,RETAINING COVER ATTACHMENT	X				
70	DC221894	4	SPRING,COVER ATTACHMENT	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC130197	6	PIPE,FUEL PUMP TO INJECTOR NOZZLE	X				
15	DC130198	1	PIPE,FUEL TO CYLINDER HEAD	X				
20	DC130199	1	PIPE,FROM FUEL FILTER TO FEED PUMP	X				
25	DC120211	3	BOLT,BANJO	X				
30	DC140172	6	RING,SEAL	X				
35	DC120209	2	CONNECTOR,FUEL LINE	X				
40	DC120210	2	NUT,UNION FUEL LINES	X				

https://truckmanualshub.com/




TD0003441

https://truckmanualshub.com/

ENGINE, FUEL FILTER - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
15	DC221896	1	FILTER,FUEL COMPLETE UNIT	X				
20	DC221680	1	HEAD,FUEL FILTER	X				
23	DC140174	1	RING,SEAL	X				
25	DC221897	1	COVER,PRE-FILTER	X				
28	DC140188	1	RING,SEAL	X				
35	DC140063	1	RING,SEAL	X				
40	DC100173	1	PLUG,SCREW	X				
45	DC221898	1	INSERT,FILTER	X				
50	DC221899	1	ELEMENT,FUEL FILTER KIT	X				INCLUDES ITEM 23
55	DC221900	1	ELEMENT,FUEL PRE-FILTER	X				INCLUDES ITEM 28
60	DC221901	1	GASKET,FUEL FILTER TO CYLINDER HEAD	X				
65	DC100694	1	SCREW,FILTER TO CYL/HEAD	X				
65	DC100352	2	SCREW,FILTER TO CYL/HEAD	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221902	1	VALVE,SOLENOID	X				
15	DC221903	1	BRACKET,SOLENOID VALVE	X				
20	DC100545	2	SCREW,SOLENOID VALVE TO BRACKET	X				
25	DC100597	1	SCREW,BRACKET TO CHARGING AIR PIPE	X				
30	DC100604	1	NUT,BRACKET TO CHARGING AIR PIPE	X				
40	DC130200	1	PIPE,FROM VALVE TO HEATER PLUGS	X				
90	DC100142	1	BOLT,BANJO PIPE TO SOLENOID VALVE	X				
95	DC140189	2	RING,SEAL PIPE TO SOLENOID VALVE	X				
100	DC130201	1	PIPE,FROM FUEL FILTER TO VALVE	X				
105	DC120237	1	BOLT,BANJO,FUEL PIPE TO FILTER	X				
110	DC100143	1	BOLT,BANJO,FUEL PIPE TO VALVE	X				
115	DC140189	2	RING,SEAL FUEL PIPE TO FUEL FILTER	X				
120	DC140190	2	RING,SEAL FUEL PIPE TO VALVE	X				
125	DC221904	1	PLUG,HEATER CHARGE AIR PIPE	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222245	1	TURBO CHARGER, OM926LA T3	X				
8	DC100316	2	STUD, TURBO TO EXH/MANIFOLD	X				
10	DC100296	2	NUT, TURBO TO MANIFOLD M10	X				
20	191074	1	HEATSHEILD (NOT PART OF ENGINE)	X				SEE ENGINE MISC. ITEMS
30	DC100385	4	SCREW, HEAT SHEILD, M8X16	X				
50	DC221582	1	HOSE, MOLDED	X				
55	DC100381	1	CLAMP, MOLDED HOSE TO TURBO	X				
60	DC100326	1	CLAMP, HOSE TO BREATHER PIPE	X				
60	203588	1	CLAMP, HOSE COMP SUCTION PIPE	X				
65	DC130202	1	PIPE, AIR ON TURBO CHARGER	X				
94	DC140191	1	RING, SEAL, AIR PIPE	X				
100	DC130203	1	PIPE, CHARGE-AIR	X				
114	DC140192	1	RING, SEAL	X				
152	DC100319	1	CLAMP, CHARGE-AIR PIPE TO TURBO	X				
160	DC100390	1	SCREW, CHARGE-AIR PIPE ON MEMBER	X				
170	DC100695	1	STUD, CHARGE-AIR PIPE AT WATER PUMP	X				
175	DC100604	1	NUT, CHARGE-AIR PIPE AT WATER PUMP	X				
200	DC221906	1	BRACKET, AIR PIPE AT WATER PUMP	X				
360	DC100597	2	SCREW, BRACKET TO WATER PUMP	X				
430	206353	1	CLAMP, CHARGE-AIR PIPE ON HOUSING	X				
450	DC100369	1	SCREW, CHARGE-AIR PIPE TO HOUSING	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222156	1	COMPRESSOR,WABCO 352CCM	X				
55	DC100696	1	NUT,GEAR TO COMPRESSOR	X				
110	DC100743	4	SCREW,COMPRESSOR TO CRANKCASE	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC130212	1	PIPE, SUCTION	X				
20	DC130162	1	PIPE, SUCTION	X				
60	DC100385	1	SCREW, INTAKE PIPE TO CRANKCASE	X				
66	DC130213	1	HOSE, SUCTION LINE TO COMPRESSOR	X				
75	203588	2	CLAMP, SUCTION PIPE TO COMPRESSOR	X				
180	DC130234	1	PIPE, AT CYLINDER HEAD	X				
183	DC130235	1	PIPE, AT WATER PUMP	X				
190	DC120182	2	BOLT, BANJO	X				
195	DC140149	4	RING, SEAL	X				
240	DC220481	1	CAP, POWER STEERING PUMP	X				
245	DC220314	1	GASKET	X				
250	DC100597	2	SCREW, FLANGED, COVER TO COMP	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
25	DC221915	1	HOUSING,CHARGING AIR ELBOW	X				
50	DC222085	1	UNIT,SENDER C/AIR PRES/TEMP,4 BAR	X				
52	DC140199	1	RING, SENDER	X				
65	DC100744	2	SCREW,FLANGED	X				
75	DC100685	2	SCREW,C/AIR ELBOW TO CYL HEAD	X				
78	DC100745	10	SCREW,C/AIR ELBOW TO CYL HEAD	X				
85	DC222060	6	GASKET,C/AIR ELBOW TO CYL HEAD	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
12	DC222116	1	MANIFOLD,EXHAUST,MIDDLE PIECE	X				
14	DC222115	2	MANIFOLD,EXHAUST,END PIECE	X				
20	DC100316	2	STUD	X				
25	DC221918	3	GASKET,MANIFOLD TO CYLINDER HEAD	X				
30	DC100698	12	SCREW,MANIFOLD TO CYLINDER HEAD	X				
32	DC222117	4	RING,SEAL,3 PIECE EXHAUST	X				
95	DC260161	1	KIT,EXHAUST BRAKE	X				
100	DC220960	1	LEVER	X				
105	DC220981	1	PIVOT,BALL	X				
110	DC100378	1	SCREW,LEVER TO SHAFT	X				
115	DC100699	1	NUT,LEVER TO THROTTLE VALVE	X				
120	DC260113	1	KIT,EXHAUST BRAKE VALVE	X				
125	DC100296	4	NUT,FLANGED,EXH/BRAKE TO TURBO	X				
140	DC221919	1	BRACKET	X				
145	DC100385	2	SCREW,BRACKET TO FLANGED ELBOW	X				
160	DC221920	1	CYLINDER,EXHAUST BRAKE	X				
180	DC100112	1	SCREW,CYLINDER TO BRACKET	X				
185	DC221921	1	TUBE,PACER,CYLINDER TO BRACKET	X				
205	DC220980	1	SOCKET,BALL,CYLINDER TO LEVER	X				
210	DC100359	1	NUT,CYLINDER TO LEVER	X				
215	DC220836	1	CLIP,SECURING	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

REFER TO PAGE 1-17 FOR IDENTIFICATION OF TIER 2 OR TIER 3 ENGINE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222162	1	UNIT,CONTROL,TIER 3	X				
11	DC100366	3	SCREW,FLANGED,CONTROL UNIT	X				
17	DC221771	6	RING,RUBBER	X				
41	DC222147	1	CABLE,ELECTRIC-ENGINE	X				
53	DC120249	1	PLUG SOCKET,ENGINE START	X				
53	DC120249	1	PLUG SOCKET,ENGINE STOP	X				
53	DC120249	1	PLUG SOCKET,OIL LEVEL SENSOR	X				
70	DC120247	1	PLUG,COOLING WATER TEMP	X				
70	DC120247	1	PLUG,FUEL TEMP SENDER UNIT	X				
70	DC120247	1	PLUG,CAMSHAFT POSITION UNIT	X				
70	DC120247	1	PLUG,CRANKSHAFT POSITION UNIT	X				
70	DC120247	1	PLUG,OIL TEMP SENSOR	X				
85	DC120255	1	COUPLING,THROTTLE VALVE	X				
100	DC120248	1	PLUG,OIL PRESSURE SENDER UNIT	X				
130	DC120250	1	PLUG,BOOST AIR SENSOR	X				
205	DC120222	1	HOUSING,PIN,CONTROL MODULE	X				
220	DC120244	1	CAP,CONTROL MODULE	X				
235	DC120243	A/R	TERMINAL,PIN,CONTROL MODULE	X				
250	DC222098	A/R	GASKET,CONTROL MODULE	X				
265	DC120245	A/R	PLUG,ENGINE CONTROL	X				
280	DC120246	12	SHOE,CABLE UNIT	X				
382	DC221924	2	SWITCH,ENGINE START/STOP	X				
388	DC100700	2	NUT,ENGINE START/STOP	X				
406	101354	4	SCREW,CAP,BRACKET TO CRANKCASE	X				
412	DC221734	1	SENDER,SPEED AT CRANKCASE	X				
412	DC221734	1	SENDER,SPEED AT TIMING CASE	X				
418	DC150196	1	BUSHING,T.D.C. SENSER TO CRANKCASE	X				
418	DC150196	1	BUSHING,CRANKCASE POSITION UNIT	X				
424	DC140178	1	O-RING,T.D.C. SENDER TO CRANKCASE	X				
478	200871	A/R	CABLE TIE	X				
514	DC221726	1	ELECTRONICS,KSA	X				
520	DC221727	1	HOUSING,SOCKET FLAME START SYSTEM	X				
526	DC120221	2	PIN,SOCKET HOUSING FLAME START	X				
532	DC221728	2	GASKET,FLAME START SYSTEM	X				
538	DC221729	1	BOOT,FLAME START SYSTEM	X				
544	DC120218	1	HOUSING,PLUG FLAME START SYSTEM	X				
550	DC100664	1	NUT,FLAME START SYSTEM	X				
556	DC221730	2	GASKET,FLAME START	X				
562	DC221928	2	PIN,SOCKET HOUSING FLAME START	X				
568	DC221731	1	BOOT,FLAME START SYSTEM	X				
574	DC120220	1	PIN,BUSHING,HEATER PLUG TO GROUND	X				
580	DC100383	1	NUT,HEATER PLUG TO GROUND	X				
600	DC222101	1	CABLE,CONTROL UNIT TO SHIFT PANEL	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ENGINE, STARTING MOTOR - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221926	1	MOTOR,STARTER 24V/4KW,BOSCH	X				
10	DC221555	1	BENDIX	X				
15	DC150126	1	BUSHING,DRIVE END	X				
20	DC221930	1	HOUSING,FRONT	X				
25	DC150156	1	BUSHING,BENDIX	X				
30	DC221931	1	SWITCH,SOLENOID	X				
35	DC221932	1	LEVER,CONTROL	X				
45	DC150158	1	BUSHING,COMMUTATOR END	X				
80	DC221934	1	SWITCH,SOLENOID	X				
95	DC260114	1	KIT,GEARING	X				
100	DC260115	1	KIT,GEARING	X				
105	DC260116	1	KIT,ARMATURE	X				
110	DC100538	3	SCREW,STARTER TO TIMING CASE	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222227	1	ALTERNATOR, W/O PULLEY 28V/80AMP	X				
20	DC100715	4	SCREW, ALTERNATOR	X				
50	DC150157	1	BEARING, BALL DRIVE END	X				
60	DC150168	1	BEARING, BALL SLIP RING SIDE	X				
110	DC222017	1	RECTIFIER, ALTERNATOR	X				
130	DC222018	1	CONDENSOR, ALTERNATOR	X				
170	DC222021	1	REGULATOR AND CUT-OUT	X				
190	DC100346	2	SCREW	X				
215	DC260152	1	KIT, REPAIR SCREWS	X				
220	DC260073	1	KIT, TERMINAL PARTS	X				
259	DC220508	1	FAN, ALTERNATOR PULLEY	X				
278	DC222022	1	PULLEY, ALTERNATOR	X				
280	DC100764	1	WASHER, ALTERNATOR	X				
300	DC221967	1	SUPPORT, ALTERNATOR	X				
301	DC100755	1	PIN, SPRING	X				
302	DC100708	4	SCREW, BRACKET TO CRANKCASE	X				
303	DC100662	1	SCREW, ALTERNATOR TO SUPPORT	X				
304	DC100604	1	NUT, ALTERNATOR TO SUPPORT	X				
305	DC221968	1	BRACKET	X				
306	DC100597	1	SCREW, BRACKET TO OIL FILTER	X				
307	100478	1	SCREW, ALTERNATOR TO BRACKET	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ENGINE, OIL PUMP - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC221937	1	PUMP,OIL	X				
10	DC140194	1	SEAL,OIL FRONT CRANKSHAFT	X				
20	DC100413	8	SCREW,OIL PUMP TO CRANKCASE	X				
25	DC130207	1	PIPE,SUCTION	X				
40	DC221936	1	BRACKET	X				
45	DC100621	1	SCREW,PIPE TO DIPSTICK GUIDE TUBE	X				
50	100197	8	SCREW,SUCTION PIPE TO OIL PUMP	X				
55	DC100597	1	SCREW,SUCTION PIPE TO CRANKCASE	X				
55	DC100621	1	SCREW,SUPPORT ON OIL INTAKE PIPE	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	DC222148	1	FILTER,OIL COMPLETE UNIT	X				
15	DC221939	1	COVER,OIL FILTER	X				
25	DC221578	1	ELEMENT,OIL FILTER	X				
30	DC221940	1	NECK,FILTER	X				
35	DC140195	1	RING,SEAL	X				
46	DC140182	1	RING,SEAL TO PLUG SENDER UNIT PORT	X				
50	DC221942	1	GASKET,OIL FILTER TO CRANKCASE	X				
70	DC221943	1	VALVE,PRESSURE RELIEF	X				
75	DC100366	4	SCREW,OIL FILTER TO CRANKCASE	X				
75	DC100671	1	SCREW,OIL FILTER TO CRANKCASE	X				
105	DC221944	1	ELEMENT,OIL COOLER	X				
110	DC221945	1	COVER,OIL COOLER	X				
115	DC221946	1	GASKET,OIL COOLER TO COVER	X				
120	DC100385	2	SCREW,OIL COOLER TO COVER	X				
125	DC221947	1	GASKET,OIL COOLER TO CRANKCASE	X				
130	DC100085	12	SCREW,OIL COOLER TO CRANKCASE	X				
132	DC221743	1	SENDER,OIL TEMPERATURE	X				
133	DC140149	1	RING,SEAL	X				
135	DC221171	A/R	PLUG,SCREW	X				
140	DC140059	A/R	WASHER,SEALING	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
8	DC130208	1	PIPE,OIL FEED	X				
35	DC130231	1	PIPE,OIL RETURN	X				
55	DC120182	1	BOLT,BANJO FEED PIPE TO OIL FILTER HD	X				
70	DC140149	2	RING,SEAL FEED PIPE TO OIL FILTER HD	X				
90	DC221746	1	GASKET,RETURN PIPE TO TURBO	X				
105	DC100414	2	SCREW,RETURN PIPE TO TURBO	X				
115	DC130210	1	PIPE,PLASTIC,RETURN TO CRANKCASE	X				
125	DC100326	2	CLAMP,RETURN PIPE TO CRANKCASE	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ENGINE, WATER PUMP - OM926LA

ITEM	PART No	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
8	DC221949	1	PUMP,WATER WITH GASKETS	X				
15	267546	1	KIT,GASKET WATER PUMP	X				
20	DC221948	1	GASKET,WATER PUMP TO CRANKCASE	X				
24	DC100198	3	SCREW,WATER PUMP TO CRANKCASE	X				
28	DC100702	4	SCREW,WATER PUMP TO CRANKCASE	X				
42	DC221743	1	SENDER,TEMPERATURE	X				
45	DC140149	1	RING,SEAL SENDER UNIT TO FLANGE	X				
57	DC222145	1	CONNECTOR,RETARDER	X				
100	DC221950	1	GASKET,PIPE SOCKET TO CYL/HEAD	X				
106	DC100408	1	SCREW,PIPE SOCKET TO CYL/HEAD	X				
112	DC120238	1	SOCKET,PIPE TO WATER PUMP	X				
200	DC221577	2	THERMOSTAT,83 DEGREE	X				
205	DC140110	2	RING,SEAL	X				
224	DC220008	1	COVER,TWIN THERMOSTAT HOUSING	X				
230	DC100366	2	SCREW,FLANGED,40MM LG	X				
232	DC100657	1	SCREW,FLANGED,70MM LG	X				
235	DC220800	1	SENDER,UNIT COOLING WATER OUTLET	X				
245	DC120239	1	UNION,BANJO	X				
265	DC120240	1	FITTING,HEAT FEED	X				
270	DC140182	2	RING,SEAL TO FITTING	X				
275	DC221952	1	CAP,RUBBER TO PLUG PIPE SOCKET	X				
280	203588	1	CLAMP,RUBBER CAP 20-32MM	X				
285	DC221953	1	PULLEY	X				
310	DC100507	4	SCREW,FAN PULLEY TO WATER PUMP	X				
315	DC222166	1	BELT-V,1939MM	X				
315	DC222204	1	BELT-V,1369MM,W/O AIR CON	X				FOR EMERGENCY ONLY
320	DC222167	1	PULLEY,GUIDE FUEL FEED PUMP	X				
345	DC222168	1	TIGHTENER,BELT	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	216898	1	FAN, SUCKER C/W VISCOUS HUB	X				NOT SUPPLIED WITH ENGINE
5	214065	1	FAN, SUCKER, DIA 725	X				
15	NSI	1	HUB, VISCOUS	X				
20	DC100359	4	NUT, FAN CLUTCH AT ADAPTOR PIECE	X				
35	DC222225	1	SPACER ,FAN	X				
40	DC100703	4	STUD	X				
55	DC100704	6	SCREW, SPACER TO VIBRATION DAMPER	X				

https://truckmanualshub.com/




TD0003478A

https://truckmanualshub.com/

ITEM	PART No	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
75	DC221958	1	EYE,LIFTING REAR	X				
85	DC100597	4	SCREW,LIFTING EYE TO CYLINDER HEAD	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
8	DC221758	1	COMPRESSOR,LESS COUPLING	X				
10	DC260118	1	KIT,COUPLING	X				
15	DC260098	1	KIT,GASKET	X				
20	DC221959	1	CONSOLE	X				
25	DC221960	2	SLEEVE	X				
30	DC221961	2	SLEEVE	X				
80	DC100707	4	SCREW,COMPRESSOR TO SUPPORT	X				
85	DC100352	4	SCREW,SUPPORT TO CRANKCASE	X				

https://truckmanualshub.com/



TD0003835 - B
E14832403 - D


https://truckmanualshub.com/

EXHAUST SYSTEM - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218292	1	SHIELD,HEAT,EXH,FRONT	X				
2	217754	1	EXHAUST,MID SECTION	X				
3	217752	1	EXHAUST,FRONT SECTION	X				
4	216350	1	EXHAUST,STACK,POLISHED SS	X				
5	216042	1	EXHAUST,MUFFLER	X				
6	207496	1	CLAMP,EXHAUST	X				
7	216755	1	EXHAUST,H/SHIELD COVER	X				
8	216754	1	EXHAUST,H/SHIELD FIXED	X				
9	206636	1	EXHAUST,H/SHIELD MID	X				
10	204035	3	CLAMP,SEALCLAMP	X				
11	201212	4	CLAMP,EXHAUST,100MM	X				
12	191074	1	HEATSHIELD,TURBO	X				
13	174447	1	MTG,EXHAUST H/SHIELD FRNT	X				
14	100652	1	NUT,STOVER	X				
15	100548	6	WASHER,HARDENED	X				
16	100424	11	WASHER,HARDENED	X				
17	100370	10	WASHER,HARDENED	X				
18	100211	11	SCREW,HEXHD	X				
19	100199	1	BOLT,HEXHD	X				
20	100091	10	SCREW,HEXHD	X				
21	100083	4	SCREW,HEXHD	X				

https://truckmanualshub.com/

KIT, BIN HEATING (OPTIONAL) - OM926LA




https://truckmanualshub.com/

KIT, BIN HEATING (OPTIONAL) - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264799	1	KIT,RIBLESS BIN HEATING	X				
1	262900	1	ASSY,B/HEAT,HOSE GUARD	X				
2	216913	1	ASSY,MID SECTION	X				
3	214261	1	STACK,BIN HEATING	X				
4	207374	1	MTG,PLT,LOWER B/HEATING	X				
5	207373	1	MTG,BKT,B/HEATING	X				
6	206305	1	ASSY,FLEX SWIVEL B/H	X				
7	206303	1	ASSY,MID SECT,B/HEATING	X				
8	206301	1	ASSY,TOP SECT,B/HEATING	X				
9	204035	2	CLAMP,SEALCLAMP	X				
10	201667	3	SPRING,BIN HEAT,SUSP,PLT	X				
11	201666	6	SPRING,BIN HEAT,BALL,JOINT	X				
12	201212	3	CLAMP,EXHAUST	X				
13	176250	3	WASHER,PROFILED	X				
14	174760	2	FLANGE,BIN HEATING BALL	X				
15	174674	1	BKT,BIN HEATING,HYD MTG	X				
16	162456	12	WASHER,SPRING RET,BIN HEAT	X				
17	162060	3	PIN,BIN HEAT,SPRING GUIDE	X				
18	140622	4	SEAL,RING	X				
19	100747	6	BOLT,HEXHD	X				
20	100655	7	NUT,STOVER	X				
21	100652	6	NUT,STOVER	X				
22	100569	3	SCREW,HEXHD	X				
23	100548	9	WASHER,HARDENED	X				
24	100424	17	WASHER,HARDENED	X				
25	100312	3	NUT,NYLOC	X				
26	100212	7	SCREW,HEXHD	X				
27	100210	7	SCREW,HEXHD	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
2	290131	1	AIR CLEANER,FRG15,RADIAL SEAL	X				REFERENCE PAGE 2-72; 2-73
3	217684	2	MTG,BAND,2PC,AIR CLEANER,FRG 15	X				
4	208828	2	CLAMP,T-BOLT	X				
5	206489	1	PIPE,AIR INTAKE	X				
6	204668	1	CLAMP,STACK-AIR INTAKE PIPE	X				
7	201819	1	REDUCER,STACK	X				
8	200641	1	ELBOW,90 DEG 6" EQUAL RUBBER	X				
9	200466	1	INFORMER	X				
10	200051	1	CLAMP,HOSE	X				
11	100370	10	WASHER,HARDENED	X				
12	100314	4	NUT,NYLOC	X				
13	100089	6	SCREW,HEXHD	X				
14	100083	2	SCREW,HEXHD	X				
15	100062	2	WASHER,FLAT	X				
16	290230	1	PRE-CLEANER (ADT 240)	X				
17	202860	1	BOWL,PRE-CLEANER	X				
18	220535	1	COVER,PRE CLEANER	X				
19	NSI	1	BODY,PRE CLEANER	X				
20	NSI	1	NUT,WING	X				

https://truckmanualshub.com/

1




P008531

https://truckmanualshub.com/

AIR CLEANER - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	290131	1	AIR CLEANER,FRG15,RADIAL SEAL	X				REFERENCE PAGE 2-70; 2-71
2	220722	1	COVER,FRG15 AIR CLEANER	X				
3	220723	6	LATCH,FRG15 AIR CLEANER	X				
4	220725	1	ELEMENT,OUTER,FRG15 A/CLEANER	X				
5	220747	1	ELEMENT,INNER,FRG15 A/CLEANER	X				
6	220724	1	VACUATOR,VALVE,FRG15 A/CLEANER	X				
7	NSI	1	BODY,AIR CLEANER	X				
8	200871	2	CABLE TIE	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	DC220461	1	PUMP,HANDLIFT& PREFILTER LATES	X				REFERENCE PAGE 2-78; 2-79
2	241225	1	HOSE	X				
3	241224	1	HOSE	X				
4	241218	1	HOSE	X				
5	240980	1	HOSE	X				
6	207693	1	ASSY,FUEL FILTER	X				REFERENCE PAGE 2-76; 2-77
7	206945	6	MTG,RUBBER	X				
9	121451	2	ADAPTOR	X				
10	121365	1	ADAPTOR	X				
11	120969	2	CONNECTOR	X				
12	120804	2	ELBOW	X				
13	120781	2	ADAPTOR	X				
14	120670	1	CONNECT	X				
15	100731	4	SCREW,HEXHD	X				
16	100548	12	WASHER,HARDENED	X				
17	100312	6	NUT,NYLOC	X				
18	100198	2	SCREW,HEXHD	X				
19	100080	1	SCREW,HEXHD	X				
20	100061	1	WASHER,FLAT	X				
26	203764	2	P-CLIP,25MM	X				

https://truckmanualshub.com/

FUEL-WATER FILTER UNIT - OM926LA




https://truckmanualshub.com/

FUEL-WATER FILTER UNIT - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	207693	1	FILTER,UNIT,FUEL-WATER	X				REFERENCE PAGE 2-74; 2-75
2	207694	1	ELEMENT,FILTER	X				
3	224670	1	BOWL,SEE-THRU	X				
4	224667	1	VALVE,DRAIN SELF VENTING	X				
5	218508	1	CLAMP,FUEL FILTER	X				
6	226385	1	KIT,LID & GASKET	X				
7	226386	1	KIT,T-HANDLE & O-RING	X				
8	221597	1	KIT,SEAL,SERVICE	X				

https://truckmanualshub.com/

1




TD0004783

https://truckmanualshub.com/

HANDLIFT PUMP & PRE-FILTER - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	DC220461	1	HANDLIFT PUMP & PRE-FILTER	X				REFERENCE PAGE 2-74; 2-75
2	DC260058	1	KIT,PRE-FILTER ELEMENT	X				
3	DC140123	1	RING,SEAL	X				
4	DC221232	1	BOWL,FILTER	X				

https://truckmanualshub.com/



E16832405 D SH1-2
TD0005161


https://truckmanualshub.com/

ENGINE COOLING SYSTEM : DETAIL A - OM926LA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	AT310335	1	FILLER CAP	X				
2	218686	1	HOSE,RADIATOR	X				2810 MM LONG
3	218686	1	HOSE,RADIATOR	X				1660 MM LONG
4	217971	1	HOSE,INLET,ENG	X				
5	217970	1	HOSE,BOTTOM,RAD	X				
6	217969	1	HOSE,TOP,RAD	X				
12	216484	1	CLAMP,HOSE	X				
14	216097	1	SURGE TANK,8L,PLASTIC	X				
17	216016	1	PIPE,MAKE-UP LINE	X				
18	216015	1	HOSE,MAKE-UP LINE	X				
19	216014	1	HOSE,SURGE TNK OUTLET	X				
20	216011	1	PIPE,SUCTION	X				
25	208821	6	CLAMP,T-BOLT	X				
27	203926	2	GROMMET	X				
28	203764	6	P-CLIP,25MM	X				
29	203681	1	P-CLIP,50MM	X				
31	201439	4	P-CLIP,18MM	X				
32	200092	4	CLAMP	X				
33	200061	4	CLAMP	X				
34	200033	4	CLAMP	X				
35	187425	1	BKT,VENT PIPES	X				
36	187315	1	BKT,PIPE	X				
37	176353	1	MTG,HOSE	X				
39	130002	1	HOSE	X				1610 MM LONG
40	130002	1	HOSE	X				1330 MM LONG
41	130002	1	HOSE	X				1140 MM LONG
44	120051	1	ADAPTOR	X				
47	100731	8	SCREW,HEXHD	X				
48	100548	16	WASHER,HARDENED	X				
49	100494	6	SCREW,HEXHD	X				
50	100370	12	WASHER,HARDENED	X				
51	100364	2	SCREW,HEXHD	X				
52	100314	2	NUT,LOCK	X				
53	100312	8	NUT,NYLOC	X				
54	100310	6	NUT,NYLOC	X				
56	100081	5	SCREW,HEXHD	X				
57	100080	2	SCREW,HEXHD	X				
58	100062	4	WASHER,FLAT	X				
59	100061	13	WASHER,FLAT	X				

https://truckmanualshub.com/

ENGINE COOLING SYSTEM : DETAIL B - OM926LA




TD0005162
E16832405 D SH2-2

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
7	217965	1	HOSE,STRAIGHT,CAC	X				
8	217964	1	HOSE,BOTTOM,CAC	X				
9	217963	1	HOSE,TOP,CAC	X				
10	217962	1	PIPE,BOTTOM,CAC	X				
11	216830	1	COOLING PACK	X				
13	216128	2	CLAMP,T-BOLT	X				
15	216045	1	COWLING,RAD	X				
16	216035	1	CLAMP,RETAINER	X				
21	214159	1	GUARD,FAN,RHS	X				
22	214158	1	GUARD,FAN,LHS	X				
23	208824	3	CLAMP	X				
24	208823	1	CLAMP	X				
26	206523	2	MTG,RUBBER	X				
30	203538	1	CLAMP	X				
38	173733	2	PLT,SPACER	X				
42	121312	1	TAP,COOLANT DRAIN	X				
43	121224	2	PLUG	X				
45	101345	6	WASHER,HARDENED	X				
46	100733	8	SCREW,HEXHD	X				
47	100731	8	SCREW,HEXHD	X				
48	100548	16	WASHER,HARDENED	X				
49	100494	6	SCREW,HEXHD	X				
50	100370	12	WASHER,HARDENED	X				
53	100312	8	NUT,NYLOC	X				
55	100083	4	SCREW,HEXHD	X				

https://truckmanualshub.com/

ENGINE COOLING SYSTEM, RADIATOR - OM926LA



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	910142	4	WINDOW SEAL:SELF ADHV	X				990 MM LONG
2	910142	1	WINDOW SEAL:SELF ADHV	X				300 MM LONG
3	216918	1	CAC	X				
4	216917	1	RADIATOR	X				
5	216843	4	BUSH	X				
6	216047	1	FRAME,RIGHT	X				
7	216046	1	FRAME,LEFT	X				
8	214109	1	BRACE	X				
9	214108	1	FRAME,BOT	X				
10	214107	1	FRAME,TOP	X				
11	214106	1	TM OIL COOLER	X				
12	101385	4	WASHER	X				
13	101384	20	WASHER	X				
14	100657	8	NUT,STOVER	X				
15	100370	18	WASHER,HARDENED	X				
16	100210	4	SCREW,HEXHD	X				
17	100178	2	SCREW	X				
18	100089	8	SCREW,HEXHD	X				
19	100086	12	SCREW,HEXHD	X				
20	100085	8	SCREW,HEXHD	X				

https://truckmanualshub.com/

https://truckmanualshub.com/


:

SECTION 3: DRIVETRAIN

https://truckmanualshub.com/

TRANSMISSION MISC. PARTS : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



E14832410 B
TD0003124 C

https://truckmanualshub.com/

TRANSMISSION MISC. PARTS : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	Z4139330600	4	DIAPHRAGM	X	X			
2	250298	1	T/MISS,ZF-6HP592C,ECOMAT	X	X			
3	207646	2	MTG,RUBBER,T/MISSION,SPLT	X	X			
4	183375	2	ASSY,TRANS MTG,4 HOLE	X	X			
5	183155	2	MTG,TRANSMISSION,6HP590	X	X			
6	176592	4	SPACER,ENG MTG	X	X			
7	101324	2	BOLT,HEXHD	X	X			
8	100877	10	SCREW,HEXHD	X	X			
9	100655	8	NUT,STOVER	X	X			
10	100653	2	NUT,STOVER	X	X			
11	100536	8	WASHER,HARDENED	X	X			
12	100532	4	WASHER,HARDENED	X	X			
13	100424	16	WASHER,HARDENED	X	X			
14	100059	10	WASHER	X	X			
15	100114	8	SCREW,HEXHD	X	X			
16	100124	8	SCREW,HEXHD	X	X			

https://truckmanualshub.com/

TRANSMISSION MISC. PARTS : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)



E16832410 A
TD0005171

https://truckmanualshub.com/

TRANSMISSION MISC. PARTS : DETAIL B


NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	Z4139330600	4	DIAPHRAGM	X				
2	250314	1	T/MISS,ZF-6HP592C,E2+	X				
3	207646	2	MTG,RUBBER,T/MISSION,SPLT	X				
4	183375	2	ASSY,TRANS MTG,4 HOLE	X				
5	183155	2	MTG,TRANSMISSION,6HP590	X				
6	178728	1	BKT,COMP,PIPE	X				
7	176592	4	SPACER,ENG MTG	X				
8	101324	2	BOLT,HEXHD	X				
9	100877	10	SCREW,HEXHD	X				
10	100655	8	NUT,STOVER	X				
11	100653	2	NUT,STOVER	X				
12	100536	10	WASHER,HARDENED	X				
13	100532	4	WASHER,HARDENED	X				
14	100424	16	WASHER,HARDENED	X				
15	100370	10	WASHER,HARDENED	X				
16	100365	2	SCREW,HEXHD	X				
17	100210	8	BOLT	X				
18	100124	8	SCREW,HEXHD	X				

https://truckmanualshub.com/

TRANSMISSION HOUSING : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

TRANSMISSION HOUSING : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210615	1	HOUSING,TRANSMISSION	X	X			
100	ZF210192	1	CAP,SEALING	X	X			
160	ZF100156	1	PLUG,SCREW	X	X			
180	ZF120005	1	PLUG,SCREW	X	X			
180	Z0634801151	1	RING,SEALING	X	X			
190	ZF120004	5	PLUG,SCREW	X	X			
190	Z0634801152	5	RING,SEALING	X	X			
500	ZF140071	2	RING,SEALING	X	X			
510	ZF180016	2	PIPE	X	X			
520	ZF140072	4	WASHER,SEALING	X	X			
550	ZF210193	1	GASKET	X	X			
570	ZF210194	1	COVER	X	X			
580	ZF100203	1	SCREW,HEX	X	X			
580	Z0630001048	1	WASHER	X	X			
590	ZF100203	5	SCREW,HEX	X	X			
590	Z0630001048	5	WASHER	X	X			
600	ZF210535	8	INSERT,MOUNTING	X	X			

https://truckmanualshub.com/

TRANSMISSION HOUSING : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

TRANSMISSION HOUSING : DETAIL B


NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210615	1	HOUSING,TRANSMISSION	X				
100	ZF210192	1	CAP,SEALING	X				
160	ZF100156	1	PLUG,SCREW	X				
180	ZF120005	1	PLUG,SCREW	X				
180	Z0634801151	1	RING,SEALING	X				
190	ZF120004	5	PLUG,SCREW	X				
190	Z0634801152	5	RING,SEALING	X				
500	ZF140174	2	RING,SEALING	X				
510	ZF180016	2	PIPE	X				
520	ZF140175	4	WASHER,SEALING	X				
550	ZF210193	1	GASKET	X				
570	ZF210194	1	COVER	X				
580	DC100091	1	SCREW,HEX	X				
580	100542	1	WASHER	X				
590	DC100091	5	SCREW,HEX	X				
590	100542	5	WASHER	X				
600	ZF210535	8	INSERT,MOUNTING	X				

https://truckmanualshub.com/

OIL SUPPLY, CONTROL INSERT : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

OIL SUPPLY, CONTROL INSERT : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210575	1	INSERT,CONTROL	X	X			
070	ZF210576	1	SPRING,COMPRESSION	X	X			
080	ZF210577	1	PISTON	X	X			
090	ZF210578	1	PISTON	X	X			
110	ZF210579	1	BUSH	X	X			
120	ZF100157	1	WASHER	X	X			
130	ZF160379	1	RING,RETAINING	X	X			
150	ZF210202	1	PISTON	X	X			
160	ZF210203	1	SPRING,COMPRESSION	X	X			
170	ZF160380	1	RING,SPACER	X	X			
180	ZF210204	1	PIN,CYLINDRICAL	X	X			
190	ZF210205	1	PISTON	X	X			
200	ZF210206	1	SPRING,COMPRESSION	X	X			
210	ZF100158	1	WASHER	X	X			
220	ZF160381	1	RING,RETAINING	X	X			
250	ZF210207	1	PISTON	X	X			
260	ZF210208	1	SPRING,COMPRESSION	X	X			
270	ZF160382	1	RING,SPACER	X	X			
280	ZF210204	1	PIN,CYLINDRICAL	X	X			
290	ZF180017	1	PIPE	X	X			
300	Z0634801152	4	RING,SEALING	X	X			
300	Z0637835033	2	UNION SCREW	X	X			
310	ZF210580	1	FLANGE,OIL FEED	X	X			
320	ZF210581	1	PUMP,PRIMARY	X	X			
330	ZF100323	2	SCREW,CAP	X	X			
340	ZF210412	7	SCREW,TORX	X	X			
350	ZF210211	1	RING,INTERMEDIATE	X	X			
360	ZF210212	1	RING,THRUST	X	X			
370	ZF100162	3	SCREW,CAP	X	X			
370	ZF100160	3	WASHER	X	X			
380	Z0734401270	4	RING,PISTON	X	X			
382	ZF100324	1	WASHER	X	X			
384	ZF140159	1	O-RING	X	X			
390	ZF150134	1	BEARING,BALL	X	X			
400	ZF100027	3	SCREW,CAP	X	X			
400	ZF100160	3	WASHER	X	X			
402	ZF100101	1	SCREW,CAP	X	X			
402	ZF100160	1	WASHER	X	X			
404	ZF100027	1	SCREW,CAP	X	X			
404	ZF100160	1	WASHER	X	X			
410	ZF100163	3	SCREW,CAP	X	X			
410	ZF100160	3	WASHER	X	X			
414	ZF100163	1	SCREW,CAP	X	X			
414	ZF100160	1	WASHER	X	X			
420	ZF100159	3	SCREW,CAP	X	X			
420	ZF100160	3	WASHER	X	X			
430	ZF100164	3	SCREW,CAP	X	X			
430	ZF100160	3	WASHER	X	X			
440	ZF100165	5	SCREW,CAP	X	X			
440	ZF100160	5	WASHER	X	X			
650	ZF100170	1	SNAP,RING	X	X			
660	ZF210218	1	RING,PISTON	X	X			
670	ZF210219	1	SUPPORT,SUPPORT	X	X			

https://truckmanualshub.com/

OIL SUPPLY, CONTROL INSERT : DETAIL A (CONT.)

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

OIL SUPPLY, CONTROL INSERT : DETAIL A (CONT.)


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
680	ZF210220	1	CAGE,NEEDLE	X	X			
690	ZF210221	1	RING,INTERNAL	X	X			
700	ZF100326	1	PIN,SLOT	X	X			
704	ZF100327	1	PIN,SLOT	X	X			
710	ZF210583	1	SHAFT,STSTOR	X	X			
/**120**	ZF210225	1	BUSH	X	X			

https://truckmanualshub.com/

OIL SUPPLY, COVER PLATE : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

OIL SUPPLY, COVER PLATE : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
500	ZF210616	1	PLATE,COVER	X	X			
510	ZF140075	1	SEAL,SHAFT	X	X			
520	ZF140076	1	O-RING	X	X			
530	ZF180018	1	PIPE	X	X			
540	ZF100166	2	SCREW,UNION	X	X			
540	Z0634801152	4	RING,SEALING	X	X			
550	ZF210215	1	GEAR	X	X			
560	ZF210216	1	GEAR	X	X			
570	ZF210217	2	BEARING,ROLLER	X	X			
580	Z0630503015	2	RING,SNAP	X	X			
590	ZF100167	2	RING,SNAP	X	X			
600	ZF100325	13	SCREW,CAP	X	X			
600	ZF140077	13	RING,SEALING	X	X			
610	ZF100169	8	SCREW,HEX	X	X			
610	ZF140077	8	RING,SEALING	X	X			
620	ZF100110	8	SCREW,HEX	X	X			
620	ZF140077	8	RING,SEALING	X	X			
630	ZF100323	1	SCREW,CAP	X	X			
630	ZF140077	1	RING,SEALING	X	X			
750	ZF210617	1	PIPE	X	X			
760	ZF100166	2	SCREW,UNION	X	X			
760	Z0634801152	4	RING,SEALING	X	X			
770	ZF210226	2	SHACKLE	X	X			
780	ZF210227	2	SHEET	X	X			
790	ZF140160	2	O-RING	X	X			
800	ZF210584	2	AXLE	X	X			
810	ZF140079	2	O-RING	X	X			
820	ZF210229	2	WASHER,THRUST	X	X			
830	ZF210230	1	PLATE,CLAMPING	X	X			
840	ZF210231	1	PLATE,CLAMPING	X	X			
850	ZF100328	2	SCREW,CAP	X	X			

https://truckmanualshub.com/

OIL SUPPLY, CONTROL INSERT : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

OIL SUPPLY, CONTROL INSERT : DETAIL B


NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210575	1	INSERT,CONTROL	X				
070	ZF210576	1	SPRING,COMPRESSION	X				
080	ZF210577	1	PISTON	X				
090	ZF210578	1	PISTON	X				
110	ZF210579	1	BUSH	X				
120	ZF100157	1	WASHER	X				
130	ZF160379	1	RING,RETAINING	X				
150	ZF210202	1	PISTON	X				
160	ZF210203	1	SPRING,COMPRESSION	X				
170	ZF160380	1	RING,SPACER	X				
180	ZF210204	1	PIN,CYLINDRICAL	X				
190	ZF210205	1	PISTON	X				
200	ZF210206	1	SPRING,COMPRESSION	X				
210	ZF100158	1	WASHER	X				
220	ZF160381	1	RING,RETAINING	X				
250	ZF210207	1	PISTON	X				
260	ZF210208	1	SPRING,COMPRESSION	X				
270	ZF160382	1	RING,SPACER	X				
280	ZF210204	1	PIN,CYLINDRICAL	X				
290	ZF180017	1	PIPE	X				
300	Z0634801152	4	RING,SEALING	X				
300	Z0637835033	2	UNION SCREW	X				
310	ZF210580	1	FLANGE,OIL FEED	X				
320	ZF210623	1	PUMP,PRIMARY	X				
330	ZF100323	2	SCREW,CAP	X				
340	ZF210412	7	SCREW,TORX	X				
350	ZF210624	1	RING,INTERMEDIATE	X				
360	ZF210625	1	RING,THRUST	X				
370	ZF100162	3	SCREW,CAP	X				
370	ZF100160	3	WASHER	X				
380	Z0734401270	4	RING,PISTON	X				
382	ZF100324	1	WASHER	X				
384	ZF140159	1	O-RING	X				
390	ZF150134	1	BEARING,BALL	X				
400	ZF100027	3	SCREW,CAP	X				
400	ZF100160	3	WASHER	X				
402	ZF100101	1	SCREW,CAP	X				
402	ZF100160	1	WASHER	X				
404	ZF100027	1	SCREW,CAP	X				
404	ZF100160	1	WASHER	X				
410	ZF100163	3	SCREW,CAP	X				
410	ZF100160	3	WASHER	X				
414	ZF100163	1	SCREW,CAP	X				
414	ZF100160	1	WASHER	X				
420	ZF100159	3	SCREW,CAP	X				
420	ZF100160	3	WASHER	X				
430	ZF100164	3	SCREW,CAP	X				
430	ZF100160	3	WASHER	X				
440	ZF100165	5	SCREW,CAP	X				
440	ZF100160	5	WASHER	X				
650	ZF100170	1	SNAP,RING	X				
660	ZF210218	1	RING,PISTON	X				
670	ZF210219	1	SUPPORT,SUPPORT	X				

https://truckmanualshub.com/

OIL SUPPLY, CONTROL INSERT : DETAIL B (CONT.)

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

OIL SUPPLY, CONTROL INSERT : DETAIL B (CONT.)


NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
650	ZF100170	1	RING,SNAP	X				
660	ZF210218	1	RING,PISTON	X				
670	ZF210219	1	SUPPORT,PISTON	X				
680	ZF210220	1	CAGE,NEEDLE	X				
690	ZF210221	1	RING,INTERNAL	X				
700	ZF100326	1	PIN,SLOT	X				
704	ZF100327	1	PIN,SLOT	X				
710	ZF210583	1	SHAFT,STSTOR	X				
/120	ZF210225	1	BUSH	X				

https://truckmanualshub.com/

OIL SUPPLY, COVER PLATE : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)




https://truckmanualshub.com/

OIL SUPPLY, COVER PLATE : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
500	ZF210616	1	PLATE,COVER	X				
510	ZF140075	1	SEAL,SHAFT	X				
520	ZF140076	1	O-RING	X				
530	ZF180018	1	PIPE	X				
540	ZF100166	2	SCREW,UNION	X				
540	Z0634801152	4	RING,SEALING	X				
550	ZF210215	1	GEAR	X				
560	ZF210216	1	GEAR	X				
570	ZF210217	2	BEARING,ROLLER	X				
580	Z0630503015	2	RING,SNAP	X				
590	ZF100167	2	RING,SNAP	X				
600	ZF100325	13	SCREW,CAP	X				
600	ZF140077	13	RING,SEALING	X				
610	ZF100169	8	SCREW,HEX	X				
610	ZF140077	8	RING,SEALING	X				
620	ZF100110	8	SCREW,HEX	X				
620	ZF140077	8	RING,SEALING	X				
630	ZF100323	1	SCREW,CAP	X				
630	ZF140077	1	RING,SEALING	X				
750	ZF210617	1	PIPE	X				
760	ZF100166	2	SCREW,UNION	X				
760	Z0634801152	4	RING,SEALING	X				
770	ZF210226	2	SHACKLE	X				
780	ZF210227	2	SHEET	X				
790	ZF140160	2	O-RING	X				
800	ZF210584	2	AXLE	X				
810	ZF140079	2	O-RING	X				
820	ZF210229	2	WASHER,THRUST	X				
830	ZF210230	1	PLATE,CLAMPING	X				
840	ZF210231	1	PLATE,CLAMPING	X				
850	ZF100328	2	SCREW,CAP	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	Z4139320085	1	RING,STATOR	X	X			
020	ZF210233	3	SEAT,SPRING	X	X			
030	Z0732041934	3	SPRING,COMPRESSION	X	X			
040	ZF210234	3	DAMPER	X	X			
100	ZF100172	18	SCREW,HEX	X	X			
110	ZF210586	1	ROTOR	X	X			
120	ZF210236	1	RING,PISTON	X	X			
130	ZF140161	1	WASHER,SEALING	X	X			
300	ZF210237	1	SOLENOID	X	X			
370	ZF100173	2	SCREW,HEX	X	X			
370	ZF100128	2	WASHER	X	X			
390	ZF140081	1	O-RING	X	X			
400	ZF210238	1	BUSH	X	X			
410	ZF210239	1	PISTON	X	X			
440	ZF210240	1	SPRING,COMPRESSION	X	X			
460	ZF210241	1	PISTON	X	X			
480	ZF210242	1	PISTON	X	X			
490	ZF160383	1	RING,RETAINING	X	X			
600	ZF210243	1	RESISTOR	X	X			

https://truckmanualshub.com/




P008208

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210244	1	SHAFT,INPUT	X	X			
020	ZF210245	1	SLEEVE,NEEDLE	X	X			
030	ZF210246	1	WASHER,THRUST	X	X			
040	ZF210247	1	SHAFT,QUILL	X	X			
050	ZF210248	2	CAGE,NEEDLE	X	X			
060	ZF210249	1	WASHER,THRUST	X	X			
070	ZF210250	2	CAGE,NEEDLE	X	X			
074	ZF210251	1	WASHER,THRUST	X	X			
080	ZF210252	1	CARRIER,DISC	X	X			
/110	ZF210253	1	DISC CARRIER	X	X			
/120	ZF210254	1	GEAR,SUN	X	X			
/130	ZF210255	1	RING,SNAP	X	X			
/140	ZF210256	1	RING,SNAP	X	X			
090	ZF210257	1	WASHER,THRUST	X	X			
100	ZF210258	1	PLANETARY DRIVE	X	X			
/110	ZF210259	1	CARRIER,PLANET	X	X			
/120	ZF210260	5	PIN,BEARING	X	X			
/130	ZF210261	5	CAGE,NEEDLE	X	X			
/130	ZF210262	A/R	CAGE,NEEDLE	X	X			
/140	ZF210263	1	PLANET GEAR SET	X	X			
/150	ZF210264	10	PLATE,THRUST	X	X			
/160	ZF210265	1	GEAR,RING	X	X			
/170	ZF160384	2	RING,RETAINING	X	X			
110	ZF210266	1	WASHER,THRUST	X	X			
150	ZF210267	1	PLANETARY DRIVE	X	X			
/110	ZF210268	1	CARRIER,PLANET	X	X			
/120	ZF210269	5	PIN,BEARING	X	X			
/122	ZF210270	5	PIN,SLOT	X	X			
/130	ZF210271	10	CAGE,NEEDLE	X	X			
/130	ZF210272	10	CAGE,NEEDLE	X	X			
/140	ZF210273	1	PLANET GEAR SET	X	X			
/150	ZF210274	2	PLATE,THRUST	X	X			
/154	ZF210275	2	PLATE,THRUST	X	X			
/160	ZF210276	1	GEAR,RING	X	X			
/170	ZF160385	1	RING,RETAINING	X	X			
/180	ZF210464	1	GEAR,RING	X	X			
/190	ZF160384	1	RING,RETAINING	X	X			
190	ZF210277	1	WASHER,THRUST	X	X			
200	ZF210278	1	SUN GEAR	X	X			
230	ZF210279	1	CAGE,NEEDLE	X	X			
240	ZF160386	3	WASHER,AXIAL,1.8	X	X			
240	ZF160387	A/R	WASHER,AXIAL,1.5	X	X			
240	ZF160388	A/R	WASHER,AXIAL,1.2	X	X			
240	ZF160389	A/R	WASHER,AXIAL,1.13	X	X			
240	ZF160481	A/R	WASHER,AXIAL,15X28X1	X	X			
248	ZF210280	1	RING	X	X			
250	ZF210281	1	SHAFT,SUN GEAR	X	X			
260	ZF210282	1	RING,INTERNAL	X	X			
268	ZF210283	2	RING,SPLIT	X	X			
270	ZF210284	1	RING,ANGLE	X	X			
280	ZF160390	2	SHIM,1.8	X	X			
280	ZF160391	A/R	SHIM,1.6	X	X			
280	ZF160392	A/R	SHIM,1.4	X	X			
280	ZF160393	A/R	SHIM,1.2	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210285	1	SHAFT,TURBINE	X	X			
020	ZF210286	1	PIPE	X	X			
030	ZF210287	1	SLEEVE,NEEDLE	X	X			
040	ZF210587	1	HUB	X	X			
046	ZF100329	1	WASHER	X	X			
050	ZF160395	1	RING,RETAINING	X	X			
060	ZF210289	3	ROLLER,NEEDLE	X	X			
064	ZF210290	2	PIN	X	X			
070	ZF210588	1	CARRIER,CLUTCH	X	X			
080	ZF140162	1	SEAL,LIP RING	X	X			
090	ZF140163	1	SEAL,LIP RING	X	X			
100	ZF210589	1	PISTON	X	X			
110	ZF210293	1	SPRING,CUP	X	X			
120	ZF210294	1	PLATE,FIXING	X	X			
130	ZF100174	1	RING,SNAP	X	X			
140	ZF210295	1	SPRING,CUP	X	X			
150	ZF210296	1	PLATE,FIXING	X	X			
160	ZF210297	8	I. CLUTCH DISC,2.5	X	X			
160	ZF210298	A/R	I. CLUTCH DISC,2.0	X	X			
170	ZF210299	8	O. CLUTCH DISC	X	X			
180	ZF100175	1	SHIM,END	X	X			
190	ZF210300	2	RING,SPLIT	X	X			
210	ZF140164	1	RING,SEALING	X	X			
230	ZF210590	1	PISTON	X	X			
250	ZF140165	1	RING,SEALING	X	X			
260	ZF210304	1	DISC	X	X			
270	ZF210305	4	O. CLUTCH DISC,2.5	X	X			
270	ZF210306	A/R	O. CLUTCH DISC,2.0	X	X			
280	ZF210307	5	I. CLUTCH DISC	X	X			
300	ZF210591	1	SHIM,END	X	X			
310	ZF210308	9	PIN	X	X			
320	ZF210309	2	PIN	X	X			
330	ZF210310	9	SPRING,COMPRESSION	X	X			
400	ZF200524	3	O. CLUTCH DISC,2.5	X	X			
400	ZF200525	A/R	O. CLUTCH DISC,2.0	X	X			
400	ZF200526	A/R	O. CLUTCH DISC,3.0	X	X			
410	ZF210307	4	I. CLUTCH DISC	X	X			
420	ZF210311	1	DISC	X	X			
430	ZF210308	9	PIN	X	X			
440	ZF140166	1	SEAL,LIP RING	X	X			
450	ZF210592	1	PISTON	X	X			
454	ZF210313	1	RING	X	X			
460	ZF160397	1	RING,RETAINING	X	X			
470	ZF140167	1	SEAL,LIP RING	X	X			
480	ZF140086	1	O-RING	X	X			
490	ZF210557	1	HOUSING,CLUTCH	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210315	1	PISTON	X	X			
020	ZF140084	1	SEAL,LIP RING	X	X			
030	ZF140087	1	SEAL,LIP RING	X	X			
040	ZF210316	1	O. CLUTCH DISC,3.0	X	X			
050	ZF210317	4	I. CLUTCH DISC	X	X			
070	ZF210316	1	O. CLUTCH DISC,3.0	X	X			
070	ZF210318	A/R	O. CLUTCH DISC,2.5	X	X			
070	ZF210319	A/R	O. CLUTCH DISC,2.0	X	X			
070	ZF210320	A/R	O. CLUTCH DISC	X	X			
090	ZF210321	8	PIN	X	X			
100	ZF210322	8	SPRING,COMPRESSION	X	X			
120	ZF160398	1	SHIM,END	X	X			
130	ZF210323	1	RING,SNAP	X	X			
150	ZF210324	1	HOLDER,SPRING	X	X			
160	ZF210325	1	SPRING,CUP	X	X			

https://truckmanualshub.com/




P008211A

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210315	1	PISTON	X	X			
020	ZF140084	1	SEAL,LIP RING	X	X			
030	ZF140087	1	SEAL,LIP RING	X	X			
040	ZF210326	8	PIN	X	X			
050	ZF210327	1	O. CLUTCH DISC,3.0	X	X			
070	ZF210317	7	I. CLUTCH DISC	X	X			
080	ZF210327	6	O. CLUTCH DISC,3.0	X	X			
080	ZF210328	A/R	O. CLUTCH DISC,2.5	X	X			
080	ZF210319	A/R	O. CLUTCH DISC,2.0	X	X			
080	ZF210320	A/R	O. CLUTCH DISC	X	X			
100	ZF210593	1	RING,PRESSURE	X	X			
150	ZF210324	1	HOLDER,SPRING	X	X			
160	ZF210325	1	SPRING,CUP	X	X			

https://truckmanualshub.com/



P008212A


https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210327	6	O. CLUTCH DISC,3.0	X	X			
010	ZF210328	A/R	O. CLUTCH DISC,2.5	X	X			
010	ZF210319	A/R	O. CLUTCH DISC,2.0	X	X			
010	ZF210320	A/R	O. CLUTCH DISC	X	X			
020	ZF210317	7	I. CLUTCH DISC	X	X			
040	ZF210330	1	O. CLUTCH DISC	X	X			
060	ZF210326	8	PIN	X	X			
070	ZF210331	8	SPRING,COMPRESSION	X	X			
080	ZF180020	8	PIPE	X	X			
084	ZF210594	2	SLEEVE	X	X			

https://truckmanualshub.com/

BRAKE - SECTION G : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

BRAKE - SECTION G : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210332	1	GASKET	X	X			
020	ZF210333	1	PISTON	X	X			
030	ZF140088	1	SEAL,LIP RING	X	X			
040	ZF210301	1	RING,PISTON	X	X			
050	ZF210334	1	RING,PISTON	X	X			
060	ZF210335	1	HOUSING,INTERMEDIATE	X	X			
070	ZF210336	1	PIN,SLOT	X	X			
080	ZF120009	2	PLUG,SCREW	X	X			
080	Z0634801063	2	RING,SEALING	X	X			
090	ZF210337	1	O. CLUTCH DISC	X	X			
100	ZF210338	9	O. CLUTCH DISC,2.5	X	X			
110	ZF210339	9	I. CLUTCH DISC	X	X			
120	ZF210338	8	O. CLUTCH DISC,2.5	X	X			
120	ZF210340	A/R	O. CLUTCH DISC,2.0	X	X			
130	ZF210341	1	GEAR,RING	X	X			
140	ZF210342	8	PIN	X	X			
150	ZF210343	8	SPRING,COMPRESSION	X	X			
160	ZF210344	8	PIN,GUIDE	X	X			
170	ZF180021	8	PIPE	X	X			

https://truckmanualshub.com/

BRAKE - SECTION G : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)




https://truckmanualshub.com/

BRAKE - SECTION G : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210332	1	GASKET	X				
020	ZF210333	1	PISTON	X				
030	ZF140088	1	SEAL,LIP RING	X				
040	ZF210301	1	RING,PISTON	X				
050	ZF210334	1	RING,PISTON	X				
060	ZF210335	1	HOUSING,INTERMEDIATE	X				
070	ZF210336	1	PIN,SLOT	X				
080	ZF120009	2	PLUG,SCREW	X				
080	Z0634801063	2	RING,SEALING	X				
090	ZF210626	1	O. CLUTCH DISC	X				
100	ZF210338	9	O. CLUTCH DISC,2.5	X				
110	ZF210339	9	I. CLUTCH DISC	X				
120	ZF210338	8	O. CLUTCH DISC,2.5	X				
120	ZF210340	A/R	O. CLUTCH DISC,2.0	X				
130	ZF210341	1	GEAR,RING	X				
140	ZF210342	8	PIN	X				
150	ZF210343	8	SPRING,COMPRESSION	X				
160	ZF210344	8	PIN,GUIDE	X				
170	ZF180021	8	PIPE	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210595	1	COVER,OUTPUT	X	X			
014	ZF100176	1	PLUG,SCREW	X	X			
014	ZF140089	1	RING,SEALING	X	X			
020	ZF140090	1	SEAL,SHAFT	X	X			
030	ZF210596	1	PISTON	X	X			
040	ZF140088	1	SEAL,LIP RING	X	X			
044	ZF210334	1	RING,PISTON	X	X			
050	ZF210332	1	GASKET	X	X			
060	ZF100177	24	SCREW,HEXAGON	X	X			
060	Z0630001048	24	WASHER	X	X			
114	ZF100178	2	SCREW,HEXAGON	X	X			
114	Z0630001048	2	WASHER	X	X			
190	ZF210347	1	RING,THRUST	X	X			
200	ZF210348	1	PLANETARY DRIVE	X	X			
/110	ZF210349	1	PLANET CARRIER	X	X			
/120	ZF210350	6	PIN,BEARING	X	X			
/130	ZF210351	6	CAGE,ROLLER	X	X			
/140	ZF210352	1	PLANET GEAR SET	X	X			
/150	ZF210353	24	WASHER,THRUST,1.0	X	X			
/160	ZF210270	6	PIN,SLOT	X	X			
/200	ZF150132	1	SLEEVE,NEEDLE	X	X			
/210	ZF210355	4	PIN,BEARING	X	X			
/220	ZF210356	8	CASE,NEEDLE	X	X			
/230	ZF210357	1	PLANET GEAR SET	X	X			
/240	ZF210358	16	WASHER,THRUST	X	X			
/250	ZF210270	4	PIN,SLOT	X	X			
220	ZF210359	1	BEARING,TAPPER ROLLER	X	X			
222	ZF100330	1	WASHER	X	X			
230	ZF210360	1	BUSH,45.00	X	X			
250	ZF160399	1	SHIM,1.20	X	X			
250	ZF160400	A/R	SHIM,1.15	X	X			
250	ZF160401	A/R	SHIM,1.10	X	X			
250	ZF160402	A/R	SHIM,1.05	X	X			
250	ZF160403	A/R	SHIM,1.00	X	X			
250	ZF160404	A/R	SHIM,0.95	X	X			
250	ZF160405	A/R	SHIM,0.90	X	X			
250	ZF160406	A/R	SHIM,0.85	X	X			
250	ZF160407	A/R	SHIM,0.80	X	X			
250	ZF160408	A/R	SHIM,0.60	X	X			
250	ZF160409	A/R	SHIM,0.40	X	X			
260	ZF160410	1	BEARING,TAPER ROLLER	X	X			
300	ZF160411	1	FLANGE,OUTPUT	X	X			
310	ZF100179	1	WASHER	X	X			
320	ZF100180	1	WASHER,TAB	X	X			
330	ZF100331	2	SCREW,HEX	X	X			
358	ZF100176	1	PLUG,SCREW	X	X			
358	ZF140089	1	RING,SEALING	X	X			
380	ZF210361	1	TRANSMITTER,INDUCTION	X	X			
380	ZF160412	A/R	SHIM,6.00	X	X			
380	ZF160413	A/R	SHIM,5.80	X	X			
380	ZF160414	A/R	SHIM,5.60	X	X			
380	ZF160415	A/R	SHIM,5.40	X	X			
380	ZF160416	A/R	SHIM,5.20	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
380	ZF160417	A/R	SHIM,5.00	X	X			
380	ZF160418	A/R	SHIM,4.80	X	X			
380	ZF160419	A/R	SHIM,4.60	X	X			
380	ZF160420	A/R	SHIM,4.40	X	X			
380	ZF160421	A/R	SHIM,4.20	X	X			
380	ZF160422	A/R	SHIM,4.00	X	X			
380	ZF160423	A/R	SHIM,3.80	X	X			
380	ZF160424	A/R	SHIM,3.60	X	X			
380	ZF160425	A/R	SHIM,3.20	X	X			
380	ZF160426	A/R	SHIM,3.00	X	X			
380	ZF160427	A/R	SHIM,2.90	X	X			
380	ZF160428	A/R	SHIM,2.80	X	X			
380	ZF160429	A/R	SHIM,2.70	X	X			
380	ZF160430	A/R	SHIM,2.60	X	X			
380	ZF160431	A/R	SHIM,2.50	X	X			
380	ZF160432	A/R	SHIM,2.40	X	X			
380	ZF160433	A/R	SHIM,2.20	X	X			
380	ZF160434	A/R	SHIM,2.10	X	X			
380	ZF160435	A/R	SHIM,2.00	X	X			
380	ZF160436	A/R	SHIM,1.90	X	X			
380	ZF160437	A/R	SHIM,1.80	X	X			
380	ZF160438	A/R	SHIM,1.70	X	X			
380	ZF160439	A/R	SHIM,1.60	X	X			
380	ZF160440	A/R	SHIM,1.50	X	X			
380	ZF160441	A/R	SHIM,1.40	X	X			
380	ZF160442	A/R	SHIM,1.30	X	X			
380	ZF160443	A/R	SHIM,1.20	X	X			
380	ZF160444	A/R	SHIM,1.00	X	X			
380	ZF160445	A/R	SHIM,0.80	X	X			
380	ZF210362	1	SCREW,TORX	X	X			
380	ZF140091	1	O-RING	X	X			
400	ZF210363	1	CABLE CONNECT	X	X			
410	ZF210364	1	COVER	X	X			
420	ZF140168	1	O-RING,40X3	X	X			
430	ZF100182	2	STUD	X	X			
430	ZF100183	2	WASHER	X	X			
430	ZF100184	2	NUT,HEX	X	X			
440	ZF100185	1	PLUG	X	X			
454	ZF100176	1	PLUG,SCREW	X	X			
454	ZF140089	1	RING,SEALING	X	X			
464	ZF100176	1	SCREW,PLUG	X	X			
464	ZF140089	1	RING,SEALING	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210365	1	PLATE,DUCT	X	X			
020	ZF210366	1	VALVE,DRAIN	X	X			
022	ZF210367	1	SHEET,SPRING	X	X			
024	ZF210368	1	SCREW,TORX	X	X			
030	ZF210369	1	PLATE,INTERMEDIATE	X	X			
058	ZF210598	1	VALVE BLOCK	X	X			
060	ZF210391	1	PLATE,COVER	X	X			
070	ZF210358	15	SCREW,TORX	X	X			
100	ZF210392	1	BALL,5MM	X	X			
110	ZF210393	1	GASKET	X	X			
128	ZF210602	1	VALVE BLOCK	X	X			
130	ZF210398	1	PLATE,COVER	X	X			
150	ZF210388	7	SCREW,TORX	X	X			
160	ZF210399	1	SCREW,TORX	X	X			
180	ZF210400	1	GASKET	X	X			
240	ZF210401	1	VALVE,THROTTLE	X	X			
290	ZF210388	5	SCREW,TORX	X	X			
290	ZF210399	1	SCREW,TORX	X	X			
310	ZF210408	1	WIRING HARNESS	X	X			
/200	ZF210568	1	SENSOR,TEMP	X	X			
340	ZF210409	1	VALVE,CONVERTER	X	X			
344	ZF210410	1	RING,SNAP	X	X			
590	ZF210411	4	MAGNET	X	X			
600	ZF100333	1	PLUG,SCREW	X	X			
610	ZF210412	24	SCREW,TORX	X	X			
620	ZF210413	9	SCREW,TORX	X	X			
630	ZF210412	6	SCREW,TORX	X	X			
640	ZF210361	1	TRANSMITTER,INDUCTION	X	X			
640	ZF160412	A/R	WASHER,6.00	X	X			
640	ZF160413	A/R	WASHER,5.80	X	X			
640	ZF160414	A/R	WASHER,5.60	X	X			
640	ZF160415	A/R	WASHER,5.40	X	X			
640	ZF160416	A/R	WASHER,5.20	X	X			
640	ZF160417	A/R	WASHER,5.00	X	X			
640	ZF160418	A/R	WASHER,4.80	X	X			
640	ZF160419	A/R	WASHER,4.60	X	X			
640	ZF160420	A/R	WASHER,4.40	X	X			
640	ZF160421	A/R	WASHER,4.20	X	X			
640	ZF160422	A/R	WASHER,4.00	X	X			
640	ZF160423	A/R	WASHER,3.80	X	X			
640	ZF160424	A/R	WASHER,3.60	X	X			
640	ZF160425	A/R	WASHER,3.20	X	X			
640	ZF160426	A/R	WASHER,3.00	X	X			
640	ZF160427	A/R	WASHER,2.90	X	X			
640	ZF160428	A/R	WASHER,2.80	X	X			
640	ZF160429	A/R	WASHER,2.70	X	X			
640	ZF160430	A/R	WASHER,2.60	X	X			
640	ZF160431	A/R	WASHER,2.50	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
640	ZF160432	A/R	WASHER,2.40	X	X			
640	ZF160433	A/R	WASHER,2.20	X	X			
640	ZF160434	A/R	WASHER,2.10	X	X			
640	ZF160435	A/R	WASHER,2.00	X	X			
640	ZF160436	A/R	WASHER,1.90	X	X			
640	ZF160437	A/R	WASHER,1.80	X	X			
640	ZF160438	A/R	WASHER,1.70	X	X			
640	ZF160439	A/R	WASHER,1.60	X	X			
640	ZF160440	A/R	WASHER,1.50	X	X			
640	ZF160441	A/R	WASHER,1.40	X	X			
640	ZF160442	A/R	WASHER,1.30	X	X			
640	ZF160443	A/R	WASHER,1.20	X	X			
640	ZF160444	A/R	WASHER,1.00	X	X			
640	ZF160445	A/R	WASHER,0.80	X	X			
650	ZF210362	1	SCREW,TORX	X	X			
660	ZF140091	1	O-RING,4X1.5	X	X			
670	ZF100117	2	SCREW,HEX	X	X			
670	ZF100128	2	WASHER	X	X			
800	ZF210414	1	VALVE BLOCK	X	X			
810	ZF210399	7	SCREW,TORX	X	X			

https://truckmanualshub.com/

SHIFT CONTROL, VALVE BLOCK A : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

SHIFT CONTROL, VALVE BLOCK A : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
058	ZF210598	1	VALVE BLOCK	X	X			
/010	ZF210599	1	VALVE BLOCK	X	X			
/020	ZF210372	4	PISTON	X	X			
/040	ZF210373	1	SPRING,COMPRESSION	X	X			
/042	ZF210374	1	SPRING,COMPRESSION	X	X			
/044	ZF210375	1	SPRING,COMPRESSION	X	X			
/045	ZF210375	1	SPRING,COMPRESSION	X	X			
/050	ZF100186	4	WASHER	X	X			
/060	ZF210376	4	PISTON	X	X			
/070	ZF210377	1	GASKET	X	X			
/080	ZF210378	1	PLATE,COVER	X	X			
/090	ZF210368	9	SCREW,TORX	X	X			
/110	ZF210600	1	STRIP,VALVE	X	X			
/120	ZF140093	1	O-RING	X	X			
/130	ZF210380	12	BALL	X	X			
/140	ZF210381	4	BUSH	X	X			
/150	ZF140094	4	O-RING	X	X			
/160	ZF210382	4	PIN	X	X			
/170	ZF100187	4	WASHER	X	X			
/172	Z0630502228	4	RING,RETAINING	X	X			
/180	ZF210383	4	PISTON	X	X			
/200	ZF120006	1	ORIFICE,0.8	X	X			
/202	ZF120034	1	ORIFICE,0.7	X	X			
/204	ZF120035	1	ORIFICE,1.00	X	X			
/206	ZF120006	1	ORIFICE,0.8	X	X			
/210	ZF100115	4	SPRING,COMPRESSION	X	X			
/220	ZF210384	1	GASKET	X	X			
/230	ZF210385	1	PLATE,COVER	X	X			
/240	ZF210386	4	PISTON	X	X			
/250	ZF210387	4	SPRING,COMPRESSION	X	X			
/280	ZF210388	5	SCREW,TORX	X	X			
/290	ZF210368	11	SCREW,TORX	X	X			
/310	ZF210601	4	VALVE,SOLENOID	X	X			
/320	ZF100026	8	SCREW,CAP	X	X			
/320	ZF100332	8	WASHER	X	X			

https://truckmanualshub.com/

SHIFT CONTROL, VALVE BLOCK A : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

SHIFT CONTROL, VALVE BLOCK A : DETAIL B


NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	ZF210598	1	VALVE BLOCK	X				
010	ZF210599	1	VALVE BLOCK	X				
020	ZF210372	4	PISTON	X				
040	ZF210373	1	SPRING,COMPRESSION	X				
042	ZF210374	1	SPRING,COMPRESSION	X				
044	ZF210375	1	SPRING,COMPRESSION	X				
046	ZF210375	1	SPRING,COMPRESSION	X				
050	ZF100186	4	WASHER	X				
060	ZF210376	4	PISTON	X				
070	ZF210377	1	GASKET	X				
080	ZF210378	1	PLATE,COVER	X				
090	ZF210368	9	SCREW,TORX	X				
110	ZF210627	1	STRIP,VALVE	X				
120	ZF140093	1	O-RING	X				
130	ZF210380	12	BALL	X				
140	ZF210381	4	BUSH	X				
150	ZF140094	4	O-RING	X				
160	ZF210382	4	PIN	X				
170	ZF100187	4	WASHER	X				
172	Z0630502228	4	RING,RETAINING	X				
180	ZF210383	4	PISTON	X				
200	ZF120006	1	ORIFICE,0.8	X				
202	ZF120034	1	ORIFICE,0.7	X				
204	ZF120035	1	ORIFICE,1.00	X				
206	ZF120006	1	ORIFICE,0.8	X				
210	ZF100115	4	SPRING,COMPRESSION	X				
220	ZF210384	1	GASKET	X				
230	ZF210385	1	PLATE,COVER	X				
240	ZF210386	4	PISTON	X				
250	ZF210387	4	SPRING,COMPRESSION	X				
280	ZF210388	5	SCREW,TORX	X				
290	ZF210368	11	SCREW,TORX	X				
310	ZF210601	4	VALVE,SOLENOID	X				
320	ZF100026	8	SCREW,CAP	X				
320	ZF100332	8	WASHER	X				

https://truckmanualshub.com/

SHIFT CONTROL, VALVE BLOCK B : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

SHIFT CONTROL, VALVE BLOCK B : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
128	ZF210602	1	VALVE BLOCK	X	X			
/110	ZF210603	1	VALVE BLOCK	X	X			
/120	ZF210372	3	PISTON	X	X			
/124	ZF210372	1	PISTON	X	X			
/150	ZF210395	3	STOP	X	X			
/160	ZF210396	1	SPRING,COMPRESSION	X	X			
/170	ZF210396	1	SPRING,COMPRESSION	X	X			
/180	ZF210396	1	SPRING,COMPRESSION	X	X			
/190	ZF210373	1	SPRING,COMPRESSION	X	X			
/200	ZF100186	3	WASHER	X	X			
/210	ZF100186	1	WASHER	X	X			
/220	ZF210376	3	PISTON	X	X			
/230	ZF210376	1	PISTON	X	X			
/234	ZF210377	1	GASKET	X	X			
/240	ZF210378	1	PLATE,COVER	X	X			
/250	ZF210368	9	SCREW,TORX	X	X			
/260	ZF210604	1	VALVE STRIP	X	X			
/270	ZF140093	1	O-RING	X	X			
/280	ZF210380	12	BALL	X	X			
/290	ZF210397	3	BUSH	X	X			
/300	ZF210397	1	BUSH	X	X			
/310	ZF140094	3	O-RING	X	X			
/320	ZF140094	1	O-RING	X	X			
/330	ZF210382	3	PIN	X	X			
/340	ZF210382	1	PIN	X	X			
/350	ZF100187	3	WASHER	X	X			
/360	ZF100187	1	WASHER	X	X			
/370	Z0630502228	3	RING,RETAINING	X	X			
/380	Z0630502228	1	RING,RETAINING	X	X			
/390	ZF210383	3	PISTON	X	X			
/400	ZF210383	1	PISTON	X	X			
/402	ZF120006	1	ORIFICE,0.8	X	X			
/404	ZF120006	1	ORIFICE,0.8	X	X			
/406	ZF120006	1	ORIFICE,0.8	X	X			
/408	ZF120006	1	ORIFICE,0.8	X	X			
/410	ZF100115	3	SPRING,COMPRESSION	X	X			
/420	ZF100115	1	SPRING,COMPRESSION	X	X			
/430	ZF210386	3	PISTON	X	X			
/440	ZF210386	1	PISTON	X	X			
/450	ZF210387	3	SPRING,COMPRESSION	X	X			
/460	ZF210387	1	SPRING,COMPRESSION	X	X			
/464	ZF210384	1	GASKET	X	X			
/470	ZF210385	1	PLATE,COVER	X	X			
/490	ZF210388	5	SCREW,TORX	X	X			
/510	ZF210368	11	SCREW,TORX	X	X			
/520	ZF210601	3	VALVE,SOLENOID	X	X			
/530	ZF100026	6	SCREW,CAP	X	X			
/530	ZF100332	6	WASHER	X	X			
/540	ZF210601	1	VALVE,SOLENOID	X	X			
/580	ZF100026	2	SCREW,CAP	X	X			
/580	ZF100332	2	WASHER	X	X			

https://truckmanualshub.com/

SHIFT CONTROL, VALVE BLOCK B : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)




https://truckmanualshub.com/

SHIFT CONTROL, VALVE BLOCK B : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	ZF210602	1	VALVE BLOCK	X				
110	ZF210603	1	VALVE BLOCK	X				
120	ZF210372	3	PISTON	X				
124	ZF210372	1	PISTON	X				
150	ZF210395	3	STOP	X				
160	ZF210396	1	SPRING,COMPRESSION	X				
170	ZF210396	1	SPRING,COMPRESSION	X				
180	ZF210396	1	SPRING,COMPRESSION	X				
190	ZF210373	1	SPRING,COMPRESSION	X				
200	ZF100186	3	WASHER	X				
210	ZF100186	1	WASHER	X				
220	ZF210376	3	PISTON	X				
230	ZF210376	1	PISTON	X				
234	ZF210377	1	GASKET	X				
240	ZF210378	1	PLATE,COVER	X				
250	ZF210368	9	SCREW,TORX	X				
260	ZF210627	1	VALVE STRIP	X				
270	ZF140093	1	O-RING	X				
280	ZF210380	12	BALL	X				
290	ZF210397	3	BUSH	X				
300	ZF210397	1	BUSH	X				
310	ZF140094	3	O-RING	X				
320	ZF140094	1	O-RING	X				
330	ZF210382	3	PIN	X				
340	ZF210382	1	PIN	X				
350	ZF100187	3	WASHER	X				
360	ZF100187	1	WASHER	X				
370	Z0630502228	3	RING,RETAINING	X				
380	Z0630502228	1	RING,RETAINING	X				
390	ZF210383	3	PISTON	X				
400	ZF210383	1	PISTON	X				
402	ZF120006	1	ORIFICE,0.8	X				
404	ZF120006	1	ORIFICE,0.8	X				
406	ZF120006	1	ORIFICE,0.8	X				
408	ZF120006	1	ORIFICE,0.8	X				
410	ZF100115	3	SPRING,COMPRESSION	X				
420	ZF100115	1	SPRING,COMPRESSION	X				
430	ZF210386	3	PISTON	X				
440	ZF210386	1	PISTON	X				
450	ZF210387	3	SPRING,COMPRESSION	X				
460	ZF210387	1	SPRING,COMPRESSION	X				
464	ZF210384	1	GASKET	X				
470	ZF210385	1	PLATE,COVER	X				
490	ZF210388	5	SCREW,TORX	X				
510	ZF210368	11	SCREW,TORX	X				
520	ZF210601	3	VALVE,SOLENOID	X				
530	ZF100026	6	SCREW,CAP	X				
530	ZF100332	6	WASHER	X				
540	ZF210601	1	VALVE,SOLENOID	X				
580	ZF100026	2	SCREW,CAP	X				
580	ZF100332	2	WASHER	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
240	ZF210401	1	VALVE BLOCK	X	X			
/110	ZF210402	1	VALVE BLOCK	X	X			
/120	ZF210403	1	PISTON	X	X			
/130	ZF210404	1	PISTON	X	X			
/140	ZF210605	1	SPRING,COMPRESSION	X	X			
/160	ZF210406	1	PLATE,FIXING	X	X			
/180	ZF210407	1	SOLENOID	X	X			
/190	ZF210390	2	SCREW,TORX	X	X			
/200	ZF210601	1	VALVE,SOLENOID	X	X			
/210	ZF100390	2	SCREW,CAP	X	X			
/210	ZF100026	2	WASHER	X	X			
/220	ZF210414	1	VALVE BLOCK	X	X			
/110	ZF210415	1	HOUSING,VALVE	X	X			
/120	ZF210416	1	PISTON	X	X			
/130	ZF210605	1	SPRING,COMPRESSION	X	X			
/140	ZF120014	1	PLUG,SCREW	X	X			
/140	Z0634801045	1	RING,SEALING	X	X			

https://truckmanualshub.com/

TRANSMISSION DIPSTICK : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

TRANSMISSION DIPSTICK : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210417	1	TUBE,FILLER	X	X			
014	ZF210418	1	TAPE,SEALING	X	X			
060	ZF100189	1	NUT,SLOTTED	X	X			
200	ZF210606	1	DIPSTICK,OIL	X	X			

https://truckmanualshub.com/

TRANSMISSION DIPSTICK : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)



TD0005064


https://truckmanualshub.com/

TRANSMISSION DIPSTICK : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210417	1	TUBE,FILLER	X				
014	ZF210418	1	TAPE,SEALING	X				
060	ZF100189	1	NUT,SLOTTED	X				
200	ZF210629	1	DIPSTICK,OIL	X				

https://truckmanualshub.com/



https://truckmanualshub.com/


TRANSMISSION OIL SUMP

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
500	ZF210607	1	OIL SUMP	X	X			
510	ZF210422	1	GASKET	X	X			
520	ZF100190	25	HEXAGON SCREW	X	X			
520	ZF100128	25	WASHER	X	X			
530	ZF100191	10	HEXAGON SCREW	X	X			
530	ZF100128	10	WASHER	X	X			
540	ZF100190	2	HEXAGON SCREW	X	X			
540	ZF140077	2	SEALING RING	X	X			
550	ZF100192	1	SCREW PLUG	X	X			
550	ZF140095	1	SEALING RING	X	X			
560	ZF140096	1	O-RING	X	X			
570	ZF210423	1	SUCTION TUBE	X	X			
572	ZF100193	1	TAB WASHER	X	X			
574	ZF100018	2	HEXAGON SCREW	X	X			
580	ZF210424	1	SCREEN,SUCTION	X	X			
590	ZF140097	1	O-RING	X	X			
600	ZF210425	1	COVER	X	X			

https://truckmanualshub.com/

TORQUE CONVERTER : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

TORQUE CONVERTER : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
500	ZF210608	1	CONVERTER,TORQUE	X	X			
/010	ZF210609	1	TURBINE WHEEL	X	X			
/050	ZF210444	1	BEARING,ROLLER	X	X			
/060	ZF210441	1	STATOR	X	X			
/070	ZF100199	2	WASHER	X	X			
/080	ZF210442	1	RING,FREE WHEEL	X	X			
/090	ZF150133	2	BEARING,BALL	X	X			
/120	ZF210443	16	ROLLER	X	X			
/130	ZF210445	1	PUMP,WHEEL	X	X			
/140	ZF210610	1	COVER,CIRCUIT	X	X			
/142	ZF210446	2	PIN,CYLINDERICAL	X	X			
/150	ZF210611	1	PLATE,PISTON	X	X			
/152	ZF210430	1	CUP,SPRING	X	X			
/160	ZF200527	2	I.CLUTCH DISC	X	X			
/170	ZF200528	2	O.CLUTCH DISC,3.5	X	X			
/170	ZF200529	A/R	O.CLUTCH DISC,4.0	X	X			
/174	ZF210612	12	PIN,CYLINDERICAL	X	X			
/180	ZF210613	1	SHIM,END	X	X			
/190	ZF140169	1	RING,SEALING	X	X			
/200	ZF140170	1	RING,SEALING	X	X			
/230	ZF210435	1	RING,PISTON	X	X			
/240	ZF100334	12	SCREW,CAP	X	X			
/250	ZF140099	1	O-RING	X	X			
/260	Z0750116266	1	BEARING,BALL	X	X			
/270	ZF210614	1	WASHER	X	X			
/280	ZF210438	1	CAGE,NEEDLE	X	X			
/290	ZF210437	1	HOUSING,DISC	X	X			
/310	ZF100200	36	SCREW,CAP	X	X			
/310	ZF100201	36	WASHER	X	X			

https://truckmanualshub.com/

TORQUE CONVERTER : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

TORQUE CONVERTER : DETAIL B


NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
020	ZF100195	1	PLUG,SCREW	X				
020	ZF140098	1	RING,SEALING	X				
150	ZF100197	1	SCREW,CAP	X				
170	ZF160456	1	SHIM,1.00	X				
170	ZF160455	A/R	SHIM,1.10	X				
170	ZF160454	A/R	SHIM,1.20	X				
170	ZF160453	A/R	SHIM,1.50	X				
170	ZF160452	A/R	SHIM,1.70	X				
170	ZF160451	A/R	SHIM,1.80	X				
170	ZF160450	A/R	SHIM,1.90	X				
170	ZF160449	A/R	SHIM,2.00	X				
170	ZF160448	A/R	SHIM,2.50	X				
170	ZF160447	A/R	SHIM,2.60	X				
450	ZF100338	1	WASHER,0.50	X				
450	ZF100337	A/R	WASHER,0.80	X				
450	ZF100202	A/R	WASHER,1.00	X				
500	ZF210628	1	CONVERTER,TORQUE	X				
/010	ZF210609	1	TURBINE WHEEL	X				
/050	ZF210444	1	BEARING,ROLLER	X				
/060	ZF210441	1	STATOR	X				
/070	ZF100199	2	WASHER	X				
/080	ZF210442	1	RING,FREE WHEEL	X				
/090	ZF150133	2	BEARING,BALL	X				
/120	ZF210443	16	ROLLER	X				
/130	ZF210445	1	PUMP,WHEEL	X				
/140	ZF210610	1	COVER,CIRCUIT	X				
/142	ZF210446	2	PIN,CYLINDERICAL	X				
/150	ZF210611	1	PLATE,PISTON	X				
/152	ZF210430	1	CUP,SPRING	X				
/160	ZF200527	2	I.CLUTCH DISC	X				
/170	ZF200528	2	O.CLUTCH DISC,3.5	X				
/170	ZF200529	A/R	O.CLUTCH DISC,4.0	X				
/174	ZF210612	12	PIN,CYLINDERICAL	X				
/180	ZF210613	1	SHIM,END	X				
/190	ZF140169	1	RING,SEALING	X				
/200	ZF140170	1	RING,SEALING	X				
/230	ZF210435	1	RING,PISTON	X				
/240	ZF100334	12	SCREW,CAP	X				
/250	ZF140099	1	O-RING	X				
/260	Z0750116266	1	BEARING,BALL	X				
/270	ZF210614	1	WASHER	X				
/280	ZF210438	1	CAGE,NEEDLE	X				
/290	ZF210437	1	HOUSING,DISC	X				
/310	ZF100200	36	SCREW,CAP	X				
/310	ZF100201	36	WASHER	X				

https://truckmanualshub.com/

POWER TAKE OFF : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

POWER TAKE OFF : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210447	1	HOUSING	X	X			
012	ZF210448	2	PIN,CYLINDRICAL	X	X			
020	ZF210193	1	GASKET	X	X			
030	ZF100203	3	SCREW,HEXAGON	X	X			
040	ZF100203	2	SCREW,HEXAGON	X	X			
040	Z0630001048	2	WASHER	X	X			
200	ZF210449	1	BEARING,ROLLER,50X90X23	X	X			
210	ZF210450	1	COVER,SHEET	X	X			
220	ZF210451	1	GEAR	X	X			
230	ZF210452	1	BEARING,BALL	X	X			
240	ZF160468	1	SHIM,RING,90X110X2	X	X			
240	ZF160469	A/R	SHIM,RING,90X110X1.8	X	X			
240	ZF160470	A/R	SHIM,RING,90X110X1.6	X	X			
240	ZF160471	A/R	SHIM,RING,90X110X1.4	X	X			
240	ZF160472	A/R	SHIM,RING,90X110X1.2	X	X			
240	ZF160473	A/R	SHIM,RING,90X110X1.1	X	X			
240	ZF160474	A/R	SHIM,RING,90X110X1.0	X	X			
240	ZF160475	A/R	SHIM,RING,90X110X0.5	X	X			
240	ZF160476	A/R	SHIM,RING,90X110X0.3	X	X			
240	ZF160477	A/R	SHIM,RING,90X110X0.2	X	X			
240	ZF160478	A/R	SHIM,RING,90X110X0.1	X	X			
540	ZF210465	1	FLANGE,BEARING	X	X			
550	ZF100204	5	SCREW,CAP	X	X			
570	ZF160479	1	RING,RETAINING	X	X			
590	ZF140100	1	O-RING	X	X			
594	ZF140101	1	O-RING	X	X			
800	ZF210457	1	PLATE,TYPE	X	X			
810	ZF100004	2	STUD,GROOVED	X	X			

https://truckmanualshub.com/

POWER TAKE OFF : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)




https://truckmanualshub.com/

POWER TAKE OFF : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210447	1	HOUSING	X				
012	ZF210448	2	PIN,CYLINDRICAL	X				
020	ZF210193	1	GASKET	X				
030	ZF100203	5	SCREW,HEXAGON	X				
030	Z0630001048	5	WASHER	X				
200	ZF210449	1	BEARING,ROLLER,50X90X23	X				
210	ZF210450	1	COVER,SHEET	X				
220	ZF210451	1	GEAR	X				
230	ZF210452	1	BEARING,BALL	X				
240	ZF160468	1	SHIM,RING,90X110X2	X				
240	ZF160469	A/R	SHIM,RING,90X110X1.8	X				
240	ZF160470	A/R	SHIM,RING,90X110X1.6	X				
240	ZF160471	A/R	SHIM,RING,90X110X1.4	X				
240	ZF160472	A/R	SHIM,RING,90X110X1.2	X				
240	ZF160473	A/R	SHIM,RING,90X110X1.1	X				
240	ZF160474	A/R	SHIM,RING,90X110X1.0	X				
240	ZF160475	A/R	SHIM,RING,90X110X0.5	X				
240	ZF160476	A/R	SHIM,RING,90X110X0.3	X				
240	ZF160477	A/R	SHIM,RING,90X110X0.2	X				
240	ZF160478	A/R	SHIM,RING,90X110X0.1	X				
540	ZF210465	1	FLANGE,BEARING	X				
550	ZF100204	5	SCREW,CAP	X				
570	ZF160479	1	RING,RETAINING	X				
590	ZF140100	1	O-RING	X				
594	ZF140176	1	O-RING	X				
600	ZF160480	1	RING,RETAINING	X				
604	ZF210453	1	RING,SNAP	X				
610	ZF210454	1	BUSH	X				
624	ZF140102	1	O-RING	X				
630	ZF210455	1	FLANGE,INTERMEDIATE	X				
640	ZF100335	6	SCREW,CAP	X				
800	ZF210457	1	PLATE,TYPE	X				
810	ZF100004	2	STUD,GROOVED	X				

https://truckmanualshub.com/



P008326B


https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF210458	1	GASKET	X	X			
012	ZF140103	2	O-RING	X	X			
014	ZF210459	1	INSERT	X	X			
016	ZF210460	1	INSERT	X	X			
020	ZF210558	1	ADAPTOR CONNECTOR	X	X			INCLUDES ITEMS 114
050	ZF100190	1	SCREW,HEX	X	X			
050	ZF100128	1	WASHER	X	X			
056	ZF100190	1	SCREW,HEX	X	X			
056	ZF100128	1	WASHER	X	X			
062	ZF100190	1	SCREW,HEX	X	X			
062	ZF100128	1	WASHER	X	X			
068	ZF100190	1	SCREW,HEX	X	X			
068	ZF100128	1	WASHER	X	X			
080	ZF100190	1	SCREW,HEX	X	X			
080	ZF100128	1	WASHER	X	X			
086	ZF100190	1	SCREW,HEX	X	X			
086	ZF100128	1	WASHER	X	X			
100	ZF120004	1	PLUG,SCREW	X	X			
100	ZF140070	1	RING,SEALING	X	X			
110	ZF100206	1	PLUG,SCREW	X	X			
110	Z0634801063	1	RING,SEALING	X	X			
114	ZF210559	1	PLUG,SCREW	X	X			
114	ZF140069	1	SEALING RING	X	X			
120	ZF120005	1	PLUG,SCREW	X	X			
120	Z0634801151	1	RING,SEALING	X	X			
124	ZF210462	1	SENSOR,TEMPERATURE	X	X			
124	Z0634801151	1	RING,SEALING	X	X			
150	ZF210463	2	UNION,PIPE	X	X			
150	ZF140104	2	RING,SEALING	X	X			

https://truckmanualshub.com/

PERIPHERALS : DETAIL A

NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)



https://truckmanualshub.com/

PERIPHERALS : DETAIL A


NOTE: USED WITH OM906LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
120	206345	1	SELECTOR,SHIFT	X	X			
/390	ZF210188	1	PLATE,SELECTOR INDICATOR	X	X			
150	206336	1	HARNESS	X	X			
164	206337	1	HARNESS	X	X			
540	ZF210190	1	LEVER,ZF RETARDER,6 POSITION	X	X			

https://truckmanualshub.com/

PERIPHERALS : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)




https://truckmanualshub.com/

PERIPHERALS : DETAIL B

NOTE: USED WITH OM926LA ENGINE (REFER TO SIB 2010/1027)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
120	206345	1	SELECTOR,SHIFT	X				
/390	ZF210188	1	PLATE,SELECTOR INDICATOR	X				
150	216653	1	HARNESS	X				
164	216654	1	HARNESS	X				

https://truckmanualshub.com/




TD0003180
E14832411 - B

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	243884	1	HOSE	X	X			
2	243883	1	HOSE	X	X			
3	207123	2	SPACER,CLAMP,ALU	X	X			
4	207092	1	CLAMP,RUBBER,4,TRAN HOSES	X	X			
5	207017	2	CLAMP,ALUM,2 BOLT	X	X			
6	203681	6	P-CLIP,50MM	X	X			
7	120237	4	FLANGE,HALF	X	X			
8	100548	4	WASHER,HARDENED	X	X			
9	100312	4	NUT,NYLOC	X	X			
10	100225	8	CAPSCREW,SOCHD	X	X			
11	100200	2	BOLT,HEXHD	X	X			
12	100198	2	SCREW,HEXHD	X	X			
13	100083	2	SCREW,HEXHD	X	X			
14	100062	6	WASHER,FLAT	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	250192	1	T/CASE,13100	X	X			
2	223816	1	FILTER,FUEL	X	X			
3	204483	8	MTG,T/BOX SPLIT	X	X			
4	200062	2	CLAMP,HOSE	X	X			
5	186889	1	BKT,BREATHER,TRANSFER CASE	X	X			
6	174756	8	SHIM,DROP BOX MTG	X	X			
7	162404	2	WASHER	X	X			
8	130001	1	HOSE,PUSHLOCK	X	X			
9	121275	1	MALE-8,M20,TAIL,90 DEG,PCT-M20	X	X			
10	120161	1	ADAPTOR,BARBED HOSE	X	X			
11	100698	2	BOLT,HEXHD	X	X			
12	100532	6	WASHER,HARDENED	X	X			
13	100323	2	NUT,NYLOC	X	X			
14	100165	2	BOLT,HEXHD	X	X			
15	100080	2	SCREW,HEXHD	X	X			
16	100061	2	WASHER,FLAT	X	X			

https://truckmanualshub.com/




P008267

https://truckmanualshub.com/

DROP BOX MOUNTINGS

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	181527	2	MOUNTING,T/CASE,TOP BRACKET	X	X			
2	161221	2	MOUNTING,T/CASE,LOWER	X	X			
3	100212	14	SCREW,HEXHD	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

DROP BOX HOUSING

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	224428	1	HOUSING,M/C	X	X			
3	224425	1	HOUSING,CLUTCH M/C	X	X			
4	224208	1	HOUSING,BEARING REAR	X	X			
43	224254	1	PLUG,MAGNETIC DRAIN	X	X			
44	120396	2	PLUG,CLOSURE HEX SOCKET HD	X	X			
45	224368	1	PLUG	X	X			
46	DC140060	1	WASHER,SEALING	X	X			
47	DC140072	4	WASHER,SEALING	X	X			
50	224257	1	BOLT,EYE	X	X			
76	226661	1	GLASS,SIGHT-BOROSILICATE-S/IN	X	X			
100	225245	3	PLUG,SCREW	X	X			
101	224427	14	INSERT,THREADED	X	X			
102	225262	44	HELICOIL,HCM10X1,5D	X	X			
103	224373	1	MAGNET	X	X			

https://truckmanualshub.com/

DROP BOX INPUT SHAFT




https://truckmanualshub.com/

DROP BOX INPUT SHAFT

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
7	224211	1	FRONT INSERT,IDLER	X	X			
8	225244	1	REAR,INSERT,IDLER	X	X			
12	224423	1	SHAFT,INPUT	X	X			
18	224220	1	GEAR,INPUT	X	X			
27	225251	1	SPACER,BEARING	X	X			
30	224203	1	FLANGE,8.5C	X	X			
31	224666	1	PLATE,FLANGE	X	X			
32	225253	1	LID,INPUT	X	X			
34	225255	1	PLATE,RETARDER	X	X			
37	224221	1	SHIELD,MUD	X	X			
56	224223	1	BEARING,CYLINDER ROLLER	X	X			
61	225270	1	BEARING,SPHERICAL ROLLER	X	X			
65	224367	1	CIRCLIP,INTERNAL	X	X			
67	224370	6	SCREW,HEXHD	X	X			
68	100089	6	SCREW,HEXHD	X	X			
69	100209	3	SCREW,HEXHD	X	X			
72	100123	4	CAPSCREW,SOCHD	X	X			
73	100213	12	CAPSCREW,SOCHD	X	X			
77	224202	1	SEAL,SHAFT	X	X		UPTO S/N: 4123	REFER SIB 2006/1090
77	226917	1	SEAL,SHAFT	X	X		FROM S/N: 4124	REFER SIB 2006/1090
81	224229	1	O-RING	X	X			
83	224231	3	O-RING	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

DROP BOX IDLER

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	224209	1	INSERT,IDLER FRONT	X	X			
6	224210	1	INSERT,IDLER PTO	X	X			
11	224424	1	SHAFT,IDLER	X	X			
17	224421	1	GEAR,IDLER	X	X			
33	225254	1	LID,P.T.O.	X	X			
55	225261	2	BEARING,CYL. ROLLER NJ2213	X	X			
67	224370	16	SCREW,HEXHD	X	X			
69	100209	2	SCREW,HEXHD	X	X			
73	100213	6	SCREW,HEXHD	X	X			
82	225269	1	O-RING	X	X			
83	224231	2	O-RING	X	X			

https://truckmanualshub.com/

DROP BOX OUTPUT SHAFT




https://truckmanualshub.com/

DROP BOX OUTPUT SHAFT

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
2	224426	1	HOUSING,FRONT BEARING	X	X			
3	224425	1	HOUSING,CLUTCH M/C	X	X			
4	224208	1	HOUSING,BEARING REAR	X	X			
9	224222	1	SHAFT,OUTPUT FRONT	X	X			
10	224214	1	SHAFT,OUTPUT REAR	X	X			
13	224206	1	GEAR,SUN	X	X			
14	224246	1	GEAR,PLANET SET	X	X			
15	224238	1	GEAR,RING	X	X			
16	224422	1	GEAR,OUTPUT	X	X			
19	224242	3	PIN,PLANET	X	X			
20	224419	1	CARRIER,PLANET	X	X			
21	224251	1	CLUTCH,INSERT	X	X			
22	224248	1	CLUTCH,SLIDE	X	X			
23	224418	1	FORK	X	X			
24	224244	1	PISTON	X	X			
26	225250	1	COVER,ACTUATOR	X	X			
28	227039	1	KIT,SPACER & WASHERS	X	X			REFER TO SIB 2007/1053
29	224204	1	FLANGE,7C	X	X			
30	224203	1	FLANGE,8.5C	X	X			
31	224666	2	PLATE,FLANGE	X	X			
35	225256	6	WASHER,WEAR	X	X			
36	225257	1	COVER,CLUTCH	X	X			
37	224221	2	SHIELD,MUD	X	X			
40	224253	3	PIN,SPRING	X	X			
41	224237	1	SPRING,COMPRESSION	X	X			
52	224241	2	BUSH,MB 8530 DU	X	X			
53	224240	3	WASHER,THRUST	X	X			
54	224239	168	NEEDLE,ROLLER NRO.B2,5X2,5	X	X			
57	224224	2	BEARING,CYL. ROLLER	X	X			
58	ST20032	1	BEARING,DEEP GROOVE BALL	X	X			
59	224226	1	BEARING,D.G.BALL 16022 C3/C4	X	X			
60	224225	1	BEARING,FOUR POINT QJ213	X	X			
62	224249	3	CIRCLIP,SHAFT	X	X			
64	224258	1	CIRCLIP,EXTERNAL	X	X			
65	224367	2	CIRCLIP,INTERNAL	X	X			
66	224372	8	SCREW,HEXHD	X	X			
67	224370	12	SCREW,HEXHD	X	X			
70	100684	8	BOLT,HEXHD	X	X			
71	223219	1	CAP SCREW	X	X			
72	100123	20	CAPSCREW,SOCHD	X	X			
73	100213	9	CAPSCREW,SOCHD	X	X			
74	224252	3	SCREW,GRUB	X	X			
77	226917	2	SEAL,SHAFT	X	X			REFER TO SIB 2006/1090
78	224200	1	SEAL,PISTON	X	X			
79	224228	3	O-RING	X	X			
80	224235	1	O-RING	X	X			
81	224229	2	O-RING	X	X			
84	224232	1	O-RING	X	X			
85	224236	1	O-RING	X	X			
86	225268	1	O-RING	X	X			

https://truckmanualshub.com/




TD0003463
E9836432 - G

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	290421	1	ACTUATOR,PARK BRAKE,DX195	X	X			
2	204160	1	DISC,PARK BRAKE DX195	X	X			
3	186299	2	MTG,PARK BRAKE,FIELD FIX	X	X			
4	174057	6	SHIM,C# ADT PARK BRAKE DX195	X	X			
5	100945	8	SCREW,HEXHD	X	X			
6	100923	4	SCREW,HEXHD	X	X			
7	100532	8	WASHER,HARDENED	X	X			
8	100491	4	SCREW,HEXHD	X	X			

https://truckmanualshub.com/

PARK BRAKE ASSEMBLY




https://truckmanualshub.com/

PARK BRAKE ASSEMBLY

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	290421	1	ACTUATOR, PARK BRAKE	X	X			
2	222240	1	CALIPER BODY	X	X			
3	NSI	1	SADDLE	X	X			
4	222242	1	PLATE, END MERITOR BRAKE	X	X			
5	226224	1	PADS, SET PARK BRAKE	X	X			(SET CONSISTS OF 2 PADS)
6	222605	2	SPRING, ANTI RATTLE	X	X			
7	222606	2	SPACER	X	X			
8	NSI	1	STABILISER BAR	X	X			
9	223722	1	KIT, SLIDE PIN	X	X			INCLUDES ITEMS 10-21
10	NSI	1	RETAINING PIN	X	X			
11	NSI	1	LOCKING CLIP	X	X			
12	NSI	2	PISTON SCREWS	X	X			
13	NSI	2	ROLL PINS	X	X			
14	NSI	2	PISTON SEAL ASSY	X	X			
15	NSI	2	SLIDE PIN SEALS	X	X			
16	NSI	2	SLIDE PIN BUSHING	X	X			
17	NSI	2	SLIDE PIN COVER PLUGS	X	X			
18	NSI	2	SLIDE PINS	X	X			
19	NSI	2	SLIDE PIN CLAMP BOLTS	X	X			
20	NSI	1	COPPER WASHER	X	X			
21	NSI	1	BLANKING PLUG	X	X			
22	223717	1	KIT, SEAL & GASKET	X	X			INCLUDES ITEMS 14, 15, 17 & 19
23	223721	1	KIT, ADJUSTER SLEEVE & THRUST	X	X			INCLUDES ITEMS 12-14 & 24-31
24	NSI	1	END COVER PLUG	X	X			
25	NSI	2	CIRCLIPS	X	X			
26	NSI	2	SPRINGS	X	X			
27	NSI	1	ACTUATOR BLOCK	X	X			
28	NSI	2	ADJUSTER SLEEVES GEARS	X	X			
29	NSI	2	ADJUSTER SLEEVES	X	X			
30	NSI	2	PISTONS	X	X			
31	NSI	1	LOAD PLATE	X	X			
32	227070	1	KIT, ECCENTRIC SHAFT	X	X			INCLUDES ITEMS 10,11,20,21, 33-40, 43,44
33	NSI	1	SEAL ASSY	X	X			
34	NSI	2	CAPSCREWS-COVER PLATE	X	X			
35	NSI	1	SHAFT COVER-BEARING SEAL	X	X			
36	NSI	1	BEARING	X	X			
37	NSI	1	GASKET SEAL-TOP COVER	X	X			
38	NSI	1	SPACER, WASHER	X	X			
39	NSI	1	ECCENTRIC SHAFT	X	X			
40	NSI	1	BEARING	X	X			
41	223646	1	KIT, LEVER	X	X			
42	223646	1	LEVER, MERITOR BRAKE	X	X			
43	100083	1	SCREW, HEXHEAD	X	X			
44	100312	1	NUT, NYLOC	X	X			
45	223719	1	KIT, ADJUSTER RH	X	X			INCLUDES ITEMS 20,21 & 46-53
46	NSI	1	ADJUSTER SCREW	X	X			
47	NSI	2	DAMPING RING	X	X			
48	NSI	1	COMPRESSION SPRING	X	X			
49	NSI	1	ADJUSTER CASSETTE	X	X			
50	NSI	1	BEVEL GEAR-TORQUE LIMITER	X	X			
51	NSI	1	ADJUSTER GEAR SEGMENT	X	X			
52	NSI	4	RETAINING BOLT	X	X			
53	NSI	2	COUNTERSUNK BOLT	X	X			
54	NSI	1	GASKET SEAL	X	X			
55	223716	1	KIT, BEARING	X	X			NLA UNTIL FURTHER NOTICE
56	222239	1	ACTUATOR ASSEMBLY	X	X			SEE NEXT PAGE FOR BREAK DOWN

https://truckmanualshub.com/




https://truckmanualshub.com/

ACTUATOR ASSEMBLY

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	222239	1	ACTUATOR ASSEMBLY	X	X			
2	100037	2	NUT	X	X			
3	100010	2	WASHER	X	X			
4	200093	1	CLEVIS	X	X			
5	220211	1	DIAPHRAGM	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D		B25D		Vin Series From: To:	REMARKS
1	290139	1	PROPSHAFT,06008,5C8,5C 165M85			X			
2	206765	2	CROSS & ROLLER,LUBE-FOR-LIFE			X			
3	100720	8	BOLT,HEX HD			X			
4	290289	1	PROPSHAFT,02807C,7C L/F/L			X			
5	207990	2	CROSS & ROLLER,LUBE-FOR-LIFE			X			
6	100129	8	BOLT,HEX HD			X			
7	121290	1	VALVE,AIR RELIEF			X			
8	121297	1	CAP,DUST			X			
9	290665	1	PROPSHAFT,02838,5C8,5C 165M85-02			X			
10	206765	2	CROSS & ROLLER,LUBE-FOR-LIFE			X			
11	100720	8	BOLT,HEX HD			X			
12	121290	1	VALVE,AIR RELIEF			X			
13	121289	1	CAP,DUST			X			
14	290297	1	PROSHAFT,12007C7C-015 L/F/L			X			
15	207990	2	CROSS & ROLLER,LUBE-FOR-LIFE			X			
16	100129	8	BOLT,HEX HD			X			
17	290299	1	PROPSHAFT,10207C7C-010 L/F/L			X			
18	207990	2	CROSS & ROLLER,LUBE-FOR-LIFE			X			
19	100129	8	BOLT,HEX HD			X			
20	162960	1	SHAFT,T/DRIVE			X			
21	101349	2	WASHER			X			
22	101382	2	NUT			X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	290139	1	PROPSHAFT,06008,5C8,5C 165M85	X				
2	206765	2	CROSS & ROLLER,LUBE-FOR-LIFE	X				
3	100720	8	BOLT,HEX HD	X				
4	290289	1	PROPSHAFT,02807C,7C L/F/L	X				
5	207990	2	CROSS & ROLLER,LUBE-FOR-LIFE	X				
6	100129	8	BOLT,HEX HD	X				
7	121290	1	VALVE,AIR RELIEF	X				
8	121297	1	CAP,DUST	X				
9	290665	1	PROPSHAFT,02838,5C8,5C 165M85-02	X				
10	206765	2	CROSS & ROLLER,LUBE-FOR-LIFE	X				
11	100720	8	BOLT,HEX HD	X				
12	121290	1	VALVE,AIR RELIEF	X				
13	121289	1	CAP,DUST	X				
14	290119	1	P/SHAFT,10757C7C 148M70 -010	X				
15	207990	2	CROSS & ROLLER,LUBE-FOR-LIFE	X				
16	100129	8	BOLT,HEX HD	X				
17	290298	1	P/SHAFT,0978,7C-7C-010, LUBE-FOR-LIFE	X				USED WITH ZF DIFFERENTIAL
17	290343	1	P/SHAFT,0845,7C-7C,148M70-010	X				USED WITH BELL DIFFERENTIAL
18	207990	2	CROSS & ROLLER,7C LUBE-FOR-LIFE	X				USED WITH ZF DIFFERENTIAL
18	206050	2	CROSS & ROLLER,7C, LOW MAINT	X				USED WITH BELL DIFFERENTIAL
19	100129	8	BOLT,HEX HD	X				
20	162960	1	SHAFT,T/DRIVE	X				
21	101349	2	WASHER	X				
22	101382	2	NUT	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

AXLE, FRONT: B30D

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320568	1	AXLE,MK2,F,HK,DISC	X				
1	310105	1	DIFF HEAD	X				REFERENCE PAGES 3-83
2	290366	4	BRAKE CALIPER:ROCKWELL MINERAL	X				
3	262082	2	KIT,PLANETARY HUB,5.2	X				
4	208200	4	GUARD,CAL,TOP,LHS	X				OPTION FOR NARROW TYRES ONLY
4	208204	4	GUARD,CAL,TOP,REAR	X				OPTION FOR WIDE TYRES ONLY
5	208011	1	SIDE SHAFT	X				
6	208010	1	SIDE SHAFT	X				
7	207660	1	PLUG	X				
8	207626	1	PLUG,MAGNETIC	X				
9	203375	1	PLATE,AXLE SERIAL NUMBER	X				
10	202621	2	SEAL PLATE,B30 16T HUB	X				
11	201420	4	P CLIPS	X				
12	187019	1	BRKT,PIPE,BRAKE	X				
13	184070	1	HSG,BANJO,FRONT	X				
14	183436	2	MTG,BOT.FRNT,CAL/GUARD	X				
15	183433	2	MTG,TOP,FRNT,CAL/GUARD	X				
16	176558	1	PIPE,BRAKE,FRONT,LHS	X				
17	176557	1	PIPE,BRAKE,FRONT,RHS	X				
18	171079	4	PIPE,BRAKE,CRADLE L.F/R.R	X				
19	140340	2	V-RING	X				
20	120379	4	ELBOW	X				
21	120308	3	BULKHEAD	X				
22	125008	1	CONNECTOR	X				REFER SB 2006 / 1040
23	100925	16	SCREW,HEXHD	X				
24	100466	12	CAPSCREW,SOCHD	X				
25	100370	8	WASHER,HARDENED	X				
26	100310	4	NUT,NYLOC	X				
27	100264	12	CAPSCREW,SOCHD	X				
28	100246	1	SCREW,HEXHD	X				
29	100211	8	WASHER,HARDENED	X				

https://truckmanualshub.com/

AXLE, FRONT: B30D WDB OPTION




https://truckmanualshub.com/

AXLE, FRONT: B30D WDB OPTION

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320394	1	AXLE,F,HK,3.18X5.2,SWB	X				
1	310105	1	DIFF HEAD	X				REFERENCE PAGES 3-83
2	264379	1	KIT,BRAKE	X				
3	262506	2	KIT,FINAL DRIVE	X				
4	241620	1	HOSE	X				
5	210984	1	VALVE,CHECK	X				
6	208397	2	SEAL,DUO-CONE	X				
7	208011	1	SIDE SHAFT,HK,1269,5LG	X				
8	208010	1	SIDE SHAFT,HK,1349,5LG	X				
9	207660	1	PLUG	X				
10	207626	1	PLUG,MAGNETIC	X				
11	203375	1	PLT,AXLE SERIAL NUMBER	X				
12	184215	1	HSG,BANJO,FRONT	X				
13	122020	1	ELBOW	X				
14	121429	1	ELBOW,B/HEAD	X				
15	100978	4	POP RIVET	X				
16	100925	16	SCREW,HEXHD	X				

https://truckmanualshub.com/

FRONT DIFFERENTIAL ASSEMBLY: B30D




https://truckmanualshub.com/

FRONT DIFFERENTIAL ASSEMBLY: B30D

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	310105	1	DIFF,HK,3.182,LS,25%,CCW,60DEG	X				REFERENCE PAGE 3-79 & 3-81
020	ZF200183	1	AXLE DR.HOUSING	X				
030	ZF200170	1	GEAR,BEVEL SET	X				
050	ZF150031	1	BEARING,ROLLER	X				
080	ZF160159	1	SPACER RING,S = 7,3	X				
080	ZF160160	1	SPACER RING,S = 7,4	X				
080	ZF160161	1	SPACER RING,S = 7,5	X				
080	ZF160162	1	SPACER RING,S = 7,6	X				
080	ZF160163	1	SPACER RING,S = 7,7	X				
080	ZF160164	1	SPACER RING,S = 7,9	X				
080	ZF160165	1	SPACER RING,S = 8,0	X				
080	ZF160166	1	SPACER RING,S = 8,1	X				
080	ZF160167	1	SPACER RING,S = 8,2	X				
080	ZF160168	1	SPACER RING,S = 8,3	X				
080	ZF160169	1	SPACER RING,S = 8,4	X				
080	ZF160170	1	SPACER RING,S = 8,5	X				
080	ZF160171	1	SPACER RING,S = 8,6	X				
080	ZF160172	1	SPACER RING,S = 8,7	X				
080	ZF160173	1	SPACER RING,S = 8,8	X				
080	ZF160174	1	SPACER RING,S = 8,9	X				
080	ZF160175	1	SPACER RING,S = 9,0	X				
080	ZF160176	1	SPACER RING,S = 7,8	X				
080	ZF160177	1	SPACER RING,S = 7,82	X				
080	ZF160178	1	SPACER RING,S = 7,84	X				
080	ZF160179	1	SPACER RING,S = 7,86	X				
080	ZF160180	1	SPACER RING,S = 7,88	X				
080	ZF160181	1	SPACER RING,S = 7,92	X				
080	ZF160182	1	SPACER RING,S = 7,94	X				
080	ZF160183	1	SPACER RING,S = 7,96	X				
080	ZF160184	1	SPACER RING,S = 7,98	X				
080	ZF160185	1	SPACER RING,S = 8,02	X				
080	ZF160186	1	SPACER RING,S = 8,04	X				
080	ZF160187	1	SPACER RING,S = 8,06	X				
080	ZF160188	1	SPACER RING,S = 8,08	X				
080	ZF160189	1	SPACER RING,S = 8,12	X				
080	ZF160190	1	SPACER RING,S = 8,14	X				
080	ZF160191	1	SPACER RING,S = 8,16	X				
080	ZF160192	1	SPACER RING,S = 8,18	X				

https://truckmanualshub.com/

FRONT DIFFERENTIAL ASSEMBLY: B30D




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
100	ZF150032	1	BEARING,ROLLER	X				
130	ZF160193	1	WASHER,S=0,7	X				
130	ZF160194	1	WASHER,S=0,8	X				
130	ZF160195	1	WASHER,S=0,9	X				
130	ZF160196	1	WASHER,S=1,0	X				
130	ZF160197	1	WASHER,S=1,1	X				
130	ZF160198	1	WASHER,S=1,2	X				
130	ZF160199	1	WASHER,S=1,3	X				
130	ZF160200	1	WASHER,S=1,4	X				
130	ZF160201	1	WASHER,S=1,5	X				
170	ZF150033	1	BEARING,ROLLER	X				
200	ZF150034	1	BEARING,ROLLER	X				
220	ZF100056	2	NUT,ADJUSTING	X				
230	ZF100057	2	PIN,SLOT	X				
280	ZF140030	1	SEAL,SHAFT	X				
300	ZF100058	1	WASHER	X				
320	ZF100059	1	NUT,SLOTTED	X				
420	ZF200048	1	FLANGE,INPUT	X				
430	ZF200049	1	RING,DUST PROTECTION	X				

https://truckmanualshub.com/

FRONT DIFF, CLUTCH CONFIGURATION: B30D




https://truckmanualshub.com/

FRONT DIFF, CLUTCH CONFIGURATION: B30D

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF200177	1	HOUSING,DIFF	X				
030	ZF200061	2	WASHER,THRUST	X				
034	ZF200063	2	WASHER,THRUST	X				
040	ZF200473	4	DISC,CLUTCH OUTER,2.7	X				
040	ZF200474	4	DISC,CLUTCH OUTER,2.9	X				
040	ZF200472	4	DISC,OUTER CLUTCH,3.0	X				
040	ZF200475	4	DISC,CLUTCH OUTER,3.1	X				
040	ZF200476	4	DISC,CLUTCH OUTER,3.2	X				
040	ZF200477	4	DISC,CLUTCH OUTER,3.3	X				
050	ZF200058	2	DISC,CLUTCH INNER	X				
060	ZF200496	2	RING,PRESSURE	X				
070	ZF200064	2	AXLE,DIFFERENTIAL	X				
080	ZF200060	2	GEAR,BEVEL AXLE	X				
090	ZF200062	4	GEAR,BEVEL DIFF	X				
110	ZF200184	1	HOUSING,COVER	X				
114	ZF100061	2	SCREW,CAP	X				
130	ZF100060	20	SCREW,LOCKING	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

AXLE, FRONT: B25D

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320569	1	AXLE,MK2,F,DK,DISC,B25D		X			
1	310109	1	DIFF		X			REFERENCE PAGE 3-91
2	290366	4	CALIPER,BRAKE		X			
3	262082	2	KIT,PLANETARY HUB		X			
4	208202	4	GUARD,CAL,TOP,RHS		X			
5	207660	1	PLUG		X			
6	207626	1	PLUG,MAGNETIC		X			
7	206959	1	SIDE SHAFT,ZF DK,1191LG		X			
8	206958	1	SIDE SHAFT,ZF DK,1261LG		X			
9	203375	1	PLT,AXLE SERIAL NUMBER		X			
10	202621	2	PLT,SEAL		X			
11	201420	4	P-CLIP		X			
12	187019	1	BRKT,PIPE,BRAKE		X			
13	184069	1	HSG,BANJO,FRONT		X			
14	183436	2	MTG,BOT.FRNT,CAL/GUARD		X			
15	183433	2	MTG,TOP,FRNT,CAL/GUARD		X			
16	173724	1	PIPE,BRAKE,FRONT,LHS		X			
17	173723	1	PIPE,BRAKE,FRONT,RHS		X			
18	171079	4	PIPE,BRAKE,CRADLE L.F/R.R		X			
19	140340	2	V-RING		X			
20	120379	4	ELBOW		X			
21	120308	3	BULKHEAD		X			
22	125008	1	CONNECTOR		X			REFER SB 2006 / 1040
23	100925	16	SCREW,HEXHD		X			
24	100466	12	CAPSCREW,SOCHD		X			
25	100370	8	WASHER,HARDENED		X			
26	100310	4	NUT,NYLOC		X			
27	100264	12	CAPSCREW,SOCHD		X			
28	100246	1	SCREW,HEXHD		X			
29	100211	8	SCREW,HEXHD		X			

https://truckmanualshub.com/




https://truckmanualshub.com/

FRONT DIFFERENTIAL ASSEMBLY: B25D

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D	Vin Series From: To:	REMARKS
1	310109	1	DIFFERENTIAL ASSEMBLY		X		REFERENCE PAGE 3-89
020	ZF200302	1	HOUSING,AXLE DRIVE		X		
050	ZF150082	1	BEARING,ROLLER		X		
080	ZF160203	1	SPACER,WASHER S=8,8		X		
080	ZF160204	1	SPACER,WASHER S=8,7		X		
080	ZF160205	1	SPACER,WASHER S=8,6		X		
080	ZF160206	1	SPACER,WASHER S=8,5		X		
080	ZF160207	1	SPACER,WASHER S=8,4		X		
080	ZF160208	1	SPACER,WASHER S=8,3		X		
080	ZF160209	1	SPACER,WASHER S=8,9		X		
080	ZF160210	1	SPACER,WASHER S=9,1		X		
080	ZF160211	1	SPACER,WASHER S=9,2		X		
080	ZF160212	1	SPACER,WASHER S=9,3		X		
080	ZF160213	1	SPACER,WASHER S=9,4		X		
100	ZF150030	1	BEARING,ROLLER		X		
130	ZF160193	1	WASHER,S=0,7		X		
130	ZF160194	1	WASHER,S=0,8		X		
130	ZF160195	1	WASHER,S=0,9		X		
130	ZF160196	1	WASHER,S=1,0		X		
130	ZF160197	1	WASHER,S=1,1		X		
130	ZF160198	1	WASHER,S=1,2		X		
130	ZF160199	1	WASHER,S=1,3		X		
130	ZF160200	1	WASHER,S=1,4		X		
130	ZF160201	1	WASHER,S=1,5		X		
130	ZF160232	1	WASHER,S=0,2		X		
130	ZF160233	1	WASHER,S=0,1		X		
170	ZF150047	1	BEARING,ROLLER		X		
200	ZF150048	1	BEARING,ROLLER		X		
220	ZF100086	2	NUT,ADJUSTING		X		
230	ZF100074	2	PIN,SLOTTED		X		
280	ZF140041	1	SEAL,SHAFT		X		
300	ZF100075	1	WASHER		X		
320	ZF100076	1	NUT,HEXAGON		X		
420	ZF200129	1	FLANGE,INPUT		X		
428	ZF200101	1	DUST,PROTECTOR		X		
500	ZF200182	1	GEAR,BEVEL SET		X		

https://truckmanualshub.com/

FRONT DIFF, CLUTCH CONFIGURATION: B25D




https://truckmanualshub.com/

FRONT DIFF, CLUTCH CONFIGURATION: B25D

ITEM	PART No.	QTY	DESCRIPTION	B30D		B25D		Vin Series From: To:	REMARKS
010	ZF200175	1	HOUSING,LIMITED SLIP DIFF			X			
014	ZF200105	6	CAP,SEALING			X			
020	ZF100077	1	RING,SNAP			X			
030	ZF100078	2	WASHER,THRUST			X			
036	ZF100079	2	WASHER,THRUST			X			
040	ZF200110	4	O.CLUTCH DISC,2.1			X			
040	ZF200106	4	O.CLUTCH DISC,2.2			X			
040	ZF200107	4	O.CLUTCH DISC,2.3			X			
040	ZF200108	4	O.CLUTCH DISC,2.4			X			
040	ZF200109	4	O.CLUTCH DISC,2.5			X			
050	ZF200111	4	I.CLUTCH DISC			X			
060	ZF200498	2	PRESSURE RING			X			
070	ZF200113	2	DIFF AXLE			X			
080	ZF200185	2	GEAR,AXLE BEVEL			X			
090	ZF200115	4	GEAR,DIFF BEVEL			X			
100	ZF100080	12	PIN,DRIVING			X			
110	ZF200176	1	HOUSING,DIFF			X			
120	ZF100061	2	SCREW,CAP			X			
130	ZF100087	12	SCREW,LOCKING			X			

https://truckmanualshub.com/



TD0003469 - A
E9836431 - P


https://truckmanualshub.com/

THRU DRIVE AND OSCILLATION JOINT

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	241252	1	HOSE	X	X			
2	217864	1	NONSLIP,ARTIC	X	X			
3	208770	2	DEFLECTOR,DUST COVER,YOKE	X	X			
4	206945	2	MTG,RUBBER	X	X			
5	206071	2	SHOCK MAT	X	X			
6	203286	1	FLANGE,7C 315PL-120LG	X	X			
7	203285	1	FLANGE,8.C,315PL-121LG	X	X			
8	201194	2	BUSH,OSCILL.JOINT	X	X			
9	200036	4	NIPPLE,GREASE	X	X			
10	182958	1	OSCILLATION JOINT	X	X			
11	178710	2	SHIM,INSIDE OSCILLATION	X	X			
12	178691	2	PLT,LOCK,OSCILLATION,NUT	X	X			
13	178419	1	SHIM,OSCILLATION LOCK NUT	X	X			
14	173729	1	PIPE,GREASE,OSC BOTTOM BRG	X	X			
15	173728	1	PIPE,GREASE,OSC FNT T/B BRG	X	X			
16	173727	1	PIPE,GREASE,OSC TOP BRG	X	X			
17	162960	1	SHAFT,T/DRIVE	X	X			
18	162041	1	HOUSING,BRG,REAR-OSC,T/D	X	X			
19	162040	2	COVER,PLT,SEAL OSC,T/D	X	X			
20	160723	1	BLOCK,GREASE NIPPLE	X	X			
21	150082	2	BEARING,D.G.BALL	X	X			
22	140775	2	SEAL,OSCILLATION	X	X			
23	140429	2	O-RING	X	X			
24	140352	2	O-RING	X	X			
25	140203	2	O-RING	X	X			
26	140011	2	SEAL,OIL	X	X			
27	120807	1	ELBOW	X	X			
28	120148	7	CONNECTOR	X	X			
29	100786	8	BOLT,HEXHD	X	X			
30	100763	8	BOLT,HEXHD	X	X			
31	100684	8	BOLT,HEXHD	X	X			
32	100598	8	CAPSCREW,SOCHD	X	X			
33	100569	2	SCREW,HEXHD	X	X			
34	100147	8	WASHER,FLAT	X	X			

https://truckmanualshub.com/

AXLE, MIDDLE: B30D ZF DIFFERENTIAL




https://truckmanualshub.com/

AXLE, MIDDLE: B30D ZF DIFFERENTIAL

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320122	1	AXLE,MIDDLE	X				
1	310066	1	DIFF,DK-7	X				REFERENCE PAGE 3-103
2	290366	2	CALIPER,BRAKE	X				
3	262082	2	KIT,PLANETARY HUB	X				
4	208033	2	GUARD,CAL.BOT	X				
5	208031	2	GUARD,CAL.TOP	X				
6	208013	1	SIDE SHAFT,DK-7,1255LG	X				
7	208012	1	SIDE SHAFT,DK-7,1374LG	X				
8	207660	1	PLUG	X				
9	207626	1	PLUG,MAGNETIC	X				
10	206071	2	SHOCK MAT	X				
11	203375	1	PLT,AXLE SERIAL NUMBER	X				
12	202621	2	PLT,SEAL	X				
13	201420	1	P-CLIP	X				
14	183510	1	BANJO,HOUSING,DK7 MIDDLE	X				
15	183435	2	MTG,LHS,CALIPER GUARD	X				
16	183432	2	MTG,RHS,CALIPER GUARD	X				
17	176560	1	PIPE,BRAKE-LHS MIDDLE	X				
18	176559	1	PIPE,BRAKE-RHS MIDDLE	X				
19	176194	1	GUARD,BRAKE PIPE,RHS	X				
20	176193	1	GUARD,BRAKE PIPE,LHS	X				
21	173025	2	PLT,STIFFNER	X				
22	172806	4	SHIM	X				
23	162955	3	PIN,SLOTTED	X				
24	161127	1	CARRIER,SEAL,DK-7,OUTPUT	X				
25	140340	2	V-RING	X				
26	120379	2	ELBOW	X				
27	120308	1	BULKHEAD	X				
28	100925	16	SCREW,HEXHD	X				
29	100506	8	CAPSCREW,SOCHD	X				
30	100466	12	CAPSCREW,SOCHD	X				
31	100370	12	WASHER,HARDENED	X				
32	100310	4	NUT,NYLOC	X				
33	100111	4	SCREW,HEXHD	X				
34	100211	8	SCREW,HEXHD	X				
35	100208	8	CAPSCREW,SOCHD	X				
36	100148	4	WASHER,FLAT	X				
37	100086	2	SCREW,HEXHD	X				
38	100085	2	SCREW,HEXHD	X				

https://truckmanualshub.com/

AXLE, MIDDLE: B30D BELL DIFFERENTIAL




https://truckmanualshub.com/

AXLE, MIDDLE: B30D BELL DIFFERENTIAL

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320519	1	AXLE,MIDDLE,BELL,DISC	X				
1	322004	1	DIFF	X				REFERENCE PAGE 3-111
2	290366	2	CALIPER,BRAKE,ROCKWELL,MINERAL	X				
3	262082	2	KIT,PLANETARY HUB	X				
4	217616	1	CARRIER,BRG THRU DRV	X				
5	217527	1	SIDESHAFT	X				
6	217526	1	SIDESHAFT	X				
7	208033	2	GUARD,CAL.BOT,NARROW	X				
8	208031	2	GUARD,CAL.TOP,LHS,NARROW	X				
9	207660	1	PLUG	X				
10	207626	1	PLUG,MAGNETIC	X				
11	203375	1	PLT,AXLE SERIAL NUMBER	X				
12	202621	2	PLT,SEAL,B30 16T HUB	X				
13	201420	4	P-CLIP	X				
14	191058	1	FLANGE,7C,THRU DRV SHAFT	X				
15	187311	1	PIPE,BRAKE,R	X				
16	187310	1	PIPE,BRAKE,L	X				
17	187167	1	GUARD,BRAKE PIPE,LHS	X				
18	187166	1	GUARD,BRAKE PIPE,RHS	X				
19	187020	1	BRKT,PIPE,BRAKE,REAR	X				
20	183435	2	MTG,LHS,CALIPER GUARD	X				
21	183432	2	MTG,RHS,CALIPER GUARD	X				
22	182966	1	BANJO,HSG	X				
23	173025	2	PLT,STIFFNER	X				
24	162955	2	PIN,SLOTTED	X				
25	150216	1	BEARING,SPHERICAL ROLLER	X				
26	140777	1	SEAL,D/LIP	X				
27	140342	1	V-RING	X				
28	140340	2	V-RING	X				
29	120379	2	ELBOW	X				
30	120308	1	BULKHEAD	X				
31	101141	2	STUD,BELL DIFF	X				
32	101140	2	NUT,HEX,FLANGED	X				
33	101113	1	NUT,FLANGED	X				
34	100978	4	POP RIVET	X				
35	100925	10	SCREW,HEXHD	X				
36	100466	12	CAPSCREW,SOCHD	X				
37	100370	12	WASHER,HARDENED	X				
38	100310	4	NUT,NYLOC	X				
39	100211	8	SCREW,HEXHD	X				
40	100148	5	WASHER,FLAT	X				
41	100111	5	SCREW,HEXHD	X				
42	100085	4	SCREW,HEXHD	X				
43	172806	4	SHIM,5MM BIN HEIGHT	X				
44	206071	2	SHOCK MAT	X				
45	100506	8	CAPSCREW	X				

https://truckmanualshub.com/

AXLE, MIDDLE: B30D WDB OPTION




https://truckmanualshub.com/

AXLE, MIDDLE: B30D WDB OPTION

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320395	1	AXLE,M,BELL,3.18X5.2,SWB	X				
1	322008	1	DIFF	X				REFERENCE PAGE 3-117
2	263530	1	KIT,BRAKE	X				
3	262506	2	KIT,FINAL DRIVE	X				
4	241619	1	HOSE	X				
5	241618	1	HOSE	X				
6	217616	1	CARRIER,BRG THRU DRV	X				
7	217527	1	SIDESHAFT,BELL,36/30,L-1279	X				
8	217526	1	SIDESHAFT,BELL,36/30,L-1349.5	X				
9	210963	1	FILTER,HYD,10 MIC	X				
10	208397	2	SEAL,DUO-CONE	X				
11	207660	1	PLUG	X				
12	207626	1	PLUG,MAGNETIC	X				
13	203375	1	PLT,AXLE SERIAL NUMBER	X				
14	191070	1	FLANGE,7C,THRU DRV	X				
15	187777	1	MTG,FILTER	X				
17	182804	1	BANJO,HSG	X				
18	150216	1	BEARING,SPHERICAL ROLLER	X				
19	140777	1	SEAL,D/LIP	X				
20	140342	1	V RING	X				
21	120962	1	ELBOW	X				
22	120047	1	ELBOW	X				
23	120030	1	CONNECT	X				
24	120026	1	CONNECT	X				
25	101141	2	STUD	X				
26	101140	2	NUT,HEX,FLANGED	X				
27	100978	4	POP RIVET	X				
28	100925	10	SCREW,HEXHD	X				
29	100148	1	WASHER,FLAT	X				
30	100111	1	SCREW,HEXHD	X				
31	100061	2	WASHER,FLAT	X				
32	100005	2	SCREW,HEXHD	X				
33	172806	4	SHIM,5MM BIN HEIGHT	X				
34	206071	2	SHOCK MAT	X				
35	100506	8	CAPSCREW	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

MIDDLE DIFFERENTIAL ASSY: B30D ZF DIFF.

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	310066	1	DIFFERENTIAL HEAD	X				REFERENCE PAGE 3-97
020	ZF200233	1	HOUSING,AXLE DRIVE	X				
030	ZF200520	1	CROWNWHEEL	X				
031	ZF200521	1	PINION	X				
050	ZF150092	1	BEARING,ROLLER	X				
080	ZF150093	1	BEARING,ROLLER	X				
082	ZF150096	2	BEARING,ROLLER	X				
100	ZF150094	1	BEARING,ROLLER	X				
114	ZF200245	1	SPACER RING,S = 22,5	X				
122	ZF150095	1	BEARING,ROLLER	X				
140	ZF160518	1	SPACER,WASHER S=19.5	X				Use as required to fit upon measurement
140	ZF160519	1	SPACER,WASHER S=19.6	X				Use as required to fit upon measurement
140	ZF160520	1	SPACER,WASHER S=19.7	X				Use as required to fit upon measurement
140	ZF160521	1	SPACER,WASHER S=19.8	X				Use as required to fit upon measurement
140	ZF160522	1	SPACER,WASHER S=19.9	X				Use as required to fit upon measurement
140	ZF200252	1	RING,SPACER	X				Use as required to fit upon measurement
140	ZF160523	1	SPACER,WASHER S=20.1	X				Use as required to fit upon measurement
140	ZF160524	1	SPACER,WASHER S=20.2	X				Use as required to fit upon measurement
140	ZF160525	1	SPACER,WASHER S=20.3	X				Use as required to fit upon measurement
140	ZF160526	1	SPACER,WASHER S=20.4	X				Use as required to fit upon measurement
140	ZF160527	1	SPACER,WASHER S=20.5	X				Use as required to fit upon measurement
144	ZF200253	1	SHIM,S = 6,2	X				Use as required to fit upon measurement
144	ZF200254	1	SHIM,S = 6,1	X				Use as required to fit upon measurement
144	ZF200255	1	SHIM,S = 6,0	X				Use as required to fit upon measurement
144	ZF200256	1	SHIM,S = 5,9	X				Use as required to fit upon measurement
144	ZF200257	1	SHIM,S = 5,8	X				Use as required to fit upon measurement
166	ZF200258	1	SPACER RING,S = 22,5	X				Use as required to fit upon measurement
166	ZF200259	1	SPACER RING,S = 22,6	X				Use as required to fit upon measurement
166	ZF200260	1	SPACER RING,S = 22,7	X				Use as required to fit upon measurement
166	ZF200261	1	SPACER RING,S = 22,8	X				Use as required to fit upon measurement
166	ZF200262	1	SPACER RING,S = 22,9	X				Use as required to fit upon measurement
166	ZF200263	1	SPACER RING,S = 23,0	X				Use as required to fit upon measurement
166	ZF200264	1	SPACER RING,S = 23,1	X				Use as required to fit upon measurement
166	ZF200265	1	SPACER RING,S = 23,2	X				Use as required to fit upon measurement
166	ZF200266	1	SPACER RING,S = 23,3	X				Use as required to fit upon measurement
166	ZF200267	1	SPACER RING,S = 23,4	X				Use as required to fit upon measurement
166	ZF200268	1	SPACER RING,S = 23,5	X				Use as required to fit upon measurement
166	ZF200269	1	SPACER RING,S = 23,6	X				Use as required to fit upon measurement
166	ZF200270	1	SPACER RING,S = 23,7	X				Use as required to fit upon measurement
166	ZF200271	1	SPACER RING,S = 23,8	X				Use as required to fit upon measurement
166	ZF200272	1	SPACER RING,S = 23,9	X				Use as required to fit upon measurement
166	ZF200273	1	SPACER RING,S = 24,0	X				Use as required to fit upon measurement
166	ZF200274	1	SPACER RING,S = 24,1	X				Use as required to fit upon measurement
168	ZF200245	1	SPACER RING,S = 22,5	X				Use as required to fit upon measurement
200	ZF150040	2	BEARING,ROLLER	X				
214	ZF150097	1	BEARING,ROLLER	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D	Vin Series From: To:	REMARKS
220	ZF200234	1	NUT,ADJUSTING	X			
222	ZF200235	1	NUT,ADJUSTING	X			
224	ZF100233	1	PIN,SLOTTED	X			
228	ZF200276	1	SHIM,S = 0,3	X			Use as required to fit upon measurement
228	ZF200277	1	SHIM,S = 0,5	X			Use as required to fit upon measurement
228	ZF200278	1	SHIM,S = 1,0	X			Use as required to fit upon measurement
228	ZF200279	1	SHIM,S = 0,2	X			Use as required to fit upon measurement
228	ZF200280	1	SHIM,S = 1,2	X			Use as required to fit upon measurement
228	ZF200281	1	SHIM,S = 0,1	X			Use as required to fit upon measurement
228	ZF200282	1	SHIM,S = 0,15	X			Use as required to fit upon measurement
228	ZF200283	1	SHIM,S = 1,2	X			Use as required to fit upon measurement
228	ZF200284	1	SHIM,S = 1,3	X			Use as required to fit upon measurement
228	ZF200285	1	SHIM,S = 1,4	X			Use as required to fit upon measurement
228	ZF200286	1	SHIM,S = 1,5	X			Use as required to fit upon measurement
228	ZF200287	1	SHIM,S = 1,6	X			Use as required to fit upon measurement
228	ZF200288	1	SHIM,S = 1,7	X			Use as required to fit upon measurement
228	ZF200289	1	SHIM,S = 1,8	X			Use as required to fit upon measurement
228	ZF200290	1	SHIM,S = 2,6	X			Use as required to fit upon measurement
228	ZF200291	1	SHIM,S = 2,7	X			Use as required to fit upon measurement
228	ZF200292	1	SHIM,S = 2,8	X			Use as required to fit upon measurement
228	ZF200293	1	SHIM,S = 2,9	X			Use as required to fit upon measurement
228	ZF200294	1	SHIM,S = 3,0	X			Use as required to fit upon measurement
228	ZF200295	1	SHIM,S = 3,1	X			Use as required to fit upon measurement
228	ZF200296	1	SHIM,S = 3,2	X			Use as required to fit upon measurement
228	ZF200297	1	SHIM,S = 3,3	X			Use as required to fit upon measurement
228	ZF200298	1	SHIM,S = 3,4	X			Use as required to fit upon measurement
228	ZF160528	1	SHIM,S = 2,0	X			Use as required to fit upon measurement
228	ZF160529	1	SHIM,S = 2,05	X			Use as required to fit upon measurement
228	ZF160530	1	SHIM,S = 2,1	X			Use as required to fit upon measurement
228	ZF160531	1	SHIM,S = 2,15	X			Use as required to fit upon measurement
228	ZF160532	1	SHIM,S = 2,2	X			Use as required to fit upon measurement
228	ZF160533	1	SHIM,S = 2,25	X			Use as required to fit upon measurement
228	ZF160534	1	SHIM,S = 2,3	X			Use as required to fit upon measurement
228	ZF160535	1	SHIM,S = 2,35	X			Use as required to fit upon measurement
228	ZF160536	1	SHIM,S = 2,4	X			Use as required to fit upon measurement
228	ZF160537	1	SHIM,S = 2,45	X			Use as required to fit upon measurement
228	ZF160538	1	SHIM,S = 2,5	X			Use as required to fit upon measurement
230	ZF100321	12	SCREW,LOCKING	X			
232	ZF100234	1	PIN,SLOT	X			
250	ZF100322	2	SCREW,HEX	X			
256	ZF100237	2	PLUG,SCREW	X			
258	ZF140115	2	RING,SEALING	X			
280	ZF140106	1	SEAL,SHAFT	X		UPTO S/N: 954746	REFER SIB 2006/1068
280	ZF140171	1	SEAL,OIL	X		FROM S/N: 954747	REFER SIB 2006/1068
288	ZF200236	1	BUSH,BEARING	X			
318	ZF160539	1	RING,RETAINING	X			
319	ZF160540	1	WASHER,THRUST	X			
322	ZF160541	1	NUT,HEX	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
328	ZF200237	1	COVER	X				
336	ZF210466	1	FLANGE,BEARING	X				
340	ZF100233	1	PIN,SLOTTED	X				
346	ZF160542	1	RING,RETAINING	X				
350	ZF140116	1	SEAL,SHAFT	X				
360	ZF100181	9	SCREW,HEX	X				
368	ZF100017	6	SCREW,HEX	X				
372	ZF210467	1	HOUSING,REDUCTION GEAR	X				
380	ZF160543	1	RETAINER,SEAL	X				
420	ZF200165	1	SHAFT,INPUT	X				
430	ZF210469	1	CAP,DUST	X				
450	ZF210470	1	SHAFT,FLANGE	X				
460	ZF200323	1	FLANGE MECH 7C	X				
464	ZF200168	1	SHIELD,DUST	X			UPTO S/N: 954746	REFER SIB 2006/1068
464	ZF160777	1	COVER,DUST	X			FROM S/N: 954747	REFER SIB 2006/1068
470	ZF100207	1	WASHER,FLANGE NUT	X				
480	ZF100208	1	NUT,FLANGE	X				
610	ZF200238	1	GEAR,SPUR	X				
630	ZF200239	1	GEAR,SPUR	X				

https://truckmanualshub.com/

MIDDLE DIFF, CLUTCH CONFIG: B30D ZF DIFF.




https://truckmanualshub.com/

MIDDLE DIFF, CLUTCH CONFIG: B30D ZF DIFF.

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
10	ZF200500	1	HOUSING,DIFF	X				
14	ZF200105	6	CAP,SEAL	X				
20	ZF100077	1	SNAP RING	X				
30	ZF100078	2	WASHER,THRUST	X				
40	ZF200110	4	O.CLUTCH DISC,2.1	X				
40	ZF200106	4	O.CLUTCH DISC,2.2	X				
40	ZF200107	4	O.CLUTCH DISC,2.3	X				
40	ZF200108	4	O.CLUTCH DISC,2.4	X				
40	ZF200109	4	O.CLUTCH DISC,2.5	X				
50	ZF200111	4	I.CLUTCH DISC	X				
60	ZF200498	2	PRESSURE RING	X				SIB 2005/1028
70	ZF200113	2	DIFF AXLE	X				
80	ZF200185	2	GEAR,AXLE BEVEL	X				
90	ZF200115	4	GEAR,DIFF BEVEL	X				
100	ZF100080	12	PIN,DRIVING	X				
110	ZF200501	1	COVER,HOUSING	X				

https://truckmanualshub.com/

MIDDLE DIFFERENTIAL ASSEMBLY: B30D BELL DIFF.




https://truckmanualshub.com/

MIDDLE DIFFERENTIAL ASSEMBLY: B30D BELL DIFF.

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	322004	1	DIFF,3.182:1,LS 18%,T/D	X				REFERENCE PAGE 3-99
1	263485	1	ASSY,DIFF CENTRE	X				
2	263269	1	ASSY,DIFF HOUSING,MACHINED	X				
3	218991	1	SET,CW & PINION	X				
4	217842	1	PLT,DIFF SERIAL NUMBER	X				
5	217774	A/R	SPACER,PINION,17.67MM	X				Use as required to fit upon measurement
5	217773	A/R	SPACER,PINION,17.66MM	X				Use as required to fit upon measurement
5	217772	A/R	SPACER,PINION,17.65MM	X				Use as required to fit upon measurement
5	217771	A/R	SPACER,PINION,17.64MM	X				Use as required to fit upon measurement
5	217770	A/R	SPACER,PINION,17.63MM	X				Use as required to fit upon measurement
5	217769	A/R	SPACER,PINION,17.62MM	X				Use as required to fit upon measurement
5	217768	A/R	SPACER,PINION,17.61MM	X				Use as required to fit upon measurement
5	217767	A/R	SPACER,PINION,17.60MM	X				Use as required to fit upon measurement
5	217766	A/R	SPACER,PINION,17.59MM	X				Use as required to fit upon measurement
5	217765	A/R	SPACER,PINION,17.58MM	X				Use as required to fit upon measurement
5	217764	A/R	SPACER,PINION,17.57MM	X				Use as required to fit upon measurement
5	217763	A/R	SPACER,PINION,17.56MM	X				Use as required to fit upon measurement
5	217762	A/R	SPACER,PINION,17.55MM	X				Use as required to fit upon measurement
5	217761	A/R	SPACER,PINION,17.54MM	X				Use as required to fit upon measurement
5	217760	A/R	SPACER,PINION,17.53MM	X				Use as required to fit upon measurement
5	217220	A/R	SPACER,PINION,17.52MM	X				Use as required to fit upon measurement
5	217219	A/R	SPACER,PINION,17.51MM	X				Use as required to fit upon measurement
5	217218	A/R	SPACER,PINION,17.50MM	X				Use as required to fit upon measurement
5	217217	A/R	SPACER,PINION,17.49MM	X				Use as required to fit upon measurement
5	217216	A/R	SPACER,PINION,17.48MM	X				Use as required to fit upon measurement
5	217215	A/R	SPACER,PINION,17.47MM	X				Use as required to fit upon measurement
5	217214	A/R	SPACER,PINION,17.46MM	X				Use as required to fit upon measurement
5	217213	A/R	SPACER,PINION,17.45MM	X				Use as required to fit upon measurement
5	217212	A/R	SPACER,PINION,17.44MM	X				Use as required to fit upon measurement
5	217211	A/R	SPACER,PINION,17.43MM	X				Use as required to fit upon measurement
5	217210	A/R	SPACER,PINION,17.42MM	X				Use as required to fit upon measurement
6	217174	1	CARRIER,PINION	X				
7	217112	A/R	SHIM,ADJUST,PINION SHAFT,0.5	X				Use as required to fit upon measurement
8	217111	A/R	SHIM,ADJUST,PINION SHAFT,0.25	X				Use as required to fit upon measurement
9	217110	A/R	SHIM,ADJUST,PINION SHAFT,0.1	X				Use as required to fit upon measurement
10	217109	A/R	SHIM,ADJUST,POWER DIVIDER,0.5	X				Use as required to fit upon measurement
11	217108	A/R	SHIM,ADJUST,POWER DIVIDE,0.25	X				Use as required to fit upon measurement
12	217107	A/R	SHIM,ADJUST,POWER DIVIDER,0.1	X				Use as required to fit upon measurement
13	217101	1	SHAFT,THRU DRIVE	X				Use as required to fit upon measurement
14	217063	1	GEAR,PINION SHAFT	X				
15	217062	1	GEAR,THRU DRIVE SHAFT	X				
16	201497	1	CIRCLIP-OUTSIDE	X				
17	191032	1	FLANGE,7C,THRU DRIVE,FRONT	X				
18	162268	1	DOWEL,BELL DIFF	X				
19	162231	1	PLT,LOCK,LH	X				
20	162230	1	PLT,LOCK,LH	X				
21	162229	1	NUT,ADJUSTER,LH,MACHINED	X				
22	162228	1	NUT,ADJUSTER,RH,MACHINED	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
23	162225	1	CARRIER,FRONT SEAL,MACHINED	X				
24	162208	1	SPACER,THRU DRIVE	X				
25	150078	2	BEARING,PINION	X				
26	150077	2	BEARING,CONE	X				
27	150076	1	BEARING,PILOT	X				
28	150073	1	BEARING,CUP	X				
29	150072	1	CONE,DIFF BEARING LH	X				
30	150071	1	BEARING,CONE	X				
31	150064	1	BEARING,CUP	X				
32	150057	2	BEARING,TAPER ROLLER	X				
33	140821	1	V-RING	X				
34	140777	1	SEAL,D/LIP	X				
35	101128	20	NUT,HEX	X				
36	101127	20	BOLT,HEXHD	X				
37	101126	4	CAPSCREW,SOCHD	X				
38	101116	1	NUT,FLANGED	X				
39	101115	1	NUT,SLOTTED	X				
40	101113	1	NUT,FLANGED	X				
41	100977	2	PIN,DOWEL,CYLINDER	X				
42	100430	2	SPLITPIN	X				
43	100211	8	SCREW,HEXHD	X				
44	100150	12	BOLT,HEXHD	X				
45	100115	4	SCREW,HEXHD,LONG	X				

https://truckmanualshub.com/

MIDDLE DIFF, CLUTCH CONFIG: B30D BELL DIFF.




https://truckmanualshub.com/

MIDDLE DIFF, CLUTCH CONFIG: B30D BELL DIFF.

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	263485	1	ASSY,DIFF CENTRE,LSD 18%,140	X				
1	263838	1	ASSY,DIFF CENTRE,LSD,MACHINED	X				Items 1 machined together.
2	217703	2	RING,PRESSURE	X				
3	217702	2	SHAFT,CROSS	X				
4	217701	2	GEAR,SIDE	X				
5	217700	4	GEAR,SPIDER	X				
6	217148	A/R	SHIM,ADJUST,LSD,0.5	X				Use as required to fit upon measurement
7	217104	4	DISC,STATIONARY	X				
8	217103	4	DISC,FRICTION	X				
9	217102	2	SPACER	X				
10	217088	A/R	SHIM,ADJUST,LSD,0.25	X				Use as required to fit upon measurement
11	217087	A/R	SHIM,ADJUST,LSD,0.1	X				Use as required to fit upon measurement
12	101136	12	DOWEL	X				
13	101079	12	CAPSCREW	X				
14	100183	6	GRUBSCREW	X				

https://truckmanualshub.com/

MIDDLE DIFFERENTIAL ASSY: B30D WDB OPTION




https://truckmanualshub.com/

MIDDLE DIFFERENTIAL ASSY: B30D WDB OPTION

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	322008	1	DIFF,3.182:1,LS 35%,T/D	X				REFERENCE PAGE 3-101
1	264277	1	ASSY,DIFF HSG,PUMP,MACHINED	X				
2	263474	1	ASSY,DIFF CENTRE	X				REFERENCE PAGE 3-121 ; 149 ; 155
3	217950	1	SHAFT,THRU DRV	X				
4	217842	1	PLT,DIFF SERIAL NUMBER	X				
5	217774	A/R	SPACER,PINION,17.67MM	X				Use as required to fit upon measurement
5	217773	A/R	SPACER,PINION,17.66MM	X				Use as required to fit upon measurement
5	217772	A/R	SPACER,PINION,17.65MM	X				Use as required to fit upon measurement
5	217771	A/R	SPACER,PINION,17.64MM	X				Use as required to fit upon measurement
5	217770	A/R	SPACER,PINION,17.63MM	X				Use as required to fit upon measurement
5	217769	A/R	SPACER,PINION,17.62MM	X				Use as required to fit upon measurement
5	217768	A/R	SPACER,PINION,17.61MM	X				Use as required to fit upon measurement
5	217767	A/R	SPACER,PINION,17.60MM	X				Use as required to fit upon measurement
5	217766	A/R	SPACER,PINION,17.59MM	X				Use as required to fit upon measurement
5	217765	A/R	SPACER,PINION,17.58MM	X				Use as required to fit upon measurement
5	217764	A/R	SPACER,PINION,17.57MM	X				Use as required to fit upon measurement
5	217763	A/R	SPACER,PINION,17.56MM	X				Use as required to fit upon measurement
5	217762	A/R	SPACER,PINION,17.55MM	X				Use as required to fit upon measurement
5	217761	A/R	SPACER,PINION,17.54MM	X				Use as required to fit upon measurement
5	217760	A/R	SPACER,PINION,17.53MM	X				Use as required to fit upon measurement
5	217220	A/R	SPACER,PINION,17.52MM	X				Use as required to fit upon measurement
5	217219	A/R	SPACER,PINION,17.51MM	X				Use as required to fit upon measurement
5	217218	A/R	SPACER,PINION,17.50MM	X				Use as required to fit upon measurement
5	217217	A/R	SPACER,PINION,17.49MM	X				Use as required to fit upon measurement
5	217216	A/R	SPACER,PINION,17.48MM	X				Use as required to fit upon measurement
5	217215	A/R	SPACER,PINION,17.47MM	X				Use as required to fit upon measurement
5	217214	A/R	SPACER,PINION,17.46MM	X				Use as required to fit upon measurement
5	217213	A/R	SPACER,PINION,17.45MM	X				Use as required to fit upon measurement
5	217212	A/R	SPACER,PINION,17.44MM	X				Use as required to fit upon measurement
5	217211	A/R	SPACER,PINION,17.43MM	X				Use as required to fit upon measurement
5	217210	A/R	SPACER,PINION,17.42MM	X				Use as required to fit upon measurement
6	217174	1	CARRIER,PINION	X				
7	217112	A/R	SHIM,ADJUST,PINION SHAFT,0.5	X				Use as required to fit upon measurement
8	217111	A/R	SHIM,ADJUST,PINION SHAFT,0.25	X				Use as required to fit upon measurement
9	217110	A/R	SHIM,ADJUST,PINION SHAFT,0.1	X				Use as required to fit upon measurement
10	217109	A/R	SHIM,ADJUST,POWER DIVIDER,0.5	X				Use as required to fit upon measurement
11	217108	A/R	SHIM,ADJUST,POWER DIVIDE,0.25	X				Use as required to fit upon measurement
12	217107	A/R	SHIM,ADJUST,POWER DIVIDER,0.1	X				Use as required to fit upon measurement
13	217062	1	GEAR,THRU DRIVE SHAFT	X				Use as required to fit upon measurement
14	216594	1	COUPLING,SHAFT	X				
15	216481	1	SHAFT,COUPLING-NUT	X				
16	216480	1	PLT,SPACER,DIFF & PUMP	X				
17	216200	1	SET,CW&PINION	X				
18	216199	1	GEAR,PINION SHAFT	X				
19	210956	1	PUMP,#26 EATON GEAR	X				
20	201497	1	CIRCLIP-OUTSIDE	X				
21	191032	1	FLANGE,7C,THRU DRIVE	X				
22	184244	1	PLT,GUARD,PUMP	X				

https://truckmanualshub.com/

MIDDLE DIFFERENTIAL ASSY: B30D WDB OPTION




https://truckmanualshub.com/

MIDDLE DIFFERENTIAL ASSY: B30D WDB OPTION

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
23	162577	3	TUBE	X				
24	162268	4	DOWEL	X				
25	162231	1	PLT,LOCK,RH	X				
26	162230	1	PLT,LOCK,LH	X				
27	162229	1	NUT,ADJUSTER,LH	X				
28	162228	1	NUT,ADJUSTER,RH	X				
29	162225	1	CARRIER,FRONT SEAL	X				
30	162208	1	SPACER,THRU DRIVE	X				
31	150078	2	BEARING,PINION	X				
32	150077	2	BEARING,CONE	X				
33	150076	1	BEARING,PILOT	X				
34	150073	1	BEARING,CUP	X				
35	150072	1	CONE,DIFF BEARING LH	X				
36	150071	1	BEARING,CONE	X				
37	150064	1	BEARING,CUP	X				
38	150057	2	BEARING,TAPER ROLLER	X				
39	140821	1	V-RING	X				
40	140777	1	SEAL,D/LIP	X				
41	101195	10	WASHER,SPRING	X				
42	101128	20	NUT,HEX	X				
43	101127	20	BOLT,HEXHD	X				
44	101126	4	CAPSCREW,SOCHD	X				
45	101116	1	NUT,FLANGED	X				
46	101113	1	NUT,FLANGED	X				
47	101023	3	BOLT,HEXHD	X				
48	100977	2	PIN,DOWEL,CYL,MTG	X				
49	100821	2	CAPSCREW,SOCHD	X				
50	100430	2	SPLITPIN	X				
51	100212	6	SCREW,HEXHD	X				
52	100211	2	SCREW,HEXHD	X				
53	100150	12	BOLT,HEXHD	X				
54	100119	4	BOLT,HEXHD	X				
55	100010	3	WASHER,FLAT	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

MIDDLE DIFF, CLUTCH CONFIG: B30D WDB OPTION

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	263474	1	ASSY,DIFF CENTRE,LSD 35%,140	X				Reference Page 3-117 ; 149 ; 155
1	263838	1	ASSY,DIFF CENTRE,LSD,MACH.	X				Items 1 machined together.
2	217703	2	RING,PRESSURE	X				
3	217702	2	SHAFT,CROSS	X				
4	217701	2	GEAR,SIDE	X				
5	217700	4	GEAR,SPIDER	X				
6	217148	A/R	SHIM,0.5	X				Use as required to fit upon measurement
7	217104	4	DISC,STEEL	X				
8	217103	4	DISC,FRICTION	X				
9	217102	2	SPACER	X				
10	217088	A/R	SHIM,0.25	X				Use as required to fit upon measurement
11	217087	A/R	SHIM,0.1	X				Use as required to fit upon measurement
12	101136	12	DOWEL,PIN	X				
13	101079	12	CAPSCREW	X				
14	100183	6	GRUBSCREW	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

AXLE, MIDDLE: B25D

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320119	1	AXLE,MID,DK7,3.18 X 5.2,B25D		X			
1	310066	1	DIFF		X			REFERENCE PAGE 3-125
2	290366	2	CALIPER,BRAKE		X			
3	262082	2	KIT,PLANETARY HUB		X			
4	207660	1	PLUG		X			
5	207626	1	PLUG,MAGNETIC		X			
6	207368	2	PLT,BOT,CALIPER GUARD		X			
7	207367	2	PLT,TOP,RHS,CALIPER GUARD		X			
8	206957	1	SIDE SHAFT,DK7,1170LG		X			
9	206956	1	SIDE SHAFT,DK7,1289LG		X			
10	206071	2	SHOCK MAT		X			
11	203375	1	PLT,AXLE SERIAL NUMBER		X			
12	202621	2	PLT,SEAL		X			
13	201420	4	P-CLIP		X			
14	187020	1	BRKT,PIPE,BRAKE,REAR		X			
15	183636	1	BANJO,HOUSING,DK-7,MID		X			
16	183435	2	MTG,LHS,CALIPER GUARD		X			
17	183432	2	MTG,RHS,CALIPER GUARD		X			
18	176194	1	GUARD,BRAKE PIPE,RHS		X			
19	176193	1	GUARD,BRAKE PIPE,LHS		X			
20	173726	1	PIPE,BRAKE-LHS		X			
21	173725	1	PIPE,BRAKE-RHS		X			
22	173025	2	PLT,STIFFNER		X			
23	172806	4	SHIM		X			
24	162955	3	PIN,SLOTTED SPRING		X			
25	161127	1	CARRIER,SEAL		X			
26	140340	2	V-RING		X			
27	120379	2	ELBOW		X			
28	120308	1	ELBOW		X			
29	120148	1	CONNECTOR		X			
30	100978	4	POP RIVET		X			
31	100925	16	SCREW,HEXHD		X			
32	100786	12	BOLT,HEXHD		X			
33	100466	12	CAPSCREW,SOCHD		X			
34	100372	8	CAPSCREW,SOCHD		X			
35	100370	12	WASHER,HARDENED		X			
36	100310	4	NUT,NYLOC		X			
37	100111	4	SCREW,HEXHD		X			
38	100197	8	CAPSCREW,SOCHD		X			
39	100148	4	WASHER,FLAT		X			

https://truckmanualshub.com/




https://truckmanualshub.com/

MIDDLE DIFFERENTIAL ASSY: B25D

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	310066	1	DIFFERENTIAL HEAD		X			REFERENCE PAGE 3-123
020	ZF200233	1	HOUSING,AXLE DRIVE		X			
030	ZF200520	1	CROWNWHEEL		X			
031	ZF200521	1	PINION		X			
050	ZF150092	1	BEARING,ROLLER		X			
080	ZF150093	1	BEARING,ROLLER		X			
082	ZF150096	2	BEARING,ROLLER		X			
100	ZF150094	1	BEARING,ROLLER		X			
114	ZF200245	1	SPACER RING,S =22,5		X			
122	ZF150095	1	BEARING,ROLLER		X			
140	ZF160518	1	SPACER,WASHER S=19.5		X			Use as required to fit upon measurement
140	ZF160519	1	SPACER,WASHER S=19.6		X			Use as required to fit upon measurement
140	ZF160520	1	SPACER,WASHER S=19.7		X			Use as required to fit upon measurement
140	ZF160521	1	SPACER,WASHER S=19.8		X			Use as required to fit upon measurement
140	ZF160522	1	SPACER,WASHER S=19.9		X			Use as required to fit upon measurement
140	ZF200252	1	RING,SPACER		X			Use as required to fit upon measurement
140	ZF160523	1	SPACER,WASHER S=20.1		X			Use as required to fit upon measurement
140	ZF160524	1	SPACER,WASHER S=20.2		X			Use as required to fit upon measurement
140	ZF160525	1	SPACER,WASHER S=20.3		X			Use as required to fit upon measurement
140	ZF160526	1	SPACER,WASHER S=20.4		X			Use as required to fit upon measurement
140	ZF160527	1	SPACER,WASHER S=20.5		X			Use as required to fit upon measurement
144	ZF200253	1	SHIM,S=6,2		X			Use as required to fit upon measurement
144	ZF200254	1	SHIM,S=6,1		X			Use as required to fit upon measurement
144	ZF200255	1	SHIM,S=6,0		X			Use as required to fit upon measurement
144	ZF200256	1	SHIM,S=5,9		X			Use as required to fit upon measurement
144	ZF200257	1	SHIM,S=5,8		X			Use as required to fit upon measurement
166	ZF200258	1	SPACER RING,S=22,5		X			Use as required to fit upon measurement
166	ZF200259	1	SPACER RING,S=22,6		X			Use as required to fit upon measurement
166	ZF200260	1	SPACER RING,S=22,7		X			Use as required to fit upon measurement
166	ZF200261	1	SPACER RING,S=22,8		X			Use as required to fit upon measurement
166	ZF200262	1	SPACER RING,S=22,9		X			Use as required to fit upon measurement
166	ZF200263	1	SPACER RING,S=23,0		X			Use as required to fit upon measurement
166	ZF200264	1	SPACER RING,S=23,1		X			Use as required to fit upon measurement
166	ZF200265	1	SPACER RING,S=23,2		X			Use as required to fit upon measurement
166	ZF200266	1	SPACER RING,S=23,3		X			Use as required to fit upon measurement
166	ZF200267	1	SPACER RING,S=23,4		X			Use as required to fit upon measurement
166	ZF200268	1	SPACER RING,S=23,5		X			Use as required to fit upon measurement
166	ZF200269	1	SPACER RING,S=23,6		X			Use as required to fit upon measurement
166	ZF200270	1	SPACER RING,S=23,7		X			Use as required to fit upon measurement
166	ZF200271	1	SPACER RING,S=23,8		X			Use as required to fit upon measurement
166	ZF200272	1	SPACER RING,S=23,9		X			Use as required to fit upon measurement
166	ZF200273	1	SPACER RING,S=24,0		X			Use as required to fit upon measurement
166	ZF200274	1	SPACER RING,S=24,1		X			Use as required to fit upon measurement
168	ZF200245	1	SPACER RING,S=22,5		X			Use as required to fit upon measurement
200	ZF150040	2	BEARING,ROLLER		X			
214	ZF150097	1	BEARING,ROLLER		X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D	Vin Series From: To:	REMARKS
220	ZF200234	1	NUT,ADJUSTING		X		
222	ZF200235	1	NUT,ADJUSTING		X		
224	ZF100233	1	PIN,SLOTTED		X		
228	ZF200276	1	SHIM,S=0,3		X		Use as required to fit upon measurement
228	ZF200277	1	SHIM,S=0,5		X		Use as required to fit upon measurement
228	ZF200278	1	SHIM,S=1,0		X		Use as required to fit upon measurement
228	ZF200279	1	SHIM,S=0,2		X		Use as required to fit upon measurement
228	ZF200280	1	SHIM,S=1,2		X		Use as required to fit upon measurement
228	ZF200281	1	SHIM,S=0,1		X		Use as required to fit upon measurement
228	ZF200282	1	SHIM,S=0,15		X		Use as required to fit upon measurement
228	ZF200283	1	SHIM,S=1,2		X		Use as required to fit upon measurement
228	ZF200284	1	SHIM,S=1,3		X		Use as required to fit upon measurement
228	ZF200285	1	SHIM,S=1,4		X		Use as required to fit upon measurement
228	ZF200286	1	SHIM,S=1,5		X		Use as required to fit upon measurement
228	ZF200287	1	SHIM,S=1,6		X		Use as required to fit upon measurement
228	ZF200288	1	SHIM,S=1,7		X		Use as required to fit upon measurement
228	ZF200289	1	SHIM,S=1,8		X		Use as required to fit upon measurement
228	ZF200290	1	SHIM,S=2,6		X		Use as required to fit upon measurement
228	ZF200291	1	SHIM,S=2,7		X		Use as required to fit upon measurement
228	ZF200292	1	SHIM,S=2,8		X		Use as required to fit upon measurement
228	ZF200293	1	SHIM,S=2,9		X		Use as required to fit upon measurement
228	ZF200294	1	SHIM,S=3,0		X		Use as required to fit upon measurement
228	ZF200295	1	SHIM,S=3,1		X		Use as required to fit upon measurement
228	ZF200296	1	SHIM,S=3,2		X		Use as required to fit upon measurement
228	ZF200297	1	SHIM,S=3,3		X		Use as required to fit upon measurement
228	ZF200298	1	SHIM,S=3,4		X		Use as required to fit upon measurement
228	ZF160528	1	SHIM,S=2,0		X		Use as required to fit upon measurement
228	ZF160529	1	SHIM,S=2,05		X		Use as required to fit upon measurement
228	ZF160530	1	SHIM,S=2,1		X		Use as required to fit upon measurement
228	ZF160531	1	SHIM,S=2,15		X		Use as required to fit upon measurement
228	ZF160532	1	SHIM,S=2,2		X		Use as required to fit upon measurement
228	ZF160533	1	SHIM,S=2,25		X		Use as required to fit upon measurement
228	ZF160534	1	SHIM,S=2,3		X		Use as required to fit upon measurement
228	ZF160535	1	SHIM,S=2,35		X		Use as required to fit upon measurement
228	ZF160536	1	SHIM,S=2,4		X		Use as required to fit upon measurement
228	ZF160537	1	SHIM,S=2,45		X		Use as required to fit upon measurement
228	ZF160538	1	SHIM,S=2,5		X		Use as required to fit upon measurement
230	ZF100321	12	SCREW,LOCKING		X		
232	ZF100234	1	PIN,SLOT		X		
250	ZF100322	2	SCREW,HEX		X		
256	ZF100237	2	PLUG,SCREW		X		
258	ZF140115	2	RING,SEALING		X		
280	ZF140106	1	SEAL,SHAFT		X	UPTO S/N: 954746	REFER SIB 2006/1068
280	ZF140171	1	SEAL,OIL		X	FROM S/N: 954747	REFER SIB 2006/1068
288	ZF200236	1	BUSH,BEARING		X		
318	ZF160539	1	RING,RETAINING		X		
319	ZF160540	1	WASHER,THRUST		X		
322	ZF160541	1	NUT,HEX		X		

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
328	ZF200237	1	COVER		X			
336	ZF210466	1	FLANGE,BEARING		X			
340	ZF100233	1	PIN,SLOTTED		X			
346	ZF160542	1	RING,RETAINING		X			
350	ZF140116	1	SEAL,SHAFT		X			
360	ZF100181	9	SCREW,HEX		X			
368	ZF100017	6	SCREW,HEX		X			
372	ZF210467	1	HOUSING,REDUCTION GEAR		X			
380	ZF160543	1	RETAINER,SEAL		X			
420	ZF200165	1	SHAFT,INPUT		X			
430	ZF210469	1	CAP,DUST		X			
450	ZF210470	1	SHAFT,FLANGE		X			
460	ZF200323	1	FLANGE MECH 7C		X			
464	ZF200168	1	SHIELD,DUST		X		UPTO S/N: 954746	REFER SIB 2006/1068
464	ZF160777	1	COVER,DUST		X		FROM S/N: 954747	REFER SIB 2006/1068
470	ZF100207	1	WASHER,FLANGE NUT		X			
480	ZF100208	1	NUT,FLANGE		X			
610	ZF200238	1	GEAR,SPUR		X			
630	ZF200239	1	GEAR,SPUR		X			

https://truckmanualshub.com/

MIDDLE DIFF, CLUTCH CONFIGURATION: B25D




https://truckmanualshub.com/

MIDDLE DIFF, CLUTCH CONFIGURATION: B25D

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
10	ZF200500	1	HOUSING,DIFF		X			
14	ZF200105	6	CAP,SEAL		X			
20	ZF100077	1	SNAP RING		X			
30	ZF100078	2	WASHER,THRUST		X			
40	ZF200110	4	O.CLUTCH DISC,2.1		X			
40	ZF200106	4	O.CLUTCH DISC,2.2		X			
40	ZF200107	4	O.CLUTCH DISC,2.3		X			
40	ZF200108	4	O.CLUTCH DISC,2.4		X			
40	ZF200109	4	O.CLUTCH DISC,2.5		X			
50	ZF200111	4	I.CLUTCH DISC		X			
60	ZF200498	2	PRESSURE RING		X			REFER SIB 2005/1028
70	ZF200113	2	DIFF AXLE		X			
80	ZF200185	2	GEAR,AXLE BEVEL		X			
90	ZF200115	4	GEAR,DIFF BEVEL		X			
100	ZF100080	12	PIN,DRIVING		X			
110	ZF200501	1	COVER,HOUSING		X			

https://truckmanualshub.com/




https://truckmanualshub.com/

AXLE, REAR: B30D ZF DIFFERENTIAL

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320123	1	AXLE,REAR,HK,B30D(PROD)	X				
1	310104	1	DIFF	X				REFERENCE PAGE 3-139
2	290366	2	CALIPER,BRAKE,ROCKWELL,MINERAL	X				
3	262082	2	KIT,PLANETARY HUB,5.2	X				
4	208033	2	GUARD,CAL.BOT,NARROW	X				OPTION FOR NARROW TYRES ONLY
4	208030	2	GUARD,CAL.BOT.WIDE	X				OPTION FOR WIDE TYRES ONLY
5	208031	2	GUARD,CAL.TOP,LHS,NARROW	X				OPTION FOR NARROW TYRES ONLY
5	208028	2	GUARD,CAL.TOP,RHS,WIDE	X				OPTION FOR WIDE TYRES ONLY
6	208011	1	SIDE SHAFT,HK,1269,5LG	X				
7	208010	1	SIDE SHAFT,HK,1349,5LG	X				
8	207660	1	PLUG	X				
9	207626	1	PLUG,MAGNETIC	X				
10	206071	2	SHOCK MAT	X				
11	203375	1	PLATE,AXLE SERIAL NUMBER	X				
12	202621	2	SEAL PLATE,B30 16T HUB	X				
13	201420	4	P-CLIPS	X				
14	183511	1	BANJO,HOUSING,HK REAR	X				
15	183435	2	MTG,LHS,CALIPER GUARD	X				
16	183432	2	MTG,RHS,CALIPER GUARD	X				
17	176710	1	PIPE,BRAKE,REAR,RHS	X				
18	176709	1	PIPE,BRAKE,REAR,LHS	X				
19	176556	1	GAURD,BRAKE PIPE,RHS	X				
20	176555	1	GUARD,BREAKE PIPE,LHS	X				
21	173025	2	PLATE,STIFFNER	X				
22	172806	4	SHIM	X				
23	140340	2	V-RING	X				
24	120379	2	ELBOW	X				
26	120308	1	BULKHEAD	X				
27	120106	1	CONNECTOR	X				
28	100925	16	SCREW,HEXHD	X				
28	100506	8	CAPSCREW,SOCHD	X				
29	100466	12	CAPSCREW,SOCHD	X				
30	100370	12	WASHER,HARDENED	X				
31	100310	4	NUT,NYLOC	X				
32	100111	4	SCREW,HEXHD	X				
33	100211	8	SCREW,HEXHD	X				
34	100148	4	WASHER,FLAT	X				
35	100086	2	SCREW,HEXHD	X				
36	100085	2	SCREW,HEXHD	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

AXLE, REAR: B30D BELL DIFFERENTIAL

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320520	1	AXLE,REAR,BELL,DISC	X				
1	322007	1	DIFF	X				REFERENCE PAGE 3-145
2	290366	2	CALIPER,BRAKE,ROCKWELL,MINERAL	X				
3	262082	2	KIT,PLANETARY HUB	X				
4	217527	1	SIDESHAFT	X				
5	217526	1	SIDESHAFT	X				
6	208033	2	GUARD,CAL.BOT	X				
7	208031	2	GUARD,CAL.TOP,LHS	X				
8	207660	1	PLUG	X				
9	207626	1	PLUG,MAGNETIC	X				
10	203375	1	PLT,AXLE SERIAL NUMBER	X				
11	202621	2	PLT,SEAL,B30 16T HUB	X				
12	201420	4	P-CLIP	X				
13	187428	1	PLT,BULKHEAD MTG,AXLE	X				
14	187311	1	PIPE,BRAKE,M&R,R	X				
15	187310	1	PIPE,BRAKE,M&R,L	X				
16	187167	1	GUARD,BRAKE PIPE,LHS	X				
17	187166	1	GUARD,BRAKE PIPE,RHS	X				
18	183435	2	MTG,LHS,CALIPER GUARD	X				
19	183432	2	MTG,RHS,CALIPER GUARD	X				
20	182967	1	BANJO,HSG	X				
21	173025	2	PLT,STIFFNER	X				
22	162955	2	PIN,SLOTTED	X				
23	140340	2	V-RING	X				
24	120379	2	ELBOW	X				
25	120308	1	BULKHEAD	X				
26	101305	1	WASHER,FLAT	X				
27	101151	1	SCREW,HEXHD	X				
28	101141	2	STUD	X				
29	101140	2	NUT,HEX	X				
30	100978	4	POP RIVET	X				
31	100925	10	SCREW,HEXHD	X				
32	100466	12	CAPSCREW,SOCHD	X				
33	100370	12	WASHER,HARDENED	X				
34	100310	4	NUT,NYLOC	X				
35	100211	8	SCREW,HEXHD	X				
36	100148	4	WASHER,FLAT	X				
37	100111	4	SCREW,HEXHD	X				
38	100085	4	SCREW,HEXHD	X				
39	172806	4	SHIM,5MM BIN HEIGHT	X				
40	206071	2	SHOCK MAT	X				
41	100506	8	CAPSCREW	X				

https://truckmanualshub.com/

AXLE, REAR: B30D WDB OPTION




https://truckmanualshub.com/

AXLE, REAR: B30D WDB OPTION

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320611	1	AXLE,R,BELL,3.18X5.2,SWB	X				
2	322009	1	DIFF	X				REFERENCE PAGE 3-151
3	263530	1	KIT,BRAKE	X				
4	262506	2	KIT,FINAL DRIVE	X				
5	241619	1	HOSE	X				
6	241618	1	HOSE	X				
7	217527	1	SIDESHAFT,BELL,36/30,L-1279	X				
8	217526	1	SIDESHAFT,BELL,36/30,L-1349.5	X				
9	210963	1	FILTER,HYD	X				
10	208397	2	SEAL,DUO-CONE	X				
11	207660	1	PLUG	X				
12	207626	1	PLUG,MAGNETIC	X				
13	203375	1	PLT,AXLE SERIAL NUMBER	X				
14	187777	1	MTG,FILTER	X				
16	184239	1	BANJO,HSG	X				
17	120962	1	ELBOW	X				
18	120047	1	ELBOW	X				
19	120030	1	CONNECT	X				
20	120026	1	CONNECT	X				
21	101141	2	STUD	X				
22	101140	2	NUT,HEX,FLANGED	X				
23	100978	4	POP RIVET	X				
24	100925	10	SCREW,HEXHD	X				
25	100148	1	WASHER,FLAT	X				
26	100111	1	SCREW,HEXHD	X				
27	100061	2	WASHER,FLAT	X				
28	100005	2	SCREW,HEXHD	X				
29	172806	4	SHIM,5MM BIN HEIGHT	X				
30	206071	2	SHOCK MAT	X				
31	100506	8	CAPSCREW	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	310104	1	DIFFERENTIAL ASSEMBLY	X				Reference Page 3-133
020	ZF200183	1	AXLE DR.HOUSING	X				
030	ZF200301	1	GEAR,BEVEL SET	X				
050	ZF150031	1	BEARING,ROLLER	X				
080	ZF160159	1	SPACER RING,S = 7,3	X				Use as required to fit upon measurement
080	ZF160160	1	SPACER RING,S = 7,4	X				Use as required to fit upon measurement
080	ZF160161	1	SPACER RING,S = 7,5	X				Use as required to fit upon measurement
080	ZF160162	1	SPACER RING,S = 7,6	X				Use as required to fit upon measurement
080	ZF160163	1	SPACER RING,S = 7,7	X				Use as required to fit upon measurement
080	ZF160164	1	SPACER RING,S = 7,9	X				Use as required to fit upon measurement
080	ZF160165	1	SPACER RING,S = 8,0	X				Use as required to fit upon measurement
080	ZF160166	1	SPACER RING,S = 8,1	X				Use as required to fit upon measurement
080	ZF160167	1	SPACER RING,S = 8,2	X				Use as required to fit upon measurement
080	ZF160168	1	SPACER RING,S = 8,3	X				Use as required to fit upon measurement
080	ZF160169	1	SPACER RING,S = 8,4	X				Use as required to fit upon measurement
080	ZF160170	1	SPACER RING,S = 8,5	X				Use as required to fit upon measurement
080	ZF160171	1	SPACER RING,S = 8,6	X				Use as required to fit upon measurement
080	ZF160172	1	SPACER RING,S = 8,7	X				Use as required to fit upon measurement
080	ZF160173	1	SPACER RING,S = 8,8	X				Use as required to fit upon measurement
080	ZF160174	1	SPACER RING,S = 8,9	X				Use as required to fit upon measurement
080	ZF160175	1	SPACER RING,S = 9,0	X				Use as required to fit upon measurement
080	ZF160176	1	SPACER RING,S = 7,8	X				Use as required to fit upon measurement
080	ZF160177	1	SPACER RING,S = 7,82	X				Use as required to fit upon measurement
080	ZF160178	1	SPACER RING,S = 7,84	X				Use as required to fit upon measurement
080	ZF160179	1	SPACER RING,S = 7,86	X				Use as required to fit upon measurement
080	ZF160180	1	SPACER RING,S = 7,88	X				Use as required to fit upon measurement
080	ZF160181	1	SPACER RING,S = 7,92	X				Use as required to fit upon measurement
080	ZF160182	1	SPACER RING,S = 7,94	X				Use as required to fit upon measurement
080	ZF160183	1	SPACER RING,S = 7,96	X				Use as required to fit upon measurement
080	ZF160184	1	SPACER RING,S = 7,98	X				Use as required to fit upon measurement
080	ZF160185	1	SPACER RING,S = 8,02	X				Use as required to fit upon measurement
080	ZF160186	1	SPACER RING,S = 8,04	X				Use as required to fit upon measurement
080	ZF160187	1	SPACER RING,S = 8,06	X				Use as required to fit upon measurement
080	ZF160188	1	SPACER RING,S = 8,08	X				Use as required to fit upon measurement
080	ZF160189	1	SPACER RING,S = 8,12	X				Use as required to fit upon measurement
080	ZF160190	1	SPACER RING,S = 8,14	X				Use as required to fit upon measurement
080	ZF160191	1	SPACER RING,S = 8,16	X				Use as required to fit upon measurement
080	ZF160192	1	SPACER RING,S = 8,18	X				Use as required to fit upon measurement


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
100	ZF150032	1	BEARING,ROLLER	X				
130	ZF160193	1	WASHER,S=0,7	X				Use as required to fit upon measurement
130	ZF160194	1	WASHER,S=0,8	X				Use as required to fit upon measurement
130	ZF160195	1	WASHER,S=0,9	X				Use as required to fit upon measurement
130	ZF160196	1	WASHER,S=1,0	X				Use as required to fit upon measurement
130	ZF160197	1	WASHER,S=1,1	X				Use as required to fit upon measurement
130	ZF160198	1	WASHER,S=1,2	X				Use as required to fit upon measurement
130	ZF160199	1	WASHER,S=1,3	X				Use as required to fit upon measurement
130	ZF160200	1	WASHER,S=1,4	X				Use as required to fit upon measurement
130	ZF160201	1	WASHER,S=1,5	X				Use as required to fit upon measurement
170	ZF150033	1	BEARING,ROLLER	X				
200	ZF150034	1	BEARING,ROLLER	X				
220	ZF100056	2	NUT,ADJUSTING	X				
230	ZF100057	2	PIN,SLOT	X				
280	ZF140030	1	SEAL,SHAFT	X				
300	ZF100058	1	WASHER	X				
320	ZF100059	1	NUT,SLOTTED	X				
420	ZF200048	1	FLANGE,INPUT	X				
430	ZF200049	1	RING,DUST PROTECTION	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

REAR DIFF, CLUTCH CONFIGURATION: B30D ZF DIFF.

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
010	ZF200177	1	HOUSING,DIFF	X				
030	ZF200061	2	WASHER,THRUST	X				
034	ZF200063	2	WASHER,THRUST	X				
040	ZF200473	4	DISC,CLUTCH OUTER,2.7	X				
040	ZF200474	4	DISC,CLUTCH OUTER,2.9	X				
040	ZF200472	4	DISC,OUTER CLUTCH,3.0	X				
040	ZF200475	4	DISC,CLUTCH OUTER,3.1	X				
040	ZF200476	4	DISC,CLUTCH OUTER,3.2	X				
040	ZF200477	4	DISC,CLUTCH OUTER,3.3	X				
050	ZF200058	2	DISC,CLUTCH INNER	X				
060	ZF200496	2	RING,PRESSURE	X				
070	ZF200064	2	AXLE,DIFFERENTIAL	X				
080	ZF200060	2	GEAR,BEVEL AXLE	X				
090	ZF200062	4	GEAR,BEVEL DIFF	X				
110	ZF200184	1	HOUSING,COVER	X				
114	ZF100061	2	SCREW,CAP	X				
130	ZF100060	20	SCREW,LOCKING	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	322007	1	DIFF,3.182:1,LS 35%,CW,H/D	X				Reference Page 3-135
1	263474	1	ASSY,DIFF CENTRE	X				
2	263269	1	ASSY,DIFF HOUSING	X				
3	218991	1	SET,CW & PINION	X				
4	217842	1	PLT,DIFF SERIAL NUMBER	X				
5	217775	1	SHAFT,HIGH DRIVE	X				
6	217774	AR	SPACER,PINION,17.67MM	X				Use as required to fit upon measurement
6	217773	AR	SPACER,PINION,17.66MM	X				Use as required to fit upon measurement
6	217772	AR	SPACER,PINION,17.65MM	X				Use as required to fit upon measurement
6	217771	AR	SPACER,PINION,17.64MM	X				Use as required to fit upon measurement
6	217770	AR	SPACER,PINION,17.63MM	X				Use as required to fit upon measurement
6	217769	AR	SPACER,PINION,17.62MM	X				Use as required to fit upon measurement
6	217768	AR	SPACER,PINION,17.61MM	X				Use as required to fit upon measurement
6	217767	AR	SPACER,PINION,17.60MM	X				Use as required to fit upon measurement
6	217766	AR	SPACER,PINION,17.59MM	X				Use as required to fit upon measurement
6	217765	AR	SPACER,PINION,17.58MM	X				Use as required to fit upon measurement
6	217764	AR	SPACER,PINION,17.57MM	X				Use as required to fit upon measurement
6	217763	AR	SPACER,PINION,17.56MM	X				Use as required to fit upon measurement
6	217762	AR	SPACER,PINION,17.55MM	X				Use as required to fit upon measurement
6	217761	AR	SPACER,PINION,17.54MM	X				Use as required to fit upon measurement
6	217760	AR	SPACER,PINION,17.53MM	X				Use as required to fit upon measurement
6	217220	AR	SPACER,PINION,17.52MM	X				Use as required to fit upon measurement
6	217219	AR	SPACER,PINION,17.51MM	X				Use as required to fit upon measurement
6	217218	AR	SPACER,PINION,17.50MM	X				Use as required to fit upon measurement
6	217217	AR	SPACER,PINION,17.49MM	X				Use as required to fit upon measurement
6	217216	AR	SPACER,PINION,17.48MM	X				Use as required to fit upon measurement
6	217215	AR	SPACER,PINION,17.47MM	X				Use as required to fit upon measurement
6	217214	AR	SPACER,PINION,17.46MM	X				Use as required to fit upon measurement
6	217213	AR	SPACER,PINION,17.45MM	X				Use as required to fit upon measurement
6	217212	AR	SPACER,PINION,17.44MM	X				Use as required to fit upon measurement
6	217211	AR	SPACER,PINION,17.43MM	X				Use as required to fit upon measurement
6	217210	AR	SPACER,PINION,17.42MM	X				Use as required to fit upon measurement
7	217174	1	CARRIER,PINION	X				
8	217112	AR	SHIM,ADJUST,PINION SHAFT,0.5	X				Use as required to fit upon measurement
9	217111	AR	SHIM,ADJUST,PINION SHAFT,0.25	X				Use as required to fit upon measurement
10	217110	AR	SHIM,ADJUST,PINION SHAFT,0.1	X				Use as required to fit upon measurement
11	217109	AR	SHIM,ADJUST,POWER DIVIDER,0.5	X				Use as required to fit upon measurement
12	217108	AR	SHIM,ADJUST,POWER DIVIDE,0.25	X				Use as required to fit upon measurement
13	217107	AR	SHIM,ADJUST,POWER DIVIDER,0.1	X				Use as required to fit upon measurement
14	217063	1	GEAR,PINION SHAFT	X				
15	217062	1	GEAR,THRU DRIVE SHAFT	X				
16	201497	1	CIRCLIP-OUTSIDE	X				
17	191032	1	FLANGE,7C,THRU DRIVE,FRONT	X				
18	162268	4	DOWEL,BELL DIFF	X				
19	162231	1	PLT,LOCK,RH	X				
20	162230	1	PLT,LOCK,LH	X				
21	162229	1	NUT,ADJUSTER,LH	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
22	162228	1	NUT,ADJUSTER,RH	X				
23	162225	1	CARRIER,FRONT SEAL	X				
24	162208	1	SPACER,THRU DRIVE	X				
25	150078	2	BEARING,PINION	X				
26	150077	2	BEARING,CONE	X				
27	150076	1	BEARING,PILOT	X				
28	150073	1	BEARING,CUP	X				
29	150072	1	CONE,DIFF BEARING LH	X				
30	150071	1	BEARING,CONE	X				
31	150064	1	BEARING,CUP	X				
32	150057	2	BEARING,TAPER ROLLER	X				
33	140821	1	V-RING	X				
34	140777	1	SEAL,D/LIP	X				
35	101128	20	NUT,HEX	X				
36	101127	20	BOLT,HEXHD	X				
37	101126	4	CAPSCREW,SOCHD	X				
38	101116	1	NUT,FLANGED	X				
39	101115	1	NUT,SLOTTED	X				
40	100977	2	PIN,DOWEL,CYL,MTG	X				
41	100430	2	SPLITPIN	X				
42	100211	8	SCREW,HEXHD	X				
43	100150	12	BOLT,HEXHD	X				
44	100115	4	SCREW,HEXHD	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

REAR DIFF, CLUTCH CONFIG: B30D BELL DIFF.

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	263474	1	ASSY,DIFF CENTRE,LSD 35%,140	X				Reference Page 3-117 ; 3-121 ; 155
1	263838	1	ASSY,DIFF CENTRE,LSD,MACH.	X				Items 1 machined together.
2	217703	2	RING,PRESSURE	X				
3	217702	2	SHAFT,CROSS	X				
4	217701	2	GEAR,SIDE	X				
5	217700	4	GEAR,SPIDER	X				
6	217148	A/R	SHIM,0.5	X				Use as required to fit upon measurement
7	217104	4	DISC,STEEL	X				
8	217103	4	DISC,FRICTION	X				
9	217102	2	SPACER	X				
10	217088	A/R	SHIM,0.25	X				Use as required to fit upon measurement
11	217087	A/R	SHIM,0.1	X				Use as required to fit upon measurement
12	101136	12	DOWEL,PIN	X				
13	101079	12	CAPSCREW	X				
14	100183	6	GRUBSCREW	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	322009	1	DIFF,3.182:1,LS 35%,H/D,CW	X				Reference Page 3-137
1	264277	1	ASSY,DIFF HOUSING,MACHINED	X				
2	263474	1	ASSY,DIFF CENTRE,LSD 35%,140	X				
3	217842	1	PLT,DIFF SERIAL NUMBER	X				
4	217775	1	SHAFT,HIGH DRIVE	X				
5	217774	1	SPACER,PINION,17.67MM	X				Use as required to fit upon measurement
5	217773	1	SPACER,PINION,17.66MM	X				Use as required to fit upon measurement
5	217772	1	SPACER,PINION,17.65MM	X				Use as required to fit upon measurement
5	217771	1	SPACER,PINION,17.64MM	X				Use as required to fit upon measurement
5	217770	1	SPACER,PINION,17.63MM	X				Use as required to fit upon measurement
5	217769	1	SPACER,PINION,17.62MM	X				Use as required to fit upon measurement
5	217768	1	SPACER,PINION,17.61MM	X				Use as required to fit upon measurement
5	217767	1	SPACER,PINION,17.60MM	X				Use as required to fit upon measurement
5	217766	1	SPACER,PINION,17.59MM	X				Use as required to fit upon measurement
5	217765	1	SPACER,PINION,17.58MM	X				Use as required to fit upon measurement
5	217764	1	SPACER,PINION,17.57MM	X				Use as required to fit upon measurement
5	217763	1	SPACER,PINION,17.56MM	X				Use as required to fit upon measurement
5	217762	1	SPACER,PINION,17.55MM	X				Use as required to fit upon measurement
5	217761	1	SPACER,PINION,17.54MM	X				Use as required to fit upon measurement
5	217760	1	SPACER,PINION,17.53MM	X				Use as required to fit upon measurement
5	217220	1	SPACER,PINION,17.52MM	X				Use as required to fit upon measurement
5	217219	1	SPACER,PINION,17.51MM	X				Use as required to fit upon measurement
5	217218	1	SPACER,PINION,17.50MM	X				Use as required to fit upon measurement
5	217217	1	SPACER,PINION,17.49MM	X				Use as required to fit upon measurement
5	217216	1	SPACER,PINION,17.48MM	X				Use as required to fit upon measurement
5	217215	1	SPACER,PINION,17.47MM	X				Use as required to fit upon measurement
5	217214	1	SPACER,PINION,17.46MM	X				Use as required to fit upon measurement
5	217213	1	SPACER,PINION,17.45MM	X				Use as required to fit upon measurement
5	217212	1	SPACER,PINION,17.44MM	X				Use as required to fit upon measurement
5	217211	1	SPACER,PINION,17.43MM	X				Use as required to fit upon measurement
5	217210	1	SPACER,PINION,17.42MM	X				Use as required to fit upon measurement
6	217174	1	CARRIER,PINION	X				
7	217112	1	SHIM,ADJUST,PINION SHAFT,0.5	X				Use as required to fit upon measurement
8	217111	2	SHIM,ADJUST,PINION SHAFT,0.25	X				Use as required to fit upon measurement
9	217110	2	SHIM,ADJUST,PINION SHAFT,0.1	X				Use as required to fit upon measurement
10	217109	1	SHIM,ADJUST,POWER DIVIDER,0.5	X				Use as required to fit upon measurement
11	217108	2	SHIM,ADJUST,POWER DIVIDE,0.25	X				Use as required to fit upon measurement
12	217107	2	SHIM,ADJUST,POWER DIVIDER,0.1	X				Use as required to fit upon measurement
13	217062	1	GEAR,THRU DRIVE SHAFT	X				
14	216594	1	COUPLING,SHAFT	X				
15	216481	1	SHAFT,COUPLING-NUT	X				
16	216480	1	PLT,SPACER,DIFF & PUMP	X				
17	216200	1	SET,CW&PINION	X				
18	216199	1	GEAR,PINION SHAFT	X				
19	210956	1	PUMP	X				
20	201497	1	CIRCLIP-OUTSIDE	X				
21	191032	1	FLANGE	X				

https://truckmanualshub.com/


REAR DIFFERENTIAL ASSEMBLY: B30D WDB OPTION



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
22	184244	1	PLT,GUARD,PUMP	X				
23	162577	3	TUBE,#20 DIFF,PUMP,GUARD	X				
24	162268	4	DOWEL	X				
25	162231	1	PLT,LOCK,RH	X				
26	162230	1	PLT,LOCK,LH	X				
27	162229	1	NUT,ADJUSTER,LH	X				
28	162228	1	NUT,ADJUSTER,RH	X				
29	162225	1	CARRIER,FRONT SEAL	X				
30	162208	1	SPACER,THRU DRIVE	X				
31	150078	2	BEARING,PINION	X				
32	150077	2	BEARING,CONE	X				
33	150076	1	BEARING,PILOT	X				
34	150073	1	BEARING,CUP	X				
35	150072	1	CONE,DIFF BEARING LH	X				
36	150071	1	BEARING,CONE	X				
37	150064	1	BEARING,CUP	X				
38	150057	2	BEARING,TAPER ROLLER	X				
39	140821	1	V-RING	X				
40	140777	1	SEAL,D/LIP	X				
41	101195	10	WASHER,SPRING	X				
42	101128	20	NUT,HEX	X				
43	101127	20	BOLT,HEXHD	X				
44	101126	4	CAPSCREW,SOCHD	X				
45	101116	1	NUT,FLANGED	X				
46	101023	3	BOLT,HEXHD	X				
47	100977	2	PIN,DOWEL	X				
48	100821	2	CAPSCREW,SOCHD	X				
49	100430	2	SPLITPIN	X				
50	100212	6	SCREW,HEXHD	X				
51	100211	2	SCREW,HEXHD	X				
52	100150	12	BOLT,HEXHD	X				
53	100119	4	BOLT,HEXHD	X				
54	100010	3	WASHER,FLAT	X				

https://truckmanualshub.com/




https://truckmanualshub.com/

REAR DIFF, CLUTCH CONFIG: B30D WDB OPTION

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	263474	1	ASSY,DIFF CENTRE,LSD 35%,140	X				Reference Page 3-117 ; 121 ; 149
1	263838	1	ASSY,DIFF CENTRE,LSD,MACH.	X				Items 1 machined together.
2	217703	2	RING,PRESSURE	X				
3	217702	2	SHAFT,CROSS	X				
4	217701	2	GEAR,SIDE	X				
5	217700	4	GEAR,SPIDER	X				
6	217148	A/R	SHIM,0.5	X				Use as required to fit upon measurement
7	217104	4	DISC,STEEL	X				
8	217103	4	DISC,FRICTION	X				
9	217102	2	SPACER	X				
10	217088	A/R	SHIM,0.25	X				Use as required to fit upon measurement
11	217087	A/R	SHIM,0.1	X				Use as required to fit upon measurement
12	101136	12	DOWEL,PIN	X				
13	101079	12	CAPSCREW	X				
14	100183	6	GRUBSCREW	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	320527	1	AXLE,REAR,B25D		X			
1	310108	1	DIFF		X			REFERENCE PAGE 3-159
2	290366	2	CALIPER,BRAKE		X			
3	262082	2	KIT,PLANETARY HUB		X			
4	207660	1	PLUG		X			
5	207626	1	PLUG,MAGNETIC		X			
6	207368	2	PLT,BOT,CALIPER GUARD		X			
7	207367	2	PLT,TOP,RHS,CALIPER GUARD		X			
8	206959	1	SIDE SHAFT,ZF DK,1191LG		X			
9	206958	1	SIDE SHAFT,ZF DK,1261LG		X			
10	206071	2	SHOCK MAT		X			
11	203375	1	PLT,AXLE SERIAL NUMBER		X			
12	202621	2	PLT,SEAL		X			
13	201420	4	P-CLIP		X			
14	183435	2	MTG,LHS,CALIPER GUARD		X			
15	183432	2	MTG,RHS,CALIPER GUARD		X			
16	183170	1	BANJO,HOUSING,DK REAR		X			
17	176671	1	PIPE,BRAKE,REAR,LHS		X			
18	176670	1	PIPE,BRAKE,REAR,RHS		X			
19	176194	1	GUARD,BRAKE PIPE,RHS		X			
20	176193	1	GUARD,BRAKE PIPE,LHS		X			
21	173025	2	PLT,STIFFNER		X			
22	172806	4	SHIM		X			
23	140340	2	V-RING		X			
24	120379	2	ELBOW		X			
25	120308	1	BULKHEAD		X			
26	120106	1	CONNECTOR		X			
27	100925	16	SCREW,HEXHD		X			
28	100506	8	CAPSCREW,SOCHD		X			
29	100466	12	CAPSCREW,SOCHD		X			
30	100370	12	WASHER,HARDENED		X			
31	100310	4	NUT,NYLOC		X			
32	100111	4	SCREW,HEXHD		X			
33	100211	8	SCREW,HEXHD		X			
34	100148	4	WASHER,FLAT		X			
35	100086	2	SCREW,HEXHD		X			
36	100085	2	SCREW,HEXHD		X			

https://truckmanualshub.com/




https://truckmanualshub.com/

REAR DIFFERENTIAL ASSEMBLY: B25D

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D	Vin Series From: To:	REMARKS
1	310108	1	DIFFERENTIAL ASSEMBLY		X		REFERENCE PAGE 3-157
020	ZF200302	1	HOUSING,AXLE DRIVE		X		
050	ZF150082	1	BEARING,ROLLER		X		
080	ZF160208	1	SPACER,WASHER,8.3		X		
080	ZF160207	1	SPACER,WASHER,8.4		X		
080	ZF160206	1	SPACER,WASHER,8.5		X		
080	ZF160205	1	SPACER,WASHER,8.6		X		
080	ZF160204	1	SPACER,WASHER,8.7		X		
080	ZF160209	1	SPACER,WASHER,8.9		X		
080	ZF160210	1	SPACER,WASHER,9.1		X		
080	ZF160211	1	SPACER,WASHER,9.2		X		
080	ZF160212	1	SPACER,WASHER,9.3		X		
080	ZF160213	1	SPACER,WASHER,9.4		X		
100	ZF150030	1	BEARING,ROLLER		X		
130	ZF160233	1	WASHER,0.1		X		
130	ZF160232	1	WASHER,0.2		X		
130	ZF160193	1	WASHER,0.7		X		
130	ZF160194	1	WASHER,0.8		X		
130	ZF160195	1	WASHER,0.9		X		
130	ZF160196	1	WASHER,1.0		X		
130	ZF160197	1	WASHER,1.1		X		
130	ZF160198	1	WASHER,1.2		X		
130	ZF160199	1	WASHER,1.3		X		
130	ZF160200	1	WASHER,1.4		X		
130	ZF160201	1	WASHER,1.5		X		
170	ZF150047	1	BEARING,ROLLER		X		
200	ZF150048	1	BEARING,ROLLER		X		
220	ZF100086	2	NUT,ADJUSTING		X		
230	ZF100074	2	PIN,SLOTTED		X		
280	ZF140041	1	SEAL,SHAFT		X		
300	ZF100075	1	WASHER		X		
320	ZF100076	1	NUT,HEXAGON		X		
420	ZF200129	1	FLANGE,INPUT		X		
428	ZF200101	1	DUST,PROTECTOR		X		
500	ZF200182	1	GEAR,BEVEL SET		X		

https://truckmanualshub.com/




https://truckmanualshub.com/

REAR DIFF, CLUTCH CONFIGURATION: B25D

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D	Vin Series From: To:	REMARKS
010	ZF200175	1	HOUSING,DIFFERENTIAL		X		
014	ZF200105	6	SEALING,CAP		X		
020	ZF100077	1	RING,SNAP		X		
030	ZF100078	2	WASHER,THRUST		X		
036	ZF100079	2	WASHER,THRUST		X		
040	ZF200110	4	O.CLUTCH DISC,2.1		X		
040	ZF200106	4	O.CLUTCH DISC,2.2		X		
040	ZF200107	4	O.CLUTCH DISC,2.3		X		
040	ZF200108	4	O.CLUTCH DISC,2.4		X		
040	ZF200109	4	O.CLUTCH DISC,2.5		X		
050	ZF200111	4	I.CLUTCH DISC		X		
060	ZF200498	2	PRESSURE RING		X		
070	ZF200113	2	AXLE,DIFF		X		
080	ZF200185	2	AXLE,BEVEL GEAR		X		
090	ZF200115	4	GEAR,DIFF BEVEL		X		
100	ZF100080	12	PIN,DRIVING		X		
110	ZF200176	1	HOUSING,DIFF		X		
120	ZF100061	2	SCREW,CAP		X		
130	ZF100087	12	SCREW,LOCKING		X		


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	290366	1	CALIPER,BRAKE,ROCKWELL,MINERAL	X	X			
2	NSI	1	HOUSING	X	X			
3	201428	2	VALVE,BLEED	X	X			
4	223905	4	PLATE,END	X	X			
5	100039	8	SCREW,HEX HEAD	X	X			
6	100466	6	SCREW,CAP	X	X			
7	218439	4	PISTON	X	X			
8	140330	1	KIT,SEAL,MINERAL OIL	X	X			
9	223908	2	CYLINDER HEAD	X	X			
10	120332	1	PLUG	X	X			
11	ZF140008	1	O-RING	X	X			
12	217180	2	PAD,BRAKE,SCL-2,NA-4	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

PLANETARY HUB

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	262082	2	KIT,PLANETARY HUB	X	X			
1	160571	1	STUB,AXLE,MACHINED	X	X			
2	161786	1	HUB:MACHINED	X	X			
3	190550	1	PLANET CARRIER	X	X			
4	162077	1	DISC:14T AXLE	X	X			
5	161893	1	RING GEAR CARRIER	X	X			
6	162440	3	PIN,PLANET	X	X			
7	206597	1	RING GEAR MKII	X	X			
8	207061A	1	SUNGEAR	X	X			
9	206987A	3	PLANET GEAR	X	X			
10	160190	4	PLATE,RETAINER,RING GEAR	X	X			
11	160360	4	PLATE,LOCK	X	X			
12	100149	8	SCREW,HEXHD	X	X			
13	100760	14	SCREW,HEXHD	X	X			
14	100211	24	SCREW,HEXHD	X	X			
15	100228	30	CAPSCREW	X	X			
16	207676	1	PLUG,MAGNETIC	X	X			
17	140105	3	O-RING	X	X			
18	140471	1	SEAL,CASSETTE	X	X			
19	201926	1	CIRCLIP: INNER	X	X			
20	120128	1	PLUG	X	X			
21	160956	1	RING,THRUST,SUNGEAR,HTB	X	X			
22	190141	1	WASHER,HEAT TREATED	X	X			
23	170222	1	CIRCLIP,REAR,AXLE	X	X			
24	160194	1	PLUG,BRONZE THRUST	X	X			
25	160193	1	RING,STEEL	X	X			
26	160182	6	SHIM: PLANET	X	X			
27	160263	1	NUT: LOCK,REAR,AXLE	X	X			
28	150060	3	BEARING,ROLLER	X	X			
29	204457	3	CIRCLIP,OUTSIDE	X	X			
30	201650	1	CIRCLIP EXTERNAL	X	X			
31	100268	12	STUD,WHEEL,DRIVE AXLE	X	X			
32	100351	12	NUT,TAPERED	X	X			
33	150065	1	BEARING,TAPER ROLLER	X	X			
34	150069	1	BEARING,TAPER ROLLER	X	X			
35	150018	1	ROLLER,BEARING	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

WHEEL SET

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	260326	6	W/SET,23.5R25,XADN,MICH		X			
1	262068	6	W/SET,23.5R25,RL2+,GOOD		X			
1	262301	6	W/SET,23.5R25,XADN	X				
2	202983	1	TYRE,23.5R25,XADN,MICH	X	X			
2	200499	1	TYRE,23.5R25,2*,MUD/SAND		X			
3	190904	1	WHEEL,3 PCE	X				
3	190859	1	WHEEL,3 PCE		X			
4	226117	1	RING,LOCK	X	X			
5	202043	1	DRIVER,RECTANGULAR	X	X			
6	226122	1	BAND,BEAD SEAT	X	X			
7	NSI	1	RIM BASE	X	X			
8	200437	1	VALVE,JUMBO 63MM SWIVEL	X	X			
9	200438	1	SPUD,TUBELESS	X	X			
10	100351	12	NUT,TAPERED	X	X			

https://truckmanualshub.com/

WHEEL SET (OPTIONAL): B30D (WIDE)



https://truckmanualshub.com/

WHEEL SET (OPTIONAL): B30D (WIDE)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	262300	6	W/SET,750/65R25,XAD65	X				
2	201559	1	TYRE,750/65R25,XAD65,MICH	X				
3	190903	1	WHEEL,3 PCE	X				
4	226117	1	RING,LOCK	X				
5	202043	1	DRIVER,RECTANGULAR	X				
6	226118	1	BAND,BEAD SEAT	X				
7	NSI	1	RIM BASE	X				
8	200437	1	VALVE,JUMBO 63MM SWIVEL	X				
9	200438	1	SPUD,TUBELESS	X				
10	100351	12	NUT,TAPERED	X				


https://truckmanualshub.com/

https://truckmanualshub.com/

SECTION 4: HYDRAULICS

https://truckmanualshub.com/

HYDRAULIC SYSTEM, CAB - DETAIL A



TD0003473 - B


E14832503 SH2-3 B

https://truckmanualshub.com/

HYDRAULIC SYSTEM, CAB - DETAIL A

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
4	243950	1	HOSE	X	X			
5	243949	1	HOSE	X	X			
8	243946	1	HOSE	X	X			
9	243945	1	HOSE	X	X			
10	243944	1	HOSE	X	X			
11	216283	1	RUBBER,ISOLATE,HYDR,CAB,FRONT	X	X			
12	216282	1	RUBBER,ISOLATE,HYDR,CAB,MID	X	X			
15	210247	1	VALVE,STEERING	X	X			
16	207865	1	GASKET,ORBITAL	X	X			
17	207253	1	HOSE,PROTECT,SPIRAL GRD	X	X			
18	206829	8	SPACER,CLAMP,ALUM	X	X			
19	206827	4	CLAMP,ALU,4 BOLT	X	X			
20	206826	4	CLAMP,ALU,2 BOLT	X	X			
21	206825	4	CLAMP,RUBBER,15,UNDER CAB	X	X			
22	206480	5	ISOLATOR,STEERING ORBITAL	X	X			
23	204541	2	MTG,RUBBER CIRCULAR	X	X			
24	187502	1	PLT,RETAIN,HOSES,CAB,MID	X	X			
25	174550	1	MTG,ORBITAL,CAB	X	X			
26	161099	2	BOSS,ORBITAL	X	X			
27	161028	5	WASHER,ORBITAL MTG	X	X			
29	122032	1	ELBOW	X	X			
32	122017	4	CONNECT	X	X			
34	101307	5	WASHER,FLAT	X	X			
35	101156	4	CAPSCREW,SOCHD	X	X			
36	101080	6	WASHER,HARDENED	X	X			
37	100945	3	SCREW,HEXHD	X	X			
38	100733	4	SCREW,HEXHD	X	X			
39	100569	11	SCREW,HEXHD	X	X			
40	100548	16	WASHER,HARDENED	X	X			
41	100543	4	WASHER,FENDER	X	X			
42	100370	7	WASHER,HARDENED	X	X			
43	100314	3	NUT,NYLOC	X	X			
44	100312	8	NUT,NYLOC	X	X			
45	100091	2	SCREW,HEXHD	X	X			
46	100086	2	SCREW,HEXHD	X	X			
47	100084	8	BOLT,HEXHD	X	X			

https://truckmanualshub.com/




TD0003474 A
E14832503 SH3-3 B

https://truckmanualshub.com/

HYDRAULIC SYSTEM, CAB - DETAIL B

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	243954	1	HOSE	X	X			
2	243954	1	HOSE	X	X			
3	243951	1	HOSE	X	X			
6	243948	1	HOSE	X	X			
7	243947	1	HOSE	X	X			
13	216255	1	GASKET,PEDAL,BRAKE,MICO	X	X			
14	210947	1	PEDAL,BRAKE	X	X			
18	206829	8	SPACER,CLAMP,ALUM	X	X			
19	206827	4	CLAMP,ALU,4 BOLT	X	X			
20	206826	4	CLAMP,ALU,2 BOLT	X	X			
21	206825	4	CLAMP,RUBBER,15,UNDER CAB	X	X			
28	122153	1	ELBOW	X	X			
30	122028	2	ELBOW	X	X			
31	122021	3	CONNECT	X	X			
33	120397	1	PLUG,HOLLOW HEX	X	X			
39	100569	11	SCREW,HEXHD	X	X			
40	100548	16	WASHER,HARDENED	X	X			
44	100312	8	NUT,NYLOC	X	X			
47	100084	8	BOLT,HEXHD	X	X			
48	100062	3	WASHER,FLAT	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

BRAKE PEDAL

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	210947	1	BRAKE PEDAL,MICO,120/120 BAR	X	X			
2	226821	1	PEDAL & BASE ASSEMBLY	X	X			
3	NSI	1	PEDAL	X	X			
4	NSI	1	BASE,PEDAL	X	X			
5	NSI	2	SCREW,CAP	X	X			
6	NSI	2	WASHER	X	X			
7	226818	1	KIT,REPAIR,PEDAL & BASE	X	X			
8	NSI	1	PIN	X	X			
9	NSI	2	CIRCLIP	X	X			
10	NSI	2	PIN,SPLIT	X	X			
11	NSI	1	CAM	X	X			
12	NSI	1	PIN	X	X			
13	NSI	2	BUSH	X	X			
14	NSI	2	CIRCLIP	X	X			
15	226817	1	KIT,SWITCH/HARNESS REPAIR	X	X			
16	NSI	2	PIN,SPLIT	X	X			
17	NSI	1	SWITCH AND HARNESS	X	X			
18	NSI	2	SCREW	X	X			
19	NSI	2	SCREW	X	X			
20	NSI	1	INSULATOR	X	X			
21	NSI	1	BRACKET	X	X			
22	NSI	1	BRACKET	X	X			
23	NSI	2	NUT	X	X			
24	NSI	2	WASHER,LOCK	X	X			
25	NSI	1	CLAMP	X	X			
26	NSI	1	SCREW,CAP	X	X			
27	NSI	1	SPACER	X	X			
28	NSI	1	STOP	X	X			
29	226820	1	VALVE ASSEMBLY,120/120 BAR	X	X			
30	NSI	1	HOUSING	X	X			
31	226815	1	KIT,VALVE REPAIR	X	X			
32	NSI	1	CUP	X	X			
33	NSI	1	SEAL	X	X			
34	NSI	1	O-RING	X	X			
35	NSI	1	O-RING	X	X			
36	NSI	1	O-RING	X	X			
37	NSI	1	BOOT	X	X			
38	NSI	2	WASHER	X	X			
39	NSI	1	SPRING	X	X			
40	NSI	1	PLUG,END	X	X			
41	NSI	1	RETAINER	X	X			
42	NSI	1	SPRING	X	X			
43	NSI	1	SPOOL	X	X			
44	NSI	1	SPOOL	X	X			
45	NSI	1	RETAINER ASSY	X	X			
46	NSI	A/R	SHIM	X	X			
47	NSI	1	SPRING	X	X			
48	NSI	1	SPRING	X	X			
49	NSI	1	SPRING	X	X			
50	NSI	1	PISTON	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

STEERING CONTROL VALVE, EATON

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	210247	1	VALVE,STEERING,#20,985CC	X	X			
1	220609	1	PLUG	X	X			
2	220610	1	O,RING	X	X			
3	220697	1	KIT,SEAL ORBITAL VALVE	X	X			
4	220608	2	RACE,BEARING	X	X			
5	220693	1	BEARING,NEEDLE THRUST	X	X			
6	220611	1	RING,RETAINING	X	X			
7	220694	1	SPRING,CENTERING	X	X			
8	220607	7	SCREW,CAP	X	X			

https://truckmanualshub.com/




TD0000008A

https://truckmanualshub.com/

EMERGENCY STEERING PUMP CHECK VALVE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	210791	1	VALVE,CHECK,EMERGENCY STEERING	X	X			REFERENCE PAGES 4-33
2	220606	1	VALVE ,RELIEF	X	X			
3	220605	1	KIT,SEAL,RELIEF VALVE	X	X			
4	120335	5	PLUG	X	X			
5	140806	1	O-RING	X	X			
6	140805	1	O-RING	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

PUMP, EMERGENCY STEERING

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	210493	1	PUMP,EMERGENCY STEERING	X	X			REFERENCE PAGES 4-33
2	223654	1	ROTARY,GROUP	X	X			
3	223648	1	PLATE,DISTRIBUTION	X	X			
4	222285	1	SHIM	X	X			
5	222287	1	BEARING,TAPERED,ROLLER	X	X			
6	222290	1	O-RING	X	X			
7	223214	1	PIN,DOWEL	X	X			
8	226025	1	PLATE,PORT	X	X			
9	223661	4	SCREW,SOC. HEAD	X	X			
10	223657	1	PLATE,SWASH	X	X			
11	222288	2	SHELL,CRADLE	X	X			
12	222284	1	SPRING	X	X			
13	223658	1	SHAFT,DRIVE	X	X			
14	222286	1	BEARING,TAPERED,ROLLER	X	X			
15	222289	1	SEAL,SHAFT	X	X			
16	221366	1	CIRCLIP	X	X			
17	222308	1	PLUG	X	X			
18	222277	1	O-RING	X	X			
19	223655	1	PISTON,CONTROL	X	X			
20	222280	1	ROD,PISTON	X	X			
21	222281	1	HOUSING,PUMP	X	X			
22	221367	1	PLUG	X	X			
23	223247	1	VALVE,PILOT	X	X			
24	223674	4	WASHER,DOWTY,PILOT VALVE CAPS	X	X			
25	223218	3	O-RING	X	X			
26	223220	1	PLUG	X	X			
27	223219	4	SCREW,CAP	X	X			
28	223210	1	O-RING	X	X			
29	223213	1	PLUG	X	X			

https://truckmanualshub.com/



TD0003577 - A
E9836303 SH 1-2 H


https://truckmanualshub.com/

HYDRAULIC KIT: CAB TILT SYSTEM

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	243309	2	HOSE	X	X			
2	243309	2	HOSE	X	X			
3	230152	1	CYLINDER	X	X			REFERENCE PAGES 4-17
4	210920	1	PUMP,MANUAL,TANK CAP	X	X			REFERENCE PAGES 4-19
5	207219	1	SPRING,CABSTRUT	X	X			
6	203923	1	GROMMET	X	X			
7	203764	2	P-CLIP	X	X			
8	203680	2	P-CLIP	X	X			
9	187696	1	BKT,MTG,HOSES,CAB TILT	X	X			
10	186038	1	MTG,CAB,TILT CYL,REAR	X	X			
11	186037	1	MTG,CAB,TILT CYL,FRONT	X	X			
12	174739	1	STAY,CAB	X	X			
13	162456	2	WASHER,SPRING RET,BIN HEAT	X	X			
14	162014	4	WASHER,VESCONITE	X	X			
15	161914	1	PIN,SMALL HEAD	X	X			
16	160432	2	SLEEVE,PEDAL,VESCONITE	X	X			
17	160074	1	BUSH	X	X			
18	122098	2	ELBOW	X	X			
19	122032	2	ELBOW	X	X			
20	101993	1	SCREW,HEXHD	X	X			
21	101345	1	WASHER,HARDENED	X	X			
22	101343	1	WASHER,MILDSTEEL	X	X			
23	100698	1	BOLT,HEXHD	X	X			
24	100653	3	NUT,STOVER	X	X			
25	100652	1	NUT,STOVER	X	X			
26	100644	1	BOLT,HEXHD	X	X			
27	100532	10	WASHER,HARDENED	X	X			
28	100370	2	WASHER,HARDENED	X	X			
29	100356	2	WASHER,COPPER	X	X			
30	100310	3	NUT,NYLOC	X	X			
31	100200	1	BOLT,HEXHD	X	X			
32	100141	1	BOLT,HEXHD	X	X			
33	100081	2	SCREW,HEXHD	X	X			
34	100070	1	SPLITPIN	X	X			
35	100061	6	WASHER,FLAT	X	X			
36	100012	5	WASHER,FLAT	X	X			

https://truckmanualshub.com/

CAB TILT CYLINDER BREAKDOWN




TD0004268
230152 - A

https://truckmanualshub.com/

CAB TILT CYLINDER BREAKDOWN

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	230152	1	CYLINDER	X	X			REFERENCE PAGES 4-15
2	160523	2	BUSH,TILT CYL	X	X			
3	183202	1	BARREL,CAB TILT	X	X			
4	183203	1	ROD,CAB TILT	X	X			
5	100290	1	NUT,CASTLE	X	X			
6	160993	1	NECKBUSH,NUT	X	X			
7	160994	1	NECKBUSH,SET	X	X			
8	161318	1	PISTON	X	X			
9	140565	1	KIT,SEAL	X	X			
10	140059	1	O-RING	X	X			
11	140033	1	SEAL,WIPER	X	X			
12	140044	1	SEAL,SINGLE ACTING	X	X			
13	140368	1	O-RING	X	X			
14	140400	1	RING,BACK UP	X	X			
15	140734	1	O-RING	X	X			
16	100152	1	SPLITPIN	X	X			
17	140032	1	SEAL,PISTON	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

PUMP, CAB TILT

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	210920	1	PUMP,MANUAL,TANK CAP	X	X			REFERENCE PAGES 4-15
2	140660	1	KIT,SERVICE	X	X			

https://truckmanualshub.com/




VOAC PORT FUNCTIONS	
A	BIN TIP UP
B	BIN TIP DOWN
A4	PLUGGED
A5	REAR BRAKE ACCUMULATORS
A6	FRONT BRAKE ACCUMULATORS
B5	BRAKE PEDAL (P)
B6	BRAKE PEDAL (P)
D	TANK
L1	MAIN PUMP (X)
L2	STEERING PUMP (X)
L3	STEERING VALVE (LS)
M4	TEST POINT MANIFOLD (M4)
M5	TEST POINT
M6	TEST POINT
ML1	TEST POINT
ML2	TEST POINT
MP1	TEST POINT MANIFOLD (MP1)
MP2	TEST POINT MANIFOLD (MP2)
MP3	TEST POINT
MR	TEST POINT
P1	MAIN PUMP PRESSURE (B)
P2	STEERING PUMP PRESSURE (B)
P3	STEERING VALVE (P)
S4	LOW ACCUMULATOR BRAKE PRESSURE SWITCH
SP1	EMERGENCY STEERING SWITCH
T2	TANK RETURN
T3	STEERING VALVE (T)
TT	TEMP SENDER UNIT

TD0003214 - B
E14832501 SH2-4 B

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
12	210907	1	VALVE,MANIFOLD	X	X			
23	201737	6	POINT,TEST,HYD	X	X			
27	182999	1	MTG,BRACKET,T3,HYD BLOCK	X	X			
41	122156	2	CONNECT	X	X			
43	122071	1	ELBOW	X	X			
45	122068	1	CONNECT	X	X			
46	122049	4	CONNECT	X	X			
47	122047	2	ELBOW	X	X			
49	122021	2	CONNECT	X	X			
50	122018	6	CONNECT	X	X			
51	122014	1	ELBOW	X	X			
55	120238	8	FLANGE,HALF	X	X			
57	120040	1	PLUG,HEX	X	X			
72	100370	13	WASHER,HARDENED	X	X			
75	100314	4	NUT,NYLOC	X	X			
77	100225	12	CAPSCREW,SOCHD	X	X			
79	100178	4	SCREW,HEXHD	X	X			
80	100089	5	SCREW,HEXHD	X	X			

https://truckmanualshub.com/



TD0004051


https://truckmanualshub.com/

HYDRAULIC, VOAC BLOCK - PRESSURE SWITCH

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218281	1	SWITCH,PRESSURE,123 BAR,S4	X	X			REFERENCE PAGES 6-41
2	218282	1	SWITCH,PRESSURE,5 BAR,SP1	X	X			REFERENCE PAGES 6-41

https://truckmanualshub.com/

HYDRAULIC, VOAC BLOCK - VALVE POSITIONS




https://truckmanualshub.com/

HYDRAULIC, VOAC BLOCK - VALVE POSITIONS

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	210907	1	VOAC BLOCK	X	X			
2	224398	1	VALVE, PRESSURE RELIEF	X	X			ALSO ORDER SEAL KIT ITEM 20
3	224399	1	ORIFICE, 2.5	X	X			
4	221418	1	VALVE, CHECK	X	X			
5	226848	1	VALVE, SHUTTLE	X	X			
6	226849	1	VALVE, PRESSURE REDUCING	X	X			ALSO ORDER SEAL KIT ITEM 25
7	221417	1	VALVE, RELIEF UNLOADING	X	X			ALSO ORDER SEAL KIT ITEM 20
8	221425	1	VALVE, PRESSURE RELIEF	X	X			
9	221420	1	VALVE, DIRECTIONAL CONTROL, 24V	X	X			ALSO ORDER SEAL KIT ITEM 21
10	224363	1	COIL, DIRECTIONAL CONTROL, 24V	X	X			
11	224400	1	ORIFICE, SCREW, 0.7	X	X			
12	226850	1	VALVE, PRIORITY, STEERING	X	X			
13	224401	1	VALVE, CHECK	X	X			ALSO ORDER SEAL KIT ITEM 24
14	224405	1	VALVE, CHECK	X	X			ALSO ORDER SEAL KIT ITEM 22
15	224402	2	VALVE, SHUTTLE	X	X			ALSO ORDER SEAL KIT ITEM 23
16	224406	1	VALVE, PRESSURE RELIEF	X	X			
17	226851	2	COIL, DIRECTIONAL CONTROL	X	X			
18	226852	2	ORIFICE WASHER, 1.2	X	X			
19	226853	1	ORIFICE, SCREW, 0.6	X	X			
20	221422	A/R	KIT, SEAL	X	X			NOT ILLUSTRATED
21	221423	A/R	KIT, SEAL	X	X			NOT ILLUSTRATED
22	221424	A/R	KIT, SEAL	X	X			NOT ILLUSTRATED
23	224413	A/R	KIT, SEAL	X	X			NOT ILLUSTRATED
24	224412	A/R	KIT, SEAL	X	X			NOT ILLUSTRATED
25	226857	A/R	KIT, SEAL	X	X			NOT ILLUSTRATED
26	226858	1	VALVE, BIN TIP SECTION COMPLETE	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

HYDRAULIC, VOAC BLOCK - VALVES

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	210907	1	VOAC BLOCK	X	X			
2	224398	1	VALVE, PRESSURE RELIEF	X	X			ALSO ORDER SEAL KIT ITEM 20
3	224399	1	ORIFICE, 2.5	X	X			
4	221418	1	VALVE, CHECK	X	X			
5	226848	1	VALVE, SHUTTLE	X	X			
6	226849	1	VALVE, PRESSURE REDUCING	X	X			ALSO ORDER SEAL KIT ITEM 25
7	221417	1	VALVE, RELIEF UNLOADING	X	X			ALSO ORDER SEAL KIT ITEM 20
8	221425	1	VALVE, PRESSURE RELIEF	X	X			
9	221420	1	VALVE, DIRECTIONAL CONTROL, 24V	X	X			ALSO ORDER SEAL KIT ITEM 21
10	224363	1	COIL, DIRECTIONAL CONTROL, 24V	X	X			
11	224400	1	ORIFICE, SCREW, 0.7	X	X			
12	226850	1	VALVE, PRIORITY, STEERING	X	X			
13	224401	1	VALVE, CHECK	X	X			ALSO ORDER SEAL KIT ITEM 24
14	224405	1	VALVE, CHECK	X	X			ALSO ORDER SEAL KIT ITEM 22
15	224402	2	VALVE, SHUTTLE	X	X			ALSO ORDER SEAL KIT ITEM 23
16	224406	1	VALVE, PRESSURE RELIEF	X	X			
17	226851	2	COIL, DIRECTIONAL CONTROL	X	X			
18	226852	2	ORIFICE WASHER, 1.2	X	X			
19	226853	1	ORIFICE, SCREW, 0.6	X	X			
20	221422	A/R	KIT, SEAL	X	X			
21	221423	A/R	KIT, SEAL	X	X			
22	221424	A/R	KIT, SEAL	X	X			
23	224413	A/R	KIT, SEAL	X	X			
24	224412	A/R	KIT, SEAL	X	X			
25	226857	A/R	KIT, SEAL	X	X			

https://truckmanualshub.com/

1




TD0003926

https://truckmanualshub.com/

HYDRAULIC, VOAC BLOCK - TIP SECTION

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	226858	1	VALVE,BIN TIP SECTION COMPLETE	X	X			
2	226859	2	KIT,CAP TIP LEVER	X	X			
3	226860	1	KIT,SEAL,SPOOL STOP	X	X			
4	226861	1	KIT,SPRING	X	X			
5	226862	1	VALVE,RELIEF,080	X	X			INCLUDES ITEM 7
6	226863	1	VALVE,RELIEF,280	X	X			INCLUDES ITEM 7
7	226864	2	KIT,SEAL,RELIEF VALVE	X	X			
8	226865	2	SPOOL,LS	X	X			
9	140988	1	KIT,SEAL INTERSECTION	X	X			
10	226866	1	VALVE,CHECK	X	X			
11	226867	1	ORIFICE	X	X			

https://truckmanualshub.com/




TD0003218 - B
E14832501 SH3-4 B

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
4	243339	1	HOSE	X	X			PART OF KIT 262230
5	243338	1	HOSE	X	X			PART OF KIT 262230
10	230167	2	CYL,D60XD100X468S	X	X			
16	207788	2	SPACER,STEER PLASTIC	X	X			
28	176408	2	PIN,D60X116L,EXPANDER	X	X			
29	176407	4	CONE,STEER TOP	X	X			
30	176406	2	PLT,STEER TOP	X	X			
32	162394	2	PLT,LOCATING	X	X			
33	162384	2	PLT,LOWER,STEERING	X	X			
34	150044	2	BEARING,CARB	X	X			
36	140398	2	O-RING	X	X			
37	140162	4	O-RING	X	X			
42	122107	2	TEE,RUN	X	X			
50	122018	6	CONNECT	X	X			
58	101048	2	CAPSCREW,SOCHD	X	X			
59	101021	2	CAPSCREW,SOCHD	X	X			
61	100927	2	BOLT,HEXHD	X	X			
66	100654	2	NUT,STOVER	X	X			
67	100653	4	NUT,STOVER	X	X			
69	100536	6	WASHER,HARDENED	X	X			
70	100532	8	WASHER,HARDENED	X	X			
74	100322	4	NUT,HEX	X	X			

https://truckmanualshub.com/




TD0003226 - B
E14832501 SH4-4 B


https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	243875	1	HOSE	X	X			PART OF KIT 262230
2	243875	1	HOSE	X	X			PART OF KIT 262230
3	243396	1	HOSE	X	X			PART OF KIT 262230
6	243317	1	HOSE	X	X			PART OF KIT 262230
7	243316	1	HOSE	X	X			PART OF KIT 262230
8	243315	1	HOSE	X	X			PART OF KIT 262230
9	243003	1	HOSE	X	X			PART OF KIT 262230
11	223816	1	FILTER,FUEL	X	X			
13	210791	1	VALVE,CHECK,E/STEER	X	X			REFERENCE PAGES 4-11
14	210493	1	PUMP,#52 A10VO28 E/STEER	X	X			REFERENCE PAGES 4-13
15	210492	1	PUMP,#31 A10VO74 SERVICE	X	X			
17	207251	1	HOSE,PROTECT,SPIRAL GUARD	X	X			
18	207124	1	CLAMP,RUBBER	X	X			
19	207117	1	P-CLIP	X	X			
20	206945	1	MTG,RUBBER	X	X			
21	206829	2	SPACER,CLAMP,ALUM	X	X			
22	206658	2	CLAMP,ALU,2 BOLT	X	X			
24	200653	1	CABLE TIE	X	X			
25	200062	1	CLAMP,HOSE	X	X			
26	186890	1	BKT,BREATHER,AXLE	X	X			
31	162404	2	WASHER	X	X			
35	140728	1	O-RING	X	X			
38	140159	1	O-RING	X	X			
39	130001	1	HOSE,PUSHLOCK	X	X			
40	122192	1	ELBOW	X	X			
41	122156	2	CONNECT	X	X			
44	122069	1	ELBOW	X	X			
48	122032	2	ELBOW	X	X			
52	121275	1	MALE-8	X	X			
53	120596	1	CONNECT	X	X			
55	120238	8	FLANGE,HALF	X	X			
56	121443	1	FTG,PUSHLOCK	X	X			
60	100952	4	CAPSCREW,SOCHD	X	X			
62	100848	4	CAPSCREW,SOCHD	X	X			
63	100847	4	CAPSCREW,SOCHD	X	X			
64	100747	2	BOLT,HEXHD	X	X			
65	100731	1	SCREW,HEXHD	X	X			
68	100548	5	WASHER,HARDENED	X	X			
69	100536	6	WASHER,HARDENED	X	X			
71	100424	2	WASHER,HARDENED	X	X			
72	100370	13	WASHER,HARDENED	X	X			
73	100365	2	SCREW,HEXHD	X	X			
75	100314	4	NUT,NYLOC	X	X			
76	100312	2	NUT,NYLOC	X	X			
78	100212	2	SCREW,HEXHD	X	X			
80	100089	5	SCREW,HEXHD	X	X			
82	125008	1	CONNECTOR	X	X			

https://truckmanualshub.com/



ISO VIEW



TOP VIEW

TD0004043 B
264137 A


https://truckmanualshub.com/

ACCUMULATOR KIT - SOUTH AFRICA


ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264137	1	KIT,ACCU,S/AFRICA	X	X			
1	210923	2	ACCUM,PISTON,CRIMPED	X	X			
2	187318	1	CLAMP,2 ACCUMULATORS	X	X			
3	122257	2	REDUCER	X	X			
4	122008	2	ELBOW	X	X			
5	101309	1	WASHER,FENDER	X	X			
6	101211	1	BOLT,J	X	X			
7	100312	1	NUT,NYLOC	X	X			

https://truckmanualshub.com/

A



ISO VIEW



TOP VIEW


TD0005032
264138

https://truckmanualshub.com/

ACCUMULATOR KIT - EUROPE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264138	1	KIT,ACCU,EURO	X	X			
1	210244	2	PISTON,ACCUM	X	X			
2	187318	1	CLAMP,2 ACCUMULATORS	X	X			
3	122257	2	REDUCER	X	X			
4	122008	2	ELBOW	X	X			
5	101309	1	WASHER,FENDER	X	X			
6	101211	1	BOLT,J	X	X			
7	100312	1	NUT,NYLOC	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/


ACCUMULATOR KIT, WDB OPTION - SOUTH AFRICA

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264139	1	KIT,ACCU,S/AFRICA,WDB	X				
1	243876	1	HOSE	X				
2	210923	3	ACCUM,PISTON,CRIMPED	X				
3	187319	1	CLAMP,2 ACCUMULATORS	X				
4	122263	1	TEE,BRANCH	X				
5	122257	3	REDUCER	X				
6	122008	2	ELBOW	X				
7	101309	2	WASHER,FENDER	X				
8	101211	2	BOLT,J	X				
9	100312	2	NUT,NYLOC	X				

https://truckmanualshub.com/



ISO VIEW



TOP VIEW

TD0005033
264140


https://truckmanualshub.com/

ACCUMULATOR KIT, WDB OPTION - EUROPE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264140	1	KIT,ACCU,EURO,B30D,WDB	X				
1	243876	1	HOSE	X				
2	210250	3	ACCUM,PISTON,CRIMPED	X				
3	187319	1	CLAMP,2 ACCUMULATORS	X				
4	122263	1	TEE,BRANCH	X				
5	122008	2	ELBOW	X				
6	101309	2	WASHER,FENDER	X				
7	101211	2	BOLT,J	X				
8	100312	2	NUT,NYLOC	X				

https://truckmanualshub.com/

HYD. SYS, FRONT AXLE COOLING, WDB OPTION




https://truckmanualshub.com/

HYD. SYS, FRONT AXLE COOLING, WDB OPTION

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264415	1	KIT,WDB COOLING,F/AXLE	X				
1	241575	1	HOSE	X				
2	241574	1	HOSE	X				
3	241573	1	HOSE	X				
4	210963	1	FILTER,HYD	X				
5	210959	1	PUMP,CASSAPA GEAR	X				
6	201438	1	P-CLIP	X				
7	187796	1	BKT,FILTER,WDB COOLING	X				
8	122165	1	TEE,RUN	X				
9	122120	1	CAP	X				
10	122020	2	ELBOW	X				
11	122017	1	CONNECT	X				
12	122015	1	CONNECT	X				
13	120101	1	ELBOW	X				
14	100821	2	CAPSCREW,SOCHD	X				
15	100663	2	WASHER	X				
16	100569	2	SCREW,HEXHD	X				
17	100312	2	NUT,NYLOC	X				
18	100310	1	NUT,NYLOC	X				
19	100081	1	SCREW,HEXHD	X				
20	100062	4	WASHER,FLAT	X				
21	100061	4	WASHER,FLAT	X				
22	100005	2	SCREW,HEXHD	X				


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	210492	1	PUMP,#31 A10VO74 SERVICE,D#ADT	X	X			
1	223219	4	CAP SCREW	X	X			
2	223247	1	PILOT VALVE DFRI COMPLETE	X	X			
3	223220	1	PLUG	X	X			
4	223218	3	O-RING	X	X			
5	100256	4	CAPSCREW,SOCHD	X	X			
6	223244	4	O-RING	X	X			
7	226039	1	PLATE,PORT A10V	X	X			
8	223213	1	TEAR-OFF-PLUG	X	X			
9	223214	1	DOWEL PIN	X	X			
10	223246	1	PLUG VSTI	X	X			
11	226046	1	PISTON,CONTROL	X	X			
12	226047	1	GUIDE,PISTON	X	X			
13	223259	1	COUNTER PISTON	X	X			
14	223261	1	SPRING	X	X			
15	223260	1	SPRING	X	X			
16	226037	1	GROUP,ROTARY A10V	X	X			
17	224693	3	PIN,PRESSURE	X	X			
18	223248	9	PISTON	X	X			
19	223238	1	SHIM	X	X			
20	223240	1	TAPERED ROLLER BEARING	X	X			
21	223237	1	DISC	X	X			
22	223235	1	SWASH PLATE	X	X			
23	223241	2	CRADLE,SHELL	X	X			
24	226040	1	SHAFT,DRIVE	X	X			
25	223239	1	TAPERED ROLLER BEARING	X	X			
26	223243	1	O-RING	X	X			
27	223233	1	PUMP HOUSING	X	X			
28	223212	1	PLUG	X	X			
29	140062	1	O-RING	X	X			
30	223245	1	SEEGER-V-RING	X	X			
31	223242	1	SHAFT SEAL	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

STEERING CYLINDER ASSEMBLY

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	230167	2	CYL,D60XD100X468S	X	X			
1	181693	1	ROD,CYL,STEER,CARB	X	X			
2	181675	1	BARREL,STEER,D100,#8MOR	X	X			
3	161071	1	NECKBUSH	X	X			
4	161020	1	PISTON	X	X			
5	140438	1	KIT,SEAL,STEERING CYL	X	X			
6	100430	1	SPLITPIN	X	X			
7	100334	1	NUT,CASTLE	X	X			
8	200036	1	NIPPLE,GREASE	X	X			
9	206074	1	BEARING,2 BOLT	X	X			
10	202599	1	CIRCLIP:INTERNAL	X	X			
11	206075	1	SPACER,SPHERICAL BRG	X	X			

https://truckmanualshub.com/




TD0003677 - B
E14832504 SH 2-3 - C

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	243340	1	HOSE	X	X			PART OF KIT 262219
2	243331	1	HOSE	X	X			PART OF KIT 262219
3	243330	1	HOSE	X	X			PART OF KIT 262219
4	243329	1	HOSE	X	X			PART OF KIT 262219
5	243328	1	HOSE	X	X			PART OF KIT 262230
6	243320	1	HOSE	X	X			PART OF KIT 262219
7	243319	1	HOSE	X	X			PART OF KIT 262219
8	243318	1	HOSE	X	X			PART OF KIT 262230
9	243304	1	HOSE	X	X			PART OF KIT 262219
10	243303	2	HOSE	X	X			PART OF KIT 262219
11	243027	1	HOSE	X	X			PART OF KIT 262230
12	241414	1	HOSE	X	X			
14	218928	1	HOSE,SUCTION,HYD TANK	X	X			
15	218469	1	PIPE,SUCTION,HYD,B25D	X	X			
19	208823	1	CLAMP,T-BOLT	X	X			
20	208822	3	CLAMP,T-BOLT	X	X			
25	207283	1	PIPE,SUCTION,HYD PUMP,B25D	X	X			
26	207252	1	HOSE PROTECT,SPIRAL GUARD,75ID	X	X			
28	206467	2	CLIP,P-CLIP,WITH BOLT	X	X			
30	204169	2	CLAMP,SEALING	X	X			
31	201737	3	TEST POINT,6MOR	X	X			
39	173954	1	PLATE,LOCK BULKHEAD	X	X			
40	173782	1	MANIFOLD,3 PORT,HYD TEST POINT	X	X			
42	140731	1	O-RING	X	X			
44	140728	3	O-RING	X	X			
45	122157	1	CONNECTOR	X	X			
46	122154	2	ELBOW	X	X			
47	122279	1	ELBOW	X	X			
49	122092	1	CONNECTOR	X	X			
50	122091	2	CONNECTOR	X	X			
51	122049	3	CONNECTOR	X	X			
52	122028	1	ELBOW	X	X			
53	120222	2	FLANGE,HALF 2”	X	X			
54	100731	26	SCREW	X	X			
56	100548	48	WASHER,HARDENED	X	X			
58	100370	8	WASHER,HARDENED	X	X			
59	100364	2	SCREW,HEXHD	X	X			
60	100314	8	NUT,NYLOC CLASS	X	X			
64	100091	2	SCREW,HEXHD	X	X			
66	100021	4	CAPSRW,SOCHD	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	243341	2	HOSE	X	X			PART OF KIT 262218
2	243157	2	HOSE	X	X			PART OF KIT 262218
3	241232	1	HOSE	X	X			PART OF KIT 262218
4	241231	1	HOSE	X	X			PART OF KIT 262218
5	241230	1	HOSE	X	X			PART OF KIT 262218
6	241229	1	HOSE	X	X			PART OF KIT 262218
7	230345	1	CYL,TIP,MK2,D70XD100,RHS,B30D	X				REFER PAGES 4-53
7	230347	1	CYL,TIP,MK2,D70XD100,RHS,B25D		X			REFER PAGES 4-53
8	230344	1	CYL,TIP,MK2,D70XD100,LHS,B30D	X				REFER PAGES 4-53
8	230346	1	CYL,TIP,MK2,D70XD100,LHS,B25D		X			REFER PAGES 4-53
9	223816	2	FILTER,FUEL	X	X			
10	218797	1	CLAMP,K	X	X			
11	207637	4	COVER,DUST,SEALED BEARING	X	X			
12	206945	3	MTG,RUBBER	X	X			
13	203349	3	K-CLAMP	X	X			
14	201885	4	CLAMP,RUBBER	X	X			
15	200062	4	CLAMP,HOSE	X	X			
16	200050	4	CLAMP,HOSE	X	X			
17	200038	2	NIPPLE,GREASE	X	X			
18	176516	1	MTG PLT,RHS,BIN PIPES	X	X			
19	176515	1	MTG PLT,LHS,BIN PIPES	X	X			
20	174579	1	ASSY,MTG,BIN PIPES	X	X			
21	174578	1	PLT,COVER,BIN PIPES	X	X			
22	172816	1	PIPE,HYD BRAKES,REAR	X	X			
23	172815	2	PIPE,TIP,BIN UP AND DOWN	X	X			
24	172814	1	PIPE,HYD BRAKES,FRONT	X	X			
25	162404	4	WASHER	X	X			
26	161017	4	BOSS	X	X			
27	130001	1	HOSE,PUSHLOCK	X	X			
28	130001	1	HOSE,PUSHLOCK	X	X			
29	122189	1	TEE,BRANCH	X	X			
30	122157	1	CONNECT	X	X			
31	122149	2	TEE,SPEC	X	X			
32	122148	2	CONNECT	X	X			
33	122015	2	CONNECT	X	X			
34	121275	2	MALE-8	X	X			
35	120671	2	BULKHEAD	X	X			
36	120161	2	ADAPTOR,BARBED	X	X			
37	120148	1	CONNECTOR	X	X			
38	120106	1	CONNECTOR	X	X			
39	100887	8	CAPSCREW,SOCHD	X	X			
40	100757	1	BOLT,HEXHD	X	X			
41	100619	6	SCREW,HEXHD	X	X			
42	100532	8	WASHER,HARDENED	X	X			
43	100424	8	WASHER,HARDENED	X	X			
44	100370	24	WASHER,HARDENED	X	X			
45	100322	4	NUT,HEXAGON	X	X			
46	100316	4	NUT,NYLOC	X	X			
47	100314	8	NUT,NYLOC	X	X			
48	100310	6	NUT,NYLOC	X	X			
49	100089	16	SCREW,HEXHD	X	X			
50	100061	7	WASHER,FLAT	X	X			

https://truckmanualshub.com/

TIP CYLINDER BREAKDOWN



Note:
All items marked with * form part of Seal Kit 140257

230344
230345
230346
230347
TD0004283 A

https://truckmanualshub.com/

TIP CYLINDER BREAKDOWN


ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	230344	1	CYL,TIP,MK2,D70XD100,LHS,B30D	X				REFER PAGES 4-51
A	230345	1	CYL,TIP,MK2,D70XD100,RHS,B30D	X				REFER PAGES 4-51
A	230346	1	CYL,TIP,MK2,D70XD100,LHS,B25D		X			REFER PAGES 4-51
A	230347	1	CYL,TIP,MK2,D70XD100,RHS,B25D		X			REFER PAGES 4-51
1	T105773	2	GUIDE	X	X			
2	206074	1	SPHERICAL BRG	X	X			
3	206075	1	SPACER,SPHERICAL BRG	X	X			
4	202599	1	CIRCLIP,INTERNAL	X	X			
5	200085	2	CLAMP,HOSE	X	X			
6	186961	1	PIPE,OIL LEAD,TIP CYL,B25D		X			
6	186960	1	PIPE,OIL LEAD,TIP CYL,B30D	X				
7	182989	1	BARREL,TIP MK2,D100,B25D		X			
7	182988	1	BARREL,TIP,MK2,D100,B30D	X				
8	181539	1	ASSY,ROD,CYL,LIFT,B25D		X			
8	181551	1	ASSY,ROD,CYL,LIFT,B30D	X				
9	162424	1	NECKBUSH	X	X			
10	162423	1	NUT,NECKBUSH	X	X			
11	161312	1	PISTON	X	X			
12	150191	1	BEARING,SEALED	X	X			
13	140836	1	RING,QUAD	X	X			
14	140702	1	W/BAND,ROD	X	X			*
15	140623	1	O-RING	X	X			
16	140613	1	SEAL,WIPER	X	X			*
17	140201	1	O-RING	X	X			*
18	140160	1	U-SEAL	X	X			
19	140103	1	RING,ANTI-EXTRUSION	X	X			*
20	140031	1	SEAL,PISTON	X	X			*
21	140020	1	O-RING	X	X			*
22	122015	1	CONNECT	X	X			
23	100455	1	NUT,LOCK	X	X			
24	100430	1	SPLITPIN	X	X			*
25	100341	1	NUT,CASTLE	X	X			
-	140257	1	KIT,SEAL,TIP CYL	X	X			INCLUDES ITEMS MARKED (*)

https://truckmanualshub.com/

https://truckmanualshub.com/

SECTION 5: PNEUMATICS

https://truckmanualshub.com/




https://truckmanualshub.com/

PNEUMATIC KIT, CAB

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	243888	1	HOSE	X	X			
2	241460	1	HOSE	X	X			
3	241459	1	HOSE	X	X			
4	241223	1	HOSE	X	X			
5	216692	1	VALVE,BLOCK,IPM,SMALL	X	X			
6	140193	1	O-RING	X	X			
7	130029	1	PIPE,AIR LINE	X	X			
8	120313	1	BULKHEAD	X	X			
9	120157	1	CONNECTOR	X	X			
10	100588	1	G-RING	X	X			

https://truckmanualshub.com/

KIT, AIR HORN (OPTIONAL)




https://truckmanualshub.com/

KIT, AIR HORN (OPTIONAL)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	241461	1	HOSE	X	X			
2	210067	1	HORN,AIR,TWIN	X	X			
3	203923	1	GROMMET	X	X			
4	121350	1	ELBOW	X	X			
5	120680	1	CONNECTOR	X	X			
6	120352	1	ADAPTOR	X	X			
7	100312	1	NUT,NYLOC	X	X			
8	100081	1	SCREW,HEXHD	X	X			
9	100061	2	WASHER,FLAT	X	X			

https://truckmanualshub.com/

PNEUMATIC BLOCK ASSEMBLY




https://truckmanualshub.com/

PNEUMATIC BLOCK ASSEMBLY

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	216692	1	VALVE, BLOCK, IPM, SMALL, G2	X	X			
2	210833	2	VALVE, SOLENOID	X	X			
3	221589	2	GASKET, SOLENOID/MANIFOLD	X	X			
4	221585	4	GASKET, BLOCK/PILOT, INTERFACE	X	X			
5	221587	4	SCREW, CAP, SOLENOID	X	X			
6	210905	4	SOLENOID, PILOT VALVE, 24V	X	X			
7	221586	8	SCREW, BODY/PILOT VALVE	X	X			
8	206387	2	SWITCH, PRESSURE, (NC), 5 BAR	X	X			
9	221590	2	O-RING, PRESSURE SWITCH	X	X			
10	201375	1	PRESSURE SENDER, 0-10 BAR, SWITCH	X	X			
11	221595	1	SCREW, PRESSURE SENDER	X	X			
12	120631	1	FITTING, TUBE	X	X			
13	210731	1	MANIFOLD, TYRE TOWER INFLATOR	X	X			
14	221594	1	O-RING, TYRE TOWER MANIFOLD	X	X			
15	120640	1	FITTING, HOSE	X	X			
16	121186	1	ADAPTOR	X	X			
17	120322	2	PLUG, WITH O-RING	X	X			
18	226831	3	DISC, FILTER, 16MM	X	X			
19	226832	3	CIRCLIP, INTERNAL	X	X			
20	226835	1	KIT, SERVICE, QUICK EXHAUST VALVE	X	X			
21	226870	1	BODY, QUICK EXHAUST VALVE	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	264042	1	KIT,AIR DRYER	X	X			
2	264041	2	KIT,10L RESERVOIR	X	X			
3	243887	1	HOSE	X	X			
4	241458	1	HOSE	X	X			
5	241458	1	HOSE	X	X			
6	241455	1	HOSE	X	X			
7	241454	1	HOSE	X	X			
8	241454	1	HOSE	X	X			
9	217855	1	HOSE,TEFLON	X	X			
10	210547	1	VALVE,PURGE TANK	X	X			REFERENCE PAGE 5-11
11	187418	1	PIPE,INTERM,PNEUM,COOL	X	X			
12	187252	1	PIPE,PNEUM,COOLING	X	X			
13	187245	1	BKT,FNT,PIPE,COMPRES	X	X			
14	160510	5	CLAMP,ALUM	X	X			
15	121024	1	TEE,BRANCH	X	X			
16	120970	1	CONNECTOR	X	X			
17	120804	3	ELBOW	X	X			
18	120758	1	UNION	X	X			
19	120286	1	UNION	X	X			
20	120258	1	ELBOW,UNION	X	X			
21	100706	3	SCREW,HEXHD	X	X		TO VIN. 3319	REFER SIB 2006/1064
21	101225	3	SCREW,HEXHD	X	X		FROM VIN. 3320	REFER SIB 2006/1064
22	100524	1	WASHER,ALUMINIUM,SEAL	X	X			
23	100364	2	SCREW,HEXHD	X	X			
24	100314	2	NUT,NYLOC	X	X			
25	100148	3	WASHER,FLAT	X	X			
26	100064	4	WASHER,FLAT	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

PURGE TANK VALVE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	210547	1	VALVE,PURGE TANK	X	X			REFERENCE PAGE 5-9
2	NSI	1	BODY,VALVE	X	X			
3	NSI	1	COVER,VALVE	X	X			
4	NSI	4	SCREW,CAP	X	X			
5	NSI	1	DIAPHRAGM	X	X			INCLUDED IN SEAL KIT
6	NSI	1	SPRING,PRESSURE	X	X			INCLUDED IN SEAL KIT
7	226024	1	SOLENOID	X	X			
8	NSI	1	O-RING	X	X			
9	NSI	1	TUBE,CORE	X	X			
10	NSI	1	SPRING	X	X			INCLUDED IN SEAL KIT
11	NSI	1	CORE	X	X			INCLUDED IN SEAL KIT
12	NSI	1	O-RING	X	X			INCLUDED IN SEAL KIT
13	NSI	1	CLIP,SPRING	X	X			
14	121086	1	ADAPTOR	X	X			
15	140462	2	WASHER,DOWTY	X	X			
16	121045	1	ADAPTOR	X	X			
17	140628	1	KIT,SEAL	X	X			INCLUDES ITEMS 5, 6, 10, 11 & 12
18	201529	1	PLUG,CONNECTING	X	X			NOT PART OF VALVE

https://truckmanualshub.com/




https://truckmanualshub.com/

KIT, AIR DRIER

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264042	1	Kit,Air Dryer	X	X			
1	220949	1	FILTER,AIR DRIER	X	X			
2	210561	1	VALVE,UNLOADER,AIR DRIER	X	X			
3	203895	1	RESERVOIR,AIR,5L CE MARK	X	X			
4	200318	1	MOUNTING BAND	X	X			
5	140370	6	O-RING	X	X			
6	140193	1	O-RING	X	X			
7	121365	2	ADAPTOR	X	X			
8	121364	1	CONNECT	X	X			
9	120399	3	PLUG,BLANKING	X	X			
10	120157	1	CONNECTOR	X	X			
11	100590	6	G-RING	X	X			
12	100588	1	G-RING	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

KIT, REPAIR, AIR DRIER

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	210561	1	VALVE,UNLOADER,AIR DRYER	X	X			
2	220949	1	FILTER,AIR DRYER	X	X			
3	221703	1	ELEMENT,HEATING,AIR DRYER	X	X			
4	223714	1	KIT,REPAIR AIR DRYER	X	X			INCLUDES ITEMS MARKED *
5	*	1	WASHER,RUBBER	X	X			
6	*	1	O-RING	X	X			
7	*	1	PLASTIC PISTON	X	X			
8	*	1	O-RING	X	X			
9	*	1	O-RING	X	X			
10	*	1	SEAT,RUBBER	X	X			
11	*	1	O-RING	X	X			
12	*	1	O-RING	X	X			
13	*	1	VALVE,POPPET	X	X			
14	*	2	O-RING	X	X			
15	*	1	O-RING	X	X			
16	*	1	O-RING	X	X			
17	*	1	SPACER,RUBBER	X	X			
18	*	1	O-RING	X	X			
19	*	1	O-RING	X	X			
20	*	1	O-RING	X	X			
21	*	1	WASHER,COPPER	X	X			
22	*	1	O-RING,HEATING ELEMENT	X	X			

https://truckmanualshub.com/




TD0003200 - A
264041 - 0

https://truckmanualshub.com/

KIT, 10L RESERVOIR

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264041	1	KIT,10L RESERVOIR	X	X			
1	203896	1	RESEVOIR,AIR,10L	X	X			
2	200318	2	MTG,BAND	X	X			
3	140370	4	O-RING	X	X			
4	121365	2	ADAPTOR	X	X			
5	121364	1	CONNECT	X	X			
6	120166	1	VALVE,DRAIN	X	X			
7	100590	4	G-RING	X	X			

https://truckmanualshub.com/



https://truckmanualshub.com/

PNEUMATIC KIT, REAR CHASSIS

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	120969	1	CONNECTOR	X	X			
2	241206	1	HOSE	X	X			PART OF KIT 262224


https://truckmanualshub.com/

https://truckmanualshub.com/

SECTION 6: ELECTRICAL

https://truckmanualshub.com/

CAB HARNESS & RELATED COMPONENTS - DETAIL A



514850602 SH1-3 A
TD0003557 A


https://truckmanualshub.com/

CAB HARNESS & RELATED COMPONENTS - DETAIL A

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
19	216412	1	HARNESS,REAR WIPER	X	X			
20	216221	1	HARNESS,CAB	X	X			
28	207288	22	MTG,SWIVEL HEAD	X	X			

https://truckmanualshub.com/

CAB HARNESS & RELATED COMPONENTS - DETAIL B




https://truckmanualshub.com/

CAB HARNESS & RELATED COMPONENTS - DETAIL B

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
2	900450	1	PIPE,W/WASHER	X	X			
6	217902	2	FRAME,SWITCH,CARLING	X	X			
7	217745	1	WASHER,BOTTLE AND PUMP	X	X			
8	217737	1	FRAME,SWITCH,3 PLACES	X	X			
9	217736	1	FRAME,SWITCH,1 PLACE	X	X			
10	217735	1	SWITCH,PARK BRAKE	X	X			
11	217724	1	SWITCH,HAZARD	X	X			
12	217672	1	LEVER,PARKER	X	X			
14	216702	2	P-CLIP	X	X			
21	216168	1	E-MODULE,MDU2	X	X			
22	216167	1	E-MODULE,SSM	X	X			
23	216088	1	SWITCH,STEERING COLUMN	X	X			
24	216037	1	SOCKET,12V,ACCESSORY	X	X			
25	216017	1	BUZZER	X	X			
27	208158	1	COVER,PLUG,COLUMN SWITCH	X	X			
30	206940	1	LIGHT,INTERIOR	X	X			
31	206306	1	NUT,IGNITION SWITCH MTG	X	X			
32	206258	1	SWITCH,IGNITION	X	X			
33	206070	1	THROTTLE,FOOT ACTUATOR	X	X			
36	202729	1	CIGARETTE LIGHTER	X	X			
38	200871	54	CABLE TIE	X	X			
41	187559	1	PLT,MTG,BIN TIP LEVER	X	X			
43	176435	1	WASHER,CIG LIGHTER	X	X			
44	176434	1	WASHER,IGNITION	X	X			
45	161081	1	SLEEVE	X	X			
46	101997	4	CAPSCREW,SOCHD	X	X			
47	101235	4	SCREW,PANHD	X	X			
48	101216	1	WASHER,SERRATED	X	X			
55	100594	4	WASHER,FENDER	X	X			
57	100370	1	WASHER,HARDENED	X	X			
59	100309	4	NUT,NYLOC	X	X			
61	100196	3	BOLT,HEXHD	X	X			
63	100085	1	SCREW,HEXHD	X	X			
64	100080	10	SCREW,HEXHD	X	X			
67	100062	3	WASHER,FLAT	X	X			
68	100061	8	WASHER,FLAT	X	X			

https://truckmanualshub.com/

CAB HARNESS & RELATED COMPONENTS - DETAIL C




https://truckmanualshub.com/

CAB HARNESS & RELATED COMPONENTS - DETAIL C


ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	DC221726	1	ELECTRONICS,KSA FLAME START	X	X			
3	900450	1	PIPE,W/WASHER	X	X			
4	263441	1	KIT,WIPER	X	X			REFERENCE PAGES 6-11
5	217999	2	E-MODULE,CCU2	X	X			
13	217551	1	E-MODULE,BATT BALANCER	X	X			
15	216650	2	TRAY,E-MODULE	X	X			
16	216645	2	ISOLATOR,RUBBER	X	X			
17	216527	1	STRAP,EARTH	X	X			
18	216451	4	FOOT,TRAY,E-MODULE	X	X			
26	208771	1	GROMMET	X	X			
29	206945	1	MTG,RUBBER	X	X			
34	206065	1	E-MODULE,ADM	X	X			
35	203264	9	GROMMET,BLANK	X	X			
37	202094	3	GROMMET,FLAT SPLIT	X	X			
38	200871	54	CABLE TIE	X	X			
39	187775	2	PLT,MTG,TRAY,E-MODULE	X	X			
40	187701	1	PLT,RETAINER,DEUTSCH PLUG	X	X			
42	187506	1	PLT,ADM	X	X			
49	101193	6	WASHER,SPRING	X	X			
50	101171	8	SCREW,PANHD	X	X			
51	101170	3	SCREW,PANHD	X	X			
52	101168	4	SCREW,PANHD	X	X			
53	101167	11	WASHER,SPRING	X	X			
54	100615	12	WASHER,FLAT	X	X			
56	100548	2	WASHER,HARDENED	X	X			
58	100310	6	NUT,NYLOC	X	X			
60	100283	2	NUT,HEXAGON	X	X			
62	100189	2	SCREW,HEXHD	X	X			
64	100080	10	SCREW,HEXHD	X	X			
65	100065	2	WASHER,SPRING	X	X			
66	100063	13	WASHER,FLAT	X	X			
68	100061	8	WASHER,FLAT	X	X			
69	100054	4	WASHER,SPRING	X	X			

https://truckmanualshub.com/

COMPONENT DETAIL



DETAIL OF FUSES / RELAYS / DIODE POSITIONING ON MODULE




TD0004588

https://truckmanualshub.com/

FUSE AND RELAY PANEL COMPONENTS

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	206350	31	FUSE,10A,BLADE TYPE	X	X			
2	207114	2	FUSE,30A,BLADE TYPE	X	X			
3	207115	2	FUSE,25A,BLADE TYPE	X	X			
4	207116	8	FUSE,20A,BLADE TYPE	X	X			
5	207118	2	FUSE,15A,BLADE TYPE	X	X			
6	207027	1	DIODE,3A,SPADE TERMINAL	X	X			
7	216462	1	FUSE,BLANK,BLADE TYPE	X	X			
8	216945	1	FUSE,40A,BLADE TYPE	X	X			
9	217717	4	RELAY,24V	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

KIT, WIPER

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	263441	1	KIT,WIPER	X	X			REFERENCE PAGES 6-7
1	217619	1	ARM,WIPER	X	X			
2	210895	1	VALVE,NON RETURN	X	X			
3	217620	3	CLIPS,WASHER SYSTEM	X	X			
4	217621	1	NOZZLE,6 WAY,WASHER SYSTEM	X	X			
5	217617	AR	PIPE,W/WASHER KIT	X	X			
6	217618	1	BLADE,WIPER	X	X			
7	210896	1	MOTOR,WIPER	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	217910	1	E-MODULE,TCU	X	X			
2	216220	1	HARNESS	X	X			
3	207288	1	MTG,BONDED	X	X			
4	206345	1	SELECTOR,SHIFT	X	X			
5	176315	1	PLT,SPREADER,GEAR LEVER	X	X			
6	101171	2	SCREW,PANHD	X	X			
7	101170	2	SCREW,PANHD	X	X			
8	101167	4	WASHER,SPRING	X	X			
9	100083	2	SCREW,HEXHD	X	X			
10	100063	4	WASHER,FLAT	X	X			
11	100062	2	WASHER,FLAT	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

REAR VIEW MIRROR ELECTRICAL KIT (CHOICE)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264241	1	KIT,MIRRORS,ELEC,ADJ	X	X			
1	216456	1	HARNESS,LH	X	X			
2	216455	1	HARNESS,RH	X	X			
3	216002	2	MIRROR,WIDE	X	X			REFERENCE PAGE 6-17 ; 6-19
4	216001	2	MIRROR,ELECTRIC	X	X			REFERENCE PAGE 6-19
5	207662	2	CONDUIT,265MM	X	X			
6	207453	1	CONDUIT,670MM	X	X			
7	207453	1	CONDUIT,670MM	X	X			
8	207031	1	SWITCH	X	X			
9	206945	2	MTG,RUBBER	X	X			
10	200653	2	CABLE TIE	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

REAR VIEW MIRROR MANUAL KIT (CHOICE)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264242	1	KIT,MIRRORS,MANUAL,ADJ	X	X			
1	216003	2	MIRROR,MANUAL	X	X			REFERENCE PAGE 6-19
2	216002	2	MIRROR,WIDE	X	X			REFERENCE PAGE 6-15 ; 6-19


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	216001	1	MIRROR,ELECTRICAL,24V	X	X			REFERENCE PAGE 6-15
1	216003	1	MIRROR,MANUAL	X	X			REFERENCE PAGE 6-17
2	226685	1	GLASS,MIRROR,ELECTRICAL	X	X			
2	226688	1	GLASS,MIRROR,MANUAL	X	X			
3	NSI	1	BODY	X	X			
4	NSI	2	CLAMP	X	X			
5	NSI	4	SCREW	X	X			
6	226686	1	COVER,BACK	X	X			
7	216002	1	MIRROR,WIDE ANGLE	X	X			REFERENCE PAGE 6-15 ; 6-17
8	226687	1	GLASS,MIRROR	X	X			
9	NSI	1	SEAL	X	X			
10	NSI	1	BODY	X	X			
11	NSI	1	CLAMP	X	X			
12	NSI	2	SCREW	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ELEC. SYSTEM, CAB, BEACON (OPTIONAL)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218912	1	LIGHT,BEACON,XENON,AMBER	X	X			
2	216286	1	HARNESS,BEACON,EXTENSION	X	X			
3	206939	1	MOUNTING PIPE	X	X			
4	176111	1	BKT,FLASHING BEACON	X	X			
5	100370	4	WASHER,HARDENED	X	X			
6	100314	2	NUT,NYLOC	X	X			
7	100086	2	SCREW,HEXHD	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	216287	1	HARNESS,WORK LIGHT	X	X			
2	207454	2	CONDUIT,584MM	X	X			
3	207030	1	LIGHT,WORK LIGHT	X	X			
4	207030	1	LIGHT,WORK LIGHT	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	217719	1	LIGHT,FLOOD,65W	X	X			
2	100731	1	SCREW,HEXHD	X	X			
3	100548	2	WASHER,HARDENED	X	X			
4	100312	1	NUT,NYLOC	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ELEC. SYSTEM, CAB, MEMORY MODULE (OPTIONAL)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218849	1	ANTENNA,GPS,3000MM CABLE	X	X			
2	218481	2	KEY,DRIVER ID,GREEN	X	X			
3	218480	1	DRIVER,ID,RECEPTACLE	X	X			
4	217166	1	E-MODULE,MEMORY MODULE	X	X			
5	208614	2	DUAL LOCK,3M	X	X			
6	203266	1	GROMMET,BLANK	X	X			
7	187648	2	SPACER	X	X			
8	186757	1	PLT,COVER,GPS ANTENNA	X	X			
9	101181	2	SCREW,PANHD	X	X			
10	101167	4	WASHER,SPRING	X	X			
11	100841	2	SCREW,PANHD	X	X			
12	100730	2	BOLT,HEXHD	X	X			
13	100421	2	WASHER,FENDER	X	X			
14	100063	4	WASHER,FLAT	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ELEC. SYSTEM, CAB, SATELITE (OPTIONAL)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218544	1	E-MODULE,SAT MODULE	X	X			
2	216085	1	HARNESS,SAT MODULE,PIGTAIL	X	X			
3	203266	1	GROMMET,BLANK	X	X			
4	178039	1	PLT,COVER,SATELLITE BOX	X	X			
5	100665	4	SCREW,CHEESEHD	X	X			
6	100421	3	WASHER,FENDER	X	X			
7	100079	3	SCREW,HEXHD	X	X			
8	100063	4	WASHER,FLAT	X	X			

https://truckmanualshub.com/

KIT, RADIO (OPTIONAL)




https://truckmanualshub.com/

KIT, RADIO (OPTIONAL)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	264661	1	KIT,RADIO,BLAUPUNKT	X	X			
1	263592	1	KIT,SPEAKERS,BLAUPUNKT	X	X			
2	216640	1	RADIO,BLAUPUNKT,5000M	X	X			
3	216383	1	ANTENNA,RADIO,BLAUPUNKT	X	X			
4	216291	1	HARNESS,RADIO,BLAUPUNKT	X	X			
5	178159	1	BRACKET,ANTENNA RADIO	X	X			
6	101176	8	NUT,SPEED	X	X			
7	100594	1	WASHER,FENDER	X	X			
8	100309	1	NUT,NYLOC	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218241	1	HEADLAMP,COMBO,RHS	X	X			REFERENCE PAGE 6-37
2	218240	1	HEADLAMP,COMBO,LHS	X	X			REFERENCE PAGE 6-37
3	217810	1	HARNESS,ENGINE	X	X			
4	216486	4	PLT,PIVOT,HEADLIGHT	X	X			
5	216445	1	SENDER,FUEL	X	X			
6	216258	2	COVER,DUST,HEADLAMP	X	X			
7	216217	1	HORN	X	X			
8	207832	2	COVER,HEAD LIGHTS,FRAME	X	X			
9	206945	29	MTG,RUBBER	X	X			
10	203923	2	GROMMET	X	X			
11	200653	33	CABLE TIE	X	X			
12	187531	1	COVER,PLT,FUEL SENDER	X	X			
13	187424	1	MTG,HOOTER	X	X			
14	176428	1	BKT,ELEC F/CHASSIS	X	X			
15	176249	1	PLT,MTG,ELEC HARNESS	X	X			
16	174737	2	PLT,PIVOT RETAINER	X	X			
17	101997	4	CAPSCREW,SOCHD	X	X			
18	101345	2	WASHER,HARDENED	X	X			
19	100953	4	CAPSCREW,SOCHD	X	X			
20	100733	1	SCREW,HEXHD	X	X			
21	100731	1	SCREW,HEXHD	X	X			
22	100383	4	BOLT	X	X			
23	100370	1	WASHER,HARDENED	X	X			
24	100312	2	NUT,NYLOC	X	X			
25	100208	4	CAPSCREW,SOCHD	X	X			
26	100083	3	SCREW,HEXHD	X	X			
27	100062	4	WASHER,FLAT	X	X			

https://truckmanualshub.com/




514850650
TD0003519

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	207981	1	ELEMENT,HEATER,FUEL	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	207030	2	LIGHT,WORK LIGHT,2-WAY DEUTSCH	X	X			
2	217719	2	LIGHT,REVERSE FLOODLIGHT	X	X			
3	202933	6	BULB,24V 70W H3 PK22S (PIGTAIL)	X	X			
4	206703	4	CONNECTOR,2-WAY DEUTSCH,MALE	X	X			
5	100312	1	NUT,NYLOC	X	X			
6	100082	1	SCREW	X	X			
7	218240	1	HEADLAMP,COMBO,LHS,HELLA	X	X			REFERENCE PAGE 6-33
8	218241	1	HEADLAMP,COMBO,RHS,HELLA	X	X			REFERENCE PAGE 6-33
9	226126	1	LENS,HAEDLAMP,COMBO,LHS,HELLA	X	X			
10	226127	1	LENS,HAEDLAMP,COMBO,RHS,HELLA	X	X			
11	202934	2	BULB,24V 75/70W H4 P43T HDLT	X	X			
12	201453	2	BULB,24V,4W	X	X			
13	204710	2	BULB,HEAVY DUTY 24V/22W/BA15S	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

GRILL, HEAD LIGHTS

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	207831	2	COVER,HEAD LIGHTS,GRILL	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218282	1	SWITCH,PRESSURE,5BAR	X	X			REFERENCE PAGES 4-23
2	218281	1	SWITCH,PRESSURE,123BAR	X	X			REFERENCE PAGES 4-23
3	217812	1	HARNESS,ARTIC	X	X			
4	207390	1	SENDER,TEMP	X	X			
5	121131	2	CONNECT,G	X	X			
6	101088	1	WASHER,DOWTY	X	X			
7	100879	1	SCREW,SLT CHEESEHD	X	X			
8	100812	1	WASHER,FLAT	X	X			
9	100370	1	WASHER,HARDENED	X	X			
10	100085	1	SCREW,HEXHD	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218777	1	CABLE,EARTH	X	X			
2	218777	1	CABLE,EARTH	X	X			
3	217961	2	BATTERY,12V,108AH,DELPHI	X	X			
3	216296	2	BATTERY,12V,102AH,DELPHI	X	X			(OPTIONAL)
4	217725	1	CABLE,BATTERY,RED	X	X			
5	217625	1	SOLENOID	X	X			
6	216271	1	HARNESS,BATT BOX	X	X			
7	216270	1	CABLE,BATT,BK	X	X			
8	216268	1	CABLE,BATT,BK	X	X			
9	216267	1	CABLE,BATT,RD	X	X			
10	216129	1	SWITCH,BATTERY DISCONNECT	X	X			
11	216064	1	CABLE,BATTERY,RED	X	X			
12	206945	3	MTG,RUBBER	X	X			
13	206291	1	GROMMET	X	X			
14	205259	1	CIRCUIT BREAKER,60AMP	X	X			
15	203830	2	CIRCUIT BREAKER,20AMP	X	X			
16	200653	13	CABLE TIE	X	X			
17	187244	1	CLAMP,BATTERY	X	X			
18	101309	3	WASHER,FENDER	X	X			
19	101211	3	BOLT	X	X			
20	101059	6	SCREW,SLT CHEESEHD	X	X			
21	100642	4	CAPSCREW,SOCHD	X	X			
22	100385	2	SCREW,MACHINE,H SLT	X	X			
23	100370	2	WASHER,HARDENED	X	X			
24	100312	3	NUT,NYLOC	X	X			
25	100085	2	SCREW,HEXHD	X	X			
26	100063	8	WASHER,FLAT	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	216470	1	HARNESS,ZF TRANSM,ARTIC	X	X			
2	206945	4	MTG,RUBBER	X	X			
3	200653	8	CABLE TIE	X	X			
4	176398	2	PLT,HARNESS MTG	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	223244	2	O-RING	X	X			
2	217813	1	HARNESS,REAR	X	X			
3	217719	1	LIGHT,FLOOD	X	X			
4	217719	1	LIGHT,FLOOD	X	X			
5	216222	1	HARNESS,ARTIC JUMP	X	X			
6	216028	2	LAMP,LED,BRAKE/PARK,REAR	X	X			
7	216027	2	LAMP,LED,INDICATOR,REAR	X	X			
8	207975	1	ALARM,BACK UP-PRECO	X	X			
9	207445	1	E-CLIP	X	X			
10	207440	1	SHAFT,ROTARY SENSOR	X	X			
11	207289	1	O-RING	X	X			
12	207281	1	SHAFT,POSITION SENSOR ARM	X	X			
13	207231	1	SUPPORT,POSITION SENSOR SHAFT	X	X			
14	207021	1	SENSOR,BIN PIVOT,ROTARY	X	X			
15	206945	11	MTG,RUBBER	X	X			
16	200779	2	TIE ROD,END	X	X			
17	200653	29	CABLE TIE	X	X			
18	190685	1	ISOLATOR,VIBRATION,RUBBER	X	X			
19	187539	1	PLT,ELEC BULKHEAD MTG	X	X			
20	186891	1	CLAMP,BREATHER	X	X			
21	186221	1	PLT,R/CHASSIS,ELEC MTG	X	X			
22	176415	3	PLT,TWO HOLE WASHER	X	X			
23	176109	1	PLT,ROT SENSOR MTG	X	X			
24	176107	1	PLT,ROT SENSOR COVER	X	X			
25	100949	2	SCREW,SLOTTED	X	X			
26	100945	2	SCREW,HEXHD	X	X			
27	100812	4	WASHER,FLAT	X	X			
28	100811	2	NUT,NYLOC	X	X			
29	100548	8	WASHER,HARDENED	X	X			
30	100370	4	WASHER,HARDENED	X	X			
31	100312	4	NUT,NYLOC	X	X			
32	100203	2	BOLT,HEXHD	X	X			
33	100198	4	SCREW,HEXHD	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	263470	1	KIT,HARNESS,STRAIN GUAGE	X	X			
2	217705	8	INSERT,PLASTIC,K-CLAMP	X	X			
3	216348	1	E-MODULE,OBW	X	X			
4	200871	7	CABLE TIE	X	X			
5	187092	4	PLT,TOP,K-CLAMP	X	X			
6	187063	1	PLT,MTG,OBW TPMS	X	X			
7	101129	8	BOLT,HEXHD	X	X			
8	100364	2	SCREW,HEXHD	X	X			
9	100081	2	SCREW,HEXHD	X	X			
10	100064	2	WASHER,FLAT	X	X			
11	100061	2	WASHER,FLAT	X	X			

https://truckmanualshub.com/



128-1000-00
TD0004554


https://truckmanualshub.com/

ELECTRICAL CONNECTORS (SHEETS 1 OF 8)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	216784	1	AMP 90 DEG FLAG TERMINAL, 11 MM					USAGE: 217810
2	216816	2	AMP, 4.8 MM, FEMALE, PUSH-ON					USAGE: 216291
3	216817	1	AMP, 1 WAY, SLIP-ON					USAGE: 216221
4	206778	24	BOSCH, 1 WAY, PLUG, SOCKETS					USAGE: 216221(3); 216286(2); 216604(4); 217787(5); 217801(5); 217810(5)
5	208041	26	GROTE & HARTMANN, 1 WAY, PUSH ON TERMINAL					USAGE: 216221(2); 216604(6); 217787(6); 217801(6); 217810(6)
6	216788	1	GROTE & HARTMANN, 13 MM NON-INSULATED TERMINAL					USAGE: 216271
7	216809	1	GROTE & HARTMANN, 10 MM LUG					USAGE: 216221
8	216810	1	GROTE & HARTMANN, 10 MM LUG					USAGE: 216221
9	216811	1	GROTE & HARTMANN, 8 MM LUG					USAGE: 216221
10	216812	2	GROTE & HARTMANN, 6 MM LUG					USAGE: 216221
11	216813	2	GROTE & HARTMANN, 6 MM LUG					USAGE: 216221
12	218737	2	GROTE & HARTMANN, SOCKET					USAGE: 217801(1); 217810(1)
13	218950	24	GROTE & HARTMANN, 4 MM LUG					USAGE: 216221(1); 217787(1); 217789(1); 217791(2); 217801(1); 217806(1); 217807(2); 217808(1); 217809(2); 217810(1); 217812(1); 217813(2); 217816(2); 217817(2); 217818(2); 217819(2)
14	218952	11	GROTE & HARTMANN, 5 MM LUG					USAGE: 216271(3); 216292(3); 216433(1); 216761(1); 217787(1); 217801(1); 217810(1)
15	218953	2	GROTE & HARTMANN, 5 MM LUG					USAGE: 216271(1); 216292(1)
16	218955	11	GROTE & HARTMANN, 6 MM LUG					USAGE: 216221(1); 216433(1); 216604(1); 216761(1); 217787(1); 217789(1); 217801(1); 217806(1); 217808(1); 217810(1); 217812(1)
17	218956	4	GROTE & HARTMANN, 6 MM LUG					USAGE: 216221(2); 216271(1); 216292(1)
18	218957	10	GROTE & HARTMANN, 6 MM LUG					USAGE: 216271(5); 216292(5)
19	218958	2	GROTE & HARTMANN, 8 MM LUG					USAGE: 216271(1); 216292(1)
20	218961	1	GROTE & HARTMANN, 10 MM LUG					USAGE: 217819

https://truckmanualshub.com/

ELECTRICAL CONNECTORS (SHEETS 2 OF 8)




128-1000-00
TD0004555

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
21	218962	15	GROTE & HARTMANN, 10 MM LUG					USAGE: 216221(3); 216604(1); 217789(2); 217801(2); 217806(2); 217808(2); 217812(2); 217880(1)
22	218963	9	GROTE & HARTMANN, 10 MM LUG					USAGE: 216221(1); 217787(2); 217787(1); 217801(2); 217810(2); 217810(1)
23	218964	4	GROTE & HARTMANN, 10 MM LUG					USAGE: 216604(1); 217787(1); 217801(1); 217810(1)
24	218965	6	GROTE & HARTMANN, 12 MM LUG					USAGE: 216271(2); 216292(2); 216604(2)
25	207829	4	HELLERMANN TYTON, 1 WAY, BOOTLACE TERMINAL					USAGE: 217880
26	216815	2	SUMITOMO, 3.0 MM, FEMALE, PUSH-ON					USAGE: 216291
27	208580	37	AMP, 2 WAY, PLUG, SOCKETS					USAGE: 216284(3); 216285(16); 217789(7); 217806(7); 217808(1); 217812(3)
28	216328	1	AMP, 2 WAY, PLUG, SOCKETS					USAGE: 216604
29	217711	7	AMP, 2 WAY, PLUG, SOCKETS					USAGE: 216271(1); 216292(1); 216604(1); 217810(1); 217816(1); 217817(1); 217818(1)
30	206726	1	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS					USAGE: 216604
31	207080	1	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS					USAGE: 216026
32	216326	4	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS					USAGE: 216604
33	216327	1	DELPHI PACKARD, 2 WAY, RECEPTACLE, PINS					USAGE: 216604
34	216329	2	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS					USAGE: 216604
35	216334	1	DELPHI PACKARD, 2 WAY, RECEPTACLE, SOCKETS					USAGE: 216604
36	216839	1	DELPHI PACKARD, 2 WAY, RECEPTACLE, PINS					USAGE: 216604
37	216856	3	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS					USAGE: 216026
38	216857	1	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS					USAGE: 216026
39	218559	1	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS					USAGE: 216345
40	206703	28	DT DEUTSCH, 2 WAY, RECEPTACLE, PINS					USAGE: 216286(1); 216425(1); 216433(1); 217787(2); 217789(5); 217791(1); 217801(2); 217805(2); 217806(4); 217808(4); 217810(4); 217812(1)

https://truckmanualshub.com/




128-1000-00
TD0004556

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
41	206704	75	DT DEUTSCH, 2 WAY, PLUG, SOCKETS					USAGE: 216026(1); 216221(7); 216285(1); 216287(2); 216415(1); 216425(1); 216604(1); 216605(1); 217787(2); 217789(6); 217791(5); 217801(3); 217805(1); 217806(4); 217807(4); 217808(4); 217809(2); 217810(5); 217812(5); 217813(4); 217816(4); 217817(4); 217818(4); 217819(3)
42	216735	1	DT DEUTSCH, 2 WAY, RECEPTACLE, PINS WITH 1500 ohm 2W RESISTOR					USAGE: 216605
43	216779	2	DT DEUTSCH, 2 WAY, RECEPTACLE, PINS					USAGE: 216345(1); 216761(1)
44	216780	6	DT DEUTSCH, 2 WAY, PLUG, SOCKETS					USAGE: 216415(2); 217789(4)
45	216852	5	DT DEUTSCH, 2 WAY, RECEPTACLE, BLANKING PINS (x2) & WEDGE. NO TERMINALS.					USAGE: 217812
46	202557	11	M24, 2 WAY, 90° BAYONET, SOCKETS					USAGE: 217787(1); 217791(1); 217801(1); 217807(1); 217809(1); 217810(1); 217813(1); 217816(1); 217817(1); 217818(1); 217819(1)
47	202916	3	M27, 2 WAY, 90° BAYONET, SOCKETS					USAGE: 216271(1); 217787(1); 217801(1)
48	218079	1	SUMITOMO, 2 WAY, RECEPTACLE, PINS					USAGE: 216604
49	206735	3	UTILUX, 2 WAY, PLUG, SOCKETS					USAGE: 216221
50	216330	1	AMP, 3 WAY, PLUG, SOCKETS					USAGE: 216604
51	218077	1	AMP, 3 WAY, RECEPTACLE, PINS					USAGE: 216604
52	207524	7	DELPHI PACKARD, 3 WAY, PLUG, PINS					USAGE: 217789(1); 217791(1); 217807(1); 217809(1); 217813(1); 217816(1); 217817(1)
53	216325	1	DELPHI PACKARD, 3 WAY, RECEPTACLE, SOCKETS					USAGE: 216604
54	216333	3	DELPHI PACKARD, 3 WAY, RECEPTACLE, SOCKETS					USAGE: 216604
55	206690	18	DT DEUTSCH, 3 WAY, PLUG, SOCKETS					USAGE: 216221(3); 217791(3); 217807(2); 217813(2); 217816(2); 217817(2); 217818(2); 217819(2)
56	216924	3	DT DEUTSCH, 3 WAY, PLUG, SOCKETS					USAGE: 216221(2); 216281(1)
57	206705	3	DT DEUTSCH, 3 WAY, RECEPTACLE, PINS					USAGE: 216287(1); 216291(1); 216415(1)
58	216925	2	DT DEUTSCH, 3 WAY, RECEPTACLE, PINS					USAGE: 216025
59	216926	1	DT DEUTSCH, 3 WAY, RECEPTACLE, PINS					USAGE: 216220
60	216358	10	DT DEUTSCH, 3 WAY, PLUG, SOCKETS					USAGE: 216221(1); 216686(1); 217791(1); 217807(1); 217809(1); 217813(1); 217816(1); 217817(1); 217818(1); 217819(1)

https://truckmanualshub.com/

ELECTRICAL CONNECTORS (SHEETS 4 OF 8)




128-1000-00
TD0004557

https://truckmanualshub.com/

ELECTRICAL CONNECTORS (SHEETS 4 OF 8)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
61	216558	1	DT DEUTSCH, 3 WAY, RECEPTACLE, PINS WITH GREEN/GREY WIRE BRIDGE					USAGE: 217791
62	217820	5	HD10 DEUTSCH, 3 WAY, PLUG, SOCKETS					USAGE: 216686(1); 217789(1); 217806(1); 217808(1); 217812(1)
63	217821	1	HD10 DEUTSCH, 3 WAY, RECEPTACLE, PINS					USAGE: 216221
64	206777	8	UTILUX, 3 WAY, PLUG, SOCKETS					USAGE: 216604(2); 217787(2); 217801(2); 217810(2)
65	216359	10	TERMINATOR, CAN, 120 OHM					USAGE: 216221(1); 216686(1); 217791(1); 217807(1); 217809(1); 217813(1); 217816(1); 217817(1); 217818(1); 217819(1)
66	207475	3	AMP, 4 WAY, BAYONET, PLUG, SOCKETS					USAGE: 217787(1); 217801(1); 217810(1)
67	208000	1	AMP, 4 WAY, PLUG, SOCKETS					USAGE: 216470
68	208001	1	AMP, 4 WAY, PLUG, SOCKETS					USAGE: 216470
69	206722	1	BOSCH, 4 WAY, PLUG, SOCKETS					USAGE: 216221
70	218308	8	BRAD HARRISON, 4 WAY, 90°, SOCKETS					USAGE: 217789(2); 217806(2); 217808(2); 217812(2)
71	206706	6	DT DEUTSCH, 4 WAY, RECEPTACLE, PINS					USAGE: 216085(1); 217791(1); 217813(1); 217816(1); 217817(1); 217818(1)
72	206707	23	DT DEUTSCH, 4 WAY, PLUG, SOCKETS					USAGE: 216221(4); 217791(3); 217807(3); 217809(3); 217813(3); 217816(3); 217817(3); 217818(1)
73	216331	1	DT DEUTSCH, 4 WAY, PLUG, SOCKETS					USAGE: 216604
74	216782	1	DT DEUTSCH, 4 WAY, PLUG, SOCKETS					USAGE: 217787
75	217706	2	DT DEUTSCH, 4 WAY, RECEPTACLE					USAGE: 217807(1); 217809(1)
76	218464	2	HARNESS FLEX, 4 WAY, M27, SOCKETS					USAGE: 217787(1); 217801(1)
77	201529	7	HIRSCHMANN, 4 WAY, FLUSH, SOCKETS					USAGE: 216221(4); 216271(1); 217787(1); 217801(1)
78	207504	6	HIRSCHMANN, 4 WAY, FLUSH, SOCKETS					USAGE: 216221
79	208468	6	MOLEX, 4 WAY, PLUG, SOCKETS					USAGE: 217880
80	207830	2	GROTE & HARTMANN, 5 WAY, PLUG, SOCKETS					USAGE: 216604(1); 217787(1)

https://truckmanualshub.com/




128-1000-00
TD0004558

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
81	208348	1	AMP, 6 WAY, PLUG, SOCKETS					USAGE: 217880
82	208495	1	AMP, 6 WAY, IQAN, PLUG, SOCKETS					USAGE: 217880
83	218750	2	AMP, 6 WAY, PLUG, SOCKETS					USAGE: 217789
84	206729	1	DELPHI PACKARD, 6 WAY, PLUG, SOCKETS					USAGE: 216221
85	206708	7	DT DEUTSCH, 6 WAY, RECEPTACLE, PINS					USAGE: 216412(1); 217809(1); 217817(1); 217818(1); 217819(2); 217880(1)
86	206709	14	DT DEUTSCH, 6 WAY, PLUG, SOCKETS					USAGE: 216221(7); 216412(1); 217809(2); 217817(1); 217818(1); 217819(2)
87	216336	1	DT DEUTSCH, 6 WAY, PLUG, SOCKETS					USAGE: 216604
88	216335	1	FCI, 6 WAY, PLUG, SOCKETS					USAGE: 216604
89	200742	5	HELLA, 7 WAY, TRAILER CONNECTOR WITH SOCKETS					USAGE: 217809(1); 217817(1); 217818(1); 217819(2)
90	206724	1	BOSCH, 8 WAY, PLUG, SOCKETS					USAGE: 216221
91	206711	3	DT DEUTSCH, 8 WAY, RECEPTACLE, PINS					USAGE: 217812(1); 218619(1); 218755(1)
92	206712	3	DT DEUTSCH, 8 WAY, PLUG, SOCKETS					USAGE: 217806(1); 217808(1); 217812(1)
93	218437	2	DT DEUTSCH, 8 WAY, RECEPTACLE					USAGE: 217806(1); 217808(1)
94	207505	3	GROENEVELD, 8 WAY, PLUG, SOCKETS					USAGE: 217789(1); 218619(1); 218755(1)
95	216332	1	TYCO, 8 WAY, PLUG, SOCKETS					USAGE: 216604
96	217730	1	YAZAKI, 8 WAY, PLUG, SOCKETS					USAGE: 216221
97	207498	1	AMP, 9 WAY, RECEPTACLE, PINS					USAGE: 216221
98	216785	2	AMP, 9 WAY, RECEPTACLE, PINS					USAGE: 216220(1); 216281(1)
99	216786	1	AMP, 9 WAY, PLUG, SOCKETS					USAGE: 216220
100	216789	1	AMPHENOL, 9 WAY, PLUG, PINS					USAGE: 216221

https://truckmanualshub.com/




128-1000-00
TD0004559

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
101	208880	1	HD DEUTSCH, 9 WAY, RECEPTACLE, SOCKETS					USAGE: 216281
102	206719	1	HDP DEUTSCH, 9 WAY, RECEPTACLE, PINS					USAGE: 216221
103	206720	4	HDP DEUTSCH, 9 WAY, PLUG, SOCKETS					USAGE: 216604(1); 217787(1); 217801(1); 217810(1)
104	216777	2	HDP DEUTSCH, 9 WAY, RECEPTACLE, SOCKETS					USAGE: 216271(1); 216292(1)
105	216778	4	HDP DEUTSCH, 9 WAY, PLUG, PINS					USAGE: 216604(1); 217787(1); 217801(1); 217810(1)
106	217739	5	AMP, 10 WAY, PLUG, SOCKETS					USAGE: 216221(2); 216605(1); 217880(2)
107	207499	1	AMP, 12 WAY, PLUG, SOCKETS					USAGE: 216221
108	207273	2	DT DEUTSCH, 12 WAY, RECEPTACLE, PINS					USAGE: 216025(1); 216220(1)
109	207274	9	DT DEUTSCH, 12 WAY, PLUG, SOCKETS					USAGE: 216221(3); 217791(1); 217806(1); 217807(1); 217813(1); 217816(1); 217817(1)
110	218735	1	DT DEUTSCH, 12 WAY, RECEPTACLE					USAGE: 217806
111	207476	1	AMP, 14 WAY, PLUG, SOCKETS					USAGE: 216281
112	216084	1	DELPHI PACKARD, 14 WAY, PLUG, SOCKETS					USAGE: 216221
113	208008	1	HDP DEUTSCH, 14 WAY, PLUG, SOCKETS					USAGE: 216220
114	207477	3	AMP, 15 WAY, PLUG, SOCKETS					USAGE: 217787(1); 217801(1); 217810(1)
115	207500	2	AMP, 15 WAY, PLUG, SOCKETS					USAGE: 216221
116	216798	1	AMP, 15 WAY, RECEPTACLE, PINS					USAGE: 216605
117	218255	1	DB, 15 WAY, PLUG, SOCKETS					USAGE: 216085
118	216077	1	DELPHI PACKARD, 16 WAY, PLUG, SOCKETS					USAGE: 216025
119	216083	1	DELPHI PACKARD, 16 WAY, PLUG, SOCKETS					USAGE: 216221
120	121296	1	FRAMATONE, 16 WAY, PLUG, SOCKETS					USAGE: 216291

https://truckmanualshub.com/




128-1000-00
TD0004560

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
121	207501	2	AMP, 18 WAY, PLUG, SOCKETS					USAGE: 216221
122	216076	1	AFL AUTOMOTIVE, 20 WAY, PLUG, SOCKETS					USAGE: 216026
123	207502	3	AMP, 21 WAY, PLUG, SOCKETS					USAGE: 216221
124	216787	1	AMP, 21 WAY, RECEPTACLE, PINS					USAGE: 216605
125	206713	2	HDP DEUTSCH, 21 WAY, PLUG, SOCKETS					USAGE: 216222(1); 217790(1)
126	216071	1	HDP DEUTSCH, 21 WAY, PLUG, SOCKETS, 90°					USAGE: 217788
127	216767	4	HDP DEUTSCH, 21 WAY, PLUG, PINS, 90°					USAGE: 216222(1); 217789(1); 217806(1); 217812(1)
128	216768	4	HDP DEUTSCH, 21 WAY, PLUG, PINS					USAGE: 217788(1); 217790(1); 217809(1); 217819(1)
129	216769	4	HDP DEUTSCH, 21 WAY, RECEPTACLE, SOCKETS					USAGE: 217789(1); 217806(1); 217808(1); 217812(1)
130	216770	6	HDP DEUTSCH, 21 WAY, RECEPTACLE, PINS					USAGE: 217791(1); 217807(1); 217813(1); 217816(1); 217817(1); 217818(1)
131	216771	1	HDP DEUTSCH, 21 WAY, RECEPTACLE, SOCKETS					USAGE: 216221
132	216772	1	HDP DEUTSCH, 21 WAY, PLUG, PINS					USAGE: 217880
133	216773	5	HDP DEUTSCH, 23 WAY, PLUG, PINS, 90°					USAGE: 216604(1); 217789(1); 217806(1); 217808(1); 217812(1)
134	216774	2	HDP DEUTSCH, 23 WAY, RECEPTACLE, SOCKETS					USAGE: 216221(1); 216605(1)
135	208002	1	ZF, 24 WAY, PLUG, SOCKETS					USAGE: 216470
136	206717	2	HDP DEUTSCH, 31 WAY, RECEPTACLE, PINS					USAGE: 216025(1); 216220(1)
137	206718	1	HDP DEUTSCH, 31 WAY, PLUG, SOCKETS					USAGE: 216026
138	207473	2	HDP DEUTSCH, 31 WAY, RECEPTACLE, SOCKETS					USAGE: 216221(1); 217880(1)
139	216091	5	HDP DEUTSCH, 31 WAY, PLUG, PINS					USAGE: 216285(1); 216604(1); 217787(1); 217801(1); 217810(1)
140	216095	1	HDP DEUTSCH, 31 WAY, RECEPTACLE, SOCKETS					USAGE: 216284

https://truckmanualshub.com/



128-1000-00
TD0004561

https://truckmanualshub.com/

ELECTRICAL CONNECTORS (SHEETS 8 OF 8)


ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
141	216096	1	HDP DEUTSCH, 31 WAY, PLUG, PINS, 90 DEGREE					USAGE: 216284
142	216861	1	HDP DEUTSCH, 31 WAY, PLUG, SOCKETS					USAGE: 216470
143	216081	3	CINCH BL, 32 WAY, PLUG, SOCKETS					USAGE: 216221(2); 216605(1)
144	216082	2	CINCH BN, 32 WAY, PLUG, SOCKETS					USAGE: 216221
145	216405	1	CINCH BN, 32 WAY, PLUG, SOCKETS					USAGE: 216605
146	216775	1	HDP DEUTSCH, 33 WAY, PLUG, PINS, 90°					USAGE: 216604
147	216776	1	HDP DEUTSCH, 33 WAY, RECEPTACLE, SOCKETS					USAGE: 216605
148	208439	1	AMP, 42 WAY, PLUG, SOCKETS					USAGE: 217880
149	216080	3	CINCH, 48 WAY, PLUG, SOCKETS					USAGE: 216221(2); 216605(1)
150	208009	1	AMP, 68 WAY, PLUG, SOCKETS					USAGE: 216220
151	216074	1	AFL AUTOMOTIVE, 80 WAY, PLUG, SOCKETS					USAGE: 216025

https://truckmanualshub.com/

https://truckmanualshub.com/

SECTION 7: FRAME & BODY

https://truckmanualshub.com/




TD0003468

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	264353	1	KIT,CAB,SPARE COMPLETE,B30D,G2	X				
1	264351	1	KIT,CAB,SPARE COMPLETE,B25D,G2		X			

https://truckmanualshub.com/




Td0003497 A

https://truckmanualshub.com/

CAB SHELL

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	264362	1	SHELL,CAB,SMALL,YELLOW	X	X			
2	207871	1	ROOF,CAB,YELLOW	X	X			
5	208104	A/R	GASKET	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

CAB / BONNET INTERFACE SEAL

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
18	207799	1	SEAL,BONNET/CAB INTERFACE	X	X			
63	145018	2	O-RING	X	X			
64	101307	5	WASHER,FLAT	X	X			
88	100125	2	SCREW,HEXHD	X	X			
90	100090	25	SCREW,HEXHD	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

HVAC SEALING, CAB

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
14	208044	1	SEAL,LASTO 'D',SIDE,CAB	X	X			
15	208043	1	SEAL,LASTO 'D',FRONT,CAB	X	X			
50	176593	1	ASSY,BAFFLE MTG,CAB,BTM	X	X			
51	176591	1	ASSY,BAFFLE MTG,CAB,FRONT	X	X			
52	176590	1	PLT,BAFFLE MTG,BONNET	X	X			
78	100370	44	WASHER,HARDENED	X	X			
92	100086	2	SCREW, HEXHD	X	X			
93	100081	18	SCREW,HEXHD	X	X			
96	100061	22	WASHER,FLAT	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
16	207881	8	GASKET,GRAB HANDLE	X	X			
30	206293	4	MTG,RUBBER,CAB	X	X		UPTO VIN: 3498	REFER SIB 2007/1001
30	187891	4	MTG,RUBBER,CAB	X	X		FROM VIN: 3501	REFER SIB 2007/1001
37	182285	1	HANDRAIL,CAB,ROOF	X	X			
42	181880	1	HANDLE,CAB,LHS,TOP,REAR	X	X			
55	176312	8	SHIM,1.6MM,G/HANDLE BKT	X	X			
58	174676	1	PLT,MTG,RHS,GUARD,WINDOW	X	X			
59	187790	1	HANDRAIL,CAB,RHS,REAR	X	X			
60	173443	1	GUARD WINDOW REAR	X	X			
72	100734	8	BOLT,HEXHD	X	X			
75	100654	16	NUT,STOVER	X	X			
76	100536	36	WASHER,HARDENED	X	X			
77	100424	8	WASHER,HARDENED	X	X			
78	100370	44	WASHER,HARDENED	X	X			
81	100316	8	NUT,NYLOC	X	X			
86	100210	4	BOLT	X	X			
87	100128	8	SCREW,HEXHD	X	X			
90	100090	25	SCREW,HEXHD	X	X			

https://truckmanualshub.com/

REAR VIEW MIRROR BRACKETS




https://truckmanualshub.com/

REAR VIEW MIRROR BRACKETS

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218678	4	BLOCK,LOCATE,MIRROR	X	X			
11	216003	2	MIRROR,MANUAL	X	X			
12	216002	2	MIRROR,WIDE	X	X			
17	207863	2	GASKET,LOWER MIRROR BKT	X	X			
31	201666	4	SPRING	X	X			
34	186316	2	SHIM	X	X			
35	186315	2	SHIM	X	X			
36	186149	4	PIN,LOCATE,MIRROR	X	X			
38	182284	1	MTG,CAB,MIRROR,BKT,RHS	X	X			
39	182283	1	MTG,CAB,MIRROR,LHS	X	X			
40	182282	1	MTG,MIRROR,LHS	X	X			
41	182281	1	MTG,MIRROR,RHS	X	X			
44	178726	8	TAG,LOCK,MIRROR	X	X			
45	178569	2	SHIM	X	X			
46	178568	2	SHIM	X	X			
47	178567	2	SHIM	X	X			
48	178407	2	SHIM	X	X			
54	176379	8	WASHER,SPRING	X	X			
57	176303	2	SHIM	X	X			
61	166566	8	PIN,MTG,MIRROR	X	X			
68	100936	2	BOLT	X	X			
74	100730	8	BOLT,HEXHD	X	X			
78	100370	44	WASHER,HARDENED	X	X			
79	100364	8	SCREW,HEXHD	X	X			
80	100359	2	WASHER,FENDER	X	X			
81	100316	8	NUT,NYLOC	X	X			
82	100314	8	NUT,NYLOC	X	X			
90	100090	25	SCREW,HEXHD	X	X			
91	100089	4	SCREW,HEXHD	X	X			
96	100061	22	WASHER,FLAT	X	X			

https://truckmanualshub.com/

CAB DOOR ASSEMBLY




TD0003520 D
E14832301 SH2 F

https://truckmanualshub.com/

CAB DOOR ASSEMBLY

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
3	218331	1	BOOT,RUBBER,DOOR HANDLE	X	X			
4	217590	1	SEAL,DOOR,MAIN	X	X			
6	217557	1	WINDOW,DOOR,SLIDING	X	X			
7	217556	1	DOOR,MAIN,YELLOW	X	X			
13	208103	12	GASKET,5X5 ROLL STOCK	X	X			
19	207647	1	KNOB,BIN TIP	X	X			
20	207375	1	BOLT,STRIKER,TRIMARK	X	X			
21	207366	1	LATCH,LH,TRI/MARK	X	X			
22	207230	1	TRIMARK,LH HOUSING	X	X			
24	206465	1	STRUT,CAB	X	X			
25	206453	1	RUBBER,STRAP,DOOR	X	X			
26	206451	2	BKT,STRAP,DOOR	X	X			
28	206415	6	HINGE,EXTERIOR	X	X			
32	201509	1	LATCH,GASKET	X	X			
33	200779	2	TIE ROD END	X	X			
49	176962	2	MTG BKT,LATCH	X	X			
53	176431	2	SHIM	X	X			
56	176306	1	WASHER,CAB	X	X			
62	161086	1	SPACER BLOCK,DOOR STRAP	X	X			
65	101174	2	CAPSCREW,CSK,SOC	X	X			
66	101085	4	SCREW,HEXHD	X	X			
67	100947	4	WASHER,FLAT	X	X			
69	100850	1	STUD,M/S,FULL THREAD	X	X			
70	100837	36	CAPSCREW,CSK	X	X			
71	100832	4	CAPSCREW,CSK	X	X			
84	100310	2	NUT,NYLOC	X	X			
85	100281	2	NUT,HEXAGON	X	X			
93	100081	18	SCREW,HEXHD	X	X			
94	100063	4	WASHER,HARDENED	X	X			
95	100062	7	WASHER,FLAT	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
2	218342	1	WINDOW,RHS,SLIDING	X	X			
8	217555	1	WINDOW,LH,FRONT,TOUGHENED	X	X			
9	217151	1	WINDOW,REAR	X	X			
13	208103	12	GASKET	X	X			
27	206418	1	WINDOW,CURVED	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

WINDOW CATCHES

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	221629	1	CATCH,CAB,SLIDING WINDOW	X	X			
2	221627	1	CATCH,VERTICAL,SLIDING WINDOW,RHS	X	X			
3	221628	1	CATCH,VERTICAL,SLIDING WINDOW,LHS	X	X			
4	101197	2	SCREW,MACHINE CSK POSI.S/S	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

DOOR, HVAC SYSTEM

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
5	217588	1	SEAL,DOOR,HVAC,RHS,ADT D#	X	X			
23	206491	1	STRUT,CAB,4044	X	X			
28	206415	6	HINGE,EXTERIOR	X	X			
29	206412	1	DOOR,HVAC,YELLOW D#	X	X			
43	181684	1	MTG,HATCH,HVAC DOOR STRUT	X	X			
70	100837	36	CAPSCREW,CSK,SOCHD	X	X			
73	100731	3	SCREW	X	X			
78	100370	44	WASHER,HARDENED	X	X			
83	100312	1	NUT,NYLOC	X	X			
89	100092	2	BOLT,HEXHD	X	X			
95	100062	7	WASHER,FLAT	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
2	220397	2	HOOK,CLOTHES	X	X			
5	217758	1	PLT,BLANKING,RADIO FACE	X	X			
10	216473	1	MAT,COOL BOX	X	X			
13	216454	1	GASKET	X	X			
14	216453	1	KIT,GASKET,COOL BOX,	X	X			
20	216278	1	LID,FUSES/RELAYS	X	X			
21	216277	1	LID,COOLER BOX,CAB	X	X			
31	216039	1	HAMMER,EMERGENCY EXIT	X	X			
32	216004	1	PANEL,INTERIOR,MAIN DOOR	X	X			
35	207968	2	COVER,SPEAKER	X	X			
36	207879	1	STRAP,COAT	X	X			
39	206585	35	HEXSERT	X	X			
43	206444	2	RUBBER,LATCH,COOLBOX	X	X			
44	206442	2	LATCH,COOLBOX	X	X			
45	206441	4	HINGE,INTERIOR	X	X			
46	206439	5	HANDLE,CAB INTERIOR	X	X			
54	101185	8	CAPSCREW	X	X			
55	101176	15	NUT,SPEED	X	X			
56	101175	8	CAPSCREW,CSK	X	X			
59	101152	2	SCREW,CSK,SELFTAP	X	X			
61	101010	1	WASHER,FENDER	X	X			
63	100872	3	SCREW,PANHD SELFTAP	X	X			
64	100842	8	POP RIVET	X	X			
65	100838	15	WASHER,FLAT	X	X			
66	100835	23	CAPSCREW	X	X			
68	100830	26	SCREW,PANHD,SELFTAP	X	X			
71	100615	18	WASHER, FLAT	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

CAB INTERIOR HATCHES AND LIDS

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
11	216472	1	MAT,DASH ACCESS	X	X			
12	216457	1	COVER,E-MODULE	X	X			
15	216430	1	PANEL,WIPER,REAR	X	X			
16	216429	1	PANEL,HOLD-ALL	X	X			
19	216280	1	PANEL,LEVER	X	X			
25	216235	1	PANEL,MDU	X	X			
34	208085	1	BLANK,MIRROR SWITCH	X	X			
37	207864	1	GASKET,ELECTRICAL HATCH	X	X			
39	206585	35	HEXSERT	X	X			
40	206454	1	ASHTRAY,TOP MNT,PLASTIC	X	X			
47	206437	18	HEXSERT	X	X			
50	181860	1	ARM,WHEEL SPANNER	X	X			
52	171508	2	CLAMP,PIPE,HOLE	X	X			
55	101176	15	NUT,SPEED	X	X			
62	100947	2	WASHER,FLAT	X	X			
63	100872	3	SCREW,PANHD SELFTAP	X	X			
65	100838	15	WASHER,FLAT	X	X			
66	100835	23	CAPSCREW	X	X			
68	100830	26	SCREW,PANHD,SELFTAP	X	X			
69	100799	2	BOLT,WING	X	X			

https://truckmanualshub.com/




TD0003487 A
E14832302 SH3-9 C

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
6	216673	1	MAT,TOOLBOX,	X	X			
23	216238	1	COVER,B PILLAR,RHS	X	X			
24	216237	1	COVER,B PILLAR,LHS	X	X			
26	216234	1	MAT,FLOOR,CAB	X	X			
29	216214	1	COVER,A PILLAR,RHS	X	X			
30	216197	1	COVER,A PILLAR,LHS	X	X			
33	208614	12	DUAL LOCK	X	X			
38	207266	8	HEXSERT,OPEN	X	X			
42	206447	1	PLATE,STEP	X	X			
57	101174	6	CAPSCREW,CSK	X	X			
67	100832	2	CAPSCREW,CSK	X	X			

https://truckmanualshub.com/




E14832302 SH2-9 C
Td0003490 A

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
7	216646	14	FASTENER,PLASTIC,HEADLINER	X	X			
27	216233	1	HOODLINER,FRONT	X	X			
28	216232	1	HOODLINER,REAR	X	X			
38	207266	8	HEXSERT	X	X			
39	206585	35	HEXSERT	X	X			
41	206449	1	SUN VISOR	X	X			
57	101174	6	CAPSCREW,CSK	X	X			
66	100835	23	CAPSCREW	X	X			
73	100358	3	WASHER,FLAT	X	X			

https://truckmanualshub.com/

OPERATOR AND TRAINER SEAT INSTALLATION




TD0003567 A
E14832302 SH4-9 C

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	290433	1	SEAT,OPERATOR	X	X			EXCLUDES HEADREST AND ARMREST
1	290444	1	SEAT,OPERATOR	X	X			INCLUDES HEADREST AND ARMREST
3	218867	1	SEAT,TRAINER	X	X			
8	216523	1	COVER,SEAT,TRAINER	X	X			
17	216382	1	CUSHION,SEAT,TRAINER	X	X			
18	216381	1	CUSHION,BACKREST,TRAINER	X	X			
22	216243	1	HOLDER,DOCUMENT,SEARS	X	X			
47	206437	18	HEXSERT	X	X			
49	187533	1	PLT,MNT,BACKREST,SEAT,TRAINER	X	X			
58	101172	6	BOLT,HEX	X	X			
60	101062	6	POP RIVET	X	X			
70	100731	10	SCREW	X	X			
76	100083	7	SCREW, HEXHD	X	X			
77	100062	17	WASHER, FLAT	X	X			

https://truckmanualshub.com/




TD0003580

https://truckmanualshub.com/

TRAINER SEAT MOUNTING

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218867	1	MOUNTING,SEAT,TRAINER	X	X			
2	264103	1	ASSY,SEATBELT,SEAT,TRAINER	X	X			
3	100316	1	NUT,NYLOC	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	290444	1	SEAT,OPERATOR,DDH	X	X			COMPLETE WITH ITEMS 11 TO 21
1	290433	1	SEAT,OPERATOR,DDH2	X	X			COMES WITHOUT ITEM 11 TO 21
2	226735	1	CUSHION,BACKREST	X	X			
3	226736	1	CUSHION,SEAT	X	X			
4	226654	1	SEAT BELT,2”	X	X			
5	226655	1	COVER,SIDE	X	X			
6	226652	1	SUSPENSION ASSY,C.E.AIR	X	X			
7	226653	1	MOUNTING	X	X			
8	226773	1	KIT,SLIDE CONTROL	X	X			
9	216952	1	COVER,ARMREST,SEAT,LH	X	X			USED IN PLACE OF OPTIONAL ARMREST
10	216953	1	COVER,ARMREST,SEAT,RH	X	X			USED IN PLACE OF OPTIONAL ARMREST
11	263818	1	KIT,HEADREST & ARMREST,DDH	X	X			(OPTIONAL)
12	263936	1	KIT,ARMREST,RH	X	X			(OPTIONAL) INCLUDE ITEMS 11, 14 TO 18
13	226747	1	PAD,ARMREST,RH	X	X			
14	263937	1	KIT,ARMREST,LH	X	X			(OPTIONAL) INCLUDES ITEMS 13 TO 18
15	226748	1	PAD,ARMREST,LH	X	X			
16	100857	1	WASHER,BODY	X	X			
17	100846	2	NUT,CENTRE LOCK	X	X			
18	100147	1	WASHER,FLAT	X	X			
19	226749	1	BLOCK,SPACER,ARMREST	X	X			
20	100608	1	CAPSCREW,BUTTON,SOC HD	X	X			
21	226746	1	HEADREST	X	X			(OPTIONAL)

https://truckmanualshub.com/

BASE, SEAT ASSEMBLY, SEARS




https://truckmanualshub.com/

BASE, SEAT ASSEMBLY, SEARS

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	226652	1	SUSPENSION ASSY,C.E.AIR	X	X			
2	226644	1	KIT,SERVICE,AIR VALVE	X	X			
3	226645	1	KIT,SERVICE,ISOLATOR SHOCK	X	X			
4	226737	1	KIT,SERVICE,AIR SPRING	X	X			
5	226647	1	KIT,SERVICE,BEARING & ROLLERS	X	X			
6	226648	1	KIT,SERVICE,ISOLATOR LATCH	X	X			
7	226646	1	SHAFT,BEARING	X	X			
8	226649	1	KIT,SERVICE,SUSPENSION SHOCK	X	X			
9	226738	1	BELLOWS	X	X			
10	226650	1	KIT,TETHER BELT	X	X			
11	226651	1	KIT,SERVICE,BUMPER	X	X			
12	T55224	1	BUMPER	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

STEERING COLUMN MISCELLANEOUS PARTS

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
4	218287	1	COLUMN,STEERING	X	X			
48	204600	1	STEERING WHEEL	X	X			
51	176327	1	SPACER,STEERING COLOUMN	X	X			
53	101356	2	BOLT,HEXHD	X	X			
72	100370	6	WASHER,HARDENED	X	X			
74	100314	3	NUT,NYLOC	X	X			
75	100090	1	SCREW,HEXHD	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	218287	1	COLUMN,STEERING	X	X			
2	205422	1	SUPPORT	X	X			
3	204112	1	SCREW,ADJUSTING HANDLE	X	X			
4	204111	1	GUARD,TELESCOPIC	X	X			
5	204110	1	BOOT,STEERING COLUMN	X	X			
6	205429	1	SHAFT,STEERING	X	X			
7	204115	2	SPACER,SPLINED	X	X			
8	101364	1	NUT,HEXAGON	X	X			
9	204600	1	WHEEL,STEERING	X	X			
10	204438	1	CAP,STEERING WHEEL	X	X			
11	205427	1	BOLT,STEPPED	X	X			
12	205428	1	SPACER	X	X			
13	204113	1	NUT,ADJUSTING HANDLE	X	X			
14	100390	2	CAPSCREW	X	X			
15	100615	2	WASHER,FLAT	X	X			
16	223968	2	NUT,ROUND SPECIAL	X	X			
17	204170	1	BASE ASSY	X	X			INCLUDES ITEMS 30 TO 32
18	100090	1	SCREW,HEXHD	X	X			
19	101356	2	BOLT,HEXHD	X	X			
20	100370	3	WASHER,HARDENED	X	X			
21	100314	3	NUT,NYLOC	X	X			
22	205423	1	SHAFT	X	X			
23	205424	1	NUT	X	X			
24	205425	1	SHAFT,SPLINED	X	X			
25	218286	1	KNUCKLE,STEERING	X	X			
26	100198	2	SCREW,HEXHD	X	X			
27	100283	2	NUT,HEXAGON	X	X			
28	207787	1	COLUMN,BASE,STEER ORBITAL	X	X			
29	100085	4	SCREW,HEXHD	X	X			
30	226657	1	CIRCLIP	X	X			COMES WITH ITEM 17
31	226658	1	CIRCLIP	X	X			COMES WITH ITEM 17
32	226659	1	BEARING	X	X			COMES WITH ITEM 17

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	264448	1	KIT,GASKET,HVAC SYSTEM	X	X			
2	216463	3	ADAPTOR,VENT	X	X			
3	216525	4	VENT,SWIVEL,HVAC	X	X			
4	216236	1	VENT,BOX,COOLER	X	X			
5	216216	1	HVAC UNIT	X	X			
6	207175	2	ASSY,DRAIN TUBE,HVAC	X	X			
7	204187	A/R	AIRDUCT,FLEX	X	X			
8	202346	1	AIRDUCT,FLEX	X	X			
9	200871	22	CABLE TIE	X	X			
10	100938	21	SCREW,COUNTERSUNK	X	X			
11	206945	2	MTG,RUBBER	X	X			
12	264449	1	KIT,GASKET,HVAC FRESH	X	X			

https://truckmanualshub.com/

AIRCON DRIER UNIT AND PIPING




https://truckmanualshub.com/

AIRCON DRIER UNIT AND PIPING

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	910264	1	INSULATION,HOSE,HVAC	X	X			
2	241148	1	ASSY,HOSE,HVAC,UNIT,FWAL	X	X			
3	241147	1	ASSY,HOSE,HVAC,DRY,UNIT	X	X			
4	241146	1	ASSY,HOSE,HVAC,FWAL,DRY	X	X			
5	218686	2	HOSE,RADIATOR	X	X			
6	207117	2	P-CLIP	X	X			
7	206585	6	HEXSERT,OPEN	X	X			
8	204043	1	RECEIVER DRIER	X	X			
9	204042	1	SWITCH,BINARY PRESSURE	X	X			
10	203908	4	P-CLIP	X	X			
11	203588	4	CLAMP,HOSE	X	X			
12	200050	2	CLAMP,HOSE	X	X			
13	176177	1	PLATE,BULKHEAD,FIREWALL	X	X			
14	176088	1	BKT,RECEIVER DRIER,HVAC	X	X			
15	120679	2	ADAPTOR	X	X			
16	100198	4	SCREW,HEXHD	X	X			
17	100193	1	SCREW,HEXHD	X	X			
18	100080	6	BOLT	X	X			
19	100065	4	WASHER,SPRING	X	X			
20	100062	4	WASHER,FLAT	X	X			
21	100061	7	WASHER,FLAT	X	X			
22	100054	1	WASHER,SPRING	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

AIRCONDITIONER UNIT BREAKDOWN

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	216216	1	HVAC UNIT,24V	X	X			
1	226837	1	CASING ASSEMBLY	X	X			
2	226050	1	SIDE COVER ASSY	X	X			
3	226838	1	TOP COVER ASSY	X	X			
4	226052	1	MOUNTING PLATE,ACTUATOR	X	X			
5	226839	1	FLAPPER,FLOOR	X	X			
6	226840	1	FLAPPER,DEFROST / DASH	X	X			
7	226055	1	FLAPPER,FRESH AIR	X	X			
8	226056	1	SUPPORT,COIL	X	X			
9	226057	1	SUPPORT,BLOCK VALVE	X	X			
11	226841	1	BRACKET MTG,FRESH AIR ACTUATOR	X	X			
12	226021	1	HEATER COIL	X	X			
13	226020	1	EVAPORATOR COIL	X	X			
14	226019	1	AIR FILTER ASSY	X	X			
15	226018	1	BLOWER ASSY,24V	X	X			
16	226842	1	RETAINER,AIRCON COIL	X	X			
17	226843	1	THERMOSTAT	X	X			
18	226844	3	CLIP,PANEL	X	X			
19	226015	3	MOTOR ACTUATOR 12V	X	X			
20	226014	1	COPPER TUBE ASSY	X	X			
21	207178	9	AIR HOSE ADAPTER	X	X			
22	207177	1	AIR HOSE ADAPTER,2"	X	X			
23	226013	3	SNAP BUSHING,1/4"	X	X			
25	226060	8	SCREW	X	X			
26	100613	8	WASHER	X	X			
27	226011	8	NYLON SPACER 1/2"	X	X			
28	226010	6	CONSTANT TENSION BAND CLAMP	X	X			
29	226006	1	HOSE,HEATER,60MM LONG	X	X			
30	226006	1	HOSE,HEATER,325MM LONG	X	X			
31	226009	2	STUD BAIL STYLE	X	X			
32	226008	2	RETAINER	X	X			
33	226007	2	RECEPTACLE	X	X			
34	101129	2	BOLT,HEXHD	X	X			
35	220635	1	BLOCK VALVE	X	X			
40	220765	2	O-RING	X	X			
41	226006	1	HEATER HOSE,220MM LONG	X	X			
42	226005	2	NYLON SPACER	X	X			
45	226016	1	MOTORIZED VALVE ASSY	X	X			
50	226280	1	RELAY BOARD	X	X			
51	226846	1	WIRING HARNESS	X	X			
61	200061	2	CLAMP,PIPE	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	241466	1	HOSE,HVAC,COMP,COND	X	X			
2	241465	1	HOSE,HVAC,COND,FWALL	X	X			
3	216373	1	CLAMP,RUBBER,6,FRAME	X	X			
4	216372	1	CLAMP,RUBBER,5,FRAME	X	X			
5	216366	1	ADAPTOR,COMPRESS,HVAC	X	X			
6	216365	1	PIPE,CONDENSOR,AC	X	X			
7	216364	1	PIPE,CONDENSOR,AC	X	X			
8	207908	1	CLAMP,RUBBER,10,F/WALL	X	X			
9	207853	1	ASSY,HOSE,HVAC,F/WAL,COMP	X	X			
10	207213	4	MTG,RUBBER,CONDENSER,HVAC	X	X			
11	207044	2	CLAMP,ALU,4 BOLT	X	X			
12	207043	2	CLAMP,ALU,2 BOLT	X	X			
13	207018	1	CLAMP,ALUM,4 BOLT	X	X			
14	207017	1	CLAMP,ALUM,2 BOLT	X	X			
15	206979	1	CONDENSER,AIR-CON	X	X			
16	206945	2	MTG,RUBBER	X	X			
17	206829	6	SPACER,CLAMP,ALUM	X	X			
18	203975	1	PROTECTOR,HOSE STRAP ON	X	X			
19	203764	1	P-CLIP	X	X			
20	201439	1	P-CLIP	X	X			
21	201419	2	P-CLIP	X	X			
22	200653	3	CABLE TIE	X	X			
23	187336	1	BKT,RUBBER CLAMP	X	X			
24	187225	1	MTG,ELEC HARNESS/HVAC	X	X			
25	186978	1	BKT,FNT,HVAC HOSES	X	X			
26	176589	1	BKT,P-CLIP,AIRCON	X	X			
27	175041	1	MTG ARM,HOSE RUBBER,CAB	X	X			
28	100548	24	WASHER,HARDENED	X	X			
29	100370	18	WASHER,HARDENED	X	X			
30	100364	1	SCREW,HEXHD	X	X			
31	100314	11	NUT,NYLOC	X	X			
32	100312	14	NUT,NYLOC	X	X			
33	100310	2	NUT,NYLOC	X	X			
34	100198	6	SCREW,HEXHD	X	X			
35	100089	6	SCREW,HEXHD	X	X			
36	100084	6	BOLT,HEXHD	X	X			
37	100083	2	SCREW,HEXHD	X	X			
38	100081	1	SCREW,HEXHD	X	X			
39	100080	1	SCREW,HEXHD	X	X			
40	100061	4	WASHER,FLAT	X	X			

https://truckmanualshub.com/



https://truckmanualshub.com/


FRONT CHASSIS KIT

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	187272	1	FRAME,S/TNK,BON/CATCH,T3	X	X			
2	186040	1	MTG,MK2,HYD BLOCK	X	X			
3	186036	2	CHANNEL,STRAP,SUPPORT	X	X			
4	182489	1	CHASSIS,FRONT,10MM	X	X			
5	178889	1	MTG,FRONT,P/SHAFT GUARD	X	X			
6	178747	1	MTG PLT,HOSES,F/CHASSIS	X	X			
7	178746	1	MTG PLT,EXHAUST,F/CHASSIS	X	X			
8	174687	1	MTG,REAR,P/SHAFT GUARD	X	X			
9	174677	1	GUARD,P/SHAFT	X	X			
10	174497	1	MTG,CAB,FRONT RIGHT	X	X			
11	174496	1	MTG,CAB,FRONT LEFT	X	X			
12	174490	2	MTG,FUEL TANK,BATT BOX	X	X			
13	161913	8	BOSS,STRAP,F/CHASSIS	X	X			
14	100945	8	SCREW,HEXHD	X	X			
15	100653	8	NUT,STOVER	X	X			
16	100569	4	SCREW,HEXHD	X	X			
17	100548	16	WASHER,HARDENED	X	X			
18	100536	8	WASHER,HARDENED	X	X			
19	100532	16	WASHER,HARDENED	X	X			
20	100491	8	SCREW,HEXHD	X	X			
21	100424	8	WASHER,HARDENED	X	X			
22	100415	4	NUT,NYLOC	X	X			
23	100370	32	WASHER,HARDENED	X	X			
24	100316	4	NUT,NYLOC	X	X			
25	100314	16	NUT,NYLOC	X	X			
26	100312	12	NUT,NYLOC	X	X			
27	100212	4	SCREW,HEXHD	X	X			
28	100198	8	SCREW,HEXHD	X	X			
29	100146	4	SCREW,HEXHD	X	X			
30	100091	2	SCREW,HEXHD	X	X			
31	100090	6	SCREW,HEXHD	X	X			
32	100062	8	WASHER,FLAT	X	X			

https://truckmanualshub.com/

BONNET KIT: DETAIL A

TO VIN 3313



https://truckmanualshub.com/

BONNET KIT: DETAIL A

TO VIN 3313


ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	263642	1	KIT,BONNET COMPL SMALL D# P&A	X	X			For Parts and Aftersales only. Also referenced on page 7-59.
1	218690	1	BONNET,SHELL	X	X			
3	218315	1	HANDLE,PADDLE,BONNET	X	X			
4	207861	1	PLT,RUBBER,BONNET SEAL	X	X			
5	207860	1	RUBBER,SEAL,BONNET	X	X			
6	206439	1	HANDLE,CAB INTERIOR	X	X			
7	204122	2	RUBBER,PROG.BUMP STOP	X	X			
8	201509	1	LATCH,GASKET	X	X			
10	183496	1	HINGE,BONNET,LHS	X	X			
11	183200	1	HINGE,BONNET,RHS	X	X			
12	178967	1	PLT,BOX,PADHANDLE	X	X			
14	176519	2	PLT,BONNET MTG,HINGE	X	X			
15	175066	2	MTG,STRUT,BONNET	X	X			
19	100994	2	CAPSCREW,SOCHD	X	X			
22	100548	4	CAPSCREW,SOCHD	X	X			
23	100456	8	CAPSCREW,CSK SOCHD	X	X			
24	100424	2	WASHER,HARDENED	X	X			
25	100370	8	WASHER,HARDENED	X	X			
27	100314	8	NUT,NYLOC	X	X			
28	100312	8	NUT,NYLOC	X	X			
29	100310	13	NUT,NYLOC	X	X			
30	100288	2	NUT,HEXAGON	X	X			
31	100220	4	CAPSCREW,SOCHD	X	X			
33	100063	4	WASHER,FLAT	X	X			
34	100062	4	WASHER,FLAT	X	X			
35	100061	13	WASHER,FLAT	X	X			
36	186229	1	PLT,GUIDE,ROD,BONNET	X	X			

https://truckmanualshub.com/

BONNET KIT: DETAIL A

FROM VIN 3314

A



TD0004208
264427 SH1-2 A

https://truckmanualshub.com/

BONNET KIT: DETAIL A


FROM VIN 3314

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	263642	1	KIT,BONNET COMPL SMALL D# P&A	X	X			For Parts and Aftersales only. Also referenced on page 7-63.
1	218999	1	RUBBER,SEAL,BONNET	X	X			
2	218690	1	BONNET,SHELL	X	X			
5	207861	1	PLT,RUBBER,BONNET SEAL	X	X			
6	206439	1	HANDLE,CAB INTERIOR	X	X			
7	204122	2	RUBBER,PROG.BUMP STOP	X	X			
17	183496	1	HINGE,BONNET,LHS	X	X			
18	183200	1	HINGE,BONNET,RHS	X	X			
20	176519	2	PLT,BONNET MTG,HINGE	X	X			
21	175066	2	MTG,STRUT,BONNET	X	X			
22	100994	2	CAPSCREW,SOCHD	X	X			
27	100548	12	WASHER,HARDENED	X	X			
28	100456	8	CAPSCREW	X	X			
29	100424	2	WASHER,HARDENED	X	X			
30	100370	8	WASHER,HARDENED	X	X			
31	100314	9	NUT,NYLOC	X	X			
32	100312	16	NUT,NYLOC	X	X			
33	100310	16	NUT,NYLOC	X	X			
34	100288	2	NUT,HEXAGON	X	X			
38	100062	12	WASHER,FLAT	X	X			
39	100061	15	WASHER,FLAT	X	X			

https://truckmanualshub.com/

BONNET KIT: DETAIL A (CONTINUED)

FROM VIN 3314



TD0004394
264427 SH2-2 A

https://truckmanualshub.com/


BONNET KIT: DETAIL A (CONTINUED)

FROM VIN 3314

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
3	218315	1	HANDLE,PADDLE,BONNET	X	X			
4	216626	1	SPRING,T,BONNET CATCH	X	X			
8	201509	1	LATCH,GASKET	X	X			
9	200779	1	TIE ROD,END,WITH CLIP	X	X			
10	200779	1	TIE ROD,END,WITH CLIP	X	X			
11	187690	2	PLT,TONGUE,BONNET CATCH	X	X			
12	187688	1	LINK,BONNET CATCH	X	X			
13	187634	1	LINKAGE,BONNET	X	X			
14	187633	1	MTG,BONNET CATCH	X	X			
15	187632	1	HOUSING,BONNET CATCH	X	X			
16	186229	1	PLT,GUIDE,ROD,BONNET	X	X			
19	178967	1	PLT,BOX,PADHANDLE TRIMARK	X	X			
23	100757	1	BOLT,HEXHD	X	X			
24	100731	4	SCREW,HEXHD	X	X			
25	100684	1	BOLT,HEXHD	X	X			
26	100569	4	SCREW,HEXHD	X	X			
27	100548	12	WASHER,HARDENED	X	X			
31	100314	9	NUT,NYLOC	X	X			
32	100312	16	NUT,NYLOC	X	X			
33	100310	16	NUT,NYLOC	X	X			
35	100220	4	CAPSCREW,SOCHD	X	X			
36	100064	1	WASHER,FLAT	X	X			
37	100063	4	WASHER,FLAT	X	X			
38	100062	12	WASHER,FLAT	X	X			
39	100061	15	WASHER,FLAT	X	X			

https://truckmanualshub.com/

BONNET KIT: DETAIL B




TD0003688 C
E9836103 SH1-2 I

https://truckmanualshub.com/

BONNET KIT: DETAIL B

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	263642	1	KIT,BONNET COMPL SMALL D# P&A	X	X			For Parts and Aftersales only. Also referenced on page 7-53.
1	264427	1	KIT,BONNET ASSY	X	X			
2	221760	4	CIRCLIP:EXTERNAL	X	X			
5	208072	2	STRAP,BONNET	X	X			
6	207606	2	GASSTRUT,BONNET	X	X			
9	183201	2	HINGE,CHASSIS(BONNET)	X	X			
12	161055	2	PIN,BONNET HINGE	X	X			
15	100655	4	NUT,STOVER	X	X			
18	100424	8	WASHER,HARDENED	X	X			
19	100370	12	WASHER,HARDENED	X	X			
20	100314	6	NUT,NYLOC	X	X			
23	100119	4	BOLT,HEXHD	X	X			
24	100364	6	SCREW,HEXHD	X	X			

https://truckmanualshub.com/




TD0003689 B
E9836103 SH2-2 I

https://truckmanualshub.com/

BONNET CATCH

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
3	218855	2	PAD,GUIDE BONNET	X	X			
4	216625	1	SPRING,C,BONNET CATCH	X	X			
7	187689	1	PEG,BONNET CATCH	X	X			
8	186347	1	PLT,GUIDE BONNET	X	X			
10	173802	1	CUP,BONNET CATCH	X	X			
11	172043	2	WASHER,RUBBER	X	X			
13	101301	2	WASHER,FLAT,BONNET CATCH	X	X			
14	100731	4	SCREW,HEXHD	X	X			
16	100654	2	NUT,STOVER	X	X			
17	100548	8	WASHER,HARDENED	X	X			
21	100312	4	NUT,NYLOC	X	X			
22	100293	1	NUT,HEXAGON	X	X			
25	100083	6	SCREW,HEXHD	X	X			
26	100062	6	WASHER,FLAT	X	X			

https://truckmanualshub.com/




TD0003162
E14832115 - C

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	910241	1	PINCH WELD,BOOTSEAL,1.6mm PLATE	X	X			690 mm Long.
2	910241	1	PINCH WELD,BOOTSEAL,1.6mm PLATE	X	X			615 mm Long.
3	910241	1	PINCH WELD,BOOTSEAL,1.6mm PLATE	X	X			40 mm Long.
4	910241	1	PINCH WELD,BOOTSEAL,1.6mm PLATE	X	X			235 mm Long.
5	910241	1	PINCH WELD,BOOTSEAL,1.6mm PLATE	X	X			18 mm Long.
6	910241	1	PINCH WELD,BOOTSEAL,1.6mm PLATE	X	X			165 mm Long.
7	216231	1	SEAL,TOP,RAD	X	X			
8	216063	1	SEAL,BOTTOM,RAD	X	X			
9	216062	2	SEAL,SIDE,BONNET	X	X			
10	216060	1	SEAL,TOP,BONNET	X	X			
11	204708	1	PLT,PERFORATED,GRILL	X	X			
12	187454	1	PLT,SEAL,RAD,LHS	X	X			
13	187453	1	PLT,SEAL,RAD,RHS	X	X			
14	187452	1	MTG,PIPE,COMPRESSOR	X	X			
15	187226	1	FRAME,GRILL	X	X			
16	176204	1	PLT,MTG,TOP,CONDENSOR	X	X			
17	101307	6	WASHER,FLAT	X	X			
18	100370	28	WASHER,HARDENED	X	X			
19	100364	4	SCREW,HEXHD	X	X			
20	100314	4	NUT,NYLOC	X	X			
21	100089	26	SCREW,HEXHD	X	X			

https://truckmanualshub.com/

BELLY PLATE




https://truckmanualshub.com/

BELLY PLATE

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	221760	4	CIRCLIP:EXTERNAL	X	X			
2	183201	4	HINGE,CHASSIS(BONNET)	X	X			
3	181522	1	ASSY,BELLY PLATE	X	X			
4	174449	1	PLATE,COVER,BELLY,LHS	X	X			
5	174448	1	PLATE,COVER,BELLY,RHS	X	X			
6	174446	2	PLATE,BELLY,FRONT	X	X			
7	161055	2	PIN,BONNET HINGE	X	X			
8	161054	4	SHIM,4MM,BELLYPLT,FRONT	X	X			
9	100945	18	SCREW,HEXHD	X	X			
10	100424	14	WASHER,HARDENED	X	X			
11	100370	34	WASHER,HARDENED	X	X			
12	100316	7	NUT,NYLOC	X	X			
13	100314	16	NUT,NYLOC	X	X			
14	100212	7	BOLT	X	X			
15	100123	4	CAPSCREW	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	217861	1	NONSLIP,MUDGUARD,RHS	X	X			
2	217860	1	NONSLIP,MUDGUARD,LHS	X	X			
3	216963	1	EXTENSION,MUDGUARD,RHS	X	X			
4	216964	1	EXTENSION,MUDGUARD,LHS	X	X			
5	207521	2	MUDFLAP,MUDGUARD	X	X			
6	207520	2	MUDFLAP,MUDGUARD STUT	X	X			
7	206767	4	STRAP,STEP RUBBER CONNECTOR	X	X			
8	204374	2	REFLECTOR,AMBER,BOLT ON	X	X			
9	187789	2	HANDRAIL,MUDGUARD,RHS	X	X			
10	187782	2	MTG,STEP,BOTT,M/GUARD	X	X			
11	187781	2	MTG,STEP,MID,M/GUARD	X	X			
12	187779	2	STEP,BOTTOM,M/GUARD	X	X			
13	187754	1	MUDGUARD,RHS	X	X			
14	187753	1	MUDGUARD,LHS	X	X			
15	187750	2	STEP,BOTTOM,M/GUARD	X	X			
16	186806	2	PLT,SANDWICH,MUDGUARD	X	X			
17	176534	4	STIFFENER,MUDFLAP,STRUT	X	X			
18	173964	8	PLT,BACKING,STEP STRAP,BTM	X	X			
19	101301	24	WASHER,FLAT	X	X			
20	100731	12	SCREW,HEXHD	X	X			
21	100569	6	SCREW,HEXHD	X	X			
22	100548	36	WASHER,HARDENED	X	X			
23	100415	12	NUT,NYLOC	X	X			
24	100370	68	WASHER,HARDENED	X	X			
25	100314	34	NUT,NYLOC	X	X			
26	100312	12	NUT,NYLOC	X	X			
27	100310	18	NUT,NYLOC	X	X			
28	100146	12	SCREW,HEXHD	X	X			
29	100090	16	SCREW,HEXHD	X	X			
30	100086	18	SCREW,HEXHD	X	X			
31	100083	6	SCREW,HEXHD	X	X			
32	100081	18	SCREW,HEXHD	X	X			
33	100061	36	WASHER,FLAT	X	X			

https://truckmanualshub.com/

BATTERY BOX KIT




https://truckmanualshub.com/

BATTERY BOX KIT

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	910321	1	STRIP,GROMMET,1.6-4X8.5,BLACK	X	X			
2	910223	1	PINCHWELD:LARGE 8MMX15MM	X	X			
3	217924	1	NONSLIP,REAR,B/BOX	X	X			
4	217923	1	NONSLIP,TOP LID,B/BOX	X	X			
5	217922	1	NONSLIP,FRONT,BATTERY BOX	X	X			
6	207375	1	BOLT,STRIKER	X	X			
7	207366	1	LATCH,LH	X	X			
8	207206	1	HANDLE,PADDLE,BATT BOX	X	X			
9	206494	1	COVER,HEADLIGHT,LHS	X	X			REFERENCE PAGES 7-75
10	206415	2	HINGE,EXTERIOR	X	X			
11	204374	2	REFLECTOR,AMBER,BOLT ON	X	X			
12	201509	1	LATCH,GASKET	X	X			
13	187541	1	PLT,DOOR OPEN LOCK	X	X			
14	187191	1	DOOR,BATTERY BOX	X	X			
15	187189	1	LID,TOP,BATTERY BOX	X	X			
16	187188	1	BOX,BATTERY	X	X			
17	178799	1	WASHER,MACHINED	X	X			
18	173969	1	LINK,LOCK,BATTERY BOX	X	X			
19	173837	1	MTG,BOTTOM,F/TANK,B/BOX	X	X			
20	100878	24	WASHER,FENDER	X	X			
21	100617	1	NUT,NYLOC	X	X			
22	100608	16	CAPSCREW	X	X			
23	100569	1	SCREW,HEXHD	X	X			
24	100424	21	WASHER,HARDENED	X	X			
26	100316	10	NUT,NYLOC	X	X			
27	100312	2	NUT,NYLOC	X	X			
28	100310	10	NUT,NYLOC	X	X			
29	100273	4	SCREW,HEXHD	X	X			
31	100212	10	SCREW,HEXHD	X	X			
32	100198	1	SCREW,HEXHD	X	X			
33	100080	6	SCREW,HEXHD	X	X			
34	100063	4	WASHER,FLAT	X	X			
35	100062	3	WASHER,FLAT	X	X			
36	100061	8	WASHER,FLAT	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/


FUEL TANK MISC PARTS

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	217863	1	NONSLIP,REAR,F/TANK	X	X			
2	208649	1	CAP,DIESEL FILLER	X	X			REFERENCE PAGES 7-73
3	206495	1	COVER,HEADLIGHT,RHS	X	X			REFERENCE PAGES 7-75
4	204374	2	REFLECTOR,AMBER	X	X			
5	201503	1	GASKET,CORK,DIESEL TANK	X	X			
6	187538	1	TANK,FUEL,TIER3	X	X			
7	176427	1	LID,MAIN DIESEL,ACCESS	X	X			
8	173837	1	MTG,BOTTOM,F/TANK,B/BOX	X	X			
9	120396	1	PLUG,CLOSURE HEX SOCKET	X	X			
10	100731	6	SCREW,HEXHD	X	X			
11	100548	6	WASHER,HARDENED	X	X			
12	100424	20	WASHER,HARDENED	X	X			
13	100316	10	NUT,NYLOC	X	X			
14	100212	10	SCREW,HEXHD	X	X			


https://truckmanualshub.com/



BOTTOM VIEW



TOP VIEW




TD0004319
208649 - A

https://truckmanualshub.com/

CAP, DIESEL FILLER

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	208649	1	CAP,DIESEL FILLER	X	X			REFERENCE PAGES 7-71
2	140542	1	SEAL,CAP,DIESEL FILLER	X	X			
3	210771	1	VALVE,RELIEF,DIESEL CAP,5PSI	X	X			
4	210772	1	VALVE,RELIEF,DIESEL CAP,1PSI	X	X			

https://truckmanualshub.com/




TD0004318
206494 - E
206495 - E

https://truckmanualshub.com/

COVER, HEADLIGHT

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	206494	1	COVER,HEADLIGHT,LHS	X	X			REFERENCE PAGES 7-69
1	206495	1	COVER,HEADLIGHT,RHS	X	X			REFERENCE PAGES 7-71
2	100111	4	SCREW,HEXHD	X	X			
3	100148	4	WASHER,FLAT	X	X			

https://truckmanualshub.com/




TD0003153 - A
E14832102 - A

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	263898	2	ASSY,TRI-LINK,SPHERICAL	X	X			REFERENCE PAGES 7-79
2	230358	1	CYL,SUSP.STRUT,RHS,T3	X	X			
3	230357	1	CYL,SUSP.STRUT,LHS,T3	X	X			
4	216443	1	LINK,DRAG	X				REFER SB 2006/1040
4	216444	1	LINK,DRAG		X			REFER SB 2006/1040
5	206071	2	SHOCK MAT,B30D BIN	X	X			
6	178169	8	SHIM,AXLE SPACING,DOMEX	X	X			
7	161016	4	BOSS	X	X			
8	101326	4	BOLT,HEXHD	X	X			
9	101048	6	CAPSCREW,SOCHD	X	X			
10	100887	14	CAPSCREW,SOCHD	X	X			
11	100777	4	NUT,HEXAGON	X	X			
12	100547	4	WASHER,FLAT	X	X			
13	100532	32	WASHER,HARDENED	X	X			
14	100370	16	WASHER,HARDENED	X	X			
15	100322	16	NUT,HEX	X	X			
16	100314	8	NUT,NYLOC	X	X			
17	100089	8	SCREW,HEXHD	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

LINK ASSEMBLY, FRONT SUSPENSION

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	263898	2	ASSY,TRI-LINK,SPHERICAL	X	X			REFERENCE PAGES 7-77
1	206074	3	SPHERICAL BRG,2 BOLT	X	X			REFERENCE PAGES 7-81
2	203739	1	SPHERICAL BRG,2 BOLT	X	X			
3	187497	1	LINK,BASE,SPHERICAL	X	X			
4	187496	1	LINK,TOP,SPHERICAL	X	X			
5	161016	2	BOSS	X	X			
6	101188	2	CAPSCREW,SOCHD	X	X			

https://truckmanualshub.com/




206074
TD0004788

https://truckmanualshub.com/

SPHERICAL BEARING BREAKDOWN

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	206074	2	SPHERICAL BRG,2 BOLT	X	X			REFERENCE PAGES 7-79 ; 83
2	206075	3	SPACER,SPHERICAL BRG	X	X			
3	202599	1	RING,SNAP	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

CYLINDER, SUSPENSION STRUT

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
A	230357	1	CYLINDER,SUSP.STRUT,LHS,ASSY	X	X			
A	230358	1	CYLINDER,SUSP.STRUT,RHS,ASSY	X	X			
1	210696	1	CAP,VALVE CYL SUSPSTRUT	X	X			
2	210695	1	VALVE,CYL SUSPSTRUT	X	X			
3	208042	2	GUIDE,TAPE,PISTON PTFE,STRUT	X	X			
4	207676	1	PLUG,MAGNETIC	X	X			
5	207340	1	DECAL,SUSPENSION CYLINDER	X	X			
6	206287	1	BELLOW,RUBBER	X	X			
7	206286	1	CLAMP,HOSE	X	X			
8	206074	2	SPHERICAL BRG,2 BOLT	X	X			REFERENCE PAGES 7-81
9	200085	1	CLAMP,HOSE	X	X			
10	190742	1	PLUG,HEX	X	X			
11	186336	1	CARRIER,MAGNET,STRUT	X	X			
12	184065	1	ASSY,PISTON,SUSP.STRUT	X	X			
13	184060	1	ASSY,BARREL,SUSP.STRUT	X	X			
14	184059	1	ASSY,ROD,SUSP.STRUT	X	X			
15	174554	1	GUARD,SUSP.STRUT VALVE	X	X			
16	160839	1	NECKBUSH,SUSP.STRUT	X	X			
17	140706	2	W/BAND,PISTON	X	X			
18	140696	2	W/BAND,ROD	X	X			
19	140498	1	SEAL,WIPER POLYU	X	X			
20	140443	1	SEAL,ROD,COMPACT	X	X			
21	140442	1	SEAL,ROD,OMEGAT	X	X			
22	140411	1	RING,BACK UP	X	X			
23	140397	1	O-RING	X	X			
24	140169	1	O-RING	X	X			
25	101087	1	NUT,HEX	X	X			
26	101080	6	WASHER,HARDENED	X	X			
27	101079	8	CAPSCREW,SOCD	X	X			
28	100209	2	SCREW,HEXHD	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
13	220010	1	ELEMENT:FILTER 29MICRON GUD	X	X			
16	210862	1	ASSY,FILTER,FINN,5MICRON	X	X			REFERENCE PAGES 7-87
17	210497	1	STRAINER,125 MICRON,350L/MIN	X	X			
18	210105	1	LEVEL,INDICATOR	X	X			
21	208068	1	SLING,HOSE	X	X			
22	207988	1	SPRING,ARTIC HOSE	X	X			
23	207967	1	BOOT, RUBBER, DRAIN VALVE	X	X			
24	207795	1	SPRING,ARTIC HOSES	X	X			
27	206787	1	CAP,FILLER,HYDRAULIC	X	X			
29	206373	1	GASKET,HYD TANK	X	X			
32	201412	1	MAGNET:ULTRA-T TANK-CERAMIC	X	X			
33	183333	1	LID,IN-TANK,FILTER	X	X			
34	182624	1	TANK,HYD,FUEL	X	X			
35	176609	1	MTG,GUARD,LOWER	X	X			
36	176608	1	GUARD,WINDOW,LOWER	X	X			
37	176600	1	BKT,HYD MISC	X	X			
38	174494	1	GUARD,HYD,TANK	X	X			
39	173954	1	PLT,LOCK BULKHEAD	X	X			
41	187957	1	LID,HYD TANK	X	X			
44	140466	1	O RING	X	X			
48	122136	1	VALVE,DRAIN	X	X			
54	100731	26	SCREW	X	X			
55	100653	4	NUT,STOVER	X	X			
56	100548	48	WASHER,HARDENED	X	X			
57	100532	10	WASHER,HARDENED	X	X			
58	100370	8	WASHER,HARDENED	X	X			
59	100364	2	SCREW,HEXHD	X	X			
60	100314	8	NUT,NYLOC	X	X			
61	100196	8	BOLT,HEXHD	X	X			
62	100158	4	BOLT	X	X			
63	100144	2	SCREW,HEXHD	X	X			
65	100089	8	SCREW,HEXHD	X	X			

https://truckmanualshub.com/



https://truckmanualshub.com/


HYDRAULIC TANK FILTER ASSEMBLY

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	210862	1	ASSY,FILTER,FINN,5MICRON	X	X			REFERENCE PAGES 7-85
2	222389	1	ELEMEMT,FLTR,HYDRAULIC,5MICRON	X	X			
3	220738	1	FUNNEL,FILTER	X	X			
4	140744	1	KIT,SEAL	X	X			
5	226531	1	SPRING	X	X			
6	226532	1	HOLDER,FILTER ASSEMBLY	X	X			
7	226530	1	WASHER,WITH CAP SCREW	X	X			
8	100197	1	CAPSCREW,SOCHD	X	X			

https://truckmanualshub.com/

ARTIC JOINT BEARING ASSEMBLY

TO VIN 3448



TD0003696
E9836200 SH1-2 C

https://truckmanualshub.com/

ARTIC JOINT BEARING ASSEMBLY


TO VIN 3448

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	261891	2	PIN ASSY,ARTIC LOCK	X	X			
2	181191	1	PIN,FLOAT'G:BOTTOM ARTIC	X	X			
3	173275	2	SHIM,FIXED ARTIC	X	X			
4	172976	1	LOCK,ARTICULATED	X	X			
5	162347	1	PIN,FIXED,TOP ARTIC	X	X			
6	162346	2	PLT,COVER,FLOAT,ARTIC	X	X			
7	162345	2	PLT,COVER,FIXED,ARTIC	X	X			
8	161685	1	MTG PLT,FIXED ARTIC	X	X			
9	160706	1	SLEEVE,FIXED ARTIC	X	X			
10	150137	2	ASSY,BEARING,ARTIC HITCH	X	X			
11	140720	4	O-RING	X	X			
12	140602	2	SEAL,OIL,DOUBLE LIP	X	X			
13	140303	2	SEAL,OIL	X	X			
14	100888	4	CAPSCREW,SOCHD	X	X			
15	100461	8	CAPSCREW,SOCHD	X	X			
16	100370	1	WASHER,HARDENED	X	X			
17	100225	32	CAPSCREW,SOCHD	X	X			
18	100123	4	CAPSCREW,SOCHD	X	X			
19	100089	1	SCREW,HEXHD	X	X			

https://truckmanualshub.com/

ARTIC JOINT BEARING ASSEMBLY

FROM VIN 3449



TD0003696 B
E9836200 SH1-2 D


https://truckmanualshub.com/

ARTIC JOINT BEARING ASSEMBLY

FROM VIN 3449

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	261891	2	PIN ASSY,ARTIC LOCK	X	X			
2	187885	1	PIN ASSY,FLOAT ARTIC	X	X			
3	187011	4	BUSH,PIN RETAINING	X	X			
4	173275	2	SHIM,FIXED ARTIC	X	X			
5	172976	1	LOCK,ARTICULATED	X	X			
6	162347	1	PIN,FIXED,TOP ARTIC	X	X			
7	162346	2	PLT:COVER-FLOAT ARTIC	X	X			
8	162345	2	PLT:COVER-FIXED ARTIC	X	X			
9	161685	1	MTG PLT:FIXED ARTIC	X	X			
10	160706	1	SLEEVE,FIXED ARTIC	X	X			
11	150137	2	ASSY,BEARING,ARTIC HITCH	X	X			
12	140720	4	O RING,NEOPRENE	X	X			
13	140602	2	SEAL,OIL,DOUBLE LIP	X	X			
14	140303	2	SEAL,OIL	X	X			
15	100888	4	CAPSCREW,SOCHD	X	X			
16	100461	8	CAPSCREW	X	X			
17	100370	1	WASHER,HARDENED	X	X			
18	100225	32	CAPSCREW	X	X			
19	100212	4	SCREW,HEXHD	X	X			
20	100148	4	WASHER,FLAT	X	X			
21	100089	1	SCREW,HEXHD	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	208771	1	GROMMET	X	X			
2	203923	1	GROMMET	X	X			
3	202686	1	GRIP,PTC 25MM PIPE	X	X			
4	186940	1	PLT,ARTIC,PROTECT	X	X			
5	186919	1	PLT,MTG,B/HEAT CV	X	X			
6	186706	3	ASSY,COVER,BOTTOM	X	X			
7	186705	1	ASSY,COVER,RHS	X	X			
8	186704	1	ASSY,COVER,LHS	X	X			
9	186703	2	RUBBER,UPPER SUSP.CAVITY	X	X			
10	186699	1	COVER,TOP,F/OSCIL	X	X			
11	186698	2	COVER,BACK,REAR,F/OSCIL	X	X			
12	186697	1	COVER,REAR,RHS,F/OSCIL	X	X			
13	186696	1	COVER,REAR,LHS,F/OSCIL	X	X			
14	186695	2	STRAP,F/OSCILL,CROSS PLT	X	X			
15	186693	2	RUBBER,SUSP,CAVITY,LHS	X	X			
16	186692	1	ASSY,BIN POLE	X	X			
17	186691	2	SHIM,BIN SUPPORT POLE	X	X			
18	184100	1	CHASSIS,REAR	X	X			
19	178141	4	SHIM,BIN SUPPORT POLE	X	X			
20	176490	3	SHIM,BIN SUPPORT POLE MTG	X	X			
21	174700	1	REMOVABLE B/HEATING PROT	X	X			
22	170489	2	SAW CYL.WASHER	X	X			
23	162242	1	PIN,PIVOT,BIN STAY	X	X			
24	130049	4	HOSE,CLEAR	X	X			
25	105013	1	SCREW,HEXHD	X	X			
26	100569	8	SCREW,HEXHD	X	X			
27	100536	8	WASHER,HARDENED	X	X			
28	100424	2	WASHER,HARDENED	X	X			
29	100370	4	WASHER,HARDENED	X	X			
30	100312	8	NUT,NYLOC	X	X			
31	100288	2	NUT,HEXAGON	X	X			
32	100210	2	SCREW,HEXHD	X	X			
33	100128	8	SCREW,HEXHD	X	X			
34	100091	4	SCREW,HEXHD	X	X			
35	100085	2	SCREW,HEXHD	X	X			
36	100082	10	SCREW,HEXHD	X	X			
37	100062	26	WASHER,FLAT	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	216482	4	SANDWICH BLOCK,AXLE MTG	X	X			
2	206073	8	LINK,DRAG,B30D	X				
2	206364	8	LINK,DRAG,B25D		X			
3	201556	4	CONICAL BEARING,RUBBER	X	X			
4	216562	4	CHAIN,TIE,AXLE	X	X			
5	262778	2	ASSY,W/BEAM,WEIGHING SYS	X	X			
6	183003	2	TAPER PLUG, WALKING BEAM	X	X			
7	178169	AR	SHIM,AXLE SPACING,DOMEX	X	X			
8	187674	4	PLATE,SPACER,AXLE	X	X			
9	170548	8	PLT,LOCK,AXLE,ADT	X	X			
10	161016	8	BOSS	X	X			
11	100532	54	WASHER,HARDENED	X	X			
12	100887	38	CAPSCREW,SOCHD	X	X			
13	100424	48	WASHER,HARDENED	X	X			
14	100322	24	NUT,HEX	X	X			
15	100316	16	NUT,NYLOC	X	X			
16	100119	16	BOLT,HEXHD	X	X			
17	100111	16	SCREW,HEXHD	X	X			

https://truckmanualshub.com/




TD0003701
E9836112 - M

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D			Vin Series From: To:	REMARKS
1	218858	2	MAT,SHOCK,REAR,BIN,B30D MKII	X				
2	206079	2	MUDFLAP,BIN MOUNTED,B30D	X				
3	206071	2	SHOCK MAT,B30D BIN	X				
4	204374	6	REFLECTOR,AMBER	X				
5	204373	2	REFLECTOR,RED	X				
6	203926	2	GROMMET	X				
7	186372	2	SHIM,PAD,REAR,BIN,B30D,MKII	X				
8	186366	2	PLT,GUARD,LTBOX,BIN	X				
9	182809	1	BIN,B30D MKII	X				
10	182545	1	BOX,LIGHT,RH,BIN	X				
11	182544	1	BOX,LIGHT,LH,BIN	X				
12	178669	6	SHIM,5MM NEW GUIDE PLT	X				
13	178668	6	SHIM,1.6MM NEW GUIDE PLT	X				
14	178656	2	PLT,GUIDE,BIN	X				
15	176540	1	HANDLE,BIN,FRONT	X				
16	174768	6	PLT,MTG,REFLECTOR	X				
17	172806	2	SHIM,5MM BIN HEIGHT	X				
18	172805	2	SHIM,1.6MM BIN HEIGHT	X				
19	172782	2	PLT,MUDFLAP MTG	X				
20	161025	4	BUSH,BIN PIVOT	X				
21	161016	6	BOSS	X				
22	100985	8	SCREW,HEXHD	X				
23	100868	6	WASHER	X				
24	100731	12	SCREW,HEXHD	X				
25	100653	6	NUT,STOVER	X				
26	100598	8	CAPSCREW,SOCHD	X				
27	100548	20	WASHER,HARDENED	X				
28	100536	8	WASHER,HARDENED	X				
29	100532	18	WASHER,HARDENED	X				
30	100463	6	CAPSCREW,SOCHD	X				
31	100424	24	WASHER,HARDENED	X				
32	100370	16	WASHER,HARDENED	X				
33	100364	8	SCREW,HEXHD	X				
34	100316	12	NUT,NYLOC	X				
35	100258	2	SCREW,HEXHD	X				
36	100212	12	SCREW,HEXHD	X				
37	100198	8	SCREW,HEXHD	X				
38	100144	4	SCREW,HEXHD	X				

https://truckmanualshub.com/



TD0003703
E10814112 - N


https://truckmanualshub.com/

BIN, MISCELLANEOUS PARTS: B25D

ITEM	PART No.	QTY	DESCRIPTION		B25D		Vin Series From: To:	REMARKS
1	218858	2	MAT,SHOCK,REAR,BIN,B30D MKII		X			
2	206079	2	MUDFLAP,BIN MOUNTED,B30D		X			
3	206071	2	SHOCK MAT,B30D BIN		X			
4	204374	6	REFLECTOR,AMBER		X			
5	204373	2	REFLECTOR,RED		X			
6	203926	2	GROMMET		X			
7	186372	2	SHIM,PAD,REAR,BIN,B30D,MKII		X			
8	186366	2	PLT,GUARD,LTBOX,BIN		X			
9	182808	1	BIN,B25D MKII		X			
10	182545	1	BOX,LIGHT,RH,BIN		X			
11	182544	1	BOX,LIGHT,LH,BIN		X			
12	178669	6	SHIM,5MM NEW GUIDE PLT		X			
13	178668	6	SHIM,1.6MM NEW GUIDE PLT		X			
14	178656	2	PLT,GUIDE,BIN		X			
15	176540	1	HANDLE,BIN,FRONT		X			
16	174768	6	PLT,MTG,REFLECTOR		X			
17	172806	2	SHIM,5MM BIN HEIGHT		X			
18	172805	2	SHIM,1.6MM BIN HEIGHT		X			
19	172782	2	PLT,MUDFLAP MTG		X			
20	161025	4	BUSH,BIN PIVOT		X			
21	161016	6	BOSS		X			
22	100985	8	SCREW,HEXHD		X			
23	100868	6	WASHER		X			
24	100731	12	SCREW,HEXHD		X			
25	100653	6	NUT,STOVER		X			
26	100598	8	CAPSCREW,SOCHD		X			
27	100548	20	WASHER,HARDENED		X			
28	100536	8	WASHER,HARDENED		X			
29	100532	18	WASHER,HARDENED		X			
30	100463	6	CAPSCREW,SOCHD		X			
31	100424	24	WASHER,HARDENED		X			
32	100370	16	WASHER,HARDENED		X			
33	100364	8	SCREW,HEXHD		X			
34	100316	12	NUT,NYLOC		X			
35	100258	2	SCREW,HEXHD		X			
36	100212	12	SCREW,HEXHD		X			
37	100198	8	SCREW,HEXHD		X			
38	100144	4	SCREW,HEXHD		X			

https://truckmanualshub.com/

BIN PIVOT




TD0003705 B
E9836116 SH1-2 E

https://truckmanualshub.com/

BIN PIVOT

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	184327	1	PIN ASSY,BIN PIVOT	X	X			
2	184326	1	PIN ASSY,PIVOT ROD SENSOR	X	X			
4	140169	4	O-RING	X	X			
5	187011	2	BUSH,PIN RETAINING	X	X			
6	100148	2	WASHER,FLAT	X	X			
7	100211	2	BOLT	X	X			

https://truckmanualshub.com/




TD0003706 A
E9836025 A
E10814025 A

https://truckmanualshub.com/

BIN LINER KIT

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	263835	1	KIT,LINERS,8MM,BIN,B30D	X				
1	263834	1	KIT,LINERS,8MM,BIN,B25D		X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	207648	2	CHAIN,ASSY,AUTOGATE,30D#	X				
1	207360	2	ASSY,CHAIN,AUTOGATE,B25D#		X			
2	206251	2	DECAL,GREASE POINT,BLK ON WHT	X	X			
3	206071	2	SHOCK MAT	X	X			
4	203990	2	NIPPLE,GREASE	X	X			
5	187471	2	PLT,STRETCH,TAILGATE,ARM,B30D	X				
6	186802	1	ARM,AUTOGATE,RHS,30D#	X				
6	186804	1	ARM,AUTOGATE,RHS,25D#		X			
7	186801	1	ARM,AUTOGATE,LHS,30D#	X				
7	186803	1	ARM,AUTOGATE,LHS,25D#		X			
8	183431	1	GATE,AUTOGATE,30D#	X				
8	183430	1	GATE,AUTOGATE,25D#		X			
9	182541	1	MTG,RH,TAILGATE,BIN,B30D,MKII	X				
9	182591	1	MTG,RH,TAILGATE,BIN,B25D MKII		X			
10	182540	1	MTG,LH,TAILGATE,BIN,B30D,MKII	X				
10	182590	1	MTG,LH,TAILGATE,BIN,B25D MKII		X			
11	181804	2	OUTRIG,AUTOGATE,RH	X	X			
12	181799	2	OUTRIG,AUTOGATE,LH	X	X			
13	181798	2	PLT,CHAIN-OUTRIG,AUTOGATE	X	X			
14	181796	2	OUTRIG,AUTOGATE,BOTTOM	X	X			
15	181564	2	ASSY,PIVOT,AUTOGATE	X	X			
16	176607	4	SHIM,GATE-ARM,AUTOGATE	X	X			
17	176580	2	SHIM,AUTOGATE,MAT	X	X			
18	174293	2	RETAINER PLT	X	X			
19	172010	2	PLT,WASHER	X	X			
20	161960	8	BOSS	X	X			
21	161017	8	BOSS	X	X			
22	150097	2	BEARING,SPHERICAL	X	X			
23	100985	8	SCREW,HEXHD	X	X			
24	100536	8	WASHER,HARDENED	X	X			
25	100532	6	WASHER,HARDENED	X	X			
26	100463	6	CAPSCREW,SOCHD	X				
26	100463	14	CAPSCREW,SOCHD		X			
27	100440	8	CAPSCREW,SOCHD	X				
28	100430	2	SPLITPIN	X	X			
29	100423	8	WASHER,FLAT	X	X			
30	100341	2	NUT,CASTLE	X	X			
31	100323	4	NUT,NYLOC	X	X			
32	100316	14	NUT,NYLOC	X	X			
33	100158	2	BOLT,HEXHD	X	X			
34	100148	28	WASHER,FLAT	X	X			
35	100146	16	SCREW,HEXHD	X	X			
36	100145	2	BOLT,HEXHD	X	X			
37	100114	14	SCREW,HEXHD	X	X			
38	100089	8	SCREW,HEXHD	X	X			
39	100085	8	SCREW,HEXHD	X	X			
40	100064	16	WASHER,FLAT	X	X			
41	100010	16	WASHER,FLAT	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	176114	1	PLATE,SERIAL NUMBER	X	X			
2	216065	1	DECAL,CB'S&IGN SOL	X	X			
3	207340	2	DECAL,SUSPENSION CYLINDER	X	X			
4	207339	1	DECAL,PASSENGER SEAT	X	X			
5	207290	1	DECAL,DEERE,LIFT/TIEDOWN PNT	X	X			
6	207306	1	DECAL,WARNING EATHER,START	X	X			
7	207349	2	DECAL,COMPRESSED AIR	X	X			
8	207346	2	DECAL,B&W,B30D	X				
9	207345	2	DECAL,B&W,B25D		X			
10	207312	1	DECAL,B&W BELL LOGO,FR BONNET	X	X			
11	207330	1	DECAL,PROPSHAFT GUARDS	X	X			
12	207331	1	DECAL,RADIATOR FAN WARNING	X	X			
13	207408	1	DECAL,STARTER MOTOR	X	X			
14	208046	1	DECAL,CAB SUPPORT	X	X			
15	207897	1	DECAL,CAB,L/PUMP LEVER	X	X			
16	207382	1	DECAL,CAB TILT	X	X			
17	207329	1	DECAL,HYDRAULIC PRESSURE	X	X			
18	207191	1	DECAL,DEERE,OVERHEAD POWERLINE	X	X			
19	207192	1	DECAL,DEERE,SEATBELT,WARNING	X	X			
20	207277	1	DECAL,PARK BRAKE,APPLICATION	X	X			
21	207307	1	DECAL,WARNING READ OMM	X	X			
22	207311	2	DECAL,BELL LOGO,CAB DOOR	X	X			
23	201886	1	DECAL,PDI/QUALITY	X	X			
24	218033	1	DECAL,AIRCON,FILTER,CLEAN	X	X			
25	207900	1	DECAL,SOUND PRESSURE	X	X			
26	216424	1	DECAL,SOUND POWER LEVEL	X	X			
27	217827	1	DECAL,WARNING,OVERSPEEDING	X	X			
28	207205	1	DECAL,TORQUE BINPROP BOLT	X	X			

https://truckmanualshub.com/

DECALS



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
27	207350	1	DECAL,SPRING PRESSURE	X	X			
28	207338	2	DECAL,PARK BRAKE WARNING	X	X			
29	207337	3	DECAL,VISIBILITY WARNING	X	X			
30	216497	1	DECAL,SPEED DOWN SLOPE	X				
31	216498	1	DECAL,SPEED DOWN SLOPE		X			
32	207385	1	DECAL,SHIFT INHIB./PARK BRAKE	X	X			
33	217845	1	DECAL,CB'S,FUSES,RELAYS	X	X			
34	207409	1	DECAL,BIN TIP	X	X			
35	207411	1	DECAL,EMERGENCY EXIT	X	X			
36	207412	1	DECAL,PARK BRAKE	X	X			
37	216531	1	DECAL,ROPS/FOPS,SML	X	X			
38	207350	1	DECAL,SPRING PRESSURE	X	X			
39	207310	2	DECAL,LIFTING EYE	X	X			
40	216942	1	DECAL,TYRE PRESSURE,30TON	X				
41	216941	1	DECAL,TYRE PRESSURE,25TON		X			
42	207410	1	DECAL,GREASE,500HRS,ARTIC	X	X			
43	216513	1	DECAL,RSG,SML	X	X			
44	207995	1	DECAL,HYDRAULIC TEST POINTS	X	X			
45	208073	1	DECAL,GREASE,500HRS,STR,CYL	X	X			
46	207304	4	DECAL,TIE DOWN POINT	X	X			
47	206249	2	DECAL,REFLECTOR,RED	X	X			
48	207338	2	DECAL,PARK BRAKE WARNING	X	X			
49	207381	1	DECAL,REFRIGERANT	X	X			
50	207336	2	DECAL,ARTICULATION CRUSH	X	X			
51	207291	1	DECAL,GREASE,OSCIL/R-BRG 500HD	X	X			
52	207823	2	DECAL,CAB SUPPORT	X	X			
53	207380	2	DECAL,GREASE,500HRS,BIN PIVOT	X	X			
54	207351	2	DECAL,BIN SUPPORT	X	X			
55	216679	1	DECAL,IGNITION SWITCH	X	X			

https://truckmanualshub.com/

https://truckmanualshub.com/

SECTION 8: SERVICE KITS

https://truckmanualshub.com/

SERVICE KITS ILLUSTRATIONS NOT AVAILABLE

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
	361624	1	KIT,SERVICE 100HR SMALL ADT	X	X			
	207694	1	ELEMENT,FILTER,10MICRON	X	X			
	222389	1	ELEMEMT,FLTR,HYDRAULIC,5MICRON	X	X			
	226019	1	FILTER,AIR ASSY(AIR CON)	X	X			
	361625	1	KIT,SER 500HR SMALL ADT,WET	X	X			
	DC221578	1	ELEMENT,OIL FILTER OM906LA	X	X			
	220010	1	ELEMENT,FILTER,29MICRON	X	X			
	226019	1	FILTER,AIR ASSY(AIR CON)	X	X			
	361626	1	KIT,SER 500HR SMALL ADT,DRY	X	X			
	DC221578	1	ELEMENT,OIL FILTER OM906LA	X	X			
	226019	1	FILTER,AIR ASSY(AIR CON)	X	X			
	361627	1	KIT,SER 1000HR SMALL ADT,DRY	X	X			
	DC221578	1	ELEMENT,OIL FILTER OM906LA	X	X			
	DC221529	1	GASKET,TAPPET COVER	X	X			
	220725	1	ELEMENT,OUTER,AIR CLEANER	X	X			
	207694	1	ELEMENT,FILTER,10MICRON	X	X			
	DC221899	1	KIT,ELEMENT,FUEL FILTER	X	X			
	222389	1	ELEMEMT,FLTR,HYDRAULIC,5MICRON	X	X			
	220010	1	ELEMENT,FILTER,29MICRON	X	X			
	226019	1	FILTER,AIR ASSY(AIR CON)	X	X			
	361628	1	KIT,SER 1000HR SMALL ADT,WET	X	X			
	DC221578	1	ELEMENT,OIL FILTER OM906LA	X	X			
	DC221529	1	GASKET,TAPPET COVER	X	X			
	220725	1	ELEMENT,OUTER,AIR CLEANER	X	X			
	207694	1	ELEMENT,FILTER,10MICRON	X	X			
	DC221899	1	KIT,ELEMENT,FUEL FILTER	X	X			
	220010	1	ELEMENT,FILTER,29MICRON	X	X			
	226019	1	FILTER,AIR ASSY(AIR CON)	X	X			
	361629	1	KIT,SER 2000HR SMALL ADT,ALL	X	X			
	DC221578	1	ELEMENT,OIL FILTER OM906LA	X	X			
	DC221529	1	GASKET,TAPPET COVER	X	X			
	220725	1	ELEMENT,OUTER,AIR CLEANER	X	X			
	220747	1	ELEMENT,INNER,AIR CLEANER	X	X			
	207694	1	ELEMENT,FILTER,10MICRON	X	X			
	DC221899	1	KIT,ELEMENT,FUEL FILTER	X	X			
	ZF210424	1	KIT,SUCTION FILTER	X	X			
	222389	1	ELEMEMT,FLTR,HYDRAULIC,5MICRON	X	X			
	220010	1	ELEMENT,FILTER,29MICRON	X	X			
	220949	1	FILTER:AIR DRYER	X	X			
	226019	1	FILTER,AIR ASSY(AIR CON)	X	X			

https://truckmanualshub.com/

SERVICE KITS ILLUSTRATIONS NOT AVAILABLE

https://truckmanualshub.com/

SERVICE KITS (CONTINUED)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
	361630	1	KIT,SER 3000HR SMALL ADT,DRY	X	X			
	DC221578	1	ELEMENT,OIL FILTER OM906LA	X	X			
	DC221529	1	GASKET,TAPPET COVER	X	X			
	220725	1	ELEMENT,OUTER,AIR CLEANER	X	X			
	207694	1	ELEMENT,FILTER,10MICRON	X	X			
	DC221899	1	KIT,ELEMENT,FUEL FILTER	X	X			
	222389	1	ELEMEMT,FLTR,HYDRAULIC,5MICRON	X	X			
	220010	1	ELEMENT,FILTER,29MICRON	X	X			
	210497	1	STRAINER,125 MICRON,350L/MIN	X	X			
	226019	1	FILTER,AIR ASSY(AIR CON)	X	X			
	361631	1	KIT,SER 3000HR SMALL ADT,WET	X	X			
	DC221578	1	ELEMENT,OIL FILTER OM906LA	X	X			
	DC221529	1	GASKET,TAPPET COVER	X	X			
	220725	1	ELEMENT,OUTER,AIR CLEANER	X	X			
	207694	1	ELEMENT,FILTER,10MICRON	X	X			
	DC221899	1	KIT,ELEMENT,FUEL FILTER	X	X			
	220010	1	ELEMENT,FILTER,29MICRON	X	X			
	210497	1	STRAINER,125 MICRON,350L/MIN	X	X			
	226019	1	FILTER,AIR ASSY(AIR CON)	X	X			
	361632	1	KIT,SER 4000HR SMALL ADT,ALL	X	X			
	DC221578	1	ELEMENT,OIL FILTER OM906LA	X	X			
	DC221529	1	GASKET,TAPPET COVER	X	X			
	DC221528	1	BELT,RIBBED OM906LA	X	X			
	220725	1	ELEMENT,OUTER,AIR CLEANER	X	X			
	220747	1	ELEMENT,INNER,AIR CLEANER	X	X			
	207694	1	ELEMENT,FILTER,10MICRON	X	X			
	DC221899	1	KIT,ELEMENT,FUEL FILTER	X	X			
	ZF210424	1	KIT,SUCTION FILTER	X	X			
	222389	1	ELEMEMT,FLTR,HYDRAULIC,5MICRON	X	X			
	220010	1	ELEMENT,FILTER,29MICRON	X	X			
	220949	1	FILTER:AIR DRYER	X	X			
	226831	5	DISC,FILTER 16MM	X	X			
	226019	1	FILTER,AIR ASSY(AIR CON)	X	X			
	361652	1	KIT,SERVICE 6000HR B25D		X			
	361653	1	KIT,SERVICE 6000HR B30D	X				
	DC221578	1	ELEMENT,OIL FILTER OM906LA	X	X			
	DC221529	1	GASKET,TAPPET COVER	X	X			
	220725	1	ELEMENT,OUTER,AIR CLEANER	X	X			
	220747	1	ELEMENT,INNER,AIR CLEANER	X	X			
	206616	1	ELEMENT,FILTER,10MICRON	X	X			
	DC221899	1	KIT,ELEMENT,FUEL FILTER	X	X			
	ZF210424	1	KIT,SUCTION FILTER	X	X			
	222389	1	ELEMENT,FLTR,HYDRAULIC,5MICRON	X	X			
	220010	1	ELEMENT,FILTER,29MICRON GUD	X	X			
	220949	1	FILTER:AIR DRYER	X	X			
	226019	1	FILTER,AIR ASSY(AIR CON)	X	X			
	206765	4	CROSS & ROLLER,LUBE-FOR-LIFE	X	X			
	207990	6	CROSS & ROLLER,LUBE-FOR-LIFE		X			
	207990	4	CROSS & ROLLER,LUBE-FOR-LIFE	X				
	206050	2	CROSS & ROLLER,7C LOW MAINT	X				

https://truckmanualshub.com/


https://truckmanualshub.com/

SECTION 9:
RECOMMENDED LUBRICANTS, ADHESIVES AND PAINTS

https://truckmanualshub.com/

As per RECOMMENDED SERVICE GUIDE Decal (Bell part number 207433).

Kindly contact your nearest BELL EQUIPMENT operation for more information.



https://truckmanualshub.com/

RECOMMENDED ADHESIVES

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
	280016		LOCTITE: 2 FORM-A-GASKET	X	X			
	280039		LOCTITE: 277 THREADLOCKER,RED HS	X	X			
	280085		LOCTITE:243 THREADLOCKER,BLUE	X	X			
	280089		LOCTITE: 272 THREADLOCKER,RED	X	X			
	280107		LOCTITE: 518 ANAEROBIC GASKET	X	X			
	280111		LOCTITE: 599 GASKET,(HIGH TEMP)	X	X			
	280450		LOCTITE: 767 ANTI-SEIZE	X	X			
			SIKA PRIMER 210 T CLEANING	X	X			(USED ON D-SERIES CABS)
			SIKA FLEX ACTIVATOR	X	X			(USED ON D-SERIES CABS)
			SIKA FLEX 225 FC USED FOR WINDOW ADHESION	X	X			(USED ON D-SERIES CABS)

https://truckmanualshub.com/

RECOMMENDED PAINTS AND PROCEDURES

1. Washing and Degreasing

Use AQUA-SOLV DEGREASER (GR1) or equivalent *water*-based degreaser.

2. Priming

Prime surface with AW255 EPIWASH STRONTIUM CHROMATE PRIMER (Bell Part Number 280098), at a recommended D.F.T (Dry Film Thickness) of 25-35 microns.

3. Top Coat

Coat with two (2) coats of PLASCOTHANE 4:1 INDUSTRIAL POLY-URITHANE ACRYLIC (Bell Part number 280221) at a recommended D.F.T of 30-40 microns each.

⚠ CAUTION


Do not use Lacquer Thinners

https://truckmanualshub.com/

SECTION 10: SPECIAL TOOLS

https://truckmanualshub.com/

ENGINE - OM906LA SERVICE TOOLS, KIT 262126




https://truckmanualshub.com/

ENGINE - OM906LA SERVICE TOOLS, KIT 262126

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	281322	1	TOOL,ENG,DC,DIAL GAUGE	X	X			
2	281340	1	TOOL,ENG,DC,HOLDER,DIAL GAUGE	X	X			
3	DC280155	1	TOOL,COMPRESSION-RECORDER MERC	X	X			
4	281394	1	TOOL,ENG,DC,DIAGRAM SHEETS	X	X			
5	281383	1	TOOL,ENG,DC,CONNECTOR,INJECTOR	X	X			
6	281390	1	TOOL,ENG,DC,CRANKING DEVICE	X	X			
7	DC280127	1	TOOL,TUBE WRENCH INJ.LINES	X	X			
8	DC280018	1	BUSH,TAPER F'SEAL FITTING	X	X			
9	281328	1	TOOL,ENG,DC,HOSE,HIGH PRESSURE	X	X			
10	281365	1	TOOL,ENG,DC,ADAPTION PARTS	X	X			
11	281368	1	TOOL,ENG,DC,TESTER	X	X			
12	DC280046	1	TOOL,DELIVERY PUMP TESTER	X	X			
13	281329	1	TOOL,ENG,DC,TESTER	X	X			
14	DC280178	1	TESTER,CHARGE AIR PRESSURE	X	X			
15	281391	1	TOOL,ENG,DC,TEST FLANGE	X	X			
16	DC280171	1	PULLER	X	X			
17	DC280162	1	TESTER,COOLING SYSTEM	X	X			
18	281300	1	TOOL,ENG,DC,TORX BIT SET	X	X			

https://truckmanualshub.com/


ENGINE - OM906LA SERVICE TOOLS, KIT 262126



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
19	281330	1	TOOL,ENG,DC,PIN,MAGNETIC	X	X			
20	DC280096	1	TOOL,GAUGE CYL.PROTRUSION	X	X			
21	DC280134	1	TOOL,PLIERS PISTON RING	X	X			
22	281349	1	TOOL,ENG,DC,WRENCH SOCKET	X	X			
23	DC280180	1	HANDLE,SPRING RETAINER	X	X			
24	281384	1	TOOL,ENG,DC,LIFTING DEVICE	X	X			
25	281377	1	TOOL,ENG,DC,SCREWDRIVER BIT	X	X			
26	281379	1	TOOL,ENG,DC,PULLER	X	X			
27	281381	1	TOOL,ENG,DC,SCREWDRIVER BIT	X	X			
28	281386	1	TOOL,ENG,DC,DRIFT	X	X			
29	281387	1	TOOL,ENG,DC,CENTERING DRIFT	X	X			
30	281388	1	TOOL,ENG,DC,DRIFT	X	X			
31	281336	1	TOOL,ENG,DC,SLEEVE	X	X			
32	DC280033	1	TOOL,IMPACT PULLER INJ/NOZZLES	X	X			
33	281380	1	TOOL,ENG,DC,THREADED INSERT	X	X			
34	DC280167	1	OIL CONTAINER,PRIMING LUB.SYST	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ENGINE - OM906LA REPAIR TOOLS, KIT 262127

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	281376	1	TOOL,ENG,DC,SLOTTED NUT WRENCH	X	X			
2	281398	1	TOOL,ENG,DC,DRIFT	X	X			
3	DC280160	1	TESTER,HARDNESS "SKLEROGRAPH"	X	X			
4	DC280057	1	TOOL,INTERNAL PULLER	X	X			
5	DC280056	1	TOOL,BRACING	X	X			
6	DC280075	1	TOOL,PISTON RING PLIERS	X	X			
7	DC280071	1	TOOL,PISTON RING CLAMPING	X	X			
8	281366	1	TOOL,PISTON RING CLAMPING	X	X			
9	281398	1	TOOL,ENG,DC,DRIFT	X	X			
10	DC280062	1	TOOL,REAMER (D=8,99)	X	X			
11	DC280064	1	TOOL,VALVE GUIDE HOLE	X	X			
12	281306	1	TOOL,ENG,DC,REAMER	X	X			

https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
13	281325	1	TOOL,ENG,DC,DRIFT	X	X			
14	281326	1	TOOL,ENG,DC,STEPPED,DRIFT	X	X			
15	DC280147	1	TOOL,VALVE-LIFTER MERC	X	X			
16	281378	1	TOOL,ENG,DC,ADITIONAL PIECE	X	X			
17	281382	1	TOOL,ENG,DC,INSERTION DRIFT	X	X			
18	281385	1	TOOL,ENG,DC,GUIDE SLEEVE	X	X			
19	281392	1	TOOL,ENG,DC,SLEEVE	X	X			
20	281389	1	TOOL,ENG,DC,BLOCKING DEVICE	X	X			
21	281318	1	TOOL,ENG,DC,PULLER	X	X			
22	281333	1	TOOL,ENG,DC,THRUST PIECE	X	X			
23	281337	1	TOOL,ENG,DC,PUNCH	X	X			

https://truckmanualshub.com/

ENGINE - OM906LA REPAIR TOOLS, KIT 262128




https://truckmanualshub.com/

ENGINE - OM906LA REPAIR TOOLS, KIT 262128

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	281400	1	TOOL,ENG,DC,CASE,SPECIAL TOOLS	X	X			
2	281401	1	TOOL,ENG,DC,ADAPTER SET	X	X			
3	281335	1	TOOL,ENG,DC,BOX,SUPERCOOLING	X	X			
4	281309	1	TOOL,ENG,DC,PULLER,28-37MM	X	X			
5	281310	1	TOOL,ENG,DC,INTERNAL EXTRACTOR	X	X			
6	281312	1	TOOL,ENG,DC,COUNTER SUPPORT	X	X			
7	DC280170	1	VALVE,SEATRING TURNING CUTTER	X	X			
8	281395	1	TOOL,ENG,DC,VALVE SEAT CUTTER	X	X			
9	281396	1	TOOL,ENG,DC,VALVE SEAT CUTTER	X	X			

https://truckmanualshub.com/



https://truckmanualshub.com/


ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	281000	1	FIXTURE,LOCKING	X	X			
2	281001	1	FIXTURE,TIGHTENING	X	X			
3	281002	1	SHIELD,PUNCH	X	X			
4	281003	1	PLUG,HEATING	X	X			
5	281004	1	SEAL,PUNCH	X	X			
6	281005	1	PRESS,TOOL BEARING	X	X			
7	281006	1	PIN,INSERTING TOOL	X	X			
8	281007	1	SPEC.2 PIN SPANNER	X	X			
9	281008	1	TOOL,PRESS	X	X			
10	281009	1	PLT,CLAMPING	X	X			
11	281013	1	PLUG,HEATING	X	X			
12	281016	1	GUIDE PIN,M12	X	X			
13	281017	1	GUIDE PIN,M10	X	X			
14	281018	1	FIXTURE,PRESS	X	X			
15	281019	1	TOOL,PRESS	X	X			
16	281020	1	FIXTURE,SUPPORT	X	X			
17	281021	1	FIXTURE,PRESS	X	X			
18	281024	1	SUPPORT FIXTURE	X	X			


https://truckmanualshub.com/












https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
19	281008	1	TOOL,PRESS	X	X			
20	281026	1	PRESS FIXTURE	X	X			
21	281027	1	PROTECTION FIXTURE	X	X			
22	280532	1	TOOL,7C/8,5C POINTER SET	X	X			
23	280533	1	PULLER,BEARING,T/CASE 9100	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	281675	1	HOOK,LIFTING	X	X			
2	281676	1	PULLER	X	X			
3	281677	1	PULLER	X	X			
4	281678	1	PULLER,TWO LEG	X	X			
5	281679	1	TOOL,BASIC	X	X			
6	281680	1	PULLER	X	X			
7	281681	1	PLT,EXTRACT	X	X			
8	281682	1	DEVICE,LIFTING	X	X			
9	281683	1	DRIFTER	X	X			
10	281684	1	BLOWER,HOT AIR	X	X			
11	281685	1	BKT,ADAPTER LHS	X	X			
12	281686	1	BKT,ADAPTER RHS	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
13	281687	1	DRIFTER	X	X			
14	281688	1	EYE,LIFTING	X	X			
15	281689	1	INSERT,GRIPPING	X	X			
16	281690	1	EXTRACTOR	X	X			
17	281691	1	DEVICE,ADJUSTING	X	X			
18	281692	1	FIXTURE,HOLDING	X	X			
19	281693	1	DRIFTER	X	X			
20	281694	1	GUIDE,SCREW	X	X			
21	281695	1	DRIFTER	X	X			
22	281696	1	DEVICE,LIFTING	X	X			
23	281697	1	MOUNTING	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
24	281698	1	MOUNTING	X	X			
25	281699	1	PRESSURE PIECE	X	X			
26	281700	1	PRESSURE PIECE	X	X			
27	281701	1	DRIFT ASSY	X	X			
28	281702	1	TOOL	X	X			
29	281703	1	MOUNTING	X	X			
30	281704	1	BRACKET	X	X			
31	281705	1	DEVICE,CLAMPING	X	X			
32	281706	1	TOOL,TEST	X	X			
32	281707	1	KIT,PRESSURE TESTER	X	X			
33	281708	1	SUPPORT	X	X			
34	281709	1	DEVICE,HOLDING	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
35	281709	1	DEVICE,HOLDING	X	X			
36	281710	1	DEVICE,LIFTING	X	X			
37	281711	1	INSERT,HEXAGON	X	X			
38	281712	1	EXTRACTOR	X	X			
39	281713	1	STAND	X	X			
40	281714	1	PUNCH	X	X			
41	281715	1	PUNCH	X	X			
42	281716	1	BRACKET	X	X			
43	281717	1	PIN,CONTROL THREADED	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	280149	1	TOOL,BEARING RESISTANCE	X	X			
2	280010	1	SPANNER,BEARING ADJ-HUB NUT	X	X			
3	280272	1	TOOL,CASSETTE SEAL	X	X			


https://truckmanualshub.com/




https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	281268	1	SHAFT,MEASURING	X	X			
2	281269	1	PISTON,MEASURING	X	X			
3	281267	1	SLEEVE,GRAB	X	X			
4	281140	1	BASIC SET	X	X			
5	281266	1	FIXTURE,ADJUSTABLE	X	X			
6	281272	1	DRIVER,SEAL	X	X			
7	281271	1	SLEEVE,GRAB	X	X			
8	281140	1	BASIC SET	X	X			
9	281270	1	SLEEVE,GRAB	X	X			
10	281144	1	INDICATOR,DIAL	X	X			
11	281143	1	STAND,MAGNETIC	X	X			
12	281218	1	PLIERS,LIFTING	X	X			
13	281234	1	SHAFT,MEASURING	X	X			
14	281236	1	SHIMS,120	X	X			

https://truckmanualshub.com/






https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	121463	1	CONNECTOR,SUSPSTRUT	X	X			
2	280257	1	TOOL KIT,CHARGING NITROGEN	X	X			


https://truckmanualshub.com/



https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	201873	1	POINT,TEST,HYD	X	X			
2	206082	1	GAUGE,QUAD,PRESS	X	X			
3	240498	1	HOSE ASSY,TEST,MINIMESS,2.5M	X	X			
4	240499	1	HOSE ASSY,TEST,MINIMESS,1.0M	X	X			
5	280261	1	TOOL,ADJUSTABLE C SPANNER	X	X			
6	280470	1	WRENCH,NECKBUSH NUT	X	X			
7	120926	1	FTG,HOSE ADPT,1/4"BSP,TYRE TOW	X	X			

https://truckmanualshub.com/






https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	280082	1	CHAIN WRENCH-ADT OSC LOCK NUT	X	X			
2	280547	1	NUT,TORQUE,MULTIPLIER OSCILL	X	X			

https://truckmanualshub.com/



1




2

TD0004663

https://truckmanualshub.com/

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	216281	1	HARNESS,DIAGNOSTIC,MK4	X	X			ITEM WAS 207663
2	280479	1	MERC,MINIDIAG2	X	X			

https://truckmanualshub.com/



https://truckmanualshub.com/

TYRE INFLATION KIT - (OPTIONAL)

ITEM	PART No.	QTY	DESCRIPTION	B30D	B25D		Vin Series From: To:	REMARKS
1	262867	1	KIT,TYRE INFLATION-ALL D#	X	X			
2	280071	1	GUAGE,INFLATOR,COMBI	X	X			
3	120053	2	ADAPTOR,MALE NPTF,PUSHLOCK	X	X			
4	200033	2	CLAMP,HOSE	X	X			
5	120926	1	FTG,HOSE ADPT,1/4" BSP	X	X			
6	130020	10m	HOSE,PUSHLOCK 1/4"	X	X			

https://truckmanualshub.com/

https://truckmanualshub.com/

SECTION 11: NUMERICAL INDEX

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
100005	SCREW,HEXHD	**22**	4-43	100063	WASHER,FLAT	**33**	7-53
100005	SCREW,HEXHD	**28**	3-159	100063	WASHER,FLAT	**34**	7-69
100005	SCREW,HEXHD	**32**	3-123	100063	WASHER,FLAT	**37**	7-57
100010	WASHER	**3**	3-95	100063	WASHER,FLAT	**66**	6-7
100010	WASHER,FLAT	**41**	7-105	100063	WASHER,HARDENED	**94**	7-15
100010	WASHER,FLAT	**54**	3-175	100064	WASHER,FLAT	**10**	6-49
100010	WASHER,FLAT	**55**	3-141	100064	WASHER,FLAT	**26**	5-9
100012	WASHER,FLAT	**36**	4-15	100064	WASHER,FLAT	**36**	7-57
100021	CAPSRW,SOCHD	**66**	4-49	100064	WASHER,FLAT	**40**	7-105
100037	NUT	**2**	3-95	100065	WASHER,SPRING	**19**	7-45
100039	SCREW,HEX HEAD	**5**	3-185	100065	WASHER,SPRING	**65**	6-7
100054	WASHER,SPRING	**22**	7-45	100070	SPLITPIN	**34**	4-15
100054	WASHER,SPRING	**69**	6-7	100079	SCREW,HEXHD	**7**	6-29
100059	WASHER	**14**	3-3	100080	SCREW,HEXHD	**15**	3-79
100061	WASHER,FLAT	**9**	5-5	100080	BOLT	**18**	7-45
100061	WASHER,FLAT	**11**	6-49	100080	SCREW,HEXHD	**19**	2A-75
100061	WASHER,FLAT	**16**	3-79	100080	SCREW,HEXHD	**19**	2B-69
100061	WASHER,FLAT	**20**	2A-75	100080	SCREW,HEXHD	**33**	7-69
100061	WASHER,FLAT	**20**	2B-69	100080	SCREW,HEXHD	**39**	7-49
100061	WASHER,FLAT	**21**	4-43	100080	SCREW,HEXHD	**56**	2A-81
100061	WASHER,FLAT	**21**	7-45	100080	SCREW,HEXHD	**57**	2B-75
100061	WASHER,FLAT	**27**	3-159	100080	SCREW,HEXHD	**64**	6-5
100061	WASHER,FLAT	**31**	3-123	100080	SCREW,HEXHD	**64**	6-7
100061	WASHER,FLAT	**33**	7-67	100081	SCREW,HEXHD	**8**	5-5
100061	WASHER,FLAT	**35**	4-15	100081	SCREW,HEXHD	**9**	6-49
100061	WASHER,FLAT	**35**	7-53	100081	SCREW,HEXHD	**19**	4-43
100061	WASHER,FLAT	**36**	7-69	100081	SCREW,HEXHD	**32**	7-67
100061	WASHER,FLAT	**39**	7-55	100081	SCREW,HEXHD	**33**	4-15
100061	WASHER,FLAT	**39**	7-57	100081	SCREW,HEXHD	**38**	7-49
100061	WASHER,FLAT	**40**	7-49	100081	SCREW,HEXHD	**55**	2A-81
100061	WASHER,FLAT	**50**	4-51	100081	SCREW,HEXHD	**56**	2B-75
100061	WASHER,FLAT	**57**	2A-81	100081	SCREW,HEXHD	**93**	7-9
100061	WASHER,FLAT	**57**	2A-83	100081	SCREW,HEXHD	**93**	7-15
100061	WASHER,FLAT	**59**	2B-75	100082	SCREW	**6**	6-37
100061	WASHER,FLAT	**68**	6-5	100082	SCREW,HEXHD	**36**	7-93
100061	WASHER,FLAT	**68**	6-7	100083	SCREW,HEXHD	**9**	6-13
100061	WASHER,FLAT	**96**	7-9	100083	SCREW,HEXHD	**13**	3-77
100061	WASHER,FLAT	**96**	7-13	100083	SCREW,HEXHD	**14**	2A-71
100062	WASHER,FLAT	**11**	6-13	100083	SCREW,HEXHD	**14**	2B-65
100062	WASHER,FLAT	**14**	3-77	100083	SCREW,HEXHD	**21**	2A-67
100062	WASHER,FLAT	**15**	2A-71	100083	SCREW,HEXHD	**21**	2B-61
100062	WASHER,FLAT	**15**	2B-65	100083	SCREW,HEXHD	**25**	7-61
100062	WASHER,FLAT	**20**	4-43	100083	SCREW,HEXHD	**26**	6-33
100062	WASHER,FLAT	**20**	7-45	100083	SCREW,HEXHD	**31**	7-67
100062	WASHER,FLAT	**26**	7-61	100083	SCREW,HEXHD	**37**	7-49
100062	WASHER,FLAT	**27**	6-33	100083	SCREW, HEXHEAD	**43**	3-93
100062	WASHER,FLAT	**32**	7-51	100083	SCREW,HEXHD	**54**	2A-83
100062	WASHER,FLAT	**34**	7-53	100083	SCREW,HEXHD	**55**	2B-77
100062	WASHER,FLAT	**35**	7-69	100083	SCREW, HEXHD	**76**	7-31
100062	WASHER,FLAT	**37**	7-93	100084	BOLT,HEXHD	**36**	7-49
100062	WASHER,FLAT	**38**	7-55	100084	BOLT,HEXHD	**47**	4-3
100062	WASHER,FLAT	**38**	7-57	100084	BOLT,HEXHD	**47**	4-5
100062	WASHER,FLAT	**48**	4-5	100085	SCREW,HEXHD	**10**	6-41
100062	WASHER,FLAT	**58**	2B-75	100085	SCREW,HEXHD	**13**	2A-85
100062	WASHER,FLAT	**67**	6-5	100085	SCREW,HEXHD	**20**	2B-79
100062	WASHER, FLAT	**77**	7-31	100085	SCREW,HEXHD	**25**	6-43
100062	WASHER,FLAT	**95**	7-15	100085	SCREW,HEXHD	**29**	7-41
100062	WASHER,FLAT	**95**	7-21	100085	SCREW,HEXHD	**35**	7-93
100063	WASHER,FLAT	**8**	6-29	100085	SCREW,HEXHD	**36**	3-155
100063	WASHER,FLAT	**10**	6-13	100085	SCREW,HEXHD	**36**	3-179
100063	WASHER,FLAT	**14**	6-27	100085	SCREW,HEXHD	**38**	3-119
100063	WASHER,FLAT	**26**	6-43	100085	SCREW,HEXHD	**38**	3-157

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
100085	SCREW,HEXHD	**39**	7-105	100123	CAPSCREW	**15**	7-65
100085	SCREW,HEXHD	**42**	3-121	100123	CAPSCREW,SOCHD	**18**	7-89
100085	SCREW,HEXHD	**63**	6-5	100123	CAPSCREW,SOCHD	**72**	3-85
100086	SCREW,HEXHD	**7**	6-21	100123	CAPSCREW,SOCHD	**72**	3-89
100086	SCREW,HEXHD	**12**	2A-85	100124	SCREW,HEXHD	**16**	3-3
100086	SCREW,HEXHD	**19**	2B-79	100124	SCREW,HEXHD	**18**	3-5
100086	SCREW,HEXHD	**30**	7-67	100125	SCREW,HEXHD	**88**	7-7
100086	SCREW,HEXHD	**35**	3-155	100128	SCREW,HEXHD	**33**	7-93
100086	SCREW,HEXHD	**35**	3-179	100128	SCREW,HEXHD	**87**	7-11
100086	SCREW,HEXHD	**37**	3-119	100129	BOLT,HEX HD	**6**	3-97
100086	SCREW,HEXHD	**46**	4-3	100129	BOLT,HEX HD	**6**	3-99
100086	SCREW, HEXHD	**92**	7-9	100129	BOLT,HEX HD	**16**	3-97
100089	SCREW,HEXHD	**13**	2A-71	100129	BOLT,HEX HD	**16**	3-99
100089	SCREW,HEXHD	**13**	2B-65	100129	BOLT,HEX HD	**19**	3-97
100089	SCREW,HEXHD	**17**	7-77	100129	BOLT,HEX HD	**19**	3-99
100089	SCREW,HEXHD	**18**	2B-79	100141	BOLT,HEXHD	**32**	4-15
100089	SCREW,HEXHD	**19**	7-89	100144	SCREW,HEXHD	**38**	7-97
100089	SCREW,HEXHD	**21**	7-63	100144	SCREW,HEXHD	**38**	7-99
100089	SCREW,HEXHD	**21**	7-91	100144	SCREW,HEXHD	**63**	7-85
100089	SCREW,HEXHD	**35**	7-49	100145	BOLT,HEXHD	**36**	7-105
100089	SCREW,HEXHD	**38**	7-105	100146	SCREW,HEXHD	**28**	7-67
100089	SCREW,HEXHD	**49**	4-51	100146	SCREW,HEXHD	**29**	7-51
100089	SCREW,HEXHD	**65**	7-85	100146	SCREW,HEXHD	**35**	7-105
100089	SCREW,HEXHD	**68**	3-85	100147	WASHER,FLAT	**18**	7-35
100089	SCREW,HEXHD	**80**	4-21	100147	WASHER,FLAT	**34**	3-117
100089	SCREW,HEXHD	**80**	4-33	100148	WASHER,FLAT	**3**	7-75
100089	SCREW,HEXHD	**91**	7-13	100148	WASHER,FLAT	**6**	7-101
100090	SCREW,HEXHD	**18**	7-41	100148	WASHER,FLAT	**20**	7-91
100090	SCREW,HEXHD	**20**	2A-3	100148	WASHER,FLAT	**25**	3-159
100090	SCREW,HEXHD	**20**	2A-5	100148	WASHER,FLAT	**25**	5-9
100090	SCREW,HEXHD	**20**	2B-3	100148	WASHER,FLAT	**29**	3-123
100090	SCREW,HEXHD	**29**	7-67	100148	WASHER,FLAT	**34**	3-155
100090	SCREW,HEXHD	**31**	7-51	100148	WASHER,FLAT	**34**	3-179
100090	SCREW,HEXHD	**75**	7-39	100148	WASHER,FLAT	**34**	7-105
100090	SCREW,HEXHD	**90**	7-7	100148	WASHER,FLAT	**36**	3-119
100090	SCREW,HEXHD	**90**	7-11	100148	WASHER,FLAT	**36**	3-157
100090	SCREW,HEXHD	**90**	7-13	100148	WASHER,FLAT	**39**	3-145
100091	SCREW,HEXHD	**20**	2A-67	100148	WASHER,FLAT	**40**	3-121
100091	SCREW,HEXHD	**20**	2B-61	100149	SCREW,HEXHD	**12**	3-187
100091	SCREW,HEXHD	**30**	7-51	100150	BOLT,HEXHD	**43**	3-169
100091	SCREW,HEXHD	**34**	7-93	100150	BOLT,HEXHD	**44**	3-135
100091	SCREW,HEXHD	**45**	4-3	100150	BOLT,HEXHD	**52**	3-175
100091	SCREW,HEXHD	**64**	4-49	100150	BOLT,HEXHD	**53**	3-141
100092	BOLT,HEXHD	**89**	7-21	100152	SPLITPIN	**16**	4-17
100111	SCREW,HEXHD	**2**	7-75	100158	BOLT,HEXHD	**33**	7-105
100111	SCREW,HEXHD	**17**	7-95	100158	BOLT	**62**	7-85
100111	SCREW,HEXHD	**26**	3-159	100165	BOLT,HEXHD	**14**	3-79
100111	SCREW,HEXHD	**30**	3-123	100178	SCREW,HEXHD	**11**	2A-85
100111	SCREW,HEXHD	**32**	3-155	100178	SCREW	**17**	2B-79
100111	SCREW,HEXHD	**32**	3-179	100178	SCREW,HEXHD	**79**	4-21
100111	SCREW,HEXHD	**33**	3-119	100183	GRUBSCREW	**14**	3-137
100111	SCREW,HEXHD	**37**	3-145	100183	GRUBSCREW	**14**	3-143
100111	SCREW,HEXHD	**37**	3-157	100183	GRUBSCREW	**14**	3-171
100111	SCREW,HEXHD	**41**	3-121	100183	GRUBSCREW	**14**	3-177
100114	SCREW,HEXHD	**15**	3-3	100189	SCREW,HEXHD	**62**	6-7
100114	SCREW,HEXHD	**37**	7-105	100193	SCREW,HEXHD	**17**	7-45
100115	SCREW,HEXHD	**44**	3-169	100196	BOLT,HEXHD	**61**	6-5
100115	SCREW,HEXHD,LONG	**45**	3-135	100196	BOLT,HEXHD	**61**	7-85
100119	BOLT,HEXHD	**16**	7-95	100197	CAPSCREW,SOCHD	**8**	7-87
100119	BOLT,HEXHD	**23**	7-59	100197	CAPSCREW,SOCHD	**38**	3-145
100119	BOLT,HEXHD	**53**	3-175	100197	SCREW,SUCTION PIPE TO OIL PUMP	**50**	2A-53
100119	BOLT,HEXHD	**54**	3-141	100197	SCREW,SUCTION PIPE TO OIL PUMP	**50**	2B-47

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
100198	SCREW,HEXHD	12	3-77	100225	CAPSCREW	18	7-91
100198	SCREW,HEXHD	16	7-45	100225	CAPSCREW,SOCHD	77	4-21
100198	SCREW,HEXHD	18	2A-75	100228	CAPSCREW	15	3-187
100198	SCREW,HEXHD	18	2B-69	100238	SCREW,HEXHD	19	2A-3
100198	SCREW,HEXHD	26	7-41	100238	SCREW,HEXHD	19	2A-5
100198	SCREW,HEXHD	28	7-51	100238	SCREW,HEXHD	19	2B-3
100198	SCREW,HEXHD	32	7-69	100246	SCREW,HEXHD	28	3-101
100198	SCREW,HEXHD	33	6-47	100246	SCREW,HEXHD	28	3-111
100198	SCREW,HEXHD	34	7-49	100256	CAPSCREW,SOCHD	5	4-45
100198	SCREW,HEXHD	37	7-97	100258	SCREW,HEXHD	35	7-97
100198	SCREW,HEXHD	37	7-99	100258	SCREW,HEXHD	35	7-99
100199	BOLT,HEXHD	19	2A-67	100264	CAPSCREW,SOCHD	27	3-101
100199	BOLT,HEXHD	19	2B-61	100264	CAPSCREW,SOCHD	27	3-111
100200	BOLT,HEXHD	11	3-77	100268	STUD,WHEEL,DRIVE AXLE	31	3-187
100200	BOLT,HEXHD	31	4-15	100273	SCREW,HEXHD	29	7-69
100203	BOLT,HEXHD	32	6-47	100281	NUT,HEXAGON	85	7-15
100208	CAPSCREW,SOCHD	25	6-33	100283	NUT,HEXAGON	27	7-41
100208	CAPSCREW,SOCHD	35	3-119	100283	NUT,HEXAGON	60	6-7
100209	SCREW,HEXHD	28	7-83	100288	NUT,HEXAGON	30	7-53
100209	SCREW,HEXHD	69	3-85	100288	NUT,HEXAGON	31	7-93
100209	SCREW,HEXHD	69	3-87	100288	NUT,HEXAGON	34	7-55
100210	SCREW,HEXHD	16	2B-79	100290	NUT,CASTLE	5	4-17
100210	BOLT	17	3-5	100293	NUT,HEXAGON	22	7-61
100210	SCREW,HEXHD	27	2A-69	100309	NUT,NYLOC	8	6-31
100210	SCREW,HEXHD	27	2B-63	100309	NUT,NYLOC	59	6-5
100210	SCREW,HEXHD	32	7-93	100310	NUT,NYLOC	18	4-43
100210	BOLT	86	7-11	100310	NUT,NYLOC	26	3-101
100211	BOLT	7	7-101	100310	NUT,NYLOC	26	3-111
100211	SCREW,HEXHD	14	3-187	100310	NUT,NYLOC	27	7-67
100211	SCREW,HEXHD	18	2A-67	100310	NUT,NYLOC	28	7-69
100211	SCREW,HEXHD	18	2B-61	100310	NUT,NYLOC	29	7-53
100211	WASHER,HARDENED	29	3-101	100310	NUT,NYLOC	30	4-15
100211	SCREW,HEXHD	29	3-111	100310	NUT,NYLOC	31	3-155
100211	SCREW,HEXHD	33	3-155	100310	NUT,NYLOC	31	3-179
100211	SCREW,HEXHD	33	3-179	100310	NUT,NYLOC	32	3-119
100211	SCREW,HEXHD	34	3-119	100310	NUT,NYLOC	33	7-49
100211	SCREW,HEXHD	35	3-157	100310	NUT,NYLOC	33	7-55
100211	SCREW,HEXHD	39	3-121	100310	NUT,NYLOC	33	7-57
100211	SCREW,HEXHD	42	3-169	100310	NUT,NYLOC	34	3-157
100211	SCREW,HEXHD	43	3-135	100310	NUT,NYLOC	36	3-145
100211	SCREW,HEXHD	51	3-175	100310	NUT,NYLOC	38	3-121
100211	SCREW,HEXHD	52	3-141	100310	NUT,NYLOC	48	4-51
100212	SCREW,HEXHD	3	3-81	100310	NUT,NYLOC	53	2A-81
100212	BOLT	14	7-65	100310	NUT,NYLOC	54	2B-75
100212	SCREW,HEXHD	14	7-71	100310	NUT,NYLOC	58	6-7
100212	SCREW,HEXHD	19	7-91	100310	NUT,NYLOC	84	7-15
100212	SCREW,HEXHD	26	2A-69	100312	NUT,NYLOC	4	6-25
100212	SCREW,HEXHD	26	2B-63	100312	NUT,NYLOC	5	6-37
100212	SCREW,HEXHD	27	7-51	100312	NUT,NYLOC	7	4-35
100212	SCREW,HEXHD	31	7-69	100312	NUT,NYLOC	7	4-37
100212	SCREW,HEXHD	36	7-97	100312	NUT,NYLOC	7	5-5
100212	SCREW,HEXHD	36	7-99	100312	NUT,NYLOC	8	4-41
100212	SCREW,HEXHD	50	3-175	100312	NUT,NYLOC	9	3-77
100212	SCREW,HEXHD	51	3-141	100312	NUT,NYLOC	9	4-39
100212	SCREW,HEXHD	78	4-33	100312	NUT,NYLOC	17	4-43
100213	CAPSCREW,SOCHD	73	3-85	100312	NUT,NYLOC	17	2A-75
100213	SCREW,HEXHD	73	3-87	100312	NUT,NYLOC	17	2B-69
100213	CAPSCREW,SOCHD	73	3-89	100312	NUT,NYLOC	21	7-61
100220	CAPSCREW,SOCHD	31	7-53	100312	NUT,NYLOC	24	6-33
100220	CAPSCREW,SOCHD	35	7-57	100312	NUT,NYLOC	24	6-43
100225	CAPSCREW,SOCHD	10	3-77	100312	NUT,NYLOC	25	2A-69
100225	CAPSCREW,SOCHD	17	7-89	100312	NUT,NYLOC	25	2B-63

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
100312	NUT,NYLOC	**26**	7-51	100341	NUT,CASTLE	**25**	4-53
100312	NUT,NYLOC	**26**	7-67	100341	NUT,CASTLE	**30**	7-105
100312	NUT,NYLOC	**27**	7-69	100351	NUT,TAPERED	**10**	3-189
100312	NUT,NYLOC	**28**	7-53	100351	NUT,TAPERED	**10**	3-191
100312	NUT,NYLOC	**30**	7-93	100351	NUT,TAPERED	**32**	3-187
100312	NUT,NYLOC	**31**	6-47	100356	WASHER,COPPER	**29**	4-15
100312	NUT,NYLOC	**32**	7-49	100358	WASHER,FLAT	**73**	7-29
100312	NUT,NYLOC	**32**	7-55	100359	WASHER,FENDER	**80**	7-13
100312	NUT,NYLOC	**32**	7-57	100364	SCREW,HEXHD	**8**	6-49
100312	NUT, NYLOC	**44**	3-93	100364	SCREW,HEXHD	**19**	7-63
100312	NUT,NYLOC	**44**	4-3	100364	SCREW,HEXHD	**23**	5-9
100312	NUT,NYLOC	**44**	4-5	100364	SCREW,HEXHD	**24**	7-59
100312	NUT,NYLOC	**52**	2A-81	100364	SCREW,HEXHD	**30**	7-49
100312	NUT,NYLOC	**52**	2A-83	100364	SCREW,HEXHD	**33**	7-97
100312	NUT,NYLOC	**53**	2B-75	100364	SCREW,HEXHD	**33**	7-99
100312	NUT,NYLOC	**53**	2B-77	100364	SCREW,HEXHD	**50**	2A-81
100312	NUT,NYLOC	**76**	4-33	100364	SCREW,HEXHD	**51**	2B-75
100312	NUT,NYLOC	**83**	7-21	100364	SCREW,HEXHD	**59**	4-49
100314	NUT,NYLOC	**6**	6-21	100364	SCREW,HEXHD	**59**	7-85
100314	NUT,NYLOC	**12**	2A-71	100364	SCREW,HEXHD	**79**	7-13
100314	NUT,NYLOC	**12**	2B-65	100365	SCREW,HEXHD	**16**	3-5
100314	NUT,NYLOC	**13**	7-65	100365	SCREW,HEXHD	**73**	4-33
100314	NUT,NYLOC	**16**	7-77	100370	WASHER,HARDENED	**5**	6-21
100314	NUT,NYLOC	**20**	7-59	100370	WASHER,HARDENED	**9**	6-41
100314	NUT,NYLOC	**20**	7-63	100370	WASHER,HARDENED	**10**	2A-85
100314	NUT,NYLOC	**21**	7-41	100370	WASHER,HARDENED	**11**	7-65
100314	NUT,NYLOC	**24**	5-9	100370	WASHER,HARDENED	**11**	2A-71
100314	NUT,NYLOC	**25**	7-51	100370	WASHER,HARDENED	**11**	2B-65
100314	NUT,NYLOC	**25**	7-67	100370	WASHER,HARDENED	**14**	7-77
100314	NUT,NYLOC	**27**	7-53	100370	WASHER,HARDENED	**15**	3-5
100314	NUT,NYLOC	**31**	7-49	100370	WASHER,HARDENED	**15**	2B-79
100314	NUT,NYLOC	**31**	7-55	100370	WASHER,HARDENED	**16**	7-89
100314	NUT,NYLOC	**31**	7-57	100370	WASHER,HARDENED	**17**	7-91
100314	NUT,NYLOC	**43**	4-3	100370	WASHER,HARDENED	**17**	2A-67
100314	NUT,NYLOC	**47**	4-51	100370	WASHER,HARDENED	**17**	2B-61
100314	NUT,LOCK	**51**	2A-81	100370	WASHER,HARDENED	**18**	7-63
100314	NUT,LOCK	**52**	2B-75	100370	WASHER,HARDENED	**18**	2A-3
100314	NUT,NYLOC CLASS	**60**	4-49	100370	WASHER,HARDENED	**18**	2A-5
100314	NUT,NYLOC	**60**	7-85	100370	WASHER,HARDENED	**18**	2B-3
100314	NUT,NYLOC	**74**	7-39	100370	WASHER,HARDENED	**19**	7-59
100314	NUT,NYLOC	**75**	4-21	100370	WASHER,HARDENED	**20**	7-41
100314	NUT,NYLOC	**75**	4-33	100370	WASHER,HARDENED	**23**	6-33
100314	NUT,NYLOC	**82**	7-13	100370	WASHER,HARDENED	**23**	6-43
100316	NUT,NYLOC	**3**	7-33	100370	WASHER,HARDENED	**23**	7-51
100316	NUT,NYLOC	**12**	7-65	100370	WASHER,HARDENED	**24**	7-67
100316	NUT,NYLOC	**13**	7-71	100370	WASHER,HARDENED	**25**	3-101
100316	NUT,NYLOC	**15**	7-95	100370	WASHER,HARDENED	**25**	3-111
100316	NUT,NYLOC	**24**	7-51	100370	WASHER,HARDENED	**25**	7-53
100316	NUT,NYLOC	**26**	7-69	100370	WASHER,HARDENED	**28**	4-15
100316	NUT,NYLOC	**32**	7-105	100370	WASHER,HARDENED	**29**	7-49
100316	NUT,NYLOC	**34**	7-97	100370	WASHER,HARDENED	**29**	7-93
100316	NUT,NYLOC	**34**	7-99	100370	WASHER,HARDENED	**30**	3-155
100316	NUT,NYLOC	**46**	4-51	100370	WASHER,HARDENED	**30**	3-179
100316	NUT,NYLOC	**81**	7-11	100370	WASHER,HARDENED	**30**	6-47
100316	NUT,NYLOC	**81**	7-13	100370	WASHER,HARDENED	**30**	7-55
100322	NUT,HEX	**14**	7-95	100370	WASHER,HARDENED	**31**	3-119
100322	NUT,HEX	**15**	7-77	100370	WASHER,HARDENED	**32**	7-97
100322	NUT,HEXAGON	**45**	4-51	100370	WASHER,HARDENED	**32**	7-99
100322	NUT,HEX	**74**	4-31	100370	WASHER,HARDENED	**33**	3-157
100323	NUT,NYLOC	**13**	3-79	100370	WASHER,HARDENED	**35**	3-145
100323	NUT,NYLOC	**31**	7-105	100370	WASHER,HARDENED	**37**	3-121
100334	NUT,CASTLE	**7**	4-47	100370	WASHER,HARDENED	**42**	4-3

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
100370	WASHER,HARDENED	**44**	4-51	100466	CAPSCREW,SOCHD	**24**	3-101
100370	WASHER,HARDENED	**49**	2A-81	100466	CAPSCREW,SOCHD	**24**	3-111
100370	WASHER,HARDENED	**49**	2A-83	100466	CAPSCREW,SOCHD	**29**	3-155
100370	WASHER,HARDENED	**50**	2B-75	100466	CAPSCREW,SOCHD	**29**	3-179
100370	WASHER,HARDENED	**50**	2B-77	100466	CAPSCREW,SOCHD	**30**	3-119
100370	WASHER,HARDENED	**57**	6-5	100466	CAPSCREW,SOCHD	**32**	3-157
100370	WASHER,HARDENED	**58**	4-49	100466	CAPSCREW,SOCHD	**33**	3-145
100370	WASHER,HARDENED	**58**	7-85	100466	CAPSCREW,SOCHD	**36**	3-121
100370	WASHER,HARDENED	**72**	4-21	100478	SCREW, ALTERNATOR TO BRACKET	**307**	2A-51
100370	WASHER,HARDENED	**72**	4-33	100478	SCREW, ALTERNATOR TO BRACKET	**307**	2B-45
100370	WASHER,HARDENED	**72**	7-39	100491	SCREW,HEXHD	**8**	3-91
100370	WASHER,HARDENED	**78**	7-9	100491	SCREW,HEXHD	**20**	7-51
100370	WASHER,HARDENED	**78**	7-11	100494	SCREW,HEXHD	**48**	2A-83
100370	WASHER,HARDENED	**78**	7-13	100494	SCREW,HEXHD	**49**	2B-75
100370	WASHER,HARDENED	**78**	7-21	100494	SCREW,HEXHD	**49**	2B-77
100372	CAPSCREW,SOCHD	**34**	3-145	100506	CAPSCREW,SOCHD	**28**	3-155
100383	BOLT	**22**	6-33	100506	CAPSCREW,SOCHD	**28**	3-179
100385	SCREW,MACHINE,H SLT	**22**	6-43	100506	CAPSCREW,SOCHD	**29**	3-119
100390	CAPSCREW	**14**	7-41	100506	CAPSCREW	**31**	3-159
100415	NUT,NYLOC	**22**	7-51	100506	CAPSCREW	**35**	3-123
100415	NUT,NYLOC	**23**	7-67	100506	CAPSCREW	**41**	3-157
100421	WASHER,FENDER	**6**	6-29	100506	CAPSCREW	**45**	3-121
100421	WASHER,FENDER	**13**	6-27	100524	WASHER,ALUMINIUM,SEAL	**22**	5-9
100423	WASHER,FLAT	**29**	7-105	100532	WASHER,HARDENED	**7**	3-91
100424	WASHER,HARDENED	**10**	7-65	100532	WASHER,HARDENED	**11**	7-95
100424	WASHER,HARDENED	**12**	7-71	100532	WASHER,HARDENED	**12**	3-3
100424	WASHER,HARDENED	**13**	3-3	100532	WASHER,HARDENED	**12**	3-79
100424	WASHER,HARDENED	**13**	7-95	100532	WASHER,HARDENED	**13**	3-5
100424	WASHER,HARDENED	**14**	3-5	100532	WASHER,HARDENED	**13**	7-77
100424	WASHER,HARDENED	**16**	2A-67	100532	WASHER,HARDENED	**17**	2A-3
100424	WASHER,HARDENED	**16**	2B-61	100532	WASHER,HARDENED	**17**	2A-5
100424	WASHER,HARDENED	**18**	7-59	100532	WASHER,HARDENED	**17**	2B-3
100424	WASHER,HARDENED	**21**	7-51	100532	WASHER,HARDENED	**19**	7-51
100424	WASHER,HARDENED	**24**	7-53	100532	WASHER,HARDENED	**25**	7-105
100424	WASHER,HARDENED	**24**	7-69	100532	WASHER,HARDENED	**27**	4-15
100424	WASHER,HARDENED	**24**	2A-69	100532	WASHER,HARDENED	**29**	7-97
100424	WASHER,HARDENED	**24**	2B-63	100532	WASHER,HARDENED	**29**	7-99
100424	WASHER,HARDENED	**28**	7-93	100532	WASHER,HARDENED	**42**	4-51
100424	WASHER,HARDENED	**29**	7-55	100532	WASHER,HARDENED	**57**	7-85
100424	WASHER,HARDENED	**31**	7-97	100532	WASHER,HARDENED	**70**	4-31
100424	WASHER,HARDENED	**31**	7-99	100536	WASHER,HARDENED	**11**	3-3
100424	WASHER,HARDENED	**43**	4-51	100536	WASHER,HARDENED	**12**	3-5
100424	WASHER,HARDENED	**71**	4-33	100536	WASHER,HARDENED	**16**	2A-3
100424	WASHER,HARDENED	**77**	7-11	100536	WASHER,HARDENED	**16**	2A-5
100430	SPLITPIN	**6**	4-47	100536	WASHER	**16**	2B-3
100430	SPLITPIN	**24**	4-53	100536	WASHER,HARDENED	**18**	7-51
100430	SPLITPIN	**28**	7-105	100536	WASHER,HARDENED	**24**	7-105
100430	SPLITPIN	**41**	3-169	100536	WASHER,HARDENED	**27**	7-93
100430	SPLITPIN	**42**	3-135	100536	WASHER,HARDENED	**28**	7-97
100430	SPLITPIN	**49**	3-175	100536	WASHER,HARDENED	**28**	7-99
100430	SPLITPIN	**50**	3-141	100536	WASHER,HARDENED	**69**	4-31
100440	CAPSCREW,SOCHD	**27**	7-105	100536	WASHER,HARDENED	**69**	4-33
100455	NUT,LOCK	**23**	4-53	100536	WASHER,HARDENED	**76**	7-11
100456	CAPSCREW,CSK SOCHD	**23**	7-53	100542	WASHER	**580**	3-9
100456	CAPSCREW	**28**	7-55	100542	WASHER	**590**	3-9
100461	CAPSCREW,SOCHD	**15**	7-89	100543	WASHER,FENDER	**41**	4-3
100461	CAPSCREW	**16**	7-91	100547	WASHER,FLAT	**12**	7-77
100463	CAPSCREW,SOCHD	**26**	7-105	100548	WASHER,HARDENED	**3**	6-25
100463	CAPSCREW,SOCHD	**26**	7-105	100548	WASHER,HARDENED	**8**	3-77
100463	CAPSCREW,SOCHD	**30**	7-97	100548	WASHER,HARDENED	**11**	7-71
100463	CAPSCREW,SOCHD	**30**	7-99	100548	WASHER,HARDENED	**15**	2A-3
100466	SCREW,CAP	**6**	3-185	100548	WASHER,HARDENED	**15**	2A-5

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
100548	WASHER,HARDENED	15	2A-67	100652	NUT,STOVER	21	2A-69
100548	WASHER,HARDENED	15	2B-3	100652	NUT,STOVER	21	2B-63
100548	WASHER,HARDENED	15	2B-61	100652	NUT,STOVER	25	4-15
100548	WASHER,HARDENED	16	2A-75	100653	NUT,STOVER	10	3-3
100548	WASHER,HARDENED	16	2B-69	100653	NUT,STOVER	11	3-5
100548	WASHER,HARDENED	17	7-51	100653	NUT,STOVER	13	2A-3
100548	WASHER,HARDENED	17	7-61	100653	NUT,STOVER	13	2A-5
100548	CAPSCREW,SOCHD	22	7-53	100653	NUT,STOVER	13	2B-3
100548	WASHER,HARDENED	22	7-67	100653	NUT,STOVER	15	7-51
100548	WASHER,HARDENED	23	2A-69	100653	NUT,STOVER	24	4-15
100548	WASHER,HARDENED	23	2B-63	100653	NUT,STOVER	25	7-97
100548	WASHER,HARDENED	27	7-55	100653	NUT,STOVER	25	7-99
100548	WASHER,HARDENED	27	7-57	100653	NUT,STOVER	55	7-85
100548	WASHER,HARDENED	27	7-97	100653	NUT,STOVER	67	4-31
100548	WASHER,HARDENED	27	7-99	100654	NUT,STOVER	16	7-61
100548	WASHER,HARDENED	28	7-49	100654	NUT,STOVER	66	4-31
100548	WASHER,HARDENED	29	6-47	100654	NUT,STOVER	75	7-11
100548	WASHER,HARDENED	40	4-3	100655	NUT,STOVER	9	3-3
100548	WASHER,HARDENED	40	4-5	100655	NUT,STOVER	10	3-5
100548	WASHER,HARDENED	47	2A-81	100655	NUT,STOVER	15	7-59
100548	WASHER,HARDENED	47	2A-83	100655	NUT,STOVER	20	2A-69
100548	WASHER,HARDENED	48	2B-75	100655	NUT,STOVER	20	2B-63
100548	WASHER,HARDENED	48	2B-77	100657	NUT,STOVER	9	2A-85
100548	WASHER,HARDENED	56	4-49	100657	NUT,STOVER	14	2B-79
100548	WASHER,HARDENED	56	6-7	100663	WASHER	15	4-43
100548	WASHER,HARDENED	56	7-85	100665	SCREW,CHEESEHD	5	6-29
100548	WASHER,HARDENED	68	4-33	100684	BOLT,HEXHD	25	7-57
100569	SCREW,HEXHD	16	4-43	100684	BOLT,HEXHD	31	3-117
100569	SCREW,HEXHD	16	7-51	100684	BOLT,HEXHD	70	3-89
100569	SCREW,HEXHD	21	7-67	100698	BOLT,HEXHD	11	3-79
100569	SCREW,HEXHD	22	2A-69	100698	BOLT,HEXHD	23	4-15
100569	SCREW,HEXHD	22	2B-63	100706	SCREW,HEXHD	21	5-9
100569	SCREW,HEXHD	23	7-69	100720	BOLT,HEX HD	3	3-97
100569	SCREW,HEXHD	26	7-57	100720	BOLT,HEX HD	3	3-99
100569	SCREW,HEXHD	26	7-93	100720	BOLT,HEX HD	11	3-97
100569	SCREW,HEXHD	33	3-117	100720	BOLT,HEX HD	11	3-99
100569	SCREW,HEXHD	39	4-3	100730	BOLT,HEXHD	12	6-27
100569	SCREW,HEXHD	39	4-5	100730	BOLT,HEXHD	74	7-13
100588	G-RING	10	5-3	100731	SCREW,HEXHD	2	6-25
100588	G-RING	12	5-13	100731	SCREW,HEXHD	10	7-71
100590	G-RING	7	5-17	100731	SCREW,HEXHD	14	7-61
100590	G-RING	11	5-13	100731	SCREW,HEXHD	15	2A-75
100594	WASHER,FENDER	7	6-31	100731	SCREW,HEXHD	15	2B-69
100594	WASHER,FENDER	55	6-5	100731	SCREW,HEXHD	20	7-67
100598	CAPSCREW,SOCHD	26	7-97	100731	SCREW,HEXHD	21	6-33
100598	CAPSCREW,SOCHD	26	7-99	100731	SCREW,HEXHD	24	7-57
100598	CAPSCREW,SOCHD	32	3-117	100731	SCREW,HEXHD	24	7-97
100608	CAPSCREW,BUTTON,SOC HD	20	7-35	100731	SCREW,HEXHD	24	7-99
100608	CAPSCREW	22	7-69	100731	SCREW,HEXHD	46	2A-81
100613	washer	26	7-47	100731	SCREW,HEXHD	46	2A-83
100615	WASHER,FLAT	15	7-41	100731	SCREW,HEXHD	47	2B-75
100615	WASHER,FLAT	54	6-7	100731	SCREW,HEXHD	47	2B-77
100615	WASHER, FLAT	71	7-23	100731	SCREW	54	4-49
100617	NUT,NYLOC	21	7-69	100731	SCREW	54	7-85
100619	SCREW,HEXHD	41	4-51	100731	SCREW,HEXHD	65	4-33
100642	CAPSCREW,SOCHD	21	6-43	100731	SCREW	70	7-31
100643	SCREW,HEXHD	14	2A-3	100731	SCREW	73	7-21
100643	SCREW,HEXHD	14	2A-5	100733	SCREW,HEXHD	20	6-33
100643	SCREW,HEXHD	14	2B-3	100733	SCREW,HEXHD	38	4-3
100644	BOLT,HEXHD	26	4-15	100733	SCREW,HEXHD	45	2A-83
100652	NUT,STOVER	14	2A-67	100733	SCREW,HEXHD	46	2B-77
100652	NUT,STOVER	14	2B-61	100734	BOLT,HEXHD	72	7-11

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
100747	BOLT,HEXHD	19	2A-69	100925	SCREW,HEXHD	35	3-121
100747	BOLT,HEXHD	19	2B-63	100927	BOLT,HEXHD	61	4-31
100747	BOLT,HEXHD	64	4-33	100936	BOLT	68	7-13
100757	BOLT,HEXHD	23	7-57	100938	SCREW,COUNTERSUNK	10	7-43
100757	BOLT,HEXHD	40	4-51	100945	SCREW,HEXHD	5	3-91
100760	SCREW,HEXHD	13	3-187	100945	SCREW,HEXHD	9	7-65
100763	BOLT,HEXHD	30	3-117	100945	SCREW,HEXHD	14	7-51
100777	NUT,HEXAGON	11	7-77	100945	SCREW,HEXHD	26	6-47
100786	BOLT,HEXHD	29	3-117	100945	SCREW,HEXHD	37	4-3
100786	BOLT,HEXHD	32	3-145	100947	WASHER,FLAT	62	7-25
100799	BOLT,WING	69	7-25	100947	WASHER,FLAT	67	7-15
100811	NUT,NYLOC	28	6-47	100949	SCREW,SLOTTED	25	6-47
100812	WASHER,FLAT	8	6-41	100952	CAPSCREW,SOCHD	60	4-33
100812	WASHER,FLAT	27	6-47	100953	CAPSCREW,SOCHD	19	6-33
100821	CAPSCREW,SOCHD	14	4-43	100977	PIN,DOWEL,CYL,MTG	40	3-169
100821	CAPSCREW,SOCHD	48	3-175	100977	PIN,DOWEL,CYLINDER	41	3-135
100821	CAPSCREW,SOCHD	49	3-141	100977	PIN,DOWEL	47	3-175
100827	SCREW,HEXHD	12	2A-3	100977	PIN,DOWEL,CYL,MTG	48	3-141
100827	SCREW,HEXHD	12	2A-5	100978	POP RIVET	15	3-103
100827	SCREW,HEXHD	12	2B-3	100978	POP RIVET	23	3-159
100830	SCREW,PANHD,SELFTAP	68	7-23	100978	POP RIVET	27	3-123
100830	SCREW,PANHD,SELFTAP	68	7-25	100978	POP RIVET	30	3-145
100832	CAPSCREW,CSK	67	7-27	100978	POP RIVET	30	3-157
100832	CAPSCREW,CSK	71	7-15	100978	POP RIVET	34	3-121
100835	CAPSCREW	66	7-23	100985	SCREW,HEXHD	22	7-97
100835	CAPSCREW	66	7-25	100985	SCREW,HEXHD	22	7-99
100835	CAPSCREW	66	7-29	100985	SCREW,HEXHD	23	7-105
100837	CAPSCREW,CSK	70	7-15	100994	CAPSCREW,SOCHD	19	7-53
100837	CAPSCREW,CSK,SOCHD	70	7-21	100994	CAPSCREW,SOCHD	22	7-55
100838	WASHER,FLAT	65	7-23	101010	WASHER,FENDER	61	7-23
100838	WASHER,FLAT	65	7-25	101021	CAPSCREW,SOCHD	59	4-31
100841	SCREW,PANHD	11	6-27	101023	BOLT,HEXHD	46	3-175
100842	POP RIVET	64	7-23	101023	BOLT,HEXHD	47	3-141
100846	NUT,CENTRE LOCK	17	7-35	101048	CAPSCREW,SOCHD	9	7-77
100847	CAPSCREW,SOCHD	63	4-33	101048	CAPSCREW,SOCHD	58	4-31
100848	CAPSCREW,SOCHD	62	4-33	101059	SCREW,SLT CHEESEHD	20	6-43
100850	STUD,M/S,FULL THREAD	69	7-15	101062	POP RIVET	60	7-31
100857	WASHER,BODY	16	7-35	101079	CAPSCREW	13	3-137
100868	WASHER	23	7-97	101079	CAPSCREW	13	3-143
100868	WASHER	23	7-99	101079	CAPSCREW	13	3-171
100872	SCREW,PANHD SELFTAP	63	7-23	101079	CAPSCREW	13	3-177
100872	SCREW,PANHD SELFTAP	63	7-25	101079	CAPSCREW,SOCD	27	7-83
100877	SCREW,HEXHD	8	3-3	101080	WASHER,HARDENED	26	7-83
100877	SCREW,HEXHD	9	3-5	101080	WASHER,HARDENED	36	4-3
100878	WASHER,FENDER	20	7-69	101085	SCREW,HEXHD	66	7-15
100879	SCREW,SLT CHEESEHD	7	6-41	101087	NUT,HEX	25	7-83
100887	CAPSCREW,SOCHD	10	7-77	101088	WASHER,DOWTY	6	6-41
100887	CAPSCREW,SOCHD	12	7-95	101113	NUT,FLANGED	33	3-121
100887	CAPSCREW,SOCHD	39	4-51	101113	NUT,FLANGED	40	3-135
100888	CAPSCREW,SOCHD	14	7-89	101113	NUT,FLANGED	46	3-141
100888	CAPSCREW,SOCHD	15	7-91	101115	NUT,SLOTTED	39	3-135
100923	SCREW,HEXHD	6	3-91	101115	NUT,SLOTTED	39	3-169
100925	SCREW,HEXHD	16	3-103	101116	NUT,FLANGED	38	3-135
100925	SCREW,HEXHD	23	3-101	101116	NUT,FLANGED	38	3-169
100925	SCREW,HEXHD	23	3-111	101116	NUT,FLANGED	45	3-141
100925	SCREW,HEXHD	24	3-159	101116	NUT,FLANGED	45	3-175
100925	SCREW,HEXHD	27	3-179	101126	CAPSCREW,SOCHD	37	3-135
100925	SCREW,HEXHD	28	3-119	101126	CAPSCREW,SOCHD	37	3-169
100925	SCREW,HEXHD	28	3-123	101126	CAPSCREW,SOCHD	44	3-141
100925	SCREW,HEXHD	28	3-155	101126	CAPSCREW,SOCHD	44	3-175
100925	SCREW,HEXHD	31	3-145	101127	BOLT,HEXHD	36	3-135
100925	SCREW,HEXHD	31	3-157	101127	BOLT,HEXHD	36	3-169

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
101127	BOLT,HEXHD	43	3-141
101127	BOLT,HEXHD	43	3-175
101128	NUT,HEX	35	3-135
101128	NUT,HEX	35	3-169
101128	NUT,HEX	42	3-141
101128	NUT,HEX	42	3-175
101129	BOLT,HEXHD	7	6-49
101129	bolt,hexhd	34	7-47
101136	DOWEL	12	3-137
101136	DOWEL,PIN	12	3-143
101136	DOWEL,PIN	12	3-171
101136	DOWEL,PIN	12	3-177
101140	NUT,HEX,FLANGED	22	3-159
101140	NUT,HEX,FLANGED	26	3-123
101140	NUT,HEX	29	3-157
101140	NUT,HEX,FLANGED	32	3-121
101141	STUD	21	3-159
101141	STUD	25	3-123
101141	STUD	28	3-157
101141	STUD,BELL DIFF	31	3-121
101151	SCREW,HEXHD	27	3-157
101152	SCREW,CSK,SELFTAP	59	7-23
101156	CAPSCREW,SOCHD	35	4-3
101167	WASHER,SPRING	8	6-13
101167	WASHER,SPRING	10	6-27
101167	WASHER,SPRING	53	6-7
101168	SCREW,PANHD	52	6-7
101170	SCREW,PANHD	7	6-13
101170	SCREW,PANHD	51	6-7
101171	SCREW,PANHD	6	6-13
101171	SCREW,PANHD	50	6-7
101172	BOLT,HEX	58	7-31
101174	CAPSCREW,CSK	57	7-27
101174	CAPSCREW,CSK	57	7-29
101174	CAPSCREW,CSK,SOC	65	7-15
101175	CAPSCREW,CSK	56	7-23
101176	NUT,SPEED	6	6-31
101176	NUT,SPEED	55	7-23
101176	NUT,SPEED	55	7-25
101181	SCREW,PANHD	9	6-27
101185	CAPSCREW	54	7-23
101188	CAPSCREW,SOCHD	6	7-79
101193	WASHER,SPRING	49	6-7
101195	WASHER,SPRING	41	3-141
101195	WASHER,SPRING	41	3-175
101197	SCREW,MACHINE CSK POSI.S/S	4	7-19
101211	BOLT,J	6	4-35
101211	BOLT,J	6	4-37
101211	BOLT,J	7	4-41
101211	BOLT,J	8	4-39
101211	BOLT	19	6-43
101216	WASHER,SERRATED	48	6-5
101225	SCREW,HEXHD	21	5-9
101235	SCREW,PANHD	47	6-5
101301	WASHER,FLAT,BONNET CATCH	13	7-61
101301	WASHER,FLAT	19	7-67
101305	WASHER,FLAT	26	3-157
101307	WASHER,FLAT	17	7-63
101307	WASHER,FLAT	34	4-3
101307	WASHER,FLAT	64	7-7
101309	WASHER,FENDER	5	4-35
101309	WASHER,FENDER	5	4-37
101309	WASHER,FENDER	6	4-41
101309	WASHER,FENDER	7	4-39
101309	WASHER,FENDER	18	6-43
101324	BOLT,HEXHD	7	3-3
101324	BOLT,HEXHD	8	3-5
101324	BOLT,HEXHD	11	2A-3
101324	BOLT,HEXHD	11	2A-5
101324	BOLT,HEXHD	11	2B-3
101326	BOLT,HEXHD	8	7-77
101343	WASHER,MILDSTEEL	22	4-15
101345	WASHER,HARDENED	18	6-33
101345	WASHER,HARDENED	21	4-15
101345	WASHER,HARDENED	44	2A-83
101345	WASHER,HARDENED	45	2B-77
101349	WASHER	21	3-97
101349	WASHER	21	3-99
101354	SCREW,CAP,BRACKET TO CRANK-CASE	406	2A-45
101354	SCREW,CAP,BRACKET TO CRANK-CASE	406	2A-47
101354	SCREW,CAP,BRACKET TO CRANK-CASE	406	2B-41
101356	BOLT,HEXHD	19	7-41
101356	BOLT,HEXHD	53	7-39
101364	NUT,HEXAGON	8	7-41
101382	NUT	22	3-97
101382	NUT	22	3-99
101384	WASHER	13	2B-79
101385	WASHER	12	2B-79
101993	SCREW,HEXHD	20	4-15
101997	CAPSCREW,SOCHD	17	6-33
101997	CAPSCREW,SOCHD	46	6-5
105013	SCREW,HEXHD	25	7-93
120026	CONNECT	20	3-159
120026	CONNECT	24	3-123
120030	CONNECT	19	3-159
120030	CONNECT	23	3-123
120040	PLUG,HEX	57	4-21
120047	ELBOW	18	3-159
120047	ELBOW	22	3-123
120051	ADAPTOR,MALE	43	2A-81
120051	ADAPTOR	44	2B-75
120053	ADAPTOR,MALE NPTF,PUSHLOCK	3	10-37
120101	ELBOW	13	4-43
120106	CONNECTOR	26	3-179
120106	CONNECTOR	27	3-155
120106	CONNECTOR	38	4-51
120128	PLUG	20	3-187
120148	CONNECTOR	28	3-117
120148	CONNECTOR	29	3-145
120148	CONNECTOR	37	4-51
120157	CONNECTOR	9	5-3
120157	CONNECTOR	10	5-13
120161	ADAPTOR,BARBED HOSE	10	3-79
120161	ADAPTOR,BARBED	36	4-51
120166	VALVE,DRAIN	6	5-17
120222	FLANGE,HALF 2”	53	4-49
120237	FLANGE,HALF	7	3-77
120238	FLANGE,HALF	55	4-21
120238	FLANGE,HALF	55	4-33
120258	ELBOW,UNION	20	5-9
120286	UNION	19	5-9

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
120308	BULKHEAD	21	3-101	121289	CAP,DUST	13	3-99
120308	BULKHEAD	21	3-111	121290	VALVE,AIR RELIEF	7	3-97
120308	BULKHEAD	25	3-157	121290	VALVE,AIR RELIEF	7	3-99
120308	BULKHEAD	25	3-179	121290	VALVE,AIR RELIEF	12	3-97
120308	BULKHEAD	26	3-155	121290	VALVE,AIR RELIEF	12	3-99
120308	BULKHEAD	27	3-119	121296	FRAMATONE, 16 WAY, PLUG, SOCK-ETS	120	6-61
120308	ELBOW	28	3-145				
120308	BULKHEAD	30	3-121	121297	CAP,DUST	8	3-97
120313	BULKHEAD	8	5-3	121297	CAP,DUST	8	3-99
120322	PLUG, WITH O-RING	17	5-7	121312	TAP,COOLANT DRAIN	41	2A-83
120332	PLUG	10	3-185	121312	TAP,COOLANT DRAIN	42	2B-77
120335	PLUG	4	4-11	121350	ELBOW	4	5-5
120352	ADAPTOR	6	5-5	121364	CONNECT	5	5-17
120379	ELBOW	20	3-101	121364	CONNECT	8	5-13
120379	ELBOW	20	3-111	121365	ADAPTOR	4	5-17
120379	ELBOW	24	3-155	121365	ADAPTOR	7	5-13
120379	ELBOW	24	3-157	121365	ADAPTOR	10	2A-75
120379	ELBOW	24	3-179	121365	ADAPTOR	10	2B-69
120379	ELBOW	26	3-119	121429	ELBOW,B/HEAD	14	3-103
120379	ELBOW	27	3-145	121443	FTG,PUSHLOCK	56	4-33
120379	ELBOW	29	3-121	121451	ADAPTOR	9	2A-75
120396	PLUG,CLOSURE HEX SOCKET	9	7-71	121451	ADAPTOR	9	2B-69
120396	PLUG,CLOSURE HEX SOCKET HD	44	3-83	121463	CONNECTOR,SUSPSTRUT	1	10-29
120397	PLUG,HOLLOW HEX	33	4-5	122008	ELBOW	4	4-35
120399	PLUG,BLANKING	9	5-13	122008	ELBOW	4	4-37
120596	CONNECT	53	4-33	122008	ELBOW	5	4-41
120631	FITTING, TUBE	12	5-7	122008	ELBOW	6	4-39
120640	FITTING, HOSE	15	5-7	122014	ELBOW	51	4-21
120670	CONNECT	14	2A-75	122015	CONNECT	12	4-43
120670	CONNECT	14	2B-69	122015	CONNECT	22	4-53
120671	BULKHEAD	35	4-51	122015	CONNECT	33	4-51
120679	ADAPTOR	15	7-45	122017	CONNECT	11	4-43
120680	CONNECTOR	5	5-5	122017	CONNECT	32	4-3
120758	UNION	18	5-9	122018	CONNECT	50	4-21
120781	ADAPTOR	13	2A-75	122018	CONNECT	50	4-31
120781	ADAPTOR	13	2B-69	122020	ELBOW	10	4-43
120804	ELBOW	12	2A-75	122020	ELBOW	13	3-103
120804	ELBOW	12	2B-69	122021	CONNECT	31	4-5
120804	ELBOW	17	5-9	122021	CONNECT	49	4-21
120807	ELBOW	27	3-117	122028	ELBOW	30	4-5
120926	FTG,HOSE ADPT,1/4" BSP	5	10-37	122028	ELBOW	52	4-49
120926	FTG,HOSE ADPT,1/4"BSP,TYRE TOW	7	10-31	122032	ELBOW	19	4-15
120962	ELBOW	17	3-159	122032	ELBOW	29	4-3
120962	ELBOW	21	3-123	122032	ELBOW	48	4-33
120969	CONNECTOR	1	5-19	122047	ELBOW	47	4-21
120969	CONNECTOR	11	2A-75	122049	CONNECT	46	4-21
120969	CONNECTOR	11	2B-69	122049	CONNECTOR	51	4-49
120970	CONNECTOR	16	5-9	122068	CONNECT	45	4-21
121024	TEE,BRANCH	15	5-9	122069	ELBOW	44	4-33
121045	ADAPTOR	16	5-11	122071	ELBOW	43	4-21
121086	ADAPTOR	14	5-11	122091	CONNECTOR	50	4-49
121090	CONNECT,SPEC	10	2A-3	122092	CONNECTOR	49	4-49
121090	CONNECT,SPEC	10	2A-5	122098	ELBOW	18	4-15
121090	CONNECT	10	2B-3	122107	TEE,RUN	42	4-31
121131	CONNECT,G	5	6-41	122120	CAP	9	4-43
121186	ADAPTOR	16	5-7	122136	VALVE,DRAIN	9	2A-3
121224	PLUG,HOLLOW HEX	42	2A-83	122136	VALVE,DRAIN	9	2A-5
121224	PLUG	43	2B-77	122136	VALVE,DRAIN	9	2B-3
121275	MALE-8,M20,TAIL,90 DEG,PCT-M20	9	3-79	122136	VALVE,DRAIN	48	7-85
121275	MALE-8	34	4-51	122148	CONNECT	32	4-51
121275	MALE-8	52	4-33	122149	TEE,SPEC	31	4-51
121289	CAP,DUST	13	3-97	122153	ELBOW	28	4-5

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
122154	ELBOW	**46**	4-49	140352	O-RING	**24**	3-117
122156	CONNECT	**41**	4-21	140368	O-RING	**13**	4-17
122156	CONNECT	**41**	4-33	140370	O-RING	**3**	5-17
122157	CONNECT	**30**	4-51	140370	O-RING	**5**	5-13
122157	CONNECTOR	**45**	4-49	140397	O-RING	**23**	7-83
122165	TEE,RUN	**8**	4-43	140398	O-RING	**36**	4-31
122189	TEE,BRANCH	**29**	4-51	140400	RING,BACK UP	**14**	4-17
122192	ELBOW	**40**	4-33	140411	RING,BACK UP	**22**	7-83
122257	REDUCER	**3**	4-35	140429	O-RING	**23**	3-117
122257	REDUCER	**3**	4-37	140438	KIT,SEAL,STEERING CYL	**5**	4-47
122257	REDUCER	**5**	4-39	140442	SEAL,ROD,OMEGAT	**21**	7-83
122263	TEE,BRANCH	**4**	4-39	140443	SEAL,ROD,COMPACT	**20**	7-83
122263	TEE,BRANCH	**4**	4-41	140462	WASHER,DOWTY	**15**	5-11
122279	ELBOW	**47**	4-49	140466	O RING	**44**	7-85
125008	CONNECTOR	**22**	3-101	140471	SEAL,CASSETTE	**18**	3-187
125008	CONNECTOR	**22**	3-111	140498	SEAL,WIPER POLYU	**19**	7-83
125008	CONNECTOR	**82**	4-33	140542	SEAL,CAP,DIESEL FILLER	**2**	7-73
130001	HOSE,PUSHLOCK	**8**	3-79	140565	KIT,SEAL	**9**	4-17
130001	HOSE,PUSHLOCK	**27**	4-51	140602	SEAL,OIL,DOUBLE LIP	**12**	7-89
130001	HOSE,PUSHLOCK	**28**	4-51	140602	SEAL,OIL,DOUBLE LIP	**13**	7-91
130001	HOSE,PUSHLOCK	**39**	4-33	140613	SEAL,WIPER	**16**	4-53
130002	HOSE,PUSHLOCK	**38**	2A-81	140622	SEAL,RING	**18**	2A-69
130002	HOSE,PUSHLOCK	**39**	2A-81	140622	SEAL,RING	**18**	2B-63
130002	HOSE	**39**	2B-75	140623	O-RING	**15**	4-53
130002	HOSE,PUSHLOCK	**40**	2A-81	140628	KIT,SEAL	**17**	5-11
130002	HOSE	**40**	2B-75	140660	KIT,SERVICE	**2**	4-19
130002	HOSE	**41**	2B-75	140696	W/BAND,ROD	**18**	7-83
130020	HOSE,PUSHLOCK 1/4”	**6**	10-37	140702	W/BAND,ROD	**14**	4-53
130029	PIPE,AIR LINE	**7**	5-3	140706	W/BAND,PISTON	**17**	7-83
130049	HOSE,CLEAR	**24**	7-93	140720	O-RING	**11**	7-89
140011	SEAL,OIL	**26**	3-117	140720	O RING,NEOPRENE	**12**	7-91
140020	O-RING	**21**	4-53	140728	O-RING	**35**	4-33
140031	SEAL,PISTON	**20**	4-53	140728	O-RING	**44**	4-49
140032	SEAL,PISTON	**17**	4-17	140731	O-RING	**42**	4-49
140033	SEAL,WIPER	**11**	4-17	140734	O-RING	**15**	4-17
140044	SEAL,SINGLE ACTING	**12**	4-17	140744	KIT,SEAL	**4**	7-87
140059	O-RING	**10**	4-17	140775	SEAL,OSCILLATION	**22**	3-117
140062	O-RING	**29**	4-45	140777	SEAL,D/LIP	**19**	3-123
140103	RING,ANTI-EXTRUSION	**19**	4-53	140777	SEAL,D/LIP	**26**	3-121
140105	O-RING	**17**	3-187	140777	SEAL,D/LIP	**34**	3-135
140159	O-RING	**38**	4-33	140777	SEAL,D/LIP	**34**	3-169
140160	U-SEAL	**18**	4-53	140777	SEAL,D/LIP	**40**	3-141
140162	O-RING	**37**	4-31	140777	SEAL,D/LIP	**40**	3-175
140169	O-RING	**4**	7-101	140805	O-RING	**6**	4-11
140169	O-RING	**24**	7-83	140806	O-RING	**5**	4-11
140193	O-RING	**6**	5-3	140821	V-RING	**33**	3-135
140193	O-RING	**6**	5-13	140821	V-RING	**33**	3-169
140201	O-RING	**17**	4-53	140821	V-RING	**39**	3-141
140203	O-RING	**25**	3-117	140821	V-RING	**39**	3-175
140303	SEAL,OIL	**13**	7-89	140836	RING,QUAD	**13**	4-53
140303	SEAL,OIL	**14**	7-91	140988	KIT,SEAL INTERSECTION	**9**	4-29
140330	KIT,SEAL,MINERAL OIL	**8**	3-185	145018	O-RING	**63**	7-7
140340	V-RING	**19**	3-101	150018	ROLLER,BEARING	**35**	3-187
140340	V-RING	**19**	3-111	150044	BEARING,CARB	**34**	4-31
140340	V-RING	**23**	3-155	150057	BEARING,TAPER ROLLER	**32**	3-135
140340	V-RING	**23**	3-157	150057	BEARING,TAPER ROLLER	**32**	3-169
140340	V-RING	**23**	3-179	150057	BEARING,TAPER ROLLER	**38**	3-141
140340	V-RING	**25**	3-119	150057	BEARING,TAPER ROLLER	**38**	3-175
140340	V-RING	**26**	3-145	150060	BEARING,ROLLER	**28**	3-187
140340	V-RING	**28**	3-121	150064	BEARING,CUP	**31**	3-135
140342	V RING	**20**	3-123	150064	BEARING,CUP	**31**	3-169
140342	V-RING	**27**	3-121	150064	BEARING,CUP	**37**	3-141

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
150064	BEARING,CUP	37	3-175	161028	WASHER,ORBITAL MTG	27	4-3
150065	BEARING,TAPER ROLLER	33	3-187	161054	SHIM,4MM,BELLYPLT,FRONT	8	7-65
150069	BEARING,TAPER ROLLER	34	3-187	161055	PIN,BONNET HINGE	7	7-65
150071	BEARING,CONE	30	3-135	161055	PIN,BONNET HINGE	12	7-59
150071	BEARING,CONE	30	3-169	161071	NECKBUSH	3	4-47
150071	BEARING,CONE	36	3-141	161081	SLEEVE	45	6-5
150071	BEARING,CONE	36	3-175	161086	SPACER BLOCK,DOOR STRAP	62	7-15
150072	CONE,DIFF BEARING LH	29	3-135	161099	BOSS,ORBITAL	26	4-3
150072	CONE,DIFF BEARING LH	29	3-169	161127	CARRIER,SEAL,DK-7,OUTPUT	24	3-119
150072	CONE,DIFF BEARING LH	35	3-141	161127	CARRIER,SEAL	25	3-145
150072	CONE,DIFF BEARING LH	35	3-175	161221	MOUNTING,T/CASE,LOWER	2	3-81
150073	BEARING,CUP	28	3-135	161312	PISTON	11	4-53
150073	BEARING,CUP	28	3-169	161318	PISTON	8	4-17
150073	BEARING,CUP	34	3-141	161685	MTG PLT,FIXED ARTIC	8	7-89
150073	BEARING,CUP	34	3-175	161685	MTG PLT:FIXED ARTIC	9	7-91
150076	BEARING,PILOT	27	3-135	161786	HUB:MACHINED	2	3-187
150076	BEARING,PILOT	27	3-169	161893	RING GEAR CARRIER	5	3-187
150076	BEARING,PILOT	33	3-141	161913	BOSS,STRAP,F/CHASSIS	13	7-51
150076	BEARING,PILOT	33	3-175	161914	PIN,SMALL HEAD	15	4-15
150077	BEARING,CONE	26	3-135	161960	BOSS	20	7-105
150077	BEARING,CONE	26	3-169	162014	WASHER,VESCONITE	14	4-15
150077	BEARING,CONE	32	3-141	162040	COVER,PLT,SEAL OSC,T/D	19	3-117
150077	BEARING,CONE	32	3-175	162041	HOUSING,BRG,REAR-OSC,T/D	18	3-117
150078	BEARING,PINION	25	3-135	162060	PIN,BIN HEAT,SPRING GUIDE	17	2A-69
150078	BEARING,PINION	25	3-169	162060	PIN,BIN HEAT,SPRING GUIDE	17	2B-63
150078	BEARING,PINION	31	3-141	162077	DISC:14T AXLE	4	3-187
150078	BEARING,PINION	31	3-175	162208	SPACER,THRU DRIVE	24	3-135
150082	BEARING,D.G.BALL	21	3-117	162208	SPACER,THRU DRIVE	24	3-169
150097	BEARING,SPHERICAL	22	7-105	162208	SPACER,THRU DRIVE	30	3-141
150137	ASSY,BEARING,ARTIC HITCH	10	7-89	162208	SPACER,THRU DRIVE	30	3-175
150137	ASSY,BEARING,ARTIC HITCH	11	7-91	162225	CARRIER,FRONT SEAL,MACHINED	23	3-135
150191	BEARING,SEALED	12	4-53	162225	CARRIER,FRONT SEAL	23	3-169
150216	BEARING,SPHERICAL ROLLER	18	3-123	162225	CARRIER,FRONT SEAL	29	3-141
150216	BEARING,SPHERICAL ROLLER	25	3-121	162225	CARRIER,FRONT SEAL	29	3-175
160074	BUSH	17	4-15	162228	NUT,ADJUSTER,RH,MACHINED	22	3-133
160182	SHIM: PLANET	26	3-187	162228	NUT,ADJUSTER,RH	22	3-169
160190	PLATE,RETAINER,RING GEAR	10	3-187	162228	NUT,ADJUSTER,RH	28	3-141
160193	RING,STEEL	25	3-187	162228	NUT,ADJUSTER,RH	28	3-175
160194	PLUG,BRONZE THRUST	24	3-187	162229	NUT,ADJUSTER,LH,MACHINED	21	3-133
160263	NUT: LOCK,REAR,AXLE	27	3-187	162229	NUT,ADJUSTER,LH	21	3-167
160360	PLATE,LOCK	11	3-187	162229	NUT,ADJUSTER,LH	27	3-141
160432	SLEEVE,PEDAL,VESCONITE	16	4-15	162229	NUT,ADJUSTER,LH	27	3-175
160510	CLAMP,ALUM	14	5-9	162230	PLT,LOCK,LH	20	3-133
160523	BUSH,TILT CYL	2	4-17	162230	PLT,LOCK,LH	20	3-167
160571	STUB,AXLE,MACHINED	1	3-187	162230	PLT,LOCK,LH	26	3-141
160706	SLEEVE,FIXED ARTIC	9	7-89	162230	PLT,LOCK,LH	26	3-175
160706	SLEEVE,FIXED ARTIC	10	7-91	162231	PLT,LOCK,LH	19	3-133
160723	BLOCK,GREASE NIPPLE	20	3-117	162231	PLT,LOCK,RH	19	3-167
160839	NECKBUSH,SUSP.STRUT	16	7-83	162231	PLT,LOCK,RH	25	3-141
160956	RING,THRUST,SUNGEAR,HTB	21	3-187	162231	PLT,LOCK,RH	25	3-175
160993	NECKBUSH,NUT	6	4-17	162242	PIN,PIVOT,BIN STAY	23	7-93
160994	NECKBUSH,SET	7	4-17	162268	DOWEL,BELL DIFF	18	3-133
161016	BOSS	5	7-79	162268	DOWEL,BELL DIFF	18	3-167
161016	BOSS	7	7-77	162268	DOWEL	24	3-141
161016	BOSS	10	7-95	162268	DOWEL	24	3-175
161016	BOSS	21	7-97	162345	PLT,COVER,FIXED,ARTIC	7	7-89
161016	BOSS	21	7-99	162345	PLT:COVER-FIXED ARTIC	8	7-91
161017	BOSS	21	7-105	162346	PLT,COVER,FLOAT,ARTIC	6	7-89
161017	BOSS	26	4-51	162346	PLT:COVER-FLOAT ARTIC	7	7-91
161020	PISTON	4	4-47	162347	PIN,FIXED,TOP ARTIC	5	7-89
161025	BUSH,BIN PIVOT	20	7-97	162347	PIN,FIXED,TOP ARTIC	6	7-91
161025	BUSH,BIN PIVOT	20	7-99	162384	PLT,LOWER,STEERING	33	4-31

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
162394	PLT,LOCATING	32	4-31	173729	PIPE,GREASE,OSC BOTTOM BRG	14	3-117
162404	WASHER	7	3-79	173733	PLT,SPACER	37	2A-83
162404	WASHER	25	4-51	173733	PLT,SPACER	38	2B-77
162404	WASHER	31	4-33	173782	MANIFOLD,3 PORT,HYD TEST POINT	40	4-49
162423	NUT,NECKBUSH	10	4-53	173802	CUP,BONNET CATCH	10	7-61
162424	NECKBUSH	9	4-53	173837	MTG,BOTTOM,F/TANK,B/BOX	8	7-71
162440	PIN,PLANET	6	3-187	173837	MTG,BOTTOM,F/TANK,B/BOX	19	7-69
162456	WASHER,SPRING RET,BIN HEAT	13	4-15	173954	PLATE,LOCK BULKHEAD	39	4-49
162456	WASHER,SPRING RET,BIN HEAT	16	2A-69	173954	PLT,LOCK BULKHEAD	39	7-85
162456	WASHER,SPRING RET,BIN HEAT	16	2B-63	173964	PLT,BACKING,STEP STRAP,BTM	18	7-67
162577	TUBE	23	3-141	173969	LINK,LOCK,BATTERY BOX	18	7-69
162577	TUBE,#20 DIFF,PUMP,GUARD	23	3-175	174057	SHIM,C# ADT PARK BRAKE DX195	4	3-91
162955	PIN,SLOTTED	22	3-157	174293	RETAINER PLT	18	7-105
162955	PIN,SLOTTED	23	3-119	174446	PLATE,BELLY,FRONT	6	7-65
162955	PIN,SLOTTED	24	3-121	174447	MTG,EXHAUST H/SHIELD FRNT	13	2A-67
162955	PIN,SLOTTED SPRING	24	3-145	174447	MTG,EXHAUST H/SHIELD FRNT	13	2B-61
162960	SHAFT,T/DRIVE	17	3-117	174448	PLATE,COVER,BELLY,RHS	5	7-65
162960	SHAFT,T/DRIVE	20	3-97	174449	PLATE,COVER,BELLY,LHS	4	7-65
162960	SHAFT,T/DRIVE	20	3-99	174490	MTG,FUEL TANK,BATT BOX	12	7-51
166566	PIN,MTG,MIRROR	61	7-13	174494	GUARD,HYD,TANK	38	7-85
170222	CIRCLIP,REAR,AXLE	23	3-187	174496	MTG,CAB,FRONT LEFT	11	7-51
170489	SAW CYL.WASHER	22	7-93	174497	MTG,CAB,FRONT RIGHT	10	7-51
170548	PLT,LOCK,AXLE,ADT	9	7-95	174550	MTG,ORBITAL,CAB	25	4-3
171079	PIPE,BRAKE,CRADLE L.F/R.R	18	3-101	174554	GUARD,SUSP.STRUT VALVE	15	7-83
171079	PIPE,BRAKE,CRADLE L.F/R.R	18	3-111	174578	PLT,COVER,BIN PIPES	21	4-51
171508	CLAMP,PIPE,HOLE	52	7-25	174579	ASSY,MTG,BIN PIPES	20	4-51
172010	PLT,WASHER	19	7-105	174674	BKT,BIN HEATING,HYD MTG	15	2A-69
172043	WASHER,RUBBER	11	7-61	174674	BKT,BIN HEATING,HYD MTG	15	2B-63
172782	PLT,MUDFLAP MTG	19	7-97	174676	PLT,MTG,RHS,GUARD,WINDOW	58	7-11
172782	PLT,MUDFLAP MTG	19	7-99	174677	GUARD,P/SHAFT	9	7-51
172805	SHIM,1.6MM BIN HEIGHT	18	7-97	174687	MTG,REAR,P/SHAFT GUARD	8	7-51
172805	SHIM,1.6MM BIN HEIGHT	18	7-99	174700	REMOVABLE B/HEATING PROT	21	7-93
172806	SHIM,5MM BIN HEIGHT	17	7-97	174737	PLT,PIVOT RETAINER	16	6-33
172806	SHIM,5MM BIN HEIGHT	17	7-99	174739	STAY,CAB	12	4-15
172806	SHIM	22	3-119	174756	SHIM,DROP BOX MTG	6	3-79
172806	SHIM	22	3-155	174760	FLANGE,BIN HEATING BALL	14	2A-69
172806	SHIM	22	3-179	174760	FLANGE,BIN HEATING BALL	14	2B-63
172806	SHIM	23	3-145	174768	PLT,MTG,REFLECTOR	16	7-97
172806	SHIM,5MM BIN HEIGHT	29	3-159	174768	PLT,MTG,REFLECTOR	16	7-99
172806	SHIM,5MM BIN HEIGHT	33	3-123	175041	MTG ARM,HOSE RUBBER,CAB	27	7-49
172806	SHIM,5MM BIN HEIGHT	39	3-157	175066	MTG,STRUT,BONNET	15	7-53
172806	SHIM,5MM BIN HEIGHT	43	3-121	175066	MTG,STRUT,BONNET	21	7-55
172814	PIPE,HYD BRAKES,FRONT	24	4-51	175112	PLT,COVER,F/WHEEL,HOUSING	8	2A-3
172815	PIPE,TIP,BIN UP AND DOWN	23	4-51	175112	PLT,COVER,F/WHEEL,HOUSING	8	2A-5
172816	PIPE,HYD BRAKES,REAR	22	4-51	175112	PLT,COVER	8	2B-3
172976	LOCK,ARTICULATED	4	7-89	176088	BKT,RECEIVER DRIER,HVAC	14	7-45
172976	LOCK,ARTICULATED	5	7-91	176107	PLT,ROT SENSOR COVER	24	6-47
173025	PLT,STIFFNER	21	3-119	176109	PLT,ROT SENSOR MTG	23	6-47
173025	PLATE,STIFFNER	21	3-155	176111	BKT,FLASHING BEACON	4	6-21
173025	PLT,STIFFNER	21	3-157	176114	PLATE,SERIAL NUMBER	1	7-107
173025	PLT,STIFFNER	21	3-179	176177	PLATE,BULKHEAD,FIREWALL	13	7-45
173025	PLT,STIFFNER	22	3-145	176193	GUARD,BRAKE PIPE,LHS	19	3-145
173025	PLT,STIFFNER	23	3-121	176193	GUARD,BRAKE PIPE,LHS	20	3-119
173275	SHIM,FIXED ARTIC	3	7-89	176193	GUARD,BRAKE PIPE,LHS	20	3-179
173275	SHIM,FIXED ARTIC	4	7-91	176194	GUARD,BRAKE PIPE,RHS	18	3-145
173443	GUARD WINDOW REAR	60	7-11	176194	GUARD,BRAKE PIPE,RHS	19	3-119
173723	PIPE,BRAKE,FRONT,RHS	17	3-111	176194	GUARD,BRAKE PIPE,RHS	19	3-179
173724	PIPE,BRAKE,FRONT,LHS	16	3-111	176204	PLT,MTG,TOP,CONDENSOR	16	7-63
173725	PIPE,BRAKE-RHS	21	3-145	176249	PLT,MTG,ELEC HARNESS	15	6-33
173726	PIPE,BRAKE-LHS	20	3-145	176250	WASHER,PROFILED	13	2A-69
173727	PIPE,GREASE,OSC TOP BRG	16	3-117	176250	WASHER,PROFILED	13	2B-63
173728	PIPE,GREASE,OSC FNT T/B BRG	15	3-117	176303	SHIM	57	7-13

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
176306	WASHER,CAB	56	7-15	178668	SHIM,1.6MM NEW GUIDE PLT	13	7-97
176312	SHIM,1.6MM,G/HANDLE BKT	55	7-11	178668	SHIM,1.6MM NEW GUIDE PLT	13	7-99
176315	PLT,SPREADER,GEAR LEVER	5	6-13	178669	SHIM,5MM NEW GUIDE PLT	12	7-97
176327	SPACER,STEERING COLOUMN	51	7-39	178669	SHIM,5MM NEW GUIDE PLT	12	7-99
176353	MTG,HOSE,TEFLON	36	2A-81	178691	PLT,LOCK,OSCILLATION,NUT	12	3-117
176353	MTG,HOSE	37	2B-75	178710	SHIM,INSIDE OSCILLATION	11	3-117
176379	WASHER,SPRING	54	7-13	178726	TAG,LOCK,MIRROR	44	7-13
176398	PLT,HARNESS MTG	4	6-45	178728	BKT,COMP,PIPE	6	3-5
176406	PLT,STEER TOP	30	4-31	178746	MTG PLT,EXHAUST,F/CHASSIS	7	7-51
176407	CONE,STEER TOP	29	4-31	178747	MTG PLT,HOSES,F/CHASSIS	6	7-51
176408	PIN,D60X116L,EXPANDER	28	4-31	178799	WASHER,MACHINED	17	7-69
176415	PLT,TWO HOLE WASHER	22	6-47	178889	MTG,FRONT,P/SHAFT GUARD	5	7-51
176427	LID,MAIN DIESEL,ACCESS	7	7-71	178967	PLT,BOX,PADHANDLE	12	7-53
176428	BKT,ELEC F/CHASSIS	14	6-33	178967	PLT,BOX,PADHANDLE TRIMARK	19	7-57
176431	SHIM	53	7-15	181191	PIN,FLOAT'G:BOTTOM ARTIC	2	7-89
176434	WASHER,IGNITION	44	6-5	181522	ASSY,BELLY PLATE	3	7-65
176435	WASHER,CIG LIGHTER	43	6-5	181527	MOUNTING,T/CASE,TOP BRACKET	1	3-81
176490	SHIM,BIN SUPPORT POLE MTG	20	7-93	181539	ASSY,ROD,CYL,LIFT,B25D	8	4-53
176515	MTG PLT,LHS,BIN PIPES	19	4-51	181551	ASSY,ROD,CYL,LIFT,B30D	8	4-53
176516	MTG PLT,RHS,BIN PIPES	18	4-51	181564	ASSY,PIVOT,AUTOGATE	15	7-105
176519	PLT,BONNET MTG,HINGE	14	7-53	181675	BARREL,STEER,D100,#8MOR	2	4-47
176519	PLT,BONNET MTG,HINGE	20	7-55	181684	MTG,HATCH,HVAC DOOR STRUT	43	7-21
176534	STIFFENER,MUDFLAP,STRUT	17	7-67	181693	ROD,CYL,STEER,CARB	1	4-47
176540	HANDLE,BIN,FRONT	15	7-97	181796	OUTRIG,AUTOGATE,BOTTOM	14	7-105
176540	HANDLE,BIN,FRONT	15	7-99	181798	PLT,CHAIN-OUTRIG,AUTOGATE	13	7-105
176555	GUARD,BREAKE PIPE,LHS	20	3-155	181799	OUTRIG,AUTOGATE,LH	12	7-105
176556	GAURD,BRAKE PIPE,RHS	19	3-155	181804	OUTRIG,AUTOGATE,RH	11	7-105
176557	PIPE,BRAKE,FRONT,RHS	17	3-101	181860	ARM,WHEEL SPANNER	50	7-25
176558	PIPE,BRAKE,FRONT,LHS	16	3-101	181880	HANDLE,CAB,LHS,TOP,REAR	42	7-11
176559	PIPE,BRAKE-RHS MIDDLE	18	3-119	182281	MTG,MIRROR,RHS	41	7-13
176560	PIPE,BRAKE-LHS MIDDLE	17	3-119	182282	MTG,MIRROR,LHS	40	7-13
176580	SHIM,AUTOGATE,MAT	17	7-105	182283	MTG,CAB,MIRROR,LHS	39	7-13
176589	BKT,P-CLIP,AIRCON	26	7-49	182284	MTG,CAB,MIRROR,BKT,RHS	38	7-13
176590	PLT,BAFFLE MTG,BONNET	52	7-9	182285	HANDRAIL,CAB,ROOF	37	7-11
176591	ASSY,BAFFLE MTG,CAB,FRONT	51	7-9	182489	CHASSIS,FRONT,10MM	4	7-51
176592	SPACER,ENG MTG	6	3-3	182540	MTG,LH,TAILGATE,BIN,B30D,MKII	10	7-105
176592	SPACER,ENG MTG	7	3-5	182541	MTG,RH,TAILGATE,BIN,B30D,MKII	9	7-105
176592	SPACER,ENG MTG	7	2A-3	182544	BOX,LIGHT,LH,BIN	11	7-97
176592	SPACER,ENG MTG	7	2A-5	182544	BOX,LIGHT,LH,BIN	11	7-99
176592	SPACER,ENG MTG	7	2B-3	182545	BOX,LIGHT,RH,BIN	10	7-97
176593	ASSY,BAFFLE MTG,CAB,BTM	50	7-9	182545	BOX,LIGHT,RH,BIN	10	7-99
176600	BKT,HYD MISC	37	7-85	182590	MTG,LH,TAILGATE,BIN,B25D MKII	10	7-105
176607	SHIM,GATE-ARM,AUTOGATE	16	7-105	182591	MTG,RH,TAILGATE,BIN,B25D MKII	9	7-105
176608	GUARD,WINDOW,LOWER	36	7-85	182624	TANK,HYD,FUEL	34	7-85
176609	MTG,GUARD,LOWER	35	7-85	182804	BANJO,HSG	17	3-123
176670	PIPE,BRAKE,REAR,RHS	18	3-179	182808	BIN,B25D MKII	9	7-99
176671	PIPE,BRAKE,REAR,LHS	17	3-179	182809	BIN,B30D MKII	9	7-97
176709	PIPE,BRAKE,REAR,LHS	18	3-155	182958	OSCILLATION JOINT	10	3-117
176710	PIPE,BRAKE,REAR,RHS	17	3-155	182966	BANJO,HSG	22	3-121
176962	MTG BKT,LATCH	49	7-15	182967	BANJO,HSG	20	3-157
178039	PLT,COVER,SATELLITE BOX	4	6-29	182988	BARREL,TIP,MK2,D100,B30D	7	4-53
178141	SHIM,BIN SUPPORT POLE	19	7-93	182989	BARREL,TIP MK2,D100,B25D	7	4-53
178159	BRACKET,ANTENNA RADIO	5	6-31	182999	MTG,BRACKET,T3,HYD BLOCK	27	4-21
178169	SHIM,AXLE SPACING,DOMEX	6	7-77	183003	TAPER PLUG, WALKING BEAM	6	7-95
178169	SHIM,AXLE SPACING,DOMEX	7	7-95	183140	MTG,ENGINE	6	2A-3
178407	SHIM	48	7-13	183140	MTG,ENGINE	6	2A-5
178419	SHIM,OSCILLATION LOCK NUT	13	3-117	183140	MTG,ENGINE	6	2B-3
178567	SHIM	47	7-13	183155	MTG,TRANSMISSION,6HP590	5	3-3
178568	SHIM	46	7-13	183155	MTG,TRANSMISSION,6HP590	5	3-5
178569	SHIM	45	7-13	183170	BANJO,HOUSING,DK REAR	16	3-179
178656	PLT,GUIDE,BIN	14	7-97	183200	HINGE,BONNET,RHS	11	7-53
178656	PLT,GUIDE,BIN	14	7-99	183200	HINGE,BONNET,RHS	18	7-55

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
183201	HINGE,CHASSIS(BONNET)	2	7-65	186695	STRAP,F/OSCILL,CROSS PLT	14	7-93
183201	HINGE,CHASSIS(BONNET)	9	7-59	186696	COVER,REAR,LHS,F/OSCIL	13	7-93
183202	BARREL,CAB TILT	3	4-17	186697	COVER,REAR,RHS,F/OSCIL	12	7-93
183203	ROD,CAB TILT	4	4-17	186698	COVER,BACK,REAR,F/OSCIL	11	7-93
183333	LID,IN-TANK,FILTER	33	7-85	186699	COVER,TOP,F/OSCIL	10	7-93
183375	ASSY,TRANS MTG,4 HOLE	4	3-3	186703	RUBBER,UPPER SUSP.CAVITY	9	7-93
183375	ASSY,TRANS MTG,4 HOLE	4	3-5	186704	ASSY,COVER,LHS	8	7-93
183430	GATE,AUTOGATE,25D#	8	7-105	186705	ASSY,COVER,RHS	7	7-93
183431	GATE,AUTOGATE,30D#	8	7-105	186706	ASSY,COVER,BOTTOM	6	7-93
183432	MTG,RHS,CALIPER GUARD	15	3-179	186757	PLT,COVER,GPS ANTENNA	8	6-27
183432	MTG,RHS,CALIPER GUARD	16	3-119	186801	ARM,AUTOGATE,LHS,30D#	7	7-105
183432	MTG,RHS,CALIPER GUARD	16	3-155	186802	ARM,AUTOGATE,RHS,30D#	6	7-105
183432	MTG,RHS,CALIPER GUARD	17	3-145	186803	ARM,AUTOGATE,LHS,25D#	7	7-105
183432	MTG,RHS,CALIPER GUARD	19	3-157	186804	ARM,AUTOGATE,RHS,25D#	6	7-105
183432	MTG,RHS,CALIPER GUARD	21	3-121	186806	PLT,SANDWICH,MUDGUARD	16	7-67
183433	MTG,TOP,FRNT,CAL/GUARD	15	3-101	186889	BKT,BREATHER,TRANSFER CASE	5	3-79
183433	MTG,TOP,FRNT,CAL/GUARD	15	3-111	186890	BKT,BREATHER,AXLE	26	4-33
183435	MTG,LHS,CALIPER GUARD	14	3-179	186891	CLAMP,BREATHER	20	6-47
183435	MTG,LHS,CALIPER GUARD	15	3-119	186919	PLT,MTG,B/HEAT CV	5	7-93
183435	MTG,LHS,CALIPER GUARD	15	3-155	186940	PLT,ARTIC,PROTECT	4	7-93
183435	MTG,LHS,CALIPER GUARD	16	3-145	186960	PIPE,OIL LEAD,TIP CYL,B30D	6	4-53
183435	MTG,LHS,CALIPER GUARD	18	3-157	186961	PIPE,OIL LEAD,TIP CYL,B25D	6	4-53
183435	MTG,LHS,CALIPER GUARD	20	3-121	186978	BKT,FNT,HVAC HOSES	25	7-49
183436	MTG,BOT.FRNT,CAL/GUARD	14	3-101	187011	BUSH,PIN RETAINING	3	7-91
183436	MTG,BOT.FRNT,CAL/GUARD	14	3-111	187011	BUSH,PIN RETAINING	5	7-101
183496	HINGE,BONNET,LHS	10	7-53	187019	BRKT,PIPE,BRAKE	12	3-101
183496	HINGE,BONNET,LHS	17	7-55	187019	BRKT,PIPE,BRAKE	12	3-111
183510	BANJO,HOUSING,DK7 MIDDLE	14	3-119	187020	BRKT,PIPE,BRAKE,REAR	14	3-145
183511	BANJO,HOUSING,HK REAR	14	3-155	187020	BRKT,PIPE,BRAKE,REAR	19	3-121
183636	BANJO,HOUSING,DK-7,MID	15	3-145	187063	PLT,MTG,OBW TPMS	6	6-49
184059	ASSY,ROD,SUSP.STRUT	14	7-83	187092	PLT,TOP,K-CLAMP	5	6-49
184060	ASSY,BARREL,SUSP.STRUT	13	7-83	187166	GUARD,BRAKE PIPE,RHS	17	3-157
184065	ASSY,PISTON,SUSP.STRUT	12	7-83	187166	GUARD,BRAKE PIPE,RHS	18	3-121
184069	HSG,BANJO,FRONT	13	3-111	187167	GUARD,BRAKE PIPE,LHS	16	3-157
184070	HSG,BANJO,FRONT	13	3-101	187167	GUARD,BRAKE PIPE,LHS	17	3-121
184100	CHASSIS,REAR	18	7-93	187188	BOX,BATTERY	16	7-69
184215	HSG,BANJO,FRONT	12	3-103	187189	LID,TOP,BATTERY BOX	15	7-69
184239	BANJO,HSG	16	3-159	187191	DOOR,BATTERY BOX	14	7-69
184244	PLT,GUARD,PUMP	22	3-139	187225	MTG,ELEC HARNESS/HVAC	24	7-49
184244	PLT,GUARD,PUMP	22	3-175	187226	FRAME,GRILL	15	7-63
184326	PIN ASSY,PIVOT ROD SENSOR	2	7-101	187244	CLAMP,BATTERY	17	6-43
184327	PIN ASSY,BIN PIVOT	1	7-101	187245	BKT,FNT,PIPE,COMPRES	13	5-9
186036	CHANNEL,STRAP,SUPPORT	3	7-51	187252	PIPE,PNEUM,COOLING	12	5-9
186037	MTG,CAB,TILT CYL,FRONT	11	4-15	187272	FRAME,S/TNK,BON/CATCH,T3	1	7-51
186038	MTG,CAB,TILT CYL,REAR	10	4-15	187310	PIPE,BRAKE,M&R,L	15	3-157
186040	MTG,MK2,HYD BLOCK	2	7-51	187310	PIPE,BRAKE,L	16	3-121
186149	PIN,LOCATE,MIRROR	36	7-13	187311	PIPE,BRAKE,M&R,R	14	3-157
186221	PLT,R/CHASSIS,ELEC MTG	21	6-47	187311	PIPE,BRAKE,R	15	3-121
186229	PLT,GUIDE,ROD,BONNET	16	7-57	187315	BKT,PIPE,MAKE-UP	35	2A-81
186229	PLT,GUIDE,ROD,BONNET	36	7-53	187315	BKT,PIPE	36	2B-75
186299	MTG,PARK BRAKE,FIELD FIX	3	3-91	187318	CLAMP,2 ACCUMULATORS	2	4-35
186315	SHIM	35	7-13	187318	CLAMP,2 ACCUMULATORS	2	4-37
186316	SHIM	34	7-13	187319	CLAMP,2 ACCUMULATORS	3	4-39
186336	CARRIER,MAGNET,STRUT	11	7-83	187319	CLAMP,2 ACCUMULATORS	3	4-41
186347	PLT,GUIDE BONNET	8	7-61	187336	BKT,RUBBER CLAMP	23	7-49
186366	PLT,GUARD,LTBOX,BIN	8	7-97	187418	PIPE,INTERM,PNEUM,COOL	11	5-9
186366	PLT,GUARD,LTBOX,BIN	8	7-99	187424	MTG,HOOTER	13	6-33
186372	SHIM,PAD,REAR,BIN,B30D,MKII	7	7-97	187425	BKT,VENT PIPES	34	2A-81
186372	SHIM,PAD,REAR,BIN,B30D,MKII	7	7-99	187425	BKT,VENT PIPES	35	2B-75
186691	SHIM,BIN SUPPORT POLE	17	7-93	187428	PLT,BULKHEAD MTG,AXLE	13	3-157
186692	ASSY,BIN POLE	16	7-93	187452	MTG,PIPE,COMPRESSOR	14	7-63
186693	RUBBER,SUSP,CAVITY,LHS	15	7-93	187453	PLT,SEAL,RAD,RHS	13	7-63

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
187454	PLT,SEAL,RAD,LHS	12	7-63	200051	CLAMP,HOSE	10	2B-65
187471	PLT,STRETCH,TAILGATE,ARM,B30D	5	7-105	200061	CLAMP,HOSE	32	2A-81
187496	LINK,TOP,SPHERICAL	4	7-79	200061	CLAMP	33	2B-75
187497	LINK,BASE,SPHERICAL	3	7-79	200061	clamp,pipe	61	7-47
187502	PLT,RETAIN,HOSES,CAB,MID	24	4-3	200062	CLAMP,HOSE	4	3-79
187506	PLT,ADM	42	6-7	200062	CLAMP,HOSE	15	4-51
187531	COVER,PLT,FUEL SENDER	12	6-33	200062	CLAMP,HOSE	25	4-33
187533	PLT,MNT,BACKREST,SEAT,TRAINER	49	7-31	200085	CLAMP,HOSE	5	4-53
187538	TANK,FUEL,TIER3	6	7-71	200085	CLAMP,HOSE	9	7-83
187539	PLT,ELEC BULKHEAD MTG	19	6-47	200092	CLAMP,HOSE	31	2A-81
187541	PLT,DOOR OPEN LOCK	13	7-69	200092	CLAMP	32	2B-75
187559	PLT,MTG,BIN TIP LEVER	41	6-5	200093	CLEVIS	4	3-95
187632	HOUSING,BONNET CATCH	15	7-57	200318	MTG,BAND	2	5-17
187633	MTG,BONNET CATCH	14	7-57	200318	MOUNTING BAND	4	5-13
187634	LINKAGE,BONNET	13	7-57	200437	VALVE,JUMBO 63MM SWIVEL	8	3-189
187648	SPACER	7	6-27	200437	VALVE,JUMBO 63MM SWIVEL	8	3-191
187674	PLATE,SPACER,AXLE	8	7-95	200438	SPUD,TUBELESS	9	3-189
187688	LINK,BONNET CATCH	12	7-57	200438	SPUD,TUBELESS	9	3-191
187689	PEG,BONNET CATCH	7	7-61	200466	INFORMER	9	2A-71
187690	PLT,TONGUE,BONNET CATCH	11	7-57	200466	INFORMER	9	2B-65
187696	BKT,MTG,HOSES,CAB TILT	9	4-15	200499	TYRE,23.5R25,2*,MUD/SAND	2	3-189
187701	PLT,RETAINER,DEUTSCH PLUG	40	6-7	200641	ELBOW,90 DEG 6" EQUAL RUBBER	8	2A-71
187750	STEP,BOTTOM,M/GUARD	15	7-67	200641	ELBOW,90 DEG 6" EQUAL RUBBER	8	2B-65
187753	MUDGUARD,LHS	14	7-67	200653	CABLE TIE	3	6-45
187754	MUDGUARD,RHS	13	7-67	200653	CABLE TIE	10	6-15
187775	PLT,MTG,TRAY,E-MODULE	39	6-7	200653	CABLE TIE	11	6-33
187777	MTG,FILTER	14	3-159	200653	CABLE TIE	16	6-43
187777	MTG,FILTER	15	3-123	200653	CABLE TIE	17	6-47
187779	STEP,BOTTOM,M/GUARD	12	7-67	200653	CABLE TIE	22	7-49
187781	MTG,STEP,MID,M/GUARD	11	7-67	200653	CABLE TIE	24	4-33
187782	MTG,STEP,BOTT,M/GUARD	10	7-67	200742	HELLA, 7 WAY, TRAILER CONNECTOR WITH SOCKETS	89	6-59
187789	HANDRAIL,MUDGUARD,RHS	9	7-67				
187790	HANDRAIL,CAB,RHS,REAR	59	7-11	200779	TIE ROD,END,WITH CLIP	9	7-57
187796	BKT,FILTER,WDB COOLING	7	4-43	200779	TIE ROD,END,WITH CLIP	10	7-57
187885	PIN ASSY,FLOAT ARTIC	2	7-91	200779	TIE ROD,END	16	6-47
187891	MTG,RUBBER,CAB	30	7-11	200779	TIE ROD END	33	7-15
187957	LID,HYD TANK	41	7-85	200871	CABLE TIE	4	6-49
190141	WASHER,HEAT TREATED	22	3-187	200871	CABLE TIE	8	2A-73
190550	PLANET CARRIER	3	3-187	200871	CABLE TIE	8	2B-67
190685	ISOLATOR,VIBRATION,RUBBER	18	6-47	200871	CABLE TIE	9	7-43
190742	PLUG,HEX	10	7-83	200871	CABLE TIE	38	6-5
190859	WHEEL,3 PCE	3	3-189	200871	CABLE TIE	38	6-7
190903	WHEEL,3 PCE	3	3-191	200871	CABLE TIE	478	2A-45
190904	WHEEL,3 PCE	3	3-189	200871	CABLE TIE	478	2A-47
191032	FLANGE,7C,THRU DRIVE,FRONT	17	3-133	200871	CABLE TIE	478	2B-41
191032	FLANGE,7C,THRU DRIVE,FRONT	17	3-167	201194	BUSH,OSCILL.JOINT	8	3-117
191032	FLANGE,7C,THRU DRIVE	21	3-139	201212	CLAMP,EXHAUST,100MM	11	2A-67
191032	FLANGE	21	3-173	201212	CLAMP,EXHAUST,100MM	11	2B-61
191058	FLANGE,7C,THRU DRV SHAFT	14	3-121	201212	CLAMP,EXHAUST	12	2A-69
191070	FLANGE,7C,THRU DRV	14	3-123	201212	CLAMP,EXHAUST	12	2B-63
191074	HEATSHIELD,TURBO	12	2A-67	201375	PRESSURE SENDER, 0-10 BAR, SWITCH	10	5-7
191074	HEATSHIELD,TURBO	12	2B-61				
191074	HEATSHEILD (NOT PART OF ENGINE)	20	2B-31	201412	MAGNET:ULTRA-T TANK-CERAMIC	32	7-85
200033	CLAMP,HOSE	4	10-37	201419	P-CLIP	21	7-49
200033	CLAMP,HOSE	33	2A-81	201420	P CLIPS	11	3-101
200033	CLAMP	34	2B-75	201420	P-CLIP	11	3-111
200036	NIPPLE,GREASE	8	4-47	201420	P-CLIP	12	3-157
200036	NIPPLE,GREASE	9	3-117	201420	P-CLIP	13	3-119
200038	NIPPLE,GREASE	17	4-51	201420	P-CLIP	13	3-121
200050	CLAMP,HOSE	12	7-45	201420	P-CLIP	13	3-145
200050	CLAMP,HOSE	16	4-51	201420	P-CLIPS	13	3-155
200051	CLAMP,HOSE	10	2A-71	201420	P-CLIP	13	3-179

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
201428	VALVE,BLEED	3	3-185	203286	FLANGE,7C 315PL-120LG	6	3-117
201438	P-CLIP	6	4-43	203349	K-CLAMP	13	4-51
201439	P-CLIP	20	7-49	203375	PLATE,AXLE SERIAL NUMBER	9	3-101
201439	P-CLIP,18MM	30	2A-81	203375	PLT,AXLE SERIAL NUMBER	9	3-111
201439	P-CLIP,18MM	31	2B-75	203375	PLT,AXLE SERIAL NUMBER	10	3-157
201453	BULB,24V,4W	12	6-37	203375	PLT,AXLE SERIAL NUMBER	11	3-103
201497	CIRCLIP-OUTSIDE	16	3-133	203375	PLT,AXLE SERIAL NUMBER	11	3-119
201497	CIRCLIP-OUTSIDE	16	3-167	203375	PLT,AXLE SERIAL NUMBER	11	3-121
201497	CIRCLIP-OUTSIDE	20	3-139	203375	PLT,AXLE SERIAL NUMBER	11	3-145
201497	CIRCLIP-OUTSIDE	20	3-173	203375	PLATE,AXLE SERIAL NUMBER	11	3-155
201503	GASKET,CORK,DIESEL TANK	5	7-71	203375	PLT,AXLE SERIAL NUMBER	11	3-179
201509	LATCH,GASKET	8	7-53	203375	PLT,AXLE SERIAL NUMBER	13	3-123
201509	LATCH,GASKET	8	7-57	203375	PLT,AXLE SERIAL NUMBER	13	3-159
201509	LATCH,GASKET	12	7-69	203538	CLAMP,T-BOLT	29	2A-83
201509	LATCH,GASKET	32	7-15	203538	CLAMP	30	2B-77
201529	PLUG,CONNECTING	18	5-11	203588	CLAMP,HOSE	11	7-45
201529	HIRSCHMANN, 4 WAY, FLUSH, SOCKETS	77	6-57	203588	CLAMP,HOSE TO BREATHER PIPE	60	2A-35
				203588	CLAMP,HOSE COMP SUCTION PIPE	60	2A-35
201556	CONICAL BEARING,RUBBER	3	7-95	203588	CLAMP, HOSE COMP SUCTION PIPE	60	2B-31
201559	TYRE,750/65R25,XAD65,MICH	2	3-191	203588	CLAMP, SUCTION PIPE TO COMPRESSOR	75	2A-39
201650	CIRCLIP EXTERNAL	30	3-187				
201666	SPRING,BIN HEAT,BALL,JOINT	11	2A-69	203588	CLAMP, SUCTION PIPE TO COMPRESSOR	75	2B-35
201666	SPRING,BIN HEAT,BALL,JOINT	11	2B-63				
201666	SPRING	31	7-13	203588	CLAMP,PIPE TO CYLINDER HEAD COVER	125	2A-19
201667	SPRING,BIN HEAT,SUSP,PLT	10	2A-69				
201667	SPRING,BIN HEAT,SUSP,PLT	10	2B-63	203588	CLAMP,PIPE TO CYLINDER HEAD COVER	125	2B-15
201737	POINT,TEST,HYD	23	4-21				
201737	TEST POINT,6MOR	31	4-49	203588	CLAMP,Rubber Cap 20-32MM	280	2A-59
201819	REDUCER,STACK	7	2A-71	203588	CLAMP,Rubber Cap 20-32MM	280	2B-53
201819	REDUCER,STACK	7	2B-65	203680	P-CLIP	8	4-15
201873	POINT,TEST,HYD	1	10-31	203681	P-CLIP,50MM	6	3-77
201885	CLAMP,RUBBER	14	4-51	203681	P-CLIP,50MM	28	2A-81
201886	DECAL,PDI/QUALITY	23	7-107	203681	P-CLIP,50MM	29	2B-75
201926	CIRCLIP: INNER	19	3-187	203739	SPHERICAL BRG,2 BOLT	2	7-79
202043	DRIVER,RECTANGULAR	5	3-189	203764	P-CLIP	7	4-15
202043	DRIVER,RECTANGULAR	5	3-191	203764	P-CLIP	19	7-49
202094	GROMMET,FLAT SPLIT	37	6-7	203764	P-CLIP,25MM	26	2A-75
202346	AIRDUCT,FLEX	8	7-43	203764	P-CLIP,25MM	26	2B-69
202557	M24, 2 WAY, 90° BAYONET, SOCKETS	46	6-55	203764	P-CLIP,25MM	27	2A-81
202599	RING,SNAP	3	7-81	203764	P-CLIP,25MM	28	2B-75
202599	CIRCLIP,INTERNAL	4	4-53	203830	CIRCUIT BREAKER,20AMP	15	6-43
202599	CIRCLIP:INTERNAL	10	4-47	203895	RESERVOIR,AIR,5L CE MARK	3	5-13
202621	SEAL PLATE,B30 16T HUB	10	3-101	203896	RESEVOIR,AIR,10L	1	5-17
202621	PLT,SEAL	10	3-111	203908	P-CLIP	10	7-45
202621	PLT,SEAL,B30 16T HUB	11	3-157	203923	GROMMET	2	7-93
202621	PLT,SEAL	12	3-119	203923	GROMMET	3	5-5
202621	PLT,SEAL,B30 16T HUB	12	3-121	203923	GROMMET	6	4-15
202621	PLT,SEAL	12	3-145	203923	GROMMET	10	6-33
202621	SEAL PLATE,B30 16T HUB	12	3-155	203926	GROMMET	6	7-97
202621	PLT,SEAL	12	3-179	203926	GROMMET	6	7-99
202686	GRIP,PTC 25MM PIPE	3	7-93	203926	GROMMET	26	2A-81
202729	CIGARETTE LIGHTER	36	6-5	203926	GROMMET	27	2B-75
202860	BOWL,PRE-CLEANER	17	2A-71	203975	PROTECTOR,HOSE STRAP ON	18	7-49
202860	BOWL,PRE-CLEANER	17	2B-65	203990	NIPPLE,GREASE	4	7-105
202916	M27, 2 WAY, 90° BAYONET, SOCKETS	47	6-55	204035	CLAMP,SEALCLAMP	9	2A-69
202933	BULB,24V 70W H3 PK22S (PIGTAIL)	3	6-37	204035	CLAMP,SEALCLAMP	9	2B-63
202934	BULB,24V 75/70W H4 P43T HDLT	11	6-37	204035	CLAMP,SEALCLAMP	10	2A-67
202983	TYRE,23.5R25,XADN,MICH	2	3-189	204035	CLAMP,SEALCLAMP	10	2B-61
203264	GROMMET,BLANK	35	6-7	204042	SWITCH,BINARY PRESSURE	9	7-45
203266	GROMMET,BLANK	3	6-29	204043	RECEIVER DRIER	8	7-45
203266	GROMMET,BLANK	6	6-27	204110	BOOT,STEERING COLUMN	5	7-41
203285	FLANGE,8.C,315PL-121LG	7	3-117	204111	GUARD,TELESCOPIC	4	7-41

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
204112	SCREW,ADJUSTING HANDLE	3	7-41	206082	GAUGE,QUAD,PRESS	2	10-31
204113	NUT,ADJUSTING HANDLE	13	7-41	206249	DECAL,REFLECTOR,RED	47	7-109
204115	SPACER,SPLINED	7	7-41	206251	DECAL,GREASE POINT,BLK ON WHT	2	7-105
204122	RUBBER,PROG.BUMP STOP	7	7-53	206258	SWITCH,IGNITION	32	6-5
204122	RUBBER,PROG.BUMP STOP	7	7-55	206286	CLAMP,HOSE	7	7-83
204160	DISC,PARK BRAKE DX195	2	3-91	206287	BELLOW,RUBBER	6	7-83
204169	CLAMP,SEALING	30	4-49	206291	GROMMET	13	6-43
204170	BASE ASSY	17	7-41	206293	MTG,RUBBER,CAB	30	7-11
204187	AIRDUCT,FLEX	7	7-43	206301	ASSY,TOP SECT,B/HEATING	8	2A-69
204373	REFLECTOR,RED	5	7-97	206301	ASSY,TOP SECT,B/HEATING	8	2B-63
204373	REFLECTOR,RED	5	7-99	206303	ASSY,MID SECT,B/HEATING	7	2A-69
204374	REFLECTOR,AMBER	4	7-71	206303	ASSY,MID SECT,B/HEATING	7	2B-63
204374	REFLECTOR,AMBER	4	7-97	206305	ASSY,FLEX SWIVEL B/H	6	2A-69
204374	REFLECTOR,AMBER	4	7-99	206305	ASSY,FLEX SWIVEL B/H	6	2B-63
204374	REFLECTOR,AMBER,BOLT ON	8	7-67	206306	NUT,IGNITION SWITCH MTG	31	6-5
204374	REFLECTOR,AMBER,BOLT ON	11	7-69	206336	HARNESS	150	3-73
204438	CAP,STEERING WHEEL	10	7-41	206337	HARNESS	164	3-73
204457	CIRCLIP,OUTSIDE	29	3-187	206345	SELECTOR,SHIFT	4	6-13
204483	MTG,T/BOX SPLIT	3	3-79	206345	SELECTOR,SHIFT	120	3-73
204541	MTG,RUBBER CIRCULAR	23	4-3	206345	SELECTOR,SHIFT	120	3-75
204600	WHEEL,STEERING	9	7-41	206350	FUSE,10A,BLADE TYPE	1	6-9
204600	STEERING WHEEL	48	7-39	206353	CLAMP,CHARGE-AIR PIPE ON HOUSING	330	2A-35
204668	CLAMP,STACK-AIR INTAKE PIPE	6	2A-71				
204668	CLAMP,STACK-AIR INTAKE PIPE	6	2B-65	206353	CLAMP, CHARGE-AIR PIPE ON HOUSING	430	2B-31
204708	PLT,PERFORATED,GRILL	11	7-63				
204710	BULB,HEAVY DUTY 24V/22W/BA15S	13	6-37	206364	LINK,DRAG,B25D	2	7-95
205259	CIRCUIT BREAKER,60AMP	14	6-43	206373	GASKET,HYD TANK	29	7-85
205422	SUPPORT	2	7-41	206387	SWITCH, PRESSURE, (NC), 5 BAR	8	5-7
205423	SHAFT	22	7-41	206412	DOOR,HVAC,YELLOW D#	29	7-21
205424	NUT	23	7-41	206415	HINGE,EXTERIOR	10	7-69
205425	SHAFT,SPLINED	24	7-41	206415	HINGE,EXTERIOR	28	7-15
205427	BOLT,STEPPED	11	7-41	206415	HINGE,EXTERIOR	28	7-21
205428	SPACER	12	7-41	206418	WINDOW,CURVED	27	7-17
205429	SHAFT,STEERING	6	7-41	206437	HEXSERT	47	7-25
206050	CROSS & ROLLER,7C LOW MAINT		8-5	206437	HEXSERT	47	7-31
206050	CROSS & ROLLER,7C, LOW MAINT	18	3-99	206439	HANDLE,CAB INTERIOR	6	7-53
206065	E-MODULE,ADM	34	6-7	206439	HANDLE,CAB INTERIOR	6	7-55
206070	THROTTLE,FOOT ACTUATOR	33	6-5	206439	HANDLE,CAB INTERIOR	46	7-23
206071	SHOCK MAT,B30D BIN	3	7-97	206441	HINGE,INTERIOR	45	7-23
206071	SHOCK MAT,B30D BIN	3	7-99	206442	LATCH,COOLBOX	44	7-23
206071	SHOCK MAT	3	7-105	206444	RUBBER,LATCH,COOLBOX	43	7-23
206071	SHOCK MAT	5	3-117	206447	PLATE,STEP	42	7-27
206071	SHOCK MAT,B30D BIN	5	7-77	206449	SUN VISOR	41	7-29
206071	SHOCK MAT	10	3-119	206451	BKT,STRAP,DOOR	26	7-15
206071	SHOCK MAT	10	3-145	206453	RUBBER,STRAP,DOOR	25	7-15
206071	SHOCK MAT	10	3-155	206454	ASHTRAY,TOP MNT,PLASTIC	40	7-25
206071	SHOCK MAT	10	3-179	206465	STRUT,CAB	24	7-15
206071	SHOCK MAT	30	3-159	206467	CLIP,P-CLIP,WITH BOLT	28	4-49
206071	SHOCK MAT	34	3-123	206480	ISOLATOR,STEERING ORBITAL	22	4-3
206071	SHOCK MAT	40	3-157	206489	PIPE,AIR INTAKE	5	2A-71
206071	SHOCK MAT	44	3-121	206489	PIPE,AIR INTAKE	5	2B-65
206073	LINK,DRAG,B30D	2	7-95	206491	STRUT,CAB,4044	23	7-21
206074	SPHERICAL BRG,2 BOLT	1	7-79	206494	COVER,HEADLIGHT,LHS	1	7-75
206074	SPHERICAL BRG,2 BOLT	1	7-81	206494	COVER,HEADLIGHT,LHS	9	7-69
206074	SPHERICAL BRG	2	4-53	206495	COVER,HEADLIGHT,RHS	1	7-75
206074	SPHERICAL BRG,2 BOLT	8	7-83	206495	COVER,HEADLIGHT,RHS	3	7-71
206074	BEARING,2 BOLT	9	4-47	206523	MTG,RUBBER	25	2A-83
206075	SPACER,SPHERICAL BRG	2	7-81	206523	MTG,RUBBER	26	2B-77
206075	SPACER,SPHERICAL BRG	3	4-53	206585	HEXSERT,OPEN	7	7-45
206075	SPACER,SPHERICAL BRG	11	4-47	206585	HEXSERT	39	7-23
206079	MUDFLAP,BIN MOUNTED,B30D	2	7-97	206585	HEXSERT	39	7-25
206079	MUDFLAP,BIN MOUNTED,B30D	2	7-99	206585	HEXSERT	39	7-29

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
206597	RING GEAR MKII	7	3-187
206616	ELEMENT,FILTER,10MICRON		8-5
206636	EXHAUST,H/SHIELD MID	9	2A-67
206636	EXHAUST,H/SHIELD MID	9	2B-61
206658	CLAMP,ALU,2 BOLT	22	4-33
206690	DT DEUTSCH, 3 WAY, PLUG, SOCKETS	55	6-55
206703	CONNECTOR,2-WAY DEUTSCH,MALE	4	6-37
206703	DT DEUTSCH, 2 WAY, RECEPTACLE, PINS	40	6-53
206704	DT DEUTSCH, 2 WAY, PLUG, SOCKETS	41	6-55
206705	DT DEUTSCH, 3 WAY, RECEPTACLE, PINS	57	6-55
206706	DT DEUTSCH, 4 WAY, RECEPTACLE, PINS	71	6-57
206707	DT DEUTSCH, 4 WAY, PLUG, SOCKETS	72	6-57
206708	DT DEUTSCH, 6 WAY, RECEPTACLE, PINS	85	6-59
206709	DT DEUTSCH, 6 WAY, PLUG, SOCKETS	86	6-59
206711	DT DEUTSCH, 8 WAY, RECEPTACLE, PINS	91	6-59
206712	DT DEUTSCH, 8 WAY, PLUG, SOCKETS	92	6-59
206713	HDP DEUTSCH, 21 WAY, PLUG, SOCKETS	125	6-63
206717	HDP DEUTSCH, 31 WAY, RECEPTACLE, PINS	136	6-63
206718	HDP DEUTSCH, 31 WAY, PLUG, SOCKETS	137	6-63
206719	HDP DEUTSCH, 9 WAY, RECEPTACLE, PINS	102	6-61
206720	HDP DEUTSCH, 9 WAY, PLUG, SOCKETS	103	6-61
206722	BOSCH, 4 WAY, PLUG, SOCKETS	69	6-57
206724	BOSCH, 8 WAY, PLUG, SOCKETS	90	6-59
206726	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS	30	6-53
206729	DELPHI PACKARD, 6 WAY, PLUG, SOCKETS	84	6-59
206735	UTILUX, 2 WAY, PLUG, SOCKETS	49	6-55
206765	CROSS & ROLLER,LUBE-FOR-LIFE		8-5
206765	CROSS & ROLLER,LUBE-FOR-LIFE	2	3-97
206765	CROSS & ROLLER,LUBE-FOR-LIFE	2	3-99
206765	CROSS & ROLLER,LUBE-FOR-LIFE	10	3-97
206765	CROSS & ROLLER,LUBE-FOR-LIFE	10	3-99
206767	STRAP,STEP RUBBER CONNECTOR	7	7-67
206777	UTILUX, 3 WAY, PLUG, SOCKETS	64	6-57
206778	BOSCH, 1 WAY, PLUG, SOCKETS	4	6-51
206787	CAP,FILLER,HYDRAULIC	27	7-85
206825	CLAMP,RUBBER,15,UNDER CAB	21	4-3
206825	CLAMP,RUBBER,15,UNDER CAB	21	4-5
206826	CLAMP,ALU,2 BOLT	20	4-3
206826	CLAMP,ALU,2 BOLT	20	4-5
206827	CLAMP,ALU,4 BOLT	19	4-3
206827	CLAMP,ALU,4 BOLT	19	4-5
206829	SPACER,CLAMP,ALUM	17	7-49
206829	SPACER,CLAMP,ALUM	18	4-3
206829	SPACER,CLAMP,ALUM	18	4-5
206829	SPACER,CLAMP,ALUM	21	4-33
206939	MOUNTING PIPE	3	6-21
206940	LIGHT,INTERIOR	30	6-5
206945	MTG,RUBBER	2	6-45
206945	MTG,RUBBER	4	3-117
206945	MTG,RUBBER	7	2A-75
206945	MTG,RUBBER	7	2B-69
206945	MTG,RUBBER	9	6-15
206945	MTG,RUBBER	9	6-33
206945	MTG,RUBBER	11	7-43
206945	MTG,RUBBER	12	4-51
206945	MTG,RUBBER	12	6-43
206945	MTG,RUBBER	15	6-47
206945	MTG,RUBBER	16	7-49
206945	MTG,RUBBER	20	4-33
206945	MTG,RUBBER	29	6-7
206956	SIDE SHAFT,DK7,1289LG	9	3-145
206957	SIDE SHAFT,DK7,1170LG	8	3-145
206958	SIDE SHAFT,ZF DK,1261LG	8	3-111
206958	SIDE SHAFT,ZF DK,1261LG	9	3-179
206959	SIDE SHAFT,ZF DK,1191LG	7	3-111
206959	SIDE SHAFT,ZF DK,1191LG	8	3-179
206979	CONDENSER,AIR-CON	15	7-49
207017	CLAMP,ALUM,2 BOLT	5	3-77
207017	CLAMP,ALUM,2 BOLT	14	7-49
207018	CLAMP,ALUM,4 BOLT	13	7-49
207021	SENSOR,BIN PIVOT,ROTARY	14	6-47
207027	DIODE,3A,SPADE TERMINAL	6	6-9
207030	LIGHT,WORK LIGHT,2-WAY DEUTSCH	1	6-37
207030	LIGHT,WORK LIGHT	3	6-23
207030	LIGHT,WORK LIGHT	4	6-23
207031	SWITCH	8	6-15
207043	CLAMP,ALU,2 BOLT	12	7-49
207044	CLAMP,ALU,4 BOLT	11	7-49
207080	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS	31	6-53
207092	CLAMP,RUBBER,4,TRAN HOSES	4	3-77
207114	FUSE,30A,BLADE TYPE	2	6-9
207115	FUSE,25A,BLADE TYPE	3	6-9
207116	FUSE,20A,BLADE TYPE	4	6-9
207117	P-CLIP	6	7-45
207117	P-CLIP	19	4-33
207118	FUSE,15A,BLADE TYPE	5	6-9
207123	SPACER,CLAMP,ALU	3	3-77
207124	CLAMP,RUBBER	18	4-33
207175	ASSY,DRAIN TUBE,HVAC	6	7-43
207177	AIR HOSE ADAPTER,2"	22	7-47
207178	AIR HOSE ADAPTER	21	7-47
207191	DECAL,DEERE,OVERHEAD POWER-LINE	18	7-107
207192	DECAL,DEERE,SEATBELT,WARNING	19	7-107
207205	DECAL,TORQUE BINPROP BOLT	28	7-107
207206	HANDLE,PADDLE,BATT BOX	8	7-69
207213	MTG,RUBBER,CONDENSER,HVAC	10	7-49
207219	SPRING,CABSTRUT	5	4-15
207230	TRIMARK,LH HOUSING	22	7-15
207231	SUPPORT,POSITION SENSOR SHAFT	13	6-47
207251	HOSE,PROTECT,SPIRAL GUARD	17	4-33
207252	HOSE PROTECT,SPIRAL GUARD,75ID	26	4-49
207253	HOSE,PROTECT,SPIRAL GRD	17	4-3
207266	HEXSERT,OPEN	38	7-27
207266	HEXSERT	38	7-29
207273	DT DEUTSCH, 12 WAY, RECEPTACLE, PINS	108	6-61
207274	DT DEUTSCH, 12 WAY, PLUG, SOCKETS	109	6-61
207277	DECAL,PARK BRAKE,APPLICATION	20	7-107
207281	SHAFT,POSITION SENSOR ARM	12	6-47

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
207283	PIPE,SUCTION,HYD PUMP,B25D	25	4-49	207496	CLAMP,EXHAUST	6	2A-67
207288	MTG,BONDED	3	6-13	207496	CLAMP,EXHAUST	6	2B-61
207288	MTG,SWIVEL HEAD	28	6-3	207498	AMP, 9 WAY, RECEPTACLE, PINS	97	6-59
207289	O-RING	11	6-47	207499	AMP, 12 WAY, PLUG, SOCKETS	107	6-61
207290	DECAL,DEERE,LIFT/TIEDOWN PNT	5	7-107	207500	AMP, 15 WAY, PLUG, SOCKETS	115	6-61
207291	DECAL,GREASE,OSCIL/R-BRG 500HD	51	7-109	207501	AMP, 18 WAY, PLUG, SOCKETS	121	6-63
207304	DECAL,TIE DOWN POINT	46	7-109	207502	AMP, 21 WAY, PLUG, SOCKETS	123	6-63
207306	DECAL,WARNING EATHER,START	6	7-107	207504	HIRSCHMANN, 4 WAY, FLUSH, SOCKETS	78	6-57
207307	DECAL,WARNING READ OMM	21	7-107				
207310	DECAL,LIFTING EYE	39	7-109	207505	GROENEVELD, 8 WAY, PLUG, SOCKETS	94	6-59
207311	DECAL,BELL LOGO,CAB DOOR	22	7-107				
207312	DECAL,B&W BELL LOGO,FR BONNET	10	7-107	207520	MUDFLAP,MUDGUARD STUT	6	7-67
207329	DECAL,HYDRAULIC PRESSURE	17	7-107	207521	MUDFLAP,MUDGUARD	5	7-67
207330	DECAL,PROPSHAFT GUARDS	11	7-107	207524	DELPHI PACKARD, 3 WAY, PLUG, PINS	52	6-55
207331	DECAL,RADIATOR FAN WARNING	12	7-107	207606	GASSTRUT,BONNET	6	7-59
207336	DECAL,ARTICULATION CRUSH	50	7-109	207626	PLUG,MAGNETIC	5	3-145
207337	DECAL,VISIBILITY WARNING	29	7-109	207626	PLUG,MAGNETIC	5	3-179
207338	DECAL,PARK BRAKE WARNING	28	7-109	207626	PLUG,MAGNETIC	6	3-111
207338	DECAL,PARK BRAKE WARNING	48	7-109	207626	PLUG,MAGNETIC	8	3-101
207339	DECAL,PASSENGER SEAT	4	7-107	207626	PLUG,MAGNETIC	9	3-119
207340	DECAL,SUSPENSION CYLINDER	3	7-107	207626	PLUG,MAGNETIC	9	3-155
207340	DECAL,SUSPENSION CYLINDER	5	7-83	207626	PLUG,MAGNETIC	9	3-157
207345	DECAL,B&W,B25D	9	7-107	207626	PLUG,MAGNETIC	10	3-103
207346	DECAL,B&W,B30D	8	7-107	207626	PLUG,MAGNETIC	10	3-121
207349	DECAL,COMPRESSED AIR	7	7-107	207626	PLUG,MAGNETIC	12	3-123
207350	DECAL,SPRING PRESSURE	27	7-109	207626	PLUG,MAGNETIC	12	3-159
207350	DECAL,SPRING PRESSURE	38	7-109	207637	COVER,DUST,SEALED BEARING	11	4-51
207351	DECAL,BIN SUPPORT	54	7-109	207646	MTG,RUBBER,T/MISSION,SPLT	3	3-3
207360	ASSY,CHAIN,AUTOGATE,B25D#	1	7-105	207646	MTG,RUBBER,T/MISSION,SPLT	3	3-5
207366	LATCH,LH	7	7-69	207646	MTG,RUBBER,T/MISSION,SPLT	5	2A-3
207366	LATCH,LH,TRI/MARK	21	7-15	207646	MTG,RUBBER,T/MISSION,SPLT	5	2A-5
207367	PLT,TOP,RHS,CALIPER GUARD	7	3-145	207646	MTG,RUBBER	5	2B-3
207367	PLT,TOP,RHS,CALIPER GUARD	7	3-179	207647	KNOB,BIN TIP	19	7-15
207368	PLT,BOT,CALIPER GUARD	6	3-145	207648	CHAIN,ASSY,AUTOGATE,30D#	1	7-105
207368	PLT,BOT,CALIPER GUARD	6	3-179	207660	PLUG	4	3-145
207373	MTG,BKT,B/HEATING	5	2A-69	207660	PLUG	4	3-179
207373	MTG,BKT,B/HEATING	5	2B-63	207660	PLUG	5	3-111
207374	MTG,PLT,LOWER B/HEATING	4	2A-69	207660	PLUG	7	3-101
207374	MTG,PLT,LOWER B/HEATING	4	2B-63	207660	PLUG	8	3-119
207375	BOLT,STRIKER	6	7-69	207660	PLUG	8	3-155
207375	BOLT,STRIKER,TRIMARK	20	7-15	207660	PLUG	8	3-157
207380	DECAL,GREASE,500HRS,BIN PIVOT	53	7-109	207660	PLUG	9	3-103
207381	DECAL,REFRIGERANT	49	7-109	207660	PLUG	9	3-121
207382	DECAL,CAB TILT	16	7-107	207660	PLUG	11	3-123
207385	DECAL,SHIFT INHIB./PARK BRAKE	32	7-109	207660	PLUG	11	3-159
207390	SENDER,TEMP	4	6-41	207662	CONDUIT,265MM	5	6-15
207408	DECAL,STARTER MOTOR	13	7-107	207676	PLUG,MAGNETIC	4	7-83
207409	DECAL,BIN TIP	34	7-109	207676	PLUG,MAGNETIC	16	3-187
207410	DECAL,GREASE,500HRS,ARTIC	42	7-109	207693	FILTER,UNIT,FUEL-WATER	1	2A-77
207411	DECAL,EMERGENCY EXIT	35	7-109	207693	FILTER,UNIT,FUEL-WATER	1	2B-71
207412	DECAL,PARK BRAKE	36	7-109	207693	ASSY,FUEL FILTER	6	2A-75
207440	SHAFT,ROTARY SENSOR	10	6-47	207693	ASSY,FUEL FILTER	6	2B-69
207445	E-CLIP	9	6-47	207694	ELEMENT,FILTER,10MICRON		8-3
207453	CONDUIT,670MM	6	6-15	207694	ELEMENT,FILTER,10MICRON		8-3
207453	CONDUIT,670MM	7	6-15	207694	ELEMENT,FILTER,10MICRON		8-3
207454	CONDUIT,584MM	2	6-23	207694	ELEMENT,FILTER,10MICRON		8-3
207473	HDP DEUTSCH, 31 WAY, RECEPTACLE, SOCKETS	138	6-63	207694	ELEMENT,FILTER,10MICRON		8-5
				207694	ELEMENT,FILTER,10MICRON		8-5
207475	AMP, 4 WAY, BAYONET, PLUG, SOCKETS	66	6-57	207694	ELEMENT,FILTER,10MICRON		8-5
				207694	ELEMENT,FILTER	2	2A-77
207476	AMP, 14 WAY, PLUG, SOCKETS	111	6-61	207694	ELEMENT,FILTER	2	2B-71
207477	AMP, 15 WAY, PLUG, SOCKETS	114	6-61	207787	COLUMN,BASE,STEER ORBITAL	28	7-41

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
207788	SPACER,STEER PLASTIC	**16**	4-31	208033	GUARD,CAL.BOT	**6**	3-157
207795	SPRING,ARTIC HOSES	**24**	7-85	208033	GUARD,CAL.BOT,NARROW	**7**	3-121
207799	SEAL,BONNET/CAB INTERFACE	**18**	7-7	208041	GROTE & HARTMANN, 1 WAY, PUSH ON TERMINAL	**5**	6-51
207823	DECAL,CAB SUPPORT	**52**	7-109				
207829	HELLERMANN TYTON, 1 WAY, BOOT-LACE TERMINAL	**25**	6-53	208042	GUIDE,TAPE,PISTON PTFE,STRUT	**3**	7-83
				208043	SEAL,LASTO 'D',FRONT,CAB	**15**	7-9
207830	GROTE & HARTMANN, 5 WAY, PLUG, SOCKETS	**80**	6-57	208044	SEAL,LASTO 'D',SIDE,CAB	**14**	7-9
				208046	DECAL,CAB SUPPORT	**14**	7-107
207831	COVER,HEAD LIGHTS,GRILL	**1**	6-39	208068	SLING,HOSE	**21**	7-85
207832	COVER,HEAD LIGHTS,FRAME	**8**	6-33	208072	STRAP,BONNET	**5**	7-59
207853	ASSY,HOSE,HVAC,F/WAL,COMP	**9**	7-49	208073	DECAL,GREASE,500HRS,STR,CYL	**45**	7-109
207860	RUBBER,SEAL,BONNET	**5**	7-53	208085	BLANK,MIRROR SWITCH	**34**	7-25
207861	PLT,RUBBER,BONNET SEAL	**4**	7-53	208103	GASKET,5X5 ROLL STOCK	**13**	7-15
207861	PLT,RUBBER,BONNET SEAL	**5**	7-55	208103	GASKET	**13**	7-17
207863	GASKET,LOWER MIRROR BKT	**17**	7-13	208104	GASKET	**5**	7-5
207864	GASKET,ELECTRICAL HATCH	**37**	7-25	208158	COVER,PLUG,COLUMN SWITCH	**27**	6-5
207865	GASKET,ORBITAL	**16**	4-3	208200	GUARD,CAL,TOP,LHS	**4**	3-101
207871	ROOF,CAB,YELLOW	**2**	7-5	208202	GUARD,CAL,TOP,RHS	**4**	3-111
207879	STRAP,COAT	**36**	7-23	208204	GUARD,CAL,TOP,REAR	**4**	3-101
207881	GASKET,GRAB HANDLE	**16**	7-11	208348	AMP, 6 WAY, PLUG, SOCKETS	**81**	6-59
207897	DECAL,CAB,L/PUMP LEVER	**15**	7-107	208397	SEAL,DUO-CONE	**6**	3-103
207900	DECAL,SOUND PRESSURE	**25**	7-107	208397	SEAL,DUO-CONE	**10**	3-123
207908	CLAMP,RUBBER,10,F/WALL	**8**	7-49	208397	SEAL,DUO-CONE	**10**	3-159
207967	BOOT,RUBBER,DRAIN VALVE	**4**	2A-3	208439	AMP, 42 WAY, PLUG, SOCKETS	**148**	6-65
207967	BOOT,RUBBER,DRAIN VALVE	**4**	2A-5	208468	MOLEX, 4 WAY, PLUG, SOCKETS	**79**	6-57
207967	BOOT,RUBBER	**4**	2B-3	208495	AMP, 6 WAY, IQAN, PLUG, SOCKETS	**82**	6-59
207967	BOOT, RUBBER, DRAIN VALVE	**23**	7-85	208580	AMP, 2 WAY, PLUG, SOCKETS	**27**	6-53
207968	COVER,SPEAKER	**35**	7-23	208614	DUAL LOCK,3M	**5**	6-27
207975	ALARM,BACK UP-PRECO	**8**	6-47	208614	DUAL LOCK	**33**	7-27
207981	ELEMENT,HEATER,FUEL	**1**	6-35	208649	CAP,DIESEL FILLER	**1**	7-73
207988	SPRING,ARTIC HOSE	**22**	7-85	208649	CAP,DIESEL FILLER	**2**	7-71
207990	CROSS & ROLLER,LUBE-FOR-LIFE		8-5	208770	DEFLECTOR,DUST COVER,YOKE	**3**	3-117
207990	CROSS & ROLLER,LUBE-FOR-LIFE		8-5	208771	GROMMET	**1**	7-93
207990	CROSS & ROLLER,LUBE-FOR-LIFE	**5**	3-97	208771	GROMMET	**26**	6-7
207990	CROSS & ROLLER,LUBE-FOR-LIFE	**5**	3-99	208821	CLAMP,T-BOLT	**24**	2A-81
207990	CROSS & ROLLER,LUBE-FOR-LIFE	**15**	3-97	208821	CLAMP,T-BOLT	**25**	2B-75
207990	CROSS & ROLLER,LUBE-FOR-LIFE	**15**	3-99	208822	CLAMP,T-BOLT	**20**	4-49
207990	CROSS & ROLLER,LUBE-FOR-LIFE	**18**	3-97	208823	CLAMP,T-BOLT	**19**	4-49
207990	CROSS & ROLLER,7C LUBE-FOR-LIFE	**18**	3-99	208823	CLAMP	**24**	2B-77
207995	DECAL,HYDRAULIC TEST POINTS	**44**	7-109	208824	CLAMP,T-BOLT	**23**	2A-83
208000	AMP, 4 WAY, PLUG, SOCKETS	**67**	6-57	208824	CLAMP	**23**	2B-77
208001	AMP, 4 WAY, PLUG, SOCKETS	**68**	6-57	208828	CLAMP,T-BOLT	**4**	2A-71
208002	ZF, 24 WAY, PLUG, SOCKETS	**135**	6-63	208828	CLAMP,T-BOLT	**4**	2B-65
208008	HDP DEUTSCH, 14 WAY, PLUG, SOCK-ETS	**113**	6-61	208880	HD DEUTSCH, 9 WAY, RECEPTACLE, SOCKETS	**101**	6-61
208009	AMP, 68 WAY, PLUG, SOCKETS	**150**	6-65	210067	HORN,AIR,TWIN	**2**	5-5
208010	SIDE SHAFT	**6**	3-101	210105	LEVEL,INDICATOR	**18**	7-85
208010	SIDE SHAFT,HK,1349,5LG	**7**	3-155	210244	PISTON,ACCUM	**1**	4-37
208010	SIDE SHAFT,HK,1349,5LG	**8**	3-103	210247	VALVE,STEERING	**15**	4-3
208011	SIDE SHAFT	**5**	3-101	210247	VALVE,STEERING,#20,985CC	**A**	4-9
208011	SIDE SHAFT,HK,1269,5LG	**6**	3-155	210250	ACCUM,PISTON,CRIMPED	**2**	4-41
208011	SIDE SHAFT,HK,1269,5LG	**7**	3-103	210492	PUMP,#31 A10VO74 SERVICE	**15**	4-33
208012	SIDE SHAFT,DK-7,1374LG	**7**	3-119	210492	PUMP,#31 A10VO74 SERVICE,D#ADT	**A**	4-45
208013	SIDE SHAFT,DK-7,1255LG	**6**	3-119	210493	PUMP,EMERGENCY STEERING	**1**	4-13
208028	GUARD,CAL.TOP,RHS,WIDE	**5**	3-155	210493	PUMP,#52 A10VO28 E/STEER	**14**	4-33
208030	GUARD,CAL.BOT.WIDE	**4**	3-155	210497	STRAINER,125 MICRON,350L/MIN		8-5
208031	GUARD,CAL.TOP	**5**	3-119	210497	STRAINER,125 MICRON,350L/MIN		8-5
208031	GUARD,CAL.TOP,LHS,NARROW	**5**	3-155	210497	STRAINER,125 MICRON,350L/MIN	**17**	7-85
208031	GUARD,CAL.TOP,LHS	**7**	3-157	210547	VALVE,PURGE TANK	**1**	5-11
208031	GUARD,CAL.TOP,LHS,NARROW	**8**	3-121	210547	VALVE,PURGE TANK	**10**	5-9
208033	GUARD,CAL.BOT	**4**	3-119	210561	VALVE,UNLOADER,AIR DRYER	**1**	5-15
208033	GUARD,CAL.BOT,NARROW	**4**	3-155	210561	VALVE,UNLOADER,AIR DRIER	**2**	5-13

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
210695	VALVE,CYL SUSPSTRUT	2	7-83
210696	CAP,VALVE CYL SUSPSTRUT	1	7-83
210731	MANIFOLD, TYRE TOWER INFLATOR	13	5-7
210771	VALVE,RELIEF,DIESEL CAP,5PSI	3	7-73
210772	VALVE,RELIEF,DIESEL CAP,1PSI	4	7-73
210791	VALVE,CHECK,EMERGENCY STEERING	1	4-11
210791	VALVE,CHECK,E/STEER	13	4-33
210833	VALVE, SOLENOID	2	5-7
210862	ASSY,FILTER,FINN,5MICRON	1	7-87
210862	ASSY,FILTER,FINN,5MICRON	16	7-85
210895	VALVE,NON RETURN	2	6-11
210896	MOTOR,WIPER	7	6-11
210905	SOLENOID, PILOT VALVE, 24V	6	5-7
210907	VOAC BLOCK	1	4-25
210907	VOAC BLOCK	1	4-27
210907	VALVE,MANIFOLD	12	4-21
210920	PUMP,MANUAL,TANK CAP	1	4-19
210920	PUMP,MANUAL,TANK CAP	4	4-15
210923	ACCUM,PISTON,CRIMPED	1	4-35
210923	ACCUM,PISTON,CRIMPED	2	4-39
210947	BRAKE PEDAL,MICO,120/120 BAR	1	4-7
210947	PEDAL,BRAKE	14	4-5
210956	PUMP,#26 EATON GEAR	19	3-139
210956	PUMP	19	3-173
210959	PUMP,CASSAPA GEAR	5	4-43
210963	FILTER,HYD	4	4-43
210963	FILTER,HYD,10 MIC	9	3-123
210963	FILTER,HYD	9	3-159
210984	VALVE,CHECK	5	3-103
214065	FAN, SUCKER, DIA 725	5	2B-55
214106	TM OIL COOLER	11	2B-79
214107	FRAME,TOP	10	2B-79
214108	FRAME,BOT	9	2B-79
214109	BRACE	8	2B-79
214158	GUARD,FAN,LHS	22	2A-83
214158	GUARD,FAN,LHS	22	2B-77
214159	GUARD,FAN,RHS	21	2A-83
214159	GUARD,FAN,RHS	21	2B-77
214261	STACK,BIN HEATING	3	2B-63
216001	MIRROR,ELECTRICAL,24V	1	6-19
216001	MIRROR,ELECTRIC	4	6-15
216002	MIRROR,WIDE	2	6-17
216002	MIRROR,WIDE	3	6-15
216002	MIRROR,WIDE ANGLE	7	6-19
216002	MIRROR,WIDE	12	7-13
216003	MIRROR,MANUAL	1	6-17
216003	MIRROR,MANUAL	1	6-19
216003	MIRROR,MANUAL	11	7-13
216004	PANEL,INTERIOR,MAIN DOOR	32	7-23
216011	PIPE,SUCTION	20	2A-81
216011	PIPE,SUCTION	20	2B-75
216014	HOSE,SURGE TNK OUTLET	19	2A-81
216014	HOSE,SURGE TNK OUTLET	19	2B-75
216015	HOSE,MAKE-UP	18	2A-81
216015	HOSE,MAKE-UP LINE	18	2B-75
216016	PIPE,MAKE-UP	17	2A-81
216016	PIPE,MAKE-UP LINE	17	2B-75
216017	BUZZER	25	6-5
216027	LAMP,LED,INDICATOR,REAR	7	6-47
216028	LAMP,LED,BRAKE/PARK,REAR	6	6-47
216035	CLAMP,RETAINER	16	2A-83
216035	CLAMP,RETAINER	16	2B-77
216037	SOCKET,12V,ACCESSORY	24	6-5
216039	HAMMER,EMERGENCY EXIT	31	7-23
216042	EXHAUST,MUFFLER	5	2A-67
216042	EXHAUST,MUFFLER	5	2B-61
216045	COWLING,RAD	15	2A-83
216045	COWLING,RAD	15	2B-77
216046	FRAME,LEFT	7	2B-79
216046	FRAME,COOLING PACKAGE,LEFT	8	2A-85
216047	FRAME,RIGHT	6	2B-79
216047	FRAME,COOLING PACKAGE,RIGHT	7	2A-85
216048	FRAME,COOLING PACKAGE,TOP	6	2A-85
216049	FRAME,COOLING PACKAGE,BOT	5	2A-85
216059	BRACE,COOLING PACKAGE	4	2A-85
216060	SEAL,TOP,BONNET	10	7-63
216062	SEAL,SIDE,BONNET	9	7-63
216063	SEAL,BOTTOM,RAD	8	7-63
216064	CABLE,BATTERY,RED	11	6-43
216065	DECAL,CB'S&IGN SOL	2	7-107
216071	HDP DEUTSCH, 21 WAY, PLUG, SOCKETS, 90°	126	6-63
216074	AFL AUTOMOTIVE, 80 WAY, PLUG, SOCKETS	151	6-65
216076	AFL AUTOMOTIVE, 20 WAY, PLUG, SOCKETS	122	6-63
216077	DELPHI PACKARD, 16 WAY, PLUG, SOCKETS	118	6-61
216080	CINCH, 48 WAY, PLUG, SOCKETS	149	6-65
216081	CINCH BL, 32 WAY, PLUG, SOCKETS	143	6-65
216082	CINCH BN, 32 WAY, PLUG, SOCKETS	144	6-65
216083	DELPHI PACKARD, 16 WAY, PLUG, SOCKETS	119	6-61
216084	DELPHI PACKARD, 14 WAY, PLUG, SOCKETS	112	6-61
216085	HARNESS,SAT MODULE,PIGTAIL	2	6-29
216088	SWITCH,STEERING COLUMN	23	6-5
216091	HDP DEUTSCH, 31 WAY, PLUG, PINS	139	6-63
216095	HDP DEUTSCH, 31 WAY, RECEPTACLE, SOCKETS	140	6-63
216096	HDP DEUTSCH, 31 WAY, PLUG, PINS, 90 DEGREE	141	6-65
216097	TANK,SURGE	14	2A-81
216097	SURGE TANK,8L,PLASTIC	14	2B-75
216128	CLAMP,T-BOLT	13	2A-83
216128	CLAMP,T-BOLT	13	2B-77
216129	SWITCH,BATTERY DISCONNECT	10	6-43
216167	E-MODULE,SSM	22	6-5
216168	E-MODULE,MDU2	21	6-5
216197	COVER,A PILLAR,LHS	30	7-27
216199	GEAR,PINION SHAFT	18	3-139
216199	GEAR,PINION SHAFT	18	3-173
216200	SET,CW&PINION	17	3-139
216200	SET,CW&PINION	17	3-173
216214	COVER,A PILLAR,RHS	29	7-27
216216	HVAC UNIT	5	7-43
216216	hvac UNIT,24V	A	7-47
216217	HORN	7	6-33
216220	HARNESS	2	6-13
216221	HARNESS,CAB	20	6-3
216222	HARNESS,ARTIC JUMP	5	6-47
216231	SEAL,TOP,RAD	7	7-63
216232	HOODLINER,REAR	28	7-29

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
216233	HOODLINER,FRONT	27	7-29
216234	MAT,FLOOR,CAB	26	7-27
216235	PANEL,MDU	25	7-25
216236	VENT,BOX,COOLER	4	7-43
216237	COVER,B PILLAR,LHS	24	7-27
216238	COVER,B PILLAR,RHS	23	7-27
216243	HOLDER,DOCUMENT,SEARS	22	7-31
216255	GASKET,PEDAL,BRAKE,MICO	13	4-5
216258	COVER,DUST,HEADLAMP	6	6-33
216267	CABLE,BATT,RD	9	6-43
216268	CABLE,BATT,BK	8	6-43
216270	CABLE,BATT,BK	7	6-43
216271	HARNESS,BATT BOX	6	6-43
216277	LID,COOLER BOX,CAB	21	7-23
216278	LID,FUSES/RELAYS	20	7-23
216280	PANEL,LEVER	19	7-25
216281	HARNESS,DIAGNOSTIC,MK4	1	10-35
216282	RUBBER,ISOLATE,HYDR,CAB,MID	12	4-3
216283	RUBBER,ISOLATE,HYDR,CAB,FRONT	11	4-3
216286	HARNESS,BEACON,EXTENSION	2	6-21
216287	HARNESS,WORK LIGHT	1	6-23
216291	HARNESS,RADIO,BLAUPUNKT	4	6-31
216296	BATTERY,12V,102AH,DELPHI	3	6-43
216325	DELPHI PACKARD, 3 WAY, RECEPTACLE, SOCKETS	53	6-55
216326	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS	32	6-53
216327	DELPHI PACKARD, 2 WAY, RECEPTACLE, PINS	33	6-53
216328	AMP, 2 WAY, PLUG, SOCKETS	28	6-53
216329	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS	34	6-53
216330	AMP, 3 WAY, PLUG, SOCKETS	50	6-55
216331	DT DEUTSCH, 4 WAY, PLUG, SOCKETS	73	6-57
216332	TYCO, 8 WAY, PLUG, SOCKETS	95	6-59
216333	DELPHI PACKARD, 3 WAY, RECEPTACLE, SOCKETS	54	6-55
216334	DELPHI PACKARD, 2 WAY, RECEPTACLE, SOCKETS	35	6-53
216335	FCI, 6 WAY, PLUG, SOCKETS	88	6-59
216336	DT DEUTSCH, 6 WAY, PLUG, SOCKETS	87	6-59
216348	E-MODULE,OBW	3	6-49
216350	EXHAUST,STACK,POLISHED SS	4	2A-67
216350	EXHAUST,STACK,POLISHED SS	4	2B-61
216354	EXHAUST,STACK,BIN HEAT,SS	3	2A-69
216358	DT DEUTSCH, 3 WAY, PLUG, SOCKETS	60	6-55
216359	TERMINATOR, CAN, 120 OHM	65	6-57
216364	PIPE,CONDENSOR,AC	7	7-49
216365	PIPE,CONDENSOR,AC	6	7-49
216366	ADAPTOR,COMPRESS,HVAC	5	7-49
216372	CLAMP,RUBBER,5,FRAME	4	7-49
216373	CLAMP,RUBBER,6,FRAME	3	7-49
216381	CUSHION,BACKREST,TRAINER	18	7-31
216382	CUSHION,SEAT,TRAINER	17	7-31
216383	ANTENNA,RADIO,BLAUPUNKT	3	6-31
216405	CINCH BN, 32 WAY, PLUG, SOCKETS	145	6-65
216412	HARNESS,REAR WIPER	19	6-3
216424	DECAL,SOUND POWER LEVEL	26	7-107
216429	PANEL,HOLD-ALL	16	7-25
216430	PANEL,WIPER,REAR	15	7-25
216443	LINK,DRAG	4	7-77
216444	LINK,DRAG	4	7-77
216445	SENDER,FUEL	5	6-33
216451	FOOT,TRAY,E-MODULE	18	6-7
216453	KIT,GASKET,COOL BOX,	14	7-23
216454	GASKET	13	7-23
216455	HARNESS,RH	2	6-15
216456	HARNESS,LH	1	6-15
216457	COVER,E-MODULE	12	7-25
216462	FUSE,BLANK,BLADE TYPE	7	6-9
216463	ADAPTOR,VENT	2	7-43
216470	HARNESS,ZF TRANSM,ARTIC	1	6-45
216472	MAT,DASH ACCESS	11	7-25
216473	MAT,COOL BOX	10	7-23
216480	PLT,SPACER,DIFF & PUMP	16	3-139
216480	PLT,SPACER,DIFF & PUMP	16	3-173
216481	SHAFT,COUPLING-NUT	15	3-139
216481	SHAFT,COUPLING-NUT	15	3-173
216482	SANDWICH BLOCK,AXLE MTG	1	7-95
216484	CLAMP,HOSE	12	2A-81
216484	CLAMP,HOSE	12	2B-75
216486	PLT,PIVOT,HEADLIGHT	4	6-33
216497	DECAL,SPEED DOWN SLOPE	30	7-109
216498	DECAL,SPEED DOWN SLOPE	31	7-109
216513	DECAL,RSG,SML	43	7-109
216523	COVER,SEAT,TRAINER	8	7-31
216525	VENT,SWIVEL,HVAC	3	7-43
216527	STRAP,EARTH	17	6-7
216531	DECAL,ROPS/FOPS,SML	37	7-109
216558	DT DEUTSCH, 3 WAY, RECEPTACLE, PINS WITH GREEN/GREY WIRE BRIDGE	61	6-57
216562	CHAIN,TIE,AXLE	4	7-95
216594	COUPLING,SHAFT	14	3-139
216594	COUPLING,SHAFT	14	3-173
216625	SPRING,C,BONNET CATCH	4	7-61
216626	SPRING,T,BONNET CATCH	4	7-57
216640	RADIO,BLAUPUNKT,5000M	2	6-31
216645	ISOLATOR,RUBBER	16	6-7
216646	FASTENER,PLASTIC,HEADLINER	7	7-29
216650	TRAY,E-MODULE	15	6-7
216653	HARNESS	150	3-75
216654	HARNESS	164	3-75
216673	MAT,TOOLBOX,	6	7-27
216679	DECAL,IGNITION SWITCH	55	7-109
216692	VALVE, BLOCK, IPM, SMALL, G2	1	5-7
216692	VALVE,BLOCK,IPM,SMALL	5	5-3
216702	P-CLIP	14	6-5
216735	DT DEUTSCH, 2 WAY, RECEPTACLE, PINS WITH 1500 ohm 2W RESISTOR	42	6-55
216754	EXHAUST,H/SHIELD FIXED	8	2A-67
216754	EXHAUST,H/SHIELD FIXED	8	2B-61
216755	EXHAUST,H/SHIELD COVER	7	2A-67
216755	EXHAUST,H/SHIELD COVER	7	2B-61
216767	HDP DEUTSCH, 21 WAY, PLUG, PINS, 90°	127	6-63
216768	HDP DEUTSCH, 21 WAY, PLUG, PINS	128	6-63
216769	HDP DEUTSCH, 21 WAY, RECEPTACLE, SOCKETS	129	6-63
216770	HDP DEUTSCH, 21 WAY, RECEPTACLE, PINS	130	6-63
216771	HDP DEUTSCH, 21 WAY, RECEPTACLE, SOCKETS	131	6-63
216772	HDP DEUTSCH, 21 WAY, PLUG, PINS	132	6-63

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
216773	HDP DEUTSCH, 23 WAY, PLUG, PINS, 90°	133	6-63
216774	HDP DEUTSCH, 23 WAY, RECEPTACLE, SOCKETS	134	6-63
216775	HDP DEUTSCH, 33 WAY, PLUG, PINS, 90°	146	6-65
216776	HDP DEUTSCH, 33 WAY, RECEPTACLE, SOCKETS	147	6-65
216777	HDP DEUTSCH, 9 WAY, RECEPTACLE, SOCKETS	104	6-61
216778	HDP DEUTSCH, 9 WAY, PLUG, PINS	105	6-61
216779	DT DEUTSCH, 2 WAY, RECEPTACLE, PINS	43	6-55
216780	DT DEUTSCH, 2 WAY, PLUG, SOCKETS	44	6-55
216782	DT DEUTSCH, 4 WAY, PLUG, SOCKETS	74	6-57
216784	AMP 90 DEG FLAG TERMINAL, 11 MM	1	6-51
216785	AMP, 9 WAY, RECEPTACLE, PINS	98	6-59
216786	AMP, 9 WAY, PLUG, SOCKETS	99	6-59
216787	AMP, 21 WAY, RECEPTACLE, PINS	124	6-63
216788	GROTE & HARTMANN, 13 MM NON-INSULATED TERMINAL	6	6-51
216789	AMPHENOL, 9 WAY, PLUG, PINS	100	6-59
216798	AMP, 15 WAY, RECEPTACLE, PINS	116	6-61
216809	GROTE & HARTMANN, 10 MM LUG	7	6-51
216810	GROTE & HARTMANN, 10 MM LUG	8	6-51
216811	GROTE & HARTMANN, 8 MM LUG	9	6-51
216812	GROTE & HARTMANN, 6 MM LUG	10	6-51
216813	GROTE & HARTMANN, 6 MM LUG	11	6-51
216815	SUMITOMO, 3.0 MM, FEMALE, PUSH-ON	26	6-53
216816	AMP, 4.8 MM, FEMALE, PUSH-ON	2	6-51
216817	AMP, 1 WAY, SLIP-ON	3	6-51
216830	COOLING PACK	11	2B-77
216839	DELPHI PACKARD, 2 WAY, RECEPTACLE, PINS	36	6-53
216843	BUSH	5	2B-79
216852	DT DEUTSCH, 2 WAY, RECEPTACLE, BLANKING PINS (x2) & WEDGE. NO TERMINALS.	45	6-55
216856	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS	37	6-53
216857	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS	38	6-53
216861	HDP DEUTSCH, 31 WAY, PLUG, SOCKETS	142	6-65
216898	FAN, SUCKER C/W VISCOUS HUB	1	2B-55
216913	ASSY,MID SECTION,B/H	2	2A-69
216913	ASSY,MID SECTION	2	2B-63
216917	RADIATOR	4	2B-79
216918	CAC	3	2B-79
216924	DT DEUTSCH, 3 WAY, PLUG, SOCKETS	56	6-55
216925	DT DEUTSCH, 3 WAY, RECEPTACLE, PINS	58	6-55
216926	DT DEUTSCH, 3 WAY, RECEPTACLE, PINS	59	6-55
216941	DECAL,TYRE PRESSURE,25TON	41	7-109
216942	DECAL,TYRE PRESSURE,30TON	40	7-109
216945	FUSE,40A,BLADE TYPE	8	6-9
216952	COVER,ARMREST,SEAT,LH	9	7-35
216953	COVER,ARMREST,SEAT,RH	10	7-35
216963	EXTENSION,MUDGUARD,RHS	3	7-67
216964	EXTENSION,MUDGUARD,LHS	4	7-67
217062	GEAR,THRU DRIVE SHAFT	13	3-139
217062	GEAR,THRU DRIVE SHAFT	13	3-173
217062	GEAR,THRU DRIVE SHAFT	15	3-133
217062	GEAR,THRU DRIVE SHAFT	15	3-167
217063	GEAR,PINION SHAFT	14	3-133
217063	GEAR,PINION SHAFT	14	3-167
217087	SHIM,ADJUST,LSD,0.1	11	3-137
217087	SHIM,0.1	11	3-143
217087	SHIM,0.1	11	3-171
217087	SHIM,0.1	11	3-177
217088	SHIM,ADJUST,LSD,0.25	10	3-137
217088	SHIM,0.25	10	3-143
217088	SHIM,0.25	10	3-171
217088	SHIM,0.25	10	3-177
217101	SHAFT,THRU DRIVE	13	3-133
217102	SPACER	9	3-137
217102	SPACER	9	3-143
217102	SPACER	9	3-171
217102	SPACER	9	3-177
217103	DISC,FRICTION	8	3-137
217103	DISC,FRICTION	8	3-143
217103	DISC,FRICTION	8	3-171
217103	DISC,FRICTION	8	3-177
217104	DISC,STATIONARY	7	3-137
217104	DISC,STEEL	7	3-143
217104	DISC,STEEL	7	3-171
217104	DISC,STEEL	7	3-177
217107	SHIM,ADJUST,POWER DIVIDER,0.1	12	3-133
217107	SHIM,ADJUST,POWER DIVIDER,0.1	12	3-139
217107	SHIM,ADJUST,POWER DIVIDER,0.1	12	3-173
217107	SHIM,ADJUST,POWER DIVIDER,0.1	13	3-167
217108	SHIM,ADJUST,POWER DIVIDE,0.25	11	3-133
217108	SHIM,ADJUST,POWER DIVIDE,0.25	11	3-139
217108	SHIM,ADJUST,POWER DIVIDE,0.25	11	3-173
217108	SHIM,ADJUST,POWER DIVIDE,0.25	12	3-167
217109	SHIM,ADJUST,POWER DIVIDER,0.5	10	3-133
217109	SHIM,ADJUST,POWER DIVIDER,0.5	10	3-139
217109	SHIM,ADJUST,POWER DIVIDER,0.5	10	3-173
217109	SHIM,ADJUST,POWER DIVIDER,0.5	11	3-167
217110	SHIM,ADJUST,PINION SHAFT,0.1	9	3-133
217110	SHIM,ADJUST,PINION SHAFT,0.1	9	3-139
217110	SHIM,ADJUST,PINION SHAFT,0.1	9	3-173
217110	SHIM,ADJUST,PINION SHAFT,0.1	10	3-167
217111	SHIM,ADJUST,PINION SHAFT,0.25	8	3-133
217111	SHIM,ADJUST,PINION SHAFT,0.25	8	3-139
217111	SHIM,ADJUST,PINION SHAFT,0.25	8	3-173
217111	SHIM,ADJUST,PINION SHAFT,0.25	9	3-167
217112	SHIM,ADJUST,PINION SHAFT,0.5	7	3-133
217112	SHIM,ADJUST,PINION SHAFT,0.5	7	3-139
217112	SHIM,ADJUST,PINION SHAFT,0.5	7	3-173
217112	SHIM,ADJUST,PINION SHAFT,0.5	8	3-167
217148	SHIM,ADJUST,LSD,0.5	6	3-137
217148	SHIM,0.5	6	3-143
217148	SHIM,0.5	6	3-171
217148	SHIM,0.5	6	3-177
217151	WINDOW,REAR	9	7-17
217166	E-MODULE,MEMORY MODULE	4	6-27
217174	CARRIER,PINION	6	3-133
217174	CARRIER,PINION	6	3-139
217174	CARRIER,PINION	6	3-173
217174	CARRIER,PINION	7	3-167
217180	PAD,BRAKE,SCL-2,NA-4	12	3-185

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
217210	SPACER,PINION,17.42MM	5	3-133	217619	ARM,WIPER	1	6-11
217210	SPACER,PINION,17.42MM	5	3-139	217620	CLIPS,WASHER SYSTEM	3	6-11
217210	SPACER,PINION,17.42MM	5	3-173	217621	NOZZLE,6 WAY,WASHER SYSTEM	4	6-11
217210	SPACER,PINION,17.42MM	6	3-167	217625	SOLENOID	5	6-43
217211	SPACER,PINION,17.43MM	5	3-133	217672	LEVER,PARKER	12	6-5
217211	SPACER,PINION,17.43MM	5	3-139	217684	MTG,BAND,2PC,AIR CLEANER,FRG 15	3	2A-71
217211	SPACER,PINION,17.43MM	5	3-173	217684	MTG,BAND,2PC,AIR CLEANER,FRG 15	3	2B-65
217211	SPACER,PINION,17.43MM	6	3-167	217700	GEAR,SPIDER	5	3-137
217212	SPACER,PINION,17.44MM	5	3-133	217700	GEAR,SPIDER	5	3-143
217212	SPACER,PINION,17.44MM	5	3-139	217700	GEAR,SPIDER	5	3-171
217212	SPACER,PINION,17.44MM	5	3-173	217700	GEAR,SPIDER	5	3-177
217212	SPACER,PINION,17.44MM	6	3-167	217701	GEAR,SIDE	4	3-137
217213	SPACER,PINION,17.45MM	5	3-133	217701	GEAR,SIDE	4	3-143
217213	SPACER,PINION,17.45MM	5	3-139	217701	GEAR,SIDE	4	3-171
217213	SPACER,PINION,17.45MM	5	3-173	217701	GEAR,SIDE	4	3-177
217213	SPACER,PINION,17.45MM	6	3-167	217702	SHAFT,CROSS	3	3-137
217214	SPACER,PINION,17.46MM	5	3-133	217702	SHAFT,CROSS	3	3-143
217214	SPACER,PINION,17.46MM	5	3-139	217702	SHAFT,CROSS	3	3-171
217214	SPACER,PINION,17.46MM	5	3-173	217702	SHAFT,CROSS	3	3-177
217214	SPACER,PINION,17.46MM	6	3-167	217703	RING,PRESSURE	2	3-137
217215	SPACER,PINION,17.47MM	5	3-133	217703	RING,PRESSURE	2	3-143
217215	SPACER,PINION,17.47MM	5	3-139	217703	RING,PRESSURE	2	3-171
217215	SPACER,PINION,17.47MM	5	3-173	217703	RING,PRESSURE	2	3-177
217215	SPACER,PINION,17.47MM	6	3-167	217705	INSERT,PLASTIC,K-CLAMP	2	6-49
217216	SPACER,PINION,17.48MM	5	3-133	217706	DT DEUTSCH, 4 WAY, RECEPTACLE	75	6-57
217216	SPACER,PINION,17.48MM	5	3-139	217711	AMP, 2 WAY, PLUG, SOCKETS	29	6-53
217216	SPACER,PINION,17.48MM	5	3-173	217717	RELAY,24V	9	6-9
217216	SPACER,PINION,17.48MM	6	3-167	217719	LIGHT,FLOOD,65W	1	6-25
217217	SPACER,PINION,17.49MM	5	3-133	217719	LIGHT,REVERSE FLOODLIGHT	2	6-37
217217	SPACER,PINION,17.49MM	5	3-139	217719	LIGHT,FLOOD	3	6-47
217217	SPACER,PINION,17.49MM	5	3-173	217719	LIGHT,FLOOD	4	6-47
217217	SPACER,PINION,17.49MM	6	3-167	217724	SWITCH,HAZARD	11	6-5
217218	SPACER,PINION,17.50MM	5	3-133	217725	CABLE,BATTERY,RED	4	6-43
217218	SPACER,PINION,17.50MM	5	3-139	217730	YAZAKI, 8 WAY, PLUG, SOCKETS	96	6-59
217218	SPACER,PINION,17.50MM	5	3-173	217735	SWITCH,PARK BRAKE	10	6-5
217218	SPACER,PINION,17.50MM	6	3-167	217736	FRAME,SWITCH,1 PLACE	9	6-5
217219	SPACER,PINION,17.51MM	5	3-133	217737	FRAME,SWITCH,3 PLACES	8	6-5
217219	SPACER,PINION,17.51MM	5	3-139	217739	AMP, 10 WAY, PLUG, SOCKETS	106	6-61
217219	SPACER,PINION,17.51MM	5	3-173	217745	WASHER,BOTTLE AND PUMP	7	6-5
217219	SPACER,PINION,17.51MM	6	3-167	217752	EXHAUST,FRONT SECTION	3	2A-67
217220	SPACER,PINION,17.52MM	5	3-133	217752	EXHAUST,FRONT SECTION	3	2B-61
217220	SPACER,PINION,17.52MM	5	3-139	217754	EXHAUST,MID SECTION	2	2A-67
217220	SPACER,PINION,17.52MM	5	3-173	217754	EXHAUST,MID SECTION	2	2B-61
217220	SPACER,PINION,17.52MM	6	3-167	217758	PLT,BLANKING,RADIO FACE	5	7-23
217526	SIDESHAFT	5	3-157	217760	SPACER,PINION,17.53MM	5	3-133
217526	SIDESHAFT	6	3-121	217760	SPACER,PINION,17.53MM	5	3-139
217526	SIDESHAFT,BELL,36/30,L-1349.5	8	3-123	217760	SPACER,PINION,17.53MM	5	3-173
217526	SIDESHAFT,BELL,36/30,L-1349.5	8	3-159	217760	SPACER,PINION,17.53MM	6	3-167
217527	SIDESHAFT	4	3-157	217761	SPACER,PINION,17.54MM	5	3-133
217527	SIDESHAFT	5	3-121	217761	SPACER,PINION,17.54MM	5	3-139
217527	SIDESHAFT,BELL,36/30,L-1279	7	3-123	217761	SPACER,PINION,17.54MM	5	3-173
217527	SIDESHAFT,BELL,36/30,L-1279	7	3-159	217761	SPACER,PINION,17.54MM	6	3-167
217551	E-MODULE,BATT BALANCER	13	6-7	217762	SPACER,PINION,17.55MM	5	3-133
217555	WINDOW,LH,FRONT,TOUGHENED	8	7-17	217762	SPACER,PINION,17.55MM	5	3-139
217556	DOOR,MAIN,YELLOW	7	7-15	217762	SPACER,PINION,17.55MM	5	3-173
217557	WINDOW,DOOR,SLIDING	6	7-15	217762	SPACER,PINION,17.55MM	6	3-167
217588	SEAL,DOOR,HVAC,RHS,ADT D#	5	7-21	217763	SPACER,PINION,17.56MM	5	3-133
217590	SEAL,DOOR,MAIN	4	7-15	217763	SPACER,PINION,17.56MM	5	3-139
217616	CARRIER,BRG THRU DRV	4	3-121	217763	SPACER,PINION,17.56MM	5	3-173
217616	CARRIER,BRG THRU DRV	6	3-123	217763	SPACER,PINION,17.56MM	6	3-167
217617	PIPE,W/WASHER KIT	5	6-11	217764	SPACER,PINION,17.57MM	5	3-133
217618	BLADE,WIPER	6	6-11	217764	SPACER,PINION,17.57MM	5	3-139

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
217764	SPACER,PINION,17.57MM	5	3-173	217861	NONSLIP,MUDGUARD,RHS	1	7-67
217764	SPACER,PINION,17.57MM	6	3-167	217863	NONSLIP,REAR,F/TANK	1	7-71
217765	SPACER,PINION,17.58MM	5	3-133	217864	NONSLIP,ARTIC	2	3-117
217765	SPACER,PINION,17.58MM	5	3-139	217902	FRAME,SWITCH,CARLING	6	6-5
217765	SPACER,PINION,17.58MM	5	3-173	217910	E-MODULE,TCU	1	6-13
217765	SPACER,PINION,17.58MM	6	3-167	217922	NONSLIP,FRONT,BATTERY BOX	5	7-69
217766	SPACER,PINION,17.59MM	5	3-133	217923	NONSLIP,TOP LID,B/BOX	4	7-69
217766	SPACER,PINION,17.59MM	5	3-139	217924	NONSLIP,REAR,B/BOX	3	7-69
217766	SPACER,PINION,17.59MM	5	3-173	217950	SHAFT,THRU DRV	3	3-139
217766	SPACER,PINION,17.59MM	6	3-167	217956	COOLING PACKAGE	11	2A-83
217767	SPACER,PINION,17.60MM	5	3-133	217958	RADIATOR	3	2A-85
217767	SPACER,PINION,17.60MM	5	3-139	217959	CAC,300D,TIER,MK3	2	2A-85
217767	SPACER,PINION,17.60MM	5	3-173	217960	TM OIL COOLER	1	2A-85
217767	SPACER,PINION,17.60MM	6	3-167	217961	BATTERY,12V,108AH,DELPHI	3	6-43
217768	SPACER,PINION,17.61MM	5	3-133	217962	PIPE,BOTTOM,CAC	10	2A-83
217768	SPACER,PINION,17.61MM	5	3-139	217962	PIPE,BOTTOM,CAC	10	2B-77
217768	SPACER,PINION,17.61MM	5	3-173	217963	HOSE,TOP,CAC	9	2A-83
217768	SPACER,PINION,17.61MM	6	3-167	217963	HOSE,TOP,CAC	9	2B-77
217769	SPACER,PINION,17.62MM	5	3-133	217964	HOSE,BOTTOM,CAC	8	2A-83
217769	SPACER,PINION,17.62MM	5	3-139	217964	HOSE,BOTTOM,CAC	8	2B-77
217769	SPACER,PINION,17.62MM	5	3-173	217965	HOSE,STRAIGHT,CAC	7	2A-83
217769	SPACER,PINION,17.62MM	6	3-167	217965	HOSE,STRAIGHT,CAC	7	2B-77
217770	SPACER,PINION,17.63MM	5	3-133	217969	HOSE,TOP	6	2A-81
217770	SPACER,PINION,17.63MM	5	3-139	217969	HOSE,TOP,RAD	6	2B-75
217770	SPACER,PINION,17.63MM	5	3-173	217970	HOSE,BOTTOM	5	2A-81
217770	SPACER,PINION,17.63MM	6	3-167	217970	HOSE,BOTTOM,RAD	5	2B-75
217771	SPACER,PINION,17.64MM	5	3-133	217971	HOSE,INLET	4	2A-81
217771	SPACER,PINION,17.64MM	5	3-139	217971	HOSE,INLET,ENG	4	2B-75
217771	SPACER,PINION,17.64MM	5	3-173	217999	E-MODULE,CCU2	5	6-7
217771	SPACER,PINION,17.64MM	6	3-167	218033	DECAL,AIRCON,FILTER,CLEAN	24	7-107
217772	SPACER,PINION,17.65MM	5	3-133	218077	AMP, 3 WAY, RECEPTACLE, PINS	51	6-55
217772	SPACER,PINION,17.65MM	5	3-139	218079	SUMITOMO, 2 WAY, RECEPTACLE, PINS	48	6-55
217772	SPACER,PINION,17.65MM	5	3-173				
217772	SPACER,PINION,17.65MM	6	3-167	218240	HEADLAMP,COMBO,LHS	2	6-33
217773	SPACER,PINION,17.66MM	5	3-133	218240	HEADLAMP,COMBO,LHS,HELLA	7	6-37
217773	SPACER,PINION,17.66MM	5	3-139	218241	HEADLAMP,COMBO,RHS	1	6-33
217773	SPACER,PINION,17.66MM	5	3-173	218241	HEADLAMP,COMBO,RHS,HELLA	8	6-37
217773	SPACER,PINION,17.66MM	6	3-167	218255	DB, 15 WAY, PLUG, SOCKETS	117	6-61
217774	SPACER,PINION,17.67MM	5	3-133	218281	SWITCH,PRESSURE,123 BAR,S4	1	4-23
217774	SPACER,PINION,17.67MM	5	3-139	218281	SWITCH,PRESSURE,123BAR	2	6-41
217774	SPACER,PINION,17.67MM	5	3-173	218282	SWITCH,PRESSURE,5BAR	1	6-41
217774	SPACER,PINION,17.67MM	6	3-167	218282	SWITCH,PRESSURE,5 BAR,SP1	2	4-23
217775	SHAFT,HIGH DRIVE	4	3-173	218286	KNUCKLE,STEERING	25	7-41
217775	SHAFT,HIGH DRIVE	5	3-167	218287	COLUMN,STEERING	1	7-41
217810	HARNESS,ENGINE	3	6-33	218287	COLUMN,STEERING	4	7-39
217812	HARNESS,ARTIC	3	6-41	218292	SHIELD,HEAT,EXH,FRONT	1	2A-67
217813	HARNESS,REAR	2	6-47	218292	SHIELD,HEAT,EXH,FRONT	1	2B-61
217820	HD10 DEUTSCH, 3 WAY, PLUG, SOCKETS	62	6-57	218308	BRAD HARRISON, 4 WAY, 90°, SOCKETS	70	6-57
217821	HD10 DEUTSCH, 3 WAY, RECEPTACLE, PINS	63	6-57	218315	HANDLE,PADDLE,BONNET	3	7-53
				218315	HANDLE,PADDLE,BONNET	3	7-57
217827	DECAL,WARNING,OVERSPEEDING	27	7-107	218331	BOOT,RUBBER,DOOR HANDLE	3	7-15
217842	PLT,DIFF SERIAL NUMBER	3	3-173	218342	WINDOW,RHS,SLIDING	2	7-17
217842	PLT,DIFF SERIAL NUMBER	4	3-133	218437	DT DEUTSCH, 8 WAY, RECEPTACLE	93	6-59
217842	PLT,DIFF SERIAL NUMBER	4	3-139	218439	PISTON	7	3-185
217842	PLT,DIFF SERIAL NUMBER	4	3-167	218464	HARNESS FLEX, 4 WAY, M27, SOCKETS	76	6-57
217845	DECAL,CB'S,FUSES,RELAYS	33	7-109				
217855	HOSE,TEFLON	9	5-9	218469	PIPE,SUCTION,HYD,B25D	15	4-49
217857	NONSLIP,SUMP	3	2A-3	218480	DRIVER,ID,RECEPTACLE	3	6-27
217857	NONSLIP,SUMP	3	2A-5	218481	KEY,DRIVER ID,GREEN	2	6-27
217857	NONSLIP,SUMP	3	2B-3	218508	CLAMP,FUEL FILTER	5	2A-77
217860	NONSLIP,MUDGUARD,LHS	2	7-67	218508	CLAMP,FUEL FILTER	5	2B-71

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
218544	E-MODULE,SAT MODULE	1	6-29	220697	KIT,SEAL ORBITAL VALVE	3	4-9
218559	DELPHI PACKARD, 2 WAY, PLUG, SOCKETS	39	6-53	220722	COVER,FRG15 AIR CLEANER	2	2A-73
				220722	COVER,FRG15 AIR CLEANER	2	2B-67
218678	BLOCK,LOCATE,MIRROR	1	7-13	220723	LATCH,FRG15 AIR CLEANER	3	2A-73
218686	HOSE,RADIATOR	2	2A-81	220723	LATCH,FRG15 AIR CLEANER	3	2B-67
218686	HOSE,RADIATOR	2	2B-75	220724	VACUATOR,VALVE,FRG15 A/CLEANER	6	2A-73
218686	HOSE,RADIATOR	3	2A-81	220724	VACUATOR,VALVE,FRG15 A/CLEANER	6	2B-67
218686	HOSE,RADIATOR	3	2B-75	220725	ELEMENT,OUTER,AIR CLEANER		8-3
218686	HOSE,RADIATOR	5	7-45	220725	ELEMENT,OUTER,AIR CLEANER		8-3
218690	BONNET,SHELL	2	7-55	220725	ELEMENT,OUTER,AIR CLEANER		8-3
218735	DT DEUTSCH, 12 WAY, RECEPTACLE	110	6-61	220725	ELEMENT,OUTER,AIR CLEANER		8-5
218737	GROTE & HARTMANN, SOCKET	12	6-51	220725	ELEMENT,OUTER,AIR CLEANER		8-5
218750	AMP, 6 WAY, PLUG, SOCKETS	83	6-59	220725	ELEMENT,OUTER,AIR CLEANER		8-5
218777	CABLE,EARTH	1	6-43	220725	ELEMENT,OUTER,AIR CLEANER		8-5
218777	CABLE,EARTH	2	6-43	220725	ELEMENT,OUTER,FRG15 A/CLEANER	4	2A-73
218797	CLAMP,K	10	4-51	220725	ELEMENT,OUTER,FRG15 A/CLEANER	4	2B-67
218849	ANTENNA,GPS,3000MM CABLE	1	6-27	220738	FUNNEL,FILTER	3	7-87
218855	PAD,GUIDE BONNET	3	7-61	220747	ELEMENT,INNER,AIR CLEANER		8-3
218858	MAT,SHOCK,REAR,BIN,B30D MKII	1	7-97	220747	ELEMENT,INNER,AIR CLEANER		8-5
218858	MAT,SHOCK,REAR,BIN,B30D MKII	1	7-99	220747	ELEMENT,INNER,AIR CLEANER		8-5
218867	MOUNTING,SEAT,TRAINER	1	7-33	220747	ELEMENT,INNER,FRG15 A/CLEANER	5	2A-73
218867	SEAT,TRAINER	3	7-31	220747	ELEMENT,INNER,FRG15 A/CLEANER	5	2B-67
218912	LIGHT,BEACON,XENON,AMBER	1	6-21	220765	O-RING	40	7-47
218928	HOSE,SUCTION,HYD TANK	14	4-49	220949	FILTER:AIR DRYER		8-3
218950	GROTE & HARTMANN, 4 MM LUG	13	6-51	220949	FILTER:AIR DRYER		8-5
218952	GROTE & HARTMANN, 5 MM LUG	14	6-51	220949	FILTER:AIR DRYER		8-5
218953	GROTE & HARTMANN, 5 MM LUG	15	6-51	220949	FILTER,AIR DRIER	1	5-13
218955	GROTE & HARTMANN, 6 MM LUG	16	6-51	220949	FILTER,AIR DRYER	2	5-15
218956	GROTE & HARTMANN, 6 MM LUG	17	6-51	221366	CIRCLIP	16	4-13
218957	GROTE & HARTMANN, 6 MM LUG	18	6-51	221367	PLUG	22	4-13
218958	GROTE & HARTMANN, 8 MM LUG	19	6-51	221417	VALVE, RELIEF UNLOADING	7	4-25
218961	GROTE & HARTMANN, 10 MM LUG	20	6-51	221417	VALVE, RELIEF UNLOADING	7	4-27
218962	GROTE & HARTMANN, 10 MM LUG	21	6-53	221418	VALVE, CHECK	4	4-25
218963	GROTE & HARTMANN, 10 MM LUG	22	6-53	221418	VALVE, CHECK	4	4-27
218964	GROTE & HARTMANN, 10 MM LUG	23	6-53	221420	VALVE, DIRECTIONAL CONTROL, 24V	9	4-25
218965	GROTE & HARTMANN, 12 MM LUG	24	6-53	221420	VALVE, DIRECTIONAL CONTROL, 24V	9	4-27
218991	SET,CW & PINION	3	3-133	221422	KIT, SEAL	20	4-25
218991	SET,CW & PINION	3	3-167	221422	KIT, SEAL	20	4-27
218999	RUBBER,SEAL,BONNET	1	7-55	221423	KIT, SEAL	21	4-25
220010	ELEMENT,FILTER,29MICRON		8-3	221423	KIT, SEAL	21	4-27
220010	ELEMENT,FILTER,29MICRON		8-3	221424	KIT, SEAL	22	4-25
220010	ELEMENT,FILTER,29MICRON		8-3	221424	KIT, SEAL	22	4-27
220010	ELEMENT,FILTER,29MICRON		8-3	221425	VALVE, PRESSURE RELIEF	8	4-25
220010	ELEMENT,FILTER,29MICRON		8-5	221425	VALVE, PRESSURE RELIEF	8	4-27
220010	ELEMENT,FILTER,29MICRON		8-5	221585	GASKET, BLOCK/PILOT, INTERFACE	4	5-7
220010	ELEMENT,FILTER,29MICRON		8-5	221586	SCREW, BODY/PILOT VALVE	7	5-7
220010	ELEMENT,FILTER,29MICRON GUD		8-5	221587	SCREW, CAP, SOLENOID	5	5-7
220010	ELEMENT:FILTER 29MICRON GUD	13	7-85	221589	GASKET, SOLENOID/MANIFOLD	3	5-7
220211	DIAPHRAGM	5	3-95	221590	O-RING, PRESSURE SWITCH	9	5-7
220397	HOOK,CLOTHES	2	7-23	221594	O-RING, TYRE TOWER MANIFOLD	14	5-7
220535	COVER,PRE CLEANER	18	2A-71	221595	SCREW, PRESSURE SENDER	11	5-7
220535	COVER,PRE CLEANER	18	2B-65	221597	KIT,SEAL,SERVICE	8	2A-77
220605	KIT,SEAL,RELIEF VALVE	3	4-11	221597	KIT,SEAL,SERVICE	8	2B-71
220606	VALVE ,RELIEF	2	4-11	221627	catch,vertical,sliding window,rhs	2	7-19
220607	SCREW,CAP	8	4-9	221628	catch,vertical,sliding window,lhs	3	7-19
220608	RACE,BEARING	4	4-9	221629	CATCH,CAB,SLIDING WINDOW	1	7-19
220609	PLUG	1	4-9	221703	ELEMENT,HEATING,AIR DRYER	3	5-15
220610	O,RING	2	4-9	221760	CIRCLIP:EXTERNAL	1	7-65
220611	RING,RETAINING	6	4-9	221760	CIRCLIP:EXTERNAL	2	7-59
220635	BLOCK VALVE	35	7-47	222239	ACTUATOR ASSEMBLY	1	3-95
220693	BEARING,NEEDLE THRUST	5	4-9	222239	ACTUATOR ASSEMBLY	56	3-93
220694	SPRING,CENTERING	7	4-9	222240	CALIPER BODY	2	3-93

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
222242	PLATE, END MERITOR BRAKE	4	3-93
222277	O-RING	18	4-13
222280	ROD,PISTON	20	4-13
222281	HOUSING,PUMP	21	4-13
222284	SPRING	12	4-13
222285	SHIM	4	4-13
222286	BEARING,TAPERED,ROLLER	14	4-13
222287	BEARING,TAPERED,ROLLER	5	4-13
222288	SHELL,CRADLE	11	4-13
222289	SEAL,SHAFT	15	4-13
222290	O-RING	6	4-13
222308	PLUG	17	4-13
222389	ELEMEMT,FLTR,HYDRAU-LIC,5MICRON		8-3
222389	ELEMEMT,FLTR,HYDRAU-LIC,5MICRON		8-3
222389	ELEMEMT,FLTR,HYDRAU-LIC,5MICRON		8-3
222389	ELEMEMT,FLTR,HYDRAU-LIC,5MICRON		8-5
222389	ELEMEMT,FLTR,HYDRAU-LIC,5MICRON		8-5
222389	ELEMENT,FLTR,HYDRAULIC,5MICRON		8-5
222389	ELEMEMT,FLTR,HYDRAU-LIC,5MICRON	2	7-87
222605	SPRING, ANTI RATTLE	6	3-93
222606	SPACER	7	3-93
223210	O-RING	28	4-13
223212	PLUG	28	4-45
223213	TEAR-OFF-PLUG	8	4-45
223213	PLUG	29	4-13
223214	PIN,DOWEL	7	4-13
223214	DOWEL PIN	9	4-45
223218	O-RING	4	4-45
223218	O-RING	25	4-13
223219	CAP SCREW	1	4-45
223219	SCREW,CAP	27	4-13
223219	CAP SCREW	71	3-89
223220	PLUG	3	4-45
223220	PLUG	26	4-13
223233	PUMP HOUSING	27	4-45
223235	SWASH PLATE	22	4-45
223237	DISC	21	4-45
223238	SHIM	19	4-45
223239	TAPERED ROLLER BEARING	25	4-45
223240	TAPERED ROLLER BEARING	20	4-45
223241	CRADLE,SHELL	23	4-45
223242	SHAFT SEAL	31	4-45
223243	O-RING	26	4-45
223244	O-RING	1	6-47
223244	O-RING	6	4-45
223245	SEEGER-V-RING	30	4-45
223246	PLUG VSTI	10	4-45
223247	PILOT VALVE DFRI COMPLETE	2	4-45
223247	VALVE,PILOT	23	4-13
223248	PISTON	18	4-45
223259	COUNTER PISTON	13	4-45
223260	SPRING	15	4-45
223261	SPRING	14	4-45
223646	KIT, LEVER	41	3-93
223646	LEVER, MERITOR BRAKE	42	3-93
223648	PLATE,DISTRIBUTION	3	4-13
223654	ROTARY,GROUP	2	4-13
223655	PISTON,CONTROL	19	4-13
223657	PLATE,SWASH	10	4-13
223658	SHAFT,DRIVE	13	4-13
223661	SCREW,SOC. HEAD	9	4-13
223674	WASHER,DOWTY,PILOT VALVE CAPS	24	4-13
223714	KIT,REPAIR AIR DRYER	4	5-15
223716	KIT, BEARING	55	3-93
223717	KIT, SEAL & GASKET	22	3-93
223719	KIT, ADJUSTER RH	45	3-93
223721	KIT, ADJUSTER SLEEVE & THRUST	23	3-93
223722	KIT, SLIDE PIN	9	3-93
223816	FILTER,FUEL	2	3-79
223816	FILTER,FUEL	9	4-51
223816	FILTER,FUEL	11	4-33
223905	PLATE,END	4	3-185
223908	CYLINDER HEAD	9	3-185
223968	NUT,ROUND SPECIAL	16	7-41
224200	SEAL,PISTON	78	3-89
224202	SEAL,SHAFT	77	3-85
224203	FLANGE,8.5C	30	3-85
224203	FLANGE,7C	30	3-89
224204	FLANGE,7C	29	3-89
224206	GEAR,SUN	13	3-89
224208	HOUSING,BEARING REAR	4	3-83
224208	HOUSING,BEARING REAR	4	3-89
224209	INSERT,IDLER FRONT	5	3-87
224210	INSERT,IDLER PTO	6	3-87
224211	FRONT INSERT,IDLER	7	3-85
224214	SHAFT,OUTPUT REAR	10	3-89
224220	GEAR,INPUT	18	3-85
224221	SHIELD,MUD	37	3-85
224221	SHIELD,MUD	37	3-89
224222	SHAFT,OUTPUT FRONT	9	3-89
224223	BEARING,CYLINDER ROLLER	56	3-85
224224	BEARING,CYL. ROLLER	57	3-89
224225	BEARING,FOUR POINT QJ213	60	3-89
224226	BEARING,D.G.BALL 16022 C3/C4	59	3-89
224228	O-RING	79	3-89
224229	O-RING	81	3-85
224229	O-RING	81	3-89
224231	O-RING	83	3-85
224231	O-RING	83	3-87
224232	O-RING	84	3-89
224235	O-RING	80	3-89
224236	O-RING	85	3-89
224237	SPRING,COMPRESSION	41	3-89
224238	GEAR,RING	15	3-89
224239	NEEDLE,ROLLER NRO.B2,5X2,5	54	3-89
224240	WASHER,THRUST	53	3-89
224241	BUSH,MB 8530 DU	52	3-89
224242	PIN,PLANET	19	3-89
224244	PISTON	24	3-89
224246	GEAR,PLANET SET	14	3-89
224248	CLUTCH,SLIDE	22	3-89
224249	CIRCLIP,SHAFT	62	3-89
224251	CLUTCH,INSERT	21	3-89
224252	SCREW,GRUB	74	3-89
224253	PIN,SPRING	40	3-89
224254	PLUG,MAGNETIC DRAIN	43	3-83
224257	BOLT,EYE	50	3-83
224258	CIRCLIP,EXTERNAL	64	3-89

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
224363	COIL, DIRECTIONAL CONTROL, 24V	10	4-25	226006	hose,heater,325mm long	30	7-47
224363	COIL, DIRECTIONAL CONTROL, 24V	10	4-27	226006	HEATER HOSE,220mm long	41	7-47
224367	CIRCLIP,INTERNAL	65	3-85	226007	RECEPTACLE	33	7-47
224367	CIRCLIP,INTERNAL	65	3-89	226008	RETAINER	32	7-47
224368	PLUG	45	3-83	226009	STUD BAIL STYLE	31	7-47
224370	SCREW,HEXHD	67	3-85	226010	CONSTANT TENSION BAND CLAMP	28	7-47
224370	SCREW,HEXHD	67	3-87	226011	NYLON SPACER 1/2"	27	7-47
224370	SCREW,HEXHD	67	3-89	226013	SNAP BUSHING,1/4"	23	7-47
224372	SCREW,HEXHD	66	3-89	226014	COPPER TUBE ASSY	20	7-47
224373	MAGNET	103	3-83	226015	MOTOR ACTUATOR 12V	19	7-47
224398	VALVE, PRESSURE RELIEF	2	4-25	226016	MOTORIZED VALVE ASSY	45	7-47
224398	VALVE, PRESSURE RELIEF	2	4-27	226018	BLOWER ASSY,24V	15	7-47
224399	ORIFICE, 2.5	3	4-25	226019	FILTER,AIR ASSY(AIR CON)		8-3
224399	ORIFICE, 2.5	3	4-27	226019	FILTER,AIR ASSY(AIR CON)		8-3
224400	ORIFICE, SCREW, 0.7	11	4-25	226019	FILTER,AIR ASSY(AIR CON)		8-3
224400	ORIFICE, SCREW, 0.7	11	4-27	226019	FILTER,AIR ASSY(AIR CON)		8-3
224401	VALVE, CHECK	13	4-25	226019	FILTER,AIR ASSY(AIR CON)		8-3
224401	VALVE, CHECK	13	4-27	226019	FILTER,AIR ASSY(AIR CON)		8-3
224402	VALVE, SHUTTLE	15	4-25	226019	FILTER,AIR ASSY(AIR CON)		8-5
224402	VALVE, SHUTTLE	15	4-27	226019	FILTER,AIR ASSY(AIR CON)		8-5
224405	VALVE, CHECK	14	4-25	226019	FILTER,AIR ASSY(AIR CON)		8-5
224405	VALVE, CHECK	14	4-27	226019	FILTER,AIR ASSY(AIR CON)		8-5
224406	VALVE, PRESSURE RELIEF	16	4-25	226019	AIR FILTER ASSY	14	7-47
224406	VALVE, PRESSURE RELIEF	16	4-27	226020	EVAPORATOR COIL	13	7-47
224412	KIT, SEAL	24	4-25	226021	HEATER COIL	12	7-47
224412	KIT, SEAL	24	4-27	226024	SOLENOID	7	5-11
224413	KIT, SEAL	23	4-25	226025	PLATE,PORT	8	4-13
224413	KIT, SEAL	23	4-27	226037	GROUP,ROTARY A10V	16	4-45
224418	FORK	23	3-89	226039	PLATE,PORT A10V	7	4-45
224419	CARRIER,PLANET	20	3-89	226040	SHAFT,DRIVE	24	4-45
224421	GEAR,IDLER	17	3-87	226046	PISTON,CONTROL	11	4-45
224422	GEAR,OUTPUT	16	3-89	226047	GUIDE,PISTON	12	4-45
224423	SHAFT,INPUT	12	3-85	226050	side cover assy	2	7-47
224424	SHAFT,IDLER	11	3-87	226052	mounting plate,actuator	4	7-47
224425	HOUSING,CLUTCH M/C	3	3-83	226055	flapper,fresh air	7	7-47
224425	HOUSING,CLUTCH M/C	3	3-89	226056	support,coil	8	7-47
224426	HOUSING,FRONT BEARING	2	3-89	226057	support,block valve	9	7-47
224427	INSERT,THREADED	101	3-83	226060	screw	25	7-47
224428	HOUSING,M/C	1	3-83	226117	RING,LOCK	4	3-189
224666	PLATE,FLANGE	31	3-85	226117	RING,LOCK	4	3-191
224666	PLATE,FLANGE	31	3-89	226118	BAND,BEAD SEAT	6	3-191
224667	VALVE,DRAIN SELF VENTING	4	2A-77	226122	BAND,BEAD SEAT	6	3-189
224667	VALVE,DRAIN SELF VENTING	4	2B-71	226126	LENS,HAEDLAMP,COMBO,LHS,HELLA	9	6-37
224670	BOWL,SEE-THRU	3	2A-77	226127	LENS,HAEDLAMP,COMBO,RHS,HELLA	10	6-37
224670	BOWL,SEE-THRU	3	2B-71	226224	PADS, SET PARK BRAKE	5	3-93
224693	PIN,PRESSURE	17	4-45	226385	KIT,LID & GASKET	6	2A-77
225244	REAR,INSERT,IDLER	8	3-85	226385	KIT,LID & GASKET	6	2B-71
225245	PLUG,SCREW	100	3-83	226386	KIT,T-HANDLE & O-RING	7	2A-77
225250	COVER,ACTUATOR	26	3-89	226386	KIT,T-HANDLE & O-RING	7	2B-71
225251	SPACER,BEARING	27	3-85	226530	WASHER,WITH CAP SCREW	7	7-87
225253	LID,INPUT	32	3-85	226531	SPRING	5	7-87
225254	LID,P.T.O.	33	3-87	226532	HOLDER,FILTER ASSEMBLY	6	7-87
225255	PLATE,RETARDER	34	3-85	226644	KIT,SERVICE,AIR VALVE	2	7-37
225256	WASHER,WEAR	35	3-89	226645	KIT,SERVICE,ISOLATOR SHOCK	3	7-37
225257	COVER,CLUTCH	36	3-89	226646	SHAFT,BEARING	7	7-37
225261	BEARING,CYL. ROLLER NJ2213	55	3-87	226647	KIT,SERVICE,BEARING & ROLLERS	5	7-37
225262	HELICOIL,HCM10X1,5D	102	3-83	226648	KIT,SERVICE,ISOLATOR LATCH	6	7-37
225268	O-RING	86	3-89	226649	KIT,SERVICE,SUSPENSION SHOCK	8	7-37
225269	O-RING	82	3-87	226650	KIT,TETHER BELT	10	7-37
225270	BEARING,SPHERICAL ROLLER	61	3-85	226651	KIT,SERVICE,BUMPER	11	7-37
226005	NYLON SPACER	42	7-47	226652	SUSPENSION ASSY,C.E.AIR	1	7-37
226006	hose,heater,60mm long	29	7-47	226652	SUSPENSION ASSY,C.E.AIR	6	7-35

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
226653	MOUNTING	7	7-35	226865	SPOOL,LS	8	4-29
226654	SEAT BELT,2"	4	7-35	226866	VALVE,CHECK	10	4-29
226655	COVER,SIDE	5	7-35	226867	ORIFICE	11	4-29
226657	CIRCLIP	30	7-41	226870	BODY, QUICK EXHAUST VALVE	21	5-7
226658	CIRCLIP	31	7-41	226917	SEAL,SHAFT	77	3-85
226659	BEARING	32	7-41	226917	SEAL,SHAFT	77	3-89
226661	GLASS,SIGHT-BOROSILICATE-S/IN	76	3-83	227039	KIT,SPACER & WASHERS	28	3-89
226685	GLASS,MIRROR,ELECTRICAL	2	6-19	227070	KIT, ECCENTRIC SHAFT	32	3-93
226686	COVER,BACK	6	6-19	230152	CYLINDER	1	4-17
226687	GLASS,MIRROR	8	6-19	230152	CYLINDER	3	4-15
226688	GLASS,MIRROR,MANUAL	2	6-19	230167	CYL,D60XD100X468S	10	4-31
226735	CUSHION,BACKREST	2	7-35	230167	CYL,D60XD100X468S	A	4-47
226736	CUSHION,SEAT	3	7-35	230344	CYL,TIP,MK2,D70XD100,LHS,B30D	8	4-51
226737	KIT,SERVICE,AIR SPRING	4	7-37	230344	CYL,TIP,MK2,D70XD100,LHS,B30D	A	4-53
226738	BELLOWS	9	7-37	230345	CYL,TIP,MK2,D70XD100,RHS,B30D	7	4-51
226746	HEADREST	21	7-35	230345	CYL,TIP,MK2,D70XD100,RHS,B30D	A	4-53
226747	PAD,ARMREST,RH	13	7-35	230346	CYL,TIP,MK2,D70XD100,LHS,B25D	8	4-51
226748	PAD,ARMREST,LH	15	7-35	230346	CYL,TIP,MK2,D70XD100,LHS,B25D	A	4-53
226749	BLOCK,SPACER,ARMREST	19	7-35	230347	CYL,TIP,MK2,D70XD100,RHS,B25D	7	4-51
226773	KIT,SLIDE CONTROL	8	7-35	230347	CYL,TIP,MK2,D70XD100,RHS,B25D	A	4-53
226815	KIT,VALVE REPAIR	31	4-7	230357	CYL,SUSP.STRUT,LHS,T3	3	7-77
226817	KIT,SWITCH/HARNESS REPAIR	15	4-7	230357	CYLINDER,SUSP.STRUT,LHS,ASSY	A	7-83
226818	KIT,REPAIR,PEDAL & BASE	7	4-7	230358	CYL,SUSP.STRUT,RHS,T3	2	7-77
226820	VALVE ASSEMBLY,120/120 BAR	29	4-7	230358	CYLINDER,SUSP.STRUT,RHS,ASSY	A	7-83
226821	PEDAL & BASE ASSEMBLY	2	4-7	240498	HOSE ASSY,TEST,MINIMESS,2.5M	3	10-31
226831	DISC,FILTER 16MM		8-5	240499	HOSE ASSY,TEST,MINIMESS,1.0M	4	10-31
226831	DISC, FILTER, 16MM	18	5-7	240980	HOSE	5	2A-75
226832	CIRCLIP, INTERNAL	19	5-7	240980	HOSE	5	2B-69
226835	KIT, SERVICE, QUICK EXHAUST VALVE	20	5-7	241146	ASSY,HOSE,HVAC,FWAL,DRY	4	7-45
				241147	ASSY,HOSE,HVAC,DRY,UNIT	3	7-45
226837	Casing assembly	1	7-47	241148	ASSY,HOSE,HVAC,UNIT,FWAL	2	7-45
226838	top cover assy	3	7-47	241206	HOSE	2	5-19
226839	flapper,floor	5	7-47	241218	HOSE	4	2A-75
226840	flapper,defrost / dash	6	7-47	241218	HOSE	4	2B-69
226841	bracket mtg,fresh air actuator	11	7-47	241223	HOSE	4	5-3
226842	retainer,aircon coil	16	7-47	241224	HOSE	3	2A-75
226843	THERMOSTAT	17	7-47	241224	HOSE	3	2B-69
226844	clip,panel	18	7-47	241225	HOSE	2	2A-75
226845	relay board	50	7-47	241225	HOSE	2	2B-69
226846	wiring harness	51	7-47	241229	HOSE	6	4-51
226848	VALVE, SHUTTLE	5	4-25	241230	HOSE	5	4-51
226848	VALVE, SHUTTLE	5	4-27	241231	HOSE	4	4-51
226849	VALVE, PRESSURE REDUCING	6	4-25	241232	HOSE	3	4-51
226849	VALVE, PRESSURE REDUCING	6	4-27	241252	HOSE	1	3-117
226850	VALVE, PRIORITY, STEERING	12	4-25	241414	HOSE	12	4-49
226850	VALVE, PRIORITY, STEERING	12	4-27	241454	HOSE	7	5-9
226851	COIL, DIRECTIONAL CONTROL	17	4-25	241454	HOSE	8	5-9
226851	COIL, DIRECTIONAL CONTROL	17	4-27	241455	HOSE	6	5-9
226852	ORIFICE WASHER, 1.2	18	4-25	241458	HOSE	4	5-9
226852	ORIFICE WASHER, 1.2	18	4-27	241458	HOSE	5	5-9
226853	ORIFICE, SCREW, 0.6	19	4-25	241459	HOSE	3	5-3
226853	ORIFICE, SCREW, 0.6	19	4-27	241460	HOSE	2	5-3
226857	KIT, SEAL	25	4-25	241461	HOSE	1	5-5
226857	KIT, SEAL	25	4-27	241465	HOSE,HVAC,COND,FWALL	2	7-49
226858	VALVE,BIN TIP SECTION COMPLETE	1	4-29	241466	HOSE,HVAC,COMP,COND	1	7-49
226858	VALVE, BIN TIP SECTION COMPLETE	26	4-25	241573	HOSE	3	4-43
226859	KIT,CAP TIP LEVER	2	4-29	241574	HOSE	2	4-43
226860	KIT,SEAL,SPOOL STOP	3	4-29	241575	HOSE	1	4-43
226861	KIT,SPRING	4	4-29	241618	HOSE	5	3-123
226862	VALVE,RELIEF,080	5	4-29	241618	HOSE	6	3-159
226863	VALVE,RELIEF,280	6	4-29	241619	HOSE	4	3-123
226864	KIT,SEAL,RELIEF VALVE	7	4-29	241619	HOSE	5	3-159

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
241620	HOSE	4	3-103	262082	KIT,PLANETARY HUB	3	3-179
243003	HOSE	9	4-33	262082	KIT,PLANETARY HUB	A	3-187
243027	HOSE	11	4-49	262300	W/SET,750/65R25,XAD65	1	3-191
243157	HOSE	2	4-51	262301	W/SET,23.5R25,XADN	1	3-189
243303	HOSE	10	4-49	262449	KIT,GASKET,HVAC FRESH	12	7-43
243304	HOSE	9	4-49	262506	KIT,FINAL DRIVE	3	3-103
243309	HOSE	1	4-15	262506	KIT,FINAL DRIVE	3	3-123
243309	HOSE	2	4-15	262506	KIT,FINAL DRIVE	4	3-159
243315	HOSE	8	4-33	262778	ASSY,W/BEAM,WEIGHING SYS	5	7-95
243316	HOSE	7	4-33	262867	KIT,TYRE INFLATION-ALL D#	1	10-37
243317	HOSE	6	4-33	262900	ASSY,B/HEAT,HOSE GUARD	1	2A-69
243318	HOSE	8	4-49	262900	ASSY,B/HEAT,HOSE GUARD	1	2B-63
243319	HOSE	7	4-49	263269	ASSY,DIFF HOUSING,MACHINED	2	3-133
243320	HOSE	6	4-49	263269	ASSY,DIFF HOUSING	2	3-167
243328	HOSE	5	4-49	263441	KIT,WIPER	4	6-7
243329	HOSE	4	4-49	263441	KIT,WIPER	A	6-11
243330	HOSE	3	4-49	263470	KIT,HARNESS,STRAIN GUAGE	1	6-49
243331	HOSE	2	4-49	263474	ASSY,DIFF CENTRE	1	3-167
243338	HOSE	5	4-31	263474	ASSY,DIFF CENTRE	2	3-139
243339	HOSE	4	4-31	263474	ASSY,DIFF CENTRE,LSD 35%,140	2	3-173
243340	HOSE	1	4-49	263474	ASSY,DIFF CENTRE,LSD 35%,140	A	3-143
243341	HOSE	1	4-51	263474	ASSY,DIFF CENTRE,LSD 35%,140	A	3-171
243396	HOSE	3	4-33	263474	ASSY,DIFF CENTRE,LSD 35%,140	A	3-177
243875	HOSE	1	4-33	263485	ASSY,DIFF CENTRE	1	3-133
243875	HOSE	2	4-33	263485	ASSY,DIFF CENTRE,LSD 18%,140	A	3-137
243876	HOSE	1	4-39	263530	KIT,BRAKE	2	3-123
243876	HOSE	1	4-41	263530	KIT,BRAKE	3	3-159
243883	HOSE	2	3-77	263592	KIT,SPEAKERS,BLAUPUNKT	1	6-31
243884	HOSE	1	3-77	263642	KIT,BONNET COMPL SMALL D# P&A	A	7-53
243887	HOSE	3	5-9	263642	KIT,BONNET COMPL SMALL D# P&A	A	7-55
243888	HOSE	1	5-3	263642	KIT,BONNET COMPL SMALL D# P&A	A	7-59
243944	HOSE	10	4-3	263818	KIT,HEADREST & ARMREST,DDH	11	7-35
243945	HOSE	9	4-3	263834	KIT,LINERS,8MM,BIN,B25D	1	7-103
243946	HOSE	8	4-3	263835	KIT,LINERS,8MM,BIN,B30D	1	7-103
243947	HOSE	7	4-5	263838	ASSY,DIFF CENTRE,LSD,MACHINED	1	3-137
243948	HOSE	6	4-5	263838	ASSY,DIFF CENTRE,LSD,MACH.	1	3-143
243949	HOSE	5	4-3	263838	ASSY,DIFF CENTRE,LSD,MACH.	1	3-171
243950	HOSE	4	4-3	263838	ASSY,DIFF CENTRE,LSD,MACH.	1	3-177
243951	HOSE	3	4-5	263898	ASSY,TRI-LINK,SPHERICAL	1	7-77
243954	HOSE	1	4-5	263898	ASSY,TRI-LINK,SPHERICAL	A	7-79
243954	HOSE	2	4-5	263936	KIT,ARMREST,RH	12	7-35
250192	T/CASE,13100	1	3-79	263937	KIT,ARMREST,LH	14	7-35
250298	T/MISS,ZF-6HP592C,ECOMAT	2	3-3	264041	KIT,10L RESERVOIR	2	5-9
250314	T/MISS,ZF-6HP592C,E2+	2	3-5	264041	KIT,10L RESERVOIR	A	5-17
251111	ENGINE,DC OM906LA T3	2	2A-5	264042	KIT,AIR DRYER	1	5-9
251113	ENGINE,DC OM926LA	2	2B-3	264042	Kit,Air Dryer	A	5-13
251115	ENGINE,DC OM906LA T2	2	2A-3	264103	ASSY,SEATBELT,SEAT,TRAINER	2	7-33
255001	RING,CLAMPING,OM906LA	1	2A-3	264137	KIT,ACCU,S/AFRICA	A	4-35
255001	RING,CLAMPING,OM906LA	1	2A-5	264138	KIT,ACCU,EURO	A	4-37
255001	RING,CLAMPING,OM906LA	1	2B-3	264139	KIT,ACCU,S/AFRICA,WDB	A	4-39
260326	W/SET,23.5R25,XADN,MICH	1	3-189	264140	KIT,ACCU,EURO,B30D,WDB	A	4-41
260401	KIT,BIN HEATING	A	2A-69	264241	KIT,MIRRORS,ELEC,ADJ	A	6-15
261891	PIN ASSY,ARTIC LOCK	1	7-89	264242	KIT,MIRRORS,MANUAL,ADJ	A	6-17
261891	PIN ASSY,ARTIC LOCK	1	7-91	264277	ASSY,DIFF HSG,PUMP,MACHINED	1	3-139
262068	W/SET,23.5R25,RL2+,GOOD	1	3-189	264277	ASSY,DIFF HOUSING,MACHINED	1	3-173
262082	KIT,PLANETARY HUB,5.2	3	3-101	264351	KIT,CAB,SPARE COMPLETE,B25D,G2	1	7-3
262082	KIT,PLANETARY HUB	3	3-111	264353	KIT,CAB,SPARE COMPLETE,B30D,G2	1	7-3
262082	KIT,PLANETARY HUB	3	3-119	264362	SHELL,CAB,SMALL,YELLOW	1	7-5
262082	KIT,PLANETARY HUB	3	3-121	264379	KIT,BRAKE	2	3-103
262082	KIT,PLANETARY HUB	3	3-145	264415	KIT,WDB COOLING,F/AXLE	A	4-43
262082	KIT,PLANETARY HUB,5.2	3	3-155	264427	KIT,BONNET ASSY	1	7-59
262082	KIT,PLANETARY HUB	3	3-157	264448	KIT,GASKET,HVAC SYSTEM	1	7-43

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
264661	KIT,RADIO,BLAUPUNKT	A	6-31	281318	TOOL,ENG,DC,PULLER	21	10-9
264799	KIT,RIBLESS BIN HEATING	A	2B-63	281322	TOOL,ENG,DC,DIAL GAUGE	1	10-3
280010	SPANNER,BEARING ADJ-HUB NUT	2	10-25	281325	TOOL,ENG,DC,DRIFT	13	10-9
280016	Loctite: 2 Form-A-Gasket		9-3	281326	TOOL,ENG,DC,STEPPED,DRIFT	14	10-9
280039	Loctite: 277 Threadlocker,Red HS		9-3	281328	TOOL,ENG,DC,HOSE,HIGH PRES-SURE	9	10-3
280071	GUAGE,INFLATOR,COMBI	2	10-37				
280082	CHAIN WRENCH-ADT OSC LOCK NUT	1	10-33	281329	TOOL,ENG,DC,TESTER	13	10-3
280085	Loctite:243 Threadlocker,Blue		9-3	281330	TOOL,ENG,DC,PIN,MAGNETIC	19	10-5
280089	Loctite: 272 Threadlocker,Red		9-3	281333	TOOL,ENG,DC,THRUST PIECE	22	10-9
280107	Loctite: 518 Anaerobic Gasket		9-3	281335	TOOL,ENG,DC,BOX,SUPERCOOLING	3	10-11
280111	Loctite: 599 Gasket,(High Temp)		9-3	281336	TOOL,ENG,DC,SLEEVE	31	10-5
280149	TOOL,BEARING RESISTANCE	1	10-25	281337	TOOL,ENG,DC,PUNCH	23	10-9
280257	TOOL KIT,CHARGING NITROGEN	2	10-29	281340	TOOL,ENG,DC,HOLDER,DIAL GAUGE	2	10-3
280261	TOOL,ADJUSTABLE C SPANNER	5	10-31	281349	TOOL,ENG,DC,WRENCH SOCKET	22	10-5
280272	TOOL,CASSETTE SEAL	3	10-25	281365	TOOL,ENG,DC,ADAPTION PARTS	10	10-3
280450	Loctite: 767 Anti-seize		9-3	281366	TOOL,PISTON RING CLAMPING	8	10-7
280470	WRENCH,NECKBUSH NUT	6	10-31	281368	TOOL,ENG,DC,TESTER	11	10-3
280479	MERC,MINIDIAG2	2	10-35	281376	TOOL,ENG,DC,SLOTTED NUT WRENCH	1	10-7
280532	TOOL,7C/8,5C POINTER SET	22	10-15				
280533	PULLER,BEARING,T/CASE 9100	23	10-15	281377	TOOL,ENG,DC,SCREWDRIVER BIT	25	10-5
280547	NUT,TORQUE,MULTIPLIER OSCILL	2	10-33	281378	TOOL,ENG,DC,ADITIONAL PIECE	16	10-9
281000	FIXTURE,LOCKING	1	10-13	281379	TOOL,ENG,DC,PULLER	26	10-5
281001	FIXTURE,TIGHTENING	2	10-13	281380	TOOL,ENG,DC,THREADED INSERT	33	10-5
281002	SHIELD,PUNCH	3	10-13	281381	TOOL,ENG,DC,SCREWDRIVER BIT	27	10-5
281003	PLUG,HEATING	4	10-13	281382	TOOL,ENG,DC,INSERTION DRIFT	17	10-9
281004	SEAL,PUNCH	5	10-13	281383	TOOL,ENG,DC,CONNECTOR,INJEC-TOR	5	10-3
281005	PRESS,TOOL BEARING	6	10-13				
281006	PIN,INSERTING TOOL	7	10-13	281384	TOOL,ENG,DC,LIFTING DEVICE	24	10-5
281007	SPEC.2 PIN SPANNER	8	10-13	281385	TOOL,ENG,DC,GUIDE SLEEVE	18	10-9
281008	TOOL,PRESS	9	10-13	281386	TOOL,ENG,DC,DRIFT	28	10-5
281008	TOOL,PRESS	19	10-15	281387	TOOL,ENG,DC,CENTERING DRIFT	29	10-5
281009	PLT,CLAMPING	10	10-13	281388	TOOL,ENG,DC,DRIFT	30	10-5
281013	PLUG,HEATING	11	10-13	281389	TOOL,ENG,DC,BLOCKING DEVICE	20	10-9
281016	GUIDE PIN,M12	12	10-13	281390	TOOL,ENG,DC,CRANKING DEVICE	6	10-3
281017	GUIDE PIN,M10	13	10-13	281391	TOOL,ENG,DC,TEST FLANGE	15	10-3
281018	FIXTURE,PRESS	14	10-13	281392	TOOL,ENG,DC,SLEEVE	19	10-9
281019	TOOL,PRESS	15	10-13	281394	TOOL,ENG,DC,DIAGRAM SHEETS	4	10-3
281020	FIXTURE,SUPPORT	16	10-13	281395	TOOL,ENG,DC,VALVE SEAT CUTTER	8	10-11
281021	FIXTURE,PRESS	17	10-13	281396	TOOL,ENG,DC,VALVE SEAT CUTTER	9	10-11
281024	SUPPORT FIXTURE	18	10-13	281398	TOOL,ENG,DC,DRIFT	2	10-7
281026	PRESS FIXTURE	20	10-15	281398	TOOL,ENG,DC,DRIFT	9	10-7
281027	PROTECTION FIXTURE	21	10-15	281400	TOOL,ENG,DC,CASE,SPECIAL TOOLS	1	10-11
281140	BASIC SET	4	10-27	281401	TOOL,ENG,DC,ADAPTER SET	2	10-11
281140	BASIC SET	8	10-27	281675	HOOK,LIFTING	1	10-17
281143	STAND,MAGNETIC	11	10-27	281676	PULLER	2	10-17
281144	INDICATOR,DIAL	10	10-27	281677	PULLER	3	10-17
281218	PLIERS,LIFTING	12	10-27	281678	PULLER,TWO LEG	4	10-17
281234	SHAFT,MEASURING	13	10-27	281679	TOOL,BASIC	5	10-17
281236	SHIMS,120	14	10-27	281680	PULLER	6	10-17
281266	FIXTURE,ADJUSTABLE	5	10-27	281681	PLT,EXTRACT	7	10-17
281267	SLEEVE,GRAB	3	10-27	281682	DEVICE,LIFTING	8	10-17
281268	SHAFT,MEASURING	1	10-27	281683	DRIFTER	9	10-17
281269	PISTON,MEASURING	2	10-27	281684	BLOWER,HOT AIR	10	10-17
281270	SLEEVE,GRAB	9	10-27	281685	BKT,ADAPTER LHS	11	10-17
281271	SLEEVE,GRAB	7	10-27	281686	BKT,ADAPTER RHS	12	10-17
281272	DRIVER,SEAL	6	10-27	281687	DRIFTER	13	10-19
281300	TOOL,ENG,DC,TORX BIT SET	18	10-3	281688	EYE,LIFTING	14	10-19
281306	TOOL,ENG,DC,REAMER	12	10-7	281689	INSERT,GRIPPING	15	10-19
281309	TOOL,ENG,DC,PULLER,28-37MM	4	10-11	281690	EXTRACTOR	16	10-19
281310	TOOL,ENG,DC,INTERNAL EXTRAC-TOR	5	10-11	281691	DEVICE,ADJUSTING	17	10-19
				281692	FIXTURE,HOLDING	18	10-19
281312	TOOL,ENG,DC,COUNTER SUPPORT	6	10-11	281693	DRIFTER	19	10-19

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
281694	GUIDE,SCREW	20	10-19	290665	PROPSHAFT,02838,5C8,5C 165M85-02	9	3-99
281695	DRIFTER	21	10-19	310066	DIFF,DK-7	1	3-119
281696	DEVICE,LIFTING	22	10-19	310066	DIFFERENTIAL HEAD	1	3-125
281697	MOUNTING	23	10-19	310066	DIFF	1	3-145
281698	MOUNTING	24	10-21	310066	DIFFERENTIAL HEAD	1	3-147
281699	PRESSURE PIECE	25	10-21	310104	DIFF	1	3-155
281700	PRESSURE PIECE	26	10-21	310104	DIFFERENTIAL ASSEMBLY	1	3-161
281701	DRIFT ASSY	27	10-21	310105	DIFF HEAD	1	3-101
281702	TOOL	28	10-21	310105	DIFF HEAD	1	3-103
281703	MOUNTING	29	10-21	310105	DIFF,HK,3.182,LS,25%,CCW,60DEG	1	3-105
281704	BRACKET	30	10-21	310108	DIFF	1	3-179
281705	DEVICE,CLAMPING	31	10-21	310108	DIFFERENTIAL ASSEMBLY	1	3-181
281706	TOOL,TEST	32	10-21	310109	DIFF	1	3-111
281707	KIT,PRESSURE TESTER	32	10-21	310109	DIFFERENTIAL ASSEMBLY	1	3-113
281708	SUPPORT	33	10-21	320119	AXLE,MID,DK7,3.18 X 5.2,B25D	A	3-145
281709	DEVICE,HOLDING	34	10-21	320122	AXLE,MIDDLE	A	3-119
281709	DEVICE,HOLDING	35	10-23	320123	AXLE,REAR,HK,B30D(PROD)	A	3-155
281710	DEVICE,LIFTING	36	10-23	320394	AXLE,F,HK,3.18X5.2,SWB	A	3-103
281711	INSERT,HEXAGON	37	10-23	320395	AXLE,M,BELL,3.18X5.2,SWB	A	3-123
281712	EXTRACTOR	38	10-23	320519	AXLE,MIDDLE,BELL,DISC	A	3-121
281713	STAND	39	10-23	320520	AXLE,REAR,BELL,DISC	A	3-157
281714	PUNCH	40	10-23	320527	AXLE,REAR,B25D	A	3-179
281715	PUNCH	41	10-23	320568	AXLE,MK2,F,HK,DISC	A	3-101
281716	BRACKET	42	10-23	320569	AXLE,MK2,F,DK,DISC,B25D	A	3-111
281717	PIN,CONTROL THREADED	43	10-23	320611	AXLE,R,BELL,3.18X5.2,SWB	A	3-159
290119	P/SHAFT,10757C7C 148M70 -010	14	3-99	322004	DIFF	1	3-121
290131	AIR CLEANER,FRG15,RADIAL SEAL	1	2A-73	322004	DIFF,3.182:1,LS 18%,T/D	A	3-133
290131	AIR CLEANER,FRG15,RADIAL SEAL	1	2B-67	322007	DIFF	1	3-157
290131	AIR CLEANER,FRG15,RADIAL SEAL	2	2A-71	322007	DIFF,3.182:1,LS 35%,CW,H/D	A	3-167
290131	AIR CLEANER,FRG15,RADIAL SEAL	2	2B-65	322008	DIFF	1	3-123
290139	PROPSHAFT,06008,5C8,5C 165M85	1	3-97	322008	DIFF,3.182:1,LS 35%,T/D	A	3-139
290139	PROPSHAFT,06008,5C8,5C 165M85	1	3-99	322009	DIFF	2	3-159
290230	PRE-CLEANER (ADT 240)	16	2A-71	322009	DIFF,3.182:1,LS 35%,H/D,CW	A	3-173
290230	PRE-CLEANER (ADT 240)	16	2B-65	361624	KIT,SERVICE 100HR SMALL ADT		8-3
290289	PROPSHAFT,02807C,7C L/F/L	4	3-97	361625	KIT,SER 500HR SMALL ADT,WET		8-3
290289	PROPSHAFT,02807C,7C L/F/L	4	3-99	361626	KIT,SER 500HR SMALL ADT,DRY		8-3
290297	PROSHAFT,12007C7C-015 L/F/L	14	3-97	361627	KIT,SER 1000HR SMALL ADT,DRY		8-3
290298	P/SHAFT,0978,7C-7C-010, LUBE-FOR-LIFE	17	3-99	361628	KIT,SER 1000HR SMALL ADT,WET		8-3
				361629	KIT,SER 2000HR SMALL ADT,ALL		8-3
290299	PROPSHAFT,10207C7C-010 L/F/L	17	3-97	361630	KIT,SER 3000HR SMALL ADT,DRY		8-5
290343	P/SHAFT,0845,7C-7C,148M70-010	17	3-99	361631	KIT,SER 3000HR SMALL ADT,WET		8-5
290366	CALIPER,BRAKE,ROCKWELL,MIN-ERAL	1	3-185	361632	KIT,SER 4000HR SMALL ADT,ALL		8-5
				361652	KIT,SERVICE 6000HR B25D		8-5
290366	BRAKE CALIPER:ROCKWELL MIN-ERAL	2	3-101	361653	KIT,SERVICE 6000HR B30D		8-5
				900450	PIPE,W/WASHER	2	6-5
290366	CALIPER,BRAKE	2	3-111	900450	PIPE,W/WASHER	3	6-7
290366	CALIPER,BRAKE	2	3-119	910142	WINDOW SEAL:SELF ADHV	1	2B-79
290366	CALIPER,BRAKE,ROCKWELL,MIN-ERAL	2	3-121	910142	WINDOW SEAL:SELF ADHV	2	2B-79
				910223	PINCHWELD:LARGE 8MMX15MM	2	7-69
290366	CALIPER,BRAKE	2	3-145	910241	PINCH WELD,BOOTSEAL,1.6mm PLATE	1	7-63
290366	CALIPER,BRAKE,ROCKWELL,MIN-ERAL	2	3-155	910241	PINCH WELD,BOOTSEAL,1.6mm PLATE	2	7-63
290366	CALIPER,BRAKE,ROCKWELL,MIN-ERAL	2	3-157	910241	PINCH WELD,BOOTSEAL,1.6mm PLATE	3	7-63
290366	CALIPER,BRAKE	2	3-179	910241	PINCH WELD,BOOTSEAL,1.6mm PLATE	4	7-63
290421	ACTUATOR,PARK BRAKE,DX195	1	3-91	910241	PINCH WELD,BOOTSEAL,1.6mm PLATE	5	7-63
290421	ACTUATOR, PARK BRAKE	1	3-93	910241	PINCH WELD,BOOTSEAL,1.6mm PLATE	6	7-63
290433	SEAT,OPERATOR	1	7-31				
290433	SEAT,OPERATOR,DDH2	1	7-35				
290444	SEAT,OPERATOR	1	7-31				
290444	SEAT,OPERATOR,DDH	1	7-35				
290665	PROPSHAFT,02838,5C8,5C 165M85-02	9	3-97	910264	INSULATION,HOSE,HVAC	1	7-45

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
910321	STRIP,GROMMET,1.6-4X8.5,BLACK	1	7-69
218690	BONNET,SHELL	1	7-53
206987A	PLANET GEAR	9	3-187
207061A	SUNGEAR	8	3-187
AT310335	FILLER CAP	1	2A-81
AT310335	FILLER CAP	1	2B-75
DC100059	PIN, DOWEL, BEARING CAP	23	2B-5
DC100059	PIN,DOWEL,BEARING CAP	23	2A-7
DC100080	SCREW	10	2A-23
DC100080	SCREW	10	2B-19
DC100085	SCREW,HEX	100	2A-11
DC100085	SCREW,HEX	100	2B-9
DC100085	SCREW,OIL COOLER TO CRANKCASE	130	2B-49
DC100091	SCREW,HEX	580	3-9
DC100091	SCREW,HEX	590	3-9
DC100112	SCREW,FUEL PUMP TO C/CASE	35	2A-27
DC100112	SCREW,FUEL PUMP TO C/CASE	35	2B-23
DC100112	SCREW,OIL COOLER TO CRANKCASE	130	2A-55
DC100112	SCREW,CYLINDER TO BRACKET	180	2A-43
DC100112	SCREW,CYLINDER TO BRACKET	180	2B-39
DC100142	BOLT,BANJO PIPE TO SOLENOID VALVE	90	2A-33
DC100142	BOLT,BANJO PIPE TO SOLENOID VALVE	90	2B-29
DC100143	BOLT,BANJO,FUEL PIPE TO VALVE	110	2A-33
DC100143	BOLT,BANJO,FUEL PIPE TO VALVE	110	2B-29
DC100173	PLUG, SCREW, MAIN OIL PASSAGE	137	2B-5
DC100173	PLUG,SCREW	40	2A-31
DC100173	PLUG,SCREW	40	2B-27
DC100173	PLUG,SCREW,MAIN OIL PASSAGE	137	2A-7
DC100177	PLUG, SCREW	40	2B-7
DC100177	PLUG,ALLEN	40	2A-9
DC100198	SCREW,Water Pump to Crankcase	24	2A-59
DC100198	SCREW,Water Pump to Crankcase	24	2B-53
DC100296	NUT,TURBO TO MANIFOLD	10	2A-35
DC100296	NUT, TURBO TO MANIFOLD M10	10	2B-31
DC100296	NUT,FLANGED,EXH/BRAKE TO TURBO	125	2A-43
DC100296	NUT,FLANGED,EXH/BRAKE TO TURBO	125	2B-39
DC100316	STUD, TURBO TO EXH/MANIFOLD	8	2B-31
DC100316	STUD	20	2A-43
DC100316	STUD	20	2B-39
DC100319	CLAMP,CHARGE-AIR PIPE TO TURBO	152	2A-35
DC100319	CLAMP, CHARGE-AIR PIPE TO TURBO	152	2B-31
DC100326	CLAMP, HOSE TO BREATHER PIPE	60	2B-31
DC100326	CLAMP,RETURN PIPE TO CRANK-CASE	125	2A-57
DC100326	CLAMP,RETURN PIPE TO CRANK-CASE	125	2B-51
DC100346	SCREW	190	2A-51
DC100346	SCREW	190	2B-45
DC100352	SCREW,FILTER TO CYL/HEAD	65	2A-31
DC100352	SCREW,FILTER TO CYL/HEAD	65	2B-27
DC100352	SCREW,SUPPORT To crankcase	85	2A-65
DC100352	SCREW,SUPPORT To crankcase	85	2B-59
DC100359	NUT,FAN Clutch at adaptor piece	20	2A-61
DC100359	NUT, FAN Clutch at adaptor piece	20	2B-55
DC100359	NUT,CYLINDER TO LEVER	210	2A-43
DC100359	NUT,CYLINDER TO LEVER	210	2B-39
DC100366	SCREW,FLANGED,CONTROL UNIT	11	2A-45
DC100366	SCREW,FLANGED,CONTROL UNIT	11	2A-47
DC100366	SCREW,FLANGED,CONTROL UNIT	11	2B-41
DC100366	SCREW,OIL FILTER TO CRANKCASE	75	2A-55
DC100366	SCREW,OIL FILTER TO CRANKCASE	75	2B-49
DC100366	SCREW,FLANGED,40MM LG	230	2A-59
DC100366	SCREW,FLANGED,40MM LG	230	2B-53
DC100366	SCREW,CHARGE-AIR PIPE TO HOUSING	340	2A-35
DC100369	SCREW, CHARGE-AIR PIPE TO HOUSING	450	2B-31
DC100378	SCREW,LEVER TO SHAFT	110	2A-43
DC100378	SCREW,LEVER TO SHAFT	110	2B-39
DC100381	CLAMP,MOLDED HOSE TO TURBO	55	2A-35
DC100381	CLAMP, MOLDED HOSE TO TURBO	55	2B-31
DC100383	NUT,CHARGE-AIR PIPE TO HOUSING	345	2A-35
DC100383	NUT,HEATER PLUG TO GROUND	580	2A-45
DC100383	NUT,HEATER PLUG TO GROUND	580	2A-47
DC100383	NUT,HEATER PLUG TO GROUND	580	2B-41
DC100385	SCREW,HEAT SHEILD	30	2A-35
DC100385	SCREW, HEAT SHEILD, M8X16	30	2B-31
DC100385	SCREW, INTAKE PIPE TO CRANK-CASE	60	2A-39
DC100385	SCREW, INTAKE PIPE TO CRANK-CASE	60	2B-35
DC100385	SCREW,OIL COOLER TO COVER	120	2A-55
DC100385	SCREW,OIL COOLER TO COVER	120	2B-49
DC100385	SCREW,BRACKET TO FLANGED ELBOW	145	2A-43
DC100385	SCREW,BRACKET TO FLANGED ELBOW	145	2B-39
DC100390	SCREW,CHARGE-AIR PIPE ON MEMBER	160	2A-35
DC100390	SCREW, CHARGE-AIR PIPE ON MEMBER	160	2B-31
DC100390	SCREW,BRACKET TO CHARGE-AIR PIPE	251	2A-35
DC100408	SCREW,Pipe Socket to Cyl/Head	106	2A-59
DC100408	SCREW,Pipe Socket to Cyl/Head	106	2B-53
DC100413	SCREW,OIL PUMP TO CRANKCASE	20	2A-53
DC100413	SCREW,OIL PUMP TO CRANKCASE	20	2B-47
DC100414	SCREW,RETURN PIPE TO TURBO	105	2A-57
DC100414	SCREW,RETURN PIPE TO TURBO	105	2B-51
DC100414	SCREW	140	2A-9
DC100507	SCREW	29	2A-9
DC100507	SCREW	29	2B-7
DC100507	SCREW,FAN Pulley to wATER Pump	310	2A-59
DC100507	SCREW,FAN Pulley to wATER Pump	310	2B-53
DC100538	SCREW,STARTER TO TIMING CASE	110	2A-49
DC100538	SCREW,STARTER TO TIMING CASE	110	2B-43
DC100545	SCREW,SOLENOID VALVE TO BRACKET	20	2A-33
DC100545	SCREW,SOLENOID VALVE TO BRACKET	20	2B-29
DC100597	SCREW, FLANGED, TIMING CASE, 25MM	97	2B-7
DC100597	SCREW,GUIDE TUBE	210	2A-11
DC100597	SCREW,GUIDE TUBE	210	2B-9
DC100597	SCREW,BRACKET TO CHARGING AIR PIPE	25	2A-33
DC100597	SCREW,BRACKET TO CHARGING AIR PIPE	25	2B-29
DC100597	SCREW,SUCTION PIPE TO CRANK-CASE	55	2A-53

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
DC100597	SCREW,SUCTION PIPE TO CRANK-CASE	55	2B-47
DC100597	SCREW,LIFTING Eye to cylinder head	85	2A-63
DC100597	SCREW,LIFTING Eye to cylinder head	85	2B-57
DC100597	SCREW,FLANGED,TIMING CASE	97	2A-9
DC100597	SCREW, FLANGED, COVER TO COMP	250	2A-39
DC100597	SCREW, FLANGED, COVER TO COMP	250	2B-35
DC100597	SCREW,BRACKET TO WATER PUMP	280	2A-35
DC100597	SCREW, BRACKET TO OIL FILTER	306	2A-51
DC100597	SCREW, BRACKET TO OIL FILTER	306	2B-45
DC100597	SCREW, BRACKET TO WATER PUMP	360	2B-31
DC100604	NUT,BRACKET TO CHARGING AIR PIPE	30	2A-33
DC100604	NUT,BRACKET TO CHARGING AIR PIPE	30	2B-29
DC100604	NUT,CHARGE-AIR PIPE AT WATER PUMP	175	2A-35
DC100604	NUT, CHARGE-AIR PIPE AT WATER PUMP	175	2B-31
DC100604	NUT, ALTERNATOR TO SUPPORT	304	2A-51
DC100604	NUT, ALTERNATOR TO SUPPORT	304	2B-45
DC100621	SCREW,PIPE TO DIPSTICK GUIDE TUBE	45	2A-53
DC100621	SCREW,PIPE TO DIPSTICK GUIDE TUBE	45	2B-47
DC100621	SCREW,SUPPORT ON OIL INTAKE PIPE	55	2A-53
DC100621	SCREW,SUPPORT ON OIL INTAKE PIPE	55	2B-47
DC100636	SCREW,FITTING ON INJECTOR	295	2A-13
DC100636	SCREW,FITTING ON INJECTOR	295	2A-15
DC100636	SCREW, FITTING ON INJECTOR	295	2B-11
DC100657	SCREW,FLANGED,70MM LG	232	2A-59
DC100657	SCREW,FLANGED,70MM LG	232	2B-53
DC100659	SCREW,GUIDE TUBE	340	2A-11
DC100659	SCREW,GUIDE TUBE	340	2B-9
DC100662	SCREW, ALTERNATOR TO SUPPORT	303	2A-51
DC100662	SCREW, ALTERNATOR TO SUPPORT	303	2B-45
DC100664	NUT,FLAME START SYSTEM	550	2A-45
DC100664	NUT,FLAME START SYSTEM	550	2A-47
DC100664	NUT,FLAME START SYSTEM	550	2B-41
DC100670	SCREW,BEARING CAP	29	2A-7
DC100671	SCREW, FLANGED	296	2B-5
DC100671	SCREW,OIL FILTER TO CRANKCASE	75	2A-55
DC100671	SCREW,OIL FILTER TO CRANKCASE	75	2B-49
DC100671	SCREW,FLANGED	296	2A-7
DC100673	SCREW, FLANGED, TIMING CASE, 60MM	95	2B-7
DC100673	SCREW,FLANGED,TIMING CASE	95	2A-9
DC100674	SCREW, FLANGED, TIMING CASE, 80MM	95	2B-7
DC100674	SCREW,FLANGED,TIMING CASE	95	2A-9
DC100677	CLAMP,GUIDE TUBE	235	2A-11
DC100677	CLAMP,GUIDE TUBE	235	2B-9
DC100678	WASHER,VALVE SPRING	65	2A-13
DC100678	WASHER,VALVE SPRING	65	2A-15
DC100678	WASHER, VALVE SPRING	65	2B-11
DC100679	SCREW,CYLINDER HEAD TO CRANK-CASE	185	2A-13
DC100679	SCREW,CYLINDER HEAD TO CRANK-CASE	185	2A-15
DC100679	SCREW, CYLINDER HEAD TO CRANK-CASE	185	2B-11
DC100682	SCREW,ADJUSTING	345	2A-17
DC100682	SCREW,ADJUSTING	345	2B-13
DC100683	NUT,ADJUSTING SCREW	350	2A-17
DC100683	NUT,ADJUSTING SCREW	350	2B-13
DC100684	WASHER	365	2A-17
DC100684	WASHER	365	2B-13
DC100685	SCREW,C/AIR ELBOW TO CYL HEAD	75	2A-41
DC100685	SCREW,C/AIR ELBOW TO CYL HEAD	75	2B-37
DC100685	SCREW,ROCKER SHAFT TO CYLIN-DER HEAD	380	2A-17
DC100685	SCREW,ROCKER SHAFT TO CYLIN-DER HEAD	380	2B-13
DC100686	SCREW,COVER TO CYLINDER HEAD	74	2A-19
DC100686	SCREW,COVER TO CYLINDER HEAD	74	2B-15
DC100687	PIN,DOWEL,GEAR TO CRANKSHAFT	10	2A-21
DC100687	PIN,DOWEL,GEAR TO CRANKSHAFT	10	2B-17
DC100688	WASHER,THRUST,STANDARD	25	2A-21
DC100688	WASHER,THRUST,STANDARD	25	2B-17
DC100689	WASHER,THRUST REPAIR SIZE I,0.30MM	25	2A-21
DC100689	WASHER,THRUST REPAIR SIZE I,0.30MM	25	2B-17
DC100690	WASHER,THRUST,REPAIR SIZE II,0.50MM	25	2A-21
DC100690	WASHER,THRUST,REPAIR SIZE II,0.50MM	25	2B-17
DC100691	SCREW,DAMPER/HUB TO CRANK-SHAFT	43	2A-21
DC100691	SCREW,DAMPER/HUB TO CRANK-SHAFT	43	2B-17
DC100691	SCREW,FLYWHEEL TO CRANKSHAFT	70	2A-21
DC100691	SCREW,FLYWHEEL TO CRANKSHAFT	70	2B-17
DC100692	SCREW,PUMP TO CRANKCASE	20	2A-27
DC100692	SCREW,PUMP TO CRANKCASE	20	2B-23
DC100693	SCREW,SHEAVE PULLEY	27	2A-27
DC100693	SCREW,SHEAVE PULLEY	27	2B-23
DC100694	SCREW,FILTER TO CYL/HEAD	65	2A-31
DC100694	SCREW,FILTER TO CYL/HEAD	65	2B-27
DC100695	STUD,CHARGE-AIR PIPE AT WATER PUMP	170	2A-35
DC100695	STUD, CHARGE-AIR PIPE AT WATER PUMP	170	2B-31
DC100696	NUT,GEAR TO COMPRESSOR	55	2A-37
DC100696	NUT,GEAR TO COMPRESSOR	55	2B-33
DC100698	SCREW,MANIFOLD TO CYLINDER HEAD	30	2A-43
DC100698	SCREW,MANIFOLD TO CYLINDER HEAD	30	2B-39
DC100699	NUT,LEVER TO THROTTLE VALVE	115	2A-43
DC100699	NUT,LEVER TO THROTTLE VALVE	115	2B-39
DC100700	NUT,ENGINE START/STOP	388	2A-45
DC100700	NUT,ENGINE START/STOP	388	2A-47
DC100700	NUT,ENGINE START/STOP	388	2B-41
DC100702	SCREW,WATER Pump to Crankcase	28	2A-59
DC100702	SCREW,WATER Pump to Crankcase	28	2B-53
DC100703	STUD	40	2A-61
DC100703	STUD	40	2B-55
DC100704	SCREW,SPACER To vibration damper	55	2A-61
DC100704	SCREW, SPACER To vibration damper	55	2B-55
DC100707	SCREW,COMPRESSOR To support	80	2A-65

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
DC100707	SCREW,COMPRESSOR To support	80	2B-59
DC100708	SCREW, BRACKET TO CRANKCASE	302	2A-51
DC100708	SCREW, BRACKET TO CRANKCASE	302	2B-45
DC100715	SCREW, ALTERNATOR	20	2A-51
DC100715	SCREW, ALTERNATOR	20	2B-45
DC100739	SCREW, BEARING CAP	29	2B-5
DC100739	SCREW,BEARING CAP	29	2A-7
DC100741	SCREW,INJECTOR TO CYL HEAD	315	2A-13
DC100741	SCREW,INJECTOR TO CYL HEAD	315	2A-15
DC100741	SCREW, INJECTOR TO CYL HEAD	315	2B-11
DC100742	SCREW, FLANGED, TIMING CASE, 160MM	95	2B-7
DC100742	SCREW,FLANGED,TIMING CASE	95	2A-9
DC100743	SCREW,COMPRESSOR TO CRANK-CASE	110	2A-37
DC100743	SCREW,COMPRESSOR TO CRANK-CASE	110	2B-33
DC100744	SCREW,FLANGED	65	2A-41
DC100744	SCREW,FLANGED	65	2B-37
DC100745	SCREW,C/AIR ELBOW TO CYL HEAD	78	2A-41
DC100745	SCREW,C/AIR ELBOW TO CYL HEAD	78	2B-37
DC100755	PIN, SPRING	301	2A-51
DC100755	PIN, SPRING	301	2B-45
DC100764	WASHER, ALTERNATOR	280	2A-51
DC100764	WASHER, ALTERNATOR	280	2B-45
DC120029	PLUG,SCREW,OIL DRAIN	20	2A-11
DC120029	PLUG,SCREW,OIL DRAIN	20	2B-9
DC120057	HELICOIL,M8X12	165	2A-17
DC120057	HELICOIL,M8X12	165	2B-13
DC120058	HELICOIL,M8X116	170	2A-17
DC120058	HELICOIL,M8X116	170	2B-13
DC120059	HELICOIL,M10X15	160	2A-17
DC120059	HELICOIL,M10X15	160	2B-13
DC120061	HELICOIL,M12X1.5X12	155	2A-17
DC120061	HELICOIL,M12X1.5X12	155	2B-13
DC120104	PLUG, SCREW	50	2B-7
DC120114	PLUG, SCREW, MAIN OIL PASSAGE	167	2B-5
DC120114	PLUG,SCREW	150	2A-9
DC120114	PLUG,SCREW,MAIN OIL PASSAGE	167	2A-7
DC120116	PLUG, SCREW, CYL/HEAD	113	2B-5
DC120116	PLUG,SCREW,CYL/HEAD	113	2A-7
DC120158	PLUG, SCREW, OIL PASSAGE REAR	125	2B-5
DC120158	PLUG,SCREW,OIL PASSAGE REAR	125	2A-7
DC120170	PLUG,SCREW , OIL PASSAGE OIL PUMP	161	2B-5
DC120170	PLUG,SCREW,OIL PASSAGE OIL PUMP	161	2A-7
DC120182	BOLT,BANJO FEED PIPE TO OIL FIL-TER HD	55	2A-57
DC120182	BOLT,BANJO FEED PIPE TO OIL FIL-TER HD	55	2B-51
DC120182	BOLT, BANJO	190	2A-39
DC120182	BOLT, BANJO	190	2B-35
DC120195	PLUG, EXPANSION 40MM	53	2B-5
DC120195	PLUG,EXPANSION,40MM	25	2A-15
DC120195	PLUG, EXPANSION, 40MM	25	2B-11
DC120195	PLUG,EXPANSION 40MM	53	2A-7
DC120196	PLUG, EXPANSION 42MM	53	2B-5
DC120196	PLUG,EXPANSION 42MM	53	2A-7
DC120200	PLUG,SENDER	85	2A-11
DC120200	PLUG,SENDER	85	2B-9
DC120209	CONNECTOR,FUEL LINE	35	2A-29
DC120209	CONNECTOR,FUEL LINE	35	2B-25
DC120210	NUT,UNION FUEL LINES	40	2A-29
DC120210	NUT,UNION FUEL LINES	40	2B-25
DC120211	BOLT,BANJO	25	2A-29
DC120211	BOLT,BANJO	25	2B-25
DC120218	HOUSING,PLUG FLAME START SYS-TEM	544	2A-45
DC120218	HOUSING,PLUG FLAME START SYS-TEM	544	2A-47
DC120218	HOUSING,PLUG FLAME START SYS-TEM	544	2B-41
DC120220	PIN,BUSHING,HEATER PLUG TO GROUND	574	2A-45
DC120220	PIN,BUSHING,HEATER PLUG TO GROUND	574	2A-47
DC120220	PIN,BUSHING,HEATER PLUG TO GROUND	574	2B-41
DC120221	PIN,SOCKET HOUSING FLAME START	526	2A-45
DC120221	PIN,SOCKET HOUSING FLAME START	526	2A-47
DC120221	PIN,SOCKET HOUSING FLAME START	526	2B-41
DC120222	HOUSING,PIN,CONTROL MODULE	205	2A-45
DC120222	HOUSING,PIN,CONTROL MODULE	205	2A-47
DC120222	HOUSING,PIN,CONTROL MODULE	205	2B-41
DC120226	PLUG, EXPANSION	95	2B-5
DC120226	PLUG,EXPANSION	95	2A-7
DC120227	PLUG, SCREW, WATER DRAIN	149	2B-5
DC120227	PLUG,SCREW,WATER DRAIN	149	2A-7
DC120228	FITTING,GUIDE TUBE	218	2A-11
DC120228	FITTING,GUIDE TUBE	218	2B-9
DC120231	HELICOIL,M22X1.5X8.0	135	2A-17
DC120231	HELICOIL,M22X1.5X8.0	135	2B-13
DC120232	HELICOIL,M14X1X7.0	140	2A-17
DC120232	HELICOIL,M14X1X7.0	140	2B-13
DC120233	HELICOIL,M16X1.5X10.5	145	2A-17
DC120233	HELICOIL,M16X1.5X10.5	145	2B-13
DC120234	HELICOIL,M14X1.5X14	150	2A-17
DC120234	HELICOIL,M14X1.5X14	150	2B-13
DC120235	UNION,THREADED,CONSTANT THROTTLE	190	2A-17
DC120235	UNION,THREADED,CONSTANT THROTTLE	190	2B-13
DC120236	PLUG,EXPANSION	325	2A-17
DC120236	PLUG,EXPANSION	325	2B-13
DC120237	BOLT,BANJO,FUEL PIPE TO FILTER	105	2A-33
DC120237	BOLT,BANJO,FUEL PIPE TO FILTER	105	2B-29
DC120238	SOCKET,Pipe To water Pump	112	2A-59
DC120238	SOCKET,Pipe To water Pump	112	2B-53
DC120239	UNION,Banjo	245	2A-59
DC120239	UNION,Banjo	245	2B-53
DC120240	FITTING,Heat Feed	265	2A-59
DC120240	FITTING,Heat Feed	265	2B-53
DC120243	TERMINAL,PIN,CONTROL MODULE	235	2A-45
DC120243	TERMINAL,PIN,CONTROL MODULE	235	2A-47
DC120243	TERMINAL,PIN,CONTROL MODULE	235	2B-41
DC120244	CAP,CONTROL MODULE	220	2A-45
DC120244	CAP,CONTROL MODULE	220	2A-47
DC120244	CAP,CONTROL MODULE	220	2B-41
DC120245	PLUG,ENGINE CONTROL	265	2A-45
DC120245	PLUG,ENGINE CONTROL	265	2A-47
DC120245	PLUG,ENGINE CONTROL	265	2B-41
DC120246	SHOE,CABLE UNIT	280	2A-45
DC120246	SHOE,CABLE UNIT	280	2A-47

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
DC120246	SHOE,CABLE UNIT	280	2B-41
DC120247	PLUG,COOLING WATER TEMP	70	2A-45
DC120247	PLUG,FUEL TEMP SENDER UNIT	70	2A-45
DC120247	PLUG,CAMSHAFT POSITION UNIT	70	2A-45
DC120247	PLUG,CRANKSHAFT POSITION UNIT	70	2A-45
DC120247	PLUG,OIL TEMP SENSOR	70	2A-45
DC120247	PLUG,COOLING WATER TEMP	70	2A-47
DC120247	PLUG,FUEL TEMP SENDER UNIT	70	2A-47
DC120247	PLUG,CAMSHAFT POSITION UNIT	70	2A-47
DC120247	PLUG,CRANKSHAFT POSITION UNIT	70	2A-47
DC120247	PLUG,OIL TEMP SENSOR	70	2A-47
DC120247	PLUG,COOLING WATER TEMP	70	2B-41
DC120247	PLUG,FUEL TEMP SENDER UNIT	70	2B-41
DC120247	PLUG,CAMSHAFT POSITION UNIT	70	2B-41
DC120247	PLUG,CRANKSHAFT POSITION UNIT	70	2B-41
DC120247	PLUG,OIL TEMP SENSOR	70	2B-41
DC120248	PLUG,OIL PRESSURE SENDER UNIT	100	2A-45
DC120248	PLUG,OIL PRESSURE SENDER UNIT	100	2A-47
DC120248	PLUG,OIL PRESSURE SENDER UNIT	100	2B-41
DC120249	PLUG SOCKET,ENGINE START	53	2A-45
DC120249	PLUG SOCKET,ENGINE STOP	53	2A-45
DC120249	PLUG SOCKET,OIL LEVEL SENSOR	53	2A-45
DC120249	PLUG SOCKET,ENGINE START	53	2A-47
DC120249	PLUG SOCKET,ENGINE STOP	53	2A-47
DC120249	PLUG SOCKET,OIL LEVEL SENSOR	53	2A-47
DC120249	PLUG SOCKET,ENGINE START	53	2B-41
DC120249	PLUG SOCKET,ENGINE STOP	53	2B-41
DC120249	PLUG SOCKET,OIL LEVEL SENSOR	53	2B-41
DC120250	PLUG,BOOST AIR SENSOR	130	2A-45
DC120250	PLUG,BOOST AIR SENSOR	130	2A-47
DC120250	PLUG,BOOST AIR SENSOR	130	2B-41
DC120255	COUPLING,THROTTLE VALVE	85	2A-45
DC120255	COUPLING,THROTTLE VALVE	85	2A-47
DC120255	COUPLING,THROTTLE VALVE	85	2B-41
DC120256	PLUG,EXPANSION,WEB COOLING,M12	20	2A-13
DC120256	PLUG,EXPANSION,WEB COOLING,M12	20	2A-15
DC120256	PLUG, EXPANSION, WEB COOLING, M12	20	2B-11
DC120257	PLUG,EXPANSION,WEB COOLING,M13	20	2A-13
DC120257	PLUG,EXPANSION,WEB COOLING,M13	20	2A-15
DC120257	PLUG, EXPANSION, WEB COOLING, M13	20	2B-11
DC120258	PLUG,SCREW BRACING	33	2A-13
DC120258	PLUG,SCREW BRACING	33	2A-15
DC120258	PLUG, SCREW BRACING	33	2B-11
DC130162	PIPE, SUCTION	20	2A-39
DC130162	PIPE, SUCTION	20	2B-35
DC130194	PIPE,BREATHER	115	2A-19
DC130194	PIPE,BREATHER	115	2B-15
DC130196	HOSE,PIPE TO CYLINDER HEAD COVER	120	2A-19
DC130196	HOSE,PIPE TO CYLINDER HEAD COVER	120	2B-15
DC130197	PIPE,FUEL PUMP TO INJECTOR NOZZLE	5	2A-29
DC130197	PIPE,FUEL PUMP TO INJECTOR NOZZLE	5	2B-25
DC130198	PIPE,FUEL TO CYLINDER HEAD	15	2A-29
DC130198	PIPE,FUEL TO CYLINDER HEAD	15	2B-25
DC130199	PIPE,FROM FUEL FILTER TO FEED PUMP	20	2A-29
DC130199	PIPE,FROM FUEL FILTER TO FEED PUMP	20	2B-25
DC130200	PIPE,FROM VALVE TO HEATER PLUGS	40	2A-33
DC130200	PIPE,FROM VALVE TO HEATER PLUGS	40	2B-29
DC130201	PIPE,FROM FUEL FILTER TO VALVE	100	2A-33
DC130201	PIPE,FROM FUEL FILTER TO VALVE	100	2B-29
DC130202	PIPE,AIR ON TURBO CHARGER	65	2A-35
DC130202	PIPE, AIR ON TURBO CHARGER	65	2B-31
DC130203	PIPE,CHARGE-AIR	100	2A-35
DC130203	PIPE, CHARGE-AIR	100	2B-31
DC130205	PIPE, AT CYLINDER HEAD	180	2A-39
DC130207	PIPE,SUCTION	25	2A-53
DC130207	PIPE,SUCTION	25	2B-47
DC130208	PIPE,OIL FEED	8	2A-57
DC130208	PIPE,OIL FEED	8	2B-51
DC130210	PIPE,PLASTIC,RETURN TO CRANK-CASE	115	2A-57
DC130210	PIPE,PLASTIC,RETURN TO CRANK-CASE	115	2B-51
DC130212	PIPE, SUCTION	5	2A-39
DC130212	PIPE, SUCTION	5	2B-35
DC130213	HOSE, SUCTION LINE TO COMPRES-SOR	66	2A-39
DC130213	HOSE, SUCTION LINE TO COMPRES-SOR	66	2B-35
DC130231	PIPE,OIL RETURN	35	2A-57
DC130231	PIPE,OIL RETURN	35	2B-51
DC130233	LINE,CONSTANT THROTTLE	200	2A-17
DC130233	LINE,CONSTANT THROTTLE	200	2B-13
DC130234	PIPE, AT CYLINDER HEAD	180	2B-35
DC130235	PIPE, AT WATER PUMP	183	2B-35
DC130235	PIPE, AT WATER PUMP	184	2A-39
DC140059	WASHER,SEALING	140	2A-55
DC140059	WASHER,SEALING	140	2B-49
DC140060	WASHER,SEALING	46	3-83
DC140063	RING,SEAL	35	2A-31
DC140063	RING,SEAL	35	2B-27
DC140072	WASHER,SEALING	47	3-83
DC140110	RING,Seal	205	2A-59
DC140110	RING,Seal	205	2B-53
DC140123	RING,SEAL	3	2A-79
DC140123	RING,SEAL	3	2B-73
DC140145	RING,SEAL	330	2A-11
DC140145	RING,SEAL	330	2B-9
DC140149	RING, SEAL, MAIN OIL PASSAGE	173	2B-5
DC140149	RING, SEAL, SENDER UNIT, FUEL TEMP	248	2B-5
DC140149	RING,Seal Sender Unit to Flange	45	2A-59
DC140149	RING,Seal Sender Unit to Flange	45	2B-53
DC140149	RING,SEAL FEED PIPE TO OIL FILTER HD	70	2A-57
DC140149	RING,SEAL FEED PIPE TO OIL FILTER HD	70	2B-51
DC140149	RING,SEAL	133	2A-55
DC140149	RING,SEAL	133	2B-49
DC140149	RING,SEAL	155	2A-9
DC140149	RING,SEAL,MAIN OIL PASSAGE	173	2A-7
DC140149	RING, SEAL	195	2A-39
DC140149	RING, SEAL	195	2B-35
DC140149	RING,SEAL,SENDER UNIT,FUEL TEMP	248	2A-7

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
DC140150	RING, SEAL, CYL/HEAD	119	2B-5
DC140150	RING,SEAL,CYL/HEAD	119	2A-7
DC140151	RING, SEAL	45	2B-7
DC140151	RING,SEAL	45	2A-9
DC140155	RING,SEAL,OIL DRAIN	25	2A-11
DC140155	RING,SEAL,OIL DRAIN	25	2B-9
DC140155	RING, SEAL	55	2B-7
DC140155	RING,SEAL	55	2A-9
DC140160	RING,SEAL	50	2A-13
DC140160	RING,SEAL	50	2A-15
DC140160	RING, SEAL	50	2B-11
DC140166	RING,SEAL SOCKET TO CYLINDER HEAD	290	2A-13
DC140166	RING,SEAL SOCKET TO CYLINDER HEAD	290	2A-15
DC140166	RING, SEAL SOCKET TO CYLINDER HEAD	290	2B-11
DC140167	RING,SEAL CONSTANT THROTTLE TO HEAD	195	2A-17
DC140167	RING,SEAL CONSTANT THROTTLE TO HEAD	195	2B-13
DC140172	RING, SEAL, MAIN OIL PASSAGE	143	2B-5
DC140172	RING, SEAL, CYL/BLOCK	230	2B-5
DC140172	RING, SEAL, SENDER UNIT, OIL PRESSURE	250	2B-5
DC140172	RING,SEAL	30	2A-29
DC140172	RING,SEAL	30	2B-25
DC140172	RING,SEAL,MAIN OIL PASSAGE	143	2A-7
DC140172	RING,SEAL,CYL/BLOCK	230	2A-7
DC140172	RING,SEAL,SENDER UNIT,OIL PRESSURE	250	2A-7
DC140174	RING,SEAL	23	2A-31
DC140174	RING,SEAL	23	2B-27
DC140178	O-RING,T.D.C. SENDER TO CRANKCASE	424	2A-45
DC140178	O-RING,T.D.C. SENDER TO CRANKCASE	424	2A-47
DC140178	O-RING,T.D.C. SENDER TO CRANKCASE	424	2B-41
DC140179	RING, SEAL, INJECTOR TO CYLINDER HEAD	275	2B-11
DC140181	RING, SEAL, INTERMEDIATE FLANGE	107	2B-5
DC140181	RING,SEAL,INTERMEDIATE FLANGE	107	2A-7
DC140182	RING, SEAL, OIL PASSAGE REAR	131	2B-5
DC140182	RING,SEAL TO PLUG SENDER UNIT PORT	46	2A-55
DC140182	RING,SEAL TO PLUG SENDER UNIT PORT	46	2B-49
DC140182	RING,SEAL,OIL PASSAGE REAR	131	2A-7
DC140182	RING,Seal TO Fitting	270	2A-59
DC140182	RING,Seal TO Fitting	270	2B-53
DC140185	RING,SEAL,INJECTOR TO CYLINDER HEAD	275	2A-13
DC140185	RING,SEAL,INJECTOR TO CYLINDER HEAD	275	2A-15
DC140185	RING, SEAL, INJECTOR TO CYLINDER HEAD	275	2B-11
DC140186	RING,SEAL,INJECTOR TO CYLINDER HEAD	282	2A-13
DC140186	RING,SEAL,INJECTOR TO CYLINDER HEAD	282	2A-15
DC140186	SLEEVE, HEAT INJECTOR	282	2B-11
DC140187	RING,SEAL PUMP TO CRANKCASE	15	2A-27
DC140187	RING,SEAL PUMP TO CRANKCASE	15	2B-23
DC140188	RING,SEAL	28	2A-31
DC140188	RING,SEAL	28	2B-27
DC140189	RING,SEAL PIPE TO SOLENOID VALVE	95	2A-33
DC140189	RING,SEAL PIPE TO SOLENOID VALVE	95	2B-29
DC140189	RING,SEAL FUEL PIPE TO FUEL FILTER	115	2A-33
DC140189	RING,SEAL FUEL PIPE TO FUEL FILTER	115	2B-29
DC140190	RING,SEAL FUEL PIPE TO VALVE	120	2A-33
DC140190	RING,SEAL FUEL PIPE TO VALVE	120	2B-29
DC140191	RING,SEAL,AIR PIPE	94	2A-35
DC140191	RING, SEAL, AIR PIPE	94	2B-31
DC140192	RING, SEAL	114	2B-31
DC140192	RING,SEAL,CHARGE-AIR PIPE	335	2A-35
DC140194	SEAL,OIL FRONT CRANKSHAFT	10	2A-53
DC140194	SEAL,OIL FRONT CRANKSHAFT	10	2B-47
DC140195	RING,SEAL	35	2A-55
DC140195	RING,SEAL	35	2B-49
DC140197	SEAL, OIL CRANKSHAFT REAR	20	2B-7
DC140197	SEAL,OIL CRANKSHAFT REAR	20	2A-9
DC140198	KIT,REPAIR,FUEL INJECTION PUMP	17	2A-27
DC140198	KIT,REPAIR,FUEL INJECTION PUMP	17	2B-23
DC140199	RING,SENDER	52	2A-41
DC140199	RING, SENDER	52	2B-37
DC150126	BUSHING,DRIVE END	15	2A-49
DC150126	BUSHING,DRIVE END	15	2B-43
DC150156	BUSHING,BENDIX	25	2A-49
DC150156	BUSHING,BENDIX	25	2B-43
DC150157	BEARING, BALL DRIVE END	50	2A-51
DC150157	BEARING, BALL DRIVE END	50	2B-45
DC150158	BUSHING,COMMUTATOR END	45	2A-49
DC150158	BUSHING,COMMUTATOR END	45	2B-43
DC150168	BEARING, BALL SLIP RING SIDE	60	2A-51
DC150168	BEARING, BALL SLIP RING SIDE	60	2B-45
DC150174	BUSHING, CAMSHAFT BEARINGS	35	2B-5
DC150174	BUSHING,CAMSHAFT BEARING	35	2A-7
DC150175	BUSHING, CAMSHAFT BEARINGS	41	2B-5
DC150175	BUSHING,CAMSHAFT BEARING	41	2A-7
DC150176	BUSHING	340	2A-17
DC150176	BUSHING	340	2B-13
DC150183	BEARING,BIG END,STANDARD	30	2A-21
DC150183	BEARING,BIG END,STANDARD	30	2B-17
DC150191	BEARING,BIG END,FITTING SIZE 0.10	30	2A-21
DC150191	BEARING,BIG END,FITTING SIZE 0.10	30	2B-17
DC150192	BEARING,BIG END,FITTING SIZE 0.25	30	2A-21
DC150192	BEARING,BIG END,FITTING SIZE 0.25	30	2B-17
DC150193	BEARING,BIG END,FITTING SIZE 0.50	30	2A-21
DC150193	BEARING,BIG END,FITTING SIZE 0.50	30	2B-17
DC150194	BEARING,BIG END,FITTING SIZE 0.75	30	2A-21
DC150194	BEARING,BIG END,FITTING SIZE 0.75	30	2B-17
DC150195	BEARING,BIG END,FITTING SIZE 1.00	30	2A-21
DC150195	BEARING,BIG END,FITTING SIZE 1.00	30	2B-17
DC150196	BUSHING,T.D.C. SENSER TO CRANKCASE	418	2A-45
DC150196	BUSHING,CRANKCASE POSITION UNIT	418	2A-45
DC150196	BUSHING,T.D.C. SENSER TO CRANKCASE	418	2A-47
DC150196	BUSHING,CRANKCASE POSITION UNIT	418	2A-47

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
DC150196	BUSHING,T.D.C. SENSER TO CRANK-CASE	418	2B-41
DC150196	BUSHING,CRANKCASE POSITION UNIT	418	2B-41
DC150205	BEARING,MAIN STANDARD	20	2A-21
DC150205	BEARING,MAIN STANDARD	20	2B-17
DC206155	PISTON RING SET,102.90MM	20	2A-23
DC206155	PISTON RING SET,102.90MM	20	2B-19
DC220008	COVER,Twin Thermostat Housing	224	2B-53
DC220029	GASKET	32	2A-19
DC220029	GASKET	32	2B-15
DC220030	COLLET,VALVE	80	2A-13
DC220030	COLLET,VALVE	80	2A-15
DC220030	COLLET, VALVE	80	2B-11
DC220031	CAP,OIL FILLING	29	2A-19
DC220031	CAP,OIL FILLING	29	2B-15
DC220100	PLUG,SCREW	50	2A-9
DC220195	PLUG,EXPANSION,40MM	25	2A-13
DC220314	GASKET	245	2A-39
DC220314	GASKET	245	2B-35
DC220407	CLAMP,RUBBER CAP	350	2A-11
DC220407	CLAMP,RUBBER CAP	350	2B-9
DC220461	PUMP,HANDLIFT& PREFILTER LATES	1	2A-75
DC220461	HANDLIFT PUMP & PRE-FILTER	1	2A-79
DC220461	PUMP,HANDLIFT& PREFILTER LATES	1	2B-69
DC220461	HANDLIFT PUMP & PRE-FILTER	1	2B-73
DC220481	CAP, POWER STEERING PUMP	240	2A-39
DC220481	CAP, POWER STEERING PUMP	240	2B-35
DC220508	FAN, ALTERNATOR PULLEY	259	2A-51
DC220508	FAN, ALTERNATOR PULLEY	259	2B-45
DC220543	PLUG, WELCH, 34MM	47	2B-5
DC220543	PLUG,EXPANSION,34MM	15	2A-13
DC220543	PLUG,EXPANSION,34MM	15	2A-15
DC220543	PLUG, EXPANSION, 34MM	15	2B-11
DC220543	PLUG,WELCH,34MM	47	2A-7
DC220545	PLUG,EXPANSION,25MM	25	2A-13
DC220545	PLUG,EXPANSION,25MM	25	2A-15
DC220545	PLUG, EXPANSION, 25MM	25	2B-11
DC220549	PLUG, WELCH, 36.2MM	47	2B-5
DC220549	PLUG,EXPANSION,36MM	15	2A-13
DC220549	PLUG,EXPANSION,36MM	15	2A-15
DC220549	PLUG, EXPANSION, 36MM	15	2B-11
DC220549	PLUG,WELCH,36.2MM	47	2A-7
DC220562	CAP,RUBBER	347	2A-11
DC220562	CAP,RUBBER	347	2B-9
DC220735	BALL, OIL PASSAGE FRONT / REAR	65	2B-5
DC220735	BALL,FASTENER CONSTANT THROT-TLE	10	2A-13
DC220735	BALL,FASTENER CONSTANT THROT-TLE	10	2A-15
DC220735	BALL, PLUG FOR WEB COOLING BORE	10	2B-11
DC220735	BALL, FASTENER CONSTANT THROT-TLE	10	2B-11
DC220735	BALL,LEAK,OIL HOLE PLUG	30	2A-13
DC220735	BALL,TO PLUG COOLING WATER BORE	30	2A-13
DC220735	BALL,LEAK,OIL HOLE PLUG	30	2A-15
DC220735	BALL,TO PLUG COOLING WATER BORE	30	2A-15
DC220735	BALL, LEAK, OIL HOLE PLUG	30	2B-11

PART #	ITEM DESCRIPTION	ITEM	PG #
DC220735	BALL, TO PLUG COOLING WATER BORE	30	2B-11
DC220735	BALL,OIL PASSAGE FRONT / REAR	65	2A-7
DC220737	BALL, REAR, OIL BORE	17	2B-5
DC220737	BALL, LOCK TRANSVERSE FUEL DUCT	65	2B-5
DC220737	BALL, LOCK OIL SUPPLY UNIT PUMP	65	2B-5
DC220737	BALL,REAR,OIL BORE	17	2A-7
DC220737	BALL,LEAK,OIL HOLE PLUG	30	2A-13
DC220737	BALL,LEAK,OIL HOLE PLUG	30	2A-15
DC220737	BALL, LEAK, OIL HOLE PLUG	30	2B-11
DC220737	BALL,LOCK TRANSVERSE FUEL DUCT	65	2A-7
DC220737	BALL,LOCK OIL SUPPLY UNIT PUMP	65	2A-7
DC220800	SENDER,UNIT Cooling Water Outlet	235	2A-59
DC220800	SENDER,UNIT Cooling Water Outlet	235	2B-53
DC220836	CLIP,SECURING	215	2A-43
DC220836	CLIP,SECURING	215	2B-39
DC220960	LEVER	100	2A-43
DC220960	LEVER	100	2B-39
DC220980	SOCKET,BALL,CYLINDER TO LEVER	205	2A-43
DC220980	SOCKET,BALL,CYLINDER TO LEVER	205	2B-39
DC220981	PIVOT,BALL	105	2A-43
DC220981	PIVOT,BALL	105	2B-39
DC221152	CAP	325	2A-11
DC221152	CAP	325	2B-9
DC221171	PLUG,SCREW	135	2A-55
DC221171	PLUG,SCREW	135	2B-49
DC221232	BOWL,FILTER	4	2A-79
DC221232	BOWL,FILTER	4	2B-73
DC221254	COVER,CAP FOR CRANK MECHA-NISM	25	2A-9
DC221254	COVER, CAP FOR CRANK MECHA-NISM	25	2B-7
DC221390	HUB,VISCOUS	15	2A-61
DC221391	FAN	5	2A-61
DC221526	PAN,OIL	5	2A-11
DC221526	PAN,OIL	5	2B-9
DC221528	BELT,RIBBED OM906LA		8-5
DC221529	GASKET,TAPPET COVER		8-3
DC221529	GASKET,TAPPET COVER		8-3
DC221529	GASKET,TAPPET COVER		8-3
DC221529	GASKET,TAPPET COVER		8-5
DC221529	GASKET,TAPPET COVER		8-5
DC221529	GASKET,TAPPET COVER		8-5
DC221529	GASKET,TAPPET COVER		8-5
DC221529	GASKET	47	2A-19
DC221529	GASKET	47	2B-15
DC221555	BENDIX	10	2A-49
DC221555	BENDIX	10	2B-43
DC221577	THERMOSTAT,83 Degree	200	2A-59
DC221577	THERMOSTAT,83 Degree	200	2B-53
DC221578	ELEMENT,OIL FILTER OM906LA		8-3
DC221578	ELEMENT,OIL FILTER OM906LA		8-3
DC221578	ELEMENT,OIL FILTER OM906LA		8-3
DC221578	ELEMENT,OIL FILTER OM906LA		8-3
DC221578	ELEMENT,OIL FILTER OM906LA		8-3
DC221578	ELEMENT,OIL FILTER OM906LA		8-5
DC221578	ELEMENT,OIL FILTER OM906LA		8-5
DC221578	ELEMENT,OIL FILTER OM906LA		8-5
DC221578	ELEMENT,OIL FILTER OM906LA		8-5
DC221578	ELEMENT,OIL FILTER	25	2A-55

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
DC221578	ELEMENT,OIL FILTER	**25**	2B-49
DC221582	HOSE,MOLDED	**50**	2A-35
DC221582	HOSE, MOLDED	**50**	2B-31
DC221587	TURBO CHARGER,WASTEGATE	**5**	2A-35
DC221647	SOCKET,PIPE	**285**	2A-13
DC221647	SOCKET,PIPE	**285**	2A-15
DC221647	SOCKET, PIPE	**285**	2B-11
DC221680	HEAD,FUEL FILTER	**20**	2A-31
DC221680	HEAD,FUEL FILTER	**20**	2B-27
DC221726	ELECTRONICS,KSA FLAME START	**1**	6-7
DC221726	ELECTRONICS,KSA	**514**	2A-45
DC221726	ELECTRONICS,KSA	**514**	2A-47
DC221726	ELECTRONICS,KSA	**514**	2B-41
DC221727	HOUSING,SOCKET FLAME START SYSTEM	**520**	2A-45
DC221727	HOUSING,SOCKET FLAME START SYSTEM	**520**	2A-47
DC221727	HOUSING,SOCKET FLAME START SYSTEM	**520**	2B-41
DC221728	GASKET,FLAME START SYSTEM	**532**	2A-45
DC221728	GASKET,FLAME START SYSTEM	**532**	2A-47
DC221728	GASKET,FLAME START SYSTEM	**532**	2B-41
DC221729	BOOT,FLAME START SYSTEM	**538**	2A-45
DC221729	BOOT,FLAME START SYSTEM	**538**	2A-47
DC221729	BOOT,FLAME START SYSTEM	**538**	2B-41
DC221730	GASKET,FLAME START	**556**	2A-45
DC221730	GASKET,FLAME START	**556**	2A-47
DC221730	GASKET,FLAME START	**556**	2B-41
DC221731	BOOT,FLAME START SYSTEM	**568**	2A-45
DC221731	BOOT,FLAME START SYSTEM	**568**	2A-47
DC221731	BOOT,FLAME START SYSTEM	**568**	2B-41
DC221734	SENDER,SPEED AT CRANKCASE	**412**	2A-45
DC221734	SENDER,SPEED AT TIMING CASE	**412**	2A-45
DC221734	SENDER,SPEED AT CRANKCASE	**412**	2A-47
DC221734	SENDER,SPEED AT TIMING CASE	**412**	2A-47
DC221734	SENDER,SPEED AT CRANKCASE	**412**	2B-41
DC221734	SENDER,SPEED AT TIMING CASE	**412**	2B-41
DC221742	SENDER,OIL PRESSURE	**244**	2A-7
DC221742	SENDER, OIL PRESSURE	**244**	2B-5
DC221743	SENDER, FUEL TEMPERATURE	**242**	2B-5
DC221743	SENDER,Temperature	**42**	2A-59
DC221743	SENDER,Temperature	**42**	2B-53
DC221743	SENDER,OIL TEMPERATURE	**132**	2A-55
DC221743	SENDER,OIL TEMPERATURE	**132**	2B-49
DC221743	SENDER,FUEL TEMPERATURE	**242**	2A-7
DC221746	GASKET,RETURN PIPE TO TURBO	**90**	2A-57
DC221746	GASKET,RETURN PIPE TO TURBO	**90**	2B-51
DC221758	COMPRESSOR,LESS Coupling	**8**	2A-65
DC221758	COMPRESSOR,LESS Coupling	**8**	2B-59
DC221771	RING,RUBBER	**17**	2A-45
DC221771	RING,RUBBER	**17**	2A-47
DC221771	RING,RUBBER	**17**	2B-41
DC221799	SLEEVE, FLYWHEEL	**11**	2B-5
DC221799	SLEEVE,FLYWHEEL	**11**	2A-7
DC221800	THROTTLE, TRANSVERSE FUEL DUCT	**56**	2B-5
DC221800	THROTTLE,TRANSVERSE FUEL DUCT	**56**	2A-7
DC221801	NOZZLE, OIL	**59**	2B-5
DC221801	NOZZLE,OIL	**59**	2A-7
DC221802	BALL, FUEL FEED LOCK	**65**	2B-5
DC221802	BALL,FUEL FEED LOCK	**65**	2A-7
DC221803	BALL, FUEL RETURN LOCK	**65**	2B-5
DC221803	BALL,FUEL RETURN LOCK	**65**	2A-7
DC221804	INTERMEDIATE PIECE, OIL PUMP	**71**	2B-5
DC221804	INTERMEDIATE PIECE,OIL PUMP	**71**	2A-7
DC221805	SLEEVE, OIL PUMP	**77**	2B-5
DC221805	SLEEVE,OIL PUMP	**77**	2A-7
DC221806	INTERMEDIATE PIECE, TURBO, OIL	**83**	2B-5
DC221806	INTERMEDIATE PIECE,TURBO,OIL	**83**	2A-7
DC221807	SLEEVE, PULSE SENDER	**89**	2B-5
DC221807	SLEEVE,PULSE SENDER	**89**	2A-7
DC221809	SLEEVE, CYL/HEAD	**155**	2B-5
DC221809	SLEEVE,CYL/HEAD	**155**	2A-7
DC221810	VALVE, OVERFLOW, RELIEF 4.5 - 5 BAR	**224**	2B-5
DC221810	VALVE,OVERFLOW,RELIEF 4.5 - 5 BAR	**224**	2A-7
DC221811	SENDER,FUEL TEMPERATURE	**242**	2A-7
DC221812	VALVE, SOLENOID	**266**	2B-5
DC221812	VALVE,SOLENOID	**266**	2A-7
DC221813	VALVE	**278**	2B-5
DC221813	VALVE	**278**	2A-7
DC221814	GASKET	**290**	2B-5
DC221814	GASKET	**290**	2A-7
DC221818	GASKET,OIL PAN	**17**	2A-11
DC221818	GASKET,OIL PAN	**17**	2B-9
DC221819	SENDER,OIL LEVEL	**80**	2A-11
DC221819	SENDER,OIL LEVEL	**80**	2B-9
DC221820	TUBE,GUIDE TOP DIPSTICK	**175**	2A-11
DC221820	TUBE,GUIDE TOP DIPSTICK	**175**	2B-9
DC221821	TUBE,GUIDE BOTTOM DIPSTICK	**185**	2A-11
DC221821	TUBE,GUIDE BOTTOM DIPSTICK	**185**	2B-9
DC221822	GROMMET	**205**	2A-11
DC221822	GROMMET	**205**	2B-9
DC221823	DIPSTICK,OIL	**300**	2A-11
DC221823	DIPSTICK,OIL	**300**	2B-9
DC221825	SEAT,VALVE,INTAKE STANDARD	**40**	2A-13
DC221825	SEAT,VALVE,INTAKE STANDARD	**40**	2A-15
DC221825	SEAT, VALVE, INTAKE STANDARD	**40**	2B-11
DC221826	SEAT,VALVE,INTAKE REPAIR I,35.37MM	**40**	2A-13
DC221826	SEAT,VALVE,INTAKE REPAIR I,35.37MM	**40**	2A-15
DC221826	SEAT, VALVE, INTAKE REPAIR I, 35.37MM	**40**	2B-11
DC221827	SEAT,VALVE INTAKE REPAIR II,35.57MM	**40**	2A-13
DC221827	SEAT,VALVE INTAKE REPAIR II,35.57MM	**40**	2A-15
DC221827	SEAT, VALVE INTAKE REPAIR II, 35.57MM	**40**	2B-11
DC221828	SEAT,VALVE EXHAUST STANDARD	**40**	2A-13
DC221828	SEAT,VALVE EXHAUST STANDARD	**40**	2A-15
DC221828	SEAT, VALVE EXHAUST STANDARD	**40**	2B-11
DC221829	SEAT,VALVE EXHAUST REPAIR I,40.37MM	**40**	2A-13
DC221829	SEAT,VALVE EXHAUST REPAIR I,40.37MM	**40**	2A-15
DC221829	SEAT, VALVE EXHAUST REPAIR I, 40.37MM	**40**	2B-11
DC221830	SEAT,VALVE EXHAUST REPAIR II,40.57MM	**40**	2A-13
DC221830	SEAT,VALVE EXHAUST REPAIR II,40.57MM	**40**	2A-15

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
DC221830	SEAT, VALVE EXHAUST REPAIR II, 40.57MM	40	2B-11
DC221831	GUIDE,VALVE,INTAKE & EXHAUST,STD	45	2A-13
DC221831	GUIDE,VALVE,INTAKE & EXHAUST,STD	45	2A-15
DC221831	GUIDE, VALVE, INTAKE & EXHAUST, STD	45	2B-11
DC221832	GUIDE,VALVE,INTAKE & EXHAUST,+0.2MM	45	2A-13
DC221832	GUIDE,VALVE,INTAKE & EXHAUST,+0.2MM	45	2A-15
DC221832	GUIDE, VALVE, INTAKE & EXHAUST, +0.2MM	45	2B-11
DC221833	GUIDE,VALVE,INTAKE & EXHAUST,+0.5MM	45	2A-13
DC221833	GUIDE,VALVE,INTAKE & EXHAUST,+0.5MM	45	2A-15
DC221833	GUIDE, VALVE, INTAKE & EXHAUST, +0.5MM	45	2B-11
DC221834	SLEEVE	55	2A-13
DC221834	SLEEVE	55	2A-15
DC221834	SLEEVE	55	2B-11
DC221835	VALVE,INTAKE	60	2A-13
DC221835	VALVE,INTAKE	60	2A-15
DC221835	VALVE, INTAKE	60	2B-11
DC221836	VALVE,EXHAUST	60	2A-13
DC221836	VALVE,EXHAUST	60	2A-15
DC221836	VALVE, EXHAUST	60	2B-11
DC221837	SPRING,INTAKE VALVE	70	2A-13
DC221837	SPRING,INTAKE VALVE	70	2A-15
DC221837	SPRING, INTAKE VALVE	70	2B-11
DC221838	SPRING,EXHAUST VALVE	70	2A-13
DC221838	SPRING,EXHAUST VALVE	70	2A-15
DC221838	SPRING, EXHAUST VALVE	70	2B-11
DC221839	RETAINER,SPRING	75	2A-13
DC221839	RETAINER,SPRING	75	2A-15
DC221839	RETAINER, SPRING	75	2B-11
DC221840	HOLDER,SEAL	85	2A-13
DC221840	HOLDER,SEAL	85	2A-15
DC221840	HOLDER, SEAL	85	2B-11
DC221841	VALVE,CONSTANT THROTTLE	95	2A-13
DC221841	VALVE,CONSTANT THROTTLE	95	2A-15
DC221841	VALVE, CONSTANT THROTTLE	95	2B-11
DC221842	GUIDE	100	2A-13
DC221842	GUIDE	100	2A-15
DC221842	GUIDE	100	2B-11
DC221843	SPRING	105	2A-13
DC221843	SPRING	105	2A-15
DC221843	SPRING	105	2B-11
DC221844	RETAINER,SPRING	110	2A-13
DC221844	RETAINER,SPRING	110	2A-15
DC221844	RETAINER, SPRING	110	2B-11
DC221845	VALVE,COLLET	115	2A-13
DC221845	VALVE,COLLET	115	2A-15
DC221845	VALVE, COLLET	115	2B-11
DC221846	PISTON	120	2A-13
DC221846	PISTON	120	2A-15
DC221846	PISTON	120	2B-11
DC221847	COVER	130	2A-13
DC221847	COVER	130	2A-15
DC221847	COVER	130	2B-11
DC221848	BRIDGE,VALVE	175	2A-13
DC221848	BRIDGE,VALVE	175	2A-15
DC221848	BRIDGE, VALVE	175	2B-11
DC221850	CRANKCASE,LESS CYLINDER LINERS	5	2A-7
DC221851	BRACKET,OIL DIPSTICK	335	2A-11
DC221851	BRACKET,OIL DIPSTICK	335	2B-9
DC221854	BRACKET,CLAMPING,INJECTOR TO CYL HD	300	2A-13
DC221854	BRACKET,CLAMPING,INJECTOR TO CYL HD	300	2A-15
DC221854	BRACKET, CLAMPING, INJECTOR TO CYL HD	300	2B-11
DC221855	SPINDLE,ROCKER ARM	320	2A-17
DC221855	SPINDLE,ROCKER ARM	320	2B-13
DC221856	ARM,ROCKER,INTAKE	330	2A-17
DC221856	ARM,ROCKER,INTAKE	330	2B-13
DC221857	ARM,ROCKER,EXHAUST	335	2A-17
DC221857	ARM,ROCKER,EXHAUST	335	2B-13
DC221858	BRACKET,ROCKER ARM,FRONT	355	2A-17
DC221858	BRACKET,ROCKER ARM,FRONT	355	2B-13
DC221859	BRACKET,ROCKER ARM,CENTRAL	355	2A-17
DC221859	BRACKET,ROCKER ARM,CENTRAL	355	2B-13
DC221860	BRACKET,ROCKER ARM,REAR	355	2A-17
DC221860	BRACKET,ROCKER ARM,REAR	355	2B-13
DC221861	SPRING	360	2A-17
DC221861	SPRING	360	2B-13
DC221862	RING,LOCK	370	2A-17
DC221862	RING,LOCK	370	2B-13
DC221863	CLAMPING PIECE,ROCKER SHAFT TO HEAD	375	2A-17
DC221863	CLAMPING PIECE,ROCKER SHAFT TO HEAD	375	2B-13
DC221864	COVER,CYLINDER HEAD,PLASTIC	5	2A-19
DC221864	COVER,CYLINDER HEAD,PLASTIC	5	2B-15
DC221865	DIAPHRAGM	17	2A-19
DC221865	DIAPHRAGM	17	2B-15
DC221866	INSERT,COVER TO CYLINDER HEAD	35	2A-19
DC221866	INSERT,COVER TO CYLINDER HEAD	35	2B-15
DC221867	LOCK	41	2A-19
DC221867	LOCK	41	2B-15
DC221868	GASKET	68	2A-19
DC221868	GASKET	68	2B-15
DC221870	GEAR,CRANKSHAFT	15	2A-21
DC221870	GEAR,CRANKSHAFT	15	2B-17
DC221871	GEAR,CRANKSHAFT,FITTING SIZE - 0.30	15	2A-21
DC221871	GEAR,CRANKSHAFT,FITTING SIZE - 0.30	15	2B-17
DC221872	DAMPER,VIBRATION	35	2A-21
DC221872	DAMPER,VIBRATION	35	2B-17
DC221873	FLYWHEEL,WITH RING GEAR	55	2A-21
DC221873	FLYWHEEL,WITH RING GEAR	55	2B-17
DC221874	GEAR,RING	60	2A-21
DC221874	GEAR,RING	60	2B-17
DC221875	GEAR,CRANKSHAFT	75	2A-21
DC221875	GEAR,CRANKSHAFT	75	2B-17
DC221876	ROD,CONNECTING	5	2A-23
DC221877	PISTON,KIT,STANDARD,102MM	15	2A-23
DC221877	PISTON,KIT,STANDARD,102MM	15	2B-19
DC221878	PISTON,102MM,HEIGHT -.30	15	2A-23
DC221878	PISTON,102MM,HEIGHT -.30	15	2B-19
DC221879	PISTON,102MM,HEIGHT -.60	15	2A-23

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
DC221879	PISTON,102MM,HEIGHT -.60	15	2B-19
DC221880	PISTON,102MM,HEIGHT -.90	15	2A-23
DC221880	PISTON,102MM,HEIGHT -.90	15	2B-19
DC221881	PIN,PISTON	25	2A-23
DC221881	PIN,PISTON	25	2B-19
DC221882	RING,RETAINING	30	2A-23
DC221882	RING,RETAINING	30	2B-19
DC221883	CAMSHAFT	5	2A-25
DC221883	CAMSHAFT	5	2B-21
DC221885	PIN,CYLINDRICAL	15	2A-25
DC221885	PIN,CYLINDRICAL	15	2B-21
DC221886	FOLLOWER,CAM,INLET/EXHAUST VALVES	20	2A-25
DC221886	FOLLOWER,CAM,INLET/EXHAUST VALVES	20	2B-21
DC221887	ROD,PUSH INLET/EXHAUST VALVES	25	2A-25
DC221887	ROD,PUSH INLET/EXHAUST VALVES	25	2B-21
DC221888	PUMP,FUEL INJECTION	5	2A-27
DC221888	PUMP,FUEL INJECTION	5	2B-23
DC221889	PUMP,FUEL	25	2A-27
DC221889	PUMP,FUEL	25	2B-23
DC221890	GASKET,FUEL PUMP TO CRANKCASE	30	2A-27
DC221890	GASKET,FUEL PUMP TO CRANKCASE	30	2B-23
DC221891	COVER,INJECTION PUMP	55	2A-27
DC221891	COVER,INJECTION PUMP	55	2B-23
DC221892	PIN,LOCKING COVER ATTACHMENT	60	2A-27
DC221892	PIN,LOCKING COVER ATTACHMENT	60	2B-23
DC221893	RING,RETAINING COVER ATTACHMENT	65	2A-27
DC221893	RING,RETAINING COVER ATTACHMENT	65	2B-23
DC221894	SPRING,COVER ATTACHMENT	70	2A-27
DC221894	SPRING,COVER ATTACHMENT	70	2B-23
DC221896	FILTER,FUEL COMPLETE UNIT	15	2A-31
DC221896	FILTER,FUEL COMPLETE UNIT	15	2B-27
DC221897	COVER,PRE-FILTER	25	2A-31
DC221897	COVER,PRE-FILTER	25	2B-27
DC221898	INSERT,FILTER	45	2A-31
DC221898	INSERT,FILTER	45	2B-27
DC221899	KIT,ELEMENT,FUEL FILTER		8-3
DC221899	KIT,ELEMENT,FUEL FILTER		8-3
DC221899	KIT,ELEMENT,FUEL FILTER		8-3
DC221899	KIT,ELEMENT,FUEL FILTER		8-5
DC221899	KIT,ELEMENT,FUEL FILTER		8-5
DC221899	KIT,ELEMENT,FUEL FILTER		8-5
DC221899	KIT,ELEMENT,FUEL FILTER		8-5
DC221899	ELEMENT,FUEL FILTER KIT	50	2A-31
DC221899	ELEMENT,FUEL FILTER KIT	50	2B-27
DC221900	ELEMENT,FUEL PRE-FILTER	55	2A-31
DC221900	ELEMENT,FUEL PRE-FILTER	55	2B-27
DC221901	GASKET,FUEL FILTER TO CYLINDER HEAD	60	2A-31
DC221901	GASKET,FUEL FILTER TO CYLINDER HEAD	60	2B-27
DC221902	VALVE,SOLENOID	5	2A-33
DC221902	VALVE,SOLENOID	5	2B-29
DC221903	BRACKET,SOLENOID VALVE	15	2A-33
DC221903	BRACKET,SOLENOID VALVE	15	2B-29
DC221904	PLUG,HEATER CHARGE AIR PIPE	125	2A-33
DC221904	PLUG,HEATER CHARGE AIR PIPE	125	2B-29
DC221905	SHEILD,HEAT,FLANGED ELBOW	20	2A-35
DC221906	BRACKET,AIR PIPE AT WATER PUMP	200	2A-35
DC221906	BRACKET, AIR PIPE AT WATER PUMP	200	2B-31
DC221915	HOUSING,CHARGING AIR ELBOW	25	2A-41
DC221915	HOUSING,CHARGING AIR ELBOW	25	2B-37
DC221918	GASKET,MANIFOLD TO CYLINDER HEAD	25	2A-43
DC221918	GASKET,MANIFOLD TO CYLINDER HEAD	25	2B-39
DC221919	BRACKET	140	2A-43
DC221919	BRACKET	140	2B-39
DC221920	CYLINDER,EXHAUST BRAKE	160	2A-43
DC221920	CYLINDER,EXHAUST BRAKE	160	2B-39
DC221921	TUBE,PACER,CYLINDER TO BRACKET	185	2A-43
DC221921	TUBE,PACER,CYLINDER TO BRACKET	185	2B-39
DC221922	UNIT,CONTROL,TIER 2	5	2A-45
DC221924	SWITCH,ENGINE START/STOP	382	2A-45
DC221924	SWITCH,ENGINE START/STOP	382	2A-47
DC221924	SWITCH,ENGINE START/STOP	382	2B-41
DC221926	MOTOR,STARTER 24V/4KW,BOSCH	5	2A-49
DC221926	MOTOR,STARTER 24V/4KW,BOSCH	5	2B-43
DC221928	PIN,SOCKET HOUSING FLAME START	562	2A-45
DC221928	PIN,SOCKET HOUSING FLAME START	562	2A-47
DC221928	PIN,SOCKET HOUSING FLAME START	562	2B-41
DC221930	HOUSING,FRONT	20	2A-49
DC221930	HOUSING,FRONT	20	2B-43
DC221931	SWITCH,SOLENOID	30	2A-49
DC221931	SWITCH,SOLENOID	30	2B-43
DC221932	LEVER,CONTROL	35	2A-49
DC221932	LEVER,CONTROL	35	2B-43
DC221934	SWITCH,SOLENOID	80	2A-49
DC221934	SWITCH,SOLENOID	80	2B-43
DC221936	BRACKET	40	2A-53
DC221936	BRACKET	40	2B-47
DC221937	PUMP,OIL	5	2A-53
DC221937	PUMP,OIL	5	2B-47
DC221939	COVER,OIL FILTER	15	2A-55
DC221939	COVER,OIL FILTER	15	2B-49
DC221940	NECK,FILTER	30	2A-55
DC221940	NECK,FILTER	30	2B-49
DC221942	GASKET,OIL FILTER TO CRANKCASE	50	2A-55
DC221942	GASKET,OIL FILTER TO CRANKCASE	50	2B-49
DC221943	VALVE,PRESSURE RELIEF	70	2A-55
DC221943	VALVE,PRESSURE RELIEF	70	2B-49
DC221944	ELEMENT,OIL COOLER	105	2A-55
DC221944	ELEMENT,OIL COOLER	105	2B-49
DC221945	COVER,OIL COOLER	110	2A-55
DC221945	COVER,OIL COOLER	110	2B-49
DC221946	GASKET,OIL COOLER TO COVER	115	2A-55
DC221946	GASKET,OIL COOLER TO COVER	115	2B-49
DC221947	GASKET,OIL COOLER TO CRANKCASE	125	2A-55
DC221947	GASKET,OIL COOLER TO CRANKCASE	125	2B-49
DC221948	GASKET,Water Pump to Crankcase	20	2A-59
DC221948	GASKET,Water Pump to Crankcase	20	2B-53
DC221949	PUMP,Water with Gaskets	8	2A-59
DC221949	PUMP,Water with Gaskets	8	2B-53
DC221950	GASKET,PIPE Socket to Cyl/Head	100	2A-59
DC221950	GASKET,PIPE Socket to Cyl/Head	100	2B-53
DC221952	CAP,Rubber to Plug Pipe Socket	275	2A-59
DC221952	CAP,Rubber to Plug Pipe Socket	275	2B-53
DC221953	PULLEY	285	2A-59
DC221953	PULLEY	285	2B-53

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
DC221958	EYE,LIFTING Rear	75	2A-63
DC221958	EYE,LIFTING Rear	75	2B-57
DC221959	CONSOLE	20	2A-65
DC221959	CONSOLE	20	2B-59
DC221960	SLEEVE	25	2A-65
DC221960	SLEEVE	25	2B-59
DC221961	SLEEVE	30	2A-65
DC221961	SLEEVE	30	2B-59
DC221967	SUPPORT, ALTERNATOR	300	2A-51
DC221967	SUPPORT, ALTERNATOR	300	2B-45
DC221968	BRACKET	305	2A-51
DC221968	BRACKET	305	2B-45
DC221977	GASKET,COVER	27	2A-9
DC221977	GASKET, COVER	27	2B-7
DC222008	COVER,Twin Thermostat Housing	224	2A-59
DC222017	RECTIFIER, ALTERNATOR	110	2A-51
DC222017	RECTIFIER, ALTERNATOR	110	2B-45
DC222018	CONDENSOR, ALTERNATOR	130	2A-51
DC222018	CONDENSOR, ALTERNATOR	130	2B-45
DC222021	REGULATOR AND CUT-OUT	170	2A-51
DC222021	REGULATOR AND CUT-OUT	170	2B-45
DC222022	PULLEY, ALTERNATOR	278	2A-51
DC222022	PULLEY, ALTERNATOR	278	2B-45
DC222060	GASKET,C/AIR ELBOW TO CYL HEAD	85	2A-41
DC222060	GASKET,C/AIR ELBOW TO CYL HEAD	85	2B-37
DC222085	UNIT,SENDER C/AIR PRES/TEMP,4 BAR	50	2A-41
DC222085	UNIT,SENDER C/AIR PRES/TEMP,4 BAR	50	2B-37
DC222098	GASKET,CONTROL MODULE	250	2A-45
DC222098	GASKET,CONTROL MODULE	250	2A-47
DC222098	GASKET,CONTROL MODULE	250	2B-41
DC222101	CABLE,CONTROL UNIT TO SHIFT PANEL	600	2A-45
DC222101	CABLE,CONTROL UNIT TO SHIFT PANEL	600	2A-47
DC222101	CABLE,CONTROL UNIT TO SHIFT PANEL	600	2B-41
DC222114	INJECTOR,COMPLETE	260	2A-13
DC222115	MANIFOLD,EXHAUST,END PIECE	14	2A-43
DC222115	MANIFOLD,EXHAUST,END PIECE	14	2B-39
DC222116	MANIFOLD,EXHAUST,MIDDLE PIECE	12	2A-43
DC222116	MANIFOLD,EXHAUST,MIDDLE PIECE	12	2B-39
DC222117	RING,SEAL,3 PIECE EXHAUST	32	2A-43
DC222117	RING,SEAL,3 PIECE EXHAUST	32	2B-39
DC222126	CAP, VALVE	90	2B-11
DC222128	CRANKCASE,C/W CYLINDER LINERS	5	2A-7
DC222134	GASKET,OIL SEP TO CYL/H/COVER	20	2A-19
DC222134	GASKET,OIL SEP TO CYL/H/COVER	20	2B-15
DC222145	CONNECTOR,retarder	57	2A-59
DC222145	CONNECTOR,retarder	57	2B-53
DC222147	CABLE,ELECTRIC-ENGINE	41	2A-45
DC222147	CABLE,ELECTRIC-ENGINE	41	2A-47
DC222147	CABLE,ELECTRIC-ENGINE	41	2B-41
DC222148	FILTER,OIL COMPLETE UNIT	5	2A-55
DC222148	FILTER,OIL COMPLETE UNIT	5	2B-49
DC222149	COVER, TIMING	15	2B-7
DC222149	COVER,TIMING	15	2A-9
DC222150	COVER,TIMING CASE	120	2A-9
DC222151	GASKET	130	2A-9
DC222152	ROD,CONNECTING	5	2A-23
DC222153	CYLINDER HEAD,C/W VALVES & C/ THROTTLE	5	2A-13
DC222153	CYLINDER HEAD,C/W VALVES & C/ THROTTLE	5	2A-15
DC222153	CYLINDER HEAD,C/W VALVES & C/ THROTTLE	5	2A-17
DC222153	CYLINDER HEAD,C/W VALVES & C/ THROTTLE	5	2B-13
DC222154	INJECTOR,COMPLETE	260	2A-15
DC222155	GASKET,CYLINDER HEAD TO CRANK-CASE	180	2A-13
DC222155	GASKET,CYLINDER HEAD TO CRANK-CASE	180	2A-15
DC222156	COMPRESSOR,WABCO 352CCM	5	2A-37
DC222156	COMPRESSOR,WABCO 352CCM	5	2B-33
DC222157	BEARING,MAIN,FITTING SIZE 0.10	20	2A-21
DC222157	BEARING,MAIN,FITTING SIZE 0.10	20	2B-17
DC222158	BEARING,MAIN,FITTING SIZE 0.25	20	2A-21
DC222158	BEARING,MAIN,FITTING SIZE 0.25	20	2B-17
DC222159	BEARING,MAIN,FITTING SIZE 0.50	20	2A-21
DC222159	BEARING,MAIN,FITTING SIZE 0.50	20	2B-17
DC222160	BEARING,MAIN,FITTING SIZE 0.75	20	2A-21
DC222160	BEARING,MAIN,FITTING SIZE 0.75	20	2B-17
DC222161	BEARING,MAIN,FITTING SIZE 1.00	20	2A-21
DC222161	BEARING,MAIN,FITTING SIZE 1.00	20	2B-17
DC222162	UNIT,CONTROL,TIER 3	5	2A-47
DC222162	UNIT,CONTROL,TIER 3	5	2B-41
DC222166	BELT-V,1939MM	315	2A-59
DC222166	BELT-V,1939MM	315	2B-53
DC222167	PULLEY,Guide Fuel Feed Pump	320	2A-59
DC222167	PULLEY,Guide Fuel Feed Pump	320	2B-53
DC222168	TIGHTENER,Belt	345	2A-59
DC222168	TIGHTENER,Belt	345	2B-53
DC222204	BELT-V,1369MM,W/O AIR CON	315	2A-59
DC222204	BELT-V,1369MM,W/O AIR CON	315	2B-53
DC222223	ROD,CONNECTING	5	2A-23
DC222223	ROD,CONNECTING	5	2B-19
DC222225	SPACER,FAN	35	2A-61
DC222225	SPACER ,FAN	35	2B-55
DC222227	ALTERNATOR, W/O PULLEY 28V/ 80AMP	5	2A-51
DC222227	ALTERNATOR, W/O PULLEY 28V/ 80AMP	5	2B-45
DC222228	CYLINDER HEAD, C/W VALVES & C/ THROTTLE	5	2B-11
DC222231	PISTON,102.30MM,HEIGHT -.30	15	2A-23
DC222231	PISTON,102.30MM,HEIGHT -.30	15	2B-19
DC222232	PISTON,102.60MM,HEIGHT -.60	15	2A-23
DC222232	PISTON,102.60MM,HEIGHT -.60	15	2B-19
DC222233	PISTON,102.90MM,HEIGHT -.90	15	2A-23
DC222233	PISTON,102.90MM,HEIGHT -.90	15	2B-19
DC222234	CRANKCASE, OM926LA	5	2B-5
DC222235	GASKET, CYLINDER HEAD TO CRANK-CASE	180	2B-11
DC222243	INJECTOR, COMPLETE	260	2B-11
DC222245	TURBO CHARGER, OM926LA T3	5	2B-31
DC222247	SPRING,BREATHER	18	2A-19
DC222247	SPRING,BREATHER	18	2B-15
DC260058	KIT,PRE-FILTER ELEMENT	2	2A-79
DC260058	KIT,PRE-FILTER ELEMENT	2	2B-73
DC260073	KIT, TERMINAL PARTS	220	2A-51
DC260073	KIT, TERMINAL PARTS	220	2B-45

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
DC260098	KIT,GASKET	15	2A-65
DC260098	KIT,GASKET	15	2B-59
DC260106	KIT, GASKET CYLINDER CRANKCASE	314	2B-5
DC260106	KIT,GASKET CYLINDER CRANKCASE	314	2A-7
DC260108	PISTON RING SET,102MM STD	20	2A-23
DC260108	PISTON RING SET,102MM STD	20	2B-19
DC260109	KIT,SEAL RING	10	2A-27
DC260109	KIT,SEAL RING	10	2B-23
DC260112	KIT,EXHAUST BRAKE	95	2A-43
DC260113	KIT,EXHAUST BRAKE VALVE	120	2A-43
DC260113	KIT,EXHAUST BRAKE VALVE	120	2B-39
DC260114	KIT,GEARING	95	2A-49
DC260114	KIT,GEARING	95	2B-43
DC260115	KIT,GEARING	100	2A-49
DC260115	KIT,GEARING	100	2B-43
DC260116	KIT,ARMATURE	105	2A-49
DC260116	KIT,ARMATURE	105	2B-43
DC260117	KIT,Gasket Water Pump	15	2A-59
DC260117	KIT,Gasket Water Pump	15	2B-53
DC260118	KIT,COUPLING	10	2A-65
DC260118	KIT,COUPLING	10	2B-59
DC260125	KIT,CYLINDER HEAD GASKET	390	2A-13
DC260125	KIT,CYLINDER HEAD GASKET	390	2A-15
DC260131	KIT, CYLINDER HEAD GASKET	390	2B-11
DC260151	CRANKSHAFT,C/W MAIN/BIG END BEARINGS	5	2A-21
DC260151	CRANKSHAFT,C/W MAIN/BIG END BEARINGS	5	2B-17
DC260152	KIT, REPAIR SCREWS	215	2A-51
DC260152	KIT, REPAIR SCREWS	215	2B-45
DC260153	PISTON RING SET,102.30MM	20	2A-23
DC260153	PISTON RING SET,102.30MM	20	2B-19
DC260154	PISTON RING SET,102.60MM	20	2A-23
DC260154	PISTON RING SET,102.60MM	20	2B-19
DC260161	KIT,EXHAUST BRAKE	95	2B-39
DC280018	BUSH,TAPER F'SEAL FITTING	8	10-3
DC280033	TOOL,IMPACT PULLER INJ/NOZZLES	32	10-5
DC280046	TOOL,DELIVERY PUMP TESTER	12	10-3
DC280056	TOOL,BRACING	5	10-7
DC280057	TOOL,INTERNAL PULLER	4	10-7
DC280062	TOOL,REAMER (D=8,99)	10	10-7
DC280064	TOOL,VALVE GUIDE HOLE	11	10-7
DC280071	TOOL,PISTON RING CLAMPING	7	10-7
DC280075	TOOL,PISTON RING PLIERS	6	10-7
DC280096	TOOL,GAUGE CYL.PROTRUSION	20	10-5
DC280127	TOOL,TUBE WRENCH INJ.LINES	7	10-3
DC280134	TOOL,PLIERS PISTON RING	21	10-5
DC280147	TOOL,VALVE-LIFTER MERC	15	10-9
DC280155	TOOL,COMPRESSION-RECORDER MERC	3	10-3
DC280160	TESTER,HARDNESS "SKLEROGRAPH"	3	10-7
DC280162	TESTER,COOLING SYSTEM	17	10-3
DC280167	OIL CONTAINER,PRIMING LUB.SYST	34	10-5
DC280170	VALVE,SEATRING TURNING CUTTER	7	10-11
DC280171	PULLER	16	10-3
DC280178	TESTER,CHARGE AIR PRESSURE	14	10-3
DC280180	HANDLE,SPRING RETAINER	23	10-5
ST20032	BEARING,DEEP GROOVE BALL	58	3-89
T105773	GUIDE	1	4-53
T55224	BUMPER	12	7-37
Z0630001048	WASHER	030	3-69
Z0630001048	WASHER	040	3-67
Z0630001048	WASHER	060	3-39
Z0630001048	WASHER	114	3-39
Z0630001048	WASHER	580	3-7
Z0630001048	WASHER	590	3-7
Z0630502228	RING,RETAINING	172	3-49
Z0630502228	RING,RETAINING	370	3-53
Z0630502228	RING,RETAINING	380	3-53
Z0630502228	RING,RETAINING	/172	3-47
Z0630502228	RING,RETAINING	/370	3-51
Z0630502228	RING,RETAINING	/380	3-51
Z0630503015	RING,SNAP	580	3-15
Z0630503015	RING,SNAP	580	3-21
Z0634801045	RING,SEALING	/140	3-55
Z0634801063	RING,SEALING	080	3-35
Z0634801063	RING,SEALING	080	3-37
Z0634801063	RING,SEALING	110	3-71
Z0634801151	RING,SEALING	120	3-71
Z0634801151	RING,SEALING	124	3-71
Z0634801151	RING,SEALING	180	3-7
Z0634801151	RING,SEALING	180	3-9
Z0634801152	RING,SEALING	190	3-7
Z0634801152	RING,SEALING	190	3-9
Z0634801152	RING,SEALING	300	3-11
Z0634801152	RING,SEALING	300	3-17
Z0634801152	RING,SEALING	540	3-15
Z0634801152	RING,SEALING	540	3-21
Z0634801152	RING,SEALING	760	3-15
Z0634801152	RING,SEALING	760	3-21
Z0637835033	UNION SCREW	300	3-11

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
Z0637835033	UNION SCREW	300	3-17
Z0732041934	SPRING,COMPRESSION	030	3-23
Z0734401270	RING,PISTON	380	3-11
Z0734401270	RING,PISTON	380	3-17
Z0750116266	BEARING,BALL	/260	3-63
Z0750116266	BEARING,BALL	/260	3-65
Z4139320085	RING,STATOR	010	3-23
Z4139330600	DIAPHRAGM	1	3-3
Z4139330600	DIAPHRAGM	1	3-5
ZF100004	STUD,GROOVED	810	3-67
ZF100004	STUD,GROOVED	810	3-69
ZF100017	SCREW,HEX	368	3-129
ZF100017	SCREW,HEX	368	3-151
ZF100018	HEXAGON SCREW	574	3-61
ZF100026	SCREW,CAP	320	3-49
ZF100026	SCREW,CAP	530	3-53
ZF100026	SCREW,CAP	580	3-53
ZF100026	WASHER	/210	3-55
ZF100026	SCREW,CAP	/320	3-47
ZF100026	SCREW,CAP	/530	3-51
ZF100026	SCREW,CAP	/580	3-51
ZF100027	SCREW,CAP	400	3-11
ZF100027	SCREW,CAP	400	3-17
ZF100027	SCREW,CAP	404	3-11
ZF100027	SCREW,CAP	404	3-17
ZF100056	NUT,ADJUSTING	220	3-107
ZF100056	NUT,ADJUSTING	220	3-163
ZF100057	PIN,SLOT	230	3-107
ZF100057	PIN,SLOT	230	3-163
ZF100058	WASHER	300	3-107
ZF100058	WASHER	300	3-163
ZF100059	NUT,SLOTTED	320	3-107
ZF100059	NUT,SLOTTED	320	3-163
ZF100060	SCREW,LOCKING	130	3-109
ZF100060	SCREW,LOCKING	130	3-165
ZF100061	SCREW,CAP	114	3-109
ZF100061	SCREW,CAP	114	3-165
ZF100061	SCREW,CAP	120	3-115
ZF100061	SCREW,CAP	120	3-183
ZF100074	PIN,SLOTTED	230	3-113
ZF100074	PIN,SLOTTED	230	3-181
ZF100075	WASHER	300	3-113
ZF100075	WASHER	300	3-181
ZF100076	NUT,HEXAGON	320	3-113
ZF100076	NUT,HEXAGON	320	3-181
ZF100077	RING,SNAP	020	3-115
ZF100077	SNAP RING	20	3-131
ZF100077	SNAP RING	20	3-153
ZF100077	RING,SNAP	020	3-183
ZF100078	WASHER,THRUST	030	3-115
ZF100078	WASHER,THRUST	30	3-131
ZF100078	WASHER,THRUST	30	3-153
ZF100078	WASHER,THRUST	030	3-183
ZF100079	WASHER,THRUST	036	3-115
ZF100079	WASHER,THRUST	036	3-183
ZF100080	PIN,DRIVING	100	3-115
ZF100080	PIN,DRIVING	100	3-131
ZF100080	PIN,DRIVING	100	3-153
ZF100080	PIN,DRIVING	100	3-183
ZF100086	NUT,ADJUSTING	220	3-113
ZF100086	NUT,ADJUSTING	220	3-181
ZF100087	SCREW,LOCKING	130	3-115
ZF100087	SCREW,LOCKING	130	3-183
ZF100101	SCREW,CAP	402	3-11
ZF100101	SCREW,CAP	402	3-17
ZF100110	SCREW,HEX	620	3-15
ZF100110	SCREW,HEX	620	3-21
ZF100115	SPRING,COMPRESSION	210	3-49
ZF100115	SPRING,COMPRESSION	410	3-53
ZF100115	SPRING,COMPRESSION	420	3-53
ZF100115	SPRING,COMPRESSION	/210	3-47
ZF100115	SPRING,COMPRESSION	/410	3-51
ZF100115	SPRING,COMPRESSION	/420	3-51
ZF100117	SCREW,HEX	670	3-45
ZF100128	WASHER	050	3-71
ZF100128	WASHER	056	3-71
ZF100128	WASHER	062	3-71
ZF100128	WASHER	068	3-71
ZF100128	WASHER	080	3-71
ZF100128	WASHER	086	3-71
ZF100128	WASHER	370	3-23
ZF100128	WASHER	520	3-61
ZF100128	WASHER	530	3-61
ZF100128	WASHER	670	3-45
ZF100156	PLUG,SCREW	160	3-7
ZF100156	PLUG,SCREW	160	3-9
ZF100157	WASHER	120	3-11
ZF100157	WASHER	120	3-17
ZF100158	WASHER	210	3-11
ZF100158	WASHER	210	3-17
ZF100159	SCREW,CAP	420	3-11
ZF100159	SCREW,CAP	420	3-17
ZF100160	WASHER	370	3-11
ZF100160	WASHER	370	3-17
ZF100160	WASHER	400	3-11
ZF100160	WASHER	400	3-17
ZF100160	WASHER	402	3-11
ZF100160	WASHER	402	3-17
ZF100160	WASHER	404	3-11
ZF100160	WASHER	404	3-17
ZF100160	WASHER	410	3-11
ZF100160	WASHER	410	3-17
ZF100160	WASHER	414	3-11
ZF100160	WASHER	414	3-17
ZF100160	WASHER	420	3-11
ZF100160	WASHER	420	3-17
ZF100160	WASHER	430	3-11
ZF100160	WASHER	430	3-17
ZF100160	WASHER	440	3-11
ZF100160	WASHER	440	3-17
ZF100162	SCREW,CAP	370	3-11
ZF100162	SCREW,CAP	370	3-17
ZF100163	SCREW,CAP	410	3-11
ZF100163	SCREW,CAP	410	3-17
ZF100163	SCREW,CAP	414	3-11

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
ZF100163	SCREW,CAP	**414**	3-17	ZF100199	WASHER	**/070**	3-65
ZF100164	SCREW,CAP	**430**	3-11	ZF100200	SCREW,CAP	**/310**	3-63
ZF100164	SCREW,CAP	**430**	3-17	ZF100200	SCREW,CAP	**/310**	3-65
ZF100165	SCREW,CAP	**440**	3-11	ZF100201	WASHER	**/310**	3-63
ZF100165	SCREW,CAP	**440**	3-17	ZF100201	WASHER	**/310**	3-65
ZF100166	SCREW,UNION	**540**	3-15	ZF100202	WASHER,1.00	**450**	3-65
ZF100166	SCREW,UNION	**540**	3-21	ZF100203	SCREW,HEXAGON	**030**	3-67
ZF100166	SCREW,UNION	**760**	3-15	ZF100203	SCREW,HEXAGON	**030**	3-69
ZF100166	SCREW,UNION	**760**	3-21	ZF100203	SCREW,HEXAGON	**040**	3-67
ZF100167	RING,SNAP	**590**	3-15	ZF100203	SCREW,HEX	**580**	3-7
ZF100167	RING,SNAP	**590**	3-21	ZF100203	SCREW,HEX	**590**	3-7
ZF100169	SCREW,HEX	**610**	3-15	ZF100204	SCREW,CAP	**550**	3-67
ZF100169	SCREW,HEX	**610**	3-21	ZF100204	SCREW,CAP	**550**	3-69
ZF100170	SNAP,RING	**650**	3-11	ZF100206	PLUG,SCREW	**110**	3-71
ZF100170	SNAP,RING	**650**	3-17	ZF100207	WASHER,FLANGE NUT	**470**	3-129
ZF100170	RING,SNAP	**650**	3-19	ZF100207	WASHER,FLANGE NUT	**470**	3-151
ZF100172	SCREW,HEX	**100**	3-23	ZF100208	NUT,FLANGE	**480**	3-129
ZF100173	SCREW,HEX	**370**	3-23	ZF100208	NUT,FLANGE	**480**	3-151
ZF100174	RING,SNAP	**130**	3-27	ZF100233	PIN,SLOTTED	**224**	3-127
ZF100175	SHIM,END	**180**	3-27	ZF100233	PIN,SLOTTED	**224**	3-149
ZF100176	PLUG,SCREW	**014**	3-39	ZF100233	PIN,SLOTTED	**340**	3-129
ZF100176	PLUG,SCREW	**358**	3-39	ZF100233	PIN,SLOTTED	**340**	3-151
ZF100176	PLUG,SCREW	**454**	3-41	ZF100234	PIN,SLOT	**232**	3-127
ZF100176	SCREW,PLUG	**464**	3-41	ZF100234	PIN,SLOT	**232**	3-149
ZF100177	SCREW,HEXAGON	**060**	3-39	ZF100237	PLUG,SCREW	**256**	3-127
ZF100178	SCREW,HEXAGON	**114**	3-39	ZF100237	PLUG,SCREW	**256**	3-149
ZF100179	WASHER	**310**	3-39	ZF100321	SCREW,LOCKING	**230**	3-127
ZF100180	WASHER,TAB	**320**	3-39	ZF100321	SCREW,LOCKING	**230**	3-149
ZF100181	SCREW,HEX	**360**	3-129	ZF100322	SCREW,HEX	**250**	3-127
ZF100181	SCREW,HEX	**360**	3-151	ZF100322	SCREW,HEX	**250**	3-149
ZF100182	STUD	**430**	3-41	ZF100323	SCREW,CAP	**330**	3-11
ZF100183	WASHER	**430**	3-41	ZF100323	SCREW,CAP	**330**	3-17
ZF100184	NUT,HEX	**430**	3-41	ZF100323	SCREW,CAP	**630**	3-15
ZF100185	PLUG	**440**	3-41	ZF100323	SCREW,CAP	**630**	3-21
ZF100186	WASHER	**050**	3-49	ZF100324	WASHER	**382**	3-11
ZF100186	WASHER	**200**	3-53	ZF100324	WASHER	**382**	3-17
ZF100186	WASHER	**210**	3-53	ZF100325	SCREW,CAP	**600**	3-15
ZF100186	WASHER	**/050**	3-47	ZF100325	SCREW,CAP	**600**	3-21
ZF100186	WASHER	**/200**	3-51	ZF100326	PIN,SLOT	**700**	3-13
ZF100186	WASHER	**/210**	3-51	ZF100326	PIN,SLOT	**700**	3-19
ZF100187	WASHER	**170**	3-49	ZF100327	PIN,SLOT	**704**	3-13
ZF100187	WASHER	**350**	3-53	ZF100327	PIN,SLOT	**704**	3-19
ZF100187	WASHER	**360**	3-53	ZF100328	SCREW,CAP	**850**	3-15
ZF100187	WASHER	**/170**	3-47	ZF100328	SCREW,CAP	**850**	3-21
ZF100187	WASHER	**/350**	3-51	ZF100329	WASHER	**046**	3-27
ZF100187	WASHER	**/360**	3-51	ZF100330	WASHER	**222**	3-39
ZF100189	NUT,SLOTTED	**060**	3-57	ZF100331	SCREW,HEX	**330**	3-39
ZF100189	NUT,SLOTTED	**060**	3-59	ZF100332	WASHER	**320**	3-49
ZF100190	SCREW,HEX	**050**	3-71	ZF100332	WASHER	**530**	3-53
ZF100190	SCREW,HEX	**056**	3-71	ZF100332	WASHER	**580**	3-53
ZF100190	SCREW,HEX	**062**	3-71	ZF100332	WASHER	**/320**	3-47
ZF100190	SCREW,HEX	**068**	3-71	ZF100332	WASHER	**/530**	3-51
ZF100190	SCREW,HEX	**080**	3-71	ZF100332	WASHER	**/580**	3-51
ZF100190	SCREW,HEX	**086**	3-71	ZF100333	PLUG,SCREW	**600**	3-43
ZF100190	HEXAGON SCREW	**520**	3-61	ZF100334	SCREW,CAP	**/240**	3-63
ZF100190	HEXAGON SCREW	**540**	3-61	ZF100334	SCREW,CAP	**/240**	3-65
ZF100191	HEXAGON SCREW	**530**	3-61	ZF100335	SCREW,CAP	**640**	3-69
ZF100192	SCREW PLUG	**550**	3-61	ZF100337	WASHER,0.80	**450**	3-65
ZF100193	TAB WASHER	**572**	3-61	ZF100338	WASHER,0.50	**450**	3-65
ZF100195	PLUG,SCREW	**020**	3-65	ZF100390	SCREW,CAP	**/210**	3-55
ZF100197	SCREW,CAP	**150**	3-65	ZF120004	PLUG,SCREW	**100**	3-71
ZF100199	WASHER	**/070**	3-63	ZF120004	PLUG,SCREW	**190**	3-7

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
ZF120004	PLUG,SCREW	**190**	3-9	ZF140090	SEAL,SHAFT	**020**	3-39
ZF120005	PLUG,SCREW	**120**	3-71	ZF140091	O-RING	**380**	3-41
ZF120005	PLUG,SCREW	**180**	3-7	ZF140091	O-RING,4X1.5	**660**	3-45
ZF120005	PLUG,SCREW	**180**	3-9	ZF140093	O-RING	**120**	3-49
ZF120006	ORIFICE,0.8	**200**	3-49	ZF140093	O-RING	**270**	3-53
ZF120006	ORIFICE,0.8	**206**	3-49	ZF140093	O-RING	**/120**	3-47
ZF120006	ORIFICE,0.8	**402**	3-53	ZF140093	O-RING	**/270**	3-51
ZF120006	ORIFICE,0.8	**404**	3-53	ZF140094	O-RING	**150**	3-49
ZF120006	ORIFICE,0.8	**406**	3-53	ZF140094	O-RING	**310**	3-53
ZF120006	ORIFICE,0.8	**408**	3-53	ZF140094	O-RING	**320**	3-53
ZF120006	ORIFICE,0.8	**/200**	3-47	ZF140094	O-RING	**/150**	3-47
ZF120006	ORIFICE,0.8	**/206**	3-47	ZF140094	O-RING	**/310**	3-51
ZF120006	ORIFICE,0.8	**/402**	3-51	ZF140094	O-RING	**/320**	3-51
ZF120006	ORIFICE,0.8	**/404**	3-51	ZF140095	SEALING RING	**550**	3-61
ZF120006	ORIFICE,0.8	**/406**	3-51	ZF140096	O-RING	**560**	3-61
ZF120006	ORIFICE,0.8	**/408**	3-51	ZF140097	O-RING	**590**	3-61
ZF120009	PLUG,SCREW	**080**	3-35	ZF140098	RING,SEALING	**020**	3-65
ZF120009	PLUG,SCREW	**080**	3-37	ZF140099	O-RING	**/250**	3-63
ZF120014	PLUG,SCREW	**/140**	3-55	ZF140099	O-RING	**/250**	3-65
ZF120034	ORIFICE,0.7	**202**	3-49	ZF140100	O-RING	**590**	3-67
ZF120034	ORIFICE,0.7	**/202**	3-47	ZF140100	O-RING	**590**	3-69
ZF120035	ORIFICE,1.00	**204**	3-49	ZF140101	O-RING	**594**	3-67
ZF120035	ORIFICE,1.00	**/204**	3-47	ZF140102	O-RING	**624**	3-69
ZF140008	O-RING	**11**	3-185	ZF140103	O-RING	**012**	3-71
ZF140030	SEAL,SHAFT	**280**	3-107	ZF140104	RING,SEALING	**150**	3-71
ZF140030	SEAL,SHAFT	**280**	3-163	ZF140106	SEAL,SHAFT	**280**	3-127
ZF140041	SEAL,SHAFT	**280**	3-113	ZF140106	SEAL,SHAFT	**280**	3-149
ZF140041	SEAL,SHAFT	**280**	3-181	ZF140115	RING,SEALING	**258**	3-127
ZF140069	SEALING RING	**114**	3-71	ZF140115	RING,SEALING	**258**	3-149
ZF140070	RING,SEALING	**100**	3-71	ZF140116	SEAL,SHAFT	**350**	3-129
ZF140071	RING,SEALING	**500**	3-7	ZF140116	SEAL,SHAFT	**350**	3-151
ZF140072	WASHER,SEALING	**520**	3-7	ZF140159	O-RING	**384**	3-11
ZF140074	RING,SEALING	**500**	3-9	ZF140159	O-RING	**384**	3-17
ZF140075	SEAL,SHAFT	**510**	3-15	ZF140160	O-RING	**790**	3-15
ZF140075	SEAL,SHAFT	**510**	3-21	ZF140160	O-RING	**790**	3-21
ZF140075	WASHER,SEALING	**520**	3-9	ZF140161	WASHER,SEALING	**130**	3-23
ZF140076	O-RING	**520**	3-15	ZF140162	SEAL,LIP RING	**080**	3-27
ZF140076	O-RING	**520**	3-21	ZF140163	SEAL,LIP RING	**090**	3-27
ZF140077	SEALING RING	**540**	3-61	ZF140164	RING,SEALING	**210**	3-27
ZF140077	RING,SEALING	**600**	3-15	ZF140165	RING,SEALING	**250**	3-27
ZF140077	RING,SEALING	**600**	3-21	ZF140166	SEAL,LIP RING	**440**	3-27
ZF140077	RING,SEALING	**610**	3-15	ZF140167	SEAL,LIP RING	**470**	3-27
ZF140077	RING,SEALING	**610**	3-21	ZF140168	O-RING,40X3	**420**	3-41
ZF140077	RING,SEALING	**620**	3-15	ZF140169	RING,SEALING	**/190**	3-63
ZF140077	RING,SEALING	**620**	3-21	ZF140169	RING,SEALING	**/190**	3-65
ZF140077	RING,SEALING	**630**	3-15	ZF140170	RING,SEALING	**/200**	3-63
ZF140077	RING,SEALING	**630**	3-21	ZF140170	RING,SEALING	**/200**	3-65
ZF140079	O-RING	**810**	3-15	ZF140171	SEAL,OIL	**280**	3-127
ZF140079	O-RING	**810**	3-21	ZF140171	SEAL,OIL	**280**	3-149
ZF140081	O-RING	**390**	3-23	ZF140176	O-RING	**594**	3-69
ZF140084	SEAL,LIP RING	**020**	3-31	ZF150030	BEARING,ROLLER	**100**	3-113
ZF140084	SEAL,LIP RING	**020**	3-29	ZF150030	BEARING,ROLLER	**100**	3-181
ZF140086	O-RING	**480**	3-27	ZF150031	BEARING,ROLLER	**050**	3-105
ZF140087	SEAL,LIP RING	**030**	3-31	ZF150031	BEARING,ROLLER	**050**	3-161
ZF140087	SEAL,LIP RING	**030**	3-29	ZF150032	BEARING,ROLLER	**100**	3-107
ZF140088	SEAL,LIP RING	**030**	3-35	ZF150032	BEARING,ROLLER	**100**	3-163
ZF140088	SEAL,LIP RING	**030**	3-37	ZF150033	BEARING,ROLLER	**170**	3-107
ZF140088	SEAL,LIP RING	**040**	3-39	ZF150033	BEARING,ROLLER	**170**	3-163
ZF140089	RING,SEALING	**014**	3-39	ZF150034	BEARING,ROLLER	**200**	3-107
ZF140089	RING,SEALING	**358**	3-39	ZF150040	BEARING,ROLLER	**200**	3-125
ZF140089	RING,SEALING	**454**	3-41	ZF150040	BEARING,ROLLER	**200**	3-147
ZF140089	RING,SEALING	**464**	3-41	ZF150047	BEARING,ROLLER	**170**	3-113

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
ZF150047	BEARING,ROLLER	**170**	3-181	ZF160178	SPACER RING,S = 7,84	**080**	3-161
ZF150048	BEARING,ROLLER	**200**	3-113	ZF160179	SPACER RING,S = 7,86	**080**	3-105
ZF150048	BEARING,ROLLER	**200**	3-181	ZF160179	SPACER RING,S = 7,86	**080**	3-161
ZF150054	BEARING,ROLLER	**200**	3-163	ZF160180	SPACER RING,S = 7,88	**080**	3-105
ZF150082	BEARING,ROLLER	**050**	3-113	ZF160180	SPACER RING,S = 7,88	**080**	3-161
ZF150082	BEARING,ROLLER	**050**	3-181	ZF160181	SPACER RING,S = 7,92	**080**	3-105
ZF150092	BEARING,ROLLER	**050**	3-125	ZF160181	SPACER RING,S = 7,92	**080**	3-161
ZF150092	BEARING,ROLLER	**050**	3-147	ZF160182	SPACER RING,S = 7,94	**080**	3-105
ZF150093	BEARING,ROLLER	**080**	3-125	ZF160182	SPACER RING,S = 7,94	**080**	3-161
ZF150093	BEARING,ROLLER	**080**	3-147	ZF160183	SPACER RING,S = 7,96	**080**	3-105
ZF150094	BEARING,ROLLER	**100**	3-125	ZF160183	SPACER RING,S = 7,96	**080**	3-161
ZF150094	BEARING,ROLLER	**100**	3-147	ZF160184	SPACER RING,S = 7,98	**080**	3-105
ZF150095	BEARING,ROLLER	**122**	3-125	ZF160184	SPACER RING,S = 7,98	**080**	3-161
ZF150095	BEARING,ROLLER	**122**	3-147	ZF160185	SPACER RING,S = 8,02	**080**	3-105
ZF150096	BEARING,ROLLER	**082**	3-125	ZF160185	SPACER RING,S = 8,02	**080**	3-161
ZF150096	BEARING,ROLLER	**082**	3-147	ZF160186	SPACER RING,S = 8,04	**080**	3-105
ZF150097	BEARING,ROLLER	**214**	3-125	ZF160186	SPACER RING,S = 8,04	**080**	3-161
ZF150097	BEARING,ROLLER	**214**	3-147	ZF160187	SPACER RING,S = 8,06	**080**	3-105
ZF150132	SLEEVE,NEEDLE	**/200**	3-39	ZF160187	SPACER RING,S = 8,06	**080**	3-161
ZF150133	BEARING,BALL	**/090**	3-63	ZF160188	SPACER RING,S = 8,08	**080**	3-105
ZF150133	BEARING,BALL	**/090**	3-65	ZF160188	SPACER RING,S = 8,08	**080**	3-161
ZF150134	BEARING,BALL	**390**	3-11	ZF160189	SPACER RING,S = 8,12	**080**	3-105
ZF150134	BEARING,BALL	**390**	3-17	ZF160189	SPACER RING,S = 8,12	**080**	3-161
ZF160159	SPACER RING,S = 7,3	**080**	3-105	ZF160190	SPACER RING,S = 8,14	**080**	3-105
ZF160159	SPACER RING,S = 7,3	**080**	3-161	ZF160190	SPACER RING,S = 8,14	**080**	3-161
ZF160160	SPACER RING,S = 7,4	**080**	3-105	ZF160191	SPACER RING,S = 8,16	**080**	3-105
ZF160160	SPACER RING,S = 7,4	**080**	3-161	ZF160191	SPACER RING,S = 8,16	**080**	3-161
ZF160161	SPACER RING,S = 7,5	**080**	3-105	ZF160192	SPACER RING,S = 8,18	**080**	3-105
ZF160161	SPACER RING,S = 7,5	**080**	3-161	ZF160192	SPACER RING,S = 8,18	**080**	3-161
ZF160162	SPACER RING,S = 7,6	**080**	3-105	ZF160193	WASHER,S=0,7	**130**	3-107
ZF160162	SPACER RING,S = 7,6	**080**	3-161	ZF160193	WASHER,S=0,7	**130**	3-113
ZF160163	SPACER RING,S = 7,7	**080**	3-105	ZF160193	WASHER,S=0,7	**130**	3-163
ZF160163	SPACER RING,S = 7,7	**080**	3-161	ZF160193	WASHER,0.7	**130**	3-181
ZF160164	SPACER RING,S = 7,9	**080**	3-105	ZF160194	WASHER,S=0,8	**130**	3-107
ZF160164	SPACER RING,S = 7,9	**080**	3-161	ZF160194	WASHER,S=0,8	**130**	3-113
ZF160165	SPACER RING,S = 8,0	**080**	3-105	ZF160194	WASHER,S=0,8	**130**	3-163
ZF160165	SPACER RING,S = 8,0	**080**	3-161	ZF160194	WASHER,0.8	**130**	3-181
ZF160166	SPACER RING,S = 8,1	**080**	3-105	ZF160195	WASHER,S=0,9	**130**	3-107
ZF160166	SPACER RING,S = 8,1	**080**	3-161	ZF160195	WASHER,S=0,9	**130**	3-113
ZF160167	SPACER RING,S = 8,2	**080**	3-105	ZF160195	WASHER,S=0,9	**130**	3-163
ZF160167	SPACER RING,S = 8,2	**080**	3-161	ZF160195	WASHER,0.9	**130**	3-181
ZF160168	SPACER RING,S = 8,3	**080**	3-105	ZF160196	WASHER,S=1,0	**130**	3-107
ZF160168	SPACER RING,S = 8,3	**080**	3-161	ZF160196	WASHER,S=1,0	**130**	3-113
ZF160169	SPACER RING,S = 8,4	**080**	3-105	ZF160196	WASHER,S=1,0	**130**	3-163
ZF160169	SPACER RING,S = 8,4	**080**	3-161	ZF160196	WASHER,1.0	**130**	3-181
ZF160170	SPACER RING,S = 8,5	**080**	3-105	ZF160197	WASHER,S=1,1	**130**	3-107
ZF160170	SPACER RING,S = 8,5	**080**	3-161	ZF160197	WASHER,S=1,1	**130**	3-113
ZF160171	SPACER RING,S = 8,6	**080**	3-105	ZF160197	WASHER,S=1,1	**130**	3-163
ZF160171	SPACER RING,S = 8,6	**080**	3-161	ZF160197	WASHER,1.1	**130**	3-181
ZF160172	SPACER RING,S = 8,7	**080**	3-105	ZF160198	WASHER,S=1,2	**130**	3-107
ZF160172	SPACER RING,S = 8,7	**080**	3-161	ZF160198	WASHER,S=1,2	**130**	3-113
ZF160173	SPACER RING,S = 8,8	**080**	3-105	ZF160198	WASHER,S=1,2	**130**	3-163
ZF160173	SPACER RING,S = 8,8	**080**	3-161	ZF160198	WASHER,1.2	**130**	3-181
ZF160174	SPACER RING,S = 8,9	**080**	3-105	ZF160199	WASHER,S=1,3	**130**	3-107
ZF160174	SPACER RING,S = 8,9	**080**	3-161	ZF160199	WASHER,S=1,3	**130**	3-113
ZF160175	SPACER RING,S = 9,0	**080**	3-105	ZF160199	WASHER,S=1,3	**130**	3-163
ZF160175	SPACER RING,S = 9,0	**080**	3-161	ZF160199	WASHER,1.3	**130**	3-181
ZF160176	SPACER RING,S = 7,8	**080**	3-105	ZF160200	WASHER,S=1,4	**130**	3-107
ZF160176	SPACER RING,S = 7,8	**080**	3-161	ZF160200	WASHER,S=1,4	**130**	3-113
ZF160177	SPACER RING,S = 7,82	**080**	3-105	ZF160200	WASHER,S=1,4	**130**	3-163
ZF160177	SPACER RING,S = 7,82	**080**	3-161	ZF160200	WASHER,1.4	**130**	3-181
ZF160178	SPACER RING,S = 7,84	**080**	3-105	ZF160201	WASHER,S=1,5	**130**	3-107

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
ZF160201	WASHER,S=1,5	**130**	3-113	ZF160409	SHIM,0.40	**250**	3-39
ZF160201	WASHER,S=1,5	**130**	3-163	ZF160410	BEARING,TAPER ROLLER	**260**	3-39
ZF160201	WASHER,1.5	**130**	3-181	ZF160411	FLANGE,OUTPUT	**300**	3-39
ZF160203	SPACER,WASHER S=8,8	**080**	3-113	ZF160412	SHIM,6.00	**380**	3-39
ZF160204	SPACER,WASHER S=8,7	**080**	3-113	ZF160412	WASHER,6.00	**640**	3-43
ZF160204	SPACER,WASHER,8.7	**080**	3-181	ZF160413	SHIM,5.80	**380**	3-39
ZF160205	SPACER,WASHER S=8,6	**080**	3-113	ZF160413	WASHER,5.80	**640**	3-43
ZF160205	SPACER,WASHER,8.6	**080**	3-181	ZF160414	SHIM,5.60	**380**	3-39
ZF160206	SPACER,WASHER S=8,5	**080**	3-113	ZF160414	WASHER,5.60	**640**	3-43
ZF160206	SPACER,WASHER,8.5	**080**	3-181	ZF160415	SHIM,5.40	**380**	3-39
ZF160207	SPACER,WASHER S=8,4	**080**	3-113	ZF160415	WASHER,5.40	**640**	3-43
ZF160207	SPACER,WASHER,8.4	**080**	3-181	ZF160416	SHIM,5.20	**380**	3-39
ZF160208	SPACER,WASHER S=8,3	**080**	3-113	ZF160416	WASHER,5.20	**640**	3-43
ZF160208	SPACER,WASHER,8.3	**080**	3-181	ZF160417	SHIM,5.00	**380**	3-41
ZF160209	SPACER,WASHER S=8,9	**080**	3-113	ZF160417	WASHER,5.00	**640**	3-43
ZF160209	SPACER,WASHER,8.9	**080**	3-181	ZF160418	SHIM,4.80	**380**	3-41
ZF160210	SPACER,WASHER S=9,1	**080**	3-113	ZF160418	WASHER,4.80	**640**	3-43
ZF160210	SPACER,WASHER,9.1	**080**	3-181	ZF160419	SHIM,4.60	**380**	3-41
ZF160211	SPACER,WASHER S=9,2	**080**	3-113	ZF160419	WASHER,4.60	**640**	3-43
ZF160211	SPACER,WASHER,9.2	**080**	3-181	ZF160420	SHIM,4.40	**380**	3-41
ZF160212	SPACER,WASHER S=9,3	**080**	3-113	ZF160420	WASHER,4.40	**640**	3-43
ZF160212	SPACER,WASHER,9.3	**080**	3-181	ZF160421	SHIM,4.20	**380**	3-41
ZF160213	SPACER,WASHER S=9,4	**080**	3-113	ZF160421	WASHER,4.20	**640**	3-43
ZF160213	SPACER,WASHER,9.4	**080**	3-181	ZF160422	SHIM,4.00	**380**	3-41
ZF160232	WASHER,S=0,2	**130**	3-113	ZF160422	WASHER,4.00	**640**	3-43
ZF160232	WASHER,0.2	**130**	3-181	ZF160423	SHIM,3.80	**380**	3-41
ZF160233	WASHER,S=0,1	**130**	3-113	ZF160423	WASHER,3.80	**640**	3-43
ZF160233	WASHER,0.1	**130**	3-181	ZF160424	SHIM,3.60	**380**	3-41
ZF160379	RING,RETAINING	**130**	3-11	ZF160424	WASHER,3.60	**640**	3-43
ZF160379	RING,RETAINING	**130**	3-17	ZF160425	SHIM,3.20	**380**	3-41
ZF160380	RING,SPACER	**170**	3-11	ZF160425	WASHER,3.20	**640**	3-43
ZF160380	RING,SPACER	**170**	3-17	ZF160426	SHIM,3.00	**380**	3-41
ZF160381	RING,RETAINING	**220**	3-11	ZF160426	WASHER,3.00	**640**	3-43
ZF160381	RING,RETAINING	**220**	3-17	ZF160427	SHIM,2.90	**380**	3-41
ZF160382	RING,SPACER	**270**	3-11	ZF160427	WASHER,2.90	**640**	3-43
ZF160382	RING,SPACER	**270**	3-17	ZF160428	SHIM,2.80	**380**	3-41
ZF160383	RING,RETAINING	**490**	3-23	ZF160428	WASHER,2.80	**640**	3-43
ZF160384	RING,RETAINING	/**170**	3-25	ZF160429	SHIM,2.70	**380**	3-41
ZF160384	RING,RETAINING	/**190**	3-25	ZF160429	WASHER,2.70	**640**	3-43
ZF160385	RING,RETAINING	/**170**	3-25	ZF160430	SHIM,2.60	**380**	3-41
ZF160386	WASHER,AXIAL,1.8	**240**	3-25	ZF160430	WASHER,2.60	**640**	3-43
ZF160387	WASHER,AXIAL,1.5	**240**	3-25	ZF160431	SHIM,2.50	**380**	3-41
ZF160388	WASHER,AXIAL,1.2	**240**	3-25	ZF160431	WASHER,2.50	**640**	3-43
ZF160389	WASHER,AXIAL,1.13	**240**	3-25	ZF160432	SHIM,2.40	**380**	3-41
ZF160390	SHIM,1.8	**280**	3-25	ZF160432	WASHER,2.40	**640**	3-45
ZF160391	SHIM,1.6	**280**	3-25	ZF160433	SHIM,2.20	**380**	3-41
ZF160392	SHIM,1.4	**280**	3-25	ZF160433	WASHER,2.20	**640**	3-45
ZF160393	SHIM,1.2	**280**	3-25	ZF160434	SHIM,2.10	**380**	3-41
ZF160394	SHIM,1.0	**280**	3-25	ZF160434	WASHER,2.10	**640**	3-45
ZF160395	RING,RETAINING	**050**	3-27	ZF160435	SHIM,2.00	**380**	3-41
ZF160397	RING,RETAINING	**460**	3-27	ZF160435	WASHER,2.00	**640**	3-45
ZF160398	SHIM,END	**120**	3-29	ZF160436	SHIM,1.90	**380**	3-41
ZF160399	SHIM,1.20	**250**	3-39	ZF160436	WASHER,1.90	**640**	3-45
ZF160400	SHIM,1.15	**250**	3-39	ZF160437	SHIM,1.80	**380**	3-41
ZF160401	SHIM,1.10	**250**	3-39	ZF160437	WASHER,1.80	**640**	3-45
ZF160402	SHIM,1.05	**250**	3-39	ZF160438	SHIM,1.70	**380**	3-41
ZF160403	SHIM,1.00	**250**	3-39	ZF160438	WASHER,1.70	**640**	3-45
ZF160404	SHIM,0.95	**250**	3-39	ZF160439	SHIM,1.60	**380**	3-41
ZF160405	SHIM,0.90	**250**	3-39	ZF160439	WASHER,1.60	**640**	3-45
ZF160406	SHIM,0.85	**250**	3-39	ZF160440	SHIM,1.50	**380**	3-41
ZF160407	SHIM,0.80	**250**	3-39	ZF160440	WASHER,1.50	**640**	3-45
ZF160408	SHIM,0.60	**250**	3-39	ZF160441	SHIM,1.40	**380**	3-41

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
ZF160441	WASHER,1.40	**640**	3-45	ZF160526	SPACER,WASHER S=20.4	**140**	3-147
ZF160442	SHIM,1.30	**380**	3-41	ZF160527	SPACER,WASHER S=20.5	**140**	3-125
ZF160442	WASHER,1.30	**640**	3-45	ZF160527	SPACER,WASHER S=20.5	**140**	3-147
ZF160443	SHIM,1.20	**380**	3-41	ZF160528	SHIM,S = 2,0	**228**	3-127
ZF160443	WASHER,1.20	**640**	3-45	ZF160528	SHIM,S=2,0	**228**	3-149
ZF160444	SHIM,1.00	**380**	3-41	ZF160529	SHIM,S = 2,05	**228**	3-127
ZF160444	WASHER,1.00	**640**	3-45	ZF160529	SHIM,S=2,05	**228**	3-149
ZF160445	SHIM,0.80	**380**	3-41	ZF160530	SHIM,S = 2,1	**228**	3-127
ZF160445	WASHER,0.80	**640**	3-45	ZF160530	SHIM,S=2,1	**228**	3-149
ZF160447	SHIM,2.60	**170**	3-65	ZF160531	SHIM,S = 2,15	**228**	3-127
ZF160448	SHIM,2.50	**170**	3-65	ZF160531	SHIM,S=2,15	**228**	3-149
ZF160449	SHIM,2.00	**170**	3-65	ZF160532	SHIM,S = 2,2	**228**	3-127
ZF160450	SHIM,1.90	**170**	3-65	ZF160532	SHIM,S=2,2	**228**	3-149
ZF160451	SHIM,1.80	**170**	3-65	ZF160533	SHIM,S = 2,25	**228**	3-127
ZF160452	SHIM,1.70	**170**	3-65	ZF160533	SHIM,S=2,25	**228**	3-149
ZF160453	SHIM,1.50	**170**	3-65	ZF160534	SHIM,S = 2,3	**228**	3-127
ZF160454	SHIM,1.20	**170**	3-65	ZF160534	SHIM,S=2,3	**228**	3-149
ZF160455	SHIM,1.10	**170**	3-65	ZF160535	SHIM,S = 2,35	**228**	3-127
ZF160456	SHIM,1.00	**170**	3-65	ZF160535	SHIM,S=2,35	**228**	3-149
ZF160468	SHIM,RING,90X110X2	**240**	3-67	ZF160536	SHIM,S = 2,4	**228**	3-127
ZF160468	SHIM,RING,90X110X2	**240**	3-69	ZF160536	SHIM,S=2,4	**228**	3-149
ZF160469	SHIM,RING,90X110X1.8	**240**	3-67	ZF160537	SHIM,S = 2,45	**228**	3-127
ZF160469	SHIM,RING,90X110X1.8	**240**	3-69	ZF160537	SHIM,S=2,45	**228**	3-149
ZF160470	SHIM,RING,90X110X1.6	**240**	3-67	ZF160538	SHIM,S = 2,5	**228**	3-127
ZF160470	SHIM,RING,90X110X1.6	**240**	3-69	ZF160538	SHIM,S=2,5	**228**	3-149
ZF160471	SHIM,RING,90X110X1.4	**240**	3-67	ZF160539	RING,RETAINING	**318**	3-127
ZF160471	SHIM,RING,90X110X1.4	**240**	3-69	ZF160539	RING,RETAINING	**318**	3-149
ZF160472	SHIM,RING,90X110X1.2	**240**	3-67	ZF160540	WASHER,THRUST	**319**	3-127
ZF160472	SHIM,RING,90X110X1.2	**240**	3-69	ZF160540	WASHER,THRUST	**319**	3-149
ZF160473	SHIM,RING,90X110X1.1	**240**	3-67	ZF160541	NUT,HEX	**322**	3-127
ZF160473	SHIM,RING,90X110X1.1	**240**	3-69	ZF160541	NUT,HEX	**322**	3-149
ZF160474	SHIM,RING,90X110X1.0	**240**	3-67	ZF160542	RING,RETAINING	**346**	3-129
ZF160474	SHIM,RING,90X110X1.0	**240**	3-69	ZF160542	RING,RETAINING	**346**	3-151
ZF160475	SHIM,RING,90X110X0.5	**240**	3-67	ZF160543	RETAINER,SEAL	**380**	3-129
ZF160475	SHIM,RING,90X110X0.5	**240**	3-69	ZF160543	RETAINER,SEAL	**380**	3-151
ZF160476	SHIM,RING,90X110X0.3	**240**	3-67	ZF160777	COVER,DUST	**464**	3-129
ZF160476	SHIM,RING,90X110X0.3	**240**	3-69	ZF160777	COVER,DUST	**464**	3-151
ZF160477	SHIM,RING,90X110X0.2	**240**	3-67	ZF180016	PIPE	**510**	3-7
ZF160477	SHIM,RING,90X110X0.2	**240**	3-69	ZF180016	PIPE	**510**	3-9
ZF160478	SHIM,RING,90X110X0.1	**240**	3-67	ZF180017	PIPE	**290**	3-11
ZF160478	SHIM,RING,90X110X0.1	**240**	3-69	ZF180017	PIPE	**290**	3-17
ZF160479	RING,RETAINING	**570**	3-67	ZF180018	PIPE	**530**	3-15
ZF160479	RING,RETAINING	**570**	3-69	ZF180018	PIPE	**530**	3-21
ZF160480	RING,RETAINING	**600**	3-69	ZF180020	PIPE	**080**	3-33
ZF160481	WASHER,AXIAL,15X28X1	**240**	3-25	ZF180021	PIPE	**170**	3-35
ZF160518	SPACER,WASHER S=19.5	**140**	3-125	ZF180021	PIPE	**170**	3-37
ZF160518	SPACER,WASHER S=19.5	**140**	3-147	ZF200048	FLANGE,INPUT	**420**	3-107
ZF160519	SPACER,WASHER S=19.6	**140**	3-125	ZF200048	FLANGE,INPUT	**420**	3-163
ZF160519	SPACER,WASHER S=19.6	**140**	3-147	ZF200049	RING,DUST PROTECTION	**430**	3-107
ZF160520	SPACER,WASHER S=19.7	**140**	3-125	ZF200049	RING,DUST PROTECTION	**430**	3-163
ZF160520	SPACER,WASHER S=19.7	**140**	3-147	ZF200058	DISC,CLUTCH INNER	**050**	3-109
ZF160521	SPACER,WASHER S=19.8	**140**	3-125	ZF200058	DISC,CLUTCH INNER	**050**	3-165
ZF160521	SPACER,WASHER S=19.8	**140**	3-147	ZF200060	GEAR,BEVEL AXLE	**080**	3-109
ZF160522	SPACER,WASHER S=19.9	**140**	3-125	ZF200060	GEAR,BEVEL AXLE	**080**	3-165
ZF160522	SPACER,WASHER S=19.9	**140**	3-147	ZF200061	WASHER,THRUST	**030**	3-109
ZF160523	SPACER,WASHER S=20.1	**140**	3-125	ZF200061	WASHER,THRUST	**030**	3-165
ZF160523	SPACER,WASHER S=20.1	**140**	3-147	ZF200062	GEAR,BEVEL DIFF	**090**	3-109
ZF160524	SPACER,WASHER S=20.2	**140**	3-125	ZF200062	GEAR,BEVEL DIFF	**090**	3-165
ZF160524	SPACER,WASHER S=20.2	**140**	3-147	ZF200063	WASHER,THRUST	**034**	3-109
ZF160525	SPACER,WASHER S=20.3	**140**	3-125	ZF200063	WASHER,THRUST	**034**	3-165
ZF160525	SPACER,WASHER S=20.3	**140**	3-147	ZF200064	AXLE,DIFFERENTIAL	**070**	3-109
ZF160526	SPACER,WASHER S=20.4	**140**	3-125	ZF200064	AXLE,DIFFERENTIAL	**070**	3-165

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
ZF200101	DUST,PROTECTOR	**428**	3-113	ZF200233	HOUSING,AXLE DRIVE	**020**	3-147
ZF200101	DUST,PROTECTOR	**428**	3-181	ZF200234	NUT,ADJUSTING	**220**	3-127
ZF200105	CAP,SEALING	**014**	3-115	ZF200234	NUT,ADJUSTING	**220**	3-149
ZF200105	CAP,SEAL	**14**	3-131	ZF200235	NUT,ADJUSTING	**222**	3-127
ZF200105	CAP,SEAL	**14**	3-153	ZF200235	NUT,ADJUSTING	**222**	3-149
ZF200105	SEALING,CAP	**014**	3-183	ZF200236	BUSH,BEARING	**288**	3-127
ZF200106	O.CLUTCH DISC,2.2	**040**	3-115	ZF200236	BUSH,BEARING	**288**	3-149
ZF200106	O.CLUTCH DISC,2.2	**40**	3-131	ZF200237	COVER	**328**	3-129
ZF200106	O.CLUTCH DISC,2.2	**40**	3-153	ZF200237	COVER	**328**	3-151
ZF200106	O.CLUTCH DISC,2.2	**040**	3-183	ZF200238	GEAR,SPUR	**610**	3-129
ZF200107	O.CLUTCH DISC,2.3	**040**	3-115	ZF200238	GEAR,SPUR	**610**	3-151
ZF200107	O.CLUTCH DISC,2.3	**40**	3-131	ZF200239	GEAR,SPUR	**630**	3-129
ZF200107	O.CLUTCH DISC,2.3	**40**	3-153	ZF200239	GEAR,SPUR	**630**	3-151
ZF200107	O.CLUTCH DISC,2.3	**040**	3-183	ZF200245	SPACER RING,S = 22,5	**114**	3-125
ZF200108	O.CLUTCH DISC,2.4	**040**	3-115	ZF200245	SPACER RING,S =22,5	**114**	3-147
ZF200108	O.CLUTCH DISC,2.4	**40**	3-131	ZF200245	SPACER RING,S = 22,5	**168**	3-125
ZF200108	O.CLUTCH DISC,2.4	**40**	3-153	ZF200245	SPACER RING,S=22,5	**168**	3-147
ZF200108	O.CLUTCH DISC,2.4	**040**	3-183	ZF200252	RING,SPACER	**140**	3-125
ZF200109	O.CLUTCH DISC,2.5	**040**	3-115	ZF200252	RING,SPACER	**140**	3-147
ZF200109	O.CLUTCH DISC,2.5	**40**	3-131	ZF200253	SHIM,S = 6,2	**144**	3-125
ZF200109	O.CLUTCH DISC,2.5	**40**	3-153	ZF200253	SHIM,S=6,2	**144**	3-147
ZF200109	O.CLUTCH DISC,2.5	**040**	3-183	ZF200254	SHIM,S = 6,1	**144**	3-125
ZF200110	O.CLUTCH DISC,2.1	**040**	3-115	ZF200254	SHIM,S=6,1	**144**	3-147
ZF200110	O.CLUTCH DISC,2.1	**40**	3-131	ZF200255	SHIM,S = 6,0	**144**	3-125
ZF200110	O.CLUTCH DISC,2.1	**40**	3-153	ZF200255	SHIM,S=6,0	**144**	3-147
ZF200110	O.CLUTCH DISC,2.1	**040**	3-183	ZF200256	SHIM,S = 5,9	**144**	3-125
ZF200111	I.CLUTCH DISC	**050**	3-115	ZF200256	SHIM,S=5,9	**144**	3-147
ZF200111	I.CLUTCH DISC	**50**	3-131	ZF200257	SHIM,S = 5,8	**144**	3-125
ZF200111	I.CLUTCH DISC	**50**	3-153	ZF200257	SHIM,S=5,8	**144**	3-147
ZF200111	I.CLUTCH DISC	**050**	3-183	ZF200258	SPACER RING,S = 22,5	**166**	3-125
ZF200113	DIFF AXLE	**070**	3-115	ZF200258	SPACER RING,S=22,5	**166**	3-147
ZF200113	DIFF AXLE	**70**	3-131	ZF200259	SPACER RING,S = 22,6	**166**	3-125
ZF200113	DIFF AXLE	**70**	3-153	ZF200259	SPACER RING,S=22,6	**166**	3-147
ZF200113	AXLE,DIFF	**070**	3-183	ZF200260	SPACER RING,S = 22,7	**166**	3-125
ZF200115	GEAR,DIFF BEVEL	**090**	3-115	ZF200260	SPACER RING,S=22,7	**166**	3-147
ZF200115	GEAR,DIFF BEVEL	**90**	3-131	ZF200261	SPACER RING,S = 22,8	**166**	3-125
ZF200115	GEAR,DIFF BEVEL	**90**	3-153	ZF200261	SPACER RING,S=22,8	**166**	3-147
ZF200115	GEAR,DIFF BEVEL	**090**	3-183	ZF200262	SPACER RING,S = 22,9	**166**	3-125
ZF200129	FLANGE,INPUT	**420**	3-113	ZF200262	SPACER RING,S=22,9	**166**	3-147
ZF200129	FLANGE,INPUT	**420**	3-181	ZF200263	SPACER RING,S = 23,0	**166**	3-125
ZF200165	SHAFT,INPUT	**420**	3-129	ZF200263	SPACER RING,S=23,0	**166**	3-147
ZF200165	SHAFT,INPUT	**420**	3-151	ZF200264	SPACER RING,S = 23,1	**166**	3-125
ZF200168	SHIELD,DUST	**464**	3-129	ZF200264	SPACER RING,S=23,1	**166**	3-147
ZF200168	SHIELD,DUST	**464**	3-151	ZF200265	SPACER RING,S = 23,2	**166**	3-125
ZF200170	GEAR,BEVEL SET	**030**	3-105	ZF200265	SPACER RING,S=23,2	**166**	3-147
ZF200175	HOUSING,LIMITED SLIP DIFF	**010**	3-115	ZF200266	SPACER RING,S = 23,3	**166**	3-125
ZF200175	HOUSING,DIFFERENTIAL	**010**	3-183	ZF200266	SPACER RING,S=23,3	**166**	3-147
ZF200176	HOUSING,DIFF	**110**	3-115	ZF200267	SPACER RING,S = 23,4	**166**	3-125
ZF200176	HOUSING,DIFF	**110**	3-183	ZF200267	SPACER RING,S=23,4	**166**	3-147
ZF200177	HOUSING,DIFF	**010**	3-109	ZF200268	SPACER RING,S = 23,5	**166**	3-125
ZF200177	HOUSING,DIFF	**010**	3-165	ZF200268	SPACER RING,S=23,5	**166**	3-147
ZF200182	GEAR,BEVEL SET	**500**	3-113	ZF200269	SPACER RING,S = 23,6	**166**	3-125
ZF200182	GEAR,BEVEL SET	**500**	3-181	ZF200269	SPACER RING,S=23,6	**166**	3-147
ZF200183	AXLE DR.HOUSING	**020**	3-105	ZF200270	SPACER RING,S = 23,7	**166**	3-125
ZF200183	AXLE DR.HOUSING	**020**	3-161	ZF200270	SPACER RING,S=23,7	**166**	3-147
ZF200184	HOUSING,COVER	**110**	3-109	ZF200271	SPACER RING,S = 23,8	**166**	3-125
ZF200184	HOUSING,COVER	**110**	3-165	ZF200271	SPACER RING,S=23,8	**166**	3-147
ZF200185	GEAR,AXLE BEVEL	**080**	3-115	ZF200272	SPACER RING,S = 23,9	**166**	3-125
ZF200185	GEAR,AXLE BEVEL	**80**	3-131	ZF200272	SPACER RING,S=23,9	**166**	3-147
ZF200185	GEAR,AXLE BEVEL	**80**	3-153	ZF200273	SPACER RING,S = 24,0	**166**	3-125
ZF200185	AXLE,BEVEL GEAR	**080**	3-183	ZF200273	SPACER RING,S=24,0	**166**	3-147
ZF200233	HOUSING,AXLE DRIVE	**020**	3-125	ZF200274	SPACER RING,S = 24,1	**166**	3-125

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
ZF200274	SPACER RING,S=24,1	**166**	3-147	ZF200477	DISC,CLUTCH OUTER,3.3	**040**	3-109
ZF200276	SHIM,S = 0,3	**228**	3-127	ZF200477	DISC,CLUTCH OUTER,3.3	**040**	3-165
ZF200276	SHIM,S=0,3	**228**	3-149	ZF200496	RING,PRESSURE	**060**	3-109
ZF200277	SHIM,S = 0,5	**228**	3-127	ZF200496	RING,PRESSURE	**060**	3-165
ZF200277	SHIM,S=0,5	**228**	3-149	ZF200498	PRESSURE RING	**060**	3-115
ZF200278	SHIM,S = 1,0	**228**	3-127	ZF200498	PRESSURE RING	**60**	3-131
ZF200278	SHIM,S=1,0	**228**	3-149	ZF200498	PRESSURE RING	**60**	3-153
ZF200279	SHIM,S = 0,2	**228**	3-127	ZF200498	PRESSURE RING	**060**	3-183
ZF200279	SHIM,S=0,2	**228**	3-149	ZF200500	HOUSING,DIFF	**10**	3-131
ZF200280	SHIM,S = 1,2	**228**	3-127	ZF200500	HOUSING,DIFF	**10**	3-153
ZF200280	SHIM,S=1,2	**228**	3-149	ZF200501	COVER,HOUSING	**110**	3-131
ZF200281	SHIM,S = 0,1	**228**	3-127	ZF200501	COVER,HOUSING	**110**	3-153
ZF200281	SHIM,S=0,1	**228**	3-149	ZF200520	CROWNWHEEL	**030**	3-125
ZF200282	SHIM,S = 0,15	**228**	3-127	ZF200520	CROWNWHEEL	**030**	3-147
ZF200282	SHIM,S=0,15	**228**	3-149	ZF200521	PINION	**031**	3-125
ZF200283	SHIM,S = 1,2	**228**	3-127	ZF200521	PINION	**031**	3-147
ZF200283	SHIM,S=1,2	**228**	3-149	ZF200524	O. CLUTCH DISC,2.5	**400**	3-27
ZF200284	SHIM,S = 1,3	**228**	3-127	ZF200525	O. CLUTCH DISC,2.0	**400**	3-27
ZF200284	SHIM,S=1,3	**228**	3-149	ZF200526	O. CLUTCH DISC,3.0	**400**	3-27
ZF200285	SHIM,S = 1,4	**228**	3-127	ZF200527	I.CLUTCH DISC	**/160**	3-63
ZF200285	SHIM,S=1,4	**228**	3-149	ZF200527	I.CLUTCH DISC	**/160**	3-65
ZF200286	SHIM,S = 1,5	**228**	3-127	ZF200528	O.CLUTCH DISC,3.5	**/170**	3-63
ZF200286	SHIM,S=1,5	**228**	3-149	ZF200528	O.CLUTCH DISC,3.5	**/170**	3-65
ZF200287	SHIM,S = 1,6	**228**	3-127	ZF200529	O.CLUTCH DISC,4.0	**/170**	3-63
ZF200287	SHIM,S=1,6	**228**	3-149	ZF200529	O.CLUTCH DISC,4.0	**/170**	3-65
ZF200288	SHIM,S = 1,7	**228**	3-127	ZF210188	PLATE,SELECTOR INDICATOR	**/390**	3-73
ZF200288	SHIM,S=1,7	**228**	3-149	ZF210188	PLATE,SELECTOR INDICATOR	**/390**	3-75
ZF200289	SHIM,S = 1,8	**228**	3-127	ZF210190	LEVER,ZF RETARDER,6 POSITION	**540**	3-73
ZF200289	SHIM,S=1,8	**228**	3-149	ZF210192	CAP,SEALING	**100**	3-7
ZF200290	SHIM,S = 2,6	**228**	3-127	ZF210192	CAP,SEALING	**100**	3-9
ZF200290	SHIM,S=2,6	**228**	3-149	ZF210193	GASKET	**020**	3-67
ZF200291	SHIM,S = 2,7	**228**	3-127	ZF210193	GASKET	**020**	3-69
ZF200291	SHIM,S=2,7	**228**	3-149	ZF210193	GASKET	**550**	3-7
ZF200292	SHIM,S = 2,8	**228**	3-127	ZF210193	GASKET	**550**	3-9
ZF200292	SHIM,S=2,8	**228**	3-149	ZF210194	COVER	**570**	3-7
ZF200293	SHIM,S = 2,9	**228**	3-127	ZF210194	COVER	**570**	3-9
ZF200293	SHIM,S=2,9	**228**	3-149	ZF210202	PISTON	**150**	3-11
ZF200294	SHIM,S = 3,0	**228**	3-127	ZF210202	PISTON	**150**	3-17
ZF200294	SHIM,S=3,0	**228**	3-149	ZF210203	SPRING,COMPRESSION	**160**	3-11
ZF200295	SHIM,S = 3,1	**228**	3-127	ZF210203	SPRING,COMPRESSION	**160**	3-17
ZF200295	SHIM,S=3,1	**228**	3-149	ZF210204	PIN,CYLINDRICAL	**180**	3-11
ZF200296	SHIM,S = 3,2	**228**	3-127	ZF210204	PIN,CYLINDRICAL	**180**	3-17
ZF200296	SHIM,S=3,2	**228**	3-149	ZF210204	PIN,CYLINDRICAL	**280**	3-11
ZF200297	SHIM,S = 3,3	**228**	3-127	ZF210204	PIN,CYLINDRICAL	**280**	3-17
ZF200297	SHIM,S=3,3	**228**	3-149	ZF210205	PISTON	**190**	3-11
ZF200298	SHIM,S = 3,4	**228**	3-127	ZF210205	PISTON	**190**	3-17
ZF200298	SHIM,S=3,4	**228**	3-149	ZF210206	SPRING,COMPRESSION	**200**	3-11
ZF200301	GEAR,BEVEL SET	**030**	3-161	ZF210206	SPRING,COMPRESSION	**200**	3-17
ZF200302	HOUSING,AXLE DRIVE	**020**	3-113	ZF210207	PISTON	**250**	3-11
ZF200302	HOUSING,AXLE DRIVE	**020**	3-181	ZF210207	PISTON	**250**	3-17
ZF200323	FLANGE MECH 7C	**460**	3-129	ZF210208	SPRING,COMPRESSION	**260**	3-11
ZF200323	FLANGE MECH 7C	**460**	3-151	ZF210208	SPRING,COMPRESSION	**260**	3-17
ZF200472	DISC,OUTER CLUTCH,3.0	**040**	3-109	ZF210211	RING,INTERMEDIATE	**350**	3-11
ZF200472	DISC,OUTER CLUTCH,3.0	**040**	3-165	ZF210212	RING,THRUST	**360**	3-11
ZF200473	DISC,CLUTCH OUTER,2.7	**040**	3-109	ZF210215	GEAR	**550**	3-15
ZF200473	DISC,CLUTCH OUTER,2.7	**040**	3-165	ZF210215	GEAR	**550**	3-21
ZF200474	DISC,CLUTCH OUTER,2.9	**040**	3-109	ZF210216	GEAR	**560**	3-15
ZF200474	DISC,CLUTCH OUTER,2.9	**040**	3-165	ZF210216	GEAR	**560**	3-21
ZF200475	DISC,CLUTCH OUTER,3.1	**040**	3-109	ZF210217	BEARING,ROLLER	**570**	3-15
ZF200475	DISC,CLUTCH OUTER,3.1	**040**	3-165	ZF210217	BEARING,ROLLER	**570**	3-21
ZF200476	DISC,CLUTCH OUTER,3.2	**040**	3-109	ZF210218	RING,PISTON	**660**	3-11
ZF200476	DISC,CLUTCH OUTER,3.2	**040**	3-165	ZF210218	RING,PISTON	**660**	3-17

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
ZF210218	RING,PISTON	**660**	3-19	ZF210274	PLATE,THRUST	**/150**	3-25
ZF210219	SUPPORT,SUPPORT	**670**	3-11	ZF210275	PLATE,THRUST	**/154**	3-25
ZF210219	SUPPORT,SUPPORT	**670**	3-17	ZF210276	GEAR,RING	**/160**	3-25
ZF210219	SUPPORT,PISTON	**670**	3-19	ZF210277	WASHER,THRUST	**190**	3-25
ZF210220	CAGE,NEEDLE	**680**	3-13	ZF210278	SUN GEAR	**200**	3-25
ZF210220	CAGE,NEEDLE	**680**	3-19	ZF210279	CAGE,NEEDLE	**230**	3-25
ZF210221	RING,INTERNAL	**690**	3-13	ZF210280	RING	**248**	3-25
ZF210221	RING,INTERNAL	**690**	3-19	ZF210281	SHAFT,SUN GEAR	**250**	3-25
ZF210225	BUSH	**/120**	3-13	ZF210282	RING,INTERNAL	**260**	3-25
ZF210225	BUSH	**/120**	3-19	ZF210283	RING,SPLIT	**268**	3-25
ZF210226	SHACKLE	**770**	3-15	ZF210284	RING,ANGLE	**270**	3-25
ZF210226	SHACKLE	**770**	3-21	ZF210285	SHAFT,TURBINE	**010**	3-27
ZF210227	SHEET	**780**	3-15	ZF210286	PIPE	**020**	3-27
ZF210227	SHEET	**780**	3-21	ZF210287	SLEEVE,NEEDLE	**030**	3-27
ZF210229	WASHER,THRUST	**820**	3-15	ZF210289	ROLLER,NEEDLE	**060**	3-27
ZF210229	WASHER,THRUST	**820**	3-21	ZF210290	PIN	**064**	3-27
ZF210230	PLATE,CLAMPING	**830**	3-15	ZF210293	SPRING,CUP	**110**	3-27
ZF210230	PLATE,CLAMPING	**830**	3-21	ZF210294	PLATE,FIXING	**120**	3-27
ZF210231	PLATE,CLAMPING	**840**	3-15	ZF210295	SPRING,CUP	**140**	3-27
ZF210231	PLATE,CLAMPING	**840**	3-21	ZF210296	PLATE,FIXING	**150**	3-27
ZF210233	SEAT,SPRING	**020**	3-23	ZF210297	I. CLUTCH DISC,2.5	**160**	3-27
ZF210234	DAMPER	**040**	3-23	ZF210298	I. CLUTCH DISC,2.0	**160**	3-27
ZF210236	RING,PISTON	**120**	3-23	ZF210299	O. CLUTCH DISC	**170**	3-27
ZF210237	SOLENOID	**300**	3-23	ZF210300	RING,SPLIT	**190**	3-27
ZF210238	BUSH	**400**	3-23	ZF210301	RING,PISTON	**040**	3-35
ZF210239	PISTON	**410**	3-23	ZF210301	RING,PISTON	**040**	3-37
ZF210240	SPRING,COMPRESSION	**440**	3-23	ZF210304	DISC	**260**	3-27
ZF210241	PISTON	**460**	3-23	ZF210305	O. CLUTCH DISC,2.5	**270**	3-27
ZF210242	PISTON	**480**	3-23	ZF210306	O. CLUTCH DISC,2.0	**270**	3-27
ZF210243	RESISTOR	**600**	3-23	ZF210307	I. CLUTCH DISC	**280**	3-27
ZF210244	SHAFT,INPUT	**010**	3-25	ZF210307	I. CLUTCH DISC	**410**	3-27
ZF210245	SLEEVE,NEEDLE	**020**	3-25	ZF210308	PIN	**310**	3-27
ZF210246	WASHER,THRUST	**030**	3-25	ZF210308	PIN	**430**	3-27
ZF210247	SHAFT,QUILL	**040**	3-25	ZF210309	PIN	**320**	3-27
ZF210248	CAGE,NEEDLE	**050**	3-25	ZF210310	SPRING,COMPRESSION	**330**	3-27
ZF210249	WASHER,THRUST	**060**	3-25	ZF210311	DISC	**420**	3-27
ZF210250	CAGE,NEEDLE	**070**	3-25	ZF210313	RING	**454**	3-27
ZF210251	WASHER,THRUST	**074**	3-25	ZF210315	PISTON	**010**	3-31
ZF210252	CARRIER,DISC	**080**	3-25	ZF210315	PISTON	**010**	3-29
ZF210253	DISC CARRIER	**/110**	3-25	ZF210316	O. CLUTCH DISC,3.0	**040**	3-29
ZF210254	GEAR,SUN	**/120**	3-25	ZF210316	O. CLUTCH DISC,3.0	**070**	3-29
ZF210255	RING,SNAP	**/130**	3-25	ZF210317	I. CLUTCH DISC	**070**	3-31
ZF210256	RING,SNAP	**/140**	3-25	ZF210317	I. CLUTCH DISC	**020**	3-33
ZF210257	WASHER,THRUST	**090**	3-25	ZF210317	I. CLUTCH DISC	**050**	3-29
ZF210258	PLANETARY DRIVE	**100**	3-25	ZF210318	O. CLUTCH DISC,2.5	**070**	3-29
ZF210259	CARRIER,PLANET	**/110**	3-25	ZF210319	O. CLUTCH DISC,2.0	**080**	3-31
ZF210260	PIN,BEARING	**/120**	3-25	ZF210319	O. CLUTCH DISC,2.0	**010**	3-33
ZF210261	CAGE,NEEDLE	**/130**	3-25	ZF210319	O. CLUTCH DISC,2.0	**070**	3-29
ZF210262	CAGE,NEEDLE	**/130**	3-25	ZF210320	O. CLUTCH DISC	**080**	3-31
ZF210263	PLANET GEAR SET	**/140**	3-25	ZF210320	O. CLUTCH DISC	**010**	3-33
ZF210264	PLATE,THRUST	**/150**	3-25	ZF210320	O. CLUTCH DISC	**070**	3-29
ZF210265	GEAR,RING	**/160**	3-25	ZF210321	PIN	**090**	3-29
ZF210266	WASHER,THRUST	**110**	3-25	ZF210322	SPRING,COMPRESSION	**100**	3-29
ZF210267	PLANETARY DRIVE	**150**	3-25	ZF210323	RING,SNAP	**130**	3-29
ZF210268	CARRIER,PLANET	**/110**	3-25	ZF210324	HOLDER,SPRING	**150**	3-31
ZF210269	PIN,BEARING	**/120**	3-25	ZF210324	HOLDER,SPRING	**150**	3-29
ZF210270	PIN,SLOT	**/122**	3-25	ZF210325	SPRING,CUP	**160**	3-31
ZF210270	PIN,SLOT	**/160**	3-39	ZF210325	SPRING,CUP	**160**	3-29
ZF210270	PIN,SLOT	**/250**	3-39	ZF210326	PIN	**040**	3-31
ZF210271	CAGE,NEEDLE	**/130**	3-25	ZF210326	PIN	**060**	3-33
ZF210272	CAGE,NEEDLE	**/130**	3-25	ZF210327	O. CLUTCH DISC,3.0	**050**	3-31
ZF210273	PLANET GEAR SET	**/140**	3-25	ZF210327	O. CLUTCH DISC,3.0	**080**	3-31

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
ZF210327	O. CLUTCH DISC,3.0	010	3-33	ZF210368	SCREW,TORX	/090	3-47
ZF210328	O. CLUTCH DISC,2.5	080	3-31	ZF210368	SCREW,TORX	/250	3-51
ZF210328	O. CLUTCH DISC,2.5	010	3-33	ZF210368	SCREW,TORX	/290	3-47
ZF210330	O. CLUTCH DISC	040	3-33	ZF210368	SCREW,TORX	/510	3-51
ZF210331	SPRING,COMPRESSION	070	3-33	ZF210369	PLATE,INTERMEDIATE	030	3-43
ZF210332	GASKET	010	3-35	ZF210372	PISTON	020	3-49
ZF210332	GASKET	010	3-37	ZF210372	PISTON	120	3-53
ZF210332	GASKET	050	3-39	ZF210372	PISTON	124	3-53
ZF210333	PISTON	020	3-35	ZF210372	PISTON	/020	3-47
ZF210333	PISTON	020	3-37	ZF210372	PISTON	/120	3-51
ZF210334	RING,PISTON	044	3-39	ZF210372	PISTON	/124	3-51
ZF210334	RING,PISTON	050	3-35	ZF210373	SPRING,COMPRESSION	040	3-49
ZF210334	RING,PISTON	050	3-37	ZF210373	SPRING,COMPRESSION	190	3-53
ZF210335	HOUSING,INTERMEDIATE	060	3-35	ZF210373	SPRING,COMPRESSION	/040	3-47
ZF210335	HOUSING,INTERMEDIATE	060	3-37	ZF210373	SPRING,COMPRESSION	/190	3-51
ZF210336	PIN,SLOT	070	3-35	ZF210374	SPRING,COMPRESSION	042	3-49
ZF210336	PIN,SLOT	070	3-37	ZF210374	SPRING,COMPRESSION	/042	3-47
ZF210337	O. CLUTCH DISC	090	3-35	ZF210375	SPRING,COMPRESSION	044	3-49
ZF210338	O. CLUTCH DISC,2.5	100	3-35	ZF210375	SPRING,COMPRESSION	046	3-49
ZF210338	O. CLUTCH DISC,2.5	100	3-37	ZF210375	SPRING,COMPRESSION	/044	3-47
ZF210338	O. CLUTCH DISC,2.5	120	3-35	ZF210375	SPRING,COMPRESSION	/045	3-47
ZF210338	O. CLUTCH DISC,2.5	120	3-37	ZF210376	PISTON	060	3-49
ZF210339	I. CLUTCH DISC	110	3-35	ZF210376	PISTON	220	3-53
ZF210339	I. CLUTCH DISC	110	3-37	ZF210376	PISTON	230	3-53
ZF210340	O. CLUTCH DISC,2.0	120	3-35	ZF210376	PISTON	/060	3-47
ZF210340	O. CLUTCH DISC,2.0	120	3-37	ZF210376	PISTON	/220	3-51
ZF210341	GEAR,RING	130	3-35	ZF210376	PISTON	/230	3-51
ZF210341	GEAR,RING	130	3-37	ZF210377	GASKET	070	3-49
ZF210342	PIN	140	3-35	ZF210377	GASKET	234	3-53
ZF210342	PIN	140	3-37	ZF210377	GASKET	/070	3-47
ZF210343	SPRING,COMPRESSION	150	3-35	ZF210377	GASKET	/234	3-51
ZF210343	SPRING,COMPRESSION	150	3-37	ZF210378	PLATE,COVER	080	3-49
ZF210344	PIN,GUIDE	160	3-35	ZF210378	PLATE,COVER	240	3-53
ZF210344	PIN,GUIDE	160	3-37	ZF210378	PLATE,COVER	/080	3-47
ZF210347	RING,THRUST	190	3-39	ZF210378	PLATE,COVER	/240	3-51
ZF210348	PLANETARY DRIVE	200	3-39	ZF210380	BALL	130	3-49
ZF210349	PLANET CARRIER	/110	3-39	ZF210380	BALL	280	3-53
ZF210350	PIN,BEARING	/120	3-39	ZF210380	BALL	/130	3-47
ZF210351	CAGE,ROLLER	/130	3-39	ZF210380	BALL	/280	3-51
ZF210352	PLANET GEAR SET	/140	3-39	ZF210381	BUSH	140	3-49
ZF210353	WASHER,THRUST,1.0	/150	3-39	ZF210381	BUSH	/140	3-47
ZF210355	PIN,BEARING	/210	3-39	ZF210382	PIN	160	3-49
ZF210356	CASE,NEEDLE	/220	3-39	ZF210382	PIN	330	3-53
ZF210357	PLANET GEAR SET	/230	3-39	ZF210382	PIN	340	3-53
ZF210358	SCREW,TORX	070	3-43	ZF210382	PIN	/160	3-47
ZF210358	WASHER,THRUST	/240	3-39	ZF210382	PIN	/330	3-51
ZF210359	BEARING,TAPPER ROLLER	220	3-39	ZF210382	PIN	/340	3-51
ZF210360	BUSH,45.00	230	3-39	ZF210383	PISTON	180	3-49
ZF210361	TRANSMITTER,INDUCTION	380	3-39	ZF210383	PISTON	390	3-53
ZF210361	TRANSMITTER,INDUCTION	640	3-43	ZF210383	PISTON	400	3-53
ZF210362	SCREW,TORX	380	3-41	ZF210383	PISTON	/180	3-47
ZF210362	SCREW,TORX	650	3-45	ZF210383	PISTON	/390	3-51
ZF210363	CABLE CONNECT	400	3-41	ZF210383	PISTON	/400	3-51
ZF210364	COVER	410	3-41	ZF210384	GASKET	220	3-49
ZF210365	PLATE,DUCT	010	3-43	ZF210384	GASKET	464	3-53
ZF210366	VALVE,DRAIN	020	3-43	ZF210384	GASKET	/220	3-47
ZF210367	SHEET,SPRING	022	3-43	ZF210384	GASKET	/464	3-51
ZF210368	SCREW,TORX	024	3-43	ZF210385	PLATE,COVER	230	3-49
ZF210368	SCREW,TORX	090	3-49	ZF210385	PLATE,COVER	470	3-53
ZF210368	SCREW,TORX	250	3-53	ZF210385	PLATE,COVER	/230	3-47
ZF210368	SCREW,TORX	290	3-49	ZF210385	PLATE,COVER	/470	3-51
ZF210368	SCREW,TORX	510	3-53	ZF210386	PISTON	240	3-49

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #	PART #	ITEM DESCRIPTION	ITEM	PG #
ZF210386	PISTON	**430**	3-53	ZF210422	GASKET	**510**	3-61
ZF210386	PISTON	**440**	3-53	ZF210423	SUCTION TUBE	**570**	3-61
ZF210386	PISTON	**/240**	3-47	ZF210424	KIT,SUCTION FILTER		8-3
ZF210386	PISTON	**/430**	3-51	ZF210424	KIT,SUCTION FILTER		8-5
ZF210386	PISTON	**/440**	3-51	ZF210424	KIT,SUCTION FILTER		8-5
ZF210387	SPRING,COMPRESSION	**250**	3-49	ZF210424	SCREEN,SUCTION	**580**	3-61
ZF210387	SPRING,COMPRESSION	**450**	3-53	ZF210425	COVER	**600**	3-61
ZF210387	SPRING,COMPRESSION	**460**	3-53	ZF210430	CUP,SPRING	**/152**	3-63
ZF210387	SPRING,COMPRESSION	**/250**	3-47	ZF210430	CUP,SPRING	**/152**	3-65
ZF210387	SPRING,COMPRESSION	**/450**	3-51	ZF210435	RING,PISTON	**/230**	3-63
ZF210387	SPRING,COMPRESSION	**/460**	3-51	ZF210435	RING,PISTON	**/230**	3-65
ZF210388	SCREW,TORX	**150**	3-43	ZF210437	HOUSING,DISC	**/290**	3-63
ZF210388	SCREW,TORX	**280**	3-49	ZF210437	HOUSING,DISC	**/290**	3-65
ZF210388	SCREW,TORX	**290**	3-43	ZF210438	CAGE,NEEDLE	**/280**	3-63
ZF210388	SCREW,TORX	**490**	3-53	ZF210438	CAGE,NEEDLE	**/280**	3-65
ZF210388	SCREW,TORX	**/280**	3-47	ZF210441	STATOR	**/060**	3-63
ZF210388	SCREW,TORX	**/490**	3-51	ZF210441	STATOR	**/060**	3-65
ZF210390	SCREW,TORX	**/190**	3-55	ZF210442	RING,FREE WHEEL	**/080**	3-63
ZF210391	PLATE,COVER	**060**	3-43	ZF210442	RING,FREE WHEEL	**/080**	3-65
ZF210392	BALL,5MM	**100**	3-43	ZF210443	ROLLER	**/120**	3-63
ZF210393	GASKET	**110**	3-43	ZF210443	ROLLER	**/120**	3-65
ZF210395	STOP	**150**	3-53	ZF210444	BEARING,ROLLER	**/050**	3-63
ZF210395	STOP	**/150**	3-51	ZF210444	BEARING,ROLLER	**/050**	3-65
ZF210396	SPRING,COMPRESSION	**160**	3-53	ZF210445	PUMP,WHEEL	**/130**	3-63
ZF210396	SPRING,COMPRESSION	**170**	3-53	ZF210445	PUMP,WHEEL	**/130**	3-65
ZF210396	SPRING,COMPRESSION	**180**	3-53	ZF210446	PIN,CYLINDERICAL	**/142**	3-63
ZF210396	SPRING,COMPRESSION	**/160**	3-51	ZF210446	PIN,CYLINDERICAL	**/142**	3-65
ZF210396	SPRING,COMPRESSION	**/170**	3-51	ZF210447	HOUSING	**010**	3-67
ZF210396	SPRING,COMPRESSION	**/180**	3-51	ZF210447	HOUSING	**010**	3-69
ZF210397	BUSH	**290**	3-53	ZF210448	PIN,CYLINDRICAL	**012**	3-67
ZF210397	BUSH	**300**	3-53	ZF210448	PIN,CYLINDRICAL	**012**	3-69
ZF210397	BUSH	**/290**	3-51	ZF210449	BEARING,ROLLER,50X90X23	**200**	3-67
ZF210397	BUSH	**/300**	3-51	ZF210449	BEARING,ROLLER,50X90X23	**200**	3-69
ZF210398	PLATE,COVER	**130**	3-43	ZF210450	COVER,SHEET	**210**	3-67
ZF210399	SCREW,TORX	**160**	3-43	ZF210450	COVER,SHEET	**210**	3-69
ZF210399	SCREW,TORX	**290**	3-43	ZF210451	GEAR	**220**	3-67
ZF210399	SCREW,TORX	**810**	3-45	ZF210451	GEAR	**220**	3-69
ZF210400	GASKET	**180**	3-43	ZF210452	BEARING,BALL	**230**	3-67
ZF210401	VALVE,THROTTLE	**240**	3-43	ZF210452	BEARING,BALL	**230**	3-69
ZF210401	VALVE BLOCK	**240**	3-55	ZF210453	RING,SNAP	**604**	3-69
ZF210402	VALVE BLOCK	**/110**	3-55	ZF210454	BUSH	**610**	3-69
ZF210403	PISTON	**/120**	3-55	ZF210455	FLANGE,INTERMEDIATE	**630**	3-69
ZF210404	PISTON	**/130**	3-55	ZF210457	PLATE,TYPE	**800**	3-67
ZF210406	PLATE,FIXING	**/160**	3-55	ZF210457	PLATE,TYPE	**800**	3-69
ZF210407	SOLENOID	**/180**	3-55	ZF210458	GASKET	**010**	3-71
ZF210408	WIRING HARNESS	**310**	3-43	ZF210459	INSERT	**014**	3-71
ZF210409	VALVE,CONVERTER	**340**	3-43	ZF210460	INSERT	**016**	3-71
ZF210410	RING,SNAP	**344**	3-43	ZF210462	SENSOR,TEMPERATURE	**124**	3-71
ZF210411	MAGNET	**590**	3-43	ZF210463	UNION,PIPE	**150**	3-71
ZF210412	SCREW,TORX	**340**	3-11	ZF210464	GEAR,RING	**/180**	3-25
ZF210412	SCREW,TORX	**340**	3-17	ZF210465	FLANGE,BEARING	**540**	3-67
ZF210412	SCREW,TORX	**610**	3-43	ZF210465	FLANGE,BEARING	**540**	3-69
ZF210412	SCREW,TORX	**630**	3-43	ZF210466	FLANGE,BEARING	**336**	3-129
ZF210413	SCREW,TORX	**620**	3-43	ZF210466	FLANGE,BEARING	**336**	3-151
ZF210414	VALVE BLOCK	**800**	3-45	ZF210467	HOUSING,REDUCTION GEAR	**372**	3-129
ZF210414	VALVE BLOCK	**/220**	3-55	ZF210467	HOUSING,REDUCTION GEAR	**372**	3-151
ZF210415	HOUSING,VALVE	**/110**	3-55	ZF210469	CAP,DUST	**430**	3-129
ZF210416	PISTON	**/120**	3-55	ZF210469	CAP,DUST	**430**	3-151
ZF210417	TUBE,FILLER	**010**	3-57	ZF210470	SHAFT,FLANGE	**450**	3-129
ZF210417	TUBE,FILLER	**010**	3-59	ZF210470	SHAFT,FLANGE	**450**	3-151
ZF210418	TAPE,SEALING	**014**	3-57	ZF210535	INSERT,MOUNTING	**600**	3-7
ZF210418	TAPE,SEALING	**014**	3-59	ZF210535	INSERT,MOUNTING	**600**	3-9

https://truckmanualshub.com/

PART #	ITEM DESCRIPTION	ITEM	PG #
ZF210557	HOUSING,CLUTCH	**490**	3-27
ZF210558	ADAPTOR CONNECTOR	**020**	3-71
ZF210559	PLUG,SCREW	**114**	3-71
ZF210568	SENSOR,TEMP	**/200**	3-43
ZF210575	INSERT,CONTROL	**010**	3-11
ZF210575	INSERT,CONTROL	**010**	3-17
ZF210576	SPRING,COMPRESSION	**070**	3-11
ZF210576	SPRING,COMPRESSION	**070**	3-17
ZF210577	PISTON	**080**	3-11
ZF210577	PISTON	**080**	3-17
ZF210578	PISTON	**090**	3-11
ZF210578	PISTON	**090**	3-17
ZF210579	BUSH	**110**	3-11
ZF210579	BUSH	**110**	3-17
ZF210580	FLANGE,OIL FEED	**310**	3-11
ZF210580	FLANGE,OIL FEED	**310**	3-17
ZF210581	PUMP,PRIMARY	**320**	3-11
ZF210583	SHAFT,STSTOR	**710**	3-13
ZF210583	SHAFT,STSTOR	**710**	3-19
ZF210584	AXLE	**800**	3-15
ZF210584	AXLE	**800**	3-21
ZF210586	ROTOR	**110**	3-23
ZF210587	HUB	**040**	3-27
ZF210588	CARRIER,CLUTCH	**070**	3-27
ZF210589	PISTON	**100**	3-27
ZF210590	PISTON	**230**	3-27
ZF210591	SHIM,END	**300**	3-27
ZF210592	PISTON	**450**	3-27
ZF210593	RING,PRESSURE	**100**	3-31
ZF210594	SLEEVE	**084**	3-33
ZF210595	COVER,OUTPUT	**010**	3-39
ZF210596	PISTON	**030**	3-39
ZF210598	VALVE BLOCK	**1**	3-49
ZF210598	VALVE BLOCK	**058**	3-43
ZF210598	VALVE BLOCK	**058**	3-47
ZF210599	VALVE BLOCK	**010**	3-49
ZF210599	VALVE BLOCK	**/010**	3-47
ZF210600	STRIP,VALVE	**/110**	3-47
ZF210601	VALVE,SOLENOID	**310**	3-49
ZF210601	VALVE,SOLENOID	**520**	3-53
ZF210601	VALVE,SOLENOID	**540**	3-53
ZF210601	VALVE,SOLENOID	**/200**	3-55
ZF210601	VALVE,SOLENOID	**/310**	3-47
ZF210601	VALVE,SOLENOID	**/520**	3-51
ZF210601	VALVE,SOLENOID	**/540**	3-51
ZF210602	VALVE BLOCK	**1**	3-53
ZF210602	VALVE BLOCK	**128**	3-43
ZF210602	VALVE BLOCK	**128**	3-51
ZF210603	VALVE BLOCK	**110**	3-53
ZF210603	VALVE BLOCK	**/110**	3-51
ZF210604	VALVE STRIP	**/260**	3-51
ZF210605	SPRING,COMPRESSION	**/130**	3-55
ZF210605	SPRING,COMPRESSION	**/140**	3-55
ZF210606	DIPSTICK,OIL	**200**	3-57
ZF210607	OIL SUMP	**500**	3-61
ZF210608	CONVERTER,TORQUE	**500**	3-63
ZF210609	TURBINE WHEEL	**/010**	3-63
ZF210609	TURBINE WHEEL	**/010**	3-65
ZF210610	COVER,CIRCUIT	**/140**	3-63
ZF210610	COVER,CIRCUIT	**/140**	3-65
ZF210611	PLATE,PISTON	**/150**	3-63
ZF210611	PLATE,PISTON	**/150**	3-65
ZF210612	PIN,CYLINDERICAL	**/174**	3-63
ZF210612	PIN,CYLINDERICAL	**/174**	3-65
ZF210613	SHIM,END	**/180**	3-63
ZF210613	SHIM,END	**/180**	3-65
ZF210614	WASHER	**/270**	3-63
ZF210614	WASHER	**/270**	3-65
ZF210615	HOUSING,TRANSMISSION	**010**	3-7
ZF210615	HOUSING,TRANSMISSION	**010**	3-9
ZF210616	PLATE,COVER	**500**	3-15
ZF210616	PLATE,COVER	**500**	3-21
ZF210617	PIPE	**750**	3-15
ZF210617	PIPE	**750**	3-21
ZF210623	PUMP,PRIMARY	**320**	3-17
ZF210624	RING,INTERMEDIATE	**350**	3-17
ZF210625	RING,THRUST	**360**	3-17
ZF210626	O. CLUTCH DISC	**090**	3-37
ZF210627	STRIP,VALVE	**110**	3-49
ZF210627	VALVE STRIP	**260**	3-53
ZF210628	CONVERTER,TORQUE	**500**	3-65
ZF210629	DIPSTICK,OIL	**200**	3-59