https://truckmanualshub.com/

SCANIA

Spare parts for trucks

Qualität – made by dph Germany

dph®

Dichtungspartner Hamburg

https://truckmanualshub.com/

Important notes

1. This catalogue replaces all previous issues.
2. The catalogue is protected by copyright.
   The duplication of it or any part of it is prohibited.
3. The supply of dph components strictly adhere to our sales and delivery agreement and are subject to our conditions of payment.
4. We reserve the right to modify our components as necessary.
5. The original equipment part numbers, as well as SLP, Elring-No., etc. indicated in the catalogue only serve as a cross-reference comparison with dph numbers. They must not appear on any advice notes or invoices.
6. All original part numbers of engine or vehicle manufacturers in this catalogue are mentioned for comparison reasons only and should not be used in contacts with vehicle owners.
7. Every effort has been made to ensure that the information in this catalogue is correct at the time of printing, but dph cannot accept any responsibility for errors which may occur.

Dichtungspartner Hamburg GmbH
Ferdinand-Harten-Straße 15
D-22949 Ammersbek
Germany

P.O. Box 651144
D-22371 Hamburg
Germany

Phone ++49 (0)40-66 86 13-0
Fax ++49 (0)40-66 86 13-90
E-mail service@dph.de
www.dph.de

https://truckmanualshub.com/

Qualität – made by dph Germany

Dichtungspartner Hamburg

https://truckmanualshub.com/

High quality guarantees growing success



We have always supplied our customers with high quality seals for the following sectors: Automobile, hydraulic seals, mountings and other fields all at reasonable prices and quick delivery. We can count many well-known companies throughout the world as satisfied customers.

Four strategies guarantee our success:

- ➔ First rate products with top class quality assured
- ➔ Short delivery times due to our own stock levels
- ➔ Flexibility in the procurement of all parts
- ➔ Attractive pricing policy

Fully automated electronic quality checks and manufacturing to DIN standards guarantee continuous high quality products. To your advantage and always at very fair prices.

Perfect manufacturing and continuous quality assurance

Together we are strong – this is the maxim in our group. High quality is not achieved just as a result of monitoring but of production technique. Therefore, Dichtungspartner Hamburg receives the bulk of its products from OEM suppliers and from suppliers whose quality management is certified in accordance with DIN/ISO 9000/9001.

Despite this, we still think it is necessary to check the finished products thoroughly once more within our group according to DIN/ISO 9001. Our high-grade measuring instruments are checking the radial force of oil seals, the tensile strength of elastomers, the compression set and the surface quality by means of computer-based cameras and many more. The results of the checks are registered and filed. It is good to have confidence but qualification is better!

https://truckmanualshub.com/

Contents

OEM numbers, reference list ..... **6 – 13**

Engine gaskets and gasket sets ..... **14 – 24**

Cylinder head gaskets & sets, cylinder liner sealing rings & kits, complete gasket sets, valve cover gaskets, oil pan gaskets & kits, manifold gaskets, gaskets flywheel, full sets

Engine parts, fuel, exhaust and cooling system parts ..... **25 – 44**

Oil seals, washers, o-rings/seal rings, gaskets, repair kits compressor (engine) oil seals for hubs & wheels, oil seals crankshaft, cylinder liner shims

Rubber cushions for engine, exhaust systems and gearbox ..... **45 – 46**

Oil seals, gaskets

Clutch, gearbox ..... **47 – 48**

Servo cylinders, repair kits, o-rings, oil seals

Brake parts ..... **49 – 56**

Oil seals, valve lifter, valve guide, valves, repair kits, diaphragms

Front and rear axle parts, steering ..... **57 – 60**

Oil seals, gaskets

Front and rear suspension parts ..... **61 – 62**

Bushings, o-rings

Hose **63**

Overview of most popular oil seal types **64**

Standard terms and conditions ..... **65 – 66**

https://truckmanualshub.com/

OEM numbers, reference list

OEM-no.		dph-no.	description	page
_		50826	Cylinder liner sealing ring kit	16
_		95842	Cylinder liner sealing ring kit	17
1 100 645		109531	Oil seal brake part	55
1 101 276		70432	Gasket flywheel/gear housing	23
1 103 236		82835	Repair kit/compressor (engine)	41
1 103 422	replaced by 1 116 635		Valve lifter	50
1 107 097		80236	O-ring/seal ring – engine	31
1 107 098		80411	O-ring/seal ring – engine	31
1 108 223		81677	Repair kit/compressor (engine)	41
1 108 228	(300 162)	81715	Repair kit	41
1 109 288		70434	Manifold gasket	22
1 109 869		82871	Oil seal – engine	25
1 109 870	replaced by 310 951		Oil seal – engine	25
1 114 036		33008	Cylinder liner shim	43
1 116 635	(1 103 422, 131 105)	51307	Valve lifter	50
1 301 628		70435	Manifold gasket	22
1 301 629		70436	Manifold gasket	22
1 302 243		80404	O-ring/seal ring – engine	32
1 302 556		97850	Gasket	34
1 302 827		36768	Gasket	34
1 302 828	(170 951)	36769	Cylinder liner sealing ring	17
1 303 673	replaced by 1 363 673		Oil seals front and rear axle, steering	59
1 303 789		98260	O-ring/seal ring – engine	32
1 304 293		104348	Gasket seal – engine	37
1 305 139		97851	Gasket	46
1 305 341		70437	Gasket for steering	57
1 305 595		84528	Gasket	34
1 305 596		84529	Gasket seal – engine	36
1 305 597		84530	Gasket seal – engine	37
1 305 673		97849	Gasket seal – engine	37
1 305 959	(170 610)	94530	Valve cover gasket	18
1 307 340	replaced by 1 338 018		Brake part/front-/rear wheel brake	50
1 312 934		111269	Cylinder liner sealing ring kit	16
1 312 934	(323 641, 177 587)	4212	Cylinder liner sealing ring	17
1 313 459		70438	Cylinder head gasket	14
1 315 437		98261	O-ring/seal ring – engine	32
1 318 388		96716	Oil seal	45
1 319 081		98679	Valve intake	51
1 320 298		70442	Gasket	46
1 327 886		82836	Repair kit	41
1 329 585		97852	Gasket	46
1 331 770	(371 612)	81803	Clutch servo cylinder	47
1 334 294		97290	O-ring/seal ring – engine	32
1 334 535		93430	Oil seal front and rear axle, steering	60
1 335 243		84730	Oil seal front and rear axle, steering	60
1 336 159	(550 455/6)	51926	Repair kit clutch servo	47
1 338 018	(1 307 340)	104111	Brake part/front-/rear wheel brake	50
1 338 019	(391 962)	69230	Brake part front-/rear wheel brake	49
1 342 363		93428	Oil seal front and rear axle, steering	60
1 343 372		109530	Oil seal brake part	55
1 345 278		95457	Oil seal – engine	26
1 345 279		96311	Oil seal	55
1 349 018		98264	O-ring/seal ring – engine	32
1 349 089		95458	Oil seal – engine	26
1 350 378		70443	Gasket	35

https://truckmanualshub.com/

OEM-no.		dph-no.	description	page
1 350 379		70444	Gasket	35
1 350 380		70445	Gasket	35
1 360 833	(366 256)		Valve exhaust	52
1 360 834	(352 347)		Valve exhaust	52
1 360 836		110771	Valve intake	51
1 361 189	(272 803)		Valve intake	51
1 361 190		110773	Valve intake	51
1 361 195		110772	Valve exhaust	52
1 361 197	(243 477)		Valve exhaust	52
1 363 673	(1 303 673)	96111	Oil seals front and rear axle, steering	59
1 363 674	(1 309 342)	82497	Oil seal front and rear axle, steering	60
1 367 027		104470	Valve cover gasket	19
1 367 028		104471	Valve cover gasket	19
1 374 326		111443	Gasket seal – engine	37
1 374 327		111445	Gasket seal – engine	38
1 374 334		111442	Gasket seal – engine	38
1 374 338			Manifold gasket	23
1 374 340			Manifold gasket	23
1 374 344		111446	Gasket seal – engine	38
1 375 002		111452	Oil seal – crankshaft	40
1 375 383		111444	Gasket seal – engine	38
1 377 039			Cylinder head gasket	14
1 380 834		93808	O-ring/seal ring – engine	33
1 383 129		95649	Oil seal differential bevel pinion	60
1 384 004			Gasket seal – engine	38
1 384 552			Manifold gasket	22
1 386 594		98061	Oil seal differential bevel pinion	60
1 388 678		95969	Gasket seal – engine	38
1 388 683			Gaskets flywheel/gear housing	24
1 392 936	(371 500)	96313	Gasket	46
1 393 331		98060	Oil seals front and rear axle, steering	59
1 395 999		109529	Oil seal brake part	55
1 398 810			O-ring kit – engine	33
1 401 982			Valve cover gasket	20
1 401 984		110342	Valve cover gasket	19
1 403 129		111440	Gasket seal – engine	38
1 403 258			Cylinder head gasket	14
1 403 260			Cylinder head gasket	14
1 403 587			Cylinder head gasket	14
1 404 306			Manifold gasket	23
1 409 889		112266	Oil seal brake part	55
1 409 890		112282	Oil seal brake part	55
1 411 851		109728	Valve cover gasket	20
1 412 666			oil pan gasket	20
1 414 422		109729	Valve cover gasket	20
1 422 564		111565	O-ring kit – engine	33
1 423 290		111441	Gasket seal – engine	38
1 433 183		111453	Oil seal – crankshaft	40
1 444 941	(1 403 260, 1 377 039)	104473	Cylinder head gasket	14
1 459 004			Oil pan gasket	20
1 460 359		111447	Oil pan gasket	20
1 476 506		109730	Valve cover gasket	20
1 502 384		111330	Oil seal brake part	56
1 502 384		111330	Oil seal differential bevel pinion	60
1 516 145			Manifold gasket	23

https://truckmanualshub.com/

OEM-no.		dph-no.	description	page
1 516 474		111568	Manifold gasket	23
1 541 633			Gasket seal – engine	38
1 675 602		111231	Gasket seal – engine	38
120 310		61641	Oil seal for hubs and wheels	40
120 828		68810	Brake part front-/rear wheel brake	49
120 979	(227 138, 304 552)	70446	Oil seals front and rear axle, steering	59
121 257		70447	Oil seal for hubs and wheels	39
123 102		69284	Brake part front-/rear wheel brake	49
124 268	(388 728)	34426	Oil seals front and rear axle, steering	59
125 766		110713	Oil seals front and rear axle, steering	59
127mm		94742	Cylinder liner sealing ring kit	16
130 934-2			Oil seal front and rear axle, steering	60
131 039			Valve cover gasket	18
131 571			Valve cover gasket	19
132 672		82323	Oil seal – engine	25
135 036		70172	Shackle bushing	61
135 698		70448	Shackle bushing	61
136 083-6	(294 674)		Valve intake	51
136 106		70449	Oil seals front and rear axle, steering	59
136 119-5	(168 843)		Valve exhaust	52
137 207	(332 738)	82302	Rubber bushing	62
139 023		70450	Oil seal – engine	26
14 107		70451	Oil seal – engine	26
141 964		82837	Repair kit	42
143 112		69219	Diaphragm/Brake part	54
143 113		69220	Diaphragm/Brake part	54
143 118		69223	Diaphragm/Brake part	54
144 116		70452	Oil seals front and rear axle, steering	59
151 476		69218	Diaphragm/Brake part	54
159 496		34422	Oil seal for hubs and wheels	39
160 342		69217	Diaphragm/Brake part	54
165 507		70454	Washer – engine	29
168 843	(136 119-5)	93996	Valve exhaust	52
17 115		93997	Valve seal ring	52
17 543		93998	Valve seal ring	53
170 205		32990	Seal ring/cooling system	44
170 226		70455	Oil seal – engine	26
170 424		21255	O-ring/fuel system	44
170 610	replaced by 1 305 959	32906	Valve cover gasket	18
170 700-9	replaced by 371 505, 1 459 004		Oil pan gasket	20
170 761		70457	Oil seal – engine	25
171 566		69215	Diaphragm/Brake part	54
173 320		34423	Oil seal for hubs and wheels	39
174 229		32999	O-ring/seal ring – engine	32
177 587	(1 312 934, 323 641)	110487	Cylinder liner sealing ring	17
178 562		70460	Washer – engine	27
178 866		70461	Oil seals front and rear axle, steering	58
182 524		70463	Washer – engine	27
182 929		61342	O-ring for shackle pins	61
182 930		3889	Brake part front-/rear wheel brake	49
182 931		61343	O-ring for shackle pins	61
182 935		94398	O-ring/front axle	57
192 081		70464	Washer – engine	27
192 600		70465	Oil seal – engine	26
192 633		70466	Washer – engine	27

https://truckmanualshub.com/

OEM-no.		dph-no.	description	page
192 651		70467	Washer – engine	27
192 820-9		70468	Washer – engine	27
192 871		98658	O-ring/fuel system	43
194 414		96197	O-ring/gearbox control	48
202 288		81457	Oil seal – engine	26
203 670		69213	Diaphragm/Brake part	54
204 466		70469	Washer – engine	27
204 750		95869	Gasket bogie axle	57
209 261		70470	Washer – engine	28
209 770		70471	Washer – engine	28
210 648		95850	Oil seal – engine	26
211 077		70472	Washer – engine	28
211 337	(216 608)	70473	Oil seals front and rear axle, steering	59
211 813		93836	O-ring/seal ring – engine	33
214 008		34425	Brake part front-/rear wheel brake	49
215 242-9	(371 503)	80016	Oil pan gasket	20
215 715		93995	Valve intake	51
216 608	replaced by 211 337		Oil seals front and rear axle, steering	59
227 138	(304 552, 120 979)		Oil seals front and rear axle, steering	59
229 373		81725	Repair kit	42
230 297		34434	Gasket seal – engine	37
231 938		34428	Oil seals front and rear axle, steering	59
232 018		61145	Valve exhaust	52
241 805		81973	Hose	63
242 672		61151	Valve seal ring	53
242 857		93837	O-ring/fuel system	43
243 477	(1 361 197)	98682	Valve exhaust	52
244 446		32996	O-ring/gearbox control	48
244 448		95851	Seal ring/wiper ring for gearbox	62
252 496		98656	O-ring/fuel system	43
254 635		70475	Oil seal	45
257 737		84526	O-ring/seal ring – engine	33
258 458		70476	Valve cover gasket	19
258 459-7		61109	Valve cover gasket	18
270 247		93994	Valve intake	50
272 803	(1 361 189)	98681	Valve intake	51
272 804		61144	Valve intake	50
276 587		81970	O-ring/seal ring – engine	32
277 272	(385 997)		Manifold gasket	22
277 273		70479	Manifold gasket	22
278 198		81716	Repair kit/compressor (engine)	41
280 759		84543	Oil seal – engine	26
282 501		81714	Repair kit	42
282 799		81717	Repair kit	42
289 517		61149	Valve seal ring	53
290 534	(372 984)	34620	O-ring/seal ring – engine	30
291 076		34427	Oil seal front and rear axle, steering	60
291 159			Cylinder head gasket	14
291 826		70315	Seal ring/cooling system	44
293 546		82816	Repair kit	43
294 275		84541	Oil seal	45
294 674	(136 083-6)	98678	Valve intake	51
297 991		70481	Oil seals front and rear axle, steering	58
297 999		61643	Oil seals front and rear axle, steering	59
298 021	(392 309)		O-ring/hubs and wheels	41

https://truckmanualshub.com/

OEM-no.		dph-no.	description	page
300 162	(1 108 228)	82817	Repair kit	41
300 278		61645	Oil seal for hubs and wheels	39
300 957		61147	Valve guide	50
300 958		61148	Valve guide	50
303 098		70482	Washer – engine	27
304 552	(227138, 120979)		Oil seals front and rear axle, steering	59
309 113		98517	Oil seal for hubs and wheels	39
309 164-2		70814	Repair kit	42
309 164		82818	Repair kit air dryer drain valve	55
310 951	(1 109 870)	84537	Oil seal – engine	25
313 004		81718	Repair kit	42
313 114		82819	Repair kit/brake valve	53
314 063-9	(388 528)	70483	Oil seal/gearbox	48
315 022		81458	Seal ring/wiper ring for gearbox	62
315 270		95868	Gasket seal – engine	36
317 916		95647	Gasket seal – engine	36
318 415			Manifold gasket	22
319 475		81682	Repair kit/brake valve	53
319 477		81719	Repair kit	43
32 201		70484	Oil seal	45
32 898		70485	Oil seals front and rear axle, steering	58
321 991		80746	O-ring/seal ring – engine	33
321 992		97479	O-ring/seal ring – engine	32
323 451		69231	O-ring/seal ring – engine	30
323 641	(1 312 934, 177 587)	32970	Cylinder liner sealing ring	17
323 661			Cylinder liner sealing ring	17
323 662	(323 661)	32971	Cylinder liner sealing ring	17
329 583		81975	Vibration insulator (motor hood)	62
329 638		81460	Oil seal	45
33 326		70486	Oil seal brake part	56
33 352		3888	Oil seals front and rear axle, steering	58
330 323		70487	Washer – engine	28
332 448		84527	Gasket seal – engine	37
332 738			Rubber bushing	62
338 643		34421	Oil seals front and rear axle, steering	58
340 895		81971	Rubber bushing	62
342 989		36090	Cylinder liner sealing ring	17
344 426		22995	Valve cover gasket	19
345 362	(550 720)	81422	Clutch servo cylinder	47
346 143		69286	Cylinder head gasket	14
346 216			Cylinder head gasket	14
347 468		109532	Oil seal brake part	56
348 339		4147	Gasket seal – engine	37
349 353		80747	O-ring/seal ring – engine	33
35 528		70488	Washer – engine	28
352 347	(1 360 834)	98683	Valve exhaust	52
353 173		98692	Washer – engine	28
357 363		68531	Manifold gasket	23
360 717		81524	Clutch servo cylinder	47
361 523		80408	O-ring/seal ring – engine	33
361 526		80406	O-ring/seal ring – engine	33
362 128		34432	O-ring/seal ring – engine	33
362 129		94386	O-ring/seal ring – engine	33
364 791		70503	Manifold gasket	21
364 792		70490	Manifold gasket	21

https://truckmanualshub.com/

OEM-no.		dph-no.	description	page
365 375		70491	Washer – engine	28
366 256	(1 360 833)	98680	Valve exhaust	52
366 303		69285	Oil seals front and rear axle, steering	58
366 539		70494	Oil pan gasket	20
366 546		70495	Gasket	46
366 547		70496	Manifold gasket	22
366 557		70501	Gasket	35
369 229		70502	Gasket seal – engine	35
369 276		70503	Manifold gasket	21
369 477		111285	Oil seal – crankshaft	40
369 478		111272	Oil seal – crankshaft	40
370 074		61647	Oil seals front and rear axle, steering	59
370 075		50176	Oil seal for hubs and wheels	40
370 076	(291 463)	50177	Oil seal for hubs and wheels	39
370 076		111548	Oil seal rear axle	60
371 483		70504	Valve cover gasket	19
371 486		70505	Gaskets flywheel/gear housing	24
371 487		70506	Gasket flywheel/gear housing	23
371 490		70507	Gasket	35
371 491		70508	Gasket	34
371 492		70314	Gasket seal – engine	36
371 493		70509	Gasket seal – engine	36
371 495		70510	Gasket for steering	57
371 498		70514	Gasket	46
371 499		70515	Manifold gasket	23
371 500	replaced by 1 392 936		Gasket	46
371 502		70518	Gasket seal – engine	36
371 503	(215 242-9)	68593	Oil pan gasket	20
371 505	(170 700-9, 1 459 004)	68592	Oil pan gasket	20
371 507		68532	Gasket seal – engine	36
371 510		70519	Manifold gasket	21
371 612	(1 331 770)	81525	Clutch servo cylinder	47
372 472	(373 472, 346 143)	93725	Cylinder head gasket	14
372 984	(290 534)	3890	O-ring/seal ring – engine	30
372 985		3891	O-ring/seal ring – engine	30
373 472	(372 472, 346 143)	69228	Cylinder head gasket	14
375 086		61649	Oil seal for hubs and wheels	40
375 087		61651	Oil seal for hubs and wheels	39
378 264		70521	Manifold gasket	23
378 299	(344 426)	80777	Valve cover gasket	19
378 480		95648	Oil seal – engine	25
381 083		80590	O-ring/seal ring – engine	30
381 962	replaced by 1 338 019		Brake part front-/rear wheel brake	49
382 361-4		69816	Gasket for oil filter	55
383 917		4143	O-ring/seal ring – engine	30
384 464		68533	Gasket	34
385 022		70524	Gasket flywheel/gear housing	23
385 997	(277 272)	97659	Manifold gasket	22
385 998		95844	Manifold gasket	22
386 901		70525	Oil seal	45
386 967		70527	Oil seals front and rear axle, steering	58
387 503		36494	Cylinder head gasket	14
388 422		70529	Gasket	34
388 528	(314 063-9)	81462	Oil seal/gearbox	48
388 728	(124 268)		Oil seals front and rear axle, steering	59

https://truckmanualshub.com/

OEM-no.		dph-no.	description	page
391 766		80215	Gasket	34
392 088		98026	O-ring/seal ring – engine	30
392 309	(298 021)	80851	O-ring/hubs and wheels	41
392 652		93835	O-ring/seal ring – engine	31
392 653		94357	O-ring/seal ring – engine	32
393 820		68534	Manifold gasket	22
550 422		81723	Repair kit clutch servo	47
550 453		81463	Repair kit clutch servo	47
550 455/6		81724	Repair kit clutch servo	47
550 469	(551 363)	111587	Cylinder head gasket set	15
550 720	(345 362)	81092	Clutch servo cylinder	47
551 350		104472	Cylinder head gasket set	15
551 356		111287	Full set	15
551 363		111284	Cylinder head gasket set	15
551 386		111286	Full set	15
551 430		97486	Gasket set complete engine overhaul incl. cylinder liner rings	18
551 446		96430	Oil pan gasket kit	21
551 449		95241	Gasket set complete engine overhaul incl. cylinder liner rings	18
551 451		82873	Oil pan gasket kit	21
551 459		95242	Gasket set complete engine overhaul incl. cylinder liner rings	18
551 466		97485	Oil pan gasket kit	21
551 469		82868	Cylinder head gasket set	15
551 470		82869	Gasket set complete engine overhaul incl. cylinder liner rings	18
551 484		95825	Cylinder head gasket set	14
551 512		82872	Cylinder head gasket set	15
551 513		95824	Cylinder head gasket set	15
551 516			Gasket set complete engine overhaul incl. cylinder liner rings	18
551 519		111410	Full set	15
551 519		111410	Gasket set complete engine overhaul incl. cylinder liner rings	18
551 570		111547	Full set	15
804 655		94385	O-ring/seal ring – engine	30
804 660		95693	O-ring/seal ring – engine	31
804 662		93838	O-ring/gearbox control	48
804 664		95695	O-ring/seal ring – engine	31
804 666		98262	O-ring/seal ring – engine	31
804 674		97292	O-ring/seal ring – engine	31
804 710		95991	O-ring/seal ring – engine	31
804 713		97291	O-ring/seal ring – engine	31
810 958		95694	O-ring/seal ring – engine	31
810 970		3892	Brake part front-/rear wheel brake	49
810 983		81720	O-ring/gearbox control	48
811 038		70532	O-ring/seal ring – engine	32
811 045		81721	O-ring/front axle	57
811 926		32997	O-ring/seal ring – engine	31
811 942		93594	O-ring/seal ring – engine	32
812 411		70533	Washer – engine	28
812 412		70534	Washer – engine	27
812 413		70535	Washer – engine	28
812 414		70536	Washer – engine	28
812 415		70537	Washer – engine	27
812 416		70316	Washer – engine	28
812 417		70538	Washer – engine	28
812 418		70539	Washer – engine	28
812 419		70540	Washer – engine	29
812 420		70317	Washer – engine	29

https://truckmanualshub.com/

OEM-no.	dph-no.	description	page
812 421	70541	Washer – engine	29
812 423	70543	Washer – engine	29
812 424	70544	Washer – engine	28
812 425	70545	Washer – engine	29
812 426	70546	Washer – engine	29
837 613	70547	Oil seal – engine	25
CLS662S	94523	Cylinder liner sealing ring kit	16
CLS827S	48191	Cylinder liner sealing ring kit	16
CLS828S	50827	Cylinder liner sealing ring kit	16
CLS934S	61340	Cylinder liner sealing ring kit	17
DS11/DSC11	98210	Cylinder liner sealing ring kit	17
DS14 8Zyl	95099	Cylinder liner sealing ring kit	17
DS9 6Zyl	95100	Cylinder liner sealing ring kit	16

https://truckmanualshub.com/

Engine gaskets and gasket sets

Cylinder head gasket

dph-no.	OEM-no.		application
36494	387 503 346 216 291 159 1 403 258		**DN9, DS9, DSC9** 6 cyl. from 1984 G, P82, F, G P, R,T92/93, K93
93725 **69228** **69286**	372 472/ 373 472/ 346 143		**D11, DS11** – 6 cyl. 1975.1979 L, LB, LS, LT, LBS, LBT111 **DN11** up to motor 5258563 from 1980, 6 cyl., G, B, R, T112 **DS11** up to motor 5307928SSS from 1980, 6 cyl., G, B, R, T112/113 **DSC11** up to motor 40701045N from 1980, G, B, R, T112/113
70438	1 313 459 1 403 587		**D14, DS14, DSC14** 8 cyl. up to 1979 L, LB, LS, LBS140/141, LBT141 LT146, B, CR145 from 1980 DS14, DSC14 R, T142/143
104473	1 444 941/ 1 403 260 1 377 039		**DSC12** application Scania 124 up to engine 6119599

Cylinder head gasket set

dph-no.	OEM-no.		application
95825	551 484		**DN9, DS9, DSC9** 6 cyl. Dia 115 1984- G82, P82, G92, P92, R92, T92, P92HK, F92 H, K92, G93, P93, P93HK, P93MK, R93, T93, T93HK, F93 H, K93

https://truckmanualshub.com/

Cylinder head gasket set

dph-no.	OEM-no.		application
95824	551 513		**D11, DS11** 1975-1979 6 cylinder L, LB, LS, LT, LS, LBT111 **DN11** from 1980 up to motor 5258563, G, P, R, T112 **DS11** 6 cylinder from 1980 up to motor 5307928SSS, G, P, R, T112 **DSC11** 6 cylinder from 1980 up to motor 40701045N, G, P, R, T112
82872	551 512		**DS11, DSC11** Mot. 5307929 SSS, Mot. 4070105 SN, 6 cyl. Dia 127 P113, P113 HK, R113, R113 HK, T113, K113 CLB, K113 CLP, K113, TLB, K113 TLP
82868	551 469		**DS14**, 8 cyl. Dia 127 1975 – 1979 L, LS, LB, LBS140, L, LS141, LB, LBS, LBT141, LT146 **D14,** CR, BR145 **DS14, DSC14**, 1980-, 8 cyl. Dia 127 R142 1981-1988, T142 1980-1988 R143 1988-, R143 HK1990-, T143 1988-
104472	551 350		**DSC12** application Scania 124 up to engine 6119599
111587 **111284**	550 469 551 363		**DC 11** **DC 12** **DSC 12** **DT 12**

Full set

dph-no.	OEM-no.		application
111287	551 356	**DC 11** up to engine 6119599 8004779	
111286	551 386	**DC 11** up to engine 6119599 8004779	
111410	551 519	**DS11, DSC11** up to engine 5307929 until year 12/1987	
111547	551 570		

https://truckmanualshub.com/

Cylinder liner sealing ring kit

dph-no.	OEM-no.		application
94523	CLS662S		**DS8, D8,** Contents: 3x 323 662 installation paste 6 cylinder dia. 115, 1975- L, LS, LB80, LBS85, LB80H, L, LB81, L, LS, LB LBS86 **DN8, DS8, DSI8** 6 cylinder dia. 115, G82, P82 1981-, T82 1980-
48191	CLS827S		**DN9, DS9, DSC9** Contents: 2 o-rings 323 662 1 sealing ring 1302827 installation paste
95100	DS9 6Zyl		**DS9, DN9, DSC9** Contents: 6x1 302 827 12x 323 662 6 cylinder dia. 115 1984- G82, P82, G92, P92, R92, T92, P92HK, F92H, K92, G93, P93, P93HK, P93MK, R93, T93, T93HK, F93H, K93
50827	CLS828S		**DN11, DS11, DSC11, DSI11, DTC11** Late version with 2 o-rings and 1 sealing ring **D14, DS14, DSC14, DS14** Contents: 2 o-rings 1312934 1 sealing ring 1302828 installation paste
94742	127mm		**DS11**
111269	1 312 934		**D11, DS11, DS14**
50826			DS 11

https://truckmanualshub.com/

Cylinder liner sealing ring kit

dph-no.	OEM-no.		application
95842			DS 8
61340	CLS934S		**D11, DN11, DS11, DSC11, DSI11, DTC11** Early version with 3 o-rings Contents: 3 o-rings 1312934 installation paste
95099	DS14 8Zyl		**DS14** Contents: 16x 1 312 934, 8x 1 302 828, 8 cylinder/dia 127, 1975-1979 L, LS, LB, LBS140, L, LS141, LB, LBS, LBT141, LT146 D14, CR, BR145 **DS14/DSC14** 8 cylinder/dia 127, 1981-1988 R142, 1980-1988 T142, 1988- R143, 1990- R143 HK, 1988- T143
98210	DS11/DSC11		**DS11/DSC11** Contents: 3x 1 312 934 1x 148,10x153,7x 0,3 FL

Cylinder liner sealing ring

dph-no.	OEM-no.		application
4212 **32970**	1 312 934/ 323 641/ 177 587		**D11, DS11, DS14** Size: 140x4 green FPM
36769 **36090**	1 302 828 (170 951) 342 989		**D 14, DS 14, DSC 14** **DS 11** **DSC 11** 8 pcs.required
32971	323 662 323 661		Size: 128x4 green FPM **D 8** **DS 8** **DS 9** **DSC 9** **DSI 8** 18 pcs.required

https://truckmanualshub.com/

Gasket set complete engine overhaul incl. cylinder liner rings

dph-no.	OEM-no.		application
95242	551 459 551 516		**DN11** up to motor 5258563 **DS11** up to motor 5307928SSS **DSC11** up to motor 4070105SN 6 cylinder, from 1980 G, P, R, T112
95241	551 449		**DN9, DS9, DSC9** 6 cylinder, from 1984 G, P, 82 F, G, P, R, T92/93, K93
82869	551 470		**DS14, DSC14** 8 cylinder, from 1980 R, T142/143
97486	551 430		**D11, DS11** 6 cyl. Dia 127 1975-1979 L, LB, LS, LT, LBS, LBT111
111410	551 519		**DS11** **DSC11** from engine 5307929 until year 12/1987

Valve cover gasket

dph-no.	OEM-no.		application
61109	258 459-7 131 039		**D11, DS11** 6 cyl. Dia 127, 1974 L, LS, LT, LB, LBS110 1975-1979 L, LS, LT111, LB, LBS, LBT111 **DN11, DS11, DSC11** up to motor 5258563 **DS, DSC11** up to motor 5307928 SSS, G112, P112 1980-1987 R112 1981-, T112 1980- -1973 L76, L, LS, LB, LBS110
94530 **32906**	1 305 959/ 170 610		**D14, DS14, DSC14, DSI14**

https://truckmanualshub.com/

Valve cover gasket

dph-no.	OEM-no.		application
80777 **22995**	378 299/ 344 426		**DN9, DS9, DSC9** 6 cylinder dia 115
70476	258 458 131 571		**DN8, DS8, DSI8, D8** 6 cylinder dia 115
70504	371 483		
104470	1 367 027		**DSC12 Diesel** Lower gasket up to engine 6119599
104471	1 367 028		**DSC12 Diesel** Upper gasket up to engine 6119599
110342	1 401 984		**DSC 12** Upper gasket up to engine 6119599

https://truckmanualshub.com/

Valve cover gasket

dph-no.	OEM-no.		application
109728	1 411 851		Upper gasket **DC11** **DC12** **DT12**
109729	1 414 422		Upper gasket **DSC12**
109730	1 476 506 1 401 982		Lower gasket **DC11** **DC12** **DSC12** **DT12**

Oil pan gasket

dph-no.	OEM-no.		application
68593 **80016**	371 503/ 215 242-9		**DN11, DS11, DSC11, D11, DSI11**
68592	371 505/ 170 700-9 1 459 004		**DS14, DSC14**
70494	366 539 1 412 666		**DN9, DS9, DSC9**
111447	1 460 359		**DC11** **DC12** **DSC12** **DT12**

https://truckmanualshub.com/

Oil pan gasket kit

dph-no.	OEM-no.		application
96430	551 446		**D8, DS8, DN8, DSI8** 6 cylinder dia 115
97485	551 466		**D11, DS11, DSC11**
82873	551 451		**DN9, DS9, DSC9**

Manifold gasket

dph-no.	OEM-no.		application
70519	371 510		**D14, DS14, DSC14** L, LB, LS, LBS14/141 LBT141, LT146, BR, CR145 R, T142/143
70503	369 276		**DS14** L, LS, LB, LBS140, L, LS141, LB, LBS, LBT141, LT146 **D14** CR, BR145 1975-1979, 8 cylinder, 14190 ccm Exhaust manifold 8 pcs required
70489	364 791		**DN9, DS9, DSC9** G, P82 F, G, P, R, T92/93, K93 G, P82 F, G, P, R, T, 92/93, K93
70490	364 792		**DN9, DS9, DSC9** G, P82 F, G, P, R, T92/93, K93 G, P82 F,G,P,R,T, 92/93, K93

https://truckmanualshub.com/

Manifold gasket

dph-no.	OEM-no.		application
70496	366 547		**DN9, DS9, DSC9** G, P82 F, G, P, R, T92/93, K93 G, P82 F, G, P, R, T, 92/93, K93 INTAKE
70435	1 301 628		**DS11, DSC11** 6 cylinder from 1980 from motor 5307929SSS from motor 4070105SN K, P, R, T113
70436	1 301 629		**DS11, DSC11** 6 cylinder from 1980 from motor 5307929SSS from motor 4070105SN K, P, R, T113
70434	1 109 288 318 415		1,4 mm thickness application: right T113, R113 **DS 11, DSC 11** from engine 5307929 EXHAUST
97659	385 997/ 277 272		**D11, DN 11** **DN 8** **DS 11** EXHAUST
95844 **70479**	385 998/ 277 273		**DS-DSI11, DN11, DSC11** 6 cylinder, L76, L, LB, LS, LBS110, up to year –1974 L, LB, LS, LT, LBS, LBT111 year 1975-1979, G, P, R, T112 up to motor 5258563 – DN11 up to motor 5307928SSS – DS11 up to motor 4070104SN – DSC11 from year 1980 EXHAUST
68534	393 820 1 384 552		INTAKE **DN-DS-DSI11**

https://truckmanualshub.com/

Manifold gasket

dph-no.	OEM-no.		application
68531	357 363		INTAKE **DN-DS-DSC11**
70521	378 264		**DS11, 6 cylinder** **DS11:** from motor: 5307929SSS **DSC11:** from motor: 4070105SN K, P, R, T113, year 1980- EXHAUST
70515	371 499		
111568	1 516 474 1 516 145 1 404 306 1 374 340 1 374 338		INTAKE **DC 11** **DC 12** **DSC 12** **DT 12**

Gasket flywheel/gear housing

dph-no.	OEM-no.		application
70506	371 487		Fly wheel housing; T112/113, G-P-R112; P-R113
70432	1 101 276		Gear housing **DN-DS DSI-DSC11**
70524	385 022		Gear housing **DN-DS-DSI-DSC11**

https://truckmanualshub.com/

Gaskets flywheel/gear housing

dph-no.	OEM-no.		application
70505	371 486/ 1 388 683		

https://truckmanualshub.com/

Oil seal – engine

dph-no.	OEM-no.	application
70457	170 761	Size: 25x47x10 NBR A blue L, LS, LT, LB, LBS, LBT140/141; T142/143; R142 (M, H, E)/143
82871	1 109 869	Size: 30x47x10/7 ACM ASW WD **DS14, DSC14, DSC14**
95648	378 480	Size: 70x85x8 NBR BS WD blue
82323	132 672	Size: 35x58x10 NBR A **D10, D11, DS11** L75, L76LS, LKS101
84537	310 951/ 1 109 870	Size: 35x62x7 ACM ASW F WD injection pump K-92/112 N-112, P-82/92/93/112/113 R-92/112/113/142/143, T-82/92/112/142
70547	837 613	Size: 22x32x8 NBR AS

https://truckmanualshub.com/

Oil seal – engine

dph-no.	OEM-no.	application
95457	1 345 278	Size: 44,45x60x7 BS SP NBR blue
95458	1 349 089	Size: 38,1x50x6,8 NBR AS W SP blue
70450	139 023	Size: 30x47x10 NBR A **D10, D11, DS11 8 cyl.:** LK, LKS, LKT141 Water pump
70451	14 107	Size: 50x70x10 NBR A
70455	170 226	Size: 42x72x8 ACM AS WD **D10, D11, DS11 8 cyl.:** R142, LK, LKS, LKT141
70465	192 600	Size: 25x35x7 AS NBR blue **D10, D11, DS11 8 cyl** R112 (112M, H, E), T112 (112M/H/E) Injection pump
95850	210 648	Size: 17x28x7 NBR AS
81457	202 288	Size: 42x62x6 AS W blue
84543	280 759	Size: 30x42x6/6,8 BABSL WD NBR blue **DN11, DS11, DSC11 6L:** G112, P112, R112, T112 `80->** **DS9 6L:** G93, P93, R93 4x2; 6x2, 6x4 `86->** **DS11, DSC11:** K113 CLB Bus `91->** **DS14 V8:** L141, LB141, LS141; LBS141, LBT141, R142, T142 `80->, R143L-R4x2; 6x2-6x2/4; 8x2, 8x4 `88->** **DS11, DSC11 6L:** P113, R113 4x2, 6x2, 6x4 `88->** Injection pump

https://truckmanualshub.com/

Washer – engine



dph-no.	OEM-no.	application
70460	178 562	Size: 10x13,5x1 CU
70534	812 412	
70463	182 524	Size: 24x29x2 CU
70466	192 633	Size: 14x20x1,5 CU
70482	303 098	
70464	192 081	Size: 12x15,5x1,5 ALU
70467	192 651	Size: 16x20x1,5 CU
70537	812 415	
70468	192 820-9	Size: 6x10x1 CU
70469	204 466	Size: 10x14x1 CU

https://truckmanualshub.com/

Washer – engine

dph-no.	OEM-no.	application
70471 **70535**	209 770 812 413	Size: 12x15,5x1,5 CU
70472	211 077	Size: 5x9x1 CU
70487	330 323	Size: 6x12x1 CU
70488	35 528	Size: 8x12x1 ALU
98692 **70544**	353 173 812 424	(screw, oil level) DS-DSI-DSC14 Size: 36x42x2 AL U
70491	365 375	Size: 20x26x1,5 CU
70533 **70470**	812 411 209 261	Size: 8x11,5x1 CU
70536	812 414	Size: 14x18x1,5 CU
70316	812 416	Size: 18x22x1,5 CU
70538	812 417	Size: 20x24x1,5 CU
70539	812 418	Size: 22x27x1,5 CU

https://truckmanualshub.com/

Washer – engine

dph-no.	OEM-no.	application
70540	812 419	Size: 24x29x2 CU
70317	812 420	Size: 26x31x2 CU
70545	812 425	Size: 38x44x2 CU
70454	165 507	Size: 17 x 22 x 1,5 CU
70541	812 421	Size: 28 x 33 x 2 CU
70543	812 423	Size: 32 x 38 x 2 CU
70546	812 426	Size: 45 x 52 x 2 CU

https://truckmanualshub.com/

O-ring/seal ring – engine



dph-no.	OEM-no.	application
69231	323 451	Size: 98,02x3,53 FPM LB82, LB-LBS86, L-LS-LT111, LB-LBS-LBT111, T112/113, G-P-R92/93, G-P-R112, P-R113
3891	372 985	Size: 132,94x3,53 **DN-DS-DSI8** **DN-DS9** **DN-DS-DSI-DSC11** **DS-DSI-DSC14**
3890 **34620**	372 984/ 290 534	Size: 111x3,5 NBR **DN-DS-DSI8, DN-DS9** **DN-DS-DSI-DSC11** **DS-DSI-DSC14** For oil filter housing
80590	381 083	Size: 48x6 NBR
4143	383 917	Size: 11x4 NBR For injection
98026	392 088	Size: 12x2 NBR
94385	804 655	Size: 9,3x2,4 FPM Model 94C Motorcode DCC9.12 For valve lid screw

https://truckmanualshub.com/

O-ring/seal ring – engine

dph-no.	OEM-no.	application
95693	804 660	Size: 19x3 NBR
95695	804 664	Size: 29x3 NBR
97291	804 713	Size: 70x3 NBR
95694	810 958	Size: 11,3x2,4 NBR
93835	392 652	Size: 90x3 MVQ red (intake manifold) T92/112/142/113/143, G-P-R92/112/93, P-R113, R143
80236	1 107 097	Size: 29,1x1,6 FPM green
80411	1 107 098	Size: 45,8x1,6 FPM green
98262	804 666	Size: 21x3 NBR
97292	804 674	Size: 59,2x5,7 NBR
95991	804 710	Size: 54,5x3 NBR
32997	811 926	Size: 26,2x3 NBR

https://truckmanualshub.com/

O-ring/seal ring – engine

dph-no.	OEM-no.	application
93594	811 942	Size: 60x3 FPM
70532	811 038	Size: 49,5x3
94357	392 653	Size: 22,1x1,6 MVQ
80404	1 302 243	Size: 108x3 MVQ
98260	1 303 789	Size: 34,2x3 NBR
98261	1 315 437	Size: 22x28x5 type 43
97290	1 334 294	O-ring kit 4x19,10x1,6 NBR 1x12,10x1,6 NBR 2x8,13x1,78 NBR
98264	1 349 018	Size: 99,2x5,7 FPM green
32999	174 229	Size: 79,5x3 FPM
81970	276 587	Size: 100x6,5 NBR
97479	321 992	Size: 106x3 FPM

https://truckmanualshub.com/

O-ring/seal ring – engine

dph-no.	OEM-no.	application
93836	211 813	Size: 107,54x3,53 NBR
80746	321 991	Size: 99,5x3 FPM green
80747	349 353	Size: 79,2x5,7 FPM green
80408	361 523	Size: 59,2x5,7 MVQ
80406	361 526	Size: 94,1x5,7 MVQ
34432	362 128	Size: 114,5x3 MVQ
94386	362 129	Size: 149,2x5,7 MVQ
93808	1 380 834	Size: 252x6 FPM
84526	257 737	Gasket

O-ring kit – engine

dph-no.	OEM-no.		application
111565	1 422 564 1 398 810		**DC 16** 1 pc. 34x3 FPM purple 1 pc. 24,3x2,4 NBR blue 1 pc. 32x2,5 NBR

https://truckmanualshub.com/

Gasket

dph-no.	OEM-no.		application
68533	384 464		
97850	1 302 556		
36768	1 302 827		6 pcs required **DN9, DS9, DSC9** 6 cylinder, from 1984 G82, P82, G92, P92, R92, T92, P92HK, F92H, K92, G93, P93, P93HK, P93MK, R93, T93, T93HK, F93H, K93
70508	371 491		(filling flange) **DN-DS-DSI-DSC11** **DS-DSI-DSC14**
80215	391 766		
84528	1 305 595		Size: 18,6x1,9 FPM
70529	388 422		

https://truckmanualshub.com/

Gasket

dph-no.	OEM-no.		application
70507	371 490		**DN-DS9** **DN-DS-DSI-DSC11** **DS-DSI14**
70443	1 350 378		
70444	1 350 379		
70445	1 350 380		
70501	366 557		

Gasket seal – engine

dph-no.	OEM-no.		application
70502	369 229		

https://truckmanualshub.com/

Gasket seal – engine

dph-no.	OEM-no.		application
70314	371 492		Application: oil cooler
70509	371 493		
70518	371 502		
68532	371 507		
95868	315 270		V-ring NBR A50 V-45
95647	317 916		U-ring type 90 16x22x6
84529	1 305 596		

https://truckmanualshub.com/

Gasket seal – engine

dph-no.	OEM-no.		application
84530	1 305 597		
97849	1 305 673		
84527	332 448		
4147	348 339		
34434	230 297		Material: rubber
104348	1 304 293		
111443	1 374 326		

https://truckmanualshub.com/

Gasket seal – engine

dph-no.	OEM-no.	application	
111445	1 374 327		
111442	1 374 334		
111446	1 374 344 1 541 633		Water pump **DC 11** **DC 12** **DSC 12** **DT 12**
111444	1 375 383		Oil cooler
95969	1 388 678		
111440	1 403 129		Oil pump
111231	1 675 602		
111441	1 423 290 1 384 004		

https://truckmanualshub.com/

Oil seal for hubs and wheels

dph-no.	OEM-no.		application
61645	300 278		Front axle **AM55/60** Size: 110x140x12/21 NBR special K-92/112 N-112 P-82/92/93/112/113 R-92/112/113/142/143 T-82/92/112/142
61651	375 087		**AM56** Size: 110x140x15 NBR ASW spezial
34423	173 320		**AS60, ASA60/70** Size: 117,47x142,87x12,7 NBR A blue K-92/112 N-112 P-82/92/93/112/113 R-92/112/113/142/143 T-82/92/112/142
70447	121 257		**RP652, R653** Size: 136,52x161,92x12,7 NBR A
98517	309 113		Reductor hub Size: 161,92x187,32x12,7 NBR A K-92/112 N-112 P-82/92/93/112/113 R-92/112/113/142/143 T-82/92/112/142
50177	370 076		Rear axle **AD/AS90, AD85** Size: 145x170x15/20 NBR B spezial K-92/112 N-112 P-82/92/93/112/113 R-92/112/113/142/143 T-82/92/112/142
34422	159 496		**AD90** (brake shoe: 203 mm) Size: 150,8x177,8x12,7 NBR AS blue

https://truckmanualshub.com/

Oil seal for hubs and wheels

dph-no.	OEM-no.		application
50176	370 075		**AD100** shaft RB/RBP803 Size: 155x180x24/29 FPM B spezial K-92/112 N-112 P-82/92/93/112/113 R-92/112/113/142/143 T-82/92/112/142
61641	120 310		**AD/AS90** Rubber cork Size: 158x170x5,3
61649	375 086		**AM56/61/70** Size: 125x160x15 NBR AS W

Oil seal – crankshaft

dph-no.	OEM-no.		application
111452 **111453**	1 375 002 1 433 183		Size: 145 x 175 x 13 special Crankshaft rear **DC 11** **DC 12** **DT 12**
111285	369 477		Size: 80 x 100 x 13 special
111272	369 478		Size: 130 x 160 x 15 FPM AW/BS LD Crankshaft rear **DS9** **DS11, DN11, DSC11** **DS14** **DSC14**

https://truckmanualshub.com/

O-ring/hubs and wheels

dph-no.	OEM-no.		application
80851	392 309/ 298 021		**AD100** Size: 249,2x5,7 T142, R142, T93/113/143, G-P-R93, P-R113, R143

Repair kit/compressor (engine)

dph-no.	OEM-no.		application
81677	1 108 223		Compressor 15,5 W
81716	278 198		Compressor 15,5 W
82835	1 103 236		Compressor 15,5 W

Repair kit

dph-no.	OEM-no.		application
81715/ **82817**	1 108 228/ 300 162		15,5 compressor Bendix
82836	1 327 886		15,5 compressor Bendix

https://truckmanualshub.com/

Repair kit

dph-no.	OEM-no.		application
82837	141 964		Bendix Tuflo 500
81725	229 373		Inlet exhaust valve kit
81714	282 501		Trailer control valve kit
81717	282 799		D2 governor kit
70814	309 164-2		For same type as 272 760-0
81718	313 004		Hand control valve kit

https://truckmanualshub.com/

Repair kit

dph-no.	OEM-no.		application
81719	319 477		Trailer dump valve kit
82816	293 546		

Cylinder liner shim

dph-no.	OEM-no.		application
33008	1 114 036		**DS11/DSC1101** For cylinder liner 1114035 Late production

O-ring/fuel system

dph-no.	OEM-no.		application
93837	242 857		Size: 60x4 NBR **All models**
98656	252 496		Size: 14x18x1,5 CU **All models**
98658	192 871		Size: 16x20x1 CU **All models**

https://truckmanualshub.com/

O-ring/fuel system

dph-no.	OEM-no.		application
21255	170 424		Size: 9,6x19,7x2 CU **All models**

Seal ring/cooling system

dph-no.	OEM-no.		application
32990	170 205		For: Thermostat Scania 251 899 and 255 502
70315	291 826		L-LS-LT111, LB-LBS-LBT111, T112/113, G-P-R112, P-R113

https://truckmanualshub.com/

Rubber cushions for engine, exhaust systems and gearbox

Oil seal

dph-no.	OEM-no.		application
70525	386 901		Transmission, mechanical Size: 85x105x13 NBR BS blue
70484	32 201		Transmission, mechanical Size: 35x52x10 NBR A
70475	254 635		Transmission, mechanical Size: 25x35x7 NBR B dph
96716	1 318 388		Input gearbox Size: 55x75x9 FPM BS RD **Engine DS11, DSC11:** K113 CLB Bus '91->**Engine DSC14 V8:** R143L-R4x2, 6x2-6x2/4; 8x2, 6x4; 8x4 '88->, 144L '95->**DSC12:** 124C'96->**DSC9:** 94G '96->,
84541	294 275		Size: 75x90x10/11 blue **DSC12:** 124C '96 ->, **DCS14:** 144L '95->**DSC9:** 94G '96->**DSC9 6L:** G93, P93, R93 6x4 `86->, G82, P82 `86->**DN11, DS11, DSC11 6L:** G112, 112, R112, T112 `80->, P113, R113 4x2; 6x2, 6x4 `88->**DS14 V8:** L141, LB141, LS141, LBS141; LBT141, R142, T142 `80-> R143L-R, 4x2; 6x2-6x2/4, 8x2 `88->
81460	329 638		Size: 25x35x7 BABSL NBR For gearshift shaft

https://truckmanualshub.com/

Gasket

dph-no.	OEM-no.		application
70495	366 546		
70514	371 498		
96313	1 392 936/ 371 500		Application: water pump
97851/ **97852**	1 305 139/ 1 329 585		
70442	1 320 298		

https://truckmanualshub.com/

Clutch, gearbox

Clutch servo cylinder

dph-no.	OEM-no.		application
81422/ 81092	345 362/ 550 720		(Wabco); GR871 (no. 6337157-6339120), interchangable with Scania 371 612 T112/T113/T142/T143; G-P-R112; R142, P-R113, R143
81524	360 717		T82, T92, T112; G-P82, G-P-R92/112
81525 81803	371 612/ 1 331 770		T82, T92, T93, T112, T113, T140; G-P82, G-P-R92/93/112; P-R113, R143

Repair kit clutch servo

dph-no.	OEM-no.		application
81723	550 422		For: 360 717 (old version)
81463	550 453		For: 360 717 (new version)
81724 51926	550 455/6/ 1 336 159		For: 371 612

https://truckmanualshub.com/

O-ring/gearbox control

dph-no.	OEM-no.		application
32996	244 446		For: control cylinder 284 015 **All models** Size: 41,2x3 NBR
93838	804 662		For: control cylinder 284 015 T82/92/93/112/113/142/143, G-P82, G-P-R92/92/112, P-R113, R142/143 Size: 24x3 NBR
96197	194 414		Size: 199,3x3 NBR For gearbox G770, GS770, GH774, GS771, GS772, GR871, GR-E871, GR-H880
81720	810 983		For: control cylinder 284 015 **All models** Size: 79,2x5,7 NBR

Oil seal/gearbox

dph-no.	OEM-no.		application
81462 **70483**	388 528/ 314 063-9		Size: 45x65x10/8 FPM A/BS LD Size: 45x65x9 ACM BS RD LA For gearbox G770, GS770, GH774, GS771, GS772, GR871, GR-E871, GR-H880

https://truckmanualshub.com/

Brake parts

Brake part front-/rear wheel brake

dph-no.	OEM-no.		application
3892	810 970		Size: 33x3 NBR, **all models**, Quantity required: 8 L/LB, 80H, L/LB81, 81H, F/G/K/P/S/T82, BR/CR/L/LBS/LS85, 85H, B/BF/BR/L/LB/LBS/LS86, F/G/K/P/R/T92, F/G/K/R/P/T93, BR/CR/L/LB/LBS/LB/LS/LT110, 110H, B/BF/BR/CR/L/LB/LBS/LBT/LK/LKT/LS/LT111, 111H, SBA/SBAT111, BF/BR/CN/F/G/K/MTR/N/P/R/S/T112, BN/CN/F/K/L/N/P/R/T113, BR116, L/LB/LBS/LBT/LS140, 140H, L/LB/LBS/LBT/LKT/LS141, 141H, R/T142, R/T143, BR/CR/LT145, LT146
3889	182 930		Size: 31x4,5 NBR, **all models**, Quantity required: 8 L/LB, 80H, L/LB81, 81H, F/G/K/P/S/T82, BR/CR/L/LBS/LS85, 85H, B/BF/BR/L/LB/LBS/LS86, F/G/K/P/R/T92, F/G/K/R/P/T93, BR/CR/L/LB/LBS/LB/LS/LT110, 110H, B/BF/BR/CR/L/LB/LBS/LBT/LK/LKT/LS/LT111, 111H, SBA/SBAT111, BF/BR/CN/F/G/K/MTR/N/P/R/S/T112, BN/CN/F/K/L/N/P/R/T113, BR116, L/LB/LBS/LBT/LS140, 140H, L/LB/LBS/LBT/LKT/LS141, 141H, R/T142, R/T143, BR/CR/LT145, LT146
69284	123 102		Size: 38x50x7 NBR A **all models** Quantity required: 4
68810	120 828		Size: 45x60x7 NBR A blue **all models** Quantity required: 4
34425	214 008		Size: 90x110x14 BS NBR blue Differential, assembly K-92/112 N-112 P-82/92/93/112/113 R-92/112/113/142/143 T-82/92/112/142
69230	1 338 019/ 381 962		Size: 31x4,5 MVQ G93, P93, R93, T93 K93CLB from chassis no. 1820107-, K113TLA from chassis no. 1820107-, N113CLL/CRL, N113ALLB/CLB/CRB/DRB from chassis no. 1820118-, L113TRB, P113, R113, T113, R143, T143

https://truckmanualshub.com/

Brake part/front-/rear wheel brake

dph-no.	OEM-no.		application
104111	1 338 018/ 1 307 340		For brake shoe roller 154259 Size: 32,5x3 mm

Valve lifter

dph-no.	OEM-no.		application
51307	1 116 635/ 1 103 422		**D8, DN8, DS8, DSI8, D11, DN11, DS11, DSC11, DSI11, DTC1101, D14, DS14, DSC14, DSI14** P113, R113, T113, R143

Valve guide

dph-no.	OEM-no.		application
61147	300957		INTAKE **DS8/DSI8 late production, DN9, DS9, DSC9, D11, DN11, DS11, DSC11, DSI11, D14, DS14, DSC14** Not for cyl. heads ref. 300612-7. 397775-8 Not for engines with catalytic converter
61148	300958		EXHAUST **D8, DN8, DS8, DSI8, DN9, DSC9, D11, DN11, DS11, DSC11, DSI11, D14, DS14, DSC14** Not for cyl heads ref. 300612-7, 397775-8 Not for engines with catalytic converter

Valve intake

dph-no.	OEM-no.		application
61144	272 804		INTAKE **DS11, L-LS-LT111, LB-LBS-LBT111**
93994	270 247		INTAKE **DS-DSI14, L-LS141, LT146, LB-LBS-LBT141**

https://truckmanualshub.com/

Valve intake

dph-no.	OEM-no.		application
98678	294 674/ 136 083-6		INTAKE **DS11-turbo, DN14, DCS14-turbo**
93995	215 715		INTAKE **Engine D420**
98681	272 803/ 1 361 189		INTAKE **D10**
98679	1 319 081		INTAKE **DS9-turbo, DSC9-turbo**
110771	1 360 836		INTAKE
110773	1 361 190		INTAKE

https://truckmanualshub.com/

Valve exhaust

dph-no.	OEM-no.		application
61145	232 018		EXHAUST **DN-DS-DSI-DSC11** **DS-DSI14 (- motor 5530537)**
98680	366 256/ 1 360 833		EXHAUST **DS9-turbo, DSC9-turbo**
110772	1 361 195		EXHAUST **DS9-turbo, DSC9-turbo**
98682	243 477/ 1 361 197		EXHAUST **D10, DN14**
98683	352 347/ 1 360 834		EXHAUST **DCS14-turbo**
93996	168 843/ 136 119-5		EXHAUST **Engine D440**

Valve seal ring

dph-no.	OEM-no.		application
93997	17 115		**Engine D420** 5650 ccm 66 kW (90 PS)

https://truckmanualshub.com/

Valve seal ring

dph-no.	OEM-no.		application
93998	17 543		**Engine D440** 6230 ccm 73 kW (100 PS)
61149	289 517		INTAKE **DN11/DS11/DSC11** engine no. 5220094-, **DS14/DSC14/DSI14** engine no. 5504736-
61151	242 672		EXHAUST **D11/DN11/DS11/DSC11** engine no. –3075634, -4070104-. 5307760-, **DS14/DSC14/DSI14** engine no. –5530537 Not for cylinder hea ref. 163588

Repair kit/brake valve

dph-no.	OEM-no.		application
81682	319 475		For: Scania 290 013
82819	313 114		For: Scania 290020 foot brake valve = G-P-82, G-P-R92, 112, R142, T82/92/112/142 T92/112/142/93/113/143 T92/93/112/113/142/143

https://truckmanualshub.com/

Diaphragm/Brake part

dph-no.	OEM-no.		application
69213	203 670		T9, dia 130
69215	171 566		T12, dia 140
69217	160 342		T16, dia 150
69218	151 476		T20, dia 165
69219	143 112		T24, dia 180
69220	143 113		T30, dia 200
69223	143 118		T36, dia 230

https://truckmanualshub.com/

Repair kit air dryer drain valve

dph-no.	OEM-no.		application
82818	309164		For Bendix air dryers

Gasket for oil filter

dph-no.	OEM-no.		application
69816	382 361-4		For oil filter 382353-1 (not in our range)

Oil seal

dph-no.	OEM-no.		application
96311	1 345 279		Size: 44,5x58x7,5 SPNBR blue For brake shoe shaft

Oil seal brake part

dph-no.	OEM-no.		application
109531	1 100 645	Size: 54,1 x 70/74 x 7,5/11 NBR	
109530	1 343 372		Size: 45 x 60 x 7 NBR A blau Steering knuckle pin
109529	1 395 999		Size: 56x72x7 NBR SP A Steering knuckle pin
112266	1 409 889	Size: 142 x 170 x 15/16 NBR Wheel hub, inside	
112282	1 409 890	Size: 75 x 100 x 10/13 NBR Wheel hub, outside	

https://truckmanualshub.com/

Oil seal brake part

dph-no.	OEM-no.		application
111330 **111372**	1 502 384		Size: 84,93x104,77x18,26 FPM/ACM spezial 85x105x18 FPM SP LD
70486	33 326		Size: 70 x 100 x 12 A NBR blau
109532	347 468	Size: 56 x 70 x 6 NBR A SP	

https://truckmanualshub.com/

Front and rear axle parts, steering

O-ring/front axle

dph-no.	OEM-no.		application
94398	182 935		Upper AM55 Size: 49x7 NBR
81721	811 045		Lower AM56/61/70 AM800/820 Size: 84,5x3 NBR

Gasket bogie axle

dph-no.	OEM-no.		application
95869	204 750		Application: bogie axle L, LS, LT110, LB, LBS, LBT140H, L, LS, LT111, LB, LBS, LBT141, T112, T142, G82, P82, G112, P112, R112, R142, T93, G93, R93, T113, P113, R113, T143 2 pcs. required

Gasket for steering

dph-no.	OEM-no.		application
70437	1 305 341		For steering
70510	371 495		(For hydraulic pump 300130/571368)

https://truckmanualshub.com/

Oil seals front and rear axle, steering

dph-no.	OEM-no.	application
34421	338 643	DN8, DS8, DSI8, DSC8, DN9, DS9, DSI9, DSC9 DN11, DS11, DSI11, DSC11 DN14, DS14, DSI14, DSC14 Size: 80x100x12 FPM BS LA RD Front
70461	178 866	DN11, DS11, DSI11, DSC11 DN14, DS14, DSI14, DSC14 Size: 130x160x13 NBR B Rear
69285	366 303	DN9, DS9, T92/93/113/142/143; G-P-R92/93, P-R113; R143 Size: 130x160x15 MVQ AS W LD Rear
70527	386 967	Front axle Size: 72x105x13 NBR BS green
70485	32 898	Front Axle AM55 (1st series) size: 120,65x146,05x12,7 K-92/112, N-112 P-82/92/93/112/113 R-92/112/113/142/143 T-82/92/112/142
3888	33 352	Rear axle AD90 (ext.) size: 75x100x10 NBR A blue K-92/112, N-112 P-82/92/93/112/113 R-92/112/113/142/143 T-82/92/112/142
70481	297 991	Size: 137x161,92x15/12 BS WD SP LA Rear axle

https://truckmanualshub.com/

Oil seals front and rear axle, steering

dph-no.	OEM-no.	application
34428	231 938	Size: 130x160x15 MVQ AS W LD Engine, crankshaft rear K-92/112, N-112 P-82/92/93/112/113 R-92/112/113/142/143, T-82/92/112/142
61643	297 999	Size: 115x135x10 A SP blue Rear axle
70449	136 106	Size: 28x38x7 NBR A For steering
70473	211 337/ 216 608	Size: 25x35x8 AD NBR For steering
96111	1 363 673/ 1 303 673/	Rear axle AD85 Size: 145x170x14,5/18 FPM BS special K-92/112, N-112 P-82/92/93/112/113 R-92/112/113/142/143, T-82/92/112/142
70446	120 979/ 227 138/ 304 552	Front/rear axle Size: 80x100x10 A NBR green D10, D11, DS11 L75, L76LS, LKS101, L, LS110, L, LS, LT, LK111, R112 (112M,H,E) B75, B76, B110, B111, BR115, BR116
70452	144 116	Rear axle Size: 30x55x10 NBR A
34426	124 268/ 388 728	Rear axle Size: 80x100x13 BS NBR K-92/112, N-112, P-82/92/93/112/113, R-92/112/113/142/143 T-82/92/112/142 Also for transmission GR870/GR871T
61647	370 074	Size: 137x161, 92x15/20 NBR BS WD SP LA, Rear axle **AD80** outer/inner, K-92/112, N-112, P-82/92/93/112/113, R-92/112/113/142/143, T-82/92/112/142 **Engine DSC14** 144L `95-> **Engine DN11, DS11, DSC11 6L:** G112; P112; R112; T112 '80->, P113, R113 4x2; 6x2, 6x4 `88-> **Engine DS9 6L:** G93, P93, R93 4x2; 6x2; 6x4, G92, P82, `86-> **Engine D8, DS8 6L:** L86, LS86, LB86, LBS/LBT86, L81, LB81 `75-> **Engine DS14 V8:** R142, T142 `80->, R143L-R, 4x2, 6x2-6x2/4; 8x2, 8x4 `88->
110713	125 766	Size: 70x90x10 A LDNBR L75, L76 LS
98060	1 393 331	Size: 85x105x18 FPM LD SP Steering

https://truckmanualshub.com/

Oil seal front and rear axle, steering

dph-no.	OEM-no.	application
82497	1 363 674/ 130 934-2	Size: 158x188x14,5/18 FPM RWDR Kassette Wheel bearing, exterior **DSC12:** 124C `96->
93428	1 342 363	With Polrad
93430	1 334 535	Size: 125x150x14 NBR AS SO blue
84730	1 335 243	Crankshaft, front Size: 80x100x12 FPM BS LA RD **Engine DS11, DSC11, DN11:** K113 CLB Bus '91->, P113, R113 4x2; 6x2 '88-> 6L, P113, R113 6x4 '88->, G112, P112, R112, T112 '80->**Engine D11, DS11:** L110, LS110, LB110, LBS110 ,74->, L111, LB111, LS111 ,75->, LB111H, LBS111H, LBT111H '77->80, **engine D14, DS14:** L140, LB140, LS140, LBS140. LT146, R142, T142 '80->, BR145, CR145 **Engine D8, DS8, DN8. DSI8:** L86, LS86, LB86, LBS/LBT86, '75->, L81, LB81, '75->, L81, LB81, LBS85, G82, P82; T82 '80'> **Engine DS14 V8:** L141, LB141, LS141, LBS141, LBT141, R143L-R4x2, 6x2-6x2/4; 8x2 '88->**Engine DSC14 V8:** R143L-R, 6x4; 8x4 '88-> 144L '95->, **Engine DS9, DSC9 6L:** P92, R92, T92 '86->, G93, P93, R93 4x2; 6x2 '86->, G82, P82 '86->
34427	291 076	Rear axle, interior Size: 145x170x15/20 NBR B spezial **Engine DSC12** 124C`96->**Engine DSC14** 144L `95->**Engine DSC9** 94G `96->**Engine DSC9 6L:** G93, P93, R93 4x2; 6x2, 6x4, G82, P82 `86->, **Engine DN11, DS11, DSC11 6L:** G112, P112, R112, T112 `80->, P113, R113 4x2; 6x2; 6x4 `88->**Engine DN8, DS8, DSI8 6L:** G82, P82, T82 `80->**Engine DS11, DSC11:** K113CLB Bus `91->**D8, DS8 6L:** L86, LS86,k LB86, LBS/LBT86 `75->**Engine DS14 V8:** L141, LB141, LS141, LBS141, LBT141, R142, T142 `80>, R143L-R, 6x4; 8x4 `88->**Engine D11LB, DS11 6L:** LB111H, LBS111H, LBT111H `77->80

Oil seal rear axle

dph-no.	OEM-no.	application
111548	370 076	Size: 145 x 170 x 15/12 B special FPM

Oil seal differential bevel pinion

dph-no.	OEM-no.	application
95649 **111330**	1 383 129 1 502 384	Size: 84,93x104,77x18,26 FPM/ACM SP 1
98061	1 386 594	Size: 84,93x104,77x18,26 FPM/ACM SP 2

https://truckmanualshub.com/

Front and rear suspension parts

Shackle bushing

dph-no.	OEM-no.		application
70172	135 036		For shackle pins: 355147, 355149 Dia. 46x89, 2 pcs required REAR SPRING
70448	135 698		For shackle pin: 355148 Dia. 46x102, 4 pcs required REAR SPRING

O-ring for shackle pins

dph-no.	OEM-no.		application
61342	182 929		For shackle pins: 355145, 355146 Dia 23x6,5 mm NBR FRONT SPRING **All models**
61343	182 931		For shackle pins: 355147, 355148, 355149 Dia 31x6,5 mm NBR REAR SPRING **All models**

https://truckmanualshub.com/

Seal ring/wiper ring for gearbox

dph-no.	OEM-no.		application
81458	315 022		G-GS770, GH774, GR-GRE870/871 Size: 60x80x8,25 rubber/metal
95851	244 448		GS771/772; GR-GRE870/871 Size: 25x35x5/7 T112/R142 transmission

Vibration insulator (motor hood)

dph-no.	OEM-no.		application
81975	329 583		T82/92/112/142/93/113/143

Rubber bushing

dph-no.	OEM-no.		application
82302	137 207/ 332 738		Left & Right
81971	340 895		

https://truckmanualshub.com/

Hose

Hose

dph-no.	OEM-no.		application
81973	241 805		

https://truckmanualshub.com/

Overview of most popular oil seal types acc to DIN 3760/3761

Application	Description
A	rubber version with single lip
AS	rubber version with sealing and dust lip
AD	rubber version with 2 lips and 2 springs
AW	rubber version with sealing lip and corrugated profile
ASW	rubber version with sealing lip and dust lip and corrugated profile
 A/B	seal with combined elastomer/metal outer cover

Application	Description
 B	metal cased open
BS	metal cased open with dust lip
C	metal cased closed
CS	metal cased closed with dust lip
 BD	metal cased open with 2 lips
 A/BS	seal with combined elastomer/metal outer cover with dust lip

Abbreviations at „style“

FL Washer
PR Profile seal
OR O-Ring
WR Oil seal

Complimentary definitions

RD	Right hand helix
LD	Left hand helix
WD	Double helix
SF	Special design
OF	Without spring
V	Reinforced seal lip
LA	With sealant film
W	Corrugated profile
SP	Special

Abbreviations at „mat“ (material)

ACM	Polyacryl rubber
FPM	Fluor rubber (Viton)
MVQ	Silicone rubber
NBR	Nitril rubber
EPDM	Ethylen-Propylen-Dien-rubber
PTFE	Polyterafluoren-ethylen
HNBR	Hydrogenated NBR
AL	Aluminium
CU	Copper
FE	Iron
FZ	Felt

https://truckmanualshub.com/

Standard terms and conditions

Standard Terms and Conditions of Trade and Delivery, as established by Dichtungspartner Hamburg GmbH, Ferdinand-Harten-Str. 15, 22949 Ammersbek, Germany, hereafter referred to as "dph":

Application
The terms and conditions set out below form part of all contracts for services, supplies and quotations by dph. Sales shall be made solely on the basis of the terms and conditions below. Ancillary agreements and amendments shall only be deemed valid if in writing.

If our contracting partner has its own terms and conditions which differ from dph's terms and conditions, we shall only be bound by the aforementioned terms and conditions of the contracting partner if we specifically accepted them in writing on conclusion of the contract. We hereby specifically state that we shall not accept a counter-confirmation by the customer with reference to its own terms and conditions.

Quotations
All quotations are subject to change. We shall not be bound by any arrangements made orally, by telegraph or telephone until we have issued a written confirmation. Any details given in brochures, advertisements, etc., including prices, shall not be binding until specifically agreed in writing.

Prices
Our prices are given in euros (EUR) ex works and exclude German VAT. Prices exclude postage/delivery, packing and insurance.

Delivery
1. Prices are given ex works. Unless free delivery has been agreed, the purchaser shall bear the costs associated with dispatch/shipment. It shall also bear costs ex delivery destination. Freight refunds are not granted. The goods shall be insured only if the customer so requests in writing, and insurance shall be at the customer's expense.
2. Collection and dispatch of the goods ex works or distribution warehouse is in all cases at the customer's risk.
3. We reserve the right to charge a minimum-quantity flat rate or a minimum cost-contribution flat rate for small orders.
4. In the case of blanket/call orders, we are entitled to procure the material for the whole order and to manufacture the entire quantity ordered immediately. Any change requests by the customer cannot be accepted after the order has been placed, unless this was specifically agreed.

Payment
1. Our invoices are payable in euro (EUR).
2. Invoiced amounts are payable (free of dispatch costs and other expenses) within 14 days after invoice date less 2% discount, or within 30 days after invoice date without deduction. Default interest is payable at the rate of 8% above the base interest if payment is late.
3. Cheques shall be regarded as cash payments, provided they have been sent to us in sufficient time that they can be cashed within the above payment periods.
4. Only payments made at the place of performance have the effect of discharging obligations. Payments made to employees of our company shall only discharge obligations if such employees have the appropriate collecting power (Inkassovollmacht).
5. If it becomes apparent after conclusion of the contract that our claim to payment may be in jeopardy because the customer is not able to discharge its obligations, then any other debt claims we have shall become due and payable immediately. In this event, we are entitled to make any remaining deliveries subject to payment in cash or the provision of security. This will not affect any further legal claims.
6. The customer may only set off payments against counterclaims which we have accepted or which have the authority of a final court judgment. This also applies to the retention of payments.

Tools and equipment
Tools and equipment which we manufacture or engage a third party to manufacture shall be our property, even if our customer pays part of the manufacturing costs.

Packaging
Paper packaging shall be subject to the lowest-possible charge. Chests, crates, barrels, sacks and other types of packaging shall be invoiced and, if returned freight-paid and in good condition within 4 weeks after receipt of the delivery, a credit note will be issued for 2/3 of the amount charged.
In the event that a rail company classifies a delivery as inadequately packed, this may not be used against us.

Periods of delivery
1. The periods of delivery shall begin when all details of the order have been explained, however, not before the purchaser has fulfilled any contractual obligations which must be performed beforehand. The delivery date is deemed to have been met if the goods have left the warehouse by the end of such date or, if the delivery is delayed for reasons not attributable to us, on notification that the goods are ready for dispatch within the agreed period of delivery.
2. The delivery obligation is subject to the condition that dph has been supplied correctly and in due time by its suppliers.
3. Partial deliveries within the agreed time and quantities are permissible and may be invoiced separately.
4. If any acts of force majeure, industrial disputes or their consequences or other events which are outside the scope of our control delay the performance of our delivery obligation, regardless of whether they affect us or our sub-contractors, the period of delivery shall be extended by the length of such delay. Both parties shall have the right to cancel the contract if the delivery later becomes impossible or unreasonable for one of the parties due to an event of the above nature.
5. The purchaser is entitled to terminate the contract, in accordance with the legal provisions, in the event of delay or if delivery is impossible for reasons attributable to us. If the delivery is delayed and if the purchaser thereby suffers loss, it is entitled to demand a lump-sum amount as compensation for the delay. Such compensation shall be, for each full week of delay, 0.5% of the value of that portion of the total delivery which, as a result of the delay, cannot be used on time or in accordance with the contract, up to a maximum of 5% of such value.
6. If delivery is delayed at the purchaser's request, the purchaser shall be charged the costs of storage, commencing 2 weeks after notification that delivery is ready, subject to a minimum charge of 1% of the invoice amount for each week.

Tolerances
Any recommendations we give as to the use of our products are made to the best of our knowledge. The purchaser is at all times under an obligation to satisfy itself by means of its own enquiries that the goods delivered are suitable for the intended purpose. Deviations from samples and earlier deliveries are permissible if they do not affect quality and use. We reserve the right to deviations in quantity of ±10%.

Complaints and liability for defects
1. Immediately after receipt, the purchaser must inspect the goods and give written notification promptly, or no later than within 10 days after receipt, of any obvious visible defects, incorrect quantities or incorrect deliveries, specifying the defect. In the case of latent defects, it must do this within 10 days after discovery of the defect.
2. If there are defects, we guarantee as follows: We shall, at our discretion, replace free of charge or repair all parts which prove to be unusable or whose use is not inconsiderably affected as a result of circumstances existing before risk was transferred.

https://truckmanualshub.com/

3. The purchaser is entitled to rescission of the contract or to a reduction in price if we allow a reasonable extension of time for post-performance or repairs to elapse without resolving the defect, or if more than one attempt at post-performance or repair does not resolve the defect. If we deliver a defect-free item for the purpose of supplementary performance, or if the purchaser rescinds the contract, then it must pay value-related compensation for the benefit derived. The value of the benefit derived shall be determined by pro rata temporis straight-line depreciation in the ratio between the actual period of use and the estimated useful life.
4. The statutory limitation period of 2 years shall apply to notification of defects under Section 437 BGB (Bürgerliches Gesetzbuch – German Civil Code).
5. The provisions below under "General Liability" shall apply to liability to pay compensatory damages for liability for defects.

General liability

1. Without prejudice to the provisions under point 5 of "Periods for delivery", claims for damages of any kind in connection with and apart from liability for defects are excluded – for delay or impossibility, for breach of other contractual obligations, for mistakes on conclusion of the contract, for tort or for any other legal reason, in particular also for damages which do not occur to the items delivered themselves. There shall only be liability where there is intentional conduct, gross negligence, culpable injury to life, limb or health, defects which we have fraudulently concealed, on assumption of a warranty made regarding the existence of any specific feature or for defects in the items delivered, to the extent that there is liability under product liability laws for material damage to privately used items and for personal injury.
2. We shall also be liable for culpable breach of essential contractual obligations. However, provided there is no gross fault, such liability shall be limited to damage which is deemed typical as regards this type of contract and reasonably foreseeable.

Returns

Returns which are not based on a legal claim shall only be accepted, carriage paid, with our express written consent. As compensation for the costs incurred on any return, we shall retain from the credit note a corresponding reduction in the net invoiced value of the goods, subject to a minimum of 20% of the net invoiced value of the goods.

Reservation of title

1. The goods delivered shall remain our property until all outstanding amounts owed to us in connection with the business relationship, including incidental expenses, have been paid. If operating an open account, the property subject to the reservation of title shall be deemed to be security for our current account.
2. If our goods are combined or mixed with other goods which do not belong to us, we shall have joint ownership in the new object or the mixed item in proportion to the invoice value of the goods subject to the reservation of title compared with the value of the other combined or mixed goods at the time they were combined or mixed. If, as a result of combination, the purchaser acquires sole ownership in the new item, it hereby assigns to us joint ownership in the new item in proportion to the invoice value of our goods subject to the reservation of title compared with the value of the other combined goods remaining at the time they were combined, and shall keep such item in custody for us using the care of a prudent merchant.
3. Resale of the goods delivered, even if combined or mixed, is only permitted to resellers in the usual course of business and subject to the reservation of title and only if the debt claim arising from the resale is assigned to us. The purchaser may not pledge the goods as collateral nor transfer ownership therein by way of security, nor may it agree on a non-assignment clause. The purchaser must notify us immediately if there is any pledge or any other third-party action which may affect our rights.
4. The purchaser hereby assigns to us in advance any outstanding debts owed to it from the resale or for any other legal reason in respect of the goods we have supplied, both existing and arising in future as soon as they come into being. We accept such assignment. The value of the goods subject to the reservation of title shall be our invoice amount plus a security premium of 10% which shall however not apply if third-party rights present an obstacle to this. If our goods are resold after they have been combined or mixed with other goods, or if the new item which arises through combination is resold, the claim against the purchaser's customer will be assigned in the amount of the invoice value of our processed, combined or mixed item, or up to the amount which corresponds to our share in the joint property, if this is lower.
5. The purchaser is entitled to collect the debt claims assigned provided that it duly fulfils its payment obligations to us.
6. If the value of the security assigned to us exceeds our debt claims by more than 10% in total, we are under an obligation to release the securities of our choice upon request by the purchaser. Ownership in the goods subject to the reservation of title and the assigned debt claims shall pass to the customer on payment of all our debt claims in connection with the business relationship.

Property rights

If we have made our supplies in accordance with drawings, models, samples or other documents provided by the purchaser, the purchaser guarantees that third-party property rights are not breached. If a third party claims in such a case that we are breaching a property right, e.g. through the manufacture or supply of the goods, then we shall be entitled, without further inspection, to discontinue our activity subject to our other rights. The purchaser undertakes to notify us immediately if there are any risks of breach or alleged cases of breach as soon as they become known.

Place of performance, jurisdiction, applicable law, general

1. The place of performance for deliveries and payments is Ammersbek. The courts of Ahrensburg will have jurisdiction for any disputes with traders or with people who do not have a legal domicile within Germany – even in the cases involving bills of exchange and cheques We are also entitled, at our discretion, to bring an action against the purchaser before the courts which have jurisdiction in the place where the purchaser has its head office.
2. German law will apply to the contractual relationship. The provisions of UN sales of goods law will not apply.
3. The latest version of Incoterms 2000 will apply if clauses defined in the Incoterms are agreed.

Data storage

As required by Section 28 of the Bundesdatenschutzgesetzt (Federal Data Protection Act - BDSG), we draw attention to the fact that the data necessary for the purposes of our business will be processed and stored using data processing equipment in accordance with Section 33 of the BDSG. The purchaser agrees that we may use the data obtained from our business relationship with it, in accordance with data privacy provisions, only for our own business purposes.

Severability and concluding provision

If any individual provisions of these Terms and Conditions should be void, this shall not affect the validity of the remaining provisions. Any provision which is void will be replaced by a valid provision which comes as close as possible to the purpose sought by the void provision. This is an English translation of the original Standard Terms and Conditions. In the event of any conflict or inconsistency between the English translation and the German original, the German original shall prevail. Neither the Company nor the Language Professional can accept liability for any direct, indirect, special, consequential or other losses or damages arising out of erroneous translations. Only the German version shall be deemed authoritative

Date: June 2004

https://truckmanualshub.com/

Remarks

https://truckmanualshub.com/

We supply gaskets and other spare parts worldwide

D.E. SIEVERS DESIGN, Hamburg · Fotos: Walter Fey · Development: Alexandra Gilbert

Dichtungspartner Hamburg GmbH

Ferdinand-Harten-Straße 15
D-22949 Ammersbek
Germany

P.O. Box 651144
D-22371 Hamburg
Germany

Phone ++49 (0)40-66 86 13-0
Fax ++49 (0)40-66 86 13-90

E-mail service@dph.de
www.dph.de

Dichtungspartner Hamburg